

Operator Workstation

0	perator Workstation	3
	Introduction	
	Key Concepts	5
	Operator Workstation	5
	Theory of Operation	5
	Multiple Direct Connects	7
	Fire OWS	10
	Components	10
	Design Considerations: Configured or Non-configured Workstation	12
	Design Considerations: Direct or Dial-up Workstation	15
	OWS Installation	16
	Configure a Printer for the Metasys N1 System	23
	Configure the OWS for Printers	25
	Example of Five OWSs All Running on the Same Operating System a Three Printers	and 26
	Mixed Operating Systems	29
	Print Change-of-State (COS) Reports	29
	Print Reports and Summaries in Color	29
	General Modem Configuration	32
	Modem Wiring	
	Commissioning Overview	35
	Hardware Commissioning	
	Commissioning PMI New Project Software	37
	Commissioning PMI Software: Upgrading Existing Jobs	40
	Detailed Procedures	
	Commissioning a New OWS	
	Installing Software	
© 2	Installing Metasys Person-Machine Interface (PMI) Software	

2

Installing Metasys PMI Upgrade Software	43
Establishing a Connection to an N1 Network for the First Time with a Non-configured Workstation	i 44
Direct Connecting to N1 LAN - Ethernet Network	44
Direct Connecting to a Network Control Module (NCM)	45
Dial-up Connecting to an NCM - with Modem	45
Dial-up Connecting to an NCM - with Integrated Services Digital Network (ISDN)	46
Adding a Printer Supported by the Windows 2000 Professional Operating System	46
Adding an IBM Proprinter Printer for NCM Printing	47
Configuring the OWS for Printers	47
Fixing Line Feed Problems when Using a Serial Printer	50
Connecting and Configuring a Modem to an OWS	54
Connecting and Configuring a Modem to an NCM	56
Adding User-Defined Modems	56
Configuring ISDN Modems	57
Installing the Microsoft Backup Utility	59
Installing Metasys PMI New Project Software	61
Installing Metasys PMI Upgrade Software	63
Disabling the Parallel Port Check	66
Troubleshooting	67
Global Alarm Indicator Reset	67
Metasys N1 Ethernet Communication Problems After Any Metasys PMI Software	69
Windows 2000 Operating Systems	69

Operator Workstation

Introduction

The Operator Workstation (OWS) is an easy-to-use, high-level interface for the operator of a Metasys® Building Automation System (BAS). This document describes the OWS and how to:

- commission a new OWS
- install software
- install Metasys Person-Machine Interface (PMI) software
- install Metasys PMI upgrade software
- establish a connection to an N1 network for the first time with a non-configured workstation
- direct connect to N1 LAN Ethernet Network
- direct connect to a Network Control Module (NCM)
- dial-up connect to an NCM with modem
- dial-up connect to an NCM with Integrated Services Digital Network (ISDN)
- add a printer supported by the Windows® 2000 Professional operating system
- add an Lexmark[®] Proprinter[®] printer for NCM printing
- configure the OWS for printers
- fix line feed problems when using a serial printer
- connect and configure a modem to an OWS
- connect and configure a modem to an NCM
- add user-defined modems
- configure ISDN Modems
- install the Microsoft[®] Backup Utility
- install Metasys PMI new project software

- install Metasys PMI upgrade software
- disable the parallel port check

Use this document with the *Metasys Software Installation and Platform Requirements Technical Bulletin (LIT-12012)*, which contains hardware and software requirements and supported platforms.

This document may contain information about discontinued features or products. This information is for reference only. Beginning with Release 12.04, the following features or products are no longer supported:

- ARCNET® protocol
- Graphic Programming Language (GPL). Support for GPL ended at Release 12.03.
- Microsoft Windows 98 operating system
- Windows NT® operating system

Key Concepts

Operator Workstation

The Operator Workstation (OWS) is an easy-to-use, high-level interface for the operator of a BAS consisting of one or more N1 networks. With the workstation, the operator:

- monitors the facility
- controls the facility
- examines historical and current information about facility operations
- defines objects and features

Theory of Operation

The Metasys OWS hardware is a Personal Computer (PC) that consists of a system unit, color monitor, keyboard, mouse, and a Network Interface Card (NIC). A NIC, modem, and RS-232 allow the workstation to communicate with other nodes, such as other workstations and NCMs on the N1 Local Area Network (LAN).

The modem provides dial-up communication between the nodes from a remote location, and the RS-232 connection allows the workstation to communicate with an NCM directly.

The workstation runs several software packages that provide advanced BAS functions, including the Metasys PMI software, and Microsoft Windows operating system software. Optionally, the workstation may also have a printer.

For a list of supported platforms, refer to the *Metasys Software Installation and Platform Requirements Technical Bulletin* (*LIT-12012*).

Types

The OWS can be one of five types, depending on how you connect the workstation to the Metasys N1 network and whether the workstation is configured. The workstation can connect directly to the N1 LAN, to the NCM, or remotely connect to the NCM over telephone lines. Also, the workstation can be a configured device capable of all Metasys Network operations or a non-configured device capable of a limited set of Metasys Network operations. Figure 1 summarizes the five OWS types.



Figure 1: OWS Configuration Options

Modes

An OWS has two modes of operation: online and offline.

The **online mode** offers the operator the following functions:

- Basic Operator Control—Provides basic interaction with the BAS that consists of one or more N1 networks. The operator receives data, adjusts operating parameters, commands specific operations, reschedules events, and performs uploads and downloads.
- Automatic Data Output—Receives messages, warnings, alarms, and reports to a printer or a workstation display or file.
- Online Definition—Defines new objects, setup trends, totalizations, demand limiting, and other features.
- Dynamic Data Exchange—Provides the exchange of information between the Metasys Network and third-party Windows operating system applications with Metalink software. These applications can use Metasys system data from objects and attributes both historically (offline) and dynamically (online).
- PC Operation—Performs ordinary PC tasks and runs third-party software such as Microsoft Excel.
- NCSETUP for Windows operating system software—Configures the NCM.
- The **offline mode** offers the operator or application engineer the following functions:
 - Data Definition Language (DDL) Definition—Defines hardware and software components of a Metasys Network.
 - Graphic Programming Language (GPL) Definition—Defines software objects and creates control strategies for the NCM.

Multiple Direct Connects

The OWS can connect to multiple NCMs by way of its serial communication (COM) ports. This application benefits jobs with remote NCMs and a central OWS, where leased or dedicated lines are preferred. Multiple direct connections are useful, because you now only need one workstation to connect to multiple NCMs.

If your remote NCMs are in different time zones, use the time zone for the network to which you made the last connection. If several networks are connected and you change the time-of-day at one network, then only that network has its time updated.

Figure 2 shows an example of a multiple direct-connect workstation.

7



Figure 2: Multi-Direct OWS

As shown in Figure 2, up to four NCMs can connect to COM ports of the OWS. The actual number of NCMs that can connect directly to the workstation's COM ports depends on the type of PC. A group of NCMs on the N1 can connect from an NCM that is directly connected to the OWS.

Each directly connected NCM (or group of NCMs) is on a separate network, which means that each direct-connect network has an individual N1 global database. If you wish to have password access to all directly connected NCMs, you need to define your PMI password separately at each direct-connect network. You can log on to all directly connected N1 networks at the same time. (Use the Network Summary to switch between networks.) Each directly connected NCM can communicate directly with control modules installed next to it in the same NCM or with other NCMs on its remote N1 network.

Alarm messages can be broadcasted and acknowledged across N1 networks, even if the operator is not logged on the N1 network that is sending the message. For example, if you are logged on to Network A and a Change-of-State (COS) occurs at Network B, the report appears on the workstation. To act on this report, you do not need to log on to Network B, as long as you have password access to that network. The system performs the appropriate password checks internally.

Since each direct-connect N1 network has a separate global database, the direct-connect NCMs can share data between N1 or N2 devices on the same network. These NCMs cannot perform any of the tasks that are associated with Dynamic Data Access software (for example, obtaining the value of an object from a remote network). These types of tasks require the Metalink interface, a program included with the OWS software.

When the Facility Management System (FMS) Logon dialog box appears, a status window for each direct-connect network defined for this PC appears along the right side of the OWS screen (Figure 3). These direct-connect status windows show the:

- network name
- OWS COM port being used by the NCM
- status of the workstation
- communication speed of workstation to NCM connection

•	workstation as configured or non-configured

FM	S Logon	×	l	
	Select network:	ОК		
	HDQTRS	Cancel		
E	EAST-BLD HDQTRS NORTHBLD SOUTHBLD WEST-BLD	↑ →		Direct3 COM3 COM3 nnected @ 9600 baud nfigured Direct2 COM2 COM2
				AST-BLD COM1 onnected @ 9600 baud COM1 onnected @ 9600 baud onfigured
🙀 Start 🧕	🛿 Exploring - C:V	NC Direct4 -	SOUTHBLD	10:23

OWSLOG

Figure 3: Logon Dialog Box and Direct-Connect Status Windows

Direct-connect status windows can be minimized, in which case, they appear in the task bar at the bottom of the screen.

After you select an N1 network and enter your password, the Network Map appears for the chosen network. The direct-connect boxes remain displayed. They move to the background when you perform a task, such as displaying a summary.

A COS report from any directly connected NCM appears on the screen, even when no one is currently logged on. If your password allows, you may acknowledge the report without logging on; however, if you do not have password access, you can only acknowledge that you have read the report by selecting Look Later.

Editing DDL File for Multi-Direct Workstation

After you have installed the OWS and the PMI software, the last step for configuring an OWS that supports multiple NCM direct connections is to edit the workstation's Network/Port Configuration DDL file (@NET file). Specifically, add the PORT and NET statements for each multiple N1 network. Be sure to follow proper DDL syntax. Refer to the *DDL Programmer's Manual* for instructions and a file example.

Fire OWS

The Fire OWS is an Underwriters Laboratories Inc.® (UL) Listed OWS used for fire alarm reporting as part of the Metasys Intelligent Fire Network. Refer to the *Fire Operator Workstation (Fire OWS) Technical Bulletin (LIT-636014)* for more information.

Components

The OWS consists of hardware and software components recommended for the Metasys N1 network. For a list of supported vendor configurations, refer to the *Metasys Software Installation and Platform Requirements Technical Bulletin (LIT-12012).*

Hardware Components

The OWS consists of the following hardware components:

- Computer—Includes a system unit, monitor with display stand, keyboard, and mouse. The hard disk must have an absolute minimum of 500 Megabytes (MB) for loading the system (Windows operating system software, PMI, Graphic Programming Language [GPL], and a small database).
- Disk Drive—One 1.44 MB 3.5-inch floppy drive is required for loading (quick patches only) and backup purposes.
- CD-ROM Drive—A CD-ROM drive (4x or higher) is required for installing Metasys software.

• NIC—Card that is installed into the OWS and used to make the physical connection to the network. The type of card depends on whether you connect to an ARCNET or Ethernet network. In both cases, you must install and connect an NIC or the OWS cannot communicate on either network.

Note: If you configure the NCM to use an Ethernet connection, always install the Ethernet NIC in the NCM to prevent download failures.

- Serial Communications Board (optional)—Computer board that provides extra serial ports required for connecting one workstation to multiple networks. The serial board needed depends on the model of your PC. Refer to the *Metasys Software Installation and Platform Requirements Technical Bulletin (LIT-12012).*
- Additional Random Access Memory (RAM)— A minimum total of 128 MB of memory is required for Windows 2000 Professional operating system software and Windows XP Professional operating system software.
- Printer (optional)—An output device for printing Metasys system summaries and reports in black or color.
- Sound Blaster® Compatible Sound Board—Adds audio/tone sound to Metasys system operations for Change-of-State reporting to help differentiate among alarm levels and enable the use of multimedia technology. For Windows 2000 Professional operating system and Windows XP Professional operating system software, a soundboard is required. The operating systems do not provide support for the PC speaker.
- Modems (optional)—Enable dial-up or leased line connections between the OWS and the NCM. One modem is required at an NCM and another one is required at the workstation.
- An Integrated Services Digital Network (ISDN) application uses higher speed modems (optional). An ISDN modem is required at the NCM and another at the workstation.

The modems supported for use with Metasys software are listed in the Computer Price List (pcprices.doc) at *The Advisor* > *Business Focus* > *Purchasing* > *ePurchasing* > *CG Computer Purchasing*. These modems have been thoroughly tested. The baud rates of these modems vary, and the maximum baud rate used on the OWS depends on the dial-up NCM.

Refer to the *Network Control Module 300 Series Technical Bulletin* (*LIT-6360251*) for specific maximum baud rates.

The supported ISDN modem is the ADTRAN ISU Express. An RS-232 cable is used to connect the external modems to the OWS or NCM.

Software Components

The OWS consists of the following software components:

- Metasys PMI Software—Programs that provide all operator Metasys system functions, including DDL and Metasys Metalink software. Metalink software is an interface package for the OWS that allows data sharing between the Metasys Network and third-party Windows operating system software packages that are Dynamic Data Exchange (DDE) compatible.
- Metasys system GPL (optional)—Graphics-oriented programming language for creating software objects and programming control strategies.
- Metasys system GPL Heating, Ventilating, and Air Conditioning (HVAC) Library (optional)—Set of tested GPL compounds that the application engineer can use to program common BAS applications.
- Metasys system JC-BASIC Programming Language (optional)— Textual programming language for creating processes.
- Third-party Software—Several software packages provided by third-party software manufacturers. For a current list of recommended third-party software packages, refer to the *Metasys Software Installation and Platform Requirements Technical Bulletin (LIT-12012).*

Design Considerations: Configured or Non-Configured Workstation

Decide whether you want to set up the OWS as a configured or non-configured workstation. A configured workstation, either direct or dial-up connected, is a defined device in the Metasys system N1 database and has the full set of communication functions with other nodes. All other nodes on the N1 network can identify a configured workstation. A non-configured workstation is not defined as a hardware object in the Metasys system database and has a limited set of communication functions with other nodes. Unlike the configured workstation, any other node on the N1 network cannot identify a non-configured workstation. Therefore, a non-configured workstation does not automatically receive reports from other nodes.

Table 1 lists the different capabilities of the configured and non-configured OWS.

Capability	Description	Purpose	Configured	Non- configured
	Onlin	e		
Online Database	Workstation allows you to:	Provides central	Yes	Yes
Generation	 define new objects 	operator definition		
	 modify setup for existing objects 	system operations.		
	 implement feature actions 			
Commands	Workstation allows you to:	Provides central	Yes	Yes
	 start, stop, or reset operations 	control of all		
	 communications 	Metasys N1		
	 change operational setpoints 	system operations. Also useful for system test		
Monitor Facility	Workstation provides:	Keeps operator	Yes	No
, , , , , , , , , , , , , , , , , , ,	 pop-up message windows to alert user to special situations 	current on status of facility.		
	 summaries automatically sent at particular time or event 			
Maintenance	Provides maintenance flags to the operator based on hours of usage, number of cycles, and so on.	Optimizes maintenance efforts.	Yes	No
DDE Interface (Metalink Software)	Provides data exchange between the Metasys N1 network and third-party Windows operating system applications.	Provides useful reports, spreadsheets, and work orders.	Yes	Yes
Store Historical Data	Uploads and stores historical data on system performance automatically.	Provides convenient record keeping, and establishes database accessible to third-party programs.	Yes	No
Graphics	Allows both graphic and textual data presentation.	Provides faster user recognition.	Yes	Yes
Windows	Display is divided into regions that can be sized and moved, and act as separate displays.	Provides access to several types of information simultaneously.	Yes	Yes
System Archive	Stores operating programs and parameter as backup.	Provides quick, easy recovery after power loss or system repair.	Yes	Yes
Continued on next	bage			

Table 1: Capabilities of OWS

Capability (Cont.)	Description	Purpose	Configured	Non- configured
	Offlir	ne		
Password Protection	Allows definition of different levels of system access for various users as defined by their password. See the <i>Non-configured</i> <i>Workstation Security</i> section.	Limits exposure to errors or tampering by unqualified users.	Yes	Yes
NCSETUP for Windows Operating System Software	Allows you to set up, modify, and configure NCMs for the Metasys Network.	Configures NCM for use on Metasys Network.	Yes	Yes
GPL	Enables operator to program Metasys software functions by positioning and joining graphic symbols.	Simplifies custom programming	No	No
DDL	Enables operator to define PC groups, systems, and objects using lines of text.	Provides a quick method for defining large blocks of new system/objects.	Yes	Yes
Archive	Allows archiving of trend, totalization, follow-up, and status reports.	Provides a method of storing data.	Yes	No

Non-configured Workstation Security

Carefully consider your security needs when a person with a non-configured workstation has access to an N1 network. A non-configured direct or dial-up connection allows any person who has knowledge of the Metasys N1 network's name and default Level 1 password to view and edit the password database. This may lead to a security risk.

Non-configured workstations do not have a PC name in the NET.ddl file. See the following NET.ddl file example and note that the NET Keyword string (located in the third line) contains no PC name, thus preventing PC identification on a network.

@NET PORT "LPT1", 3 NET "XYZ-BLDG", "XYZ-BLDG NETWORK", NCDIAL "T", "123-4567"

The default password, METASYS, is created when the NET.ddl file is compiled. If a workstation has never been connected to an N1 network, only the default password exists.

To prevent access to the Metasys N1 network from a non-configured workstation, delete the Metasys system default password from the PMI software. Refer to the *Defining Passwords (LIT-120150)* chapter of the *Operator Workstation User's Manual*. Once the Metasys system default password is removed, you **cannot** use non-configured access because a non-configured workstation does not know any other password. Use a configured workstation for dial-up capabilities.

Design Considerations: Direct or Dial-Up Workstation

Consider how to connect the OWS: direct or dial-up connection. A directly connected workstation connects to the N1 LAN or to an NCM via an RS-232 cable. A dial-up workstation connects to a modem, which allows access to the Metasys N1 network over telephone lines. The primary difference between direct and dial-up connections is communication speed. See Table 2.

Type of Connection		Maximum Communication Speed	
Direct N1 LAN		10 Million bits per second (Mbps) Ethernet network	
		2.5 Mbps ARCNET network	
NCM100/200		1200 to 19,200 baud*	
	NCM300 Series	1200 to 57,600 baud	
Dial-Up	NCM100/200	1200 to 9600 baud	
	NCM300 Series	1200 to 38,400 baud*	
		57,600 for ISDN	

Table 2: Design Considerations

*Notes: A direct-connect default destination does not work, but a direct-connect OWS can be a default destination.

For the NCM300 Series only: Above the 19,200 baud, use a 16-character First In, First Out (FIFO) serial card. The serial card must use a 16550AF UART or equivalent. An example of a 16550AF serial card is the BOCA I/O AT55.

When selecting the connection types, be sure to follow these rules:

- Direct connections can use COM1, COM2, COM3, and COM4, depending on PC type.
- Dial-up connections can use COM1 and COM2 only; they cannot use COM3 or COM4.
- An expansion board may be required for additional COM in multiple direct connection applications. Refer to the *Metasys* Software Installation and Platform Requirements Technical Bulletin (LIT-12012) for recommendations for your PC.
- The maximum length allowed for the RS-232 is 50 feet (EIA-232-D). If the NCM must be placed in a remote location, use an alternate communication scheme such as dedicated line modems.

OWS Installation

Physical Dimensions

The following specifications for physical dimensions and power vary with the specific platform. See the manufacturer's literature for details.

Table 3 describes typical physical dimensions of the OWS components.

	Typical Area Required (Approximate)			
Type of	System Unit	Monitor	Keyboard	
Chassis	Height x Width x Depth	Height x Width x Depth	Height x Width x Depth	
Desktop	152 mm x 406 mm x 419 mm	381 mm x 356 mm x 406 mm	51 x 495 x 216 mm	
	(6 in. x 16 in. x 16.5 in.)	(15 in. x 14 in. x 16 in.)	(2 in. x 19.5 in. x 8.5 in.)	
Floor	597 mm x 165 mm x 483 mm	362 mm x 356 mm x 381 mm	51 mm x 495 mm x 216 mm	
Standing	(23.5 in. x 6.5 in. x 19 in.)	(14.25 in. x 14 in. x 15 in.)	(2 in. x 19.5 in. x 8.5 in.)	
Portable	114 mm x 216 mm x 343 mm	N/A	16.5 mm x 343 mm x 165 mm	
	(4.5 in. x 8.5 in. x 13.5 in.)	N/A	(0.65 in. x 13.5 in. x 6.5 in.)	

Table 3:	Typical Ph	vsical Dimen	sions for the	e Computer	Configured a	s OWS

Table 4 describes typical physical dimensions of the OWS accessories.

Table 4: Physical Dimensions	of OWS	Accessories
------------------------------	--------	-------------

Accessory	Typical Area Required (Approximate) Height x Width x Depth
Printer	127 mm x 419 mm x 356 mm (5 in. x 16.5 in. x 14 in.)
Multi Tech® MultiModemII™ Modem	35 mm x 156 mm x 229 mm (1.4 in. x 6.2 in. x 9.0 in.)
ADTRAN ISU Express	41 mm x 165 mm x 210 mm (1.6 in. x 6.5 in. x 8.25 in.)
Fiber-Optic Transceiver	25 mm x 69 mm x 43 mm (1.0 in. x 2.7 in. x 1.7 in.)
Mouse (and Pad)	203 mm x 229 mm (8.0 in. x 9.0 in.)

Power Requirements

Table 5 describes the typical power requirements for major OWS components.

Component	Power Requirements
Desktop Computer	100 VAC-125 VAC at 2.5 A-3.2 A, 50/60 Hz
	(200 VAC-240 VAC at 1.3 A-2.0 A, 50/60 Hz)
Floor Standing Computer	100 VAC-125 VAC at 5.3 A, 50/60 Hz
	(200 VAC-240 VAC at 2.7 A, 50/60 Hz)
Portable Computer	120 VAC at 1.0 A, 50/60 Hz
	(220 VAC-240 VAC, 50/60 Hz)
Printer	120 VAC at 1.0 A, 60 Hz
Multi Tech MultiModemII Modem	115 VAC at 0.3 A, 60 Hz
ADTRAN ISU Express	115 VAC, 60 Hz, 6.5 Watt Maximum Dissipation without Plain Old Telephone Service (POTS) or Modem Options
	220 VAC, 50 Hz, 13 Watt Maximum Dissipation with POTS and Modem Options

Table 5: Typical Power Requirements

Environmental Information

The following specifications for ambient operating temperature and humidity vary with the specific platform. See the manufacturer's literature for details.

The OWS is rated for use in light industrial or office room applications, specified as follows:

- ambient operating temperature: 10 to 40°C (50 to 104°F)
- ambient operating humidity: 20 to 80%
- The atmosphere must be free of corrosive chemical vapors that may damage electronic equipment.

Wiring—Sequence of Steps

The wiring procedure depends on whether the OWS is directly connected to the N1 LAN, directly connected to an NCM, or dial-up connected to an NCM. (The following instructions presume all boards are installed and properly configured.) Table 6 provides a summary of OWS connections.

Type of Connection		Parallel Port	Serial Port (COM1)	Network Interface Card Ports	Additional Serial Ports (COM2 - COM4)
Direct	N1 LAN	Printer*	Not Used	N1 LAN	Not Used
Connect	NCM	Printer*	NCM	N/A	Up to 3 NCMs
Dial-Up Connect	NCM	Printer*	Modem	N/A	1 Modem (COM2 only)

Table 6: OWS Connections

*

Printer may be connected to a serial port.



Figure 4: Directly Connecting OWS to N1 LAN







Figure 6: Directly Connecting OWS to NCM200

After making the physical connection and turning on the workstation, the initialization and connection process begins. A message window appears on the workstation screen displaying the status of the connection. **Do not close this message window** (by double-clicking the Control menu box), unless you want to cancel the connection. Closing the window cancels the connection.

During the connection process, the message changes to display the current connection status. If the connection fails, the message explains why. The explanation remains on the screen for 5 seconds before the Metasys PMI software begins in offline mode. (In offline mode, data from the NCM is unavailable.) To retry the connection, correct the reason for the failure and reboot the workstation.

Table 7 lists and explains the status and failure messages that can occur in the message window.

When directly connecting an OWS to an NCM, follow these guidelines:

- The OWS PC port must be set to the same baud rate as the NCM port.
- The OWS must have the network to which it is connecting defined in its database.
- If you are downloading from the direct-connect workstation to the NCM, the archive node address for the NCM must be the same as the NCM node address. If it is not, the download does not occur. For more information on specifying the archive node address, refer to the NCM setup information in the *NCSETUP for Windows Technical Bulletin (LIT-6360251d)*.
- If you are downloading from the direct-connect workstation to the NCM, wait 2 to 3 minutes for the download to start before assuming failure.

Message	Explanation
Code Downloading	Metasys PMI code is being downloaded from the workstation into the NCM.
Connected @ XXXX Baud Configured	The workstation and NCM are successfully
The actual baud rate of connection is displayed in message. XXXX may vary depending on the rate and quality of the connection and can be significantly less than the selected baud.	connected at the specified baud rate. The workstation is configured.
Connected @ XXXX Baud Unconfigured	The workstation and NCM are successfully
The actual baud rate of connection is displayed in message. XXXX may vary depending on the rate and quality of the connection and can be significantly less than the selected baud.	connected at the specified baud rate. The workstation is not configured.
Connecting to NC	Physical connection and initialization of workstation is successful. Connection is occurring.
Data Downloading	Data is being downloaded from the workstation into the NCM.
Disconnected, Failed! Cannot Read NC NOVRAM	The workstation cannot read the network name from the NCM's NOVRAM.
Disconnected, Failed! Cannot Read NC State	Every 30 seconds the workstation attempts to read the state of the NCM. This message indicates the state cannot be read and the workstation has lost communication from the NCM.
Disconnected, Failed! Global Data Failed	The process of synchronizing global data has failed.
Disconnected, Failed! Memory Error	An OWS memory error has occurred. Need system reboot.
Disconnected, Failed! Network Name Invalid	The network name read from the NCM's NOVRAM is not defined in the workstation's network database.
Disconnected, Failed! No Communication	NCM initialization failed or the workstation has become physically disconnected from the NCM.
Disconnected, Failed! Port Not Enabled	OWS port initialization failed (hardware failure).
Disconnected, Retrying Configured	Connection between workstation and NCM is lost because the NCM is rebooted or the cable is unplugged. Workstation is retrying connection. This message also occurs immediately before a code or data download.
Global Data Updating	Global data is synchronizing between NCM and workstation.
Initializing	The initialization process is occurring. (The workstation must be initialized before the connection process can begin.)
NC Must Force Download	NCM must be reset by using the reset button on the front, by manual command, or by cycling power on the NCM.
NC Needs a Download	The NCM needs a download from the workstation.
NC Not Defined	NCM is not defined. Need to define the NCM in the global database source file. See the <i>Source File Development</i> section (<i>LIT-630020</i>) of the <i>DDL Programmer's Manual</i> for instructions.

Table 7: Messages that Can Occur during Direct Connection

Dial-Up Connections

Figure 7 shows how baud rates can differ between the OWS to the modem, the NCM and the modem, and between the two modems.



Figure 7: Modem to Device vs. Modem to Modem Connections

The baud rate of connection is the actual rate of communication established between the OWS and the NCM. It is typically the modem baud rate but may be less depending on the quality of the phone line. The rate may change each time a connection is established.

modem



Figure 8: Remote Connection between OWS and NCM



Figure 9: ISDN Remote Connection between OWS and NCM

Configure a Printer for the Metasys N1 System

You can configure printers that have Windows operating system drivers, including many laser printers, to print Metasys N1 reports and messages. Configure color printers to print various color reports and the Critical summary. For details on color printing, see the *Print Reports and Summaries in Color* section of this technical bulletin.

Consider the complete system before installing any printers. There are two configuration possibilities:

- Single Operating System (OS)
 - One or more OWSs, all using a single OS, with one or more printers connected to one or more of the OWSs. (A single OWS with a single printer falls into this category.)
 - A Single OS is the recommended configuration and is described in the *Single Operating System* section of this document.
- Mixed Operating Systems
 - Multiple OWSs, using mixed OSs, with one or more printers connected to one or more of the OWSs.
 - Configuration of mixed Operating Systems requires special care. Refer to the *Operator Workstation Appendix Technical Bulletin (LIT-1201696)* for more help.

Single Operating System

Review the following instructions and the Adding a Printer Supported by the Windows 2000 Professional Operating System detailed procedure, and make the recommended changes to prevent printer problems when using Metasys PMI software with any Windows operating system.

To print properly in the system, complete the two following procedures:

- Install each printer using standard Windows operating system installation procedures.
- Configure Metasys software to work with each printer.

Configuring Printers Supported by Windows 2000 Professional Operating System Software

Repeat the Adding a Windows Operating System Printer in Windows 2000 Professional Operating System Software procedure for every printer type installed on the Metasys N1 network. For example, if you have three different printers connected to three of your five OWSs, then you must install three printer drivers on every OWS, even on those that do not have printers connected. If you add a new printer later, then you must add the new printer driver to all five OWSs.

IMPORTANT: Always reboot the PC when you finish making changes to the Windows Printer configuration.

Summary

On every OWS, you must install a Windows operating system printer for every printer on the system, even if there are printers with the same name (Figure 10). Later, rename these printers to match the Metasys system printer object name. Each name must be unique.



Figure 10: Typical Screen after Installing All Windows Printers for a Metasys N1 Network

Configure the OWS for Printers

After installing the Windows supported printers on all Operator Workstations, you must configure the individual Metasys system printer objects. This procedure is independent of the OS. You must configure every printer on the network. Each OWS with a physical printer connected must undergo this configuration process. See the *Configuring the OWS for Printers* section in this document.

Example of Five OWSs All Running on the Same Operating System and Three Printers

Here is an example of multiple OWSs with all OWSs running on the same OS and three printers.

Situation:

You have five OWSs all running on Windows 2000 Professional operating system software. Assume the OWSs are named OWS-210 through OWS-214. You have three Hewlett-Packard® DeskJet® 870C printers: one connected to OWS-210, the second connected to OWS-211, and the third connected to OWS-213. A Lexmark Proprinter® III printer (formerly an IBM® Proprinter III printer) is connected to OWS-214. No printer is connected to OWS-212.

Following the preceding process, you have installed the following printers on OWS-214:

Local:

The default printer LP-214 (renamed from IBM Proprinter III printers) Generic Text Printer

IBM Proprinters (renamed from IBM Proprinter printers)

Remote:

HP® DeskJet 870C HP DeskJet 870C (copy 2) HP DeskJet 870C (copy 3)

Rename the remote printers as follows:

HP DeskJet 870C becomes LP-210 HP DeskJet 870C (copy 2) becomes LP-211 HP DeskJet 870C (copy 3) becomes LP-213

Repeat this process for each OWS (Figure 11). Table 8 is a complete description of this example.



Figure 11: Typical Screen after Windows Printer Installation Complete

 Table 8: Required Printer Naming Conventions for All OWS Running on the Same Operating

 System

OWS and Printer	Printer after Initial Windows Operating System Installation at OWS and Metasys N1 System Configuration	Windows Operating System Printer Names after Renaming the Remote Printers
OWS-210	Local:	Local:
Windows 2000	LP-210 ¹	LP-210
Operating System	Generic/Text Only	Generic/Text Only
(OS)	IBM Proprinters ²	IBM Proprinters
	Remote:	Remote:
Local Printer:	HP DeskJet 870C (Copy 2)	LP-211
HP Laser Jet® 870C	HP DeskJet 870C (Copy 3)	LP-213
	IBM Proprinter III	LP-214
OWS-211	Local:	Local:
Windows 2000	LP-211 ¹	LP-211
Professional US	Generic/Text Only	Generic/Text Only
	IBM Proprinters ²	IBM Proprinters
Local Printer: HP Laser let 870C	Remote:	Remote:
	HP DeskJet 870C (Copy 2)	LP-210
	HP DeskJet 870C (Copy 3)	LP-213
	IBM Proprinter III	LP-214
Continued on next pa	ge	

1. This is the printer that has been installed and tested locally and directly connected to the OWS.

2. This is an IBM Proprinter renamed to IBM Proprinters.

OWS and Printer (Cont.)	Printer after Initial Windows Operating System Installation at OWS and Metasys N1 System Configuration	Windows Operating System Printer Names after Renaming the Remote Printers
OWS 212	Local:	Local:
Windows 2000	(None)	(None)
Professional 05	Generic/Text Only	Generic/Text Only
Leeel Drinter	IBM Proprinters ²	IBM Proprinters
Local Printer:	Remote:	Remote:
None	HP DeskJet 870C	LP-210
	HP DeskJet 870C (Copy 2)	LP-211
	HP DeskJet 870C (Copy 3)	LP-213
	IBM Proprinter III	LP-214
OWS-213	Local:	Local:
Windows 2000 Professional OS	LP-213 ¹	LP-213
	Generic/Text Only	Generic Text Only
	IBM Proprinters ²	IBM Proprinters
Local Printer: HP Desk let 870C	Remote:	Remote:
	HP DeskJet 870C (Copy 2)	LP-210
	HP DeskJet 870C (Copy 3)	LP-211
	IBM Proprinter III	LP-214
OWS-214	Local:	Local:
Windows 2000	LP-214 ¹	LP-214
Professional OS	Generic/Text Only	Generic/Text Only
	IBM Proprinters ²	IBM Proprinters
Local Printer:	Remote:	Remote:
	HP DeskJet 870C	LP-210
	HP DeskJet 870C (Copy 2)	LP-211
	HP DeskJet 870C (Copy 3)	LP-213

1. This is the printer that has been installed and tested locally and directly connected to the OWS.

2. This is an IBM Proprinter renamed to IBM Proprinters.

Mixed Operating Systems

Although installing printers that work across Metasys OWSs running on a single OS is relatively straightforward, configuring printers across mixed OSs requires special care.

IMPORTANT: You must first ensure that every printer has a driver that has the same name for all operating systems.

To ensure the printer driver name is the same for all OSs:

- 1. Install the printer in the usual way on the OWS to which the printer is to be connected. Print a test page.
- 2. Move the same printer to another OWS with the alternate OS. Install the printer in the usual way and print another test page. The Windows OS printer driver names on each test print must match.

There is no guarantee that all printers work, even if the printer driver names are identical. You may see General Protection Violation errors or no printing at all.

Many printers emulate another printer. An emulated printer may use a common driver across OSs. Examine your printer manual to check printer emulation. Test the printer as described previously to ensure the driver names are the same.

When you have a common driver, the configuration is the same as described in the *Configuring the OWS for Printers* detailed procedure. You must print a focus window across every OWS once the printers are fully installed.

If you add another printer to a Metasys N1 network with OWSs running on multiple OSs, you must repeat the printer tests to ensure driver names match.

Print Change-of-State (COS) Reports

You **cannot use** an OWS serial printer with Windows 2000 Professional operating system and Windows XP Professional operating system software for COS reports.

Print Reports and Summaries in Color

Printers that support color and style (bold and italic) printing can be used with OWSs to provide consistent color and style options for printing COS reports, critical summary messages, and various data that appear in the Metasys system windows.

If you have a color printer connected to an OWS and you are viewing colored data on the screen (for example, a trend or totalization graph), you can print that data in color. It is not necessary to reconfigure the printer, use a specific printer, or set any parameters on the OWS. Verify that you are using the correct printer driver when printing to a color printer.

Printing reports and summaries, however, requires using specific printers and/or making changes to the METASYS.INI file. You can print COS reports in a variety of colors and styles using either dot matrix printers that support ESC/P escape codes sequences or Windows printers without using escape code sequences. The COS Critical summaries can only be printed in red or black but support any type of color printer. To enable color printing in all cases requires making changes to the METASYS.INI file. See the *Modify the METASYS.INI File* section of this document.

NCMs do not support color printing.

When using a color printer on an OWS, keep in mind that:

- the OWS connected to the color printer must have the color parameters added in that OWSs METASYS.INI file
- if two or more printers are connected to a single OWS, both printers must operate identically, because both printers use the same METASYS.INI file parameters
- if a report is directed to an OWS printer, the destination OWS METASYS.INI parameters take effect
- if a critical summary is printed, the METASYS.INI file parameters on the originating OWS take effect
- if printing COS messages in color without using escape code sequences, the proper driver must be installed for the color printer

Print Reports in Color

Dot matrix printers that can print in multiple colors usually have a four-color ribbon containing the following colors:

- cyan (blue)
- magenta
- yellow
- black

When mixed together, violet, orange, and green are additional options. With the number of colors available, you can specify that you want a particular report, for example a Critical Alarm 1, to print red. In addition, you can print in each style, bold or italic, with any of the colors.

Modify the METASYS.INI File

Add the specific parameters to the METASYS.INI file for printing colors or special effects. Refer to the *Initialization Parameters Technical Bulletin (LIT-636345)* for detailed explanations of the defaults and examples of how to change the parameters.

To assign a specific color, bold style, or italic style, to a particular report type, add the following (each line specifies the particular report):

RrPrintCritical1=xxxx RrPrintCritical2=xxxx RrPrintCritical3=xxxx RrPrintCritical4=xxxx RrPrintOperatorTransaction=xxxx RrPrintFollowup=xxxx RrPrintStatus=xxxx RrPrintCardReader=xxxx

xxxx=is a four digit number that defines the desired color/feature.

In addition to the RRPrintCritical parameters above, you must add a group of escape codes to specify color and print style to the METASYS.INI file. Open the METAPRN.INI file and identify the block of parameters that correspond to your printer. Copy this block of parameters from METAPRN.INI file and paste into the METASYS.INI file under the section heading [METASYS]. When using Windows printers for color printing of COS messages, no escape codes are required. Refer to the *Initialization Parameters Technical Bulletin* (*LIT-636345*) for more information.

Print COS Summaries

Unlike the COS reports that have a variety of color choices, COS summaries can be printed only in red or black. The capability to print in red operates independently from the report logging described in the previous section. Any printer that supports color and is installed in Windows operating system software with compatible Windows driver software can be used to print the COS summaries in red. To enable the red printing, add the following single parameter to the METASYS.INI file:

CossumPrintColor=1

Refer to the *Initialization Parameters Technical Bulletin (LIT-636345)* for the parameter settings.

Modify COS Buffer

The COS buffer stores COS reports for printing. Two methods of configuring the buffer are available: Buffer Size and Buffer Interval. The print Buffer Size parameter specifies the number of COS reports buffered before they are sent to the printer. The print Buffer Interval parameter specifies the number of minutes the Metasys system waits until the buffer is sent to the printer, regardless of the number of messages in the buffer. Refer to the *Initialization Parameters Technical Bulletin (LIT-636345)* for the parameter settings.

You may configure up to four printers on an OWS for use at one time. When the COS buffer is enabled, all printers on that OWS are buffered. Each OWS has its own buffer; however, the same initialization parameter is used for all.

General Modem Configuration

For a list of qualified modems, refer to the Computer Price List (pcprices.doc) at *The Advisor* > *Business Focus* > *Purchasing* > *ePurchasing* > *CG Computer Purchasing*.

PMI Release 11.00 and later allows you to select a modem from a list. All supported modem strings are located in MODEM.INI. The new file is referenced for setting up either OWS or NCM modem applications. The MODEM.INI file includes all modems currently supported by PMI software. New modems can be added in the field as the need arises. The MODEM.INI file is located in the same directory as METASYS.INI. The MODEM.INI file is also available on *The Advisor*. Refer to the *Initialization Parameters Technical Bulletin* (*LIT-636345*).

Update the MODEM.INI

Occasionally a new set of modems supported by the Metasys N1 network is available from *The Advisor* site. To update a particular customer, copy the entire MODEM.INI from *The Advisor* and replace the present MODEM.INI on the PMI Release 11.00 or later job site.

Any user-defined modems are lost during the updating process.

Modem Wiring

See the *Configuring ISDN Modems* detailed procedure and refer to the following connections.

OWS to Modem

The external modem connects to the OWSs serial port (COM1 or COM2) with an RS-232 cable. The pinouts for this cable depend on the type of PC. Use the pinouts for your system.

Several computers support the 25-pin COM port.



Note: If you are using the Multi Tech Modem V32L (discontinued), cut pin 18 at the modem end.

Figure 12: Cable between 25-Pin COM Port and Modem (Allied Part CON94-3870-10)



Most computers support the 9-pin COM port. Use a null modem cable or prepare the RS-232 cable as shown in Figure 13.

Figure 13: Cable between 9-Pin COM Port and Modem (Allied Part CON94-3690-10)

NCM to ISDN Modem

This section shows the cable for connecting the NCM (Port 2) to the ADTRAN ISU Express. Use a standard modem cable or prepare the cable as shown in Figure 14. For more information on NCM cables, refer to the *Network Control Module 200 Series Technical Bulletin* (*LIT-636025*) and the *Network Control Module 300 Series Technical Bulletin* (*Bulletin (LIT-6360251*).



Figure 14: Cable between NCM200 Port 2 and ADTRAN ISU Express

Commissioning Overview

The commissioning process depends on whether it is a new project or existing job.

If the OWS does not function properly after installation, refer to the *Operator Workstation Appendix Technical Bulletin (LIT-1201696)*.

The information in this document is current as of its revision date. For updates, refer to the Readme.ows and Install.ows text files provided with the new release of the software.

Perform a PREP-FOR command before database restoration or conversion to set up environment variables. Refer to the *Operator Workstation Appendix Technical Bulletin (LIT-1201696)*.

Commissioning a New Project

See the *Commissioning PMI New Project Software* section in the *Detailed Procedures* section of this document for more information.

Commissioning an Existing Job

Commissioning involves installing the new software release over the old software release if:

- this is an existing job
- the hardware configuration is correct
- the job does not use multiple direct connections

See the Commissioning Software: Upgrading Existing Jobs section.

However, if the job uses multiple direct connections, but additional serial boards are not already installed on your system, you need to install serial boards. In this case, see the *Extra Serial Boards* section in the *Hardware Commissioning* section. See the *Commissioning Software: Upgrading Existing Jobs* section to install the Metasys N1 system software.

Hardware Commissioning

Commissioning hardware can involve the installation of the following equipment: memory, an NIC, extra serial boards, and a mouse. Specific procedures may depend on the model and brand of equipment being used.

Computer Platforms

The hardware required for an OWS may include: added memory, an NIC, extra serial boards, and a mouse. Refer to the *Metasys Software Installation and Platform Requirements Technical Bulletin* (*LIT-12012*) for the specific requirements of your system.

WARNING: Risk of Electric Shock. Unplug the computer from the power receptacle before removing the computer cover. Contact with internal components carrying hazardous voltage can cause electric shock and may result in severe personal injury or death.

IMPORTANT: When installing hardware, follow anti-static precautions provided by the manufacturer. Failure to follow anti-static precautions could result in damage to sensitive electronic components.

Memory

Computers may require additional memory to run Metasys N1 system software. A Single Inline Memory Module (SIMM) or expansion board provides memory. Install the module or expansion board, and refer to the manufacturer's literature for instructions.

Network Interface Card (NIC)

The following information does not apply to any portable OWS that directly or remotely connects to an NCM.

The OWS **requires** an NIC to communicate on the N1 LAN. (The OWS cannot operate without an NIC on the N1 LAN.) For details on installing the Ethernet card, refer to the *N1 Ethernet/IP Network Technical Bulletin (LIT-6360175)*.

Extra Serial Boards

The following information does not apply to any portable platforms.

If you want the OWS to connect to multiple NCMs, additional serial connections are required. The workstation supports up to three serial connections: COM1, COM2, and COM3. Standard systems typically provide COM1 and COM2. For COM3, install an Industry Standard Architecture (ISA) serial board. (For ordering information, refer to *Metasys Software Installation and Platform Requirements Technical Bulletin [LIT-12012]*.)

Mouse

When you install the mouse, refer to the mouse literature for detailed installation instructions.

For portable platforms, install the mouse into serial port COM1, the dedicated mouse port. (Use serial port COM2 for direct or dial-up connection to an NCM.) Other portable platforms may have either a dedicated mouse port or a built-in track ball.

Commissioning PMI New Project Software

This section includes instructions on how to install Metasys PMI on a new project. Before installing Metasys PMI software, make sure your system meets the necessary prerequisites listed as follows.

Table 9: Operating System Compatibility

	Windows 95 OS	Windows 98 OS	Windows NT OS	Windows 2000 Professional OS	Windows XP Professional OS
Metasys System Release					
8.0	Х	Х	Not Supported	Not Supported	Not Supported
9.0	Х	Х	Not Supported	Not Supported	Not Supported
10.00	Х	Х	Х	Not Supported	Not Supported
11.00	Not Supported	Х	Х	Not Supported	Not Supported
12.00	Not Supported	X	Х	Х	Not Supported
12.04	Not Supported	Not Supported	Not Supported	Х	Х

Prerequisites

Before you load the Metasys PMI software, verify the following:

- An earlier release of Metasys PMI software is not installed on this computer. The file C:\FMS\BIN\MFG\$\$\$.OWS should not exist. If there is a previous installation, install the Metasys software as described in the *Commissioning PMI Software: Upgrading Existing Jobs* section.
- Metasys software requires: Windows 2000 Professional operating system or Windows XP Professional operating system software. Follow the instructions for the Windows operating system version you are using. Do not set up your PC to perform a dual boot.
- Install Metasys PMI software directly on a newly installed Windows 2000 Professional operating system or Windows XP Professional operating system software.
- Disable screen savers on PCs running Metasys PMI software.
- To use the Enhanced Report Group feature, all NCMs must have a minimum of 4 MB of RAM.
- The OWS platform must have a Pentium® processor.
- Hard disk space requirements are listed as follows:
 - PMI (including Metalink), 43 MB (Note 1)
 - GPL Software (Optional), 7.0 MB (Note 2)
 - JC-BASIC (JCB) Software (Optional), 7.0 MB (Note 2)
 - GPL HVAC Library (HLIB) Software (Optional), 5.0 MB (Note 2)
 - Metasys Application Enabler (MAE) Software (Optional), 34.0 MB (Note 1)
 - Note 1: Of this number, the installation program **temporarily** uses 5 MB for the install. This 5 MB is returned to the system when the install is complete.
 - Note 2: Of this number, the installation program **temporarily** uses 1 MB (approximate) for the install. This 1 MB is returned to the system when the install is complete.
- If you are installing all packages (except MAE), the total disk space requirement is 34 MB (approximate).

Setup

Setup instructions include installing:

- Windows operating system software
- Micrografx Designer® software (not supported at Metasys Release 11.00 or later)
- Metasys PMI software

IMPORTANT: Metasys software has not been qualified with Novell® IntraNetware software. Several problems have been documented when customers attempt to run Novell IntraNetware with Metasys software. Johnson Controls strongly advises that you isolate the Metasys N1 network from an enterprise network.

Install Windows 2000 Professional Operating System or Windows XP Professional Operating System Software

Install Windows 2000 Professional operating system or Windows XP Professional operating system software before installing Metasys PMI. Refer to your Windows operating system software manual for more information. Install applicable service packs. You can download service packs from the Microsoft Web site, www.microsoft.com.

Make sure the Windows 2000 Professional operating system or Windows XP Professional operating system is running error-free before installing Metasys software.

Install Metasys PMI Software

Verify all of the prerequisites above and perform all of the setup activities, then continue with the *Installing Metasys PMI Software:* Upgrading Existing Job detailed procedure. Refer to the Metasys Software Installation and Platform Requirements Technical Bulletin (LIT-12012).

The Metasys PMI software product includes Metalink software and DDL software. However, the PMI installation procedure does not install stand-alone programs like the Graphic Programming Language (GPL).

Do not use screen savers on Metasys Workstations.

IMPORTANT: You must have administrative privileges to install Metasys PMI software on a PC running a Windows 2000 Professional operating system or a Windows XP Professional operating system. If not, an error message appears and you cannot install PMI; however, you can install all other products on the CD.

Install Metasys M5 Workstation Software

To enhance the operational capabilities for the N1 system, M5 Workstation software can be installed on top of PMI software on any OWS workstation. For installing M5 Workstation software, you must belong to the Administrators group. For more details, please refer to the *M5 Workstation Installation Technical Bulletin (LIT-1153300)*.

To run M5 Workstation software on top of PMI software, the user must belong to the Power Users group. If necessary, apply additional restrictions using M-Password software. For more details, please refer to the *M5 Workstation Installation Technical Bulletin (LIT-1153300)*.

Commissioning PMI Software: Upgrading Existing Jobs

Upgrading software involves making sure your system meets the prerequisites for an upgrade, setting up your system for the upgrade, and installing the upgrade software.

If upgrading multiple OWSs, upgrade the archive OWSs first.

IMPORTANT: Do not modify Password or Report/Access Groups or perform a global download during the upgrade process (from the time the first OWS is upgraded until the last NCM is downloaded) any time you upgrade from Release 9.01 or earlier to Release 10.01 or later. Refer to the *Connecting Metasys System Release 9.01 OWS to a Metasys System Release 10.01 or Later Network* section in the *Operator Workstation Appendix Technical Bulletin (LIT-1201696).*

Prerequisites

Before you load the Metasys PMI software, verify the following:

- An earlier release of the PMI is already installed on this machine. Check the revision number in the file C:\FMS\BIN\MFG\$\$\$. OWS. If this file does not exist, install Metasys software as a new project. See the *Commissioning PMI New Project Software* section.
- Windows 2000 Professional operating system or Windows XP Professional operating system software is required with Metasys software. Follow the instructions for the Windows operating system version you are using. Do not set up your PC to perform a dual boot.
- Hard disk space requirements are listed as follows:
 - PMI (including Metalink), 43 MB (Note 1)
 - GPL Software (Optional), 7.0 MB (Note 2)
 - JCB Software (Optional), 7.0 MB (Note 2)
 - HLIB Software (Optional), 5.0 MB (Note 2)
 - MAE Software (Optional), 34.0 MB (Note 1)
 - Note 1: Of this number, the installation program **temporarily** uses 5 MB for the install. This 5 MB is returned to the system when the install is complete.
 - Note 2: Of this number, the installation program **temporarily** uses 1 MB (approximate) for the install. This 1 MB is returned to the system when the install is complete.

If you are installing all packages (except MAE), the total disk space requirement is 34 MB (approximate).

If you are upgrading all packages (except MAE), the total additional disk space requirement must be available. Check that all NCMs must have a minimum of 4 MB of RAM to use the Enhanced Report Group feature.

Detailed Procedures

Commissioning a New OWS

To commission a new OWS:

1. Install the hardware: memory (RAM), Network Interface Card (NIC), extra serial boards, and mouse.

Note: Some of these steps are optional depending on your system. See the instructions for your particular platform in the *Hardware Commissioning* section.

2. Install the Metasys PMI software.

Note: PMI installation involves setup steps (such as installing third-party software, if necessary). See the *Commissioning PMI New Project Software* section.

3. Connect the OWS to the Metasys Network. See the steps in the *Connecting and Configuring a Modem to an OWS* detailed procedure.

Installing Software

Follow the proper sequence of installation when installing PMI software and M5 Workstation software to alleviate problems with these products on a single OWS platform.

We recommend installing software in the following order:

- 1. Install PMI software.
- 2. Install M5 Workstation software and additional M-Series Workstation components as required.
- 3. Restart the computer.

Note: The recommended steps refer to product installation sequencing only, and do not imply that all products are required.

Installing Metasys Person-Machine Interface (PMI) Software

Verify all of the previous prerequisites and perform all of the setup activities, then continue with the *Commissioning PMI New Project Software* detailed procedure. Refer to the *Metasys Software Installation and Platform Requirements Technical Bulletin* (*LIT-12012*).

The Metasys PMI software product includes Metalink and DDL software; however, the PMI installation procedure does not install stand-alone programs like the Graphic Programming Language (GPL).

Note: Do not use screen savers on Metasys workstations.

IMPORTANT: You must have administrative privileges to install Metasys PMI software on a PC running Windows 2000 Professional operating system or Windows XP Professional operating system. If not, an error message appears and you cannot install PMI.

Installing Metasys PMI Upgrade Software

The following actions must be performed before upgrading the PMI software:

- 1. Command all Demand Limiting Load Rolling (DLLR) load group objects to Monitor Only.
- 2. Upload all NCMs that are archived at this OWS. To upload an NCM, select an NCM on the Network Map, go to the Action menu, and select NC Upload to Archive PC.
- 3. Verify that this OWS contains all models necessary to download the NCMs archived on this OWS.
- 4. Archive trend and totalization data, if desired.
- 5. Verify that no global data items have been changed within the past 10 minutes. If a global data item has been changed, wait 10 minutes for global synchronization to propagate through the network.
- 6. Connect to each dial-up N1 network on the system so that its global database synchronizes with the OWS global databases. You may disconnect after synchronization.
- 7. Upload global data for each N1 network. Use the Action menu on the Network Map to upload the global data.
- 8. Do not change any global data items or perform a global download until instructed.
- 9. From the Network Map Exit menu, select Program Manager. Select No when you are asked whether you want to keep the BAS running. Terminate any other programs that might be running.
- 10. Back up the uploaded database. Refer to the *Move Utility Technical Bulletin (LIT-636110)* for instructions.
- 11. Clearly label the backup and store it.
- 12. Back up Metasys N1 system data and load Windows operating system software before upgrading the Metasys software if you are upgrading the Windows operating system version and are also installing Metasys software. See the *Prerequisites* section.

Establishing a Connection to an N1 Network for the First Time with a Non-configured Workstation

To establish a connection to a network for the first time with a non-configured workstation:

- 1. Launch PMI.
- 2. Select an N1 network.
- 3. Enter Password. (The only possible password is METASYS because you do **not** have the current online global database.) A direct or dial-up connection launches and establishes a link to the network.

IMPORTANT: At this point, you are logged on to the N1 network with the default Level 1 password.

Note: The network node manager checks to see if you have the latest online global database. Since you do not have the latest online global database, the latest version is provided including the network password database.

IMPORTANT: You are now still logged on with the default Level 1 password and are able to view and edit the password database. To protect your system from a possible security breach using a non-configured workstation, delete the default Level 1 password from your system. Refer to the *Defining Passwords* chapter (*LIT-120150*) of the *Operator Workstation User's Manual.*

Direct Connecting to N1 LAN - Ethernet Network

To direct connect to N1 LAN - Ethernet Network (Figure 4):

- 1. Connect the Ethernet cable to the NIC. (The OWS cannot operate without an NIC on the N1 LAN.) Follow the network installation requirements for the selected Ethernet media.
 - **Notes:** If the NCM is configured for an Ethernet connection, always have the NIC installed in the NCM.

If you have a printer, connect the printer cable to the parallel or serial port on the OWS.

2. Connect the keyboard, monitor, and mouse to the appropriate ports on the workstation.

Note: After you make the physical connection and turn on the workstation, the initialization and connection process begins. A message window appears on the workstation screen displaying the status of the connection. **Do not close this message window** (by double-clicking the Control menu box), unless you want to cancel the connection. Closing the window cancels the connection.

Direct Connecting to a Network Control Module (NCM)

To direct connect to an NCM (Figure 5 and Figure 6):

1. If you are connecting one NCM to the OWS, connect a cable from the RS-232 submodule or port on the NCM to the serial port on the OWS. The cable pinouts vary depending on which RS-232 port and which PC you are using. Refer to the *Network Control Module 200 Series Technical Bulletin (LIT-636025)* and *Network Control Module 300 Series Technical Bulletin (LIT-6360251)*.

If you are connecting two, three, or four NCMs to the OWS, connect each cable from the RS-232 submodule or port on the NCM to an available COM port on the OWS.

Note: If you have a printer, connect the printer cable to the parallel or serial port on the OWS.

2. Connect the keyboard, monitor, and mouse to the appropriate ports on the workstation.

After making the physical connection and turning on the workstation, the initialization and connection process begins. A message window appears on the workstation screen displaying the status of the connection. **Do not close this message window** (by double-clicking the Control menu box), unless you want to cancel the connection. Closing the window cancels the connection.

Dial-up Connecting to an NCM - with Modem

To dial-up connect to an NCM - with modem (Figure 8):

1. If you are using the internal modem submodule at the NCM, install the modem into the NCM's second submodule port.

If you are using an external modem at the NCM, connect the RS-232 cable from the modem to the NCM's RS-232 submodule. Make sure the cable screws are fastened.

2. If you are using an external modem at the workstation, connect the RS-232 cable from the modem to the serial port on the OWS. See the *Modem Wiring* section in this document for the cable's configuration.

If you are using the internal modem at the portable workstation, install the modem in the system unit.

3. Connect the modems to the telephone line.

Note: If you have a printer, connect it to the OWS.

4. Connect the keyboard, monitor, and mouse to the workstation.

The NCM makes multiple connections and disconnections during a download from a dial-up PC. When the PC initiates a download to the NCM, the PC calls the NCM, establishing the connection, and the NCM terminates the connection. The NCM calls the PC back, the code is downloaded, and the NCM terminates the connection again. Finally, the NCM calls the PC back (reestablishing the connection) and the data is downloaded. When the NCM initiates the connection (for example, for a reset), the NCM dials the PC, establishing the connection, and the code is downloaded. Then the NCM terminates the connection, and the data is downloaded.

Dial-up Connecting to NCM - with Integrated Services Digital Network (ISDN)

To dial-up connect to NCM - with ISDN (Figure 9):

- 1. Connect the RS-232 cable from the modem to the NCM's RS-232 submodule port. Make sure the cable screws are fastened.
- 2. Connect the RS-232 cable from the modem to the serial port (COM1 or COM2) on the OWS. See the *Modem Wiring* section in this document for the cable's configuration.
- 3. Connect the modems to the ISDN lines (following the instructions provided with the adapter).

Note: If you have a printer, connect it to the OWS.

4. Connect the keyboard, monitor, and mouse to the appropriate ports on the workstation.

Note: The NCM makes multiple connections and disconnections during a download from a dial-up PC. When the PC initiates a download to the NCM, the PC calls the NCM, establishing the connection, and the NCM terminates the connection. The NCM calls the PC back, the code is downloaded, and the NCM terminates the connection again. Finally, the NCM calls the PC back (reestablishing the connection) and the data is downloaded. When the NCM initiates the connection (for example, for a reset), the NCM dials the PC, establishing the connection, and the code is downloaded. Then the NCM terminates the connection, and the code is downloaded. Then the NCM terminates the connection, and the data is downloaded.

Adding a Printer Supported by the Windows 2000 Professional Operating System

Note: Use standard Windows procedures to add a printer to each OWS that should have a printer for system wide printing.

To add a printer in Windows 2000 Professional operating system:

- 1. From the Start menu, select Settings > Printers. The Printers dialog box appears.
- Double-click the Add Printer icon. The Add Printer Wizard dialog box appears asking how the printer should be managed: My Computer or Network printer server. Select My Computer and click Next.
- 3. Select the port you want to use (usually LPT1). Click Next.
- 4. Select the manufacturer and model of the printer. Click Next.
- **Note:** If the printer driver is already installed on the computer, you may be asked if you wish to keep the existing driver. Select the Replace existing driver option. Always selecting this option ensures any invalid drivers are overwritten.
- 5. Enter the printer name. The default printer name is usually fine. Click Next.
- 6. Select the Not shared option when prompted to answer if you wish to share the printer. Click Next.
- 7. Print a test page to confirm you have a valid connection. Click Finish. The driver is now loaded on the OWS.
- 8. Repeat the previous steps for every printer type installed on the Metasys Network.

Adding an IBM Proprinter Printer for NCM Printing

To add an IBM Proprinter printer for NCM printing:

- 1. Use the procedure previously described for adding Windows printers.
- 2. Use the Windows Printer Settings option to change (rename) the printer IBM Proprinters devices. The **s** in Proprinters devices is required to ensure successful NCM printing.

IMPORTANT: Always reboot the PC when you finish making changes to the Windows Printer configuration.

Configuring the OWS for Printers

Note: You must configure the individual Metasys printer objects after installing the Windows OS supported printers on all OWSs. Each OWS with a physical printer connected must undergo this configuration process.

To configure an OWS for printers:

1. Make the connected printer the default Windows printer.

- 2. Rename this printer with the appropriate Metasys printer object name. The name is often LP-xxx (xxx=the OWS number). For example, if the OWS is OWS-214, then the printer may be called LP-214.
- 3. Print a Windows printer test page for the default Windows printer and note the three required parameters: Windows Printer Name, Windows Printer Driver, and PC Port Address. The values for these parameters are needed later in the Metasys Printer Focus window.

The three required parameters with their values in this example are:

Windows Printer Name:	LP-214
Windows Printer Driver:	PROPRINT
PC Port Address:	LPT1:

Windows 2000 Professional Operating System Printer Test Page

Extract the values for the three parameters listed in Step 3, in the previous section, from the Windows 2000 Professional operating system printer test page as shown by the following bold print:

```
OWS-244
Machine name:
Printer name:
                LP-244
Printer model: HP DeskJet 890C
Color support: Yes
Port name(s):LPT1:
Data format:
                RAW
Share name:
Driver name:
                UNIDRV.DLL
Data file: HPDJ890C.GPD
Config file: UNIDRVUI.DLL
Help file: UNIDRV.HLP
Driver version: 5.0
Environment:
                Windows NT x86
```

The three required parameters with their values in this example are:

Windows Printer Name:	LP-244
Windows Printer Driver:	HPDJ890C
PC Port Address:	LPT1:

Figure 15 shows typical settings after this stage.



Figure 15: Typical Screen after Renaming the Default Windows Printer

Note: If the Metasys system printer object does not already exist, add the printer object as described in the *Operator Workstation User's Manual*.

1. In the Metasys system Printer Focus window, set the Windows Printer Driver Name field to the printer driver obtained during Step 3 of this procedure. In Figure 16, the Windows Printer Driver Name has been set to PROPRINT.

Direct connect	PC Print	er Focus					- 🗆 X
<u>I</u> tem <u>E</u> dit <u>V</u> iew	<u>A</u> ction	<u>G</u> o To A <u>c</u> cessory <u>I</u>	<u>H</u> elp				
Object Name Expanded ID	LP-21 OWS	14 -214 PRINTER			Status	offline	
Graphic Symbol #	0	Hardware Connection Type		PC-DIRECT	Default Re	eport	
Operating Instr. #	0	PC Name		OWS-214	Destinatio	n	
		PC Port Address		LPT1			
		Baud Rate			•		
	Windo	ows Printer - Driver Nam	ne:	PROPRI	NT		
	Winde	ows Printer - Printer Nar	me:	LP-214			
•							
							Print9

Figure 16: Example Metasys Focus Window

- 2. In the Metasys system Printer Focus window, set the Windows Printer Name to the Windows Printer Name obtained during Step 3 in this procedure. Figure 16 shows the Windows Printer Name is LP-214.
- 3. Save and close the Metasys Printer Focus window. Once the information is updated across the network, you can print to this device from any location in the network. Because this information is global data, it is not complete until all printers are configured.

Fixing Line Feed Problems when Using a Serial Printer

If you are using a serial printer and are having line feed problems after setting up your printers, try changing the Printer Settings in the Properties dialog box.

To fix line feed problems when using a serial printer:

- 1. From the Start menu, select Settings and then select Printers. The Printers dialog box appears.
- 2. Right-click on the icon for the printer and select Properties.
- 3. Click the Details tab.

CPRT3 Properties	?
Graphics Fonts General Details	Device Options PostScript Printer Settings Paper
Print to the following port:	
COM 1	Add Port
Print using the following driver	Delete Port
IBM Proprinter III	▼ Ne <u>w</u> Driver
Capture Printer Port	End Capture
Timeout settings Not selected: 15	seconds
Spool S	ettings Port Settings

Figure 17: Properties Dialog Box with Details Tab Showing

4. Click the Spool Settings button to display the Spool Settings dialog box.



Figure 18: Spool Settings Dialog Box

- 5. Select the Print directly to the printer option and click OK to return to the Properties dialog box (Figure 18).
- **Note:** If you still have problems, and the printer is on a COM port, skip to Step 11. If it is not on a COM port, try these additional steps.
- 6. Click the Port Settings tab to display the Port Settings dialog box.
- 7. Click the Advanced button to display the Advanced Port Settings dialog box.

Advanced Port Settings	X
Use <u>FIFO</u> buffers (requires 16550 compatible UART) Select lower settings to correct connection problems. Select higher settings for faster performance.	OK Cancel
Receive Buffer: Low (1) High (14)	<u>D</u> efaults
Transmit Buffer: Low (1) High (16)	
	Print15

Figure 19: Advanced Port Settings Dialog Box

- 8. Click and drag the Receive Buffer and Transmit Buffer settings to Low(1) (Figure 19).
- 9. Click OK to save the settings and return to the Advanced Port Settings dialog box.
- 10. Click OK to return to the Properties dialog box.
- 11. Click OK to close the Properties dialog box and save all settings.
 - **Note:** If your printer is on a COM port, look at the COM port status by viewing the Communications Port Properties dialog box. From the Start menu, choose Settings and Control Panel.
- 12. From the Control Panel dialog box, double-click on the System icon. The System Properties dialog box appears.
- 13. Click Device Manager. The Device Manager window appear (Figure 20).



Figure 20: Device Manager Window

- 14. Select Ports (COM & LPT). The list of ports appears underneath.
- 15. Select the appropriate COM port and press the Properties button.

Communications Port (COM1) Properties				? ×	
General	General Port Settings Driver Resources				
Ţ	Communications Port (COM1)				
	Device type:	Ports (COM & LP1	Ŋ		
	Manufacturer:	(Standard port typ	ies)		
	Location:	on Intel(R) 82801	DB LPC Interface	e Controller -	
Devic This If you start I	Device status This device is working properly. If you are having problems with this device, click Troubleshooter to start the troubleshooter.				
Device usage:					
Use thi	Use this device (enable)				
			ОК	Cancel	

Figure 21: Communications Port Properties Dialog Box

16. Look under the Device status section on the screen for additional troubleshooting information.

Connecting and Configuring a Modem to an OWS

To connect and configure a modem to an OWS:

- 1. Connect a straight-through cable between the modem and workstation. To avoid disconnection, make sure the cable jackscrews are fastened.
- 2. Select PC Configuration. Figure 22 shows the PC Configuration screen with the Modem Setup button.

NETWORK MAP - PC Configuration	on	×
COM1 Device Type NC Dial[modem] NC Direct	Baud Rate 1200 19200 2400 28800	OK
PrinterMouseNC Dial[ISDN]	 4800 38400 9600 57600 14400 	
COM2 Device Type NC Dial[modem] NC Direct Printer Mouse NC Dial[ISDN]	Baud Rate 1200 19200 2400 28800 4800 38400 9600 57600 14400 57600	Modem Setup
COM3 Device Type NC Direct	Baud Rate 9600 1200 9600 2400 14400 4800 19200	 28800 38400 57600
□ COM4 □ Device Type □ NC Direct □ LPT1 □ LPT2	Baud Rate 1200 9600 2400 14400 4800 19200	 28800 38400 57600
		pcConfig

Figure 22: PC Configuration Screen

3. Select the Modem Setup button and the Modem Setup-PC Configuration dialog box appears (Figure 23). The dialog box shows a communication port selection and a drop-down list box selection that displays a list of currently supported modems.

MODEM SETUP - PC Configuration	×
Modem Port COM1 COM2	ОК
	Cancel
Practical Peripherals PM144MT II External	•
	modemselc

Figure 23: Modem Setup-PC Configuration Dialog Box

4. Select a communication port and a modem brand from the list box, and click OK to copy the selected modem setup string from the MODEM.INI file to the correct spot in the METASYS.INI file.

Note: After restarting the OWS, the modem is initialized with the desired setup string.

Connecting and Configuring a Modem to an NCM

To connect and configure a modem to an NCM:

- 1. Connect a straight-through cable between the modem and the terminal. To avoid disconnection, make sure the cable jackscrews are fastened.
- 2. Use WNCSETUP and the Write Modem operation. Selecting Write Modem produces a dialog box similar to the one described previously for the OWS. Refer to the *NCSETUP for Windows Technical Bulletin (LIT-6360251d)* for details on Write Modem.

Adding User-Defined Modems

Note: If the brand modem you are using is not listed, you may add the new modem to the MODEM.INI file. The file is located in the same directory as the METASYS.INI file.

To add user-defined modems:

1. Under the [OWS] section in the METASYS.INI file, find the User Defined Modem entry as shown in Figure 24 and create a new modem string definition by following the same format as the other modem definitions (Figure 24). The first line contains an asterisk followed by the modem name. The second and third lines contain the modem initialization string following the equal (=) sign.

For OWS modem entry:

```
*ZOOM 56k External
SetCom1ModemProfile=AT&FE0V0X3M1W0S0=1S109=0&C1&D2&Q5&W0&Y0
SetCom2ModemProfile=AT&FE0V0X3M1W0S0=1S109=0&C1&D2&Q5&W0&Y0
*Practical Peripherals PM144MT II External
SetCom1ModemProfile=AT&FE0V0X3M1W0S0=1&C1&D2&W0&Y0
SetCom2ModemProfile=AT&FE0V0X3M1W0S0=1&C1&D2&W0&Y0
*User Defined Modem
SetCom1ModemProfile=REPLACE THIS LINE WITH YOUR STRING
SetCom2ModemProfile=REPLACE THIS LINE WITH YOUR STRING
```

Figure 24: Example of Excerpt from MODEM.INI File

Note: While editing this section, remember to insert the new modem so a User-defined modem line still appears in the list box.

Note: If using V.90 modems with V.34 modems, add S109=0 to the AT modem string. Insert it immediately after S0=1 in the modem string.

Configuring ISDN Modems

Note: The procedure for configuring an ADTRAN ISU Express is the same as the other modems.

To configure ISDN modems (ADTRAN ISU Express):

- Connect a cable between the ADTRAN and either the OWS or the NCM. For the OWS or NCM200, use a 25-pin cable. The cable for a 25-pin COM port is shown in Figure 12 for the OWS. Use a 9-pin cable for the NCM300 and NCM350. The cable for a 9-pin COM port is shown in Figure 13.
- 2. Start Windows operating system on your OWS and use the terminal emulation program to configure the ADTRAN ISU Express.
- 3. Set up a HyperTerminal session when using Windows operating system software. The HyperTerminal wizard prompts you for a session name, a communication connection type (referred to as a connector [Table 10]), and the rest of the communication parameters. Use the settings in Table 10. Following the configuration process, Windows operating system prompts you to save the session.

Parameter	Setting
Baud Rate	19,200 (The baud rate must match the bit rate on the PC/NCM configuration screen.)
Data Bits	8
Stops Bits	1
Parity	None
Flow Control	None
Connector	COM1 or COM2 (depends on current connection)

Table 10: HyperTerminal Parameters

- 4. Type the following commands to program the adapter. Press Enter after each command. Note that these commands use the number 0 (zero), not the letter O.
 - a. After typing the first line and pressing Enter, OK appears below the line you have just typed. When you press Enter after typing the last line, a 0 overwrites the first character of the line.
 - b. AT&F <Enter>
 - c. ATV0E0&W <Enter>

5. Type AT ! V. The ADTRAN PC or NCM configuration menu appears as follows. Verify that your settings match those in the figures.

Note: Lines 4 and 6 on the PC Configuration Menu show the phone number of the OWS. Line 4 shows the phone number with the area code and extension. Line 6 shows the phone number without the area code and extension (Figure 25).

```
ISU Express Configuration Menu (PC)
1) NETWORK options = Dial Line
                                17) CTS Options = Follows RTS
2) Switch Protocol = DMS-100
                                18) CD Options = Normal
3) Call type = Data 64Kbps
                                19) DTR Options = Idle when
                                Off
  SPID 1 = 41422727040111
                                20) DSR Options =DSR forced
4)
                                on
                                21) Flow Control = Hardware
5) SPID 2 =
                                Flow
6) LDN 1 = 2272704
                                22) Data Bits = 8 Data Bits
                                23) Parity Bits = None
7) LDN 2 =
8) Dial options = AT commands
                                24) Stop Bits = 1 Stop Bit
9) Auto answer = Disabled
                                25) PROTOCOL = v.120
                                26) QUICK Setup
10) Answer tone =
No Answer tone
11) Connect Timeout =
30 sec (def)
12) Call Screening =
Answer any
13) Call Routing =
All types->DTE
14) DTE options = Asynchronous
15) Bit Rate = 19200
16) RTS Options = 1 ms delay
```

Figure 25: ADTRAN Configuration for PC

Note: Lines 4 and 6 on the NCM Configuration Menu below show the phone number of the NCM. Line 4 shows the phone number with the area code and extension. Line 6 shows the phone number without the area code and extension (Figure 26).

```
ISU Express Configuration Menu (NCM)
1) NETWORK options = Dial
                                17) CD Options = Normal
Line
2) Switch type = DMS-100
                                18) DTR Options = Idle when
                                Off
3) Call type = Data 64Kbps
                                19) DSR Options = Off idle +
                                test
4)
   SPID 1 = 41422727020111
                                20) Flow Control = Hardware
                                Flow
5) SPID 2 =
                                21) Data Bits = 8 Data Bits
6) LDN 1 = 2272702
                                22) Parity Bits = None
7) LDN 2 =
                                23) Stop Bits = 1 Stop Bit
8) Dial options = AT commands
                               24) PROTOCOL = v.120
9) Auto answer = Enabled
                                25) QUICK Setup
10) Answer tone = No Answer
tone
11) Connect Timeout = 30 sec
(def)
12) Call Screening = Answer
any
13) DTE options =
Asynchronous
14) Bit Rate = 19200
15) RTS Options = 1 ms delay
16) CTS Options = Follow RTS
```

Figure 26: ADTRAN Configuration for NCM

The ADTRAN ISU Express is programmed. Repeat Steps 1 through 4 for each adapter.

Installing the Microsoft Backup Utility

Note: You must install Windows operating system software before installing the Microsoft Backup Utility.

To install the Microsoft Backup Utility:

- 1. Click the Start button on the Windows operating system taskbar. The Start menu appears.
- 2. Click the Settings > Control Panel menu option. The Control Panel appears.
- Double-click the Add/Remove Programs icon in the Program Manager. The Add/Remove Programs Properties dialog box appears.
- 4. Click the Windows operating system Setup tab to bring it to the front of the dialog box (Figure 27).

Refer to the Windows NT Operating System or Windows 2000 Professional Operating System Details section in the Operator Workstation Appendix Technical Bulletin (LIT-1201696) for backup information.

Add/Remove Programs Properties					
Install/Uninstall Wind	dows Setup S	tartup Disk			
To add or remove a component, click the check box. A shaded box means that only part of the component will be installed. To see what's included in a component, click Details.					
🗹 🐻 Accessibility	Options		0.4 MB		
🗹 📻 Accessories			4.2 MB		
🗹 🧇 Communicati	ions		0.7 MB		
🗌 🚭 Disk Tools		0.0 MB			
Microsoft Exc	change		4.6 MB		
Space required:			1.6 MB		
Space available on disk:		40.4 MB			
Description					
Includes options to change keyboard, sound, display, and mouse-behavior for people with mobility, hearing and visual impairments.					
1 of 1 components selected		<u>D</u> etails			
			Have Disk		
	OK	Cancel	<u>A</u> pply		
			setup		

Figure 27: Add/Remove Programs Properties Dialog Box with Windows Setup Tab in Front

5. Click the check box next to Disk Tools and click the Details button to display the Disk Tools dialog box (Figure 28).

Disk Tools		X			
To add or remove a component, click the check box. A shaded box means that only part of the component will be installed. To see what's included in a component, click Details.					
<u>C</u> omponents:					
✓ The Backup		1.2 MB			
Space required: Space available on disk:		2.7 MB 40.0 MB			
Program to backup and save data and files. Supports backup to floppy and tape drives.					
		<u>D</u> etails			
	ОК	Cancel			
		Disktol			



6. Click the check box next to **Backup** to select it and click OK. The dialog box closes and you return to the Add/Remove Programs Properties dialog box.

Installing Metasys PMI New Project Software

Note: Verify all of the prerequisites in the *Commissioning PMI New Project Software* section and perform all of the setup activities, then continue with the installation steps below.

Do not use screen savers on Metasys workstations.

IMPORTANT: You must have administrative privileges to install Metasys PMI software on a PC running Windows 2000 Professional operating system or Windows XP Professional operating system. If not, an error message appears and you cannot install PMI.

To install Metasys PMI new project software:

- 1. Keep Windows operating system software running and close all other software applications.
- 2. Insert the Metasys PMI software CD into the CD-ROM drive.

- 3. Click the Start button on the Windows operating system taskbar. The Start menu appears.
- 4. Click the Run menu option. The Run dialog box appears.
- 5. Type d:/Setup in the Open box and press Enter. Use the appropriate drive letter for the CD-ROM drive. For example, if the CD-ROM is using Drive E, enter e:/Setup instead of d:/Setup.
- 6. Click the appropriate check box to select the software you want to install.
- Select whether you want the program to automatically update your Autoexec.bat file, or whether you want to update it yourself later. If you select to have the file automatically updated, the changes are made directly to the Autoexec.bat file.
 - **Note:** If you select to **not** have the file updated automatically, the Autoexec.bat file is not changed. Instead, a new file containing the necessary changes is created. This file is named Autoexec.jci. It is your responsibility to add the necessary changes to the Autoexec.bat file at a later time. These changes are required for the Metasys N1 system to operate. If you are installing additional software, you must make these changes and reboot the PC before installing other software.
- 8. Select to reboot the PC.
 - **Note:** Some PCs may not automatically reboot. If a reboot does not occur within 10 seconds after clicking the reboot button, manually reboot the PC by pressing Ctrl\Alt\Del or by cycling power.
- 9. In the Logon dialog box, type METASYS, the default password, or type the password appropriate for the restored database to log on the network. If you wait too long, the slide show program begins to run. If this happens, press any key to return to the Logon dialog box.

The Metasys PMI installation is complete. You may now use the OWS functions. For instructions, refer to the *Operator Workstation User's Manual*.

Note: The PMI Software installation process creates four temporary files. These may not be automatically deleted from the hard disk. Check both the WINDOWS and the TEMP directories for these files. Delete both the WINDOWS and the TEMP directories. (The TEMP directory location depends on the directory specified by the TEMP environment variable). The files that may be created are:

- ~INS0163.~MP
- ~INS0363.~MP
- ~INS0463.~MP
- ~INS0762.LIB

Installing Metasys PMI Upgrade Software

Notes: If you are installing over Metasys system Release 5.2 or earlier software, a database conversion is required. The conversion takes place automatically toward the end of the install program. Follow the onscreen instructions given for the conversion. Refer to the *Database Conversion* section in the *Operator Workstation Appendix Technical Bulletin* (*LIT-1201696*) for further information on the archive database conversion.

> Verify all of the prerequisites in the *Commissioning PMI New Project Software* section and perform all of the setup activities, then continue with the installation steps below.

Do not use screen savers on Metasys workstations.

You must have administrative privileges to install Metasys PMI software on a PC running Windows 2000 Professional operating system or Windows XP Professional operating system. If not, an error message appears and you cannot install PMI.

To install Metasys PMI upgrade software:

- 1. Keep Windows operating system software running and close all other applications (for example, Metalink software and Microsoft Office).
- 2. Insert the Metasys system CD into the CD-ROM drive.
- 3. Click the Start button on the Windows operating system taskbar. The Start menu appears.
- 4. Click the Run menu option. The Run dialog box appears.
- 5. Type d:/Setup in the Open box and press Enter. Use the appropriate drive letter for the CD-ROM drive. For example, if the CD-ROM uses Drive E, enter e:/Setup instead of d:/Setup.

- 6. Click on the appropriate check box to select the software you want to install.
- Select whether you want the program to automatically update your Autoexec.bat file, or whether you want to update it yourself later. If you select to have the file automatically updated, the changes are made directly to the Autoexec.bat file.
 - **Notes:** If you select to **not** have the file updated automatically, the Autoexec.bat file is not changed. Instead, a new file containing the necessary changes is created. This file is named Autoexec.jci. It is your responsibility to add the necessary changes to the Autoexec.bat file at a later time. These changes are required for Metasys software to operate. If you are installing additional software, you must make these changes and reboot the PC before installing other software.

A database conversion automatically occurs when upgrading from Metasys Release 5.2 software or earlier. Follow the onscreen instructions given for the conversion. Do not interrupt the conversion. Refer to the *Database Conversion* section in the *Operator Workstation Appendix Technical Bulletin* (*LIT-1201696*) for further information.

8. Select to reboot the PC.

Note: Some PCs may not automatically reboot. If a reboot does not occur within 10 seconds after clicking the reboot button, manually reboot the PC by pressing Ctrl/Alt/Del or by cycling power.

9. Cancel the Metasys software load on Windows operating system startup.

10. Verify that the Autoexec.bat file contains all the lines shown in the sample files provided in the *Autoexec.bat* and *Config.sys Files* in the *Operator Workstation Appendix Technical Bulletin* (*LIT-1201696*).

For information on the WIN.INI, METASYS.INI and SYSTEM.INI file parameters, refer to the *Initialization Parameters Technical Bulletin (LIT-636345)*.

If the OWS is going to connect to the Metasys system via an Internet Protocol (IP) network, refer to the *N1 Ethernet/IP Network Technical Bulletin (LIT-6360175)* for additional configuration requirements.

- 11. Back up the converted database if a database conversion occurred (described in Step 7). Use the Windows operating system Backup Utility.
- 12. Type METASYS at the C:\> prompt and press Enter, or start Windows operating system software and click the Metasys system icon.
- 13. In the Logon dialog box, enter your password to log on to the network.
- 14. Perform a global download for each network (using the Action menu on the Network Map).

Note: If the Metasys system subnet (gate) address of any NCM is being changed, the NCM DDL file must be recompiled before the NCM is downloaded.

If upgrading from Release 5 software or earlier, run WNCSETUP to select a new download file (Lighting Control) for each NCM101 that has an Intelligent Lighting Controller (ILC) device.

- 15. Download all NCMs that are archived at this OWS with Code and Data. To download an NCM, select one NCM from the Network Map, display the Action menu, and select NC Download. In the Download dialog box, choose these options: Code and NC Data, and This PC. Download one NCM at a time. Wait for each download to complete before initiating the next download. During the download, the NCM is not controlling equipment.
- 16. Command desired Demand Limiting Load Rolling (DLLR) load groups to Shedding.

The Metasys PMI upgrade is complete. You may now use the OWS functions. For instructions, refer to the *Operator Workstation User's Manual*.

Note: The install process creates four temporary files. These may not be automatically deleted from the hard disk. It is advised that you check both the WINDOWS and the TEMP directories for these files. Delete both the WINDOWS and the TEMP directories. (The TEMP directory location depends on the directory specified by the TEMP environment variable.) The files that may be created are:

- ~INS0163.~MP
- ~INS0363.~MP
- ~INS0463.~MP
- ~INS0762.LIB

Disabling the Parallel Port Check

If the computer on which you installed PMI software does not have a physical parallel port (many server computers do not have one), you see an error in the event log when PMI first starts up. To eliminate the message perform the following procedure.

Note: This does not affect the operation of the computer if you are not attempting to write to a parallel printer.

Note: You must perform this process **after** PMI software is installed. If you reinstall PMI software for any reason, you must repeat this process. To install PMI software, see *Installing Metasys PMI New Project Software*.

To disable the parallel port check:

- Use Windows Explorer and browse to C:\WINNT\System32\drivers and delete chklpt.sys.
- 2. Browse to C:\FMS\BIN and double-click on chklptu.reg. A dialog box appears and asks if you want to add the information in chklptu.reg to the registry.
- 3. Click Yes. A dialog box appears to tell you that the information was added.
- 4. Click OK.
- 5. Restart the computer.

The parallel port check is now disabled.

Troubleshooting

Global Alarm Indicator Reset

Problem

When upgrading from Metasys Person-Machine Interface (PMI) Release 11.00 or earlier to Metasys PMI Release 12.00, you may experience a problem with the Global Alarm Indicator (GAI) feature.

This problem may occur under the following circumstances:

- One or more workstations are upgraded without upgrading the Network Control Modules (NCMs).
- One or more workstations are upgraded from Metasys PMI Release 11.00 to Metasys PMI Release 12.00 without a subsequent NCM download.
- One or more NCMs are upgraded to Metasys PMI Release 12.00 before all Operator Workstations (OWSs) are upgraded to Metasys PMI Release 12.00.

Symptom

The GAI feature was changed at Metasys (PMI) Release 12.00. As a result, if Network Control Modules (NCMs) running downloaded code at Metasys PMI Release 11.00 or earlier are used with an Operator Workstation (OWS) running Metasys PMI Release 12.00, the NCM may fail to send Global Alarm Indicator updates to the OWS under certain circumstances. This problem usually occurs during an upgrade of the network; however, if you have already upgraded all NCMs and OWSs to Metasys PMI Release 12.00 and are experiencing this problem or are unable to upgrade all the NCMs at this time, follow the procedure in the *Solution* section of this document.

Important: To avoid this problem with the GAI, upgrade all OWSs, then upgrade the NCMs. Complete system-wide upgrades as soon as possible. Do not leave NCMs and OWSs at different revisions of Metasys PMI.

Solution

If you are experiencing this problem, before making any other changes, please verify the following:

- 1. Using Windows Explorer, open the Metasys.ini file.
- 2. Verify that the parameter EnaAlmind is set to 1. This line of the file should read EnaAlmind=1. If the parameter is set to 1, Skip Steps 3 through 5 and continue reading this section. If the parameter is set to 0 (zero), change it to 1 and continue with Step 3.

- 3. Save and exit the Metasys.ini file.
- 4. Shut down and restart Metasys PMI software.
- 5. Verify that the GAIs are now operational from all NCMs. If all GAIs are operational, you are done. If GAIs are still not operational, continue reading this section.

If you are experiencing this problem on an OWS that is connected via the N1 network or Network Controller (NC) Dial, see the *N1 Network/NC Dial Connection* section.

N1 Network/NC Dial Connection

Important: If Metasys PMI Release 12.00 or later is used with NCMs running Metasys software Release 11.00 or earlier, you must test the Global Alarm Indicators for each NCM at each OWS.

When testing the Global Alarm Indicators, if any alarm (red) indicator appears, the feature is working. If not, it is possible to recover using a special utility to reset the Global Alarm Indicator sign-up at the NCMs. This utility does not affect any process or other function running in the NCMs and works if a mixture of Metasys PMI Release 11.00 and Metasys Release 12.00 download code is running on the system.

To reset the Global Alarm Indicator, follow these steps:

- 1. Complete the upgrade to Metasys PMI Release 12.00 at the Metasys Operator Workstation (OWS).
- 2. Log on to Metasys PMI at the Metasys OWS and display the device summary.
- 3. Verify that all NCMs you are testing are online and have been online for several minutes. If some of the defined NCMs are offline, the process may require 30 minutes. In the case of dial-up connections, the modems must be connected for the entire time.
- 4. Use Windows Explorer to execute the program GAIRESET.EXE. This program is located in the directory C:\FMS\BIN.

Note: If all defined NCMs are online, the process should be complete in 5 minutes. If some of the defined NCMs are offline, the process may require 30 minutes. Several messages appear during this operation. The first message, **Running NCM alarm indicator release**, indicates the GAIRESET.EXE program has started. The last messages are **Normal Completion** — **all done** followed by **Please restart Metasys now**. Any other completion messages indicate a problem. Please contact the Field Support Center for assistance identifying the cause of any other completion messages.

Note: When the GAIRESET.EXE program finishes, the Metasys OWS software must be shut down and restarted. Once this is done, Global Alarm Indicators should work for the NCMs that were online.

Metasys N1 Ethernet Communication Problems After Any Metasys PMI Software Upgrade

Problem

Network Control Modules (NCMs) and Operator Workstations (OWSs) on a Metasys N1 Ethernet Network go offline depending on their subnet mask after **any** Metasys PMI software upgrade. This communication problem occurs when you upgrade from **any** version of Metasys PMI software to **any** version of Metasys PMI software, because the install overwrites the Subnet_Mask parameter in the Metasys.ini file with 255.255.255.0.

Workaround

Before you upgrade any version of PMI software, note the Subnet_Mask parameter in the Metasys.ini file. After the PMI upgrade, change the Subnet_Mask parameter in the Metasys.ini file back to the original subnet mask as noted before the upgrade.

If you have already upgraded the software, recover the subnet mask according to the following Windows 2000 operating system procedure.

Windows 2000 Operating Systems

To recover the subnet mask on Windows 2000 operating systems:

1. From the Start menu, select Run. The Run dialog box appears (Figure 29).



Figure 29: Run Dialog Box

2. Type **command** in the Open text box and click OK. The DOS Command Screen appears (Figure 30).



Figure 30: DOS Command Screen

3. At the C:\> prompt, type **ipconfig** and press Enter. The IP Configuration information appears (Figure 31).



Figure 31: DOS Command Screen with IP Configuration Information

- 4. Note the subnet mask.
- 5. At the C:> prompt, type **exit** and press Enter.
- 6. Change the Subnet_Mask parameter in the Metasys.ini file to the subnet mask noted in Step 4.



Controls Group 507 E. Michigan Street P.O. Box 423 Milwaukee, WI 53201

www.johnsoncontrols.com Published in U.S.A.