GE MDS, LLC.

NETio[™] Series

DNP V3 Protocol Communications Supplement





Part No. 05-4874A01, Rev. A March 2009

DNP Protocol

NETio Implementation Summary

This document summarizes the implementation of the DNP V3.00 protocol in NETio. There are a number of important considerations about the DNP implementation in NETio that a user should understand.

- 1. NETio implementation of DNP is Poll/Response, sometimes also referred to as Master/Slave. NETio modules never initiate communication on their own. They communicate only in response to messages and commands issued by host DNP devices.
- NETio supports serial DNP and DNP over UDP/TCP, sometimes referred to as DNP Ethernet. DNP over UDP/TCP requires the use of a NETio AP or an entraNET Access point with the NETio firmware support option.
- 3. NETio Remotes (Base and Expansion Modules) only support the direct interrogation of connected I/O using DNP over UDP/TCP when the host device is connected to the Ethernet port of the NETio Access Point or entraNET Access Point.
- 4. NETio requires that DNP messages and commands must be issued to each NETio module, Remote Base Module, Expansion Module or wireless Expansion Module. Range requests and commands cannot include more than one module; each module must be accessed individually. The DNP ID is assigned to a NETio Remote Base Module and shared by all Expansion Modules physically connected or wirelessly associated with it via WeXP. IMPORTANT: Make sure the DNP driver you are using in the host device support non-contiguous addressing.

Reading and understanding the remainder of this document will simplify the configuration of DNP3 in your NETio system.

DNP Protocol

NETio Architectural Implementation

As described in detail below, the DNP V3.00 protocol is a master/slave protocol. A NETio Base Module and its associated Expansion Modules each have unique DNP addresses. Accessing all I/O points from a NETio unit will require separate DNP messages for the base and it's expansions.

A NETio Base Module will process DNP messages that come from one of three sources depending upon how the user has configured it:

- a) The source is over-the-air from a NETio AP or entraNET AP. This method allows a NETio Base Module to wirelessly communicate with a DNP Master device or system via the NETio AP or entraNET Access Point. The Access Point is where the physical connection to the DNP host is made. The connection can be serial or DNP over UDP/TCP; see the NETio Manual for instructions on how to configure these options.
- b) The source is local. This method allows a NETio Base Module to communicate with a DNP Master device or system physically connected to the serial communication port on the NETio Base Module. See Local-Master-Mode, Protocol-Pass-Through and Direct Mode in the NETio Manual for additional details.
- c) The source is over-the-air from a Direct Mode root or Direct Mode node. This method allows a NETio Base Module to wirelessly communicate with a DNP Master device or system via another NETio Base Module. One of the NETio Base Modules is where the physical connection from the DNP host is made to the **serial** port of the Direct Mode root. See Local-Master-Mode, Protocol-Pass-Through and Direct Mode in the NETio Manual for additional details.

Electrical Interface (Access Point)

The hardware or electrical interface is either the COM2 RS232 connection or the LAN Ethernet interface on the front faceplate of the Access Point module. Data flow is half-duplex. That is, data is never transmitted and received at the same time. Shielded wire should always be used to minimize noise. Refer to the EntraNET Access Point User Manual for correct serial and Ethernet port wiring.

Electrical Interface (NETio Base Module)

The hardware or electrical interface is the COM1 (RJ45) RS232 connection on the front panel of the NETio module. Data flow is half-duplex. That is, data is never transmitted and received at the same time. Shielded wire should always be used to minimize noise. Refer to the NETio User Manual for correct serial port wiring.

Device Profile Document

When configured as a DNP device, the NETio Base Module supports the features listed in the Level 1 DNP V3.00 Implementation (DNP-L1) described in Chapter 2 of the subset definitions. See the DNP protocol website at <u>http://www.dnp.org/</u> for details.

NETio Point Addressing

Within the scope of a DNP network, a NETio Base Module along with its Expansion Modules will appear as independent DNP devices (although communication with the Expansion Modules is only possible through the Base Module). In terms of DNP, each Base Module and Expansion Module(s) has an independent and static I/O point list.

To address a specific I/O point, DNP uses addresses, Object numbers, Variation numbers and Index numbers. The definition of Objects, Variations and Indexes are described in the DNP specifications.

DNP uses 16-bit addressing, ranging from 0x0000 to 0xFFFF. The NETio, however, does not make use of the multicast addresses 0xFFF0 to 0xFFFF. The NETio usage of the remaining Unicast address range is that the upper byte is common to a Base Module and it's Expansions (call this the DNP Id of the NETio unit), while the lower byte is used to select the Base Module or a particular Expansion Module. The Base Module is addressed by using a lower byte value of 0x0 (zero), while Expansion Modules are addressed by using the module's Id as the lower byte value.



Each NETio module (Base or Expansion) acts as an independent DNP device; therefore I/O points start at index 0x0 (zero) for each module.

Examples:

A NETio Base Module has one Type 3 Expansion Module with a Module ID configured to 0x39. The NETio Base Modules has been configured to use the value 0x05 as the upper byte of DNP addresses (the DNP ID).

In order to access digital output 1 on the **NETio Base Module**, send a DNP message with the following:

DNP Destination Address	Object Id*	Point Index*
0x0500	0x0A	0x00

In order to access digital output 6 on the **NETio Expansion Module**, send a DNP message with the following:

DNP Destination Address	Object Id*	Point Index*
0x0539	0x0A	0x05

* See the NETio DNP Device Profile for a list of supported Objects, Variations and Indexes for each module type.

DNP V3.0 Device Profile Document

Supported Functions

DNP V3.0				
DEVICE PROFILE DOCUMENT				
(Also see the DNP 3.0 Implementation Table)				
Vendor Name: GEMDS				
Device Name: NETio EB				
Highest DNP Level Supported:	Device Function:			
For Requests: Level 1	□ Master			
For Responses: Level 1	🖾 Slave			
Notable objects, functions, and/or qualifiers su	upported in addition to the Highest DNP Levels			
Supported (the complete list is described in the	e attached table):			
For static (non-change-event) object requests,	request qualifier codes 07 and 08 (limited			
quantity), and 17 and 28 (index) are supported	. Static object requests sent with qualifiers 07,			
or 08, will be responded with qualifiers 00 or 0	1.			
Maximum Data Link Frame Size (octets):	Maximum Application Fragment Size (octets):			
T	T			
Iransmitted: 292	Iransmitted: 249			
Received 292	Received 249			
Maximum Data Link Re-tries:	Maximum Application Layer Re-tries:			
	⊠ None			
	🗋 Configurable, 0-3			
Requires Data Link Layer Confirmation:				
Mayor				
□ Always				
Sometimes Carfingership on Never Only for multi-former recording on Algeria.				
Configurable ds: Never, Only for matter:	indine messages, of Always			
Requires Application Layer Commution:				
X Never				
 When reporting Event Data 				
When sending multi-fragment response	ses			
Sometimes Configurable as: "Only when reporting event data" or "When reporting event data or				
multi-fragment messages "				
main nagment messages.				

h					
DNP V3.0					
(Also see the DNP 3.0 Implement	ntion Table)				
Timeouts while waiting for:					
Data Link Confirm: 🛛 🖾	None	Fixed at	Variable	Configurable.	
Complete Appl. Fragment: 🗵	None	Fixed at	Variable	Configurable	
Application Confirm:	None	Fixed at	Variable	Configurable.	
Complete Appl. Response: 🗵	None	Fixed at	Variable	Configurable	
Others:					
Sends/Executes Control Operatio	ns:				
WRITE Binary Outputs	Never	Always	Sometimes	🗵 Configurable	
SELECT/OPERATE	Never	Always	Sometimes	⊠ Configurable	
DIRECT OPERATE	Never	Always	Sometimes	Configurable	
DIRECT OPERATE – NO ACK	Never	Always	Sometimes	🖾 Configurable	
Count > 1	🗵 Never	Alwavs	Sometimes	Configurable	
Pulse On	⊠ Never	Always	Sometimes	Configurable	
Pulse Off	🗵 Never	Always	Sometimes	Configurable	
Latch On	Never	Always	Sometimes	🗵 Configurable	
Latch Off	Never	Always	Sometimes	🗵 Configurable	
Queue	🛛 Never	Always	Sometimes	Configurable	
Clear Queue	⊠ Never	Always	Sometimes	Configurable	
		,		5	
Explanation of Configurable: an a	utput must	be set to 'Proto	col Mode' (via	menu	
configuration) for any output con	trol operation	ons to be succes	ssfully perforn	ned. The On/Off	
times and Count value are ignore	:0. nto.uhon	Deporto timo	tagged Dipar	u Innut Change	
no specific variation requested:	nts when	Events when	no specific vo	y input Change	
no specific variation requested.		Events when	no specific ve	indtion requested.	
🗵 Never		🗵 Neve	r		
Only time-tagged		Binary Input Change With Time			
Only non-time-tagged		Binar	Binary Input Change With Relative		
Configurable to send one o	or the	Time			
other	Confi	Configurable			
Sends Unsolicited Responses:		Sends Static	Data in Unsol	icited Responses:	
⊠ Never		🛛 Neve	X Never		
Configurable		Wher	n Device Resto	irts	
Only certain objects		🗆 Wher	When Status Flags Change		
Sometimes (attach explar	nation)		_		
ENABLE/DISABLE UNSOLI	CITED	No other opt	ions are perm	itted.	
Function codes supported					

DNP V3.0			
DEVICE PROFILE DOCUMENT			
(Also see the DNP 3.0 Implementation	on Table)		
Default Counter Object/Variation:		Counters	s Roll Over at:
 No Counters Reported Configurable Default Object Default Variation: Point-by-point list attached 		⊠ N C 1 3 O P	lo Counters Reported configurable (attach explanation) 6 Bits 2 Bits 9ther Value: oint-by-point list attached
Sends Multi-Fragment Responses:			
🗆 Yes			
🗵 No			
Configurable			
Sequential File Transfer Support:			
Append File Mode	Yes	🗵 No	
Custom Status Code Strings	Yes	⊠ No	
Permissions Field	Yes	⊠ No	
File Events Assigned to Class	Yes	⊠ No	
File Events Send Immediately	Yes	⊠ No	
Multiple Blocks in a Fragment Max Number of Files Open	Yes 0	凶 No	

DNP V3.0 Implementation Table

Supported Objects

OBJECT		REQUEST		RESPONSE					
Object Number	Variation Number	Description	Functio Codes (d	on lec)	Qualifier Codes (hex)	Funct	ion Codes (dec)	Quali	fier Codes (hex)
1	0	Binary Input – Any Variation	1	(read)	00, 01 (start-stop) 06 (no range, or all)				
1	1 (default – see note 1)	Binary Input	1	(read)	00, 01 (start-stop) 06 (no range, or all)	129	()	00, 01	(start-stop)
1	2	Binary Input with Status	1	(read)	00, 01 (start-stop) 06 (no range, or all)	129	(response)	00, 01	(start-stop)
10	0	Binary Output – Any Variation	1	(read)	00, 01 (start-stop) 06 (no range, or all)				
10	1	Binary Output	1	(read)	00, 01 (start-stop) 06 (no range, or all)	129	(response)	00, 01	(start-stop)
10	2 (default – see note 1)	Binary Output Status	1	(read)	00, 01 (start-stop) 06 (no range, or all)	129	(response)	00, 01	(start-stop)
12	0	Control Relay Output Block							
12	1 (default – see note 1)	Control Relay Output Block	3 (s 4 (op 5 (dire 6 (dir. op, n	elect) erate) ect op) ioack)	17, 28 (index)	129	(response)	echo	of request
30	0	Analog Input - Any Variation	1	(read)	00, 01 (start-stop) 06 (no range, or all)				
30	2	16-Bit Analog Input	1	(read)	00, 01 (start-stop) 06 (no range, or all)	129	(response)	00, 01	(start-stop)
30	4 (default – see note 1)	16-Bit Analog Input without Flag	1	(read)	00, 01 (start-stop) 06 (no range, or all)	129	(response)	00, 01	(start-stop)
40	0	Analog Output Status	1	(read)	00, 01 (start-stop) 06 (no range, or all)				
40	2 (default – see note 1	16-Bit Analog Output Status	1	(read)	00, 01 (start-stop) 06 (no range, or all)	129	(response)	00, 01	(start-stop)
41	0	Analog Output Block							
41	2 (default – see note 1)	16-Bit Analog Output Block	3 (s 4 (op 5 (dire 6 (dir. op, n	elect) erate) ct op) ioack)	17, 28 (index)	129	(response)	echo	of request
60	0	Class 0 Data* (default to class 0)							
60	1	Class 0 Data	1	(read)	06 (no range, or all)				
80	1	Internal Indications	1	(read)	00, 01 (start-stop)	129	(response)	00, 01	(start-stop)
			2 ((see n	write) ote 3)	00 (start-stop) index=7				
		No Object (function code only)	13 (cold r	estart)		⊮			
l		No object (function code only)				íl			

Note 1: A Default variation refers to the variation responded when variation 0 is requested and/or in class 0 scans.

Note 2: For static (non-change-event) objects, qualifiers 17 or 28 are only responded when a request is sent with qualifiers 17 or 28, respectively. Otherwise, static object requests sent with qualifiers 00, 01, 06, 07, or 08, will be responded with qualifiers 00 or 01.

Note 3: Writes of Internal Indications are only supported for index 7 (Restart IIN1-7)

Note 4: For binary and analog objects (Objects 1, 10, 30, 40), the value of the requested point defaults to 0 (zero) when an error has occurred during a read operation.

DNP Point Lists

Supported Functions

The tables below identify all the default data points provided by the NETio base module and expansion modules.

1.1 Binary Input Points

Binary In	nut Points				
Static (Steady-State) Object Number: 1					
Change Event Object Number: N/A					
Static Va	Static Variation reported when variation 0 requested: 1 (Pinary Input without status)				
Change F	$v_{\rm rest}$ variation reported when variation 0 requested: N/A	1(45)			
Chunge L		Dofault			
		Change			
		Event			
Point	Name/Description	Assigned			
Index	Nulle/Description	Class			
		(1 2 3 or)			
		(1, 2, 5 0) none)			
0	NETio Paco Modulo	Nono			
0	Type 1 Expansion Module	None			
	Type 1 Expansion Module				
	Type 2 Expansion Module				
	Type & Expansion Module				
	Type 7 Expansion Module				
1	NETio Base Module	None			
1	Type 1 Expansion Module	None			
	Type 2 Expansion Module				
	Type 4 Expansion Module				
	Type 6 Expansion Module				
2	Type 2 Expansion Module	None			
2	Type 4 Expansion Module	None			
3	Type 2 Expansion Module	None			
5	Type 4 Expansion Module	None			
4	Type 2 Expansion Module	None			
4	Type 2 Expansion Module	None			
5	Type 2 Expansion Module	none			

1.2 Binary Output Status Points and Control Relay Output Blocks

The following table lists both the Binary Output Status Points (Object 10) and the Control Relay Output Blocks (Object 12). Although writes can be performed directly on Binary Output Status Points, Control Relay Output Blocks (CROB) have been included for completeness. Performing select/operate commands on CROBs has the same effect as performing write commands to Binary Output Status Points and vice versa. Reading a CROB has the same effect as reading the corresponding Binary Output Status Point and vice versa.

Binary Output Status Points Object Number: 10 Default Variation reported when variation 0 requested: 2 (Binary Output Status) Control Relay Output Blocks Object Number: 12				
Point Index	Name/Description	Supported Control Relay Output Block Fields		
0	NETio Base Module	LATCH_ON, LATCH_OFF		
	Type 1 Expansion Module			
	Type 3 Expansion Module			
	Type 6 Expansion Module			
	Type 7 Expansion Module			
1	NETio Base Module	LATCH_ON, LATCH_OFF		
	Type 1 Expansion Module			
	Type 3 Expansion Module			
	Type 6 Expansion Module			
	Type 7 Expansion Module			
2	Type 3 Expansion Module	LATCH_ON, LATCH_OFF		
	Type 7 Expansion Module			
3	Type 3 Expansion Module	LATCH_ON, LATCH_OFF		
4	Type 3 Expansion Module	LATCH_ON, LATCH_OFF		
5	Type 3 Expansion Module	LATCH_ON, LATCH_OFF		

1.3 Analog Inputs

The following table lists Analog Inputs (Object 30). It is important to note that Analog Inputs are transmitted through DNP as signed numbers. Scaling is not available.

Analog Inputs

Static (Steady-State) Object Number: **30**

Change Event Object Number: N/A

Static Variation reported when variation 0 requested: **4 (16-Bit Analog Input without Flag)** Change Event Variation reported when variation 0 requested: **N/A**

Point Index	Name/Description	Default Deadband	Default Change Event Assigned Class (1, 2, 3 or none)
0	NETio Base Module	N/A	none
	Type 1 Expansion Module		
	Type 4 Expansion Module		
	Type 6 Expansion Module		
	Type 7 Expansion Module		
1	Type 4 Expansion Module	N/A	none
	Type 6 Expansion Module		
	Type 7 Expansion Module		

1.4 Analog Output Status Points and Analog Output Control Blocks

The following table lists both the Analog Output Status Points (Object 40) and the Analog Output Control Blocks (Object 41). It is important to note that Analog Output Control Blocks and Analog Output Statuses are transmitted through DNP as signed numbers. Scaling is not available.

Analog C Object Nu Default V Analog C Object Nu	output Status Points umber: 40 ariation reported when variation 0 requested: 2 (16-Bit Analog Output Status) Output Blocks umber: 41	
Point Index	Name/Description	
0	NETio Base Module Type 1 Expansion Module	
1	Type 6 Expansion Module Type 6 Expansion Module	

Converting NETio A/D Counts in Full Scale Mode

All NETio Analog Input and Output values are represented internally in A/D counts. The actual value represented by the counts is based upon whether the analog point is configured as a current or voltage signal.

<u>4-20 mA Signals</u>

For 4-20 mA current inputs or outputs the conversion factor is .00024414. In addition, because the range of the signal is offset from zero (0) by 4 mA, the number 4 must be added to the converted number to get actual milliamps. Therefore:

A count value of 31534 read from NETio equals:

31584 X .00024414 = 7.71 milliamps 7.70 + 4.0 (Zero Offset) = 11.71 milliamps

A DNP command to generate a 12.6 milliamp would use the following count value:

12.6 Milliamps – 4.0 (Zero Offset) = 8.6 milliamps 8.6 / .00024414 = 35246 counts

0-5 Volt and 0-10 Volt Signals

For 0-5 Volt inputs and outputs the conversion factor is .000076295. For 0-10 Volt I/O the conversion factor is .00015259. Since the range begins a zero (0) there is not offset needed. Therefore:

A count value of 54320 read from NETio equals:

For a 0-5 Volt Input: 54320 X .000076295 = 4.14 Volts For a 0-10 Volt Input: 54320 X .00015259* = 8.28 Volts

A DNP command to generate a 3.4 Volt would use the following count value:

For a 0-5 Volt Output: 3.4 / .000076295* = 44564 counts For a 0-10 Volt Output: 3.4 / .00015259* = 22295 counts

* This level of resolution is for mathematical/calculation purposes only. The NETio does not support the use all of the digits displayed in these examples.

Converting NETio A/D Counts with Analog Half Scaling Enabled

When the Analog Half Scaling variable is enabled to allow DNP messages to utilize the 16-bit variation of analog read/write requests, **the full A/D range of NETio is 0-32767**. All NETio Analog Input and Output values are represented internally in A/D counts. The actual value represented by the counts is based upon whether the analog point is configured as a current or voltage signal.

<u>4-20 mA Signals</u>

For 4-20 mA current inputs or outputs the conversion factor is .00048829. In addition, because the range of the signal is offset from zero (0) by 4 mA, the number 4 must be added to the converted number to get actual milliamps. Therefore:

A count value of 31534 read from NETio equals:

31584 X .00048829 = 15.42 milliamps 15.41 + 4.0 (Zero Offset) = 19.41 milliamps

A DNP command to generate a 12.6 milliamp would use the following count value:

12.6 Milliamps – 4.0 (Zero Offset) = 8.6 milliamps 8.6 / .00048829 = 17613 counts

0-5 Volt and 0-10 Volt Signals

For 0-5 Volt inputs and outputs the conversion factor is .00015259. For 0-10 Volt I/O the conversion factor is .00030518. Since the range begins a zero (0) there is not offset needed. Therefore:

A count value of 24320 read from NETio equals:

For a 0-5 Volt Input: 24320 X .00015259= 3.72 Volts For a 0-10 Volt Input: 24320 X .00030518* = 7.44 Volts

A DNP command to generate a 3.4 Volt would use the following count value:

For a 0-5 Volt Output: 3.4 / .00015259* = 22281 counts For a 0-10 Volt Output: 3.4 / .00030518* = 11141 counts

* This level of resolution is for mathematical/calculation purposes only. The NETio does not support the use all of the digits displayed in these examples.