

## STC 160 Head-End Station SAT IF input distributor

**SID 162**



### Notes on the Assembly Instructions.

As well as this supplementary Assembly Instructions, the Assembly Instructions for the STC 160 apply.



GSS  
Grundig SAT Systems GmbH  
Beuthener Strasse 43  
D-90471 Nuremberg

Phone: +49 (0) 911 / 703 8877  
Fax: +49 (0) 911 / 703 9210  
Email: [info@gss.tv](mailto:info@gss.tv)  
Internet: [www.gss.tv](http://www.gss.tv)

# Contents

- 1 Safety regulations ..... 3**
- 2 General information ..... 3**
  - Scope of delivery ..... 3
  - Technical data..... 3
  - Description ..... 4
- 3 Overview ..... 4**
- 4 Installing the SAT IF input distributor ..... 5**
- 5 Connecting the SAT IF input distributor..... 6**
  - 5.1 Connecting the HF connections ..... 6
  - 5.2 Connecting the power supply..... 7
- 6 Final procedures ..... 8**

## 1 Safety regulations



- Assembly, installation and servicing must be carried out by an authorised electrician.
- Switch off the operating voltage of the system before beginning with assembly or service work or pull out the mains plug of the head-end station.
- Do not perform installation and service work during thunderstorms.
- Ensure that the device is adequately ventilated.
- Avoid short circuits!

**For further information please read the safety regulations listed in the assembly instructions for the STC 160 head-end station which pertain to this module.**

## 2 General information

### Scope of delivery

- 1 SAT IF input distributor SID 162
- 8 SAT cables
- 1 CD (assembly instructions)
- 1 Brief Assembly Instructions
- Mounting material

### Technical data

The requirements of the following are met:

73/23/EEC, 89/336/EEC

The product fulfils the guidelines and standards for CE labelling.

Frequency range:	950 ... 2150 MHz
Decoupling of the outputs:	typ. 20 dB
Inputs:	2 F sockets
Input impedance:	75 $\Omega$
Loop through output:	1 F socket
Outputs:	6 + 4 F sockets
Output impedance:	75 $\Omega$
Loss (D) $\rightarrow$ (E) (s. Fig. 2):	9 ... 14 dB
Loop through loss (D) $\rightarrow$ (C):	typ. 5 dB
Loss (B) $\rightarrow$ (F):	9 ... 12 dB
LNB operating voltage supply:	12 V / $\leq$ 800 mA total

## Description

The SAT IF distributor SID 162 is equipped with two SAT IF inputs, one loop-through output and 10 SAT IF outputs. This enables to distribute two reception areas to 4 and 6 SAT IF outputs. Using the loop-through output the reception area 1 can be distributed to the 10 outputs. The F sockets of both reception areas are marked with different colours.




Fig. 1

If the loop-through output is not used it must be terminated using the terminator supplied. The DC power feed of 12 V /  $\leq 800$  mA is used for the power supply of the LNBs connected.

The SAT IF distributor SID 162 is designed exclusively for use in the STC 160 head-end station.

## 3 Overview




Fig. 2

- Ⓐ LNB power connection
- Ⓑ Input 2
- Ⓒ Loop-through output of input 1 Ⓓ with terminator

- Ⓓ Input 1
- Ⓔ Outputs of input 1 Ⓓ
- Ⓕ Outputs of input 2 Ⓑ

## 4 Installing the SAT IF input distributor



Before installing or changing a module or accessory, switch off the head-end station or unplug the power cable from the mains power socket.

Installing the SAT IF input distributor take care that no cables are squeezed off or injured.

- Remove the front cover and the base plate of the STC 160 head-end station (see STC 160 assembly instructions).
- Insert the SAT IF input distributor (1) above the output collector (2) according to fig. 3 so that the LNB power connection (A) is facing the control panel.




Fig. 3

- Fasten the outer sockets of the SAT IF input distributor (3) according to fig. 4 with two nuts and lock washers put under each.




Fig. 4



Tighten the nuts until the teeth on the lock washers have penetrated the exterior coating and a good connection is made between the housing and the SAT IF input distributor.

## 5 Connecting the SAT IF input distributor

### 5.1 Connecting the HF connections

- Connect the outputs (E) and (F) (fig. 2) to the appropriate inputs of the modules.

#### Using one reception area (loop-through mode)

- Connect input (D) of the SAT IF input distributor with one of the pre-installed F terminals (4) in the rear wall of the head-end station (fig. 5) using a HF cable made on-site (length approx. 30 cm).
- Connect the loop-through output (C) with input (B) using a HF cable made on-site (length approx. 30 cm).




Fig. 5

#### Using two reception areas

- Connect inputs (B) and (D) of the SAT IF input distributor with the appropriate pre-installed F terminals (4) in the rear wall of the head-end station (fig. 6) using HF cables made on-site (length approx. 30 cm).
- Terminate the loop-through output (C) with the terminator.




Fig. 6

## 5.2 Connecting the power supply

- Connect plug ⑥ of the cable of the LNB power connection ① (fig. 7) to one of the contacts "LNB power supply" (12 V / 800 mA total).




Fig. 7

## 6 Final procedures



After installing the head-end station, retrofitting accessories or installing modules it is necessary to tighten all cable connections, F terminals and cover screws in order to maintain compliance with current EMC regulations and to ensure a reliable operation.

- Securely tighten the cable connections (F connector) using an open-ended spanner (spanner gap 11 mm).
- Program the modules connected and the head-end station if necessary.
- Position the breakthroughs in the base plate above the fastening screws (2) (fig. 8).
- Push the base plate in direction of the arrow and lock it with the locking screw (1).
- Tighten the fastening screws (2).




Fig. 8

- Tighten the nuts of retrofitted F terminals if applicable.
- Mount the front cover (see STC 160 assembly instructions).