

**KeTop T40**  
Handheld Terminal  
KEBA Standard Protocol  
User's Manual V 1.1



Automation by innovation.

## Notes on This Manual

At various points in this manual you will see notes and precautionary warnings regarding possible hazards. The meaning of the symbols used is explained below.

### **DANGER**

- **DANGER** indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

### **WARNING**

- **WARNING** indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

### **CAUTION**

- **CAUTION** indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

### **CAUTION**

- **CAUTION** used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, may result in property injury.



This symbol reminds you of the possible consequences of touching electrostatically sensitive components.

#### **Note**

*Notes on use of equipment and useful practical tips are identified by the "Notice" symbol. Notices do not contain any information that draws attention to potentially dangerous or harmful functions.*

© KEBA 2005

Specifications are subject to change due to further technical developments. Details presented may be subject to correction. All rights reserved.

Document: version 1.1 / material no.: 61869  
Filename: t40\_stdprot\_en.doc, last saving on: 10. 12. 2004

KEBA AG, Postfach 111, Gewerbepark Urfahr, A-4041 Linz  
Tel.: ++43 / 732 / 70 90-0, Fax: ++43 / 732 / 73 09 10, E-Mail: keba@keba.com, www.keba.com

KEBA GmbH, Ulmer Straße 123, D-73037 Göppingen  
Tel.: ++49 / 7161 / 97 41-0\*, Fax: ++49 / 7161 / 97 41-40

KEBA Corp., 100 West Big Beaver Road, Troy, MI 48084  
Tel. ++1 / 248 / 526 - 0561, Fax: ++1 / 248 / 526 - 0562, E-Mail: schr@us.keba.com

**History**

Modification from / to	Date	Modified pages	Description	Author
V1.0	July 02		First edition	sam
V1.0/V1.1	12-2004	all	New Layout	sam



## Contents

<b>1</b>	<b>Introduction</b> .....	<b>7</b>
<b>2</b>	<b>Connection</b> .....	<b>8</b>
<b>3</b>	<b>Configuration of KeTop T40</b> .....	<b>9</b>
	Configuration Software .....	9
	Configuration.....	9
<b>4</b>	<b>Power-Up Phase</b> .....	<b>10</b>
<b>5</b>	<b>KEBA Standard Protocol</b> .....	<b>11</b>
	Features.....	11
	Structure of Messages .....	11
	Control Characters.....	12
	Checksum Calculation (BCC) .....	12
	Protocol Sequence.....	13
	Overview of Messages.....	14
<b>6</b>	<b>KeTop System Variables</b> .....	<b>16</b>
<b>7</b>	<b>KeTop Functions</b> .....	<b>18</b>
	Keypad.....	18
	LEDs .....	22
	Texts .....	25
	Text Monitor .....	27
	Variables .....	30
	Buzzer Activation .....	35
	System Reset.....	35
	Communication Timeout.....	36
	Menu Access/Exit .....	36
	Special Functions.....	37
	Graphic Functions.....	41
<b>8</b>	<b>Error Messages</b> .....	<b>49</b>



# 1 Introduction

This document is a **supplement** to the user's manual "[KeTop T40 Handheld Terminal – General Information](#)" and exclusively refers to the KEBA standard protocol.

The following chapters describe the communication between the KeTop T40 handheld terminal and a PLC using the KEBA standard protocol.

The data exchange between the HT and the PLC takes place via commands that are explained in this manual on the basis of examples.

This manual does not describe in detail the configuration, the basic functions and the key labelling of the KeTop. For this information, please refer to the manual "[KeTop T40 Handheld Terminal – General Information](#)".

## 2 Connection

The KEBA standard protocol must be operated via a serial interface of the handheld terminal.

For details about the connection of the interfaces, refer to the corresponding chapter in the manual "KeTop T40 Handheld Terminal – General Information".

## 3 Configuration of KeTop T40

### Configuration Software

For setting the device configuration and creating the texts, KEBA supplies a configuration software that is executable under Windows.

The configuration is described in detail in the manual "KeTop T40 Hand-held Terminal – General Information" (e.g. functions for editing the keypad layout and for loading the program) and in general also applies to the KEBA standard protocol coupling.

Therefore this chapter only describes the specific details of the KEBA standard protocol.

### Configuration

#### Selection of protocol

After selecting the "**serial KEBA standard protocol**" the following protocol parameters must be set:

<b>Baudrate</b>	Selection of requested transmission rate: 9600, 19200, 38400, 57600, 115200 Baud.
<b>Parity</b>	The setting of parity is EVEN and cannot be changed.
<b>Data bit</b>	The number of data bits is 8 and cannot be changed.
<b>Stop bit</b>	The number of stop bits is 1 and cannot be changed.

#### Numbering of variables

For the serial data transmission of the KeTop, the following **restriction** must be taken into account in the text editing mode:

User variables may be defined only from variable number 100 on. The range from 1 to 99 is reserved for the system variables (see also chapter "KeTop System Variables").

EXCEPTION: string variables (numbering from 0 to 255)

## 4 Power-Up Phase

The handheld terminal carries out a self-test after turning on. For details about the test steps, refer to the manual "[KeTop T40 Handheld Terminal – General Information](#)".

- ▶ The first part of the test is identical for each KeTop T40 coupling and thus described in the User's Manual "[KeTop T40 Handheld Terminal – General Information](#)".

- ▶ Then the configuration data are loaded.

The following message is displayed:

```
Serial Standard Vx.y
Initializing...
```

In case of an error, the handheld terminal remains in this condition.

- ▶ After the configuration data have been loaded successfully, the following mask appears on the display:

```
Serial Standard Vx.y
Channel: COMn, mmmmm
          ooooo,EVEN,8,1
```

x	program version
n	number of interface port
m	type of interface ( RS232 or RSxx2 for RS232/RS422)
o	baud rate (9600, 19200, 38400, 57600, 115200 Baud)

This mask remains on the display until the PLC activates a text display on the handheld terminal.

## 5 KEBA Standard Protocol

The HT is used in industrial applications, especially for operating machines. Errors in the HT or during data transmission may endanger men and machine. Therefore higher demands are made on the data transmission compared to a standard ASCII terminal, for example.

### Features

- Transmission errors can be recognized reliably through a horizontal and vertical parity check.
- The HT acknowledges whether a message has been received correctly or not. In case of negative acknowledgement, the PLC must repeat the message.
- The acknowledgement enables the PLC to control the time. If the response expected from the HT does not occur, the HT, the connection cable or the interface of the PLC are probably defective.

### Structure of Messages

Each message is started with the control character STX. Then the command and the data are transmitted. The control character ETX terminates the data part. By means of the BCC checksum sent with the message, the receiver checks if the transmission has been completed successfully.

Depending on the command, we distinguish between messages with fixed length and messages with variable length:

#### Messages with fixed length

- The data part may also contain the characters STX (02H) and ETX (03H).

#### Messages with variable length

- The data part only contains printable characters (ASCII code  $\geq 20H$ ), i.e. the beginning and the end of a message are clearly defined by the control characters STX, ETX and BCC.

## Control Characters

Control character	HEX	Description
EOT	04	The HT sends this control character after the power-on self-test or after a reset command.
STX	02	Start of data transmission
ETX	03	End of data transmission
ACK	06	The HT has correctly understood the message it received (correct checksum).
NAK	15	HT has not correctly understood the message it received (wrong checksum). The send station must repeat the message.

## Checksum Calculation (BCC)

The checksum is calculated in accordance with DIN 66219. It always consists of one byte. The following example describes the checksum calculation of the message for activating the buzzer:


E.g.: PLC (control) sends to HT (handheld terminal):

Buzzer activation	STX	<command>	<duration>	ETX	BCC
	02	07	35	03	31

Character No.	Character	HEX	BINARY	Keys on VT100 terminal
1	STX	02	00000010	CNTL B
2	Command	07	00000111	CNTL G
3	Duration	35	00110101	5
4	ETX	03	00000011	CNTL C
5	BCC	31	00110001	1

The BCC checksum is calculated by the XOR logic of all characters beginning after STX and ending before the BCC. In this example the character 5 is calculated by the XOR logic of the characters 2, 3 and 4.

### Protocol Sequence



*Cmd ... Command*

Example of communication between PLC and HT

## Overview of Messages

Function	PLC ---> HT		HT ---> PLC	
	Cmd	Data	Cmd	Data
Keyclick on	'e'	-		
Keyclick off	'f'	-		
Config.: signalize pressing of key	'a'	-		
Config.: signalize releasing of key	'b'	-		
Event "key pressed"			('	[key code]
Event "key released"			)'	[key code]
1-line text call	'p'	[line] (text number)		
4-line text call	'q'	(text No. 0) ... (text No. 3)		
8-line text call	'Q'	(text No. 0) ... (text No. 7)		
16-line text call	'P'	(text No. 0) ... (text No. 15)		
Clear display	'g'	-		
Position cursor	'C'	[line] [column]		
Cursor attribute	'E'	[attribute]		
Text attribute (8-/16-line LCD)	'H'	[attribute]		
Text from cursor position	'B'	"text..."		
Text line 0	'0'	"text..."		
Text line 1	'1'	"text..."		
Text line 2	'2'	"text..."		
Text line 3	'3'	"text..."		
Text line 4	'4'	"text..."		
Text line 5	'5'	"text..."		
Text line 6	'6'	"text..."		
Text line 7	'7'	"text..."		
Text xy (ASCII)	'A'	"line" "column" "text..."		
Text xy (binary)	'T'	[line] [column] "text..."		
Set timeout	't'	[duration]		
Buzzer activation	BEL	"duration"		
Reset (warm start)	'd'	-		
Status configuration	'S'	[status sending time] [reserve (5)] [status content]		
Status			'J'	<..configured contents...>
Request key status	'h'	-		[G1][G2][G3][G4]
Request code of all keys pressed	'c'	-		n * [key code] (0≤n≤5)
Red LED map	'L'	[G1][G2][G3][G4][G5]		
Green LED map	'M'	[G1][G2][G3][G4][G5]		
Red flashing LED map	'F'	[G1][G2][G3][G4][G5]		
Green flashing LED map	'G'	[G1][G2][G3][G4][G5]		
LED on red	'+'	[LED code]		
LED on green	'**'	[LED code]		
LED flashing red	'%'	[LED code]		
LED flashing green	'&'	[LED code]		
LED off	'-'	[LED code]		
Graphic functions:				
Pixel	'Z'P'	(x) (y)		
Line	'Z'L'	(x0) (y0) (x1) (y1)		
Rectangle	'Z'R'	(x0) (y0) (x1) (y1) [fill]		
Circle	'Z'C'	(x) (y) (r) [fill]		
Ellipse	'Z'E'	(x) (y) (rx) (ry) [fill]		
Text	'Z'T'	(x) (y) [fontsize] [font_attr] „text....“		
Line type	'Z'I'	(type)		
Clear window	'Z'c'	(x0) (y0) (x1) (y1)		
Set colors	'Z'o'	[fg] [bg]		
Display of bitmaps	'Z'B'	(bitmap No) (x) (y)		

Function	PLC <---> HT		HT <---> PLC	
	Cmd	Data	Cmd	Data
Request 1-byte variable	'u'	(varNo)	'U'	(varNo) [Wert]
Request 2-byte variable	'v'	(varNo)	'V'	(varNo) (Wert)
Request 4-byte variable	'w'	(varNo)	'W'	(varNo) {Wert}
Request floating point variables	'x'	(varNo)	'X'	(varNo) {Wert}
Request string variables	'y'	[varNo] [length]	'Y'	[varNo] [length] "value"
Send 1-byte variable	'U'	(varNo) [value]		
Send 2-byte variable	'V'	(varNo) (value)		
Send 4-byte variable	'W'	(varNo) {value}		
Send floating point variable	'X'	(varNo) {value}		
Send string variable	'Y'	[varNo] [length] "value"		

Cmd	Command
" "	value in ASCII coding
[ ]	8-bit value in binary coding
( )	16-bit value in binary coding
{ }	32-bit value in binary coding

All values are transmitted in the Motorola format (high byte before low byte).

## 6 KeTop System Variables

System variables offer additional functions to the user. If the system variables are sent with the corresponding index they can activate/deactivate certain functions in the handheld terminal (e.g. automatic sending of key code).

**The system variables range from 1 to 99 and must not be programmed by the user.**

At the system variables, we distinguish between 1-byte, 2-byte and 4-byte variables.

Var No.	Designation	Data type	Access HT PLC	Default value	Description
<b>1-byte variables</b>					
1 (01H)	Reserved	-	- -	-	-
2 (02H)	Reserved	-	- -	-	-
3 (03H)	Reserved	-	- -	-	-
4 (04H)	Reserved	-	- -	-	-
5 (05H)	Reserved	-	- -	-	-
6 (06H)	BEEP	BOOL	R/W	FALSE	Buzzer activation (permanent tone)
7 (07H)	KEY_CLICK_PRESSED	BOOL	R/W	FALSE	Beep when pressing a key
8 (08H)	SEND_PRESSED_KEY_NR	BOOL	R/W	FALSE	The HT sends the key number when a key is pressed.
9 (09H)	SEND_RELEASED_KEY_NR	BOOL	R/W	FALSE	The HT sends the key number when a key is released.
10 (0AH)	Reserved	-	- -	-	-
11 (0BH)	Reserved	-	- -	-	-
12 (0CH)	Reserved	-	- -	-	-
13 (0DH)	SEND_KBD_MAP	BOOL	R/W	FALSE	Will not be evaluated.
14 (0EH)	Reserved	-	- -	-	-
15 (0FH)	Reserved	-	- -	-	-
16 (10H)	Reserved	-	- -	-	-
17 (11H)	SYSTEM_RESET	UINT8	W	-	System reset at bitmap 55H
18 (12H)	FETCH_TEXT_VAR	BOOL	W	FALSE	Upon text calls, the HT requests once all output variables contained in the text.
19 (13H)	SEND_PRESSED_KEY_CODE	BOOL	R/W	FALSE	Will not be evaluated.
20 (14H)	ORDER_BOX	UINT8	W	-	Will not be evaluated.
21 (15H)	KEY_CLICK_RELEASED	BOOL	R/W	FALSE	Beep when releasing a key

Var No.	Designation	Data type	Access HT PLC	Default value	Description
22 (16H)	EVENT_VAR_NOT_ON_SCREEN	BOOL	R/W	FALSE	Event message when a variable is written, for which no output field is provided on the display => EVENT_CODE
23 (17H)	DISABLE_MENU	BOOL	R/W	FALSE	Enabling(0) or disabling(1) the main menu call (pressing the 1st and 4th key)
24 (18H)	DISABLE_EDITOR	BOOL	R/W	FALSE	Enabling(0) or disabling(1) the input of variables on the HT
25 (19H)	Reserved	-	- -	-	-
26 (1AH)	Reserved	-	- -	-	-
27 (1BH)	Reserved	-	- -	-	-
28 (1CH)	EVENT_MENU	BOOL	R/W	FALSE	Event message upon menu access and exit => EVENT_CODE
29 (1DH)	KBD_LOCKED	BOOL	R/W	FALSE	Enabling (0) or disabling (1) of the keypad on the HT
30 (1EH)	NEXT_FIELD_AFTER_ENTER	BOOL	R/W	TRUE	After Enter is pressed, the cursor changes to the next input field.
31 (1FH)	SEND_RELEASED_KEY_CODE	BOOL	R/W	FALSE	Will not be evaluated.
32 (20H)	AUTO_KEY_REPEAT	BOOL	R/W	FALSE	Automatic key repetition when key is pressed.

**2-byte variables**

1 (01H)	Reserved	-	- -	-	-
2 (02H)	FETCH_TEXT_VAR_CYCLE_TIME	UINT16	R/W	0	Cycle time in ms at which the HT requests all output variables displayed.
3 (03H)	BEEP_TIME	UINT16	R/W	0	Buzzer activation (duration of beep in ms)
4 (04H)	APPLICATION_SW_VERSION	UINT16	R	-	Version of HT application software Vx.y: High Byte -> x, Low Byte -> y
5 (05H)	DEVICE_TYPE	UINT16	R	-	40 ... KeTop T40
6 (06H)	Reserved	-	- -	-	-
7 (07H)	Reserved	-	- -	-	-
8 (08H)	AUTO_KEY_DELAY_TIME	UINT16	R/W	250	Repetition rate in ms.

**4-byte variables**

1 (01H)	ERROR_CODE	UINT32	W R		Error message HT -> PLC (not used at present)
2 (02H)	EVENT_CODE	UNIT32	W R		Event message HT -> PLC: Bits 24 - 31: event number Bits 0 - 23: event-dependent information

**Access**

R Read  
W Write

**Values ranges of data types used**

BOOL Boolean number (0 = FALSE, 1 = TRUE)  
 UINT8 integral number without sign (0...255)  
 UINT16 integral number without sign (0...65535)  
 UINT32 integral number without sign (0...4294967295)


## 7 KeTop Functions

In this chapter, the commands are first represented in ASCII, and in the second line in HEX in *italics*:

Function	in ASCII:	STX	<command><data>	ETX	BCC
Transmission direction (->) (PLC ... control) (HT... handheld terminal)	<i>in HEX:</i>	02	...	03	...

### Keypad

The following drawing shows the physical grouping of the HT keys and the assignment of the particular keys to the bits of the parameter "key group n". This grouping and assignment is identical for the LEDs of the keypad.



Key Status

<b>Request key status</b>	STX	'h'	ETX	BCC
PLC -> HT	02	68	03	6B

This command requests from the KeTop T40 the bit-coded map of all keys pressed at the moment.

Response	STX	<bitmap key group 1> <bitmap key group 2> <bitmap key group 3> <bitmap key group 4>	ETX	BCC
HT -> PLC	02	...	03	...

This response contains the bit-coded map of the KeTop T40 keypad.


Example

PLC -> HT:

STX	'h'	ETX	BCC
-----	-----	-----	-----

HT -> PLC:

STX	<bitmap key group 1> to <bitmap key group 5>	ETX	BCC
02	80 00 00 02 00	03	81



<b>Request codes of all keys pressed</b>	STX	'c'	ETX	BCC
PLC -> HT	02	63	03	60

This command requests from the KeTop T40 the key codes of all keys pressed at the moment.

<b>Response HT:</b>	STX	{< key code >}	ETX	BCC
HT -> PLC	02	...	03	...

The data part of this response contains in ascending order the codes of all keys pressed at the moment.

**Example**

When the keys 'O', 'M' and '^' are pressed simultaneously, the KeTop T40 sends the following response:

HT -> PLC:

STX	'O' 'M' '^'	ETX	BCC
02	30 4D 5E	03	20

If no key is pressed no response will be sent.

<b>Keyclick on Keyclick off</b>	STX	['e'] ['f']	ETX	BCC
PLC -> HT	02		03	

After receiving the 'e' command, the HT acknowledges every pressed key with an audible signal. The 'f' command deactivates the keyclick again.

- 'e' activate keyclick
- 'f' deactivate keyclick

### Configuration

<b>Signalize pressing of key</b> <b>Signalize releasing of key</b>	STX	'a' 'b'	ETX	BCC
PLC -> HT	02	61 62	03	62 61

After receiving one of these commands the HT sends the key code each time a key is pressed and/or released.

- 'a' send key code each time a key is pressed
- 'b' send key code each time a key is released

After receiving the 'a' command, the HT will send the event message „key pressed“ each time a key is pressed.

After receiving the 'b' command, the HT will send the event message „key released“ each time a key is released.

Thus the handheld terminal becomes the active station in both cases and sends the key code without corresponding request from the PLC.

### Event

<b>Key pressed</b> <b>Key released</b>	STX	('' )'	<key code>	ETX	BCC
HT -> PLC	02	28 29	...	03	...

- (' The key code of the pressed key is sent to the PLC (after initialization by the 'a' command).
- )' The key code of the released key is sent to the PLC (after initialization by the 'b' command).

### Example

PLC -> HT:

STX	'b'	ETX	BCC
02	62	03	61

Assumption:

On the KeTop T40, the 2<sup>nd</sup> key from the left in the second row (character 5) is pressed. Each time this key is released, the KeTop sends the following message to the PLC:


HT -> PLC:

STX	'y'	5	ETX	BCC
02	29	35	03	1F

## LEDs

The following drawing shows the physical grouping of the LEDs on the KeTop T40 and the assignment of the individual LEDs to the bits of the parameter „LED group x“.

### Physical grouping



LED groups on KeTop T40 keypad

**Notice**  
 The LEDs of the keys „Shift Lock“, „Ctrl Lock“ and „Alt Lock“ are activated internally by the HT and cannot be switched by the PLC.

LED bitmap LED flashmap	STX	'L' 'M' 'F' 'G'	<bitmap LED group 1> <bitmap LED group 2> <bitmap LED group 3> <bitmap LED group 4> <bitmap LED group 5>	ETX	BCC
PLC -> HT	02	4C 4D 46 47	...	03	...

These commands switch on/off the red LED (No. 34) and all green LEDs on the KeTop T40 according to the parameters <bitmap LED group 1> to <bitmap LED group 5> or switch these LEDs to a flashing mode (the flashing frequency is 2 Hz).

'L' or 'M'      switch on all LEDs set to 1  
'F' or 'G'      switch all LEDs set to 1 to the flashing mode

**Important**


- All 5 groups must be specified even if one group does not have any LED activation.

The commands 'F' and 'G' for switching the LEDs to the flashing mode have the priority over the commands 'L' and 'M'.

**Example**

PLC -> HT:

STX	'M'	<bitmap LED group 1> to <bitmap LED group 5>	ETX	BCC
02	4D	21 79 60 5A 00	03	2C



LED on / off / flashing	STX	[ '+' ] [*] ] ['_'] ['%'] ['&']	<LED No.>	ETX	BCC
PLC -> HT	02	[ 2B ] 2A 2D 25 26 ]	...	03	...

According to the LED No., the LEDs can be switched on, off or to the flashing mode:

- '+' or '\*'      switch on LED
- '\_'              switch off LED
- '%' or '&'      let LED flash, flashing frequency 2 Hz

**Example**

PLC -> HT:

STX	['*']	"	ETX	BCC
02	2A	22	03	5A

On the KeTop T40, the ASCII character " (decimal 34) switches the LED with the number 34.

## Texts

Using the programming software the texts are created on a PC and loaded into the handheld terminal. The PLC can call texts line by line by sending the text number and the line number to the HT where these numbers will be displayed.

Furthermore the handheld terminal offers the possibility to display and alter variables directly on the device. In the programming software, input and output fields for the variables can be defined in the text lines.

The KeTop T40 provides memory for variables and texts of 192kBytes.

### Memory needed

Text	24 bytes
Variable	6 bytes

If 5000 texts are created, for example, there will remain space for approx. 12500 variables.

### Text Variables

The numbers of text variables range from 100 - 65535 (for system variables, the range from 0 to 99 is reserved). We distinguish between the following variables:

- Input variables (HT -> PLC)
- Output variables (PLC -> HT)
- Input/output variables (PLC <-> HT)

<b>Text call</b>	STX	'p'	<line> <text number>	ETX	BCC
		'q'	<textNo-H line 0> <textNo-L line 0> to <textNo-H line 3> <textNo-L line 3 >		
		'Q'	<textNo-H line 0> <textNo-L line 0> to <textNo-H line 7> <textNo-L line 7>		
		'P'	<textNo-H line 0> <textNo-L line 0> to <textNo-H line 15> <textNo-L line 15>		
PLC -> HT	02	70 71 51 50	...	03	...

The PLC calls the texts from the internal text memory of the HT. If the number FFFFH is specified as text number the corresponding display line will not be overwritten.

The commands 'q' and 'Q' must always contain the text numbers for all 4, 8 or 16 lines.


If the text call contains more lines than are available on the display only the first lines of the text call will be displayed.

- 'p' 1-line text call
- 'q' 4-line text call
- 'Q' 8-line text call
- 'P' 16-line text call
- TextNo-H text number, high byte
- TextNo-L text number, low byte

**Example**

PLC -> HT:

STX	'q'	<TextNo-H line 0 > to <TextNo-L line 3>	ETX	BCC
02	71	00 01 00 03 FF FF 01 36	03	47



## Text Monitor

With the exception of the 'g' command („Clear display“), all text monitor functions work independently of the text functions.

### Notice

*If a text mask with input or output fields is activated on the display before a text monitor function is called, the display will be overwritten. The stored cursor positions for the input and output fields are preserved. => Risk of inconsistency of display.*

<b>Clear display</b>	STX	'g'	ETX	BCC
PLC -> HT	02	67	03	64

Deletes all characters displayed at the moment.

<b>Position cursor</b>	STX	'C'	<line> <column>	ETX	BCC
PLC -> HT	02	43	...	03	...

Range: 8-line LC display

(0/0) to (7/19)

<b>Cursor attribute</b>	STX	'E'	<attribute>	ETX	BCC
PLC -> HT	02	43	...	03	...

Attribute: 0H cursor not visible  
FFH cursor visible

<b>Text attribute</b>	STX	'H'	<attribute>	ETX	BCC
PLC -> HT	02	48	...	03	...

The text attribute specifies how texts are represented on the display. The following settings are allowed:

Attribute: 01H normal display  
02H inverse display  
05H normal flashing display  
06H inverse flashing display

Text from cursor position	STX	'B'	<text>	ETX	BCC
PLC -> HT	02	42	...	03	...

This command displays the transmitted text from the current cursor position. The remaining part of the display remains unchanged. The characters for which there is no space in the corresponding line will be displayed in the next line.

Text line 0 to 7	STX	'0' '1' '2' '3' '4' '5' '6' '7'	<text>	ETX	BCC
PLC -> HT	02		...	03	...


These commands are used for the output of a text in the specified line. If the text does not need the space of the entire line the remaining characters must be filled with blanks (20H).

**Example**

The text "Hallo !" should be displayed in line 0.

PLC -> HT:

STX	0	H a l l o !	ETX	BCC
02	71	48 61 6C 6C 6F 21 20 20 20 20 20 20 20 20 20 20 20 20 20 20 20	03	54



Text xy (ASCII/binary)	STX	'A'	<30H+line> <30H+column>	ETX	BCC
		'T'	<line> <column>		

PLC -> HT	02	41 51	...	03	...
-----------	----	----------	-----	----	-----

This command positions a text on the display at a certain line and column. The remaining part of the display remains unchanged. The characters for which there is no space in the corresponding line will be displayed in the next line.


**Example**

PLC -> HT:

STX	'A'	<30H+line 0>	<30H+column 5>	T	E	S	T	ETX	BCC
02	41	30	35	54	45	53	54	03	51

or

STX	'T'	<line 0>	<column 5>	T	E	S	T	ETX	BCC
02	54	00	05	54	45	53	54	03	46



## Variables

The handheld terminal distinguishes between system and user variables.

### System Variables

The system variables influence the behavior of the HT (also refer to chapter "KeTop System Variables").

Variable numbers:            0 - 99            for 1/2/4-byte variables

Apart from few exceptions, the system variables can be read and written by the PLC.

### User Variables

User variables can be defined as input or output variables within texts.

Variable numbers:            100 - 65535            for 1/2/4-byte variables  
   0 – 255                    for string variables

User variables are not stored in the HT and, thus, cannot be read out by the PLC.

#### Input variables

The input variables are the user variables the user can enter on the handheld terminal. After pressing the Enter key, these variables will be transmitted from the HT to the PLC.

Exception:

If the status message (see chapter "Special Functions") with the content "event variable" has been activated, the entered variable will only be sent with the next status message (polling with FIFO principle) after pressing Enter.


#### Output variables

The output variables are the user variables the PLC can send to the handheld terminal where they are displayed.

The HT will only be able to display the variables if an output field for this variable number has been programmed for at least one of the texts just activated.

If, for the sent variable, no output field is available on the display the HT can inform the PLC about this fact. To activate the transmission of this information, the 1-byte system variable No. 22 (16H) „EVENT\_VAR\_NOT\_ON\_SCREEN“ must be set to TRUE.

For each variable which cannot be displayed, the HT sends the 4-byte system variable No. 2 „EVENT\_CODE“ to the PLC („W“ command).



## Sending Variables

Send 1/2/4-byte variables	STX	'U' 'V' 'W'	<varNo-H><varNo-L><value>	ETX	BCC
PLC -> HT HT -> PLC	02		...	03	...

These commands are used to write integer variables with different lengths:

- 'U' send 1-byte variable (data type UINT8)
- 'V' send 2-byte variable (data type UINT8 and SINT16)
- 'W' send 4-byte variable (data type UINT32 and SINT32)

- VarNo-H variable number, high byte
- VarNo-L variable number, low byte
- Wert 1, 2 or 4 bytes (Motorola format)

Application: system and user variables.

### Example

By sending the variable KEY\_CLICK\_PRESSED (var.No. 07H), a beep should be activated when a key is pressed.

PLC -> HT:

STX	'U'	00 07 01	ETX	BCC
02	55	00 07 01	03	50

Send floating point variable	STX	'X'	<varNo-H><varNo-L><value>	ETX	BCC
PLC -> HT HT -> PLC	02	58	...	03	...

This command is used to write floating point variables with a length of 4 bytes (data type FLOAT32).

The floating point variables are coded in accordance with the IEEE standard.

Application: user variables.

Send string variables	STX	'Y'	<varNo><length><value>	ETX	BCC
PLC -> HT HT -> PLC	02	59	...	03	...

This command is used to write string variables with a variable length (data type STRING).

Application: user variables.

**Requesting Variables**

<b>Request 1/2/4-byte variables</b>	STX	['u'] ['v'] ['w']	<varNo-H><varNo-L>	ETX	BCC
PLC -> HT HT -> PLC	02	[75] [76] [77]	...	03	...

These commands are used to request integer variables with different lengths:

- 'u' request 1-byte variable (data type UINT8 and SINT8)
- 'v' request 2-byte variable (data type UINT16 and SINT16)
- 'w' request 4-byte variable (data type UINT32 and SINT32)

- varNo-H variable number, high byte
- varNo-L variable number, low byte
- Value 1-, 2- or 4-byte (Motorola format)

Application: system variables (PLC -> HT ) and user variables (HT -> PLC).

Response:	The message „send 1/2/4-byte variables“ (command 'U'/'V'/'W') is sent to the receiver as response.
HT -> PLC or PLC -> HT	

<b>Request floating point variables</b>	STX	'x'	<varNo-H><varNo-L>	ETX	BCC
PLC -> HT HT -> PLC	02	78	...	03	...

This command is used to request floating point variables.

varNo-H    variable number, high byte  
varNo-L    variable number, low byte

Application: user variables

Response PLC: PLC -> HT	As response, the PLC must send the message „send floating point variable“ (command 'X').
----------------------------	--

<b>Request string variables</b>	STX	'y'	<varNo><length>	ETX	BCC
HT -> PLC	02	79	...	03	...

This command is used to request string variables.

Application: user variables

Response PLC: PLC -> HT	As response, the PLC must send the message „send string variable“ (command 'Y').
----------------------------	--

## Buzzer Activation

<b>Buzzer activation</b>	STX	BEL	<30H+duration>	ETX	BCC
PLC -> HT	02	07	...	03	...

This command activates the signal buzzer of the HT. The length of the audible signal can be set by means of the duration:

$$\text{duration of beep} = 2^{\text{duration}} \times 10\text{ms}$$

The duration value ranges between 0 and 7. Therefore the duration of the beep can be set to a minimum value of 10ms ( $2^0 \times 10\text{ms}$ ) up to a maximum value of 1.28s ( $2^7 \times 10\text{ms}$ ).

## System Reset

<b>System reset (warm start)</b>	STX	'd'	ETX	BCC
PLC -> HT	02	64	03	...

After receiving this command, the handheld terminal performs a warm start (without self-test). The display will be cleared, all LEDs switched off, all settings activated on the HT reset and the handwheel value set to 0. Following that, the HT sends the control character EOT to the PLC.






Status

Status	STX	'S'	<according to configured content>	ETX	BCC
HT -> PLC	02	4A	... ..	03	...

The content and the sending time of the status message ('J' command) depend on the settings of the message „Status configuration“ ('S' command) received before.

Structure



If the bit 0 "response to received message" has been activated with the message "Status configuration", the behavior of the HT will depend on the type of the message received:

- When receiving PLC messages which are not followed by any response data (e.g. "red LED on"), the HT only returns the status message:

Response HT:	STX	'J'	<status data>	ETX	BCC
HT -> PLC	02	4A	....	03	...

Exception:

After the reset command 'd', no status message will be sent.


- In case of PLC messages which are followed by response data (e.g. "request key status") the status message will be sent directly after the response data:

		ID of response ↓			ID of status information ↓		
Response HT:	STX	'..'	<data of response>	'J'	<status data>	ETX	BCC
HT -> PLC	02	..	....	4A		03	...


**Example: Send status configuration and status**

With the status message (command 'J'), the KeTop T40 should send the current key status to the PLC. For that purpose, the „bit 0: key status“ must be set with the message „Status configuration“.


Each time the handheld terminal receives a message from the PLC, the status message too should be sent to the PLC (sending time=01H).



See notice A)




See notice B)



**Notice**  
 A) If the HT receives a message that is not directly followed by a response, the HT will only return the status message to the PLC.  
 B) If the HT receives a message that is directly followed by a response, the HT will return the response including the status information to the PLC.

## Graphic Functions


The graphic functions are activated from the control. The functions enable displaying a text and drawing graphical elements (line, circle, rectangle and ellipsis) at any position of the display (pixel-oriented).




---

Letter A in standard size at x/y position 0/0 of HT display

The messages consist of a graphic command and a sub-command. The messages have the following structure:




---

Structure of message for graphic functions

### Graphical Elements

The elements circle, rectangle and ellipse can be represented as filled areas. To delete a graphical element, draw the same element of the same size, at the same position and in inverse color.


If you position graphical elements over existing texts or bitmaps, these texts and bitmaps will be overwritten.

Pixel	STX	'Z' 'P'	<x-H> <x-L> <y-H> <y-L>	ETX	BCC
PLC -> HT	02	5A 50	... ..	03	...

This command enables representing a single pixel at the specified x/y position of the HT display.


Line	STX	'Z' 'L'	<x0-H> <x0-L> <y0-H> <y0-L> <x1-H> <x1-L> <y1-H> <y1-L>	ETX	BCC
PLC -> HT	02	5A 4C	... ..	03	...

This command enables representing a line on the HT display according to the specified x/y coordinates.



<b>Set line type</b>	STX	'Z' 'I'	(line type)	ETX	BCC
PLC -> HT	02	5A 6C	... ..	03	...


This command is used to set a line type on which all other graphical elements are based. This setting remains valid until a new line type is defined.



**Notice**  
 When defining a line type take care to arrange several identical bitmaps one after the other. If you choose an unsuitable bitmap the line might get irregular.

<b>Rectangle</b>	STX	'Z' 'R'	<x0-H> <x0-L> <y0-H> <y0-L> <x1-H> <x1-L> <y1-H> <y1-L> [fill]	ETX	BCC
PLC -> HT	02	5A 52	... ..	03	...

This command enables representing a rectangle on the HT display according to the specified x/y coordinates.




**fill**

0H graphic not filled  
 1H graphic filled

<b>Circle</b>	STX	'Z' 'C'	<x-H> <x-L> <y-H> <y-L> <r-H> <r-L> [fill]	ETX	BCC
PLC -> HT	02	5A 43	... ..	03	...

This command enables representing a circle with the radius r on the HT display at the specified x/y position.




**fill**

- 0H graphic not filled
- 1H graphic filled

<b>Ellipse</b>	STX	'Z' 'E'	<x-H> <x-L> <y-H> <y-L> <rx-H> <rx-L> <ry-H> <ry-L> [fill]	ETX	BCC
PLC -> HT	02	5A 45	... ..	03	...

This command enables representing an ellipse with the radiuses rx and ry on the HT display at the specified x/y position.




**fill**

- 0H graphic not filled
- 1H graphic filled

<b>Clear window</b>	STX	'Z' 'c'	<x0-H> <x0-L> <y0-H> <y0-L> <x1-H> <x1-L> <y1-H> <y1-L> [fill]	ETX	BCC
PLC -> HT	02	5A 63	... ..	03	...

This command enables clearing a rectangular area on the HT display according to the specified x/y coordinates.



This command corresponds to the drawing of a filled rectangle with the set background color.

<b>Set colors</b>	STX	'Z' 'o'	[fg] [bg]	ETX	BCC
PLC -> HT	02	5A 6F	... ..	03	...

This command enables setting the foreground and background color (at present only black or white) for all following graphical elements and graphical texts. The color remains active until another color is set.

**fg (foreground)**

0H white  
FFH black


**bg (background)**

0H white  
FFH black

Display of bitmaps	STX	'Z' 'B'	<bitmap No.-H>< bitmap No.-L> <x> <y>	ETX	BCC
PLC -> HT	02	5A 42	.. .. .. ..	03	...

This command enables representing the content of a Windows bitmap file, stored in the bitmap memory of the handheld terminal, on the HT display at the specified x/y position.

The bitmap size is limited by the display size of the KeTop T40 (128x64 pixels).



During configuration, identification numbers are assigned to the bitmaps.

## Graphical Text

These texts must be prepared in the PLC and can then be sent to the handheld terminal with the command 'Z'T'.

The text can be placed freely on the display. The text characters may be represented in double height or double width. As standard the characters are displayed in the format 5 x 7 pixels (incl. space 6 x 8 pixels). So characters with a double height have a format of 5 x 14 pixels (incl. space 6 x 16 pixels) and characters with a double width 10 x 7 pixels (incl. space 12 x 8 pixels).

Displaying a character means that the area for the character is cleared and, following that, the character is written into the empty field. An existing graphic or bitmap representation will be deleted at this position.

### Notice


*A) Programmed texts stored in the HT can only be displayed in lines or columns. These texts cannot be displayed at any pixel position or with a larger size.*

*B) For graphical texts that are directly sent from the PLC to the handheld terminal display, no editor function is available. That means the HT will not correctly interpret symbols (\_\_\_, ###) for the input and output of variables.*

Text	STX	'Z' 'o'	<x-H><x-L> <y-H><y-L> [font_size] [font_attr] "Text..."	ETX	BCC
PLC -> HT	02	5A 54	... ..	03	...

This command enables representing a maximum of 40 text characters at the specified x/y position of the HT display (provided the characters are not displayed with a double width and begin at the pixel column 0).

The text is displayed up to the end of the line (no line folding and no continuation in the next line).



**font\_size** This parameter defines the size of the text characters on the HT display. The following settings are possible:

- 0 ... normal
- 1 ... double height
- 2 ... double width
- 3 ... double height, double width

**font\_attr** This parameter contains the font attribute and specifies if the transmitted text should be displayed normally, in inverse characters, normally flashing or inverse flashing.


- 0 ... normal
- 1 ... inverse
- 2 ... normal flashing
- 3 ... inverse flashing

## 8 Error Messages

In case of an error caused by the user, the HT triggers a short warning tone. Then an error message will be displayed. In this condition, inputs nor outputs are no longer possible. The device remains inactive until the error is eliminated. Then the error message automatically disappears from the display and the data displayed before the error will appear again.

Possible errors:

### Communication timeout



If this error appears immediately after power-on:

- ▶ check the set protocol parameters of the PLC and the connecting cable.

If this error appears during operation:

- ▶ check the mechanical connection to the PLC and if the PLC still responds to the HT.

