

Volume

1

ROEHRIG ENGINEERING, INC.



Damper Testing Equipment

2VS / 3VS / 5VS / 10VS / 20VS / 30VS

ROEHRIG ENGINEERING, INC.

Shock Absorber Testing Equipment

User Manual

© Roehrig Engineering, INC.
100 Lexington Parkway
Lexington, NC 27292
Phone 336-956-3800 • Fax 336-956-3870

Table of Contents

1. IDENTIFICATION AND MACHINE DESCRIPTION	1
1.1 Dynamometer Identification.....	1
1.2 Manufacturer Identification	1
1.3 Normal Operation and Usage	1
1.4 Incorrect Operation and Usage	2
1.5 Operator Workstation.....	2
2. TECHNICAL DATA	3
2.1 Machine Weights and Measurements	3
2.2 Power Requirements and Hookup	5
Electronics Hookup:	5
Main Motor Hookup:.....	6
2.3 Airborne Noise Emission.....	11
2.4 Other Emissions	11
2.5 Machine Features.....	11
2VS Features:	12
3VS Features:	12
5VS Features:	12
10VS Features:	13
20VS Features:	13
2.6 Accessories.....	14
3. SAFETY.....	16
3.1 Safety Notice.....	16
3.2 Emergency Stop Operation.....	18
3.3 CE Cage / Door Interlock Operation	18
3.4. Personal Protective Equipment	19
3.5. Product Specific Warnings	19
3.6. Machine Danger Zones.....	20
3.7. Other Risks.....	20
3.8. In Case Of Emergency.....	20
4. DYNAMOMETER FUNCTIONALITY	21
4.1 Overview of Dyno Functions.....	21
4.2 WHAT IS A SHOCK DYNAMOMETER.....	21
How It Works	23
Data from an Entire Cycle	26
4.2. Overview of Dyno Operation.....	28
4.3. Running a Test	28
4.4. Swapping Shocks	32
4.5. Changing Stroke	34
To change stroke:	34
5. COMMISSIONING THE DYNO	35
5.1 Anchoring the Dyno.....	35
5.2. Software Installation	36
5.3 Dyno Assembly.....	37
5.4. Initial Operation	41

6. OPERATING THE DYNO	43
6.1 Becoming Familiar with the dyno	43
6.2. Getting Started.....	45
6.3 The Software (Shock6)	46
6.3.1 File.....	47
6.3.2 Edit	52
6.3.3. Graph.....	63
6.3.4. Test	69
6.3.5. Hardware	80
6.3.6. View	81
6.3.7. Settings	82
6.3.8. Window	83
6.3.9. Help	83
6.4. Creating and Running Tests	84
6.5. Viewing and Analyzing the Data	85
Chapter	89
7. MAINTENANCE PROCEDURE	90
As Needed	90
Every TWO Months	90
Yearly Maintenance.....	91
8. APPENDIX	92
8.1 USB to Serial Adapters	92
8.2 Glossary	93
8.3 Shock 6.0 Math Syntax.....	94
Functions	94
Expression	95
Description	95
9. ADDITIONAL DOCUMENTATION.....	101
10. WARRANTY AND SERVICE	102
10.1 Warranty	102
10.2 Technical Support.....	102
10.3 SERVICE POLICY	104
Purchase Conditions	107
1.0 Payment of Purchase Price	107
2.0 Delivery and Transportation.....	107
3.0 Installation and Operator Training	107
4.0 Warranties and Limitation of Liability	108
5.0 Design Changes	109
6.0 Non-Disclosure.....	109
7.0 Entire Agreement / Governing Law / Misc. / Guarantee	109
8.0 Definitions.....	110
9.0 Software License Agreement	110

1. Identification and Machine Description

1.1 Dynamometer Identification

This manual will cover the following Roehrig Crank Dynamometers

2VS – 2HP Crank Dynamometer

3VS – 3HP Crank Dynamometer

5VS – 5HP Crank Dynamometer

10VS – 10HP Crank Dynamometer

20VS – 20HP Crank Dynamometer

30VS – 30HP Crank Dynamometer

1.2 Manufacturer Identification

Roehrig Engineering Inc.

100 Lexington Parkway

Lexington, NC 27295

Phone: +1 336 956-3800

Fax: +1 336 956-3870

1.3 Normal Operation and Usage

The 2, 3, 5VS and the 10, 20, 30VS damper dynamometers are intended for the sinusoidal testing of linear dampers. Any linear damper which is properly installed with the correct fixture may be tested by a trained operator. These units are designed for continuous usage.

1.4 Incorrect Operation and Usage

The 2, 3, 5VS and the 10, 20, 30VS damper dynamometers should never be used to test anything other than a linear damper. The damper must be properly installed using the correct fixtures. Only trained operators can correctly and safely use these machines. The dynamometer should only be used if correctly set up and installed by a professional. The machine may not be run if any safeguards have removed, damaged, or tampered with.

1.5 Operator Workstation

There is no specified or defined operator workstation, however, it is recommended that an operator be present at all times while the machine is running and in reach of the emergency shut off switch.

2.1 Machine Weights and Measurements

5VS Weight – 308lbs (140kg)



10VS Weight – 650lbs (295kg)
20VS Weight – 710lbs (322kg)




Figure 3: 10VS and 20VS Dimensioned Drawing

2.2 Power Requirements and Hookup

The 2, 3, and 5VS require two power hookups, one powers the electronics, and the other powers the motor. Make sure that both connections are properly made before using the dyno!

Electronics Hookup:

The electronics power supply is available in three configurations.

- 2/3/5/10/20/30VS:** Internal Wiring with no wall plug
- 110V Wall Plug
- 220V Wall Plug

An appropriate surge-protected power strip is recommended!

Main Motor Hookup:

Motor horse power is rated based on three phase supply; single phase results in reduction.

The 2VS is available in a 220VAC version only.

The 3 5 and 10VS are available in two configurations, 220V or 380/440VAC. The 20VS is only available in 380/440 VAC. Supply power is a choice that is determined when machine is ordered; main voltage changes require a different inverter internal to the unit. Step down/up transformers can be used in conjunction with unit.

2VS: 220VAC single phase

3VS/5VS: 220VAC US: single or three phase / Europe: single phase or
380/440VAC three phase

10VS: 220VAC US: single or three phase / Europe: single phase or
380/440VAC three phase

20/30VS: 220VAC not available
380/440VAC three phase

Caution	<i>Please review the Yellow Tag attached to the dyno for specific power requirements. If you have any doubts about wiring the dyno, STOP and call a Roehrig representative before continuing. Dynos made for customers in countries other than the U.S. could have different power requirements and should not be wired without consulting an REI representative.</i>
----------------	--


REI recommends using a power box with a fuse-protected breaker installed. For your own convenience, you may want to use the power box in conjunction with an “On/Off” switch, if your power box is not equipped with one. To wire the power in single-phase, the White and Black wires are for power and the Green wire is for ground. The Red wire is not used for a single-phase hookup and should be capped off with a wire-nut. For three-phase power, the White, Red, and Black wires are for power and the Green wire is for ground.

Most European models and other non-US models come equipped with an appropriate plug. In this case, simply plug the dynamometer into the matching receptacle.

**WIRING DIAGRAM FOR SINGLE PHASE POWER HOOK-UP
FOR COUNTRIES WHERE 220V IS MADE USING TWO "HOT" LEGS**


INPUT POWER:
From ground to leg should
have 120VAC
Leg to leg should be 220VAC
Will run on 200 - 240VAC

INPUT POWER:
220VAC Single Phase 220-240
60Hz / 50Hz
2VS - 7 amps service
3VS - 10 amps
5VS - 17 amps
10VS - 34 amps



DANGER Always be sure the power is disconnected to the box before wiring the machine! Use proper lockouts in accordance with local electrical codes!


WIRING DIAGRAM FOR SINGLE PHASE POWER HOOK-UP FOR COUNTRIES WHERE 220V IS MADE USING ONE "HOT" LEG AND A NEUTRAL



DANGER

**Always be sure the power is disconnected to the box
before wiring the machine! Use proper lockouts in
accordance with local electrical codes!**


WIRING DIAGRAM FOR 200-240 VAC THREE PHASE POWER HOOK-UP



NOTE: In non-US countries, where three phase power includes a ground and a neutral, the neutral is not used.

DANGER Always be sure the power is disconnected to the box before wiring the machine! Use proper lockouts in accordance with local electrical codes!

WIRING DIAGRAM FOR 380/440 VAC THREE PHASE POWER HOOK-UP



DANGER Always be sure the power is disconnected to the box before wiring the machine! Use proper lockouts in accordance with local electrical codes!

2.3 Airborne Noise Emission

Sound pressure levels measured at a distance of 1 meter from surface of machine and at a height of 1.6 meters from floor, per CE standard where no specific workstation exists. Sound pressure levels are worst case using a 5VS Damper Dynamometer performing a standard PVP test cycle with 7 speeds up to the maximum frequency of the machine, a warm up, and a gas test. Cycle time is 90sec.

- **Equivalent Continuous A-weighted Sound Pressure Level: 72dB**
- **Peak C-weighted instantaneous Sound Pressure Value: 86dB**

2.4 Other Emissions

The 2, 3, and 5VS damper dynamometers produce no vibrations which are harmful to the operator, since the operator is not in contact with the machine while it is running. There are no other harmful emissions produced by the machine.

2.5 Machine Features

The 2, 3, 5, 10, and 20VS damper dynamometers are fully computer controlled variable motor speed models. They are capable of testing at different strokes, up to 2 inches (50mm) for the 2, 3, and 5VS models and up to 7 inches (175mm) for the 10/20VS. The SHOCK™ Test Control and Damper Analysis software enables you to perform static and dynamic gas tests, temperature or time based warm up of a damper, as well as stop at bottom dead center of the damper stroke. The software also allows the user to run CVP, PVP, or Multi CVP tests. Specifications and features of each model are given on the next page.

2VS Features:

- 2 Hp Motor, 220V
- Zero Lash Belt Drive
- Precision scotch yoke / wear plate system
- 2 Standard English Strokes: 1.00” and 2.00”
- Standard 48” Steel Columns (28” / 700mm eye to eye test area)
- +/- 2000 lbs. S-Beam Load Cell
- 16 bit resolution USB Data Acquisition standard
- Full Computer Control with SHOCK™ Software

3VS Features:

- 3 Hp Motor, 220V or 380/440V
- Zero Lash Belt Drive
- Precision scotch yoke / wear plate system
- 4 Standard English Strokes: 0.50”, 1.00”, 1.50”, 2.00” or
- 4 Standard Metric Strokes: 15mm, 25mm, 40mm, 50mm
- Non-contact Infra Red style Temperature Transducer
- 48” Bright Nickel columns (28” / 700 mm eye to eye test area)
- +/- 5000 lbs. Pancake Load Cell
- 8 Channel Instrumentation and Signal Conditioning System
- 16 bit resolution USB Data Acquisition standard
- Full Computer Control with SHOCK™ Software

5VS Features:

- 5 Hp Motor, 220V or 380/440V
- Zero Lash Belt Drive
- Precision scotch yoke / wear plate system
- 4 Standard English Strokes: 0.50”, 1.00”, 1.50”, 2.00” or
- 4 Standard Metric Strokes: 15mm, 25mm, 40mm, 50mm
- Non-contact Infra Red style Temperature Transducer
- 48” Bright Nickel columns (28” / 700 mm eye to eye test area)
- +/- 5000 lbs. Pancake Load Cell
- 8 Channel Instrumentation and Signal Conditioning System
- 16 bit resolution USB Data Acquisition standard
- Full Computer Control with SHOCK™ Software

10VS Features:

- 10 Hp Motor, 220V or 380/440V
- Zero Lash Belt Drive
- Precision scotch yoke / wear plate system
- 6 Standard English Strokes: 0.75", 1.0", 1.5", 2.0", 3.0" and 3.90" or
- 6 Standard Metric Strokes: 15mm, 25mm, 40mm, 50mm, 75mm, 100mm
- Non-contact Infra Red style Temperature Transducer
- 48" Bright Nickel columns (28" / 700 mm eye to eye test area)
- +/- 5000 lbs. Pancake Load Cell
- 8 Channel Instrumentation and Signal Conditioning System
- 16 bit resolution USB Data Acquisition standard
- Full Computer Control with SHOCK™ Software

20VS Features:

- 20 Hp Motor, 380/440V
- Zero Lash Belt Drive
- Precision scotch yoke / wear plate system
- 7 Standard English Strokes: 0.75", 1.0", 1.5", 2.0", 3.0" and 3.90" and 6.0" or
- 7 Standard Metric Strokes: 15mm, 25mm, 40mm, 50mm, 75mm, 100mm and 150mm
- Non-contact Infra Red style Temperature Transducer
- 48" Bright Nickel columns (28" / 700 mm eye to eye test area)
- +/- 5000 lbs. Pancake Load Cell
- 8 Channel Instrumentation and Signal Conditioning System
- 16 bit resolution USB Data Acquisition standard
- Full Computer Control with SHOCK™ Software

2.6 Accessories

Roehrig Engineering provides a full line of accessories for your 2, 3, 5 and 10/20VS Dyno. Please see the list below.

- IR Temperature Sensor (Standard on 3, 5 10/20VS)
- Various Load Cell Configurations Including:
 - 500lb
 - 1000lb
 - 2000lb
 - 5000lb
- Nickel Plated Columns (Standard on 3VS – 20VS)
- Longer Length Columns
- Pressure Sensor Harness w/Sensors
- USB to serial Adapter
- Add on Spring Rater
- 16 Channel Instrumentation Capability
- Quick Open Front Cover
- Various Clevis Sets Including:
 - Standard Quick Release In 1/2", 5/16" and 1/4"
 - Universal Clevis
 - C-clamp Clevis In Any Size
 - Motorcycle Fork Fixtures
 - Bicycle Tube Fixture
 - Custom Clevis
- Lista Brand Single or Double Drawer Roller Cabinets
- Movement Assisted Crossbar
- Ball Screw Actuated Crossbar
- Self Clamping Crossbar
- Protective Cage Enclosure
- CE Cage with power shut off

3. Safety

3.1 Safety Notice

THE TEST EQUIPMENT DESCRIBED AND WRITTEN ABOUT WITHIN THIS MANUAL MUST BE OPERATED USING PROCEDURES THAT PROVIDE THE MAXIMUM LEVELS OF SAFETY TO PERSONNEL AND TO THE EQUIPMENT ITSELF.

All local and National Safety Standards, together with company-specific safety procedures MUST be observed at all times. It is essential that a detailed study of the information contained within this manual is made before operating the test equipment.

The following guidelines are laid down as MINIMUM recommendations.

Ensure that safety interlocks are fully functional at all times.

Only operate the test equipment after ensuring that no personnel are present in any areas that may be regarded as potentially hazardous. This includes the area around the test equipment and its component parts.

All potential work area hazards must be properly guarded and all guards correctly closed BEFORE the test equipment is operated.

Only trained personnel should operate the test equipment or be allowed to conduct tests using this equipment. The operators MUST be fully conversant with the Safety Considerations, Technical Descriptions and Operating Instructions contained within this manual, before operating the test system.

Always ensure that the test equipment is operated within its design limitations.

The test equipment should only be operated when regular maintenance schedules have been carried out and when it is known that the test equipment is in good working order.

If the test equipment is producing unusual or excessive noise and/or vibration, stop the operation of the test equipment until such a time as the systems have been checked for possible faults.

Maintenance procedures must only be carried out AFTER ensuring that all pneumatic and electrical power has been dissipated and that the electrical power has been disconnected from the main supply.

3.2 Emergency Stop Operation

All Roehrig damper dynamometers described in this manual are outfitted with an emergency stop button. The emergency stop button is a large red button located in plain sight on the front of the machine, and labeled as such. To shut the machine down using the emergency stop button, simply push the button. To release the emergency stop button, twist it in the direction indicated on the button. The machine will not automatically restart when the emergency button is released. The power to the machine must be shut off for one minute in order to reset the machine.

NOTICE	<i>In case of any emergency, push the emergency stop button!</i>
---------------	---

3.3 CE Cage / Door Interlock Operation

CE compliant dynamometers are outfitted with a protective cage and door interlock system. The type of cage, door interlock, and relay system used can vary depending on customer requirements. Supplemental literature is provided for CE dynamometers describing in detail the functionality of that machines' specific cage and interlock system.

3.4. Personal Protective Equipment

Operators should always wear required safety gear for the environment in which they are in. When operating or working near the dynamometer, personnel must always be wearing safety glasses. No loose fitting clothing should be worn, and long hair should be tied back.

3.5. Product Specific Warnings

Warning

Safety glasses must be worn at all times when operating or working near the damper dynamometer!

Warning

Always ensure that all guards and shields are properly installed before operating the machine!

Warning

Always disconnect power before removing front cover when changing the stroke on the crank!

Warning

Only trained operators are permitted to use the damper dynamometer!

Caution

Always be sure that the dynamometer is at bottom dead center before installing the damper. Also be sure that the damper has sufficient travel for the stroke which the dynamometer is set at.

Caution

Always be sure that the damper is installed securely using proper fixtures, and that the crossbar is properly tightened before running a test.

3.6. Machine Danger Zones

There are three danger zones on the damper dynamometer: the drive belt zone in the back of the machine which is guarded by the rear cover; the scotch yoke mechanism in the front which is guarded by the front cover; and the testing area between the crossbar and the actuator shaft which is guarded only on CE machines equipped with a cage.

3.7. Other Risks

The operator should be aware that dampers convert mechanical energy into heat, and therefore the damper being tested may get very hot. Always use caution when handling a damper which has been tested. Also, there is the possibility of a damper failure, which can cause hot oil to be sprayed from the damper itself.

Warning

Dampers may be Extremely Hot after testing. Always handle tested dampers with caution.

3.8. In Case Of Emergency

In case of emergency, press the emergency stop button and immediately call for help.

4. Dynamometer Functionality

4.1 Overview of Dyno Functions

The 2, 3, 5 and 10, 20, 30VS dynamometers are capable of carrying out standard PVP (Peak Velocity Plot) or CVP (Continuous Velocity Plot) tests on almost any type of linear damper. The dyno is also capable of running a warm-up cycle on the damper, and can measure both gas force and friction force. The technical paper below describes in more detail the fundamentals of damper dynamometers and their function.

4.2 WHAT IS A SHOCK DYNAMOMETER


Dampers produce a force proportional to the speed of shaft movement. If you compress a damper slowly, it generates less resistant force than if you move it faster. As mentioned before, a damper on a race car does several very important things including providing a tunable “feel” for the driver during cornering, controlling wheel travel over road irregularities, and most important for a ground-effects car, stabilizing the under wing of the car at optimum ride height and rake.

Since dampers are a critical component of a race car, they should be tested periodically to make sure they are working correctly. Also, when a race engineer finds a damper set-up that makes the car faster under certain conditions at a certain racetrack, that engineer will want to have dampers set up the same way the next time the car runs on that or a similar track. As

with any critical component, the race engineer would like to know more about how it works. The shock dyno is a tool used to test dampers and learn about their behavior.

The force vs. shaft speed graphs you see in this article come from data generated by testing a damper in what is generally known as a damper dynamometer or shock dyno. This is a machine that compresses and extends a damper at known speeds and measure the forces produced by the damper.

We'll start out by describing the simplest form of a shock dyno. Figure 1 shows a frame holding an electric motor with a drive belt and pulleys that spins a crank attached to the damper shaft through a linear bearing. As the motor spins the crank, the damper piston moves up and down just like the piston in an engine. Bolt holes in the crank allow several different stroke lengths. Different pulley diameters or a variable speed motor give different crank rotation speeds. The load cell measures the damper force.



We all know that the speed of a piston connected to a crank varies continuously as the crank rotates. You might remember from high school math or physics that this type of motion is called sinusoidal because it varies with the sine of the crank angle. The piston comes to a stop at bottom dead center (BDC), accelerates to a maximum speed halfway up the cylinder, and slows down to a stop again at the top (TDC). If you have a damper attached to a crank, its piston does the same, and the force generated also varies continuously. We know, however, that the maximum speed of the piston happens only once per stroke, when the piston is halfway between top and bottom, and that's also when the damper generates maximum force. With our simple shock dyno we could change the crank stroke to vary the maximum shaft speed and/or we could use drive pulleys of different sizes. However both of these methods are cumbersome and time consuming during testing. Variable speed AC motors allow easy manipulation of the crank RPM.

How It Works

You put a damper in the dyno, choose a stroke and RPM, and turn on the motor. The crank turns and the damper shaft moves up and down until you turn off the motor. If you know the crank RPM, and the stroke, you can calculate the maximum damper shaft speed. For example, let's say the crank turns 100 RPM, and the stroke is 1 inch. 100 rpm is 1.67 revolutions per second and the length of 1 revolution is the circumference of the circle traveled by the crank bolt or π times the stroke. $1.67 \times 3.14 \times 1$ inches is about 5 inches per second. This is the maximum speed of the damper piston, and it happens twice each revolution of the crank, once with the piston going up in compression and once again with the piston going down in rebound.

If we keep this example really simple and connect the damper directly to a weighing scale with a circular dial, we can stand there and read the scale pointer directly. What we'll see is the pointer cycling from 0 to some maximum bump force as the shock compresses, returns to 0, and then peaks out again at the max rebound force as the piston comes back down. The needle on our scale goes from plus some number to minus some number as the damper cycles from compression to rebound and back. We can just write down the numbers at which the

needle peaks as it goes back and forth. A commercially available shock dyno uses a computer to read the load cell and store the data.

Some dampers are set up to give more force in rebound than compression so, as our simple machine cranks away; we might see the scale peak at 190 pounds in compression and 250 pounds in rebound. So we know that, at a shaft speed of 5 inches per second, the damper produces 190 pounds in compression (or bump) and 250 pounds in rebound. We'd like several data points so we can draw a curve. If we reduce the crank speed to 50 RPM, and 25 RPM, and also speed it up to 150, and 200 RPM, this gives us five data points. After we make these runs and read the scale we can make a table like this:


CRANK RPM	MAX SPEED IN/SEC	BUMP FORCE LBS	REBOUND FORCE LBS
25	1.3	75	50
50	2.6	170	150
100	5.2	190	250
150	7.8	220	350
200	10.4	250	470

Chart 1

Presented as a force vs. shaft speed graph, it looks like Figure 2. We generated this data by running the crank at a 1.0" stroke and changing the crank RPM to give us 5 maximum piston speeds, and we read the bump and rebound forces at those maximum speeds. Then we made a graph by connecting the dots. If we want data at higher shaft speeds we need to speed up the crank or lengthen the stroke. Figure 2 shows us that the shock we tested has a pretty steep rebound curve while the compression curve starts low, rises quickly, and then levels off.

The real benefit of a machine like this comes when you test all four dampers off your race car and find out that they all give different readings even though they are supposed to have the same valving, and you've, hopefully, set them all to the same external adjustments before you started the test. Some small difference in readings is OK, but the closer together the better. If you've got the tools and experience, you can overhaul your shocks and test them again. Maybe

you'll find contaminated oil, bad seals, or worn parts. Shocks wear out like any other mechanism and need to be rebuilt periodically.



A shock dyno also allows you to see the effects of external adjustments. If the data above represents settings in the middle of the range of adjustments, varying them in increments from full-hard to full-soft will give you curves that show the effect of those changes. That will happen if your dampers produce changes big enough to be seen by your machine. If you really are just reading a scale by eye you might miss some fine points. That's why people buy dynos instead of building them

Figure 2 above came from data generated by looking at maximum or peak velocities. This is called Peak Velocity Pickoff, and that's the way a simple dyno works. We varied crank speed and the damper stroke to give us peak velocities in our range of interest.

Data from an Entire Cycle

You can get more data from a damper by taking data over a complete cycle of compression and rebound and graphing that. This is called a Continuous Velocity Plot, and there are commercially available damper dynamometers that do this. Figure 1 has notations around the crank for Bottom Dead Center (BDC, 0 deg.), Top Dead Center (TDC, 180 deg.), and 90/270 degrees. When the crank pin is at BDC the damper is fully extended. As the crank rotates clockwise it's compressing the shock in the bump direction so that the damper piston accelerates from a stop to maximum speed at 90 degrees and then slows to a stop again at TDC. Rotation continues and the piston accelerates in rebound direction to maximum speed at 270 degrees and slows to a stop again at BDC.

Figure 3 shows force data taken continuously during one revolution of the crank. Shaft speed in the down direction is positive and compression force is positive. The bottom part of the curve shows shaft speed and negative force increasing as the crank goes from TDC (180 deg.) to 270 degrees and then decreasing as the curve goes back toward zero speed and force at BDC (0 deg.). As rotation continues, speed goes negative (compression) and force increases to a maximum at 90 degrees and back to 0 at TDC (180 deg.). The speed and force data taken to produce a graph like this comes from a velocity sensor and a strain-gauge load cell. A data acquisition system in a personal computer reads these sensors 1,000 times a cycle or more. Software processes the data and displays it in this form.

This can be confusing and you might have to look at this sketch and the graph a while before it becomes clear. The important point is the force increases with piston speed. On the lower section of the curve the piston is accelerating where the curve is headed down and slowing down as the curve swings back up. It's the same on the top part. The piston speed and damping force increase to a maximum and then slow again. This is a lot more data than we had when we just changed crank RPM and looked at the damper force at maximum piston speed. So why doesn't the damper develop the same force when it's slowing down as it did when it speeded up? I'm not certain, myself, but remember you've got a bunch of oil moving through the washer stacks and bypass paths, and it has some mass and momentum. Those washer valves do not necessarily close the same way they open. Also, the fact that the damper

piston is always accelerating, slowing down or speeding up, may have something to do with the shape of this curve.

4.2. Overview of Dyno Operation

Operation of the damper dynamometer is very straight forward. The first step is to power up the dyno and computer system. From the computer, start the Roehrig Shock software (ensure that the software key is installed on the computer). Install the correct set of clevises for the shock which is being tested.

1. Hang the shock from the top clevis, making sure that the crossbar is high enough so that the shock hangs freely above the bottom clevis. Open the test screen in the software, and zero the load cell.
2. Once the load cell is zeroed, the shock can be fully installed. Before installing the shock, ensure that the dyno is at bottom dead center (the actuator shaft is at its lowest position). Lower the cross bar and fix the shock ends to the upper and lower clevis. Lower the crossbar in order to compress the shock to the desired position (Pre-load). Tighten the crossbar.
3. Ensure that the shock has sufficient travel for the given stroke setting on the dyno. Select the desired test from the test screen and start the test. Once the test is complete, save the data and remove the shock.

Caution

<i>Always be sure that the dynamometer is at bottom dead center before installing the damper. Also be sure that the damper has sufficient travel for the stroke which the dynamometer is set at.</i>

4.3. Running a Test

Once the shock is correctly installed, a test may be selected and run. Select a test from the list given in the test screen, or you may create your own.

Step by step running a test.

1. When you are ready to collect data, click on Test in the pull down menu and then click Perform test. This will bring up the Perform Test window
2. Select your test profile and click edit if you wish to make any changes.
3. **At this time be sure the dyno is at bottom dead center.**
4. Hang the shock damper from the upper clevis so that it is not touching lower clevis.
5. Click the "Zero Load Cell" button to zero the load cell and take the weight of the shock out of the data. You can verify the results by looking at the live force reading.
6. Lower the cross bar and connect the damper to lower clevis.
7. Pull cross bar down a minimum of 1/4 inch to pre-load damper and tighten clamps, this is done to prevent the damper from bottoming out in extension.
8. Tighten the clevis handles by turning clockwise until brass button in clevis seats against shock eye. This is done to remove any free play in the damper ends.
9. The program, by default, is set to do an automatic gas test to measure and record the gas force in the shock. If you have changed this setting to do a manual gas test, click "Gas Test" record the gas force.
10. Connect the temperature sensor to the damper body. Skip this step if you have a non-contact (IR) temperature sensor.
11. Click "Start Test" to begin the test.
12. The File Properties window will now appear. Enter data and valving information that you want to save with your data. The constants tab allows you to enter constants related to this damper. This is useful if you are using any math signals (This properties page may appear at the end of the test, or not at all. This is set in the Test tab of the Preferences window.)

File Properties

Description | Constants

Field	Data
Shock Name	
Shock ID	
Vehicle	
Location	
Compression Valving	
Rebound Valving	
Piston Valving	
Other Valving	
Compression Setting	
Rebound Setting	
Preload Setting	
Notes	

Fill from file Fill from last test Clear fields

☒ Ok Cancel

13. Click OK on the File Properties window to continue. The Dyno Starting warning prompt will appear.

Dyno Starting

The dyno is about to start.

The dyno is about to start. When ready, select the 'Ok' button, or select the 'Cancel' button to abort the test.

Warmup Travel: N/A
Gas Test Travel: N/A
Max Test Travel: 0.00 in

Ensure the damper is loaded with enough preload so that it will not bottom out.


Preload (in)
0.00

Damper Travel (in)
0.00


Use Last Entered

☒ Ok Cancel


14. Click OK. The dyno will now start to run. If you have selected to perform a warm-up, it will do that first. It will then run any gas test or seal drag tests that are required. It will then begin running the test(s). Use the "Skip Step" button to cancel out of the warm-up or the gas test and proceed to the next step. Use the "Abort" button to cancel the test completely.



15. Depending on the test you have selected, the dyno may run one speed or several speeds. It may perform additional warm-ups and gas tests. This is all dependant on your settings for the test. If you have selected to pause between runs, the following window will appear. Once you are ready to proceed with the testing click "Continue".



16. After the test is complete the Save As window will appear, name the file and click "Save" to save to the hard drive.



Warning ***Never try to install or swap a shock while the dynamometer is running!***

The program will display the graph of the last collected data file automatically after a test has been run and a name given to the file. File names are displayed on the left side of the main screen.

4.4. Swapping Shocks


Shocks may be swapped on the dyno only when a test cycle is not being run. First, remove the shock which is currently installed by raising the crossbar to remove any pre-load in the shock. Tighten the crossbar. Next, remove the shock from the clevises. Install the correct set of clevises for the new shock which is going to be tested. Hang

the shock from the top clevis, making sure that the crossbar is high enough so that the shock hangs freely above the bottom clevis. Open the test screen in the software, and zero the load cell. Once the load cell is zeroed, the shock can be fully installed. Before installing the shock, ensure that the dyno is at bottom dead center (the actuator shaft is at its lowest position). Lower the cross bar and fix the shock ends to the upper and lower clevis. Lower the crossbar in order to compress the shock to the desired position (Pre-load). Tighten the crossbar. Ensure that the shock has sufficient travel for the given stroke setting on the dyno.

4.5. Changing Stroke

To change stroke:

- 1) Depress the Red Emergency Stop button on the top of the dyno. Once depressed you will have 4 seconds to loosen the crank bolt.
- 2) During the 4 second braking period, use a 1-inch socket to remove the crank bolt.
- 3) Re-set the Emergency Stop button and turn the power off.
- 4) Remove the square bearing from the crank and replace the bearing in hole with the desired stroke.
- 5) Tighten the square bearing until it comes in contact with the crank.
- 6) Turn the power on.
- 7) Press the Emergency Stop button and tighten the crank bolt during the 4 second braking period. Torque crank bolt to 70 ft lbs.
- 8) Re-set the Emergency Stop button, unplug the machine and wait 30-seconds, plug the machine back into power. This will re-set the Emergency Stop error.
- 9) In the software program, go to Hardware / Motor / Yes at the warning. Click Measure Stroke and allow the software to calculate the new stroke. If the number matches your desired stroke, begin testing.



For some 10/20VS models, the E-stop will not provide the necessary braking. In this case, use a physical stop between the yoke and the center actuator shaft block. The physical stop can be an aluminum bar that will stop the movement of the yoke.

5. Commissioning the Dyno

5.1 Anchoring the Dyno

The 2, 3, 5 and 10, 20, 30VS units require no special anchoring when used at a stationary facility. Anchoring the dyno is recommended when the dyno is being used in a ride trailer or other mobile facility. Any type of bracket may be used, as long as it is attached directly to the dyno's aluminum frame and is capable of supporting the loads. Do not attach brackets to either the front or rear cover, or to any moving part on the dyno. Ensure that the brackets do not interfere with any moving parts on the dyno.

The 2, 3 and 5VS dynos may be placed on a workbench, cart, or any other type of stand that can support its weight plus a fluctuating vertical load of +/- 50lbs (+/- 23kg). The surface on which the dyno is placed must be solid and continuous, covering the entire bottom of the machine, as there is no lower guard. The dyno may not be run on its side, unless fitted with special feet and a special lower guard.

The 10/20/30VS units are designed to sit on a solid floor with the factory installed isolation feet. Make sure that the floor can support the full weight of the machine +/- 1,000lbs (46kg).

Warning

The dyno must be placed on a solid continuous surface which covers the entire base of the machine. The dyno may not be run on its side unless fitted with special feet and lower guard.

5.2. Software Installation

The 2, 3, 5 and 10, 20, 30VS dynos require a PC running Microsoft Windows XP or win 7. The PC must have a minimum of two USB ports and one serial port. In the case that the computer has no serial port, a third USB port is required, along with a USB to serial adapter.

- 1) To install the Roehrig Shock6 software, first ensure that the USB software key is NOT inserted.
- 2) Insert the Roehrig CD provided with the dyno. The software installation wizard will automatically load. If it does not automatically load, double click on your CD or DVD drive icon which contains the Roehrig CD under “My Computer”. Follow the on-screen setup instructions. Do NOT insert the software key until prompted. Once setup is complete, your system will need to reboot.
- 3) Once the system is rebooted, locate the *.reg file(s) on the Roehrig CD (Right click the CD or DVD drive icon which contains the Roehrig CD under “My Computer” and select “Explore”). The *.reg file(s) will be located under the main directory on the CD. Double click on the *.reg file(s) to install. You will be prompted “would you like to add these files to the registry”. Click “Yes”. The Roehrig software and the calibration for your dyno are now installed.

Note: The *.reg files only need to be installed if the Roehrig software is being installed for the first time on a particular computer. The *.reg files do not need to be reinstalled if the software is being updated within Shock6. If upgrading from Shock5 (or older) to Shock6, new *.reg files will be provided by Roehrig Engineering.

Note: The Roehrig software may be installed on as many computers as desired allowing users to view and analyze data however, the software key is required in order to run the dyno.



Figure 5.1: Shock 6 USB Software Key

5.3 Dyno Assembly

Step 1a: On the 2, 3 and 5VS, ensure that the columns are fully extended and tightly clamped. To do this, first remove the front cover on the dyno using a 1/8" allen key. Ensure that the columns are fully extended upward, i.e. the stop at the bottom of the column is up against the lower column clamp. If the columns are not fully extended, unclamp the columns and re-clamp them in the fully extended position. The front cover may then be re-installed.

Note: Only the bolt on the slit side of the column clamp needs to be loosened using a 1/4" Allen key.




Figure 5.2: Left Column Fully Extended




Figure 5.3: (Slits on Column Clamps)

Step 1b: On the 10/20VS, the upper columns will be shipped apart from the machine. Remove the front cover using a 1/8-inch Allen Key, loosen the side clamping bolts on the upper column blocks with a 3/16-inch Allen Key (See Number 1 in Figure 6.4). Set the column in the upper block and tighten until it meets the lower column. Tighten the column clamping bolts. Re-install the front cover.

Step 1c: On the 10/20VS slide the crossbar assembly on the columns with the handles facing the operator.

Step 2: Install the IR temperature sensor (if equipped). Using a 3/16" Allen, clamp the IR temperature sensor to one of the columns such that the red handle can be used to loosen and tighten the assembly. This allows the temperature sensor to be easily repositioned for different shocks. Plug the sensor into the "IR Temperature" port on the electronics board located at the left rear corner of the dyno. Tighten the screws on the connector using a small flat head screwdriver.



Figure 5.4: IR Temp. Sensor Installed on Column

Step 3: Connect the load cell cable. Connect the round screw type connector to the load cell. Plug the other end of the load cell cable into the “Load Cell” port on the electronics board. Tighten the screws on the connector using a small flat head screwdriver.




Figure 5.5: Screw Connector on Load Cell

Step 4: Connect the motor control cable (serial cable) to the computer. If the computer does not have a serial port, a serial to USB adapter must be used.




Figure 5.6: Motor Control Cable

Step 5: Connect the USB cable provided to the data acquisition box at the left rear of the dyno. Connect the other end to the computer.




Figure 5.7: All Connections Made

Step 6: Plug the cable from the data acquisition box into the “Data Cable” port on the electronics board. Tighten the screws using a small flat head screwdriver.

NOTE: Setup instructions for 30VS models will be included in the Equipment Installation Guide

5.4. Initial Operation

Once assembly is complete and the software is installed, the dyno can be operated. Ensure that the software key is installed. Start the Roehrig Shock program by double clicking on the icon. Once the software is up and running, the user must verify that both the motor and data card are recognized by the software. There are two boxes in the lower right hand corner of the software with the words “motor” and “datacard”. If the word is shown in a black font, then it is recognized by the software. If the word is shown in a grey font, then it is not recognized by the software.



Figure 5.8: Shock6 Lower Right Corner Screen Shot, Motor and Datacard recognized

If “motor” is in grey, click on “hardware” in the pull down menu and select “motor”. A warning will appear. Click “yes” to continue. Click “configure” and ensure that the correct COM port is selected. If a serial to USB adapter is being used, ensure that it is assigned to a COM port number less than 8 and that it is always plugged into the same USB port. Note that not all serial to USB adapters are compatible. Contact Roehrig for a current list of compatible adapters. If selecting the correct COM port does not correct the issue, contact Roehrig for technical assistance. See Appendix for more details on using a serial to USB adapter.

If “datacard” is in grey, click on “hardware” in the pull down menu and select “datacard”. A warning will appear. Click “yes” to continue. Click “configure”. “Board 0” in the upper left should be selected as the default. Change to “Board 1”. If this does not correct the issue, contact Roehrig for technical assistance.

If both “motor” and “datacard” are shown in a black font, click on “hardware” in the pull down menu and select “motor”. A warning will appear. Click “yes” to continue. Ensure that there is no shock in the machine, and that the crossbar is raised so that the actuator shaft cannot come in contact with it when the machine is run. Select “Measure Stroke”. Once complete, the dyno is ready to run.

Caution

Ensure that there is no shock in the machine, and that the crossbar is raised so that the actuator shaft cannot come in contact with the load cell before measuring the stroke.

6. Operating the Dyno

6.1 Becoming Familiar with the dyno




Figure 6.1: 2 / 3 / 5VS (Left) 10 / 20VS (Right)




Figure 6.2: Dyno Top View Typical

- | | |
|--------------------------|-------------------------|
| 1 – Data Acquisition Box | 2 – Electronics Board |
| 3 – Main Power | 4 – Motor Control Cable |
| 5 – Motor Controller | |




Figure 6.3: 3 / 5VS Damper Dyno

- | | |
|--------------------|-------------------------|
| 1 – Column Clamps | 2 – Velocity Sensor |
| 3 – Actuator Shaft | 4 – Scotch Yoke |
| 5 – Square Bearing | 6 – Displacement Sensor |




Figure 6.4: 10 / 20VS Damper Dynamometer

- | | |
|--------------------|-------------------------|
| 1 – Column Clamps | 2 – Velocity Sensor |
| 3 – Actuator Shaft | 4 – Scotch Yoke |
| 5 – Square Bearing | 6 – Displacement Sensor |

6.2. Getting Started

Once the dyno has been commissioned as described in Section 5, it is now ready for use. First, power up both the dyno and the computer system. Make sure all connections to the computer are made. Once the computer has booted, start the Roehrig Shock program. Load the shock to be tested following the procedure laid out in Section 4.2. The operator can now create and run a test. The following Section will describe the functionality of the Roehrig software in greater detail. All operators should read this manual in its entirety before using the dyno.

6.3 The Software (Shock6)

The following section will describe the various functions and tasks available within the Shock6 program. All the functions and tasks can be reached through the drop down menus at the top of the screen. Some of the more commonly used functions and tasks can also be found on the toolbar, or can be accessed through hot keys. The toolbar can be modified using standard windows procedures. The following figure shows the main program screen.




Figure 6.3: Shock6 Main Screen

NOTE: Data files saved in Shock96 or Shock5 can be opened and viewed with Shock6.

6.3.1 File




Figure 6.4 File Menu

New Template – Creates a new template. Templates allow the user to open, analyze, and save single or multiple data files in one place. The Legend and Tabbed Analysis Window make up a template. Multiple templates can be opened at the same time.

Open Template – Opens a previously saved template.

Save Template – Saves the current template.

Save Template As – Saves the current template as a new template with a unique file name.

Open Data – Opens a previously saved data file and places it in the current template. A data file is created and saved after running a test. A data file contains all the data for a single test only.

Open XML Datafile – Opens a previously saved .xml data file.

Print – Allows the user to print graphs and reports from the current template.




Figure 6.5: Print Options (Graph Layout)

Graph Layout – Allows user to size graph, legend, and notes on the printout. The “show logo” box adds a user defined logo to the “Title” block. The “logo stretch/shrink fit” box adjusts the size of the logo to fit within the “Title” block. The “Legend” and “Notes” blocks can be moved to different positions using the corresponding sliders. Their sizes can be adjusted using the “Divider at” boxes. The number entered in this box is the percent of the page from the top or left from which each block will start.




Figure 6.6: Print Options Window

Report Options – This page allows the user to define all parameters for the numeric report page which is printed after the graph page. To print only the graph page with no report, remove all the checks from the “Data Report” section. To print only the reports, uncheck the “Include Graph” box. To print the actual PVP speeds, enter “0” in the “PVP inc.” box. The graph page and report page can be printed on the same page by checking the “Partial page graph” box and adjusting the graph page size.

Report Fonts – This page defines the font used for each area of the graph and report pages. Double click on each area to open the font dialog box.

Import – Creates a Roehrig data file from imported user data. The imported data must be in a specific Excel format using the correct “short” unit names. The data header and signal definition must be in the exact location. The user can import as many signals as desired. Each signal gets its own column. Imported data cannot be

used for average graphs or data. Always turn off all smoothing when viewing imported data.

Description	Import Test	
Notes	All smoothing must be off!	
Displacement	Force	Velocity
In	lbs	In/sec
0	-500	-12
0	-500	-5
0	-300	-3
0	-100	-1
0	0	0
0	29	1
0	42	3
0	69	5
0	108	12

Figure 6.7: Correct Format for Data Import

“Short” unit names for SHOCK6 import

In	inches
m	meters
cm	centimeters
mm	millimeters
In/Sec	inches per second
m/Sec	meters per second
cm/Sec	centimeters per second
mm/Sec	millimeters per second
Lbs	pounds
N	newtons
KGF	kilograms force
F	Fahrenheit
C	Celsius
RPM	revolutions per minute
Hz	hertz
Ft	feet
Mi	mile
Km	kilometer
Sec	second
Min	minutes
Hr	hours
Ft/Sec	feet per second
MPH	miles per hour
KPH	kilometers per hour
G	grams
Ft/sec^2	feet per second squared
m/sec^2	meters per second squared
In*Lbs	inch pounds
Ft*Lbs	foot pounds
N*m	newton meters
PSI	pounds per square inch

Export – Export is used to export the highlighted data file displayed in the current template. Data files can be exported as an XML or CSV (comma separated value) file. Export selected traces will export only the channels displayed on the current graph. Both options will also export all field data. Raw data may also be exported by using copy and paste from the signal vs. time graph.

Exit – Used to exit the Roehrig Shock6 program.

6.3.2 Edit



Figure 6.8: Edit Menu

Cut – Used to cut the selected item and place it on the clipboard.

Copy – Used to copy the selected item and place it on the clipboard.

Paste – Used to paste the item on the clipboard to the selected location.

Delete – Used to delete the selected item.

Snapshot – Takes a “snapshot” (similar to print screen) of the current graph and legend and places it on the clipboard. The “snapshot” can then be paste into any windows program such as Paint, Word, etc. The size of the “snapshot” can be changed in Preferences (F12).

Show – Click to display/conceal the highlighted data file. This command is also available as a check box on the legend.

Remove Gas Force – Click to include/exclude the gas force from the highlighted data file. This command is also available as a check box on the legend.

Line Style – Changes the line style for the highlighted data file.

File – Allows the user to open and edit the data file properties/description page, also known as “Fields”.

Preferences – Opens the preferences window. The majority of the default settings for the program are found here. Keep in mind, many of these settings can be changed in other areas of the program without affecting the default settings.

Colors – This page controls the default colors and order used when displaying data traces. Left click on the color bring up the color selection window.




Figure 5 Preferences Window - Colors

Legend - This page controls the default colors and fonts for the legend. Click on the color to bring up the color selection window. Click on the font box to bring up the font dialog box.

Hide “Gas Force/Pressure” Column - Check to conceal the “Remove Gas Force” check box in the legend.




Figure 6.10: Preferences Window - Legend

Data – This page contains the default data display options.

Initially Remove Gas Force – Check this box to initially remove gas force from data when displayed.

Assume Shock 96 Data has Gas Force removed- Check this box if importing Shock 96 data which already has the gas force removed.

Filter Shock 96 Data to Single Complete Cycle – Check to display only one complete cycle when importing Shock 96 data.

Sign Convention – Allows user to change the default axis and sign convention used when displaying data.

Avg. Force vs. Velocity Graph – Controls the cursor step size on the average force graph only.

Gas Force/Gas Pressure Display – Default shock shaft diameter used for calculating the gas pressure.




Figure 6.11: Preferences Window - Data

Math Signals – This page allows the user to create additional data channels which are created using constants, math functions, and collected data channels. Math channels are treated the same as collected channels and may be graphed or used in other math channels. The math syntax used in creating these channels is located in the Appendix.




Figure 6.12: Preferences Window - Math Signals

Display – This page contains the default graphing display options.

Display Preferences – Check box options for PVP and CVP data display defaults.

Default Graph – Allows user to determine the default graph which is initially displayed in the analysis window.

Manufacturer's Report – Allows user to determine which two graphs are displayed in the manufacturer's report. The manufacturer's report is only available for PVP test data.




Figure 6.13: Preferences Window - Display

Smoothing – This page is used to place a moving average filter on a selected channel(s). All collected channels and all math channels are listed here. Use caution when using smoothing values above 5. Smoothing can cause phase shifts and attenuation in the data. If using smoothing, it is best to use the same amount of smoothing on all channels.




Figure 6.14: Preferences Window - Smoothing

Field Defaults – Allows user to edit the fields which are stored with each test, and displayed in the report tab. The fields can be edited separately for each type of test. When editing the fields for a specific test, use the insert key to add a row, and the delete key to delete a row. The names for each row can be edited by clicking on that particular cell. The number of lines displayed for each row can also be edited by clicking on the “lines” cell. Constants are number which can be used with math channels.




Figure 6.15: Preferences Window - Field Defaults

Snapshot – This page allows the user to alter the size of the snapshot taken of the graph and legend when using the “snapshot” function.




Figure 6.16: Preferences Window - Snapshot

Folder and Files – This page allows the user to set the default file names and default directories where the files are saved.




Figure 6.17: Preferences Window - Folders and Files

Test – This page allows user to edit default test settings.

Filter Data to Single Complete Cycle – Check this box to display only one cycle from the data collected. The dyno by default runs three cycles at each given speed.

Save Only PVP Peak Vel Points – Check this box to save only the peak velocity data points. Do not check this box to save the entire CVP data for each PVP test speed.

Stop at BDC – Check this box to have the dyno automatically stop at “bottom dead center” after each test.

Enable autofill from last run – Check this option to automatically fill the “Fields” with the data from the last test.

Gas Test Settle Time – This sets the length of time the dyno pauses when measuring the gas force.

Zero Velocity Settle Time – This sets the length of time the dyno pauses when taking the zero velocity recording for a PVP test.

Enter Test Description – Allows the user to choose when the “Fields” are displayed for test description entry.

Data Options – Check these boxes to automatically save a .csv or .xml file when you run and save a test.




Figure 6.18: Preferences Window - Test

Units – This tab allows the user to select the unit type to be displayed. Custom units are a user defined set of Standard and Metric units; change the converted units by clicking on the unit and selecting a new conversion from the drop down list. *Unit Precision* controls the level of precision for each unit type; valid precisions are between zero and five.




Figure 6.19: Preferences Window - Units

Graph – This page allows the user to change the default cursor, grid options, fonts, data trace style, and data trace width.




Figure 6.20: Preferences Window - Graph


PVP Options-The PVP option page allows the operator to select what cycles will be used to generate the PVP compos

Roehrig Engineering historic method-If this option is selected the program will average all collected cycles and use that average as the peak points for the PVP trace. When you check this box you will also be given the option to clip to a single cycle, in this mode the program will use the second to last cycle. This is how previous versions of Shock 6 displayed PVP traces.

PVP cycle selection- This option let the operator select what cycle or group of cycles they would like to use for PVP generation. Any number of cycles can be selected.

Cycles to sample- Defines the number of cycles that dyno will run and the user will have to select from, increase this number to see more cycles under cycle selection.

Peak force and peak velocity method- This method should not be used without contacting REI beforehand to make sure the operator has a complete understanding of the effects on the data.



6.3.3. Graph




Figure 6.21: Graph Menu

Force vs. Velocity – Changes current graph to force vs. velocity graph. Depicts a full 360 degree stroke, showing positive and negative velocity values.

Force vs. Absolute Velocity – Changes current graph to force vs. absolute velocity graph. Depicts a full 360 degree stroke, however, all velocities are shown as positive in value.

Compression Open/Rebound Close – Changes current graph to compression open/rebound close graph. Depicts half of the cycle.

Rebound Open/Compression Close – Changes current graph to rebound open/compression close graph. Depicts other half of the cycle.

Force vs. Displacement – Changes current graph to force vs. displacement. Commonly known as “football” or “potato” plot.

Average Force vs. Absolute Velocity – Changes current graph to average force vs. absolute velocity. Depicts the average of the compression forces and the average of the rebound forces vs. the absolute velocity. Roehrig Engineering does not recommend the use of this graph, as it is a poor representation of the shock data.

Absolute Compression Open/Rebound Close – Changes current graph to absolute compression open/rebound close graph. Same as compression open/rebound close graph, except all force values are shown as positive values.

Absolute Rebound Open/Compression Close – Changes current graph to absolute rebound open/compression close graph. Same as rebound open/compression close graph, except all force values are shown as positive values.

Signal vs. Time – Allows user to plot any signal or math channel vs. time. A menu will appear with a list of all available signals/channels. Select the channel to be graphed. Hold the “Ctrl” key to select multiple channels.

Signal vs. Signal – Allows user to plot any signal or math channel vs. any other signal or math channel. The user must first select the units for the x-axis. Once units are selected, hit “insert plot”. Pull down menus will appear under the x-axis trace and y-axis trace columns with available signals/channels.

Show Live – Allows user to manually operate dyno while showing the live data on the current graph. Enter a speed in the “motor speed” panel and hit enter to start the dyno.

BDC – Moves dyno to “bottom dead center”.

Cycle – Moves dyno one complete cycle at slow speed.

0 Load – Zeros the load cell

Gas Test – Performs a gas test. Result is displayed in “Gas Force” panel.

Pause – Stops the data collection.

Continue – Starts the data collection.

Color – Changes the line color.

Clear – Clears the data collection.

Stop – Stops the motor.

Done – Exits Show Live.



Figure 6.22: Show Live Screen

Toggle Validation – Turns current validation parameters on and off.

Validation Parameters – Allows user to enter a validation table based on a master shock or manually inputted data. This table is visually displayed on the graph, and a “green” or “red” box in the legend indicates if the given data file “passes” or “fails” the validation. Gas force and seal drag can also be included in the validation. Click “Import PVP” to create a validation table based off of a master shock file. The user can choose the deviation (tolerance) as a percentage, absolute, or both. The user can also create a table manually by using the “Insert Row” button and manually entering the appropriate values. Validation tables can be saved using the “Save Validation” button, or previously saved validations can be opened using the “Load Validation” button.

Build Validation Table

Velocity Units: Meters per second Force Units: Newtons

<New Table>

Gas Force Validation
☐ Validate Gas Force

Seal Drag Validation
☐ Validate Seal Drag

Zero Speed Validation

Gas Force Minimum (N) Seal Drag Minimum

Gas Force Maximum (N) Seal Drag Maximum

Zero Speed Minimum Zero Speed Maximum

Velocity	C. Min.	C. Max.	R. Min.	R. Max.	

Clear Table Import PVP... Load Validation... Save Validation... Insert Row

Figure 6.23: Validation Parameters

Validation Color – Allows user to change the color of the displayed validation parameters.

Validation Attributes – Allows user to change the line style of the displayed validation parameters.

Insert – Creates another graph inside the current template. User can toggle between graphs using the tabs displayed on the bottom of the legend.

Delete Graph – Deletes the selected graph from the current template.

6.3.4. Test




Figure 6.24: Test Menu

Create – Allows the user to create and save a test. There are three test profiles which the dyno can perform: CVP (Continuous Velocity Pickoff), PVP (Peak Velocity Pickoff), and Multi-CVP (Multiple Continuous Velocity Pickoffs).




Figure 6.25: Choose Test Type Screen

Select Warm Up Type – Allows user to choose what type of warm up cycle to run on the shock. There are four types of warm up cycles which the dyno can perform.

Do not perform a warmup – When this option is selected, a warm up cycle is not performed.

Run the shock at a set speed for a period of time – The user will be prompted to enter a speed and period of time for the warm up cycle.

Run the shock at a set speed until a particular temperature is reached - The user will be prompted to enter a speed and a target temperature for the warm up cycle.

Specify a set of temperatures to which to warm the shock. Run the specified test once at each specific warm up temperature. – This warm up cycle can only be used with CVP tests. The user is prompted to enter a speed and a table of temperatures. The CVP test will run once at each specified temperature.




Figure 6.26: Select Warmup Window

Select Gas Test Type – Allows users to perform a gas test and/or seal drag test after the warm up cycle is complete. The gas test takes a static force measurement to determine the rod reaction force due to the gas pressure inside the shock. The seal drag test is used to determine the friction force due to the seals in the shock.

Do not perform a gas test – When this option is selected, gas force and seal drag measurements are not taken.

Perform a gas test – The user will be prompted if they would like to override the zero displacement test position. If this box is not checked, the rod reaction force will be measured at zero displacement (mid stroke). If the box is checked, the user will be prompted to enter a new test position. A value of 0 corresponds to mid stroke. Positive or negative values may be entered relative to the mid stroke position. Values entered which are beyond the maximum amplitude of the machine will cause the machine to run endlessly during the gas test cycle.

Perform a seal drag test only – The user will be prompted to enter a test window and speed for the seal drag test. The test window is the amount of displacement on either side of 0 displacement (mid stroke) for which the friction force is measured.

Perform a seal drag test then a gas test – When this option is selected, both a gas force test and a seal drag test are performed.




Figure 6.27a: Gas Test Window

Multi Point Gas Test – Executes a gas test using multiple positions in the compression and rebound direction. Build a table surrounding zero displacement (mid-stroke) using positive and negative displacement values.




Figure 6.27b: Multi Point Gas Test

CVP Test – The user will be prompted to enter the test speed for the CVP test cycle. The minimum and maximum speeds possible for the dyno at the current stroke are displayed.

Durability – In this mode, the CVP test will run for the given number of cycles. The test will collect data on the first cycle only.




Figure 6.28: CVP Test Screen

PVP Test – The user will be prompted to enter a table of speeds at which to run the PVP test. The user may enter the values in the table manually using the “insert” button, or a table can be automatically generated using the “series” button. The PVP graph can be generated using one of three methods: peak velocity pickoff, average values about 0 displacement, or peak force pickoff.

Re-execute gas test prior to each speed – When this option is checked, a gas force test is performed before each speed.

Include zero velocity sample – When this option is checked, a zero velocity data point is measured. This is done at mid stroke. The settle time can be set in “preferences”.

Use peak velocity for each speed to generate PVP trace – When this option is checked, the data points generated correspond to the peak velocities seen for each test speed.

Average values in a window centered around zero displacement – When this option is checked, the data points for each test speed are generated by taking the average values inside the given window centered around zero displacement (mid stroke).

Use peak force for each speed to generate PVP trace – When this option is checked, the data points generated correspond to the peak force values seen for each test speed.




Figure 6.29: PVP Test Window

Multi-CVP – Allows user to run multiple CVP cycles in one test. CVP cycles may be run at the same speed or at different speeds. The user will be prompted to enter a table of speeds at which to run the CVP cycles. The values in the table may be entered manually using the “insert” button, or a table can be automatically generated using the “series” button. An “instruction” may be entered after each speed. This “instruction” will be displayed between cycles if the “Pause after runs” box is checked, and will also be displayed as part of the cycle name when appearing in the legend.

Pause after runs – When this option is checked, the dyno will pause between each CVP cycle, allowing the user to make adjustments to the shock. The test will not resume until the user hits the “continue” button.

Re-execute warmup – When this box is checked, the warmup cycle will run again after each CVP cycle.

Re-execute gas test – When this box is checked, a gas test will be performed after each CVP cycle.




Figure 6.30: Multi-CVP Window

Advanced – This button appears in all three types of test profiles. It allows the user to specify the move to speeds used during the test. Changing the gas test move to speed may change the gas test results. The gas test move to speed and the gas test settle time must be adjusted depending on the shock being tested. The “advanced” button also allows the user to monitor the shock temperature and automatically shut down the test if a given temperature is reached.




Figure 6.31: Advanced Properties Window

Test – Opens the test control panel. The user can select, create, edit, and run tests from this screen. The test names appear in the upper left corner of the test screen. To select a test, simply click on it. To edit a test, double click on it and the edit window will appear. Right clicking on the test allows the user to delete or rename a test. Tests may also be organized into folders. Simply right click on the folder in which you wish to create another folder, and select “new folder”. The tests can be dragged and dropped into the desired folder. To create a test, right click on an existing folder and choose “new test”.

Note: When editing a test, the user has the option of saving it as a new test with a new name by clicking the “save as” button.

Test Profile Column – Upper half of column displays available test hierarchy. Lower half of column displays the name and major parameters for the test which is currently selected.

Commands Column – Contains command buttons

Start Test – Starts the currently selected test.

Skip Step – Skips the current step in the test.

Zero Load Cell – Zeros the load cell reading. The program will retain this zero value until the program is exited or the “zero load cell” button is pressed again.

Cycle Motor - Moves dyno one complete cycle at slow speed.

Go to BDC - Moves dyno to “bottom dead center”. The box to the right of this button indicates if the dyno is at bottom dead center. If the box is “green”, the dyno is at BDC. If the box is “black”, the dyno is not at BDC.

Done – Exits test control panel.

Status Column – Lower half of this column displays live sensor readings and current test step which is being executed.

Abort – This button aborts the current test. Please note: This button is NOT an emergency stop button!

Close after test – When this box is checked, the test control panel will close after the test is complete.

Pause after gas test – When this box is checked, the dyno will pause after the gas test allowing the user to make adjustments to the shock. The dyno will only resume after the user hits the “continue” button.

Results- This box lists data from the last test run.




Figure 6.32: Test Control Panel

Create Batch – Allows user to create a batch test (multiple tests run together). The user can string together any available tests in any order, and have the software automatically run each test and save the data. The available test hierarchy is displayed on the left side of the window. To add a test to the batch, click on the test, and then click on the “right arrow” button. The test will be added to the batch. Tests can be deleted from the batch using the “black X” button. The order of the tests can also be changed using the “up arrow” and “down arrow” buttons. Each test is assigned a default data file name. This name can be changed by the user. If the user does not want to collect and save data for a given test in the batch, simply uncheck the “data” box. The batch test is given a default name in the lower left corner of the window. This name can be changed by the user. Click the “OK” button when finished.




Figure 6.33: Create Batch Test Window

Run Batch – Allows user to run a previously created batch test. Select a batch test from the list. The individual tests for that batch will be listed at the bottom of the window. At this point the batch test can be edited if required. Before running the batch test, the user is required to select an output folder for the data files which will be saved. Once this is done, click the “OK” button to begin the test.




Figure 6.34: Run Batch Test Window

Delete Batch – Allows user to delete a previously created batch test or tests.

6.3.5. Hardware



Figure 6.35: Hardware Menu

Datacard – Contains information regarding the datacard including sampling rate and calibration data for each sensor. **Warning:** Altering these numbers will change the calibration of the dyno. Please contact a Roehrig representative before making changes to the datacard values.

Motor – Contains information regarding the motor, including motor type and motor parameters. All settings are preset at the factory and should not be changed by the user, with the exception of Measure Stroke. The “Measure Stroke” option should be run whenever the stroke on the dyno has been mechanically changed. To measure the stroke, ensure that there is no test specimen in the machine, then click the “Measure Stroke” button.

Monitor – Displays the live sensor readings for the dyno.

6.3.6. View




Figure 6.36: View Menu

Template List – Displays a list of the currently open templates in a toolbar.

Standard Toolbar – Displays the standard Roehrig toolbar, which contains the most commonly used functions.

Status Bar – Displays the lower status bar.

Toolbars – Lists and displays all other available toolbars. Toolbars may be moved by clicking on the “crosshatching” located on the left side of the toolbar and dragging it to the top, bottom, left, or right side of the program window, or to the center to display it in a new window. The “more options” icon located on the right side of the toolbar can be used to modify the contents of the toolbar.




Figure 6.37: Standard Toolbar

X Offset/Y Offset – Offsets selected trace on currently displayed graph.

6.3.7. Settings



Figure 6.38: Settings Menu

User Settings – Exports or Imports user settings. User settings include all settings contained in the “preferences”, including all user tests and math channels. It is recommended that the user export and backup all settings listed under the settings menu on a regular basis in case of a computer crash.

System Settings – Exports datacard settings, motor settings, or both. These settings can be used to restore the motor properties and datacard properties (sensor calibration) in case of a computer crash. To import these settings, simply double click on the desired system settings file in any Windows Explorer window.

Export all Settings – Exports all user and system settings and saves them as one file.

Math Settings – Exports or Imports only the math channels created in “preferences.” Can be used to transfer math channels to other computers running SHOCK6. When importing math channels, the user can choose to replace existing channels with the new channels or merge the existing channels with the new channels.

Test Settings - Exports or Imports only the user’s tests. Can be used to transfer tests to other dynos running Shock6. When importing tests, the user can choose to replace existing tests with the new tests or merge the existing tests with the new tests. Test settings cannot be transferred between crank dynos and EMAs (Electro Magnetic Actuators).

6.3.8. Window




Figure 6.39: Window Menu

Window Menu – Allows user to arrange templates within the program using standard Microsoft Windows functions. Also lists currently open templates and currently selected (active) template.

6.3.9. Help



Figure 6.40: Help Menu

Help Menu – Provides searchable electronic version of this manual, which can also be listed by its table of contents. E-mail support link and interactive trouble shooting manual also provided. The “About” option provides information about the software version, motor, and datacard.

6.4. Creating and Running Tests

First, power up both the dyno and the computer system. Make sure all connections to the computer are made. Once the computer has booted, start the Roehrig Shock program. Load the shock to be tested following the procedure laid out in Section 4.2. If the user wishes to create a new test, click on the “Create” icon either from the “Test” menu or from the toolbar. The create test wizard will appear. Pick the desired test type, and click next. The wizard will guide the user through the rest of the test creation procedure. Once finished, the user will be asked to name the test. Enter a unique name and click OK. Once the test has been created, or if the user wishes to run a previously created test, click on the “Test” icon either from the “Test” menu or from the toolbar. The test screen will appear. Click on the desired test in the test profile column (left side of the test screen). The desired test will now be highlighted. Click on the “Start Test” button. Depending on the settings in preferences, the user will be prompted to enter information regarding the test run at this point, after the test is run, or not at all. The next screen displayed will be the “Dyno Starting” window. When the user is ready to start the test, click OK. Once the test is completed, the user will be prompted to save the data. The data is saved as an individual file using standard Microsoft Windows functions. Once the data is saved, it will automatically open in the currently active template.

6.5. Viewing and Analyzing the Data

Once a test run is completed, the data is automatically opened in the currently active template. The data file name is listed in the legend. Multiple data files can be opened and displayed in the same template. To open a data file, click on the “Open Data” icon either from the “File” menu or from the toolbar. The data will open in the currently active template. To remove a data file from the template, click on the data file in the legend, and click on the “Delete” icon in the toolbar. PVP data can be expanded to show the data from each individual speed. Click on the “+” to the left of the file name to expand the data tree. Multiple templates can be open at the same time. The user can save a template which also saves all associated data files with it. Once the data of interest is opened in the template, the user can now analyze that data. The tabbed analysis window allows the user to view the data in several different ways.




Figure 6.41: Template with open PVP Data File, “Graph” Display Tab Selected

When the “Graph” display tab is selected, the user defined graph will be displayed in the analysis window. The user can choose the desired graph either from the “Graph” menu or from the toolbar. The show/hide check boxes allow the user to turn on and off selected traces. When the check box under the “S” column is checked, the selected trace will show up on the graph, and vice versa. When the check box under the “G” column is checked, the gas force (if measured) will be subtracted from the trace, and vice versa. A template can have multiple graphs. Right click on one of the graph tabs (lower left) to create, delete, or rename a graph. Once the desired graph is chosen, the user can use the zoom, line, and averaging tools on the selected trace in the graph. The selected trace is the trace which is highlighted in the legend. A cursor (crosshair) will also be displayed on the selected trace on the graph. This cursor can be moved using the arrow keys on the keyboard, or by clicking on the desired point with the left mouse button. The data values for this point (where the cursor is located) are displayed in the status bar. The displayed graph can also be printed by clicking on the “Print” icon either under the “File” menu or from the toolbar.




Figure 6.42: Graph Analyzing Tools, Located in the Main Toolbar

The graph scaling can be changed by clicking on the “Scaling” display tab. When the “scaling” display tab is selected, the scaling preferences are shown for both the x and y axis. The user has the option of auto scaling by checking the box under “auto”, or manual scaling. If auto scaling is not checked, the values under “min” and “max” will be used to manually scale the graph.

The “Report” display tab allows the user to view the data from the selected trace in a tabbed format. The report tabs allow the user to display different information associated with the selected trace. The measured force vs. velocity data is also shown in the bottom table. The velocity increment for this table can be changed by clicking on the “velocity increment” pull down box. The report data can also be printed by clicking on the “Print” icon either under the “File” menu or from the toolbar.




Figure 6.43: Template with open PVP Data File, “Report” Display Tab Selected

The “PVP Mfg. Report” tab displays two user definable graphs along with the field data and the tabbed force vs. velocity data for the selected PVP data file. The report data can also be printed by clicking on the “Print” icon either under the “File” menu or from the toolbar.




Figure 6.44: Template with open PVP Data File, "PVP Mfg. Report" Display Tab Selected

The “Histogram” display tab allows the user to create a histogram using data from the selected trace. The user must define which data channel to display, the bin size, and the start and end points.




Figure 6.45: Template with open PVP Data File, "Histogram" Display Tab Selected

7. Maintenance Procedure

To ensure proper performance of your Roebrig Dynamometer follow these maintenance procedures

As Needed

Columns	Keep cleaned and lightly oiled to prevent rust. (Un-treated Steel Only)
Wear Plates	<p>Check the wear plates for grease. The dimples in the wear plates should be filled with grease at all times for proper lubrication.</p> <p>Wear plates should be greased with Mobil 1 Red Grease or any non-molybdenum or non-Lithium grease.</p>
Crossbar	Remove the crossbar handles and nuts (if equipped) and apply anti-seize to the crossbar studs.
General	<p>Keep dust and oils away from the electronics board, clean as needed.</p> <p>DO NOT apply cleaners or solvents to the IR Temperature sensor, chemicals may damage the lens.</p>

Every TWO Months

Bearings	<p>Your dyno is equipped with dry linear bearings at the actuator shaft and at the two shafts for the scotch yoke.</p> <p>These bearings DO NOT require lubrication.</p> <p>Visually inspect the three bearings on the front of the machine. The bearings should look clean and free of debris.</p> <p>Note: When the machine is in motion these bearings may move up and down slightly, this is a normal operating condition.</p>
----------	--

Yearly Maintenance

Belts	<p>Check the inner and outer belts of your dyno for excessive wear and or damage. Also check for lose belts or overly tight belts. The belts should be able to twist 45-90 degrees on the longest side.</p> <p>To gain access to the belts:</p> <p>FIRST TURN THE POWER OFF.</p> <p>Remove the rear cover by removing the two cap screws from the back side and loosening the 3 cap screws on each side with a 1/8 inch Allen tool. The rear belt will be visible</p> <p>Remove the front cover and unplug the connector from the Emergency Stop by pushing the tab to the unlock position.</p> <p>Remove the 3 flat head cap screws from the top plate and the smaller button head cap screw from the front of the electronics board.</p> <p>At this point gently lift the top plate from the front and rear and move it upward on the columns so that it is out of the way.</p> <p>Check the condition of the belts and grease the green drive bearings, see below.</p> <p>When the maintenance is complete, replace the top plate while carefully aligning the electronics board to be mated with the connectors. Attach the Emergency Stop switch and lock the tab in place. Replace the cap screws in the top plate and electronics board and install the front / rear covers.</p>
Drive Bearings	<p>There are three drive bearings inside the machine mounted on the rear plate. Grease the bearings through the grease fitting on each. See the above instructions for how to gain access to the inner bearing.</p>

8. Appendix

8.1 USB to Serial Adapters

In the case where your computer does not come with a Serial port, the use of a USB to Serial Adapter will be required. Roehrig Engineering recommends USB to Serial Adapters from Keyspan for reliability. Model# USA-19HS



Figure 8.1: Keyspan USB to Serial Adapter. Model# USA 19-HS

When installing the drivers for the device, follow the manufacturer's directions.

8.2 Glossary

Automatic Gas Test - The dynamometer automatically measures and removes the gas force.

Collection - The act of stroking the shock absorber and measuring the forces produced.

Collection Speed - The speed at which the crank rotates. See the “Frequency Versus Peak Velocity” chart to convert this to shaft speed in inches per second.

Continuous Velocity Pick-off (CVP) - When data is collected over a complete cycle of compression and rebound. The graph produced is a smooth curve.

Cycle - One revolution of the crank. It is equivalent to the shock being compressed and extended one time.

Damper - Shock Absorber

Export - Taking data from the shock program and turning it into comma separated ASCII files that can be used in other programs.

Gas Force - The internal forces in the shock caused by the pressure of the nitrogen gas. This is why the shock automatically extends itself.

Gas Test - The measuring of the shock's gas force

Keypad - This is not part of the computer, but the square pad attached to the dynamometer itself. It is used to manually control the machine's motor.

Live - When a “live” reading of a sensor is referred to, you are not collecting data, but viewing real time results on the computer monitor.

Load Cell - This is attached to the bottom of the cross bar. It is either a blue or stainless cylinder, or a steel “S” shaped piece. The top of your shock attaches to it, and it measures the forces generated by the shock during a collection.

Motor Units - The type of numbers entered in the Test Options screen. This is Hz, RPM, or (Linear) Velocity. The Velocity is calculated by multiplying the Stroke times the Frequency Ratio times Pi times the desired crank Hz.

Peak Velocity Pick-off (PVP) - The dynamometer is run at different speeds, and the data is collected and graphed only at the peak velocity of each cycle. The resulting graph is a point-to-point line graph.

Seal Drag - The internal friction of the shock caused by seals, o-rings, and binding. This number is generated during an Automatic Gas Test.

Shock Absorber - Damper

Software Key - The small white plastic square connected to the printer port of your computer. Without this your computer will not talk to your dynamometer.

Temperature Sensor - The black piece of plastic that clips around the damper. It measures the temperature of whatever it touches.

Valving - The internal parts of the shock (piston, shims, bleeders) which can be changed to modify the shock curve.

8.3 Shock 6.0 Math Syntax

Functions

The following functions are supported by the Roehrig Math system. All functions, unless specifically noted operate on all types of signals.

Expression	Description
ABS	Returns the absolute value of the 'expression'.
SGN	<p>Returns the sign of the 'expression'.</p> <p>If expression is greater than 0, SGN returns 1.</p> <p>If expression is equal to 0, SGN returns 0.</p> <p>If expression is less than 0, SGN returns -1.</p>
SIN	SIN returns the sine value of 'expression'. 'expression' is assumed to be in radians.
COS	COS returns the cosine value of 'expression'. 'expression' is assumed to be in radians.
TAN	TAN returns the tangent of 'expression', 'expression' is assumed to be in radians.
ASIN	ASIN returns the \sin^{-1} of 'expression'.
ACOS	ACOS returns the \cos^{-1} of 'expression'.
ATAN	ATAN returns the \tan^{-1} of 'expression'.
EXP	EXP returns the values of 'e' to the 'expression' power, or $e^{\text{'expression'}}$.
LOG	LOG returns the natural log of 'expression'.

SQRT	SQRT returns the square root of 'expression'
DIFF	DIFF differentiates 'expression' with respect to time. The sample rate of expression is assumed to be that same of the data being used to evaluate 'expression'.
INTG	INTG integrates 'expression' with respect to time. The sample rate of expression is assumed to be that same of the data being used to evaluate 'expression'.
POSITIVE	POSITIVE returns the value of 'expression' if it is greater then zero, otherwise POSITIVE returns zero.
NEGATIVE	NEGATIVE returns the value of 'expression' if it is less then zero, otherwise NEGATIVE returns zero.
RAD	RAD converts 'expression' from degrees into radians.
DEG	DEG converts 'expression' from radians to degrees.
MIN	MIN evaluates each individual expression and then returns the minimum of all of the expressions.
MAX	MAX evaluates each individual expression and then returns the maximum of all of the expressions.
AVE	AVE evaluates each individual expression and then returns the average of all of the expressions.
UNITS	UNITS ensures that 'symbol' is returned in 'measurement' units. For example, if Displacement may be in inches or millimeters, UNITS(Displacement, {Mm}) would ensure the Displacement is in millimeters.

TOUNITS	TOUNITS assumes 'expression' is in 'measurement' units and forces it to convert to 'targetmeasurement' units.
SMOOTH	SMOOTH evaluates expression and averages the values of 'expression' for each of the 'NUMBER' data points before and after the each data point. For example "SMOOTH(Displacement, 5)" would for each point of displacement it would average the eleven data points to generate the value at that data point. (It uses eleven because it takes 5 points from left, 5 points from the right and the data point itself.)
CYCLE	CYCLE evaluates 'expression' and then clips the data to contains only the 'opendirection' and 'closedirection' portions of the dyno cycle. 'opendirection' and 'closedirection' can be qith ~Rebound, ~Compression, or ~Ignore.

Syntax

```
expression: binaryop
|           simpleexpression
|           ( expression )

simpleexpression:      number
|                    symbol
|                    function
|                    unaryoperation
|                    conditional
|                    smooth
|                    cycle

number:      NUMBER
|           NAN

symbol      SIGNAL
|           CONSTANT

function:
|         ABS ( expression )
|         SGN ( expression )
|         SIN ( expression )
|         COS ( expression )
|         TAN ( expression )
|         ASIN ( expression )
|         ACOS ( expression )
|         ATAN ( expression )
|         EXP ( expression )
|         LOG ( expression ) |           Sqrt ( expression )
|         DIFF ( expression )
|         INTG ( expression )
|         POSITIVE ( expression )
|         NEGATIVE ( expression )
|         RAD ( expression )
|         DEG ( expression )
|         MIN ( argumentlist )
|         MAX ( argumentlist )
|         AVE ( argumentlist )
|         UNITS ( symbol , measurement )
|         TOUNITS ( expression , measurement , measurement )

argumentlist:      expression , argumentlist
|                 expression

unaryoperation:    - expression
|                 NOT expression

binaryop:      expression + expression
|             expression - expression
|             expression * expression
|             expression / expression
```



```

|          expression % expression
|          expression ^ expression
|          expression > expression
|          expression >= expression
|          expression = expression
|          expression != expression
|          expression <= expression
|          expression < expression
|          expression AND expression
|          expression OR expression
|          expression XOR expression

conditional:      expression ? expression : expression
|                IF ( expression , expression , expression )
|                IF ( expression , expression )
|                IF expression THEN expression
|                IF expression THEN expression ELSE expression

smooth:          SMOOTH ( expression , NUMBER )

direction:       ~COMPRESSION
|               ~REBOUND
|               ~IGNORE

cycle:           CYCLE ( expression , direction , direction )

measurement:     {UNKNOWNUNIT}
|               {}
|               {INCH}
|               {M}
|               {CM}
|               {MM}
|               {IPS}
|               {INCH/SEC}
|               {M/SEC}
|               {CM/SEC}
|               {MM/SEC}
|               {LBS}
|               {NEWTONS}
|               {KGF}
|               {F}
|               {C}
|               {RPM}
|               {HZ}
|               {FT}
|               {MI}
|               {KM}
|               {SEC}
|               {MIN}
|               {HR}
|               {FT/SEC}
|               {MPH}
|               {MI/HR}
|               {KPH}
|               {K/HR}

```

{G}
 {FT/SEC^2}
 {MP/SEC^2}
 {IN*LBS}
 {FT*LBS}
 {N*M}
 {PSI}
 {BAR}
 {P}
 {V}
 {LBS/IN}
 {N/MM}
 {N/CM}
 {N/M}
 {KGF/MM}
 {KGF/CM}
 {KGF/M}
 {OZ}
 {LBS}
 {GM}
 {KG}
 {FLOZ}
 {GAL}
 {L}
 {DEG}
 {RAD}
 {IN*LBS/DEG}
 {FT*LBS/DEG}
 {KGF*MM/DEG}
 {KGF*CM/DEG}
 {N*MM/DEG}
 {N*CM/DEG}
 {N*M/DEG}
 {NEWTON*CM}
 {NEWTON*MM}
 {KGF*MM}
 {KGF*CM}
 {KGF*M}
 {KGF*M/DEG}
 { % }

9. Additional Documentation

The following pages will contain information specifically related to your product.

Included are some/all of the following:

- Detailed Assembly Drawings
- Exploded Assembly Drawings
- Electrical Schematics

10. Warranty and Service

10.1 Warranty

For one year from the date of delivery (date equipment leaves REI), Roehrig Engineering, Inc. will provide, free of charge, parts and service labor to repair or replace any part of the dynamometer that fails because of a manufacturing defect.

This warranty is extended to the original purchaser and any succeeding owner of the product within the one year time period.

10.2 Technical Support

Roehrig Engineering, Inc. is committed to providing the best technical support to our customers. If you have any problems using one of our products, please follow these steps before contacting our Technical Support Representative:

- Be sure to read the equipment manuals. Many times the answer is right there.
- Document the problem you are experiencing. Be as specific as you can. The more information you have, the easier the problem will be to solve.
- If you still cannot resolve your problem, have your equipment's serial number available *before calling*.

Technical Support hours are 8:00AM to 5:00PM Eastern Time, Monday through Friday. E-mail support@roehrigengineering.com. You may also fax in your problems or questions 24 hours a day. Faxes sent outside regular working hours will usually be answered before 10:00AM ET the next working day. Please be sure to use the **Customer Service Request Form** found later in this document. Include your FAX and phone numbers, and the name of the user. Fax support number (336) 956-3870. Phone support number (336) 956-3800.

10.3 SERVICE POLICY

Roehrig Hardware Under Warranty

A one-year warranty comes with the purchase of new Roehrig Engineering manufactured hardware products. Supplemental service plans are also available at additional cost.

The following is a summary of what service can be obtained under the Standard warranty:

1. Factory repairs on hardware product defects;
2. Factory repairs are usually completed within 3 working days of Roehrig Engineering's receipt of the defective item. The customer is responsible for returning the hardware to Roehrig Engineering;
3. Roehrig Engineering will return the hardware via UPS 2 day air service (USA only). If the customer is outside the continental USA, the customer is responsible for all shipping expenses. Expedited service can be arranged at the customer's expense;
4. Free technical support, for technical problems and applications, for all trained users;
5. Warranties can be renewed annually on Roehrig Engineering products;
6. A warranty **cannot** be purchased if the original or renewed warranty has expired.
7. Warranties are transferable to subsequent owners under certain conditions:
 - ◆ The equipment is currently under warranty
 - ◆ The new owner undergoes training on the equipment
 - ◆ A warranty transfer form is completed, and submitted to Customer Service

Roehrig Hardware Not Under Warranty

- E-mail is the preferred method to address non-warranty service problems, out of warranty e-mail we be answered at no charge, or the customer may use the Customer Service Request Form for troubleshooting problems via fax at no charge. REI may charge for phone non-warranty problems
- If the initial trouble shooting does not resolve the problem, then all factory assessments and repairs will follow the following procedure:

Factory Repairs

1. The customer sends the part to Roehrig Engineering.
2. The estimated repair cost will be given to the customer prior to the repair. The total cost must be paid prior to beginning of service.
3. System testing, evaluation and repairs can take up to two weeks. However, the part will be scheduled for a service as soon as it arrives at the factory.
4. Roehrig Engineering will return the repaired part via UPS ground service in the USA only. If the customer is outside the continental USA, the customer is responsible for shipping charges. Expedited service can be arranged at the customer's expense.

Repairs at Customers Facility

1. Customer will pay all travel expenses of Roehrig Engineering service personnel. Travel rate is \$0.485 per mile, plus \$35.00 per hour, maximum \$200.00 per day. If it is necessary to fly to the customers location, customer will pay full cost of the airline ticket, plus \$35.00 per hour, maximum \$200.00 per day travel (not including airline ticket).
2. Customer will pay for all replacement parts plus \$100.00 per hour labor.
3. Payment required at time of repair.
4. It may take up to 4 weeks to schedule a service call to the customer's location.

Roehrig Engineering Software Under Warranty

- A one-year warranty comes with the purchase of all new Roehrig Engineering developed software.
- The warranty includes:
 1. Free telephone, e-mail and fax support for all trained users.
 2. Free updates and new releases of Roehrig Engineering developed software.

Roehrig Engineering Software Not Under Warranty

- Once the warranty has lapsed on Roehrig Engineering software, the following applies:
 1. REI may charge for telephone support at standard service rates;
 2. Questions may be faxes or e-mailed to Roehrig Engineering's customer service department at no charge. Please use the attached form for fax request.

Hardware and Software Training

Roehrig Engineering's training program is designed to instruct trainees in the operation of the equipment that the customer has purchase. The training sessions are set up for each trainee to obtain valuable hands on application exposure. This will help the trainees in their everyday use of the equipment. Training for additional personnel, and advanced training is available at additional expense.



ROEHRIG ENGINEERING INC.

100 Lexington Parkway
Lexington NC 27295
336 956 3800

Transfer of Warranty Service Plan Agreement

_____(Seller's Name) hereby waives all rights under
warranty service policy for:
Dynamometer Serial Number: _____
Purchased originally on: _____(date).

_____(Buyer's Name) hereby assumes all rights and
obligations of the Hardware and/or Software Warranty Service Policy from:
_____(Date of Transfer).

This transfer is valid only under the following conditions.

- 1. The Dynamometer is currently under warranty**
- 2. New owner undergoes training from Roehrig Engineering**
- 3. This warranty transfer form is completed, and submitted to Customer Service.**

AGREED

(Print Seller's Corporate Name)

By X _____

(Print Name of Signatory)

(Print Buyer's Corporate Name)

By X _____

(Print Name of Signatory)

Roehrig Engineering, Inc.

Approved by X _____

Purchase Conditions

All Purchase Orders (hereafter, the “Order”) for Roehrig Engineering provided products and services (hereafter, the “Product”) are subject to the following terms and conditions, which are agreed to by the Purchaser.

1.0 Payment of Purchase Price

- 1.1 Purchaser hereby promises to pay to the order of Roehrig Engineering all deferred portions of the Purchase Price, together with the interest on late purchase price payments payable at 1.5% per month (18% per annum).
- 1.2 the Purchaser grants to Roehrig Engineering a security interest in the products sold pursuant to the Order, which may be perfected by UCC-1 Financing Statements to be recorded in the applicable County of the Purchaser's business location and filed with the Secretary of State's Office, which security interests will remain in effect until payment in full of the purchase price together with the interest on late purchase price payments payable thereon had been received by Roehrig Engineering.
- 1.3 If the Purchaser fails to make full payment of the purchase price within the period set out in the Order, Roehrig Engineering shall have the following remedies, which shall be cumulative and not alternative:
 - A. the right to cancel the Order and enter the Purchaser's premises to re-take possession of the Product, in which event the Purchaser agrees that any down-payment or deposit shall be forfeited to Roehrig Engineering, as liquidated damages and not as a penalty, and all costs incurred shall be payable by the Purchaser upon written demand.
 - B. the right to enter the Purchaser's premises and remove any Software, components of the Product or other items necessary in order to render the Product inoperative.
 - C. the right to withhold all services which would otherwise be required to be provided by Roehrig Engineering pursuant to the Warranties set out in Section 5 hereof.
 - D. terminate any existing software license agreement
 - E. pursue any other available remedy, including suing to collect any remaining balance of the purchase price.

No waiver by Roehrig Engineering of its rights under these conditions shall be deemed to constitute a waiver of subsequent breaches or defaults by the Purchaser. In the event more than one Product is being purchased pursuant to the Order, unless otherwise set forth herein, each payment received by Roehrig Engineering from Purchaser shall be applied pro rata against the cost of each product rather than being applied to the purchase price of any product.

2.0 Delivery and Transportation

- 2.1 Delivery dates are estimates and not guarantees, and are based upon conditions at the time such estimate is given.
- 2.2 Roehrig Engineering shall not be liable for any loss of damage, whether direct, indirect or consequential, resulting from late delivery of the product. The Purchaser's sole remedy if the Product is not delivered within 90 days of the estimated delivery date, shall be to cancel the Order and recover from Roehrig Engineering without interest or penalty, the amount of the down-payment or deposit and any other part of the purchase price which has been paid by the Purchaser. Notwithstanding the foregoing, such right of cancellation shall not extend to situations where late delivery is occasioned by causes beyond Roehrig Engineering's control, including, without limitation, compliance with any rules, regulations, orders or instructions of any federal, state, county, municipal or other government or any department or agency thereof, force majeure, acts or omissions of the Purchaser, acts of civil or military authorities, embargoes, war or insurrection, labor interruption through strike or walkout, transportation delays and other inability resulting from causes beyond Roehrig Engineering's control to obtain necessary labor, manufacturing facilities or materials from its usual sources. Any delays resulting from such causes shall extend estimated delivery dates by the length of such delay.
- 2.3 Responsibility for all costs and risks in any way connected with the storage, transportation and installation of the Product shall be borne entirely by the Purchaser. If any disagreement arises as to whether or not damage to the Product was in fact caused in storage, transit or installation, the opinion of Roehrig Engineering's technical advisers, acting reasonably, shall be conclusive.

3.0 Installation and Operator Training

- 3.1 The Purchaser shall be responsible for installation of the Product, including, without limitation, the preparation of its premises, the uncrating of the product and setting up of the Product for operation. Purchaser may elect to order contract services from Roehrig Engineering to perform this service should they elect to do so.

4.0 Warranties and Limitation of Liability

- 4.1 Roehrig Engineering warrants that (subject to Section 4.6), the Product shall be free from defects in workmanship or material affecting the fitness of the product for its usual purpose under normal conditions of use, service and maintenance.
- 4.2 Roehrig Engineering warrants that the software shall operate according to specifications and the system shall operate and perform in the manner contemplated in connection with the usual purpose for which it was designed.
- 4.3 The warranties set out in paragraphs 4.1 and 4.2 above (together called the "Warranties") shall expire at the end of the twelve (12) month period commencing on the first day of the first month after the date of shipment from the Roehrig Engineering factory (the "Warranty Period").
- 4.4 Subject to the limitations contained in Section 4.6, the Warranties shall apply to any defects found by the Purchaser in the operation of the Dynamometer or the software and is reported to Roehrig Engineering within the Warranty Period. If the Dynamometer or the software is found by Roehrig Engineering, acting reasonably, to be defective, and if the defect is acknowledged by Roehrig Engineering to be the result of Roehrig Engineering's faulty material or workmanship, the Dynamometer or Software will be repaired or adjusted to the extent found by Roehrig Engineering to be necessary, or at the option of Roehrig Engineering, replaced with a new Dynamometer, Software, or parts thereof at no cost to the purchaser.

Claims under the Warranties shall be made by delivering written notice to Roehrig Engineering of the defect in the System, Dynamometer, or the Software. Within a reasonable time of receipt of such service personnel and warranty service will be provided at no cost to the Purchaser. If in the reasonable opinion of Roehrig Engineering the dynamometer and Software are not defective, the Purchaser shall pay the cost of service, which shall be the amount that Roehrig Engineering would otherwise charge for that service and shall include, without limitation, shipping, handling, and an hourly service charge.

- 4.5 The Warranties do not apply to
 - A. any defects in any component of a System where, if in the reasonable opinion of Roehrig Engineering, the Dynamometer, Software or System has been improperly stored, installed, operated, or maintained, or if Purchaser has permitted unauthorized modifications, additions, adjustments and/or repair to any part of the System, or which might affect the System, or defects caused or repairs required as a result of causes external to Roehrig Engineering workmanship or the materials used by Roehrig Engineering. As used herein, "unauthorized" means that which has not been approved and permitted by Roehrig Engineering.
 - B. The Warranties shall not cover replacement of expendable items including, but not limited to, fuses, diskettes, printer paper, printer ink, printing heads, disk cleaning materials, wear plates, or similar items.
 - C. The Warranties shall not cover minor preventative and corrective maintenance.
 - D. Any equipment or its components which was sold or transferred to any party other than the original Purchaser without the expressed written consent of Roehrig Engineering.

4.7 Factory Repairs

- A. IF SYSTEM IS UNDER WARRANTY: The Purchaser agrees to ship the Product to Roehrig Engineering in the original packing containers. Roehrig Engineering will return the repaired or replaced Product. Roehrig Engineering will incur the expense of the needed part and all return shipping charges to the Purchaser. Roehrig Engineering may authorize a component of the Product to be repaired on site.
 - B. IF SYSTEM IS NOT UNDER WARRANTY: The Purchaser is responsible for the cost of the replacement part or software, and all shipping charges.
- 4.8 Nothing herein contained shall be construed as obligating Roehrig Engineering to make service, parts, or repairs for any product available after the expiration of the Warranty Period.
 - 4.9 Limitation of Liability

Roehrig Engineering shall not be responsible under any circumstances for special, incidental or consequential damages, including, but not limited to, injury or death of any operator or other person, damage or loss resulting from inability to use the System, increased operating costs, loss of production, loss of anticipated profits, damage to property, or other special, incidental, or consequential damages of any nature arising from any cause whatsoever whether based in contract, tort (including negligence), or any other theory of law. Roehrig Engineering's only liability hereunder, arising from any cause whatsoever, whether based in contract, tort (including negligence) or any other theory of law, consists of the obligation to repair or replace defective components in the System or Dynamometer subject to the limitations set out above in this section.

This disclaimer of liability for consequential damage extends to any such special, incidental or consequential damages which may be suffered by third parties, either caused directly or indirectly resulting from test results or data produced by the system or any component thereof and the Purchaser agrees to indemnify and save Roehrig Engineering harmless from any such claims made by third parties.

- 4.10 The foregoing shall be Roehrig Engineering's sole and exclusive liability and the Purchaser's sole and exclusive remedy with respect to the system.

THE SOLE RESPONSIBILITY OF ROEHRIG ENGINEERING UNDER THE WARRANTIES IS STATED HEREIN AND ROEHRIG ENGINEERING SHALL NOT BE LIABLE FOR CONSEQUENTIAL, INDIRECT, OR INCIDENTAL DAMAGES, WHETHER THE CLAIM IS FOR BREACH OF WARRANTY, NEGLIGENCE, OR OTHERWISE.

OTHER THAN THE EXPRESS WARRANTIES HEREIN STATED, ROEHRIG ENGINEERING DISCLAIMS ALL WARRANTIES INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS.

Roehrig Engineering does not authorize any person (whether natural or corporate) to assume for Roehrig Engineering any liability in connection with or with respect to the Products. No agent or employee of Roehrig Engineering has any authority to make any representation

or promise on behalf of Roehrig Engineering, except as expressly set forth herein, or to modify the terms or limitations of the Warranties. Verbal statements are not binding by Roehrig Engineering.

4.11 The Warranties extend only to the Purchaser and are transferable, only under the following conditions:

- A. The Dynamometer is currently under warranty.
- B. New owner undergoes training.
- C. A Roehrig Engineering warranty transfer is completed, and submitted to customer service.

All claims under the Warranties must originate with the Purchaser, or any subsequent owner, and the Purchaser will indemnify and save Roehrig Engineering harmless from any claims for breach of warranty asserted against Roehrig Engineering by any third party.

4.13 Oral representations of Roehrig Engineering or its sales representatives, officers, employees or agents cannot be relied upon as correctly stating the representations of Roehrig Engineering in connection with the system. Refer to this purchase order, any exhibits hereto and any written materials supplied by Roehrig Engineering for correct representations.

4.14 PURCHASER ACKNOWLEDGES THAT IT HAS PURCHASED THE SYSTEM BASED UPON ITS OWN KNOWLEDGE OF THE USES TO WHICH THE SYSTEM WILL BE PUT. ROEHRIG ENGINEERING SPECIFICALLY DISCLAIMS ANY WARRANTY OR LIABILITY RELATED TO THE FITNESS OF THE SYSTEM FOR ANY PARTICULAR PURPOSE OR ARISING FROM THE INABILITY OF THE PURCHASER TO USE THE SYSTEM FOR ANY PARTICULAR PURPOSE.

5.0 Design Changes

5.1 The Dynamometer, the Software, and the System are subject to changes in design, manufacture and programming between the date of order and the actual delivery date. Roehrig Engineering reserves the right to implement such changes without the Purchaser's consent; however, nothing contained herein shall be construed as obligating Roehrig Engineering to include such changes in the Dynamometer, Software, or System provided to the Purchaser.

6.0 Non-Disclosure

6.1 All Software including, without limitation, any Roehrig Engineering special user programs, provided to the Purchaser as part of the system, either at the time of or subsequent to the delivery of the Dynamometer, is the intellectual property of Roehrig Engineering. The Purchaser shall not reproduce or duplicate, disassemble, decompile, reverse engineer, sell, transfer or assign, in any manner the Software or permit access to or use thereof by any third party. The Purchaser shall forthwith execute any further assurances in the form of non-disclosure or licensing agreements which may reasonably be required by Roehrig Engineering in connection with the software.

7.0 Entire Agreement / Governing Law / Misc. / Guarantee

7.1 These Purchase conditions constitute the entire agreement between Roehrig Engineering and the Purchaser in respect to the Product. There are no representations or warranties by Roehrig Engineering, express or implied, except for those herein contained and these conditions supersede and replace any prior agreements between Roehrig Engineering and the Purchaser.

7.2 No representative of Roehrig Engineering has any authority to modify, alter, delete or add to any of the terms or conditions hereof. Any such modifications shall be absolutely void unless made by instrument in writing properly executed by an actual authorized employee or agent of Roehrig Engineering.

7.3 The terms and conditions hereof shall be binding upon Roehrig Engineering and the Purchaser, and shall not be construed in accordance with the laws of the State of North Carolina, United States of America.

7.4 Roehrig Engineering shall be entitled to recover all of its reasonable fees and costs including, but not limited to, its reasonable attorney's fees incurred by Roehrig Engineering in connection with any dispute or litigation arising thereunder or in connection herewith, including appeals and bankruptcy or creditor reorganization proceeds.

7.5 These conditions shall not be construed more strictly against one party than another as a result of one party having drafted said instrument.

8.0 Definitions

- 8.1 "Roehrig Engineering" means Roehrig Engineering, Inc.
- 8.2 "Purchaser" means the party buying the Product who is legally obligated hereunder.
- 8.3 "Software" means all computer programs, including diskettes containing such computer programs sold pursuant to the Order.
- 8.4 "Product" means the Dynamometer, the Software, operating manuals and any other product or merchandise sold pursuant to the Order.
- 8.5 "System" means a combination of the Dynamometer, the Software, the Computer, and optional parts associated with the Dynamometer.
- 8.6 "Purchase Order" means the original document issued from the Purchaser to Roehrig Engineering, listing all parts and/or services to be purchased and the agreed purchase price.
- 8.7 "Warranty Transfer Form" means a document to be completed for the transfer of the Roehrig Engineering Warranty. This document is available from Roehrig Engineering upon request.

9.0 Software License Agreement

The Software License Agreement is part of the Operating Manual for the product and software System that you have purchase from Roehrig Engineering, Inc. (collectively, the "Licensor"). By your use of the software you are agreeing to the terms and conditions of this Software License Agreement. Throughout this Software License Agreement, the term "Licensee" means the owner of the System.

- 9.1 The Licensor hereby grants the Licensee the non exclusive right to use the computer software described in this Operating Manual (the "Software"). The Licensee may sell the software key but may not assign, sub-license, rent or lease the Software to any third party without the Licensor's prior written consent.
- 9.2 The Licensor further grants the Licensee the right to make a backup copies of the Software media and use the software in demo mode. The Licensee agrees that it will not decompile, disassemble, reverse engineer, copy, transfer, or otherwise use the Software except as permitted by this section.
- 9.3 The Licensee is licensed to use the Software only in the manner described in the Operating Manual. Use of the Software in a manner other than that described in the Operating Manual or use of the Software in conjunction with any non-Licensor product which decompiles or recompiles the Software or in any other way modifies the structure, sequence or function of the Software code, is not an authorized use, and further, such use voids the Licensor's Warranty as set forth below.
- 9.4 The only warranty with respect to the Software and the accompanying written materials is the warranty, if any, set forth in the Quotation/Purchase Order and Service Policy pursuant to which the Software was purchased from the Licensor.
- 9.5 THIS WARRANTY IS IN LIEU OF OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE WITH RESPECT TO THE SOFTWARE AND WRITTEN MATERIALS. IN NO EVENT WILL THE LICENSOR BE LIABLE FOR DAMAGES, INCLUDING ANY LOST PROFITS OR OTHER INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE SOFTWARE, NOTWITHSTANDING THAT THE LICENSOR MAY HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, THE LICENSOR WILL NOT BE LIABLE FOR ANY SUCH CLAIM BY ANY OTHER PARTY.

In the event of any breach by the Licensee of this Agreement, the license granted hereby shall immediately terminate and the Licensee shall return the Software media and all written materials, together with any copy of such media or materials, and the Licensee shall keep no copies of such items.

The interpretation of this Agreement shall be governed by the following provisions:

- A. This agreement shall be construed pursuant to and governed by the substantive laws of the State of North Carolina (and any provision of North Carolina laws shall not apply if the law of a state or jurisdiction other than North Carolina would otherwise apply).
 - B. If any provision of this Agreement is determined by a court of competent jurisdiction to be void and non-enforceable, such determination shall not affect any other provision of this Agreement, and the remaining provisions of this Agreement shall remain in full force and effect. If any provision or term of this Agreement is susceptible to two or more constructions or interpretations, one or more of which would render the provision or term void or non-enforceable, the parties agree that a construction or interpretation which renders the term of provision valid shall be favored.
 - C. This Agreement constitutes the entire Agreement, and supersedes all prior agreements and understandings, oral and written, among the parties to this Agreement with respect to the subject matter hereof.
- 9.8 If a party engages the service of an attorney or any other third party or in any way initiates legal action to enforce its rights under this Agreement, the prevailing party shall be entitled to recover all reasonable costs and expenses (including reasonable attorney's fees before trial and in appellate proceeding