

WELDON FLATS MACHINE 2002

OPERATOR'S MANUAL

By

Precision Abrasive Machinery, Inc.

14200 W. COMMERCE RD. * P.O. BOX 43 * DALEVILLE, INDIANA 47334
(765) 378-3315 * FAX (765) 378-3316

October 15, 2002

Chapter 1 : GENERAL INFORMATION

TABLE OF CONTENTS

- GENERAL INFORMATION SEE PAGE 1-1
- OPERATOR INTERFACE SCREENS AND EXPLANATION; SEE PAGE 2-1
- ENGINEERING PARAMETER SETUP AND TEST; SEE PAGE 3-1
- AC TECH VARIABLE SPEED MOTOR DRIVE SETUP; SEE PAGE 4-1
- PROGRAM SEQUENCE OF THE MACHINE; SEE PAGE 5-1
- ERROR CODE PRINT OUT; SEE PAGE 6-1

Chapter 2 : OPERATOR SCREENS

GP #1, Main Menu

WELDON FLATS 2002		MAIN MENU			
F2 = SETUP ROUTINES -- Vice & Workhead					
F3 = MANUAL OUTPUTS & JOG				No Faults	
F4 = FAULTS if Flashing-->				FAULTS !!	
ALARM	SETUP	MAN	FAULT	_____	ENG'R
F1	F2	F3	F4	F5	F6

This is the **Main Menu** Screen for the **WELDON FLATS** Machine. When the machine is powered up either by choice or power failure, the "**FAULTS!**" prompt will be flashing. The Operator then needs to press the '**FAULT**' **Button** (F3) and follow the prompts from the FAULT Screen. When ALL Faults have been solved, the Operator will return back to this Screen. The "FAULTS!" prompt will be gone and "**No Faults**" prompt will be seen.

Next the Operator will be able to select:

F1 ALARM - Press this key to clear any Input Over-Limits Value made by Operator.

F2 SETUP - Press this key for SETUP ROUTINES - Vice & Indexing.
(Seepage 2-2)

F3 MAN - Press this key for MANUAL OUTPUTS & JOG. (Seepage 2-70)

F3 FAULT - Press this key to view and clear any FAULTS if the red pilot lamp is flashing. (Seepage 2-78)

F5 Key not used.

F6 ENG'R - Press this key for the Special Engineering Setup section.
(Seepage 3-1)

GP #2, Operator Setup Routines

OPERATOR SETUP ROUTINES					
F2 = WORK HEAD - Routines					
F3 = VICE - Routines					
F5 = Timers/Counters					
MENU	HEAD	_____	VICE	T/C	_____
F1	F2	F3	F4	F5	F6

F1 MENU - Press this key to return to the Main Menu. (See page 2-1)

F2 HEAD - Press this key to select the Work Head routines. These routines are for Weldon flat tools using auto loading or hand loading procedures. (See page 2-3)

F3 Not used.

F4 VICE - Press this key to select the vice routines for Weldon flats or Whistle Stops. (See page 2-41)

F5 Key not used.

F6 T/C - Press this key to select the Timers and Counters section. (See page 2-68)

GP #3, Work Head Routines

WORK HEAD ROUTINES FOR WELDON FLATS Auto Loading or Hand Loading Options F3 = Setup LOADER & UNLOADER F4 = WORK HEAD - AUTO LOAD OR HAND LOAD					
MENU2	_____	LOAD	_____	HEAD	_____

F1 **F2** **F3** **F4** **F5** **F6**

F1 MENU2 - Press this key to return to the Operator Setup Routines menu. (Seepage 2-2)

F2 Key not used.

F3 LOAD -- Press this key for the screens to setup the Loader and Unloader positions. This is used to align the X and Y-axis to the Loader and Unloader assembly. Also, use this to set the length of the tool extending from the collet. (Seepage 2-4)

F4 Key not used.

F5 HEAD - Press this key for the screens to setup the Work Head Routines. This includes the auto loading or the hand loading option. (Seepage 2-13)

F6 Key not used.

GP #4, Setup Loader & Unloader for Work Head

Setup LOADER & UNLOADER for Work Head					
F1 = Back to Setup Menu					
F3 = Setup LOADER					
F5 = Setup UNLOADER					
BACK	_____	LOAD	_____	UNLOD	_____
F1	F2	F3	F4	F5	F6

F1 BACK - Press this key to return to the Work Head Routines for Weldon flats. (See page 2-3)

F2 Key not used.

F3 LOAD -- Press this key for the screen to setup the Loader positions. This is used to set the length of the tool from the collet and for the proper alignment to the loader assembly. (See page 2-5)

F4 Not used.

F5 UNLOD - Press this key for the screen to setup the Unloader positions. This is used to set the proper alignment to the Unloader assembly. (See page 2-9)

F6 Key not used.

GP #5, Loader Instructions for Work Head

LOADER Instructions for Work Head					
Use this Routine to align the X and Y Axis to the Loader Assembly and adjust the Tool Extension from the Collet.					
BACK	_____	_____	_____	_____	NEXT

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK - Press this key to return to the Setup Loader and Unloader menu. (Seepage 2-4)

F2 Not used.

F3 Not used.

F4 Not used.

F5 Not used.

F6 NEXT - Press this key for the next screen to setup the Loader Pneumatics. (Seepage 2-6)

GP #6, Setup Loader Pneumatics for Work Head

Setup LOADER Phneumatics for Work Head					
F2 : Toggle COLLET = [OPEN/CLOSED]					
F3 : Toggle EJECTOR LOW = [BACK/FORWARD]					
F4 : Toggle PUSHER = [OUT/IN]					
F6 : For X and Y Axis					
BACK	COLET	EJECT	PUSHR	_____	AXIS
F1	F2	F3	F4	F5	F6

F1 BACK - Press this key to go back to the Setup Loader Instructions screen. (Seepage 2-5)

F2 COLET - Press this key to toggle the *Collet* either Open or Closed. The *Collet* needs to be OPEN to load the tool. The status will show the state of the pneumatic valve of either "Open or Closed".

F3 EJECT - Press this key to toggle the *Ejector Low Pressure* either "Back or Forward". The *Ejector Low Pressure* needs to be forward to load the tool. The status will show the state of the pneumatic valve of either "Back or Forward".

F4 PUSHR - Press this key to toggle the *Pusher* either back or forward. First, the *Pusher* needs to be in its Back position to align the X and Y-axis. Then check the alignment by toggling the Pusher to its IN position. The status will show the state of the pneumatic valve of either "Back or Forward".

F5 Not used.

F6 AXIS - Press this key to go to the next screen to setup the Loader's X and Y-axis positions. (Seepage 2-7)

GP #7, Setup Loader X Axis for Work Head

X Axis Setup LOADER Position					
F2 : Set FEED RATE = x.xxx In/sec					
Rate Range : 0.001 to 1.000 In/sec					
X ABS= x.xxxx In Stored Pos= xx.xxxx In					
F5 : GoTo Stored Load Position.					
BACK	RATE	STORE	_____	GOTO	Y-AXI
F1	F2	F3	F4	F5	F6

F1 BACK - Press this key to go back to Setup Loader Pneumatic screen.
(Seepage 2-6)

F2 RATE - Press this key to access the *X-axis Feed Rate* and then enter the desired value. The rate range is 0.001 to 1.000 In/Sec.

F3 STORE - Press this key to access the Stored Loader Position value. Then enter the value displayed by the ABS (absolute value) position or a modified value.

F4 Key not used.

F5 GOTO - Press this key to send the axis the stored loading position.

F6 Y-AXI - Go to the next screen to setup the Loader's Y-axis position. (Seepage 2-8)

Note: Then use the **JOG IN** or **JOG OUT** push buttons to control the axis.

GP #8, Setup Loader Y Axis for Work Head

<p>Y Axis Setup LOADER Position</p> <p>F2 : Set FEED RATE = x.xxx In/sec</p> <p>Rate Range : 0.001 to 1.000 In/sec</p> <p>Y ABS= x.xxxx In Stored Pos= x.xxxx In</p> <p>F5 : GoTo Stored Position.</p> <p>BACK RATE STORE _____ GOTO _____</p>

F1 F2 F3 F4 F5 F6

F1 BACK -- Back to Setup Loader X-Axis screen. (See page 2-7)

F2 RATE - Press this key to access the Y-axis Feed Rate and then enter the desired value. The rate range is 0.001 to 1.000 In/Sec.

F3 STORE - Press this key to access the Stored Loader Position value. Then enter the value displayed by the ABS (absolute value) position or a modified value.

F4 Key not used.

F5 GOTO - Press this key to send the axis the stored loading position.

F6 Key not used.

Note: Then use the **JOG IN** or **JOG OUT** push buttons to control the axis.

GP #9, Unloader Instructions for Work Head

UNLOADER Instructions for Work Head					
Use this Routine to align the X and Y Axis to the Unloader Assembly.					
BACK	_____	_____	_____	_____	NEXT
F1	F2	F3	F4	F5	F6

F1 BACK - Press this key to go back to Setup Loader and Unloader screen. (Seepage 2-4)

F2 Key not used.

F3 Key not used.

F4 Key not used.

F5 Key not used.

F6 NEXT - Press this key to go to the next screen to setup the Unloader Pneumatics. (Seepage 2-10)

GP #10, Setup Unloader Pneumatics for Work Head

Setup UNLOADER Phneumatics for Work Head					
F2 : Toggle COLLET = [OPEN/CLOSED]					
F4 : Toggle EJECTOR High =[BACK/FORWARD]					
F6 : For X and Y Axis					
BACK	COLET		EJECT	_____	AXIS

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK - Press this key to go back to Setup Unloader Instructions screen. (Seepage 2-9)

F2 COLET - Press this key to toggle the *Collet* either Open or Closed. First, the *Collet* needs to be open to load the tool if one is not in place. Then, the *Collet* will need to be closed with the tool in place. Next, after the X and Y-axis are aligned the *collet* can be opened to release the tool. The status will show the state of the pneumatic valve of either "Open or Closed".

F3 Not used.

F4 EJECT - Press this key to toggle the *Ejector High Pressure* either back or forward. After the Shuttle is IN and the X and Y-axis are aligned and the *collet* is opened. Then, the *Ejector High Pressure* will need to be forward to unload the tool. The status will show the state of the pneumatic valve of either "Back or Forward".

F5 Key not used.

F6 AXIS - Go to the next screen to setup the Unloader X and Y-axis. (Seepage 2-11)

GP #11, Setup Unloader X Axis for Work Head

X Axis Setup UNLOADER Position					
F2 : Set FEED RATE = x.xxx In/sec					
Rate Range : 0.001 to 1.000 In/sec					
X ABS= x.xxxx In Stored Pos= xx.xxxx In					
F5 : GoTo Stored Unload Position.					
BACK	RATE	STORE	_____	GOTO	Y-AXI

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK -- Press this key to go back to Setup Unloader Pneumatic screen. (Seepage 2-10)

F2 RATE - Press this key to access the X-axis Feed Rate and then enter the desired value. The rate range is 0.001 to 1.000 In/Sec.

F3 STORE - Press this key to access the Stored Loader Position value. Then enter the value displayed by the ABS (absolute value) position or a modified value.

F4 Key not used.

F5 GOTO - Press this key to send the axis the stored unloading position.

F6 Y-AXI - Press this key to go to the next screen to setup the Unloader Y-axis. (Seepage 2-12)

Note: Then use the **JOG IN** or **JOG OUT** push buttons to control the axis.

GP #12, Setup Unloader Y Axis for Work Head

Y Axis Setup UNLOADER Position					
F2 : Set FEED RATE = x.xxx In/sec					
Rate Range : 0.001 to 1.000 In/sec					
X ABS= x.xxxx In Stored Pos= x.xxxx In					
F5 : GoTo Stored Unload Position.					
BACK	RATE	STORE	_____	GOTO	_____

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK -- Press this key to go back to Setup Unloader X-Axis screen.
(See page 2-11)

F2 RATE - Press this key to access the *Y-axis Feed Rate* and then enter the desired value. The rate range is 0.001 to 1.000 In/Sec.

F3 STORE - Press this key to access the Stored Loader Position value. Then enter the value displayed by the ABS (absolute value) position or a modified value.

F4 Key not used.

F5 GOTO - Press this key to send the axis the stored unloading position.

F6 Key not used.

Note: Then use the **JOG IN** or **JOG OUT** push buttons to control the axis.

GP #13, WORK HEAD MENU - Weldon Flats Routines

WORK HEAD MENU - WELDON FLAT ROUTINES					
F3 : SINGLE Weldon					
F5 : DOUBLE Weldon Flat Setup					
MENU3	_____	SINGL	_____	DBL	_____

F1 **F2** **F3** **F4** **F5** **F6**

F1 MENU3 - Press this key to return to Operator Setup Routines. (See page 2-3)

F2 Key not used.

F3 SINGL - Press this key for the screen to setup the Work Head for a Single Weldon Flat on the tool. (See page 2-14)

F4 Not used.

F5 DBL --- Press this key for the screen to setup two Weldon Flats that requires one wheel width to form a center flat and an end flat on the tool. (See page 2-27)

F6 Not used.

GP #14, Work Head - Setup Single Weldon Flat

Setup Work Head - SINGLE Weldon Flat					
F3 = Setup X-AXIS Position					
F4 = Setup Y-AXIS Position					
F5 = Setup Z-AXIS Position					
F6 = Setup Work Head Cycle					
MENU5	_____	--X--	--Y--	--Z--	NEXT

F1 **F2** **F3** **F4** **F5** **F6**

F1 MENU4 - Press this key to go back to Work Head Weldon Flats Routines' menu. (Seepage 2-13)

F2 Key not used.

F3 --X-- - Press this key for the screen to setup the X-AXIS position to grind the single Weldon Flat. (Seepage 2-15)

F4 --Y-- - Press this key for the screen to setup the Y-AXIS starting and finish positions. (Seepage 2-16)

F5 --Z-- - Press this key for the screen to setup the Z-AXIS touch off position and finish depth. (Seepage 2-17)

F6 NEXT - Press this key to go to the next screen to setup the Single Weldon Flat tool cycle. (Seepage 2-18)

GP #15, Setup X—Axis Work Head Single Weldon Flat

Setup X-AXIS - Single Weldon Flat					
ABS = xx.xxxx In Stored Pos= xx.xxxx In					
Edge: xx.xxxx In F3 : STORE Position					
F5 : Set FEED RATE = x.xxx In/sec					
Rate Range = 0.001 to 1.000 In/sec					
BACK	EDGE	STORE	_____	RATE	_____

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK - Press this key to go back to Setup Work Head Single Weldon Flat menu. (See page 2-14)

F2 EDGE - Press this key to access the operator's Edge reference position value. This reference value can be used to represent the distance from the Collet to the back edge of the wheel face. The program's calculations do not use the operator's Edge reference value.

F3 STORE -- Press this key to access the X-axis stored position value. Jog the X-axis to the proper grind position and then enter the ABS value to the stored position value. This value can also be revised without axis in setup position.

F4 Key not used.

F5 RATE - Press this key to access the *X-axis Feed Rate* and then enter the desired value. The rate range is 0.001 to 1.000 In/Sec.

F6 Key not used.

Note: Then use the **JOG IN** or **JOG OUT** push buttons to control the axis.

Additional, the operator may want to move the Z-axis down to close proximity of contact to the top surface of the tool to be more accurate with the X-axis position. To do this, back up to the menu and select the Z-axis and then return this screen.

GP #16, Setup Y—Axis Work Head Single Weldon Flat

Setup Y-AXIS - Single Weldon Flat					
ABS = xx.xxxx In START Pos= xx.xxxx In					
Tangent xx.xxxx" FINISH Pos= xx.xxxx In					
F5 : Set FEED RATE = x.xxx In/sec					
Rate Range = 0.001 to 1.000 In/sec					
BACK	TAN	START	FINIS	RATE	_____

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK - Press this key to go back to Setup Work Head Single Weldon Flat menu. (Seepage 2-14)

F2 TAN - Press this key to access the operator's Tangent reference position value. This reference value can be used to represent the Wheel and Collet vertical centers position. The program's calculations do not use the operator's Tangent reference value.

F3 START - Press this key to copy the Y-axis ABS position to the Y-axis starting position. The starting position is the value that the auto cycle uses.

Important: this position should be on the far side of the wheel.

F4 FINIS - Press this key to copy the Y-axis ABS position to the Y-axis finish position. The finish position is the value that the auto cycle uses.

Important: this position should be on the operator side of the wheel.

F5 RATE - Press this key to access the *Y-axis Feed Rate* and then enter the desired value. The rate range is 0.001 to 1.000 In/Sec.

F6 Key not used.

Note: Then use the **JOG IN** or **JOG OUT** push buttons to control the axis.

GP #17, Setup Z—Axis Work Head Single Weldon Flat

Setup Z-AXIS - Single Weldon Flat TOUCH OFF (-)Position = xx.xxxx In ABS = xx.xxxx In DEPTH = xx.xxxx In F5 : Set FEED RATE = x.xxx In/sec Rate Range = 0.001 to 1.000 In/sec					
BACK	_____	TOUCH	DEPTH	RATE	_____

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK - Press this key to go back to Setup Work Head Single Weldon Flat menu. (Seepage 2-14)

F2 Key not used.

F3 TOUCH - Press this key to access the Z-axis "Negative touch off position" value and enter a value from the numeric keys. Jog axis down slow until the wheel touches the tool outside diameter. Then use this function to enter the correct value to the "Negative touch off position". Use the ABS position to determine the correct value to place in the "Negative touch off position".

F4 DEPTH - Press this key to access the Z-axis "Finish DEPTH Value" and enter a value from the numeric keys. Calculate this "depth value" from the information given by the tool print. This will be the distance from the outside diameter of the tool the flat portion to be formed.

F5 RATE - Press this key to access the *Z-axis Feed Rate* and then enter the desired value. The rate range is 0.001 to 1.000 In/Sec.

F6 Key not used.

Note: Then use the **JOG IN** or **JOG OUT** push buttons to control the axis.

GP #18, Setup Cycle Counters - Work Head Single Weldon Flat

COUNTERS, Work Head Single Weldon Flat F2 : Cycle Count Down =[?] Value = xxx F3 : Cycle Count Down PRESET = xxx F5 : ADJUST PARTS Counter? = xxxxx					
BACK	TOGGL	-PRE-	_____	PARTS	NEXT

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK - Press this key to go back to Setup Work Head Single Weldon Flat menu. (Seepage 2-14)

F2 TOGGL - Press this key to toggle the state of the Count Down Counter to either "NO and RESET" or "YES".

This function will allow the machine to complete the number of desired tool cycles, determined by the preset value, and then do a cycle stop. This can be used to allow the machine to run after an operator shift is complete or for extended time periods without an operator.

F3 -PRE- - Press this key to enter a "Preset value" for the count down counter to use. This value must be a positive number, for example (1 to 100).

F4 Key not used.

F5 PARTS - Press this key to adjust the inventory Parts Counter to a value of (0) zero or to a corrected good part value. This part counter is designed for the operator to keep track of his/her inventory for each shift or long time run of a job.

F6 NEXT - Go to the next screen for more Work Head cycle setup screens. (Seepage 2-19)

GP #19, Cycle Information Work Head Single Weldon Flat

Work Head - 1 Weldon Flat - Cycle Info					
Note: The CLEAN UP PASS, if selected, is an additional finish pass to polish the tool. Select YES/NO and Feed Rates					
F4 = Home Z, X, Y					
BACK	_____	_____	HOME	_____	NEXT
F1	F2	F3	F4	F5	F6

This screen has on board information about the Clean Up Pass.

F1 BACK -- Press this key to go back to setup cycle counters for the Work Head Single Weldon Flat. (Seepage 2-18)

F2 Key not used.

F3 Key not used.

F4 HOME - Press this key to command the entire Axis to find home or go home, which ever is needed.

F5 Key not used.

F6 NEXT - Press this key to Go to the next screen for more Work Head cycle setup screens. (Seepage 2-20)

GP #20, Setup Cycle for Work Head Single Weldon Flat

Setup CYCLE - Work Head - 1 Weldon Flat					
F2 : Number of Grind PASSES = xx Passes					
F3 "Y" GRIND Feed Rate = x.xxxx In/sec					
F4 "Y" CLEAN UP Pass Rate= x.xxxx In/sec					
F5 : Do Clean Up Pass ? = [NO/YES]					
BACK	PASS	GRIND	CLEAN	N/Y	NEXT

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK - Press this key to go back 1 screen to Setup Work Head Single Weldon Flats. (Seepage 2-19)

F2 PASS - Press this key to access the value for the number of grind passes to be done on each side. The total plunge depth of the Z-axis will be equally divided by the value in the "Grind Passes".

Example: $[(-Z\text{-axis touch off} - Z\text{-axis finish depth}) / \text{Grind Passes}] = Z\text{-axis depth increments.}$

F3 GRIND - Press this key to access the value for the Y-axis Grind feed rate in Inches per second.

The valid values are 0.0001 In/sec to 0.1250 In/sec maximum.

F4 CLEAN - Press this key to access the value for the Y-axis Clean Up Pass feed rate in Inches per second.

The valid values are 0.0001 In/sec to 0.1250 In/sec maximum.

F5 N/Y - Press this key to select a clean up pass of Yes or No.

F6 NEXT - Press this key to go to the next Cycle setup screen.
(Seepage 2-21)

GP #21, Work Head, Select Cycle for Single Weldon Flat

SELECT CYCLE -- Work Head Routine 1 Weldon Flat F3 : SINGLE & AUTO CYCLE /w AUTO LOAD F4 : HAND LOAD CYCLE F5 : HOME Axis Z, X, Y					
BACK	_____	AUTO	HAND	HOME	_____

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK - Press this key to go back to Setup Cycle for the Work Head Single Weldon Flats. (Seepage 2-20)

F2 Key not used.

F3 AUTO - Press this key to go to the Single Cycle mode screen and the Auto Cycle mode screen with automatic loading. (Seepage 2-22)

F4 HAND - Press this key to go to the Hand Load cycle for the Work Head Single Weldon Flat. (Seepage 2-25)

F5 HOME - Press this key to command the entire Axis to find home or go home, which ever is needed.

F6 Key not used.

GP #22, Work Head- Setup Auto Cycle Weldon Flat

WORK HEAD - Setup Auto Cycle					
F1 : BACK 1 Screen & STOP CYCLE					
F3 : GRIND Wheel Speed = xxxx FPM					
F4 : CLEAN UP Wheel Speed = xxxx FPM					
F6 : SINGLE & AUTO CYCLE /w AUTO LOAD					
BACK	_____	GRIND	CLEAN	_____	SINGL

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK - Press this key to go back 1 screen to Setup Cycle for the Work Head Single Weldon Flats and also do a "Cycle Stop".
(See page 2-21)

F2 Key not used.

F3 GRIND - Press this key to access the value for the Grinding Wheel Head Speed in feet per minute.

F4 CLEAN - Press this key to access the value for the Clean Up Wheel Head Speed in feet per minute.

F5 Key not used

F6 SINGL - Press this key to go to the Single Cycle mode screen and the Auto Cycle mode screen with automatic loading. (See page 2-23)

GP #23, Single Cycle Work Head Single Weldon Flat

SINGLE CYCLE - Work Head 1 Weldon Flat					
F1 = STOP CYCLE		F4 = Back 1 Screen			
F3 = COOLANT =[stat]		Part Count = xxxxx			
X:xx.xxxx		Y:xx.xxxx		Cycle = xx:xx	
Z:xx.xxxx		[FAULTS!]			
STOP	START	COOL	BACK	FAULT	AUTO

F1 **F2** **F3** **F4** **F5** **F6**

F1 STOP - Press this key to Stop Cycle.

F2 START - Press this key to start the Single Cycle mode.

F3 COOL - Press this key to toggle the coolant solenoid between auto and off.

F4 BACK - Press this key to go back one screen to Setup Work Head Single Weldon Flats. (Seepage 2-22)

F5 FAULT - Press this key if the word "FAULTS!" is flashing to view the fault section.

F6 AUTO -- Press this key to advance to the Work Head Auto Cycle with auto loading screen. (Seepage 2-24)

GP #24, Auto Cycle Work Head Single Weldon Flat

AUTO CYCLE - Work Head - 1 Weldon Flat					
F1 = STOP CYCLE WHEEL = xxxx FPM					
F3 : COOLANT =[stat] Part Count = xxxxx					
X:xx.xxxx		Y:xx.xxxx		Cycle = xx:xx	
Z:xx.xxxx				[FAULTS!]	
STOP	START	COOL	_____	FAULT	SINGL

F1 **F2** **F3** **F4** **F5** **F6**

F1 STOP - Press this key to Stop Auto Cycle mode.

F2 START - Press this key to start the Auto Cycle mode.

F3 COOL - Press this key to toggle the coolant solenoid between auto and off.

F4 Key not used.

F5 FAULT - Press this key if the word "FAULTS!" is flashing to view the fault section.

F6 SINGL - Press this key to return to the Single Cycle mode. (See page 2-23)

GP #25, Work Head- Setup Hand Cycle Weldon Flat

WORK HEAD - Setup Hand Load Cycle					
F1 : BACK 1 Screen & STOP CYCLE					
F3 : GRIND Wheel Speed = xxxx FPM					
F4 : CLEAN UP Wheel Speed = xxxx FPM					
F6 : HAND LOAD CYCLE					
BACK	_____	GRIND	CLEAN	_____	HAND

F1 F2 F3 F4 F5 F6

F1 BACK - Press this key to go back 1 screen to Setup Cycle for the Work Head Single Weldon Flats and also do a "Cycle Stop".
(See page 2-21)

F2 Key not used.

F3 GRIND - Press this key to access the value for the Grinding Wheel Head Speed in feet per minute.

F4 CLEAN - Press this key to access the value for the Clean Up Wheel Head Speed in feet per minute.

F5 Key not used.

F6 HAND - Press this key to go to the Hand Load cycle for the Work Head Single Weldon Flat. (See page 2-26)

GP #26, Hand Load Cycle Work Head Single Weldon Flat

HAND LOAD CYCLE Work Head 1 Weldon Flat					
F1 = STOP CYCLE F5: COLLET =[status]					
F3 : COOLANT =[stat] Part Count = xxxxx					
X:xx.xxxx		Y:xx.xxxx		Cycle = xx:xx	
Z:xx.xxxx				[FAULTS!]	
STOP	START	COOL	FAULT	COLET	BACK

F1 **F2** **F3** **F4** **F5** **F6**

F1 STOP - Press this key to Stop Cycle.

F2 START - Press this key to start the Single Cycle mode.

F3 COOL - Press this key to toggle the coolant solenoid between auto and off.

F4 FAULT - Press this key if the word "FAULTS!" is flashing to view the fault section.

F5 COLET - Press this key to "Open" or "Close" the collet to hand load the Index Head.

F6 BACK - Press this key to go back one screen to Setup Hand Load Index Head. (Seepage [2-25](#))

GP #27, Work Head - Setup Double Weldon Flats

Setup Work Head - DOUBLE Weldon Flat					
F3 = Setup X-AXIS Position					
F4 = Setup Y-AXIS Position					
F5 = Setup Z-AXIS Position					
F6 = Setup Work Head Cycle					
MENU5	_____	--X--	--Y--	--Z--	NEXT

F1 **F2** **F3** **F4** **F5** **F6**

F1 MENU4 - Press this key to go back to Work Head Weldon Flats Routines' menu. (Seepage 2-13)

F2 Key not used.

F3 --X-- - Press this key for the screen to setup the X-AXIS position to grind the single Weldon Flat. (Seepage 2-28)

F4 --Y-- - Press this key for the screen to setup the Y-AXIS starting and finish positions. (Seepage 2-30)

F5 --Z-- - Press this key for the screen to setup the Z-AXIS touch off position and finish depth. (Seepage 2-31)

F6 NEXT - Press this key to go to the next screen to setup the Double Weldon Flats tool cycle. (Seepage 2-32)

GP #28, Setup X—Axis Work Head Double Weldon Flat

Setup X-AXIS - Double Weldon Flats					
ABS = xx.xxxx In Has 2 Stored Positions					
Edge: xx.xxxx		F3 : Goto Store PAGE			
F5 : Set FEED RATE = x.xxx In/Sec					
Rate Range = 0.001 to 1.000 In/sec					
BACK	EDGE	PAGE	_____	RATE	_____

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK - Press this key to go back to Setup Work Head Double Weldon Flats menu screen. (Seepage 2-27)

F2 EDGE - Press this key to access the operator's Edge reference position value. This reference value can be used to represent the distance from the Collet to the back edge of the wheel face. The program's calculations do not use the operator's Edge reference value.

F3 PAGE - Press this key to access the screen to store the desired positions for the flats. (Seepage 2-29)

F4 Key not used.

F5 RATE - Press this key to access the *X-axis Feed Rate* and then enter the desired value. The rate range is 0.001 to 1.000 In/Sec.

F6 Key not used.

Note: Then use the **JOG IN** or **JOG OUT** push buttons to control the axis.

Additional, the operator may want to move the Z-axis down to close proximity of contact to the top surface of the tool to be more accurate with the X-axis position. To do this, back up to the menu and select the Z-axis and then return this screen.

GP #29, X-axis Store positions, Work Head Double Weldon Flat

```

Store Positions;          X ABS = xx.xxxx In
F3 : Store X INNER Position = xx.xxxx In
F4 : Store X END   Position = xx.xxxx In
    
```

```

BACK   _____  INNER   END   _____  _____
    
```

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK - Press this key to go back 1 screen to setup Double Weldon Flat X Axis. (Seepage 2-28)

F2 Key not used.

F3 INNER - Press this key to access the inner flat value and then enter the desired position.

F4 END --- Press this key to access the end flat value and then enter the desired position.

F5 Key not used.

F6 Key not used.

GP #30, Setup Y—Axis Work Head Double Weldon Flat

Setup Y-AXIS - Double Weldon Flat					
ABS = xx.xxxx In START Pos= xx.xxxx In					
Tangent xx.xxxx" FINISH Pos= xx.xxxx In					
F5 : Set FEED RATE = x.xxx In/sec					
Rate Range = 0.001 to 1.000 In/sec					
BACK	TAN	START	FINIS	RATE	_____
F1	F2	F3	F4	F5	F6

F1 BACK - Press this key to go back to Setup Work Head Double Weldon Flats menu screen. (Seepage 2-27)

F2 TAN - Press this key to access the operator's Tangent reference position value. This reference value can be used to represent the Wheel and Collet vertical centers position. The program's calculations do not use the operator's Tangent reference value.

F3 START - Press this key to copy the Y-axis ABS position to the Y-axis starting position. The starting position is the value that the auto cycle uses.

Important: this position should be on the far side of the wheel.

F4 FINIS - Press this key to copy the Y-axis ABS position to the Y-axis finish position. The finish position is the value that the auto cycle uses.

Important: this position should be on the operator side of the wheel.

F5 RATE - Press this key to access the *Y-axis Feed Rate* and then enter the desired value. The rate range is 0.001 to 1.000 In/Sec.

F6 Key not used.

Note: Then use the **JOG IN** or **JOG OUT** push buttons to control the axis.

GP #31, Setup Z—Axis Work Head Double Weldon Flat

Setup Z-AXIS - Double Weldon Flat					
TOUCH OFF (-)Position = xx.xxxx In					
ABS = xx.xxxx In		DEPTH = xx.xxxx In			
F5 : Set FEED RATE = x.xxx In/sec					
Rate Range = 0.001 to 1.000 In/sec					
BACK	_____	TOUCH	DEPTH	RATE	_____

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK - Press this key to go back to Setup Work Head Double Weldon Flats menu screen. (Seepage 2-27)

F2 Key not used.

F3 TOUCH - Press this key to access the Z-axis "Negative touch off position" value and enter a value from the numeric keys. Jog axis down slow until the wheel touches the tool outside diameter. Then use this function to enter the correct value to the "Negative touch off position". Use the ABS position to determine the correct value to place in the "Negative touch off position".

F4 DEPTH - Press this key to access the Z-axis "Finish DEPTH Value" and enter a value from the numeric keys. Calculate this "depth value" from the information given by the tool print. This will be the distance from the outside diameter of the tool the flat portion to be formed.

F5 RATE - Press this key to access the *Z-axis Feed Rate* and then enter the desired value. The rate range is 0.001 to 1.000 In/Sec.

F6 Key not used.

Note: Then use the **JOG IN** or **JOG OUT** push buttons to control the axis.

GP #32, Setup Cycle Counters - Work Head Double Weldon Flat

COUNTERS, Work Head Double Weldon Flat					
F2 : Cycle Count Down =[?] Value = xxx					
F3 : Cycle Count Down PRESET = xxx					
F5 : ADJUST PARTS Counter? = xxxxx					
BACK	TOGGL	-PRE-	_____	PARTS	NEXT

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK - Press this key to go back to Setup Work Head Double Weldon Flats menu screen. (Seepage 2-27)

F2 TOGGL - Press this key to toggle the state of the Count Down Counter to either "NO and RESET or YES".

This function will allow the machine to complete the number of desired tool cycles, determined by the preset value, and then do a cycle stop. This can be used to allow the machine to run after an operator shift is complete or for extended time periods without an operator.

F3 -PRE- - Press this key to enter a "Preset value" for the count down counter to use. This value must be a positive number, for example (1 to 100).

F4 Key not used.

F5 PARTS - Press this key to adjust the inventory Parts Counter to a value of (0) zero or to a corrected good part value. This part counter is designed for the operator to keep track of his/her inventory for each shift or long time run of a job.

F6 NEXT - Go to the next screen for more Work Head cycle setup screens. (Seepage 2-33)

GP #33, Cycle Information Work Head Double Weldon Flat

Work Head - 2 Weldon Flats - Cycle Info					
Note: The CLEAN UP PASS, if selected, is an additional finish pass to polish the tool. Select YES/NO and Feed Rates					
F4 = Home Axis Z, X, Y					
BACK	_____	_____	HOME	_____	NEXT
F1	F2	F3	F4	F5	F6

This screen has on board information about the Clean Up Pass.

F1 BACK - Press this key to go back to setup counters for the Work Head Double Weldon Flats. (Seepage 2-32)

F2 Not used.

F3 Not used.

F4 HOME - Press this key to command the entire Axis to find home or go home, which ever is needed.

F5 Not used.

F6 NEXT - Press this key to Go to the next screen for more Work Head cycle setup screens. (Seepage 2-34)

GP #34, Setup Cycle for Work Head Double Weldon Flats

Setup CYCLE - Work Head - 2 Weldon Flats					
F2 : Number of Grind PASSES = [xx]					
F3 "Y" GRIND Feed Rate = x.xxxx In/sec					
F4 "Y" CLEAN UP Pass Rate= x.xxxx In/sec					
F5 : Do Clean Up Pass ? = [NO/YES]					
BACK	PASS	GRIND	CLEAN	N/Y	NEXT
F1	F2	F3	F4	F5	F6

F1 BACK - Press this key to go back 1 screen to setup the Work Head Double Weldon Flats. (Seepage 2-33)

F2 PASS - Press this key to access the value for the number of grind passes to be done on each side. The total plunge depth of the Z-axis will be equally divided by the value in the "Grind Passes".

Example: $[(-Z\text{-axis touch off} - Z\text{-axis finish depth}) / \text{Grind Passes}] = Z\text{-axis depth increments.}$

F3 GRIND - Press this key to access the value for the Y-axis Grind feed rate in Inches per second.

The valid values are 0.0001 In/sec to 0.1250 In/sec maximum.

F4 CLEAN - Press this key to access the value for the Y-axis Clean Up Pass feed rate in Inches per second.

The valid values are 0.0001 In/sec to 0.1250 In/sec maximum.

F5 N/Y - Press this key to select a clean up pass of Yes or No.

F6 NEXT - Press this key to go to the next Work Head cycle setup screen. (Seepage 2-35)

GP #35, Work Head, Select Cycle for Double Weldon Flats

SELECT CYCLE -- Work Head Routines					
2 Weldon Flats					
F3 : SINGLE & AUTO CYCLE /w AUTO LOAD					
F4 : HAND LOAD CYCLE					
F5 : FIND HOME for All Axis					
BACK	_____	AUTO	HAND	FHOME	_____

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK - Press this key to go back to Setup Cycle for the Work Head Double Weldon Flats. (Seepage 2-34)

F2 Key not used.

F3 AUTO - Press this key to go to the Work Head Single Cycle mode and view screen. (Seepage 2-36)

F4 HAND - Press this key to go to the Hand Load cycle for the Work Head Double Weldon Flats. (Seepage 2-39)

F5 FHOME - Press this key to command the entire Axis to find home.

F6 Not used.

GP #36, Work Head- Setup Auto Cycle Weldon Flat

WORK HEAD - Setup Auto Cycle					
F1 : BACK 1 Screen & STOP CYCLE					
F3 : GRIND Wheel Speed = xxxx FPM					
F4 : CLEAN UP Wheel Speed = xxxx FPM					
F6 : SINGLE & AUTO CYCLE /w AUTO LOAD					
BACK	_____	GRIND	CLEAN	_____	SINGL

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK - Press this key to go back 1 screen to Setup Cycle for the Work Head Double Weldon Flats and also do a "Cycle Stop".
(Seepage 2-35)

F2 Key not used.

F3 GRIND - Press this key to access the value for the Grinding Wheel Head Speed in feet per minute.

F4 CLEAN - Press this key to access the value for the Clean Up Wheel Head Speed in feet per minute.

F5 Key not used

F6 SINGL - Press this key to go to the Single Cycle mode screen and the Auto Cycle mode screen with automatic loading. (Seepage 2-37)

GP #37, Single Cycle - Work Head Double Weldon Flats

SINGLE CYCLE - Work Head 2 Weldon Flats					
F1 = STOP CYCLE		F4 = Back 1 Screen			
F3 = COOLANT =[stat]		Part Count = xxxxx			
X:xx.xxxx		Y:xx.xxxx		Cycle = xx:xx	
Z:xx.xxxx		[FAULTS!]			
STOP	START	COOL	BACK	FAULT	AUTO
F1	F2	F3	F4	F5	F6

F1 STOP - Press this key to Stop Cycle.

F2 START - Press this key to start the Single Cycle mode.

F3 COOL - Press this key to toggle the coolant solenoid between auto and off.

F4 BACK - Press this key to go back one screen to the Work Head Double Weldon Flats. (Seepage 2-36)

F5 FAULT - Press this key if the word "FAULTS!" is flashing to view the fault section.

F6 AUTO -- Press this key to advance to the Work Head Auto Cycle mode and view screen. (Seepage 2-38)

GP #39, Work Head- Setup Hand Cycle Weldon Flat

WORK HEAD - Setup Hand Load Cycle					
F1 : BACK 1 Screen & STOP CYCLE					
F3 : GRIND Wheel Speed = xxxx FPM					
F4 : CLEAN UP Wheel Speed = xxxx FPM					
F6 : HAND LOAD CYCLE					
BACK	_____	GRIND	CLEAN	_____	HAND

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK - Press this key to go back 1 screen to Setup Cycle for the Work Head Double Weldon Flats and also do a "Cycle Stop".
(See page 2-35)

F2 Key not used.

F3 GRIND - Press this key to access the value for the Grinding Wheel Head Speed in feet per minute.

F4 CLEAN - Press this key to access the value for the Clean Up Wheel Head Speed in feet per minute.

F5 Key not used.

F6 HAND - Press this key to go to the Hand Load cycle for the Work Head Single Weldon Flat. (See page 2-40)

GP #100, Hand Load Cycle Work Head Double Weldon Flat

HAND LOAD CYCLE Work Head 2 Weldon Flats					
F1 = STOP CYCLE		F5: COLLET =[status]			
F3 = COOLANT =[stat]		Part Count = xxxxx			
X:xx.xxxx		Y:xx.xxxx		Cycle = xx:xx	
Z:xx.xxxx		[FAULTS!]			
STOP	START	COOL	FAULT	COLET	BACK

F1 **F2** **F3** **F4** **F5** **F6**

F1 STOP - Press this key to Stop Cycle.

F2 START - Press this key to start the Single Cycle mode.

F3 COOL - Press this key to toggle the coolant solenoid between auto and off.

F4 FAULT - Press this key if the word "FAULTS!" is flashing to view the fault section.

F5 COLET - Press this key to open or close the collet to hand load the Index Head.

F6 BACK - Press this key to go back one screen to Setup Hand Load Index Head. (Seepage 2-39)

GP #40, VICE MENU for Weldon Flat Routines

VICE MENU - WELDON FLAT ROUTINES					
F3 : SINGLE Weldon / Whistle Setup					
F4 : DOUBLE Weldon Flat Setup					
F5 : WIDE End Double Weldon Flat Setup					
MENU2	_____	SINGL	DBL	WIDE	_____

F1 **F2** **F3** **F4** **F5** **F6**

F1 MENU2 - Press this key to return to Operator Setup Routines. (See page 2-2)

F2 Key not used.

F3 SINGL - Press this key for the screen to setup a Single Weldon Flat or Whistle Stop on the tool. This is a vice routine and uses a single cycle operation. (See page 2-42)

F4 DBL --- Press this key for the screen to setup two Weldon Flats that requires one wheel width to form a center flat and an end flat on the tool. This is a vice routine and uses a single cycle operation. (See page 2-50)

F5 WIDE -- Press this key for the screen to setup two Weldon Flats that requires one wheel width to form a center flat and more than one wheel width to form the end flat on a large tool. This is a vice routine and uses a single cycle operation. (See page 2-59)

F6 Not used.

GP #41, Vice - Setup XYZ, Single Weldon Flat

Setup VICE for SINGLE Weldon Flat					
F3 = Setup X-AXIS Position					
F4 = Setup Y-AXIS Position					
F5 = Setup Z-AXIS Position					
MENU6	_____	--X--	--Y--	--Z--	NEXT

F1 **F2** **F3** **F4** **F5** **F6**

F1 MENU6 - Press this key to go back to Weldon / Whistle Stop Routine menu. (Seepage 2-41)

F2 Key not used.

F3 --X-- - Press this key for the screen to setup the X-AXIS position to grind the Weldon Flat. (Seepage 2-43)

F4 --Y-- - Press this key for the screen to setup the Y-AXIS starting and finish positions. (Seepage 2-44)

F5 --Z-- - Press this key for the screen to setup the Z-AXIS touch off position and finish depth. (Seepage 2-45)

F6 NEXT - Press this key to go to the next screen to setup the Single Weldon / Whistle Stop tool cycle. (Seepage 2-46)

GP #42, Vice Setup X-axis, Single Weldon Flat

Setup VICE X-AXIS Single Weldon Flat					
ABS = xx.xxxx In Stored Pos= xx.xxxx In					
Edge: xx.xxxx F3 : STORE Position					
F5 : Set FEED RATE = x.xxx In/Sec					
Rate Range = 0.001 to 1.000 In/sec					
BACK	EDGE	STORE	_____	RATE	_____

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK - Press this key to go back to setup Single Weldon Flat / Whistle Stop menu. (See page 2-42)

F2 EDGE - Press this key to access the operator's Edge reference position value. This reference value can be used to represent the distance from the Vice side to the back edge of the wheel face. The program's calculations do not use the operator's Edge reference value.

F3 STORE - Press this key to access the X-axis stored position value. Jog the X-axis to the proper grind position and then enter the ABS value to the stored position value. This value can also be revised without axis in setup position.

F4 Key not used.

F5 RATE - Press this key to access the *X-axis Feed Rate* and then enter the desired value. The rate range is 0.001 to 1.000 In/Sec.

F6 Key not used.

Note: Then use the **JOG IN** or **JOG OUT** push buttons to control the axis.

Additional, the operator may want to move the Z-axis down to close proximity of contact to the top surface of the tool to be more accurate with the X-axis position. To do this, back up to the menu and select the Z-axis and then return this screen.

GP #43, Vice Setup Y-axis, Single Weldon / Whistle

Setup VICE Y-AXIS Single Weldon Flat					
ABS = xx.xxxx In START Pos= xx.xxxx In					
Tan: xx.xxxx FINISH Pos= xx.xxxx In					
F5 : Set FEED RATE = x.xxx In/sec					
Rate Range = 0.001 to 1.000 In/sec					
BACK	TAN	START	FINIS	RATE	_____

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK - Press this key to go back to setup Single Weldon Flat / Whistle Stop menu. (See page 2-42)

F2 TAN - Press this key to access the operator's Tangent reference position value. This reference value can be used to represent the Wheel and Vice tool vertical centers position. The program's calculations do not use the operator's Tangent reference value.

F3 START - Press this key to copy the Y-axis ABS position to the Y-axis starting position. The starting position is the value that the auto cycle uses.

Important: this position should be on the far side of the wheel.

F4 FINIS - Press this key to copy the Y-axis ABS position to the Y-axis finish position. The finish position is the value that the auto cycle uses.

Important: this position should be on the operator side of the wheel.

F5 RATE - Press this key to access the *Y-axis Feed Rate* and then enter the desired value. The rate range is 0.001 to 1.000 In/Sec.

F6 Key not used.

Note: Then use the **JOG IN** or **JOG OUT** push buttons to control the axis.

GP #44, Vice Setup Z-axis, Single Weldon / Whistle

Setup VICE Z-AXIS Single Weldon Flat					
TOUCH OFF (-) Position = xx.xxxx In					
ABS = xx.xxxx In		DEPTH = xx.xxxx In			
F5 : Set FEED RATE = x.xxx In/sec					
Rate Range = 0.001 to 1.000 In/sec					
BACK	_____	TOUCH	DEPTH	RATE	_____
F1	F2	F3	F4	F5	F6

F1 BACK - Press this key to go back to setup Single Weldon Flat / Whistle Stop menu. (See page 2-42)

F2 Key not used.

F3 TOUCH - Press this key to access the Z-axis "Negative touch off position" value and enter a value from the numeric keys. Jog axis down slow until the wheel touches the tool outside diameter. Then use this function to enter the correct value to the "Negative touch off position". Use the ABS position to determine the correct value to place in the "Negative touch off position".

F4 DEPTH - Press this key to access the Z-axis "Finish DEPTH Value" and enter a value from the numeric keys. Calculate this "depth value" from the information given by the tool print. This will be the distance from the outside diameter of the tool the flat portion to be formed.

F5 RATE - Press this key to access the *Z-axis Feed Rate* and then enter the desired value. The rate range is 0.001 to 1.000 In/Sec.

F6 Key not used.

Note: Then use the **JOG IN** or **JOG OUT** push buttons to control the axis.

GP #45, Vice Setup Single Weldon Flat Information

VICE - SINGLE Weldon Flat Cycle Info:					
Note: The CLEAN UP PASS to be selected is an additional finish pass to polish the tool. Select YES/NO and Feed Rates					
F4 = Home Axis Z, X, Y					
MENU	_____	_____	HOME	_____	NEXT
F1	F2	F3	F4	F5	F6

This screen has on board information about the Clean Up Pass.

F1 MENU - Press this key to go back to setup Single Weldon Flat / Whistle Stop menu. (See page 2-42)

F2 Key not used.

F3 Key not used.

F4 HOME - Press this key to command the entire Axis to find home or go home, which ever is needed.

F5 Key not used.

F6 NEXT - Press this key to go to the next screen for more setup information for the Single Weldon Flat / Whistle Stop tool. (See page 2-47)

GP #46, Vice Setup Cycle for Single Weldon / Whistle

Setup VICE CYCLE, Single Weldon Flat					
F2 : Number of Grind PASSES = [xx]					
F3 "Y" GRIND Feed Rate = x.xxxx In/sec					
F4 "Y" CLEAN UP Pass Rate= x.xxxx In/sec					
F5 : Do Clean Up Pass ? = [NO/YES]					
BACK	PASS	GRIND	CLEAN	N/Y	NEXT

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK - Press this key to go back to Single Weldon Flat / Whistle Stop information. (Seepage 2-46)

F2 PASS -- Press this key to access the value for the number of grind passes to be done on each side. The total plunge depth of the Z-axis will be equally divided by the value in the "Grind Passes".

Example: $[(-Z\text{-axis touch off} - Z\text{-axis finish depth}) / \text{Grind Passes}] = Z\text{-axis depth increments.}$

F3 GRIND - Press this key to access the value for the Y-axis Grind feed rate in Inches per second.

The valid values are 0.0001 In/sec to 0.1250 in/sec maximum.

F4 CLEAN - Press this key to access the value for the Y-axis Clean Pass feed rate in Inches per second.

The valid values are 0.0001 In/sec to 0.1250 in/sec maximum.

F5 N/Y --- Press this key to select a clean up pass of Yes or No.

F6 NEXT - Press this key to go to the next Cycle setup screen.

(Seepage 2-48)

GP #47, Vice Setup, Single Weldon Flat

SETUP VICE, Single Weldon Flat					
F2 : Adjust PARTS Counter? = xxxxx					
F3 : GRIND Wheel Speed = xxxx FPM					
F4 : CLEAN UP Wheel Speed = xxxxx FPM					
F1 : STOP CYCLE & BACK F6 : HAND CYCLE					
BACK	PARTS	GRIND	CLEAN	_____	HAND
F1	F2	F3	F4	F5	F6

F1 BACK - Press this key to go back to Setup Cycle for the Single Weldon Flat and also do a "Cycle Stop". (Seepage 2-47)

F2 PARTS - Press this key to adjust the inventory Parts Counter to a value of (0) zero or to a corrected good part value. This part counter is designed for the operator to keep track of his/her inventory for each shift or long time run of a job.

F3 GRIND - Press this key to access the value for the Grinding Wheel Head Speed in feet per minute.

F4 CLEAN - Press this key to access the value for the Clean Up Wheel Head Speed in feet per minute.

F5 Key not used.

F6 HAND - Press this key for the Vice Single Cycle mode screen. (Seepage 2-49)

GP #48, Vice Cycle, Single Weldon Flat

Hand Cycle - VICE, 1 Weldon Flat					
F1 = STOP CYCLE WHEEL = rrrr FPM					
F3 : COOLANT =[OFF] Part Count = xxxxx					
X:xx.xxxx Y:xx.xxxx Cycle = xx:xx					
Z:xx.xxxx U:xxx.xx Deg [FAULTS!]					
STOP	START	COOL	_____	FAULT	BACK
F1	F2	F3	F4	F5	F6

F1 STOP - Press this key to stop the Single Cycle mode.

F2 START - Press this key to start the Single Cycle mode.

F3 COOL - Press this key to toggle the coolant solenoid between auto and off.

F4 Key not used.

F5 FAULT - Press this key if the word "FAULTS!" is flashing to view the fault section.

F6 BACK - Press this key to and go back one screen to Set up Single Weldon Flat / Whistle Stop. (Seepage 2-48)

GP #49, Vice - Setup XYZ, Double Weldon Flat

Setup VICE for DOUBLE Weldon Flats					
F3 = Setup X-AXIS Position					
F4 = Setup Y-AXIS Position					
F5 = Setup Z-AXIS Position					
MENU6	_____	--X--	--Y--	--Z--	NEXT

F1 **F2** **F3** **F4** **F5** **F6**

F1 MENU6 - Press this key to go back to Weldon Flats Routine menu.
 (Seepage 2-41)

F2 Key not used.

F3 --X-- - Press this key for the screen to setup the X-AXIS position to grind two positions of the Weldon Flats. (Seepage 2-51)

F4 --Y-- - Press this key for the screen to setup the Y-AXIS starting and finish sweep positions. (Seepage 2-53)

F5 --Z-- - Press this key for the screen to setup the Z-AXIS touch off position and finish depth. (Seepage 2-54)

F6 NEXT - Go to the next screen to setup the Double Weldon Flat tool cycle. (Seepage 2-55)

GP #50, Vice Setup X-axis, Double Weldon Flat

Setup VICE X-AXIS Double Weldon Flats					
ABS = x.xxxx In Has 2 Stored Positions					
Edge: x.xxxx F3 : Goto Store PAGE					
F5 : Set FEED RATE = x.xxx In/Sec					
Rate Range = 0.001 to 1.000 In/sec					
BACK	EDGE	PAGE	_____	RATE	_____

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK - Press this key to go back to setup Double Weldon Flat menu.
(See page 2-50)

F2 EDGE - Press this key to access the operator's Edge reference position value. This reference value can be used to represent the distance from the Vice side to the back edge of the wheel face. The program's calculations do not use the operator's Edge reference value.

F3 PAGE - Press this key to access the screen to store the desired positions for the flats. (See page 2-52)

F4 Key not used.

F5 RATE - Press this key to access the *X-axis Feed Rate* and then enter the desired value. The rate range is 0.001 to 1.000 In/Sec.

F6 Key not used.

Note: Then use the **JOG IN** or **JOG OUT** push buttons to control the axis.

Additional, the operator may want to move the Z-axis down to close proximity of contact to the top surface of the tool to be more accurate with the X-axis position. To do this, back up to the menu and select the Z-axis and then return this screen.

GP #51, Vice X-axis Store positions, Double Weldon Flat

```

Store Positions;          X ABS = xx.xxxx In
F3 : Store X INNER Position = x.xxxx In
F4 : Store X END   Position = x.xxxx In
    
```

```

BACK      _____  INNER  END      _____  _____
    
```

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK - Press this key to go back 1 screen to setup Double Weldon Flat X Axis. (Seepage 2-51)

F2 Key not used.

F3 INNER - Press this key to access the inner flat value and then enter the desired position.

F4 END --- Press this key to access the end flat value and then enter the desired position.

F5 Key not used.

F6 Key not used.

GP #52, Vice Setup Y-axis, Double Weldon Flat

Setup VICE Y-AXIS Double Weldon Flat					
ABS = xx.xxxx		START Pos= xx.xxxx In			
Tan: xx.xxxx		FINISH Pos= xx.xxxx In			
F5 : Set FEED RATE = x.xxx In/sec					
Rate Range = 0.001 to 1.000 In/sec					
BACK	TAN	START	FINIS	RATE	_____
F1	F2	F3	F4	F5	F6

F1 BACK - Press this key to go back to setup Double Weldon Flat menu.
(See page 2-50)

F2 TAN - Press this key to access the operator's Tangent reference position value. This reference value can be used to represent the Wheel and Vice tool vertical centers position. The program's calculations do not use the operator's Tangent reference value.

F3 START - Press this key to copy the Y-axis ABS position to the Y-axis starting position. The starting position is the value that the auto cycle uses.

Important: this position should be on the far side of the wheel.

F4 FINIS - Press this key to copy the Y-axis ABS position to the Y-axis finish position. The finish position is the value that the auto cycle uses.

Important: this position should be on the operator side of the wheel.

F5 RATE - Press this key to access the *Y-axis Feed Rate* and then enter the desired value. The rate range is 0.001 to 1.000 In/Sec.

F6 Key not used.

Note: Then use the **JOG IN** or **JOG OUT** push buttons to control the axis.

GP #53, Vice Setup Z-axis, Double Weldon Flat

Setup VICE Z-AXIS Double Weldon Flat					
TOUCH OFF (-) Position = xx.xxxx In					
ABS = xx.xxxx In		DEPTH = xx.xxxx In			
F5 : Set FEED RATE = x.xxx In/sec					
Rate Range = 0.001 to 1.000 In/sec					
BACK	_____	TOUCH	DEPTH	RATE	_____
F1	F2	F3	F4	F5	F6

F1 BACK - Press this key to go back to setup Double Weldon Flat menu.
(See page 2-50)

F2 Key not used.

F3 TOUCH - Press this key to access the Z-axis "Negative touch off position" value and enter a value from the numeric keys. Jog axis down slow until the wheel touches the tool outside diameter. Then use this function to enter the correct value to the "Negative touch off position". Use the ABS position to determine the correct value to place in the "Negative touch off position".

F4 DEPTH - Press this key to access the Z-axis "Finish DEPTH Value" and enter a value from the numeric keys. Calculate this "depth value" from the information given by the tool print. This will be the distance from the outside diameter of the tool the flat portion to be formed.

F5 RATE - Press this key to access the *Z-axis Feed Rate* and then enter the desired value. The rate range is 0.001 to 1.000 In/Sec.

F6 Key not used.

Note: Then use the **JOG IN** or **JOG OUT** push buttons to control the axis.

GP #54, Vice Double Weldon Flat Information

VICE - DOUBLE Weldon Flat Cycle Info: Note: The CLEAN UP PASS, if selected, is an additional finish pass to polish the tool. Select YES/NO and Feed Rates F4 = Home Z, X, Y					
MENU	_____	_____	HOME	_____	NEXT
F1	F2	F3	F4	F5	F6

This screen has on board information about the Clean Up Pass.

F1: MENU - Press this key to go back to Double Weldon Flat setup menu.
 (See page 2-50)

F2: Not used.

F3: Not used.

F4: HOME - Press this key to command the entire Axis to find home.

F5: Not used.

F6: NEXT - Press this key to go to the next screen for more setup
 information for the Double Weldon Flat tool. (See page 2-56)

GP #55, Vice Setup Cycle, Double Weldon Flat

Setup VICE CYCLE, Double Weldon Flats					
F2 : Number of Grind PASSES = xx Passes					
F3 "Y" GRIND Feed Rate = x.xxxx In/sec					
F4 "Y" CLEAN UP Pass Rate= x.xxxx In/sec					
F5 : Do Clean Up Pass ? = [NO/YES]					
BACK	PASS	GRIND	CLEAN	N/Y	NEXT

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK - Press this key to go back 1 screen to Double Weldon Flat information. (Seepage 2-55)

F2 PASS -- Press this key to access the value for the number of grind passes to be done on each side. The total plunge depth of the Z-axis will be equally divided by the value in the "Grind Passes".

Example: $[(-Z\text{-axis touch off} - Z\text{-axis finish depth}) / \text{Grind Passes}] = Z\text{-axis depth increments.}$

F3 GRIND - Press this key to access the value for the Y-axis Grind feed rate in Inches per second.

The valid values are 0.0001 In/sec to 0.1250 in/sec maximum.

F4 CLEAN - Press this key to access the value for the Y-axis Clean Pass feed rate in Inches per second.

The valid values are 0.0001 In/sec to 0.1250 in/sec maximum.

F5 N/Y --- Press this key to select a clean up pass of Yes or No.

F6 NEXT - Press this key to go to the next Cycle setup screen.

(Seepage 2-57)

GP #56, Vice Setup, Double Weldon Flats

Setup VICE, Double Weldon Flat					
F2 : Adjust PARTS Counter? = xxxxx					
F3 : GRIND Wheel Speed = xxxx FPM					
F4 : CLEAN UP Wheel Speed = xxxx FPM					
F1 : STOP CYCLE & Back F6 : HAND CYCLE					
BACK	PARTS	GRIND	CLEAN	_____	HAND

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK - Press this key to go back to Setup Cycle for the Double Weldon Flat and also do a "Cycle Stop". (Seepage 2-56)

F2 PARTS - Press this key to adjust the inventory Parts Counter to a value of (0) zero or to a corrected good part value. This part counter is designed for the operator to keep track of his/her inventory for each shift or long time run of a job.

F3 GRIND - Press this key to access the value for the Grinding Wheel Head Speed in feet per minute.

F4 CLEAN - Press this key to access the value for the Clean Up Wheel Head Speed in feet per minute.

F5 Key not used.

F6 VICE - Press this key for the Vice Single Cycle mode screen. (Seepage 2-58)

GP #58, Vice - Setup XYZ, Wide Double Weldon Flat

Setup VICE for WIDE DOUBLE Weldon Flats
 Double Weldon Flat with Wide End
 F3 = Setup X-AXIS Position
 F4 = Setup Y-AXIS Position
 F5 = Setup Z-AXIS Position
 MENU6 _____ --X-- --Y-- --Z-- NEXT

F1 F2 F3 F4 F5 F6

F1 MENU6 - Press this key to go back to Weldon / Whistle Stop Routine menu. (Seepage 2-41)

F2: Not used.

F3: --X-- - Press this key for the screen to setup the X-AXIS position to grind three positions of the Weldon Flats. (Seepage 2-60)

F4: --Y-- - Press this key for the screen to setup the Y-AXIS starting and finish sweep positions. (Seepage 2-62)

F5: --Z-- - Press this key for the screen to setup the Z-AXIS touch off position and finish depth. (Seepage 2-63)

F6: NEXT - Go to the next screen to setup the Double Weldon Flat Wide End tool cycle. (Seepage 2-64)

GP #59, Vice Setup X-axis, Wide Double Weldon Flat

Setup VICE X-AXIS Wide Double Weldon					
ABS = xx.xxxx In Has 3 Stored Positions					
Edge: xx.xxxx F3 : Goto Store PAGE					
F5 : Set FEED RATE = x.xxx In/Sec					
Rate Range = 0.001 to 1.000 In/sec					
BACK	EDGE	PAGE	_____	RATE	_____

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK - Press this key to go back to setup the Wide Double Weldon Flat menu. (See page 2-59)

F2 EDGE - Press this key to access the operator's Edge reference position value. This reference value can be used to represent the distance from the Vice side to the back edge of the wheel face. The program's calculations do not use the operator's Edge reference value.

F3 PAGE - Press this key to access the screen to store the desired positions for the flats. (See page 2-61)

F4 Key not used.

F5 RATE - Press this key to access the *X-axis Feed Rate* and then enter the desired value. The rate range is 0.001 to 1.000 In/Sec.

F6 Key not used.

Note: Then use the **JOG IN** or **JOG OUT** push buttons to control the axis.

Additional, the operator may want to move the Z-axis down to close proximity of contact to the top surface of the tool to be more accurate with the X-axis position. To do this, back up to the menu and select the Z-axis and then return this screen.

GP #60, Vice, X-axis Store Positions Wide Double Weldon Flat

Store Positions; X ABS = xx.xxxx In					
F3 : Store X INNER Position = xx.xxxx In					
F4 : Store X END Position 1 = xx.xxxx In					
F5 : Store X END Position 2 = xx.xxxx In					
BACK	_____	INNER	END1	END2	_____

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK - Press this key to go back 1 screen to setup the Wide Double Weldon Flat X Axis. (Seepage 2-60)

F2 Key not used.

F3 INNER - Press this key to access the inner flat value and then enter the desired position.

F4 END1 -- Press this key to access the first end flat value and then enter the desired position.

F5 END2 -- Press this key to access the second end flat value and then enter the desired position. This value is used when the end tool surface area is larger than the wheel width.

F6 Key not used.

GP #61, Vice Setup Y-axis, Wide Double Weldon Flat

Setup VICE Y-AXIS WIDE Double Weldon					
ABS = xx.xxxx In		START Pos= xx.xxxx In			
Tan: xx.xxxx		FINISH Pos= xx.xxxx In			
F5 : Set FEED RATE = x.xxx In/sec					
Rate Range = 0.001 to 1.000 In/sec					
BACK	TAN	START	FINIS	RATE	_____

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK - Press this key to go back to setup the Wide Double Weldon Flat menu. (See page 2-59)

F2 TAN - Press this key to access the operator's Tangent reference position value. This reference value can be used to represent the Wheel and Vice tool vertical centers position. The program's calculations do not use the operator's Tangent reference value.

F3 START - Press this key to copy the Y-axis ABS position to the Y-axis starting position. The starting position is the value that the auto cycle uses.

Important: this position should be on the far side of the wheel.

F4 FINIS - Press this key to copy the Y-axis ABS position to the Y-axis finish position. The finish position is the value that the auto cycle uses.

Important: this position should be on the operator side of the wheel.

F5 RATE - Press this key to access the *Y-axis Feed Rate* and then enter the desired value. The rate range is 0.001 to 1.000 In/Sec.

F6 Key not used.

Note: Then use the **JOG IN** or **JOG OUT** push buttons to control the axis.

GP #62, Vice Setup Z-axis, Wide Double Weldon

Setup VICE Z-AXIS WIDE Double Weldon					
TOUCH OFF (-)Pos= xx.xxxx In					
ABS = xx.xxxx In		DEPTH = xx.xxxx In			
F5 : Set FEED RATE = x.xxx In/sec					
Rate Range = 0.001 to 1.000 In/sec					
BACK	_____	TOUCH	DEPTH	RATE	_____

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK - Press this key to go back to setup the Wide Double Weldon Flat menu. (See page 2-59)

F2 Key not used.

F3: TOUCH - Press this key to access the Z-axis "touch off position" value and enter a value from the numeric keys. Jog axis down slow until the wheel touches the tool outside diameter. Then use this function to enter the correct value to the "touch off position". Use the ABS position to determine the correct value to place in the "touch off position".

F4 DEPTH - Press this key to access the Z-axis "Finish DEPTH Value" and enter a value from the numeric keys. Calculate this "depth value" from the information given by the tool print. This will be the distance from the outside diameter of the tool the flat portion to be formed.

F5 RATE - Press this key to access the *Z-axis Feed Rate* and then enter the desired value. The rate range is 0.001 to 1.000 In/Sec.

F6 Key not used.

Note: Then use the **JOG IN** or **JOG OUT** push buttons to control the axis.

GP #63, Vice Wide Double Weldon Flat Information

VICE - WIDE DOUBLE Weldon Flat Info: Note: The CLEAN UP PASS, if selected, is an additional finish pass to polish the tool. Select YES/NO and Feed Rates F4 = Home Z, X, Y					
MENU	_____	_____	HOME	_____	NEXT

F1 **F2** **F3** **F4** **F5** **F6**

This screen has on board information about the Clean Up Pass.

F1: MENU - Press this key to go back to Double Weldon Flat setup menu.
 (See page 2-59)

F2: Not used.

F3: Not used.

F4: HOME - Press this key to command the entire Axis to find home or
 go home, which ever is needed.

F5: Not used.

F6: NEXT - Press this key to go to the next screen for more setup
 information for the Double Weldon Flat tool. (See page 2-65)

GP #64, Vice Setup Cycle, Wide Double Weldon Flat

Setup VICE CYCLE,	WIDE Double Weldon
F2 : Number of Grind PASSES = xx	Passes
F3 "Y" GRIND Feed Rate =	x.xxxx In/sec
F4 "Y" CLEAN UP Pass Rate=	x.xxxx In/sec
F5 : Do Clean Up Pass ? =	[NO/YES]
BACK	PASS GRIND CLEAN N/Y NEXT

F1 F2 F3 F4 F5 F6

F1 BACK - Press this key to go back 1 screen to the Wide Double Weldon Flat information. (See page 2-64)

F2 PASS -- Press this key to access the value for the number of grind passes to be done on each side. The total plunge depth of the Z-axis will be equally divided by the value in the "Grind Passes".

Example: $[(-Z\text{-axis touch off} - Z\text{-axis finish depth}) / \text{Grind Passes}] = Z\text{-axis depth increments.}$

F3 GRIND - Press this key to access the value for the Y-axis Grind feed rate in Inches per second.

The valid values are 0.0001 In/sec to 0.1250 in/sec maximum.

F4 CLEAN - Press this key to access the value for the Y-axis Clean Pass feed rate in Inches per second.

The valid values are 0.0001 In/sec to 0.1250 in/sec maximum.

F5 N/Y --- Press this key to select a clean up pass of Yes or No.

F6: NEXT - Press this key to go to the next Cycle setup screen. (See page 2-66)

GP #65, Vice Setup Wide Double Weldon Flat

Setup VICE, WIDE Double Weldon					
F2 : Adjust PARTS Counter? = xxxxx					
F3 : GRIND Wheel Speed = xxxx FPM					
F4 : CLEAN UP Wheel Speed = xxxx FPM					
F1 : STOP CYCLE & Back F6 : HAND CYCLE					
BACK	PARTS	GRIND	CLEAN	_____	HAND

F1 **F2** **F3** **F4** **F5** **F6**

F1 BACK - Press this key to go back to Setup Cycle for the Wide Double Weldon Flat and also do a "Cycle Stop". (Seepage 2-65)

F2 PARTS - Press this key to adjust the inventory Parts Counter to a value of (0) zero or to a corrected good part value. This part counter is designed for the operator to keep track of his/her inventory for each shift or long time run of a job.

F3 GRIND - Press this key to access the value for the Grinding Wheel Head Speed in feet per minute.

F4 CLEAN - Press this key to access the value for the Clean Up Wheel Head Speed in feet per minute.

F5 Key not used.

F6 HAND - Press this key for the Vice Single Cycle mode screen. (Seepage 2-67)

GP #68, Timers

Setup TIMERS					
F2 = HOLD Unload Ejector ON = x.x Sec					
F3 = Delay Collet OPEN = x.x Sec					
F4 = Delay Collet CLOSE = x.x Sec					
MENU2	HOLD	OPEN	CLOSE	_____	NEXT
F1	F2	F3	F4	F5	F6

F1 MENU2 - Press this key to return to the Setup Menu. (See page 2-2)

F2 HOLD -- Press this key to adjust the time delay for after the Ejector has moved out. This will allow time for the part to be ejected.

F3 OPEN - Press this key to adjust the time delay for the Collet to open. This will create a time delay to insure that the axes unload and load positions are valid before the collet opens to release the part or except a part.

F4 CLOSE - Press this key to adjust the time delay for the Collet to close. This will insure that the tool is fully in place after the pusher has loaded the part.

F5 Key not used.

F6 NEXT - Press this key for the next timer screen. (See page 2-69)

GP #69, Timers Continued

Setup TIMERS & COUNTERS					
F2 = Delay Unload Ejector ON = x.x Sec					
Start Luber after (10-100) Cycles = xxx					
Luber Run Time (2-8 Sec)? = xx Sec					
Luber Float Switch status = [status]					
BACK	EJECT	_____	CYCLE	SEC	_____

F1 F2 F3 F4 F5 F6

F1 BACK - Press this key to go back to the previous timer screen.
(See page 2-68)

F2 EJECT -- Press this key to adjust the time delay for the Ejector to turn on to eject the part. This will create a time delay to insure that the collet opened fully to unload or load the part.

F3 Key not used.

F4 CYCLE - Press this to enter the number of machine cycles needed before starting the Machine lubrication system.

F5 SEC - Press this to give the Machine Oiler the amount of seconds needed to charge the oil lines. The required amount of seconds can be from 3 to 10 seconds.

F6 Key not used.

GP #70, Manual Test, Operator Routines

MANUAL TEST, OUTPUTS & JOGS					
F2 = PNEUMATICS					
F3 = Manual WHEEL HEAD & Coolant					
F4 = JOG AXIS; X, Y, Z					
F5 = Home Z, X, Y axis					
MENU	AIR	WHEEL	JOG	HOME	_____

F1 **F2** **F3** **F4** **F5** **F6**

- F1 MENU** - Press this key to return to the Main Menu. (Seepage 2-1)
- F2 AIR** --- Press this key for the screen to select manual control of the pneumatics. (Seepage 2-71)
- F3 WHEEL** - Press this key for the screen to select manual control of the wheel head and coolant solenoid. (Seepage 2-73)
- F4 JOG** --- Press this key for the screen to select manual jog of the servo axis. (Seepage 2-74)
- F5 HOME** - Press this key to command the entire Axis to find home or go home, which ever is needed.
- F6** Key not used.

GP #71, Manual Pneumatics

```
MANUAL Phneumatic
F2 : Toggle COLLET = [OPEN/CLOSED]
Collet Air Pressure Switch = [OFF/ON]

MENU7  COLET  _____  _____  _____  NEXT
F1      F2      F3      F4      F5      F6
```

F1 MENU7 - Press this key to return to the Manual menu screen.
(Seepage 2-70)

F2 COLET - Press this key to toggle the *Collet* either Open or Closed.
The *Collet* needs to be OPEN to load the tool. The status will
show the state of the pneumatic valve of either "Open or Closed".

F3 Key not used.

F4 Not used.

F5 Not used.

F6 NEXT - Press this key for the next pneumatic screen. (Seepage 2-72)

GP #72, Manual Pneumatics

MANUAL Pneumatic					
F3 : Toggle Ejector LOW = Back---					
F4 : Toggle EJECTOR HIGH= Back---Low/hi					
F5 : Toggle PUSHER = [Out/In]					
Pusher Mag In = [Not_In / IN]					
BACK	_____	E-LOW	EJ-HI	PUSHR	_____
F1	F2	F3	F4	F5	F6

F1 BACK - Press this key to go back one Manual pneumatic screen.

(See page 2-71)

F2 Not used.

F3 E-LOW - Press this key to toggle the *Ejector* either back or forward at low pressure. The status will show the state of the pneumatic valve to be either "Back Low or Forward Low".

F4 EJ-HI - Press this key to toggle the *Ejector* either back or forward at high pressure. The status will show the state of the pneumatic valve to be either "Back High or Forward High".

F5 PUSHR - Press this key to toggle the *Pusher* either back or forward. First, the *Pusher* needs to be in its Back position to align the X and Y-axis. Then check the alignment by toggling the *Pusher* to its IN position. The status will show the state of the pneumatic valve to be either "Back or Forward".

F6 Not used.

GP #73, Manual Wheel Head & Coolant

MANUAL Wheel Head Motor & Coolant sol.					
STOP/Start Wheel Head =[OFF/ON] xxxx FPM					
GRIND Wheel Speed = xxxx FPM					
FINISH Wheel Speed = xxxx FPM					
F6 = Toggle Coolant Solenoid =[OFF/MAN]					
MENU7	STOP	START	GRIND	FINI	COOL
F1	F2	F3	F4	F5	F6

F1 MENU7 - Press this key to return to the Manual menu screen.
(See page 2-70)

F2 STOP - Press this key to Stop Wheel Head.

F3 START - Press this key to Start Wheel Head: [Status Wheel Head, OFF or ON]. The "Manual Wheel Head Speed" will be the "Grind Wheel Speed" in fpm.

F4 GRIND - Select to enter Hog Wheel Speed "Feet Per Minute"

F5 FINI -- Select to enter Finish Wheel Speed "Feet Per Minute"

F6 COOL - Press this key to manually toggle the coolant solenoid from "Off" to "On" state and back.

GP #74, Manual Jog Select Axis

	MANUAL JOG Axis			No Faults	
X	Axis	[Axis Fault]		[FAULTS!!]	
Y	Axis				
Z	Axis	[Axis Fault]			
MENU	FAULT	X	Y	Z	_____
F1	F2	F3	F4	F5	F6

F1 MENU7 - Press this key to return to the Manual menu screen.
 (See page 2-70)

F2 FAULT - Select if "FAULTS!" or "Axis Fault" prompt is flashing.

F3 X - Press this key to select Manual Jog X-axis. (See page 2-75)

F4 Y - Press this key to select Manual Jog Y-axis. (See page 2-76)

F5 Z - Press this key to select Manual Jog Z-axis. (See page 2-77)

F6 Key not used. Reserved for other axis.

GP #75, Manual Jog X-axis

MANUAL Jog X AXIS ABS = RR.RRRR In					
F2 = Find HOME		F6 = Set Position Zero			
F3 : Feed Rate = x.xxx In/sec					
[NOT Home]		[Jog +OT Reached]			
		[Jog -OT Reached]		Axis status	
BACK	HOME	RATE	_____	FAULT	ZERO

F1 F2 F3 F4 F5 F6

F1 BACK - Press this key to return to the Manual Jog Axis menu.
(See page 2-74)

F2 HOME - Press this key for the axis to find home the limit.

F3 RATE - Press this key to access the X-axis Feed Rate and then enter the desired value. The rate range is 0.001 to 1.000 In/Sec.

F4 This key not used.

F5 FAULT - Press this key if the "Axis status" displays a fault.

F6 ZERO - Press this key if axis cannot jog out or find home. This will set the axis position to 0.0000" and is not in relation to the home limit.

GP #76, Manual Jog Y-axis

MANUAL Jog Y AXIS ABS = RR.RRRR In					
F2 = Find HOME		F6 = Set Position Zero			
F3 : Feed Rate = x.xxx In/sec					
[NOT Home]		[Jog +OT Reached]		Axis status	
		[Jog -OT Reached]			
BACK	HOME	RATE	_____	FAULT	ZERO
F1	F2	F3	F4	F5	F6

F1 BACK - Press this key to return to the Manual Jog Axis menu.
(See page 2-74)

F2 HOME - Press this key for the axis to find home the limit.

F3 RATE - Press this key to access the *X-axis Feed Rate* and then enter the desired value. The rate range is 0.001 to 1.000 In/Sec.

F4 This key not used.

F5 FAULT - Press this key if the "Axis status" displays a fault.

F6 ZERO - Press this key if axis cannot jog out or find home. This will set the axis position to 0.0000" and is not in relation to the home limit.

GP #77, Manual Jog – Z-axis

MANUAL Jog Z AXIS ABS = RR.RRRR In					
F2 = Find HOME		F6 = Set Position Zero			
F3 : Feed Rate = x.xxx In/sec					
[NOT Home]		[Jog +OT Reached]		Axis status	
		[Jog -OT Reached]			
BACK	HOME	RATE	_____	FAULT	ZERO
F1	F2	F3	F4	F5	F6

F1 BACK - Press this key to return to the Manual Jog Axis menu.
(See page 2-74)

F2 HOME - Press this key for the axis to find home the limit.

F3 RATE - Press this key to access the *X-axis Feed Rate* and then enter the desired value. The rate range is 0.001 to 1.000 In/Sec.

F4 This key not used.

F5 FAULT - Press this key if the "Axis status" displays a fault.

F6 ZERO - Press this key if axis cannot jog out or find home. This will set the axis position to 0.0000" and is not in relation to the home limit.

GP #79, FAULT Section - MAIN MENU for Fault screens

AXIS	Fault = None	[Axis Faults]				
AC MOTORS	Fault = None	[AC Motor Faults]				
AIR	Fault = None	[Check Air Limits]				
E-STOP	Error = None	[E-Stop DOWN]				
POWER UP	Error = None	[POWER UP Error]				
MENU	AXIS	MOTOR	AIR	POWER	ALARM	
F1	F2	F3	F4	F5	F6	

F1 MENU - Press this key to return to the Main Menu. (Seepage 2-1)

Fault status: [None] = No faults, take no action.

[Fault Type Flashing] = Fault active, select proper Key.

Fault status is in order of priority.

F2 AXIS --- Select this Key when "Axis Faults" if flashing to view the type of fault. (Seepage 2-79)

F3 MOTOR -- Select this Key when "AC Motor Faults" is flashing.
(Seepage 2-83)

F4 AIR ---- Select this Key when "Check Air Limits" is flashing.
(Seepage 2-84)

F5 POWER -- Select this Key when "POWER UP ERROR" is flashing.

F6 ALARM -- Select this Key if Alarm Tag is flashing in upper screen area.

TURN or PULL the E-STOP operator when the "E-Stop DOWN" is flashing.

GP #80, Faults Any Axis

AXIS FAULTS: Select if fault X Axis Fault = X Axis Ok/Fault Y Axis Fault = Y Axis Ok/Fault Z Axis Fault = Z Axis Ok/Fault					
MENU8	_____	X	Y	Z	_____
F1	F2	F3	F4	F5	F6

F1 MENU8 - Press this key to return to the Main Fault Screen menu.
 (Seepage 2-78)

F2 Not Used.

Status: None - No Fault, check Axis only if "Faults!" flashing will not clear. Then check each Axis for Fault code number present.

[ACTIVE] - Select proper Key

F3 X - Select this Key if "Fault" is flashing. (Seepage 2-80)

F4 Y - Select this Key if "Fault" is flashing. (Seepage 2-81)

F5 Z - Select this Key if "Fault" is flashing. (Seepage 2-82)

F6 Key not used.

GP #81, Fault X-axis

X AXIS FAULT: Error Code = RRRRR [Axis Not Ready] [Servo Not Enabled] Drive Not Enabled> F3 Position Not Valid ABS = RR.RRRR In					
BACK	CLEAR	ENABL	SET-0	_____	FHOME
F1	F2	F3	F4	F5	F6

F1 BACK - Press this key to return to the Axis Fault menu screen.
 (See page 2-79)

F2 CLEAR - If number is not 0000, this clears any Error for this Axis.
 Note: The "Error Code Number" on the display is "Decimal Base".
 Convert the Number to a "HEX value" and then see Error Codes
 Section.

F3 ENABL - Select this Key if "Drive Not Enabled> F3" is flashing. The
 "Drive Not Enabled> F3" changes to "OK" when Key is accepted.

F4 SET-0 - Select this Key if "LOST POSITION> F4" is flashing. This
 will set this Axis position to Zero (0.0000). This is used
 instead of "Find Home", so the axis can be jogged plus and minus
 to verify it's proper direction. "LOST POSITION> F4" changes to
 "OK" when Key is accepted.

F5 Not Used.

F6 FHOME - Press this key to command this Axis only to find it's home
 limit and then set it's position to Zero.

GP #82, Fault Y-axis

Y AXIS FAULT: Error Code = RRRRR [Axis Not Ready] [Servo Not Enabled] Drive Not Enabled> F3 Position Not Valid ABS = RR.RRRR In					
BACK	CLEAR	ENABL	SET-0	_____	FHOME
F1	F2	F3	F4	F5	F6

F1 BACK - Press this key to return to the Axis Fault menu screen.
 (See page 2-79)

F2 CLEAR - If number is not 0000, this clears any Error for this Axis.
 Note: The "Error Code Number" on the display is "Decimal Base".
 Convert the Number to a "HEX value" and then see Error Codes
 Section.

F3 ENABL - Select this Key if "Drive Not Enabled> F3" is flashing. The
 "Drive Not Enabled> F3" changes to "OK" when Key is accepted.

F4 SET-0 - Select this Key if "LOST POSITION> F4" is flashing. This
 will set this Axis position to Zero (0.0000). This is used
 instead of "Find Home", so the axis can be jogged plus and minus
 to verify it's proper direction. "LOST POSITION> F4" changes to
 "OK" when Key is accepted.

F5 Not Used.

F6 FHOME - Press this key to command this Axis only to find it's home
 limit and then set it's position to Zero.

GP #83, Fault Z-axis

Z AXIS FAULT: Error Code = RRRRR					
[Axis Not Ready]					
[Servo Not Enabled]			[No Z _+OT]		
Drive Not Enabled> F3			[No Z _-OT]		
Position Not Valid			ABS = RR.RRRR In		
BACK	CLEAR	ENABL	SET-0	_____	FHOME
F1	F2	F3	F4	F5	F6

F1 BACK - Press this key to return to the Axis Fault menu screen.

(See page 2-79)

F2 CLEAR - If number is not 0000, this clears any Error for this Axis.

Note: The "Error Code Number" on the display is "Decimal Base". Convert the Number to a "HEX value" and then see Error Codes Section.

F3 ENABL - Select this Key if "Drive Not Enabled> F3" is flashing. The "Drive Not Enabled> F3" changes to "OK" when Key is accepted.

F4 SET-0 - Select this Key if "LOST POSITION> F4" is flashing. This will set this Axis position to Zero (0.0000). This is used instead of "Find Home", so the axis can be jogged plus and minus to verify it's proper direction. "LOST POSITION> F4" changes to "OK" when Key is accepted.

F5 Not Used.

F6 FHOME - Press this key to command this Axis only to find it's home limit and then set it's position to Zero.

GP #85, Faults AC Motors

AC MOTORS STATUS					
CONTACTOR For SERVO'S: [OK/NOT ENGAGED]					
CONTACTOR For AC DRIVE: [OK/NOT ENGAGED]					
Variable AC Drive OUTPUT: [OK/FAULT]					
Spare Line					
BACK					
F1	F2	F3	F4	F5	F6

F1: BACK -- Back to Main Fault screen. (See page 2-78)

This screen displays the status for the AC Motor contactors and the Variable Frequency Drive.

CONTACTOR For SERVO Drives: - This will display "OK" or "NOT ENGAGED". If Not Engaged is displayed, and then check the AC Contactor.

CONTACTOR For AC Motor Variable Speed Drive: - This will display "OK" or "NOT ENGAGED". If Not Engaged is displayed, and then check the AC Contactor.

AC Motor Variable Speed Drive OUTPUT: - This will display "OK" or "NOT ACTIVE". If Not Active, then check the Woods Drive.

Spare Line:

GP #86, Faults Air System

```
AIR SYSTEM STATUS -- Check If Not "OK"

Collet Closed-Air Switch: OK  Not Closed
Tool Pusher -- In Limit: OK  NOT Out
Spare Line

BACK  _____  _____  _____  _____  _____
      F1           F2           F3           F4           F5           F6
```

F1: BACK -- Back to Main Fault screen. (See page 2-78)


Collet Closed-Air Switch: - If "NOT CLOSED" then check Air Switch.

Tool Pusher --- In Limit: - If "NOT OUT" then check Tool Rest Position

Spare Line:

Chapter 3 : Engineering Section

GP #87, Engineering Screen Access



F1: MENU --- Return to the Main Menu Screen. (See page 2-1)

F4: MASKED -- To Engineering Main Screen. (See page 3-2)

GP #88, Engineering Main Screen

"ENGINEERING SETUP FUNCTIONS"					
F2 = Reset Registers to DEFAULT Values!					
F4 = Reset Alarm Tags from Over Values					
F6 = More Engineering Pages					
MENU	RESET	_____	ALARM	OFF-L	MORE
F1	F2	F3	F4	F5	F6

This screen and the following screens are to be accessed by a SUPERVISOR or ENGINEERING ONLY!

F1: MENU --- Return to the Main Menu. (See page 2-1)

F2: RESET -- Reset All Register Values to PLC CONSTANT (Default) Values.

F5: Not used.

F4: ALARM -- Reset Any Alarm Tag that Exceeds an Over or Under Value.

F5: OFF-L -- Changes Operator Interface from Run Mode to the Programming Mode.

F6: MORE --- Go to Change Register Values to customize for each Machine. (See page 3-3)

GP #89, Engineering Screen #2

```
OVER LOAD RELAY DWELL1 TIMER
Default = 1.0 Sec ; Preset = x.x Sec
SPARE

ENGINEERING Setup Functions page2
BACK      ENG'R      _____  O-L-R      _____  MORE
F1         F2         F3         F4         F5         F6
```

- F1: BACK** --- Back 1 Screen. (See page 3-2)
- F2: ENG'R** -- Back to Engineering Screen. (See page 3-2)
- F3:** Not Used.
- F4: O-L-R** -- Select to Write New Value of 1.0 sec to 2.0 sec.
- F5:** Not Used.
- F6: MORE** --- Go to Change Register Values to customize for each Machine. (See page 3-4)

GP #90, Engineering Screen #3

FLASHER HOLD ON TIMER Default = 1.5 Sec ; Preset = x.x Sec FLASHER HOLD OFF TIMER Default = 1.5 Sec ; Preset = x.x Sec ENGINEERING Setup Functions page3					
BACK	ENG'R	_____	F_ON	F_OFF	MORE
F1	F2	F3	F4	F5	F6

F1: BACK --- Back 1 Screen. (Seepage 3-3)

F2: ENG'R -- Back to Engineering Screen. (Seepage 3-2)

F3: Not Used.

F4: F_ON --- Select to Write New Value.

F5: F_OFF -- Select to Write New Value.

F6: MORE --- Go to Change Register Values to customize for each Machine. (See page 3-5)

GP #91, Engineering Screen #4

```

X Axis +Overtravel = xxx.xxxx
Y Axis +Overtravel = xxx.xxxx
Z Axis (-)Overtravel = xxx.xxxx

ENGINEERING Setup Functions page4

BACK      ENG'R      _____  _____  _____  MORE
F1         F2         F3         F4         F5         F6
    
```

This screen is used to view the PLC logic over travel values. These are fixed values by the programmer.

- F1: BACK** --- Back 1 Screen. (See page 3-4)
- F2: ENG'R** -- Back to Engineering Screen. (See page 3-2)
- F3:** Key not used.
- F4:** Key not used.
- F5:** Key not used.
- F6: MORE** --- Go to Change Register Values to customize for each Machine. (See page 3-6)

GP #92, Engineering Screen #5

```
AXIS AUTO ENABLE FUNCTION>> [NOT ACTIVE]
F3 = SET ; Axis Auto Enable ACTIVE
F4 = RESET; Axis Auto Enable Not Active
ENGINEERING Setup Functions page5
BACK      ENG'R   SET      RESET      _____
F1         F2         F3         F4         F5         F6
```

F1: BACK --- Back 1 Screen. (See page 3-5)

F2: ENG'R -- Back to Engineering Screen. (See page 3-2)

F3: SET -- Select to Set the "Servo Auto Enable" Function to Active.

F4: RESET -- Select to Set the "Servo Auto Enable" Function to NOT Active.

F5: Not used.

F6: Not used.

Chapter 5 : Program Sequences

FROM PAGE 1-1

Auto Load & Unload Sequencer for Work Head

```
%M0081; AUTO-01; Auto Load Sequencer, check conditions
%M0082; AUTO-02; Call Unload Subroutine
%M0083; AUTO-03; Call Load Subroutine
%M0084; AUTO-04; Do Grind Sequencer
%M0085; AUTO-05; Reset if Auto Cycle/ Next if Single Cycle
%M0086; AUTO-06; Home Z-axis
%M0087; AUTO-07; Home X & y-axis
%M0088; AUTO-08; Send U-axis to position Zero
%M0089; AUTO-09; Open Collet
%M0090; AUTO-10; Reset Polygon Sequencer
```

Unload Sequencer

```
%M0305; UNLOAD1; Unload Sequencer, check conditions to start
%M0306; UNLOAD2; Move X & Y axis to Unload position
%M0307; UNLOAD3; Move Shuttle in & dwell
%M0308; UNLOAD4; Dwell to next stage
%M0309; UNLOAD5; Ejector High pressure & hold (dwell)
%M0310; UNLOAD6; Return Ejector
%M0311; UNLOAD7; to next stage
%M0312; UNLOAD8; Unload Sequencer done
```

Load Sequencer

```
%M0321; LOAD-S1; Load Rod Sequencer, check condition to start
%M0322; LOAD-S2; Move X & Y axis to Load position
%M0323; LOAD-S3; Dwell and to next stage
%M0324; LOAD-S4; Ejector Low pressure and Open Collet
%M0325; LOAD-S5; Rod Pusher forward & dwell
%M0326; LOAD-S6; Close Collet & dwell
%M0327; LOAD-S7; Return Ejector & X-axis to position Zero
%M0328; LOAD-S8; Return Rod Pusher & pop new tool from Hopper
%M0329; LOAD-S9; Load Sequencer done
%M0330; LOADS10; spare stage
```

Program Sequences continued

Hand-Load Sequencer for Vice and Work Head

```
%M0105; HAND-S1; Hand Load Sequencer, check conditions to start
        Check if Vice or Collet, if Hand Load Work Head, is closed.
%M0106; HAND-S2; Do Grind Sequencer
%M0107; HAND-S3; Home Z-axis
%M0108; HAND-S4; Home X & Y axis
%M0109; HAND-S5; Reset Hand Load sequencer
```

Grind Sequencer

```
%M0113; GRIND01; Grind Sequencer, check conditions to start
%M0114; GRIND02; Increment Tracking counters
%M0115; GRIND03; Calculate moves
%M0116; GRIND04; Move X & Y axis to start positions
%M0117; GRIND05; Move Z-axis to calculated Depth
%M0118; GRIND06; Move Y axis to finish position
%M0119; GRIND07; Move Z axis up clearance distance & check if done
%M0120; GRIND08; If passes are done, setup U-axis or X-axis moves
%M0121; GRIND09; Repeat sequence if not done
%M0122; GRIND10; spare stage
```

Chapter 6 : Appendix B: Servo Axis Error Codes Section

FROM PAGE 1-1

Response Methods

1. **Status Only Errors:** Set the *Module Error Present* %I bit and *Module Status Code* or *Axis Error Code* %AI word, but do not affect motion.

Note

Unless otherwise noted, any command which causes a Status Only Error is ignored.

2. **Stop Normal Errors:** Perform an internal abort of any current motion using current *Jog*

Acceleration and *Jog Acceleration Mode* (LINEAR or S-CURVE). The *Drive Enabled* and *Axis Enabled* %I bits are turned OFF after the configured **Drive Disable Delay**.

3. **Stop Fast Errors:** Instantly abort all motion by setting the servo velocity command to zero.

The *Drive Enabled* and *Axis Enabled* %I bits are turned OFF after the configured **Drive Disable Delay**.

GFK-1464 Appendix B Error Reporting B-3

Table B-1. DSM302 Error Codes

Error Number

(Hexadecimal)

Response Description Error Type

00 None No Error All

Configuration Errors

02 Status Only -- Scaled data too big, maximum value in range used -- Axis

03 Status Only -- Home Position > Positive EOT, Positive EOT used -- Axis

04 Status Only -- Home Position < Negative EOT, Negative EOT used -- Axis

Configuration Parameter Errors

10 Status Only -- Position Loop Time Constant too large, Immediate command ignored -- Axis

11 Status Only -- Position Loop Time Constant too small, Immediate command ignored -- Axis

12 Status Only -- Position Loop Time Constant computation overflow, reduced to non-overflow value -- Axis

1E Status Only -- Immediate command Jog Velocity out of range, command ignored -- Axis

1F Status Only -- Immediate command Jog Acceleration out of range, command ignored -- Axis

Program Errors

20 Status Only -- Program Acceleration over range, defaults to 16.7 million cts/sec/sec -- Axis

21 Status Only -- Program Acceleration too small, defaulted to 32 cts/sec/sec -- Axis

22 Status Only -- Scaled Velocity greater than 1 million cts/sec, 1 million cts/sec is used -- Axis

23 Status Only -- Program Velocity is zero, defaulted to 1 count/sec used -- Axis

24 Stop Normal -- Program Position too large -- Axis

25 Stop Normal -- Unconditional Jump Destination not found -- Axis

26 Stop Normal -- Jump Mask error -- Axis

27 Stop Normal -- Wait Mask error -- Axis

28 Stop Normal -- Parameter Position too large -- Axis

29 Status Only -- Dwell time greater than 60 seconds, 5 seconds used -- Axis

Position Increment Errors

2C Status Only -- Position Increment Over range error, increment ignored -- Axis

Find Home Errors

30 Status Only -- Find Home while Drive Not Enabled error -- Axis

31 Status Only -- Find Home while Program Selected error -- Axis

32 Status Only -- Find Home while Force Digital Servo Velocity error -- Axis

OPERATOR'S MANUAL

33 Status Only -- Find Home while Jog error -- Axis

34 Status Only -- Find Home while Move at Velocity error -- Axis

36 Status Only -- Find Home while Abort bit set error -- Axis

Move at Velocity Errors

39 Status Only -- Move at Velocity while Drive Not Enabled error -- Axis

3A Status Only -- Move at Velocity while Program Selected error -- Axis

3B Status Only -- Move at Velocity while Home Cycle active error -- Axis

3C Status Only -- Move at Velocity while Jog error -- Axis

3D Status Only -- Move at Velocity while Abort All Moves bit is set error -- Axis

3E Status Only -- Move at Velocity Data greater than 8,388,607 user units/sec -- Axis

3F Status Only -- Move at Velocity Data greater than 1-million cts/sec error -- Axis

B-4 Motion Mate™ DSM302 for Series 90™-30 PLCs User's Manual - October 1997 GFK-1464

Table B-1. - Continued - DSM302 Error Codes

Error Number
(Hexadecimal)

Response Description Error Type

Jog Errors

- 40 Status Only -- Jog while Find Home error -- Axis
- 41 Status Only -- Jog while Move at Velocity error -- Axis
- 42 Status Only -- Jog while Force Digital Servo Velocity error -- Axis
- 43 Status Only -- Jog while Program Selected and not Feed holding error -- Axis

Force Digital Servo Velocity Errors

- 47 Status Only -- Force Digital Servo Velocity while Jog error -- Axis
- 48 Status Only -- Force Digital Servo Velocity while Move at Velocity error -- Axis
- 49 Status Only -- Force Digital Servo Velocity while Program Selected error -- Axis
- 4A Status Only -- Force Digital Servo Velocity while Follower Enabled error -- Axis

Set Position Errors

- 50 Status Only -- Set Position while Program Selected error -- Axis
- 51 Status Only -- Set Position Data over range error -- Axis
- 52 Status Only -- Servo Axis 1,2: Set Position while not In Zone error
Aux Axis 3: Set Position while ENC3 Velocity > 128 error-- Axis
- 53 Status Only -- Attempt to initialize position before digital encoder passes reference point. -- Axis
- 54 Status Only -- Digital encoder position invalid, must use Find Home or Set Position. -- Axis

End of Travel and Count Limit Errors

- 56 Status Only -- Commanded Position > Positive End of Travel or High Count Limit -- Axis
- 57 Status Only -- Commanded Position < Negative End of Travel or Low Count Limit -- Axis
- 58 Status Only -- (Absolute Position + Position offset) > Positive End of Travel or High Count Limit -- Axis
- 59 Status Only -- (Absolute Position + Position offset) < Negative End of travel or Low Count Limit -- Axis

Drive Disable Errors

- 5B Stop Normal -- Drive Disabled while Moving -- Axis
- 5C Stop Normal -- Drive Disabled while Program Active -- Axis

Software Errors

- 5F Status Only -- Software Error (Call GE Fanuc Field Service) -- Axis

Program and Subroutine Errors

- 60 Status Only -- Absolute Encoder Rotary Position Computation error -
- Axis
- 61 Stop Normal -- Subroutine not in list -- Axis

- 62 Stop Normal -- Call Error (subroutine already active) -- Axis
- 63 Stop Normal -- Subroutine End command found in Program -- Axis
- 64 Stop Normal -- Program End command found in Subroutine -- Axis
- 65 Stop Normal -- Sync subroutine encountered by non-sync program -- Axis

Program Execution Errors

- 71 Status Only -- Too many programs requested in same PLC sweep -- Module
- 72 Status Only -- Request Program 0-10 with multi-axis program active -- Module
- 73 Status Only -- Request two programs on same sweep with program active -- Module
- 74 Status Only -- Request two programs for same axis, lower number program executed -- Module
- 75 Status Only -- Empty or Invalid Program requested -- Module
- 76 Status Only -- AQ Move Command Position Out of Range -- Axis

GFK-1464 Appendix B Error Reporting B-5

Table B-1. - Continued - DSM302 Error Codes

Error Number
(Hexadecimal)

Response Description Error Type

Program Execution Conditions Errors

- 80** Status Only -- Execute Program while Home Cycle active -- Axis
- 81** Status Only -- Execute Program while Jog -- Axis
- 82** Status Only -- Execute Program while Move at Velocity -- Axis
- 83** Status Only -- Execute Program while Force Digital Servo Velocity -
- Axis
- 84** Status Only -- Execute Program while Program Selected -- Axis
- 85** Status Only -- Execute Program while Abort All Moves bit set --
Axis
- 86** Status Only -- Execute Program while Position Valid not set -- Axis
- 87** Status Only -- Execute Program while Drive Enabled not set -- Axis
- 88** Status Only -- Execute Program with active Error Stop (Axis Enabled
off) -- Axis

Program Synchronous Block Errors

- 8C** Status Only -- Sync Block Error during CMOVE -- Axis
- 8D** Status Only -- Sync Block Error during Jump -- Axis

EEPROM Errors

- 90** Status Only -- Flash EEPROM memory programming failure -- Module

Hardware Limit Switch Errors

- A0** Stop Fast -- Limit Switch (+) error -- Axis
- A1** Stop Fast -- Limit Switch (-) error -- Axis

Hardware Errors

- A8** Stop Fast -- Out of Sync error -- Axis
- A9** Stop Fast -- Encoder Loss of Quadrature or Linear Feedback Loss of
Signal error -- Axis

Digital Servo Alarms

- B0** Stop Normal -- Main DC power supply over voltage -- Axis
- B1** Stop Normal -- Control power under voltage -- Axis
- B2** Stop Normal -- Dynamic brake failure Axis
- B3** Stop Normal -- Main DC power supply under voltage -- Axis
- B4** Stop Normal -- CNV Overload -- Axis
- B5** Stop Normal -- Cooling fan failure -- Axis
- B6** Stop Normal -- Over current -- Axis
- B7** Stop Normal -- Regenerative discharge energy error; resistor
thermal switch open -- Axis
- B9** Stop Normal -- Control power under voltage -- Axis
- BA** Stop Normal -- Error detected by IPM circuit -- Axis
- BB** Stop Normal -- Main DC power supply under voltage -- Axis
- BD** Stop Normal -- Cooling fan failure -- Axis
- BE** Stop Normal -- Over current -- Axis

B-6 Motion Mate™ DSM302 for Series 90™-30 PLCs User's Manual - October 1997 GFK-1464

Table B-1. - Continued - DSM302 Error Codes (Continued)

Error Number
(Hexadecimal)

Response Description Error Type

Encoder Alarms

- C0** Stop Fast Servo not ready when MCON command is on - may be caused by E-STOP input to amplifier. Axis
- C1** Status Only -- Serial Encoder Battery Low -- Axis
- C2** Stop Normal -- Serial Encoder Battery Failed -- Axis
- C3** Stop Normal -- Servo Motor Over Temperature -- Axis
- C4** Stop Fast -- Servo Motor Over Current -- Axis
- C5** Stop Fast -- Loss of Encoder -- Axis
- C6** Stop Fast -- Error in encoder pulse detection -- Axis
- C7** Stop Fast -- Encoder counter error -- Axis
- C8** Stop Fast -- -- Encoder LED is disconnected -- Axis
- C9** Stop Fast -- Encoder CRC checksum failure -- Axis
- CA** Stop Fast -- Unsupported encoder, linear or Type A -- Axis
- CB** Stop Fast -- Unsupported encoder, Type C -- Axis

DSP Alarms

- D1** Stop Fast -- Over current Detected -- Axis
- D2** Stop Fast -- Loss of Analog Feedback -- Axis
- D3** Stop Fast -- Over Acceleration Detected -- Axis
- D4** Stop Fast -- Over Velocity Detected -- Axis
- D5** Status Only -- KpVelFix Too Large -- Axis
- D6** Status Only -- IntGainFix Too Large -- Axis
- D7** Status Only -- Alpha Calculation Overflow -- Axis
- D8** Status Only -- IntGain Calculation Overflow -- Axis
- D9** Status Only -- Kp Calculation Overflow -- Axis
- DA** Stop Fast -- FPGA Error Detected -- Axis

Special Purpose Errors

- E0** Status Only Custom Loop Type Mismatch Axis
- E2** Stop Fast DSP Interrupt failure Module

Follower Errors

- F1** Status Only -- Follower Position Error Limit Encountered -- Axis
- F2** Status Only -- Follower Velocity Limit Condition Encountered -- Axis
- F3** Status Only -- Follower Ratio B value = 0 -- Axis
- F4** Status Only -- Follower Ratio B value < 0 -- Axis
- F5** Status Only -- Follower Ratio A/B or B/A > 32 -- Axis

Winder Errors

- F6** Status Only -- A/B Change Not Allowed in Winder Mode With Follower Enabled -- Axis
- F7** Status Only -- Set Winder Position Immediate Command Out of Zone -- Axis

OPERATOR'S MANUAL

F8 Status Only -- Zone Length Out of Range or Zone Length Change Exceeded 25% -- Axis

F9 Status Only -- Zone Length Change Not Accepted; Previous Change Still in Effect -- Axis

Internal Errors

FD Stop Fast -- System software error -- Axis

FE Stop Fast -- Unrecognized encoder, not supported -- Axis

GFK-1464 Appendix B Error Reporting B-7

LED Indicators

There are seven LEDs on the DSM302 module, which provide status indications. These LEDs are described below.

STAT Normally ON. FLASHES to provide an indication of operational errors. Flashes *slow* (four times/second) for Status-Only errors. Flashes *fast* (eight times/second) for errors which cause the servo to stop.

ON: When the LED is steady ON, the DSM302 is functioning properly. Normally,

this LED should always be ON.

OFF: When the LED is OFF, the DSM302 is not functioning. This is the result of a hardware or software malfunction which will not allow the module to power up.

Flashing: When the LED is FLASHING, an error condition is being signaled.

Constant, CFG LED ON:

The LED flashes slow (four times / second for Status Only errors and fast (eight times / second for errors which cause the servo to stop. The operational error

code will be placed in one of the first four %AI status words and the *Module*

Error Present %I status bit will be ON.

Constant, CFG LED Flashing:

If the STAT and CFG LEDs both flash **together** at a constant rate, the DSM302

module is in boot mode waiting for a new firmware download. If the STAT and

CFG LEDs both flash **alternately** at a constant rate, the DSM302 firmware has

detected a software watchdog timeout due to a hardware or software malfunction.

Irregular, CFG LED OFF:

If this occurs immediately at power-up then a hardware or software malfunction

has been detected. The module will blink the STAT LED to display two error

numbers separated by a brief delay. The numbers are determined by counting

the blinks in both sequences. Record the numbers and contact GE Fanuc for

information on correcting the problem.

OK The OK LED indicates the current status of the DSM302 module.

ON: When the LED is steady ON, the DSM302 is functioning properly. Normally,

this LED should always be ON.

OFF: When the LED is OFF, the DSM302 is not functioning. This is the result of a hardware or software malfunction which will not allow the module to power up.

CFG This LED is ON when a valid module configuration has been received from the PLC. Flashes *slow* (four times/second) during the Motion Program Store function. Flashes *fast* (eight times/second) during the Write User RAM to EEPROM operation.

EN1 When this LED is ON, the servo drive for Servo Axis 1 is enabled.

EN2 When this LED is ON, the servo drive for Servo Axis 2 is enabled.

EN3 When this LED is ON, the *Force Analog Output* command for Aux Axis 3 is active.

EN4 When this LED is ON, the *Force Analog Output* command for Aux Axis 4 is active.

Appendix B: Servo Axis Error Codes Section

Response Methods

1. **Status Only Errors:** Set the *Module Error Present* %I bit and *Module Status Code* or *Axis Error Code* %AI word, but do not affect motion.

Note

Unless otherwise noted, any command which causes a Status Only Error is ignored.

2. **Stop Normal Errors:** Perform an internal abort of any current motion using current **Jog Acceleration** and **Jog Acceleration Mode** (LINEAR or S-CURVE). The *Drive Enabled* and *Axis Enabled* %I bits are turned OFF after the configured **Drive Disable Delay**.

3. **Stop Fast Errors:** Instantly abort all motion by setting the servo velocity command to zero. The *Drive Enabled* and *Axis Enabled* %I bits are turned OFF after the configured **Drive Disable Delay**.

Table B-1. DSM302 Error Codes

Error Number

(Hexadecimal)

Response Description Error Type

00 None No Error All

Configuration Errors

02 Status Only -- Scaled data too big, maximum value in range used -- Axis

03 Status Only -- Home Position > Positive EOT, Positive EOT used -- Axis

04 Status Only -- Home Position < Negative EOT, Negative EOT used -- Axis

Configuration Parameter Errors

10 Status Only -- Position Loop Time Constant too large, Immediate command ignored -- Axis

11 Status Only -- Position Loop Time Constant too small, Immediate command ignored -- Axis

12 Status Only -- Position Loop Time Constant computation overflow, reduced to non-overflow value -- Axis

1E Status Only -- Immediate command Jog Velocity out of range, command ignored -- Axis

1F Status Only -- Immediate command Jog Acceleration out of range, command ignored -- Axis

Program Errors

20 Status Only -- Program Acceleration overrange, defaults to 16.7 million cts/sec/sec -- Axis

21 Status Only -- Program Acceleration too small, defaulted to 32 cts/sec/sec -- Axis

22 Status Only -- Scaled Velocity greater than 1 million cts/sec, 1 million cts/sec is used -- Axis

23 Status Only -- Program Velocity is zero, defaulted to 1 count/sec used -- Axis

24 Stop Normal -- Program Position too large -- Axis

25 Stop Normal -- Unconditional Jump Destination not found -- Axis

26 Stop Normal -- Jump Mask error -- Axis

27 Stop Normal -- Wait Mask error -- Axis

28 Stop Normal -- Parameter Position too large -- Axis

29 Status Only -- Dwell time greater than 60 seconds, 5 seconds used -- Axis

Position Increment Errors

2C Status Only -- Position Increment Overrange error, increment ignored -- Axis

Find Home Errors

30 Status Only -- Find Home while Drive Not Enabled error -- Axis

31 Status Only -- Find Home while Program Selected error -- Axis

32 Status Only -- Find Home while Force Digital Servo Velocity error -- Axis

33 Status Only -- Find Home while Jog error -- Axis

34 Status Only -- Find Home while Move at Velocity error -- Axis

36 Status Only -- Find Home while Abort bit set error -- Axis

Move at Velocity Errors

39 Status Only -- Move at Velocity while Drive Not Enabled error -- Axis

3A Status Only -- Move at Velocity while Program Selected error -- Axis

3B Status Only -- Move at Velocity while Home Cycle active error -- Axis

3C Status Only -- Move at Velocity while Jog error -- Axis

3D Status Only -- Move at Velocity while Abort All Moves bit is set error -- Axis

3E Status Only -- Move at Velocity Data greater than 8,388,607 user units/sec -- Axis

3F Status Only -- Move at Velocity Data greater than 1 million cts/sec error -- Axis

Table B-1. - Continued - DSM302 Error Codes

Error Number

(Hexadecimal)

Response Description Error Type

Jog Errors

40 Status Only -- Jog while Find Home error -- Axis

41 Status Only -- Jog while Move at Velocity error -- Axis

42 Status Only -- Jog while Force Digital Servo Velocity error -- Axis

43 Status Only -- Jog while Program Selected and not Feedholding error -- Axis

Force Digital Servo Velocity Errors

47 Status Only -- Force Digital Servo Velocity while Jog error -- Axis

48 Status Only -- Force Digital Servo Velocity while Move at Velocity error -- Axis

49 Status Only -- Force Digital Servo Velocity while Program Selected error -- Axis

4A Status Only -- Force Digital Servo Velocity while Follower Enabled error -- Axis

Set Position Errors

50 Status Only -- Set Position while Program Selected error -- Axis

51 Status Only -- Set Position Data overrange error -- Axis

52 Status Only -- Servo Axis 1,2: Set Position while not In Zone error Aux Axis 3: Set Position while ENC3 Velocity > 128 error-- Axis

53 Status Only -- Attempt to initialize position before digital encoder passes reference point. -- Axis

54 Status Only -- Digital encoder position invalid, must use Find Home or Set Position. -- Axis

End of Travel and Count Limit Errors

56 Status Only -- Commanded Position > Positive End of Travel or High Count Limit -- Axis

57 Status Only -- Commanded Position < Negative End of Travel or Low Count Limit -- Axis

58 Status Only -- (Absolute Position + Position offset) > Positive End of Travel or High Count Limit -- Axis

59 Status Only -- (Absolute Position + Position offset) < Negative End of travel or Low Count Limit - - Axis

Drive Disable Errors

5B Stop Normal -- Drive Disabled while Moving -- Axis

5C Stop Normal -- Drive Disabled while Program Active -- Axis

Software Errors

5F Status Only -- Software Error (Call GE Fanuc Field Service) -- Axis

Program and Subroutine Errors

60 Status Only -- Absolute Encoder Rotary Position Computation error -- Axis

61 Stop Normal -- Subroutine not in list -- Axis

62 Stop Normal -- Call Error (subroutine already active) -- Axis

63 Stop Normal -- Subroutine End command found in Program -- Axis

64 Stop Normal -- Program End command found in Subroutine -- Axis

65 Stop Normal -- Sync subroutine encountered by non-sync program -- Axis

Program Execution Errors

71 Status Only -- Too many programs requested in same PLC sweep -- Module

72 Status Only -- Request Program 0-10 with multi-axis program active -- Module

73 Status Only -- Request two programs on same sweep with program active -- Module

74 Status Only -- Request two programs for same axis, lower number program executed -- Module

75 Status Only -- Empty or Invalid Program requested -- Module

76 Status Only -- AQ Move Command Position Out of Range -- Axis

Table B-1. - Continued - DSM302 Error Codes

Error Number

(Hexadecimal)

Response Description Error Type

Program Execution Conditions Errors

80 Status Only -- Execute Program while Home Cycle active -- Axis

81 Status Only -- Execute Program while Jog -- Axis

82 Status Only -- Execute Program while Move at Velocity -- Axis

83 Status Only -- Execute Program while Force Digital Servo Velocity -- Axis

84 Status Only -- Execute Program while Program Selected -- Axis

85 Status Only -- Execute Program while Abort All Moves bit set -- Axis

86 Status Only -- Execute Program while Position Valid not set -- Axis

87 Status Only -- Execute Program while Drive Enabled not set -- Axis

88 Status Only -- Execute Program with active Error Stop (Axis Enabled off) -- Axis

Program Synchronous Block Errors

8C Status Only -- Sync Block Error during CMOVE -- Axis

8D Status Only -- Sync Block Error during Jump -- Axis

EEPROM Errors

90 Status Only -- Flash EEPROM memory programming failure -- Module

Hardware Limit Switch Errors

A0 Stop Fast -- Limit Switch (+) error -- Axis

A1 Stop Fast -- Limit Switch (-) error -- Axis

Hardware Errors

A8 Stop Fast -- Out of Sync error -- Axis

A9 Stop Fast -- Encoder Loss of Quadrature or Linear Feedback Loss of Signal error -- Axis

Digital Servo Alarms

B0 Stop Normal -- Main DC power supply overvoltage -- Axis

B1 Stop Normal -- Control power undervoltage -- Axis

B2 Stop Normal -- Dynamic brake failure Axis

B3 Stop Normal -- Main DC power supply undervoltage -- Axis

B4 Stop Normal -- CNV Overload -- Axis

B5 Stop Normal -- Cooling fan failure -- Axis

B6 Stop Normal -- Over current -- Axis

B7 Stop Normal -- Regenerative discharge energy error; resistor thermal switch open -- Axis

B9 Stop Normal -- Control power undervoltage -- Axis

BA Stop Normal -- Error detected by IPM circuit -- Axis

BB Stop Normal -- Main DC power supply undervoltage -- Axis

BD Stop Normal -- Cooling fan failure -- Axis

BE Stop Normal -- Over current -- Axis

Table B-1. - Continued - DSM302 Error Codes (Continued)

Error Number

(Hexadecimal)

Response Description Error Type

Encoder Alarms

C0 Stop Fast Servo not ready when MCON command is on - may be caused by E-STOP input to amplifier.

Axis

C1 Status Only -- Serial Encoder Battery Low -- Axis

C2 Stop Normal -- Serial Encoder Battery Failed -- Axis

C3 Stop Normal -- Servo Motor Over Temperature -- Axis

C4 Stop Fast -- Servo Motor Over Current -- Axis

C5 Stop Fast -- Loss of Encoder -- Axis

C6 Stop Fast -- Error in encoder pulse detection -- Axis

C7 Stop Fast -- Encoder counter error -- Axis

C8 Stop Fast -- -- Encoder LED is disconnected -- Axis

C9 Stop Fast -- Encoder CRC checksum failure -- Axis

CA Stop Fast -- Unsupported encoder, linear or Type A -- Axis

CB Stop Fast -- Unsupported encoder, Type C -- Axis

DSP Alarms

D1 Stop Fast -- Over current Detected -- Axis

D2 Stop Fast -- Loss of Analog Feedback -- Axis

D3 Stop Fast -- Over Acceleration Detected -- Axis

D4 Stop Fast -- Over Velocity Detected -- Axis

D5 Status Only -- KpVelFix Too Large -- Axis

D6 Status Only -- IntGainFix Too Large -- Axis

D7 Status Only -- Alpha Calculation Overflow -- Axis

D8 Status Only -- IntGain Calculation Overflow -- Axis

D9 Status Only -- Kp Calculation Overflow -- Axis

DA Stop Fast -- FPGA Error Detected -- Axis

Special Purpose Errors

E0 Status Only Custom Loop Type Mismatch Axis

E2 Stop Fast DSP Interrupt failure Module

Follower Errors

F1 Status Only -- Follower Position Error Limit Encountered -- Axis

F2 Status Only -- Follower Velocity Limit Condition Encountered -- Axis

F3 Status Only -- Follower Ratio B value = 0 -- Axis

F4 Status Only -- Follower Ratio B value < 0 -- Axis

F5 Status Only -- Follower Ratio A/B or B/A > 32 -- Axis

Winder Errors

F6 Status Only -- A/B Change Not Allowed in Winder Mode With Follower Enabled -- Axis

F7 Status Only -- Set Winder Position Immediate Command Out of Zone -- Axis

F8 Status Only -- Zone Length Out of Range or Zone Length Change Exceeded 25% -- Axis

F9 Status Only -- Zone Length Change Not Accepted; Previous Change Still in Effect -- Axis

Internal Errors

FD Stop Fast -- System software error -- Axis

FE Stop Fast -- Unrecognized encoder, not supported -- Axis

LED Indicators

There are seven LEDs on the DSM302 module which provide status indications. These LEDs are described below.

STAT Normally ON. FLASHES to provide an indication of operational errors. Flashes *slow* (four times/second) for Status-Only errors. Flashes *fast* (eight times/second) for errors which cause the servo to stop.

ON: When the LED is steady ON, the DSM302 is functioning properly. Normally, this LED should always be ON.

OFF: When the LED is OFF, the DSM302 is not functioning. This is the result of a hardware or software malfunction which will not allow the module to power up.

Flashing: When the LED is FLASHING, an error condition is being signaled.

Constant, CFG LED ON:

The LED flashes slow (four times / second for Status Only errors and fast (eight times / second for errors which cause the servo to stop. The operational error code will be placed in one of the first four %AI status words and the *Module Error Present* %I status bit will be ON.

Constant, CFG LED Flashing:

If the STAT and CFG LEDs both flash **together** at a constant rate, the DSM302 module is in boot mode waiting for a new firmware download. If the STAT and CFG LEDs both flash **alternately** at a constant rate, the DSM302 firmware has detected a software watchdog timeout due to a hardware or software malfunction.

Irregular, CFG LED OFF:

If this occurs immediately at power-up then a hardware or software malfunction has been detected. The module will blink the STAT LED to display two error numbers separated by a brief delay. The numbers are determined by counting the blinks in both sequences. Record the numbers and contact GE Fanuc for information on correcting the problem.

OK The OK LED indicates the current status of the DSM302 module.

ON: When the LED is steady ON, the DSM302 is functioning properly. Normally, this LED should always be ON.

OFF: When the LED is OFF, the DSM302 is not functioning. This is the result of a hardware or software malfunction which will not allow the module to power up.

CFG This LED is ON when a valid module configuration has been received from the PLC. Flashes *slow* (four times/second) during the Motion Program Store function. Flashes *fast* (eight times/second) during the Write User RAM to EEPROM operation.

EN1 When this LED is ON, the servo drive for Servo Axis 1 is enabled.

EN2 When this LED is ON, the servo drive for Servo Axis 2 is enabled.

EN3 When this LED is ON, the *Force Analog Output* command for Aux Axis 3 is active.

EN4 When this LED is ON, the *Force Analog Output* command for Aux Axis 4 is active.