

VE.Net Generator Module (VGM)

**USER MANUAL
INSTALLATION MANUAL**

VICTRON ENERGY AT ANY TIME



victron energy

This publication or parts thereof may not be reproduced in any form, by any method, for any purpose.

For conditions of use and permission to use this manual for publication in other than the English language, contact Victron Energy B.V.

VICTRON ENERGY B.V. MAKES NO WARRANTY, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, REGARDING THESE VICTRON ENERGY PRODUCTS AND MAKES SUCH VICTRON ENERGY PRODUCTS AVAILABLE SOLELY ON AN "AS IS" BASIS.

IN NO EVENT SHALL VICTRON ENERGY B.V. BE LIABLE TO ANYONE FOR SPECIAL, COLLATERAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH OR ARISING OUT OF PURCHASE OR USE OF THESE VICTRON ENERGY PRODUCTS. THE SOLE AND EXCLUSIVE LIABILITY TO VICTRON ENERGY B.V., REGARDLESS OF THE FORM OF ACTION, SHALL NOT EXCEED THE PURCHASE PRICE OF THE VICTRON ENERGY PRODUCTS DESCRIBED HERE IN.

Victron Energy B.V. reserves the right to revise and improve its products as it sees fit. This publication describes the state of this product at the time of its publication and may not reflect the product at all times in the future.

1	Introduction	3
1.1	The VE.Net Generator Module (VGM)	3
1.2	Introduction to VE.Net	3
2	Installation of your VGM	4
2.1	Wiring – A.C.	4
2.2	Wiring – D.C.	5
3	Using your VE.Net Generator Module	6
3.1	Quick status line	6
3.2	Generator control	6
3.3	Generator monitoring	7
3.4	Generator logging	8
4	Setup	9
4.1	Generator alarms	9
4.2	Generator setup	10
4.2.1	Magnetic pickup calibration	12
	Appendix 1 Wiring diagrams for selected generators	14

1 Introduction

1.1 *The VE.Net Generator Module (VGM)*

The VE.Net Generator Module is designed to work in conjunction with the standard control system of your generator to allow networked control and monitoring of the generator. The VGM provides detailed monitoring and control facilities, including an auto-start function which allows you to send a single instruction to start the generator. The VGM will automatically carry out the correct process of pre-heat and cranking in order to start the generator.

1.2 *Introduction to VE.Net*

VE.Net stands for Victron Energy Network. It allows all VE.Net compatible devices to communicate with each other. This means that the charger for example can get information from the battery monitor to optimize the charge current. It is possible to control and monitor all your VE.Net devices from a single VE.Net compatible control panel. This saves space and allows you to control all your devices from one place. A VE.Net consists of a VE.Net panel (VPN), and one or more other VE.Net devices, such as the VE.Net Tank Sensor or VE.Net Battery Controller.

2 Installation of your VGM

To install your generator module you will need:

- VE.Net Generator Module (supplied)
- A.C. sensor box with 20 amp load shed contactor (supplied)
- 2 meter RJ11 cable (supplied)
- VE.Net panel
- Standard straight UTP cable

2.1 Wiring – A.C.

Single-phase generators rated up to 20A (approximately 5.7kW @ 230V and 3.0kW @ 120V) can use the supplied load shed contactor built into the AC sensor box (use Figure 2-1 – A.C. sensor box using the internal contactor).




Figure 2-1 – A.C. sensor box using the internal contactor

Single-phase generators rated up to 100A (approximately 23kW @ 230V and 12.0kW @ 120V) have to fit an external load shed contactor, but can still use the standard sensor box for monitoring of voltage, frequency and current (use Figure 2-2 – A.C. sensor box using an external contactor).




Figure 2-2 – A.C. sensor box using an external contactor

2.2 Wiring – D.C.

The VGM can be powered from either the starter battery or the domestic battery; however it is recommended that the domestic battery be used, as even in standby, the VGM consumes a small amount of power. If the VGM is powered from the starter battery, connect 2 and 3 together. Figure 2-3 shows how to wire the VGM for most generators. More specific wiring diagrams for some generators can be found in Appendix 1. Once the generator has been wired up, connect the VPN with the UTP cable.





Figure 2-3 - D.C. wiring

3 Using your VE.Net Generator Module

The main method of control and configuration for the VGM is provided through the VPN. To switch on the panel, hold "Enter" for 2 seconds. When the panel has started, the list of connected VE.Net devices will be displayed. If there are other VE.Net devices connected, it may be necessary to press "▼" until the VGM is displayed.

3.1 Quick status line

When viewing the VGM entry in the device list, you can also see the quick status line. This line gives you a brief summary of the current generator status.



At the quick status line, you can press "Enter" to enter the VGM menu. You can then use the "▼" and "▲" buttons to view the different menu items, and "Enter" to enter sub-menus, and change options. Please refer to the VPN manual for more information on navigating VE.Net menus.

3.2 Generator control

The following procedure is used for starting a generator (**note:** the exact procedure will vary, depending on the type of generator you are using. For more information, please refer to chapter 4.2 - Generator setup).

1. Close the pre-heat relay
2. Wait for pre-heat to complete
3. Close the start relay
4. Wait for the generator output to stabilise
5. Open the pre-heat relay
6. Open the start relay

When the VGM is instructed to start the generator (either by using the VPN, or pressing the generator start button), it automatically carries out this procedure without requiring any further action from the user. The VGM also carries out two further steps:

7. Wait for the warm-up period
8. Close the load shedding contactor in A.C. sensor box

These final steps allow the generator to reach full speed before the load is connected, and make sure that the load only receives a clean A.C. signal.

The procedure for stopping a generator is as follows (**note:** the exact procedure will vary, depending on the type of generator you are using, for more information, please refer to chapter 4.2 - Generator setup):

1. Open the load shedding contactor in the A.C. sensor box
2. Wait for the cool down period
3. Close the stop relay for one second

When the VGM is instructed to stop the generator (either by using the VPN, or pressing the generator stop button), it automatically carries out this procedure without requiring any further

action from the user. The purpose of the first two steps, are both to make sure the load only receives a clean AC signal, and to allow the generator to gradually slow down before being stopped. This is particularly important for air-cooled generators.

Gen control menu				
Menu item	Description	Range	Step size	Default value
Gen control	Use this option to perform the displayed action.	"start", "stop"	N/A	Depends on the current generator status
Delayed stop	This option determines how long to wait, after the stop command is issued, before the generator is actually stopped. This can be useful, to allow the generator to run unattended for a period of time. For example to charge batteries, or allow laundry to finish.	0 – 500 minutes	10 minutes	0 minutes
Load shed	This option allows the normal behaviour of the load shedding relay to be overridden. This can be useful if it is necessary to bring the generator online before the warm-up period is complete, or to bring the generator offline without stopping it.	"yes", "no"	N/A	Depends on the current generator status

3.3 Generator monitoring

In addition to start and stop control of the generator, the VGM also monitors the generator to make sure that it is operating correctly. The VGM can be configured to generate an alarm if the generator is not operating within desired parameters see chapter (4.1 - Generator alarms).

Gen monitoring menu		
Menu item	Description	Units
Session run time	The amount of time that has elapsed since the generator was last started.	Hours and minutes
Coolant temp	The temperature of the generator coolant. Note: this facility is not supported by all generators.	Degrees Celsius
Oil pressure	The oil pressure of the generator. Note: this facility is not supported by all generators.	Pounds per square inch
AC voltage	The A.C. output voltage of the generator.	Volts
AC amperage	The generator load current.	Amperes
AC frequency	The frequency of the generator output.	Hertz
AC kilowatts	The current power output of the generator. This is calculated from the voltage and current readings.	Kilowatts
Battery voltage	The voltage of the starter battery.	Volts
Engine speed	The generator engine speed. By default, this value is calculated from the measured A.C. frequency. However, if a magnetic pickup is installed and calibrated, then the pickup will be used for the calculation instead (see chapter 4.2.1 - Magnetic pickup calibration).	Revolutions per minute
Average load	The average load on the generator since it was last switched on.	Percent
Current load	The current load on the generator.	Percent

Next service due	The time remaining before the generator needs to be serviced.	Hours and minutes
------------------	---	-------------------

3.4 Generator logging

The generator logging menu records information about the overall usage of the generator. This can be useful for determining the health of the generator.

Gen log menu		
Menu item	Description	Units
Total run time	The total amount of time the generator has been running since the VGM was installed.	Hours and minutes
Number of starts	The number of times the generator has been started since the VGM was installed.	None
Average load	The average load on the generator since the VGM was installed.	Percent
Last alarm 1st	The last alarm type that occurred.	N/A
Last alarm 2nd	The second to last alarm type that occurred.	N/A
Last alarm 3rd	The third from last alarm type that occurred.	N/A
Num services	The number of services this generator has had during its life.	None
Service interval	Use this option when the generator is serviced, to reset the service interval and update the number of services.	N/A

4 Setup

The VGM is designed to be highly configurable, in order to meet the requirements for a wide range of applications. The following sections describe the available options and how to use them correctly.

In order to access the setup menus, it is necessary to set the VPN access level to “user and install”. Once configuration is complete, it is recommended that the VPN access level be set to “user”. For more information on access levels, refer to the VPN user manual.

4.1 Generator alarms

The VGM can be configured to generate an alarm if a problem occurs with the generator. It is also possible to have the VGM automatically stop the generator when certain faults are detected.

The actions available for each individual alarm depend on the parameter being monitored. Table 4-1 describes the available alarm actions.

Description	Action taken when alarm condition occurs
pre alarm off	None.
pre alarm on	Alarm sent to VPN and VGM fault light illuminates.
pre shutdown on	Alarm sent to VPN, VGM fault light illuminated, and generator stopped.
alarm disabled	None.
alarm enabled	Alarm sent to VPN and VGM fault light illuminates.
shutdown enabled	Alarm sent to VPN, VGM fault light illuminates, and the generator stopped.

Table 4-1 - Alarm options

Note: Most generators have preset shutdown levels for certain types of fault. The alarms for these faults use the “pre alarm on”, and “pre shutdown on” options. When using these alarms, the alarm thresholds should be configured so that the VGM recognises the alarm conditions *before* the generator does. This is because many generators will not identify the cause of an automatic shutdown, so by allowing the VGM to detect the fault first, the cause can be determined later by looking at the last alarm properties in the “gen log” menu (see chapter 3.4 - Generator logging).

For information on changing the alarm thresholds, refer to chapter 4.2 - Generator setup.

Gen alarms menu			
Menu item	Description	Supported options	Default value
Oil pressure	Generates an alarm if the oil pressure is too low). Note: do not enable this alarm unless an oil pressure sender is connected.	“pre alarm off”, “pre alarm on”, “pre shutdown on”	“pre alarm off”
Coolant temp	Generates an alarm if the coolant temperature is too high. Note: do not enable this alarm unless a temperature sender is connected.	“pre alarm off”, “pre alarm on”, “pre shutdown on”	“pre alarm off”
Generator overload	Generates an alarm if the generator load	“pre alarm off”, “pre alarm on”	“pre alarm on”

	goes over 100%		
Loss of AC power	Generates an alarm if the AC voltage drops below the specified value.	"alarm disabled", "alarm enabled", "shutdown enabled"	"alarm enabled"
Gen failure	Generates an alarm if multiple failures are detected.	"alarm disabled", "alarm enabled"	"alarm enabled"
Gen underload	Generates an alarm if the generator has been running at less than the specified load for more than the specified duration.	"pre alarm off", "pre alarm on", "pre shutdown on"	"pre alarm off"
Under speed	Generates an alarm if the generator drops below 90% of the nominal engine speed.	"alarm disabled", "alarm enabled"	"alarm enabled"
Over speed	Generates an alarm if the generator rises over 110% of the nominal engine speed.	"pre alarm off", "pre alarm enabled", "pre shutdown enabled"	"pre alarm enabled"
Service due 25hr	Generates an alarm 25 hours before the next service is due.	"alarm disabled", "alarm enabled"	"alarm enabled"

4.2 Generator setup

This menu contains all of the generator specific settings. It is important to ensure that these setting reflect the characteristics of the generator.

Note: Values for the alarm set-points will only be used if the corresponding alarm is enabled (see chapter 4.1 - Generator alarms)

Gen setup menu				
Menu item	Description	Range	Step size	Default value
Generator type	The type of generator that is connected. This determines the start up and shutdown procedures. Configurations for other generator types are available on request.	"Northern Lights" (standard), "Northern L AS" (Northern Lights auto start), "Vetus", "Westerbeke", "Kohler small", "Kohler large", "Mase", "Fischer Panda"	N/A	"Northern Lights"
Gen nom voltage	The nominal A.C. output voltage of the generator.	110V/230V	N/A	230V
Gen frequency	The nominal output frequency and engine speed for the	"50Hz – 1500rpm", "50Hz – 3000rpm",	N/A	"50Hz – 1500rpm"

	generator.	"60Hz – 1800rpm", "60Hz – 3600rpm"		
Gen amperage	The maximum continuous A.C. output current of the generator.	1 – 200A	1A	20A
OP alarm point	The set-point for the oil pressure alarm.	0 – 70PSI	1PSI	20PSI
WT alarm point	The set-point for the coolant temperature alarm.	50 – 100°C	1°C	90°C
Underload %	The level below which a sustained load current should trigger an underload alarm.	0 – 100%	1%	40%
Underload period	The amount of time the output current must be below the underload % threshold before an underload alarm is generated.	1 – 200 minutes	1 minute	30 minutes
Overload pre %	The set-point for the generator overload pre alarm	1 – 100%	1%	90%
Warm-up period	The amount of time to wait after starting the generator, before the load shedding contactor is closed.	1 – 100 seconds	1 second	5 seconds
Cool down period	The amount of time to wait after opening the load shedding contactor, before stopping the generator.	9 – 300 seconds	10 seconds	10 seconds
Service interval	The number of hours of use before the generator requires servicing.	50 – 500 hours	10 hours	200 hours
Crank disconnect	The engine speed at which the starter motor should be disconnected when starting the generator.	400 – 1000 rpm	10 rpm	500 rpm
Preheat for	The amount of time to preheat prior to cranking.	1 – 60 seconds	1 second	5 seconds
Start retries	The number of times the VGM should attempt to start the generator if the initial attempt fails. This is important for marine sets with wet exhausts, as excessive cranking can fill the exhaust and the engine with sea water.	0 – 10	1	3
Enable switch in	Enables or disables the switch inputs for controlling the generator. If for example, the start stop switch is connected to a Phoenix Multi, or other device capable of automatically starting the generator, it may be desirable to set this option to "no" at night, to prevent the generator from starting, and waking everybody.	"no", "yes"	N/A	"yes"
Magnetic pickup	Indicates whether or not a magnetic pickup is connected. If	"not connected", "connected"	N/A	"not connected"


	connected, the pickup will be used to calculate the engine speed; otherwise the speed will be estimated based on the frequency of the output voltage. Note: if you connect a pickup, it must also be calibrated. See chapter 4.2.1 - Magnetic pickup calibration.			
Calib mag pickup	This option is used to calibrate the magnetic pickup See chapter 4.2.1 - Magnetic pickup calibration.	N/A	N/A	N/A
Flywheel teeth	Specifies the number of teeth on the flywheel. This value is used for the engine speed calculation when a magnetic pickup is connected. See chapter 4.2.1 - Magnetic pickup calibration.	0 – 250	1	0
Device name	The name of the VGM. This name will appear in the device list of the VPN, with the quick status line. Changes to this property will not take effect until the VPN is restarted.	“Gen Controller”	N/A	N/A
Device address	Displays the VE.Net device address for this unit. Every VE.Net device has a unique address.	N/A	N/A	N/A
Software version	The version of the software in the VGM.	N/A	N/A	N/A

4.2.1 Magnetic pickup calibration


If the generator has a magnetic pickup installed, the output can be connected to the VGM, enabling the engine speed to be measured. The pickup generates a pulse every time a flywheel tooth passes it. If the number of teeth is known, the engine speed can be calculated based on the frequency of the pulses received from the pickup. Although the number of teeth can be entered manually, it is much simpler to allow the VGM to determine this using the magnetic pickup calibration procedure. The calibration procedure is as follows:

Step 1) Connect up the generator controller (see chapter 2 - Installation of your VGM).

Step 2) Set the “Gen frequency” property to the correct value.



Step 3) Set the “Magnetic pickup” property to “connected”.



Step 4) Manually start the generator, and run it with a steady load (or no load).

Step 5) Once the generator is stable go to the “Calib mag pickup” menu and press “Enter”.

```
Calib mag pickup  
→                               yes
```

Step 6) The text on the second line will momentarily read “Calib. Complete”.

```
Calib mag pickup  
Calib. complete
```

The calibration procedure is now complete. The number of flywheel teeth detected can be seen in the “Flywheel teeth” property.


```
Flywheel teeth  
→                               150
```

If there was a problem reading the magnetic pickup during calibration, the “Calib mag pickup” property will momentarily read “Calib. Error!”. Check the magnetic pickup connections and try again.


```
Calib mag pickup  
Calib. error!
```

Appendix 1 Wiring diagrams for selected generators

Fischer Panda




Masse IS3.5 to IS6.0




*Auxiliary relay contact is normally open. When the generator is preheating and running, auxiliary contact will be closed.

Masse 6.5 or 7.6



*Auxiliary relay contact is normally open. When the generator is preheating and running, auxiliary contact will be closed.

Northern Lights





Victron Energy B.V.

De Paal 35
1351 JG Almere
PO Box 50016
1305 AA Almere
The Netherlands

Version: 05
Date: 26 March 2007