


REDDY Heater[®]

PORTABLE FORCED AIR HEATER

OWNER'S MANUAL



Model RK150
Heater Size 150,000 Btu/Hr

IMPORTANT

Read and understand this manual before assembling, starting, or servicing heater. Improper use of heater can cause serious injury. Keep this manual for future reference.

CONTENTS

SECTION	PAGE
Safety Information	2
Product Identification	4
Unpacking	4
Assembly	5
Theory of Operation	6
Fuels	7
Ventilation	7
Operation	8
Storing, Transporting, or Shipping	9
Preventative Maintenance Schedule	9
Troubleshooting	10
Service Procedures	11
Upper Shell Removal	11
Fan	11
Air Output, Air Intake, and Lint Filters	11
Pump Pressure Adjustment	12
Fuel Filter	12
Spark Plug	12
Nozzle	13
Pump Rotor	13
Specifications	14
Wiring Diagram	15
Maintenance Kits	15
Accessories	15
Illustrated Parts Breakdown and Parts List	16
Burner Head Assembly	18
Motor and Pump Assembly	18
Warranty and Repair Service	Back Cover

SAFETY INFORMATION

WARNINGS

IMPORTANT: Read this owner's manual carefully and completely before trying to assemble, operate, or service this heater. Improper use of this heater can cause serious injury or death from burns, fire, explosion, electrical shock, and carbon monoxide poisoning.

DANGER

Carbon monoxide poisoning may lead to death!

Carbon Monoxide Poisoning: Early signs of carbon monoxide poisoning resemble the flu, with headaches, dizziness, or nausea. If you have these signs, the heater may not be working properly. **Get fresh air at once!** Have heater serviced. Some people are more affected by carbon monoxide than others. These include pregnant women, persons with heart or lung disease or anemia, those under the influence of alcohol, and those at high altitudes.

Make certain you read and understand all warnings. Keep this manual for reference. It is your guide to safe and proper operation of this heater.

SAFETY INFORMATION

Continued

WARNINGS *(Continued)*

- Use only kerosene or No. 1 fuel oil to avoid risk of fire or explosion. Never use gasoline, naphtha, paint thinners, alcohol, or other highly flammable fuels.
- Fueling
 - a) Personnel involved with fueling shall be qualified and thoroughly familiar with the manufacturer's instructions and applicable regulations regarding the safe fueling of heating units.
 - b) Only the type of fuel specified on the heater's data plate shall be used.
 - c) All flame, including the pilot light, if any, shall be extinguished and the heater allowed to cool, prior to fueling.
 - d) During fueling, all fuel lines and fuel-line connections shall be inspected for leaks. Any leaks shall be repaired prior to returning the heater to service.
 - e) At no time shall more than one day's supply of heater fuel be stored inside a building in the vicinity of the heater. Bulk fuel storage shall be outside the structure.
 - f) All fuel storage shall be located a minimum of 25 feet (7.62 m) from heaters, torches, welding equipment, and similar sources of ignition (exception: the fuel reservoir integral with the heater unit).
 - g) Whenever possible, fuel storage shall be confined to areas where floor penetrations do not permit fuel to drip onto or be ignited by a fire at lower elevation.
 - h) Fuel storage shall be in accordance with the authority having jurisdiction.
- Never use heater where gasoline, paint thinner, or other highly flammable vapors are present.
- Follow all local ordinances and codes when using heater.
- Heaters used in the vicinity of tarpaulins, canvas, or similar enclosure materials shall be located a safe distance from such materials. The recommended minimum safe distance is 10 feet (3.048 m). It is further recommended that these enclosure materials be of a fire retardant nature. These enclosure materials shall be securely fastened to prevent them from igniting or from upsetting the heater due to wind action.
- Use only in well-vented areas. Provide at least a 4 1/2-square-foot (4,180 square cm) opening of fresh outside air.
- Use only in places free of flammable vapors or high dust content.
- Use only with the electrical voltage and frequency specified on model plate.
- Use only a three-prong, grounded extension cord.
- Minimum heater clearances from combustibles:
 - Outlet: 8 Ft. (244 cm) Sides, Top, and Rear: 4 Ft. (122 cm)
- Locate heater on a stable and level surface while hot or running or a fire may occur.
- When moving or storing heater, keep heater in a level position or fuel spillage may occur.
- Keep children and animals away from heater.
- Unplug heater when not in use.
- When used with thermostat, heater may start anytime.
- Never use heater in living or sleeping areas.
- Never block air inlet (rear) or air outlet (front) of heater.
- Never move, handle, refuel, or service a hot, operating, or plugged-in heater.
- Never attach duct work to front or rear of heater.

PRODUCT IDENTIFICATION




Figure 1 - RK150 Model

UNPACKING

1. Remove all packing items applied to heater for shipment.
2. Remove all items from carton.
3. Check items for shipping damage. If heater is damaged, promptly inform dealer where you bought heater.

ASSEMBLY

This model is furnished with wheels and a front handle. Wheels, handle, and the mounting hardware are found in the shipping carton.

Tools Needed

- Medium Phillips Screwdriver
- 3/8" Open or Adjustable Wrench
- Hammer

1. Slide axle through wheel support frame. Install wheels on axle.
IMPORTANT: When installing wheels, point extended hub of wheels toward wheel support frame (see Figure 2).
2. Place cap nuts on axle ends. Gently tap with hammer to secure.
3. Place heater on wheel support frame. Make sure air inlet end (rear) of heater is over wheels. Line up holes on fuel tank flange with holes on wheel support frame.
4. Place front handle on top of fuel tank flange. Insert screws through handle, fuel tank flange, and wheel support frame. Attach nut finger tight after each screw is inserted.
5. After all screws are inserted, tighten nuts firmly.




Figure 2 - Wheel and Handle Assembly

THEORY OF OPERATION

The Fuel System: The air pump forces air through the air line. The air is then pushed through the burner head nozzle. This air causes fuel to lift from the tank. A fine mist of fuel is sprayed into the combustion chamber.

The Air System: The motor turns the fan. The fan pushes air into and around the combustion chamber. This air is heated and provides a stream of clean, hot air.

The Ignition System: The electronic ignitor sends voltage to the spark plug. The spark plug ignites the fuel and air mixture.

The Burner Control System: This system causes the heater to shut down if the flame goes out.




Figure 3 - Cross Section Operational View

FUELS

WARNING

Use only kerosene or No. 1 fuel oil to avoid risk of fire or explosion. Never use gasoline, naphtha, paint thinners, alcohol, or other highly flammable fuels.

Do not use heavy fuels such as No. 2 fuel oil or No. 2 Diesel. Using heavy fuels will result in:

- clogged fuel filter and nozzle
- carbon build up on spark plug
- the need of nontoxic anti-icer in fuel during very cold weather

IMPORTANT: Use a KEROSENE ONLY storage container. Be sure storage container is clean. Foreign matter such as rust, dirt, or water will cause the burner control to shut down heater. Foreign matter may also require you to clean fuel system often.

VENTILATION

WARNING

Follow the minimum fresh, outside air ventilation requirements. If proper fresh, outside air ventilation is not provided, carbon monoxide poisoning can occur. Provide proper fresh, outside air ventilation before running heater.

Provide a fresh air opening of at least 4 1/2 square feet (4,180 square cm). Provide extra fresh air if more heaters are being used.

Example: A 150,000 Btu/Hr heater requires one of the following:

- a two-car garage door [16 feet (5 meter) wide opening] raised 3.5 inches (8.9 cm)
- a single-car garage door [9 feet (2.75 meter) wide opening] raised 6 inches (15.25 cm)
- two, thirty-inch (76.2 cm) wide opening windows raised 11 inches (28 cm)

OPERATION

WARNING

Review and understand the warnings in the Safety Information Section. They are needed to safely operate this heater. Follow all local codes when using this heater.

To Start Heater

1. Follow all ventilation and safety information.
2. Fill fuel tank with kerosene or No. 1 fuel oil.
3. Attach fuel cap.
4. Plug power cord of heater into 220 volt/60 hertz grounded outlet. Use an extension cord if needed. Use only a three-prong, grounded (earthed) extension cord.

Extension Cord Wire Size Requirements

Up to 100 feet (30.5 meters) long, use 16 AWG (1.0 mm²) rated cord

101 to 200 feet (30.8 to 61 meters) long, use 14 AWG (1.5 mm²) rated cord

Heater will start when power cord is plugged into outlet. If not, push in burner control reset button (see Figure 4).




Figure 4 - Burner Control Reset Button

To Stop Heater

1. Unplug power cord from outlet.

To Restart Heater

1. Wait 2 minutes after stopping heater.
2. Repeat steps under *To Start Heater*, above.

STORING, TRANSPORTING, OR SHIPPING

PREVENTATIVE MAINTENANCE SCHEDULE

Note: If shipping, transport companies require fuel tanks to be empty.

1. Drain fuel tank.

Note: Some models have drain plug on underside of fuel tank. If so, remove drain plug to drain all fuel. If heater does not have drain plug, drain fuel through fuel cap opening. Be sure all fuel is removed.

2. Replace drain plug if provided.
3. If any debris is noted in old fuel, add 1 or 2 quarts (1 or 2 liters) of clean kerosene to tank, stir, and drain again. This will prevent excess debris from clogging filters during future use.
4. Replace fuel cap or drain plug. Properly dispose of old and dirty fuel. Check with local automotive service stations that recycle oil.
5. If storing, store heater in dry place. Make sure storage place is free of dust and corrosive fumes.

IMPORTANT: Do not store kerosene over summer months for use during next heating season. Using old fuel could damage heater.

WARNING

Never service heater while it is plugged in, operating, or hot. Severe burns and electrical shock can occur.

<u>Item</u>	<u>How Often</u>	<u>How To</u>
Fuel tank	Flush every 150-200 hours of operation or as needed.	See <i>Storing, Transporting, or Shipping</i> , above.
Air output and lint filters	Replace every 500 hours of operation or once a year.	See <i>Air Output, Air Intake, and Lint Filters</i> , page 11.
Air intake filter	Wash and dry with soap and water every 500 hours of operation or replace as needed.	See <i>Air Output, Air Intake, and Lint Filters</i> , page 11.
Fuel filter	Clean twice a heating season or replace as needed.	See <i>Fuel Filter</i> , page 12.
Spark plug	Clean and regap every 600 hours operation or replace as needed.	See <i>Spark Plug</i> , pages 12.
Fan blades	Clean each season or as needed.	See <i>Fan</i> , page 11.
Motor	Not required/permanently lubricated.	

TROUBLE-SHOOTING

WARNING

Never service heater while it is plugged in, operating, or hot. Severe burns and electrical shock can occur.

<u>OBSERVED FAULT</u>	<u>POSSIBLE CAUSE</u>	<u>REMEDY</u>
Heater ignites, but burner control shuts off heater after a short period of time.	Wrong pump pressure	See <i>Pump Pressure Adjustment</i> , page 12.
	Dirty air output, air intake and lint filters	See <i>Air Output, Air Intake and Lint Filters</i> , page 11.
	Dirty fuel filter	See <i>Fuel Filter</i> , page 12.
	Dirt in nozzle	See <i>Nozzle</i> , page 13.
	Dirty photocell lens	Clean photocell lens.
	Bad burner control	Replace burner control.

Heater will not ignite, but motor runs for a short period of time.	Wrong pump pressure	See <i>Pump Pressure Adjustment</i> , page 12.
	Carbon deposits on spark plug and/or improper gap	See <i>Spark Plug</i> , pages 12.
	Dirty fuel filter	See <i>Fuel Filter</i> , page 12.
	Dirt in nozzle	See <i>Nozzle</i> , page 13.
	Water in fuel tank	Drain and flush fuel tank with clean kerosene. See <i>Storing, Transporting, or Shipping</i> , page 9.

WARNING: High voltage!

Electronic ignitor not grounded	Make sure electronic ignitor mounting is tight.
Bad electronic ignitor	Replace electronic ignitor.

Motor does not start when heater is plugged in, fan rotates slowly or does not turn.	Burner control not reset	Press burner control reset button.
	Binding pump rotor	If fan is hard to turn, see <i>Pump Rotor</i> , page 13.

SERVICE PROCEDURES

Upper Shell Removal

1. Remove screws along each side of heater using 5/16" nut-driver. These screws attach upper and lower shells together.
2. Lift upper shell off.
3. Remove fan guard.

Fan

IMPORTANT: Remove fan from motor shaft before removing motor from heater. The weight of the motor resting on the fan could damage the fan pitch.

1. Remove upper shell (see above).
2. Use 1/8" Allen wrench to loosen setscrew which holds fan to motor shaft.
3. Slip fan off motor shaft.
4. Clean fan using soft cloth moistened with kerosene or solvent.
5. Dry fan thoroughly.
6. Replace fan on motor shaft. Place fan hub flush with end of motor shaft (see Figure 6).
7. Place setscrew on flat of shaft. Tighten setscrew firmly (40-50 inch-pounds/4.5-5.6 n-m).
8. Replace fan guard and upper shell.

Air Output, Air Intake, and Lint Filters

1. Remove upper shell (see above).
2. Remove filter end cover screws using 5/16" nut-driver.
3. Remove filter end cover.
4. Replace air output and lint filters.
5. Wash or replace air intake filter (see *Preventative Maintenance Schedule*, page 9).
6. Replace filter end cover.
7. Replace fan guard and upper shell.

IMPORTANT: Do not oil filters.

⚠ WARNING

Never service heater while it is plugged in, operating, or hot. Severe burns and electrical shock can occur.




Figure 5 - Upper Shell Removal




Figure 6 - Fan Cross Section




Figure 7 - Air Output, Air Intake, and Lint Filters

Pump Pressure Adjustment

1. Remove pressure gauge plug from filter end cover.
2. Install accessory pressure gauge (part number HA1180).
3. Start heater (see *Operation*, page 8). Allow motor to reach full speed.
4. Adjust pressure. Turn relief valve to right to increase pressure. Turn relief valve to left to decrease pressure. Adjust pump pressure to 4.9 psi.
5. Remove pressure gauge. Replace pressure gauge plug in filter end cover.




Figure 8 - Pressure Gauge Plug Removal




Figure 9 - Adjusting Pump Pressure

Fuel Filter

1. Remove side cover screws using 5/16" nut-driver.
2. Remove side cover.
3. Pull upper fuel line off fuel filter neck.
4. Carefully pry bushing, fuel filter, and lower fuel line out of fuel tank.
5. Wash fuel filter with clean fuel and replace in tank.
6. Attach upper fuel line to fuel filter neck.
7. Replace side cover.




Figure 10 - Fuel Filter Removal

Spark Plug

1. Remove upper shell (see page 11).
2. Remove fan (see page 11).
3. Remove spark plug wire from spark plug.
4. Remove spark plug from burner head using 13/16" open-end wrench.
5. Clean and regap spark plug electrodes to .075" (1.9 mm) gap.
6. Install spark plug in burner head.
7. Attach spark plug wire to spark plug.
8. Replace fan (see page 11).
9. Replace fan guard and upper shell.




Figure 11 - Spark Plug Removal




Figure 12 - Spark Plug Gap

Nozzle

1. Remove upper shell (see page 11).
2. Remove fan (see page 11).
3. Remove fuel and air line hoses from burner head.
4. Remove spark plug wire from spark plug.
5. Remove spark plug from burner head using 13/16" open-end wrench.
6. Remove three screws using 5/16" nut-driver and remove burner head from combustion chamber.
7. Place burner head into vise and lightly tighten.
8. Carefully remove nozzle from burner head using 5/8" socket wrench (see Figure 14).
9. Blow compressed air through face of nozzle. This will free any dirt in nozzle area.
10. Inspect nozzle seal for damage.
11. Replace nozzle into burner head and tighten firmly (80-110 inch-pounds / 9.1-12.4 n-m).
12. Attach burner head to combustion chamber.
13. Install spark plug in burner head.
14. Attach spark plug wire to spark plug.
15. Attach fuel and airline hoses to burner head.
16. Replace fan (see page 11).
17. Replace fan guard and upper shell.

Pump Rotor

(Procedure if rotor is binding)

1. Remove upper shell (see page 11).
2. Remove filter end cover screws using 5/16" nut-driver.
3. Remove filter end cover and air filters.
4. Remove pump plate screws using 5/16" nut-driver.
5. Remove pump plate.
6. Remove rotor, insert, and blades.

Continued




Figure 13 - Removing Burner Head




Figure 14 - Removing Nozzle




Figure 15 - Rotor Location

7. Check for debris in pump. If debris is found, blow out with compressed air.
8. Install insert and rotor.
9. Check gap on rotor. Adjust to .003"/.004" (.076-.101 mm) if needed (see Figure 16).

Note: Rotate rotor one full turn to insure the gap is .003"/.004" (.076-.101 mm) at tightest position. Adjust if needed.

(Pump Rotor, continued)

10. Install blades, pump plate, air filters, and filter end cover.
11. Replace fan guard and upper shell.
12. Adjust pump pressure (see page 12).

Note: If rotor is still binding, proceed as follows.

13. Perform steps 1 through 6 (see page 13).
14. Place fine grade sandpaper (600 grit) on flat surface. Sand rotor lightly in "figure 8" motion four times (see Figure 17).
15. Reinstall insert and rotor.
16. Perform steps 10 through 12 above.




Figure 16 - Gap Adjusting Screw Locations





Figure 17 - Sanding Rotor

SPECIFICATIONS

Output Rating (Btu/Hr.)	150,000
Fuel	Use Only Kerosene or No. 1 Fuel Oil
Fuel Tank Capacity (U.S. Gal./Liters)	13.5/51
Fuel Consumption (Gal. Per Hr./Liters Per Hr.)	1.1/4.16
Electric Requirements	220 volt/60 hertz
Amperage (Normal Run)	2
Amperage (Start)	9
Hot Air Output (CFM/CMM)	500/14.2
Motor RPM	3450

WIRING DIAGRAM




MAINTENANCE KITS

KIT	PART NUMBER
Spark Plug Kit	HA3012
Filter Kit	HA3017
Nozzle Kit	HA3010
Rotor/Air Pump Kit	HA3004
Handle Kit	HA2204
Photocell Kit	HA3019
Pump Adjustment Kit	HA3020
Fuel Tank Filter Screen Kit	HA2210

ACCESSORIES


Purchase accessories and parts from your nearest dealer or service center. If they can not supply these accessories or parts, contact DESA International at:

DESA International
P.O. Box 90004
Bowling Green, KY
42102-9004
U.S.A.
(502) 781-9600
Parts Department



AIR GAUGE KIT - HA1180
 Special tool to check pump pressure.

ILLUSTRATED PARTS BREAKDOWN




PARTS LIST

This list contains replaceable parts used in your heater. When ordering parts, be sure to provide the correct model and serial numbers (from the model plate), then the part number and description of the desired part.

KEY NO.	PART NUMBER	DESCRIPTION	QTY.	KEY NO.	PART NUMBER	DESCRIPTION	QTY.
1	098511-135	Upper Shell	1	32	097630-02	Burner Control	1
2	M15823-27	Screw, #10-16 x 1/2"	8	33	M11143-1	Strain Relief Bushing	1
3	098512-29	Combustion Chamber	1	34	099055-07	Power Cord	1
4	099229-01	Photocell Bracket	1	35	M51077-01AA	Side Cover	1
5	M10908-2	Screw, #6-32 x 3/8"	2	36	M11084-27	Screw, #10-16 x 1/2"	4
6	HA3019	Photocell Assembly	1	37	099125-03	Terminal Board	1
7	†	Burner Head Assembly	1	38	099157-01	Rivet	1
8	M11084-27	Screw, #10-16 x 1/2"	3	39	M16841-59	Wire Assembly (Red, 13 1/2")	1
9	097293-01	Fan	1	40	M16841-57	Wire Assembly (Red, 6")	1
10	†	Motor and Pump Assembly	1	41	M27417	Drain Plug (Includes "O" Ring)	1
11	M50631	Rubber Bumper	2	42	097896-01	Wheels	2
12	098138-02	Motor Mounting Bracket	1	43	M16801-2	Axle	1
13	M12462-15	Motor Start Relay	1	44	M12831-3	Wheel Support Frame	1
14	M12461-13	Screw, #8-32 x 1/4"	2	45	HA2204	Front Handle	1
15	NTC-4C	Hex Lock Nut, 1/4-20	2	46	M12345-33	Screw, #10-24 x 1 3/4"	8
16	M51114-01	Fan Guard	1	47	M28526	Nut cap	2
17	098557-07	Ignitor Kit	1	48	NTC-3C	Hex Lock Nut, #10-24	8
18	M11084-29	Screw, #10-16 x 3/4"	2	49	099230-01	Screw, #10-16 x 3/8"	2
19	M51345-02	Fuel Line	1	50	099213-01	Button Plug	1
20	M51150-01	Fuel Filter	1	51	M11084-27	Screw, #10-16 x 1/2"	2
21	M51151-02	Fuel Line Tube	1	52	099177-01	Hex Nut	1
22	M10990-3	Rubber Bushing	1	53	078918-01	Tab Cap	1
23	M50814-03	Air Line	1	PARTS AVAILABLE - NOT SHOWN			
24	098511-137	Lower Shell	1				
25	M50104-03	Bushing	2		097204-05	Tradename Decal	
26	M50104-01	Bushing	2		103253-04	General Information Decal	
27	M11084-27	Screw, #10-16 x 1/2"	6		098227-84	Wiring Decal	
28	M11271-8	Clip Nut	8				
29	M15823-39	Screw, #8-18 x 1/2"	1				
30	098513-56	Fuel Tank	1				
31	097663-03	Fuel Cap Gauge	1				


† Not available as an assembly. Order parts separately. See page 18.

BURNER HEAD ASSEMBLY



KEY NO.	PART NO.	DESCRIPTION	QTY.
1	HA3010	Nozzle with Sleeve	1
2	M10659-1	Nozzle Washer	2
3	M10809-1	Nozzle Spring	1
4	M8882	Nozzle Sleeve	1
5	M50924-03	Burner Head Body	1
6	M50820-02	Barb Fitting	2
7	HA3012	Spark Plug	1

MOTOR AND PUMP ASSEMBLY



KEY NO.	PART NO.	DESCRIPTION	QTY.
1	099656-01	Motor (220V/60Hz)	1
2	079975-01	Pump Body	1
3	FHPF3-2C	Screw, #10-32 x 1/4"	2
4	M22009	Rotor Insert	1
5	M22456-1	Pump Rotor	1
6	M50545	Pump End Cover	1
7	M12179	Intake Filter	1
8	M16545	Filter End Cover	1
9	M8940	Steel Ball, 1/4" diameter	1
10	M10993-1	Relief Spring	1
11	M27694	Adjusting Screw	1
12	M22997	Plug	1
13	M12461-31	Screw, #10-32 x 1"	10
14	M12244-1	Output Filter	1
15	M11637	Lint Filter	1
16	M50820-02	Barb Fitting	1
17	M8643	Blade	4

WARRANTY AND REPAIR SERVICE

CERTIFICATE OF GENERAL EQUIPMENT - LIMITED 90 DAY WARRANTY

DESA International warrants new Products sold by it to be free from defects in material or workmanship for a period of ninety days after date of delivery to the first user and subject to the following conditions:

DESA International's obligation and liability under this Warranty is expressly limited to repairing or replacing at DESA International's option, any parts which appear to DESA International upon inspection to have been defective in material or workmanship when shipped from the factory. Such parts shall be provided at no cost to the user, at the business establishment of any factory authorized service center or the factory during regular working hours. The Warranty shall not apply to component parts or accessories of Products not manufactured by DESA International and which carry the warranty of the manufacturer thereof, or to normal maintenance (such as pressure adjustments) or to normal maintenance parts (such as filters and spark plugs). Replacement or repair parts installed in the Product covered by this Warranty are warranted only for the remainder of this Warranty as if such parts were original components of said Product. DESA INTERNATIONAL MAKES NO OTHER EXPRESS WARRANTY. TO THE EXTENT PERMITTED BY LAW DESA INTERNATIONAL MAKES NO IMPLIED WARRANTY AND MAKES NO WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE.

IN ANY EVENT IMPLIED WARRANTIES INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE LIMITED TO THE DURATION OF THIS EXPRESS WARRANTY.

Any transportation charges, costs of installation, duty, taxes or any other charges whatsoever must be borne by the user. DESA International's obligation under this limited Warranty shall not include any liability for direct, indirect, incidental, or consequential damage or delay. If requested by DESA International, Products or parts for which a warranty claim is made are to be returned transportation prepaid by user to the factory. Any improper use, including operation after discovery of defective or worn parts, operation beyond capacity, substitution of parts not approved by DESA International, or any alteration or repair by others in such manner as in DESA International's judgement affects the Product materially and adversely, shall void this Warranty.

NO EMPLOYEE OR REPRESENTATIVE IS AUTHORIZED TO CHANGE THIS WARRANTY IN ANY WAY OR GRANT ANY OTHER WARRANTY UNLESS SUCH CHANGE IS MADE IN WRITING AND SIGNED BY AN OFFICER OF DESA INTERNATIONAL AT ITS HOME OFFICE.

WARRANTY SERVICE

Always specify model and serial numbers when communicating with the factory.

We reserve the right to amend these specifications at any time without notice. The only Warranty applicable is our standard written Warranty. We make no other Warranty, expressed or implied.

A Service Manual is available by writing to the Technical Service Department at:

DESA

INTERNATIONAL

Corporate Headquarters

2701 Industrial Drive

P.O. Box 90004

Bowling Green, Kentucky 42102-9004

U.S.A.