



Waterproof Industrial Touch Panel PC

PLXX-IPCR

USER MANUAL

CONTENTS

Package Contents	02
Safety Instructions	03
FCC & CE Statement	04
Introduction	05
Features	06
Motherboard Specification	07
System Specification	08
Connector Location	10
Mounting Installation	11
Bios setup	12
Driver Installation	28
Contact Information	29

PACKAGE CONTENTS

Please make sure that the items shown below are included in the package. Should an item be missing, please contact the local retailer from which you purchased this product.

1 x Industrial Touch Panel PC

1 x DC in Power adapter

1 x Power cord

1 x CD

SAFETY INSTRUCTIONS

1. **Read Instructions:** All the safety and operating instructions should be read before the equipment is operated.
2. **Retain Instructions:** The safety and operating instructions should be retained for future reference.
3. **Cleaning:** Unplug this equipment from the outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
4. **Water and Moisture:** Do not use this equipment near water.
5. **Ventilation:** The openings on the enclosure are provided for ventilation to ensure reliable operation of the equipment and to protect it from overheating. These openings should never be blocked.
6. **Power Sources:** This equipment should be operated only from the type of power source indicated on the rating label. If you are not sure of the type of power supply, consult your dealer or local power company.
7. **Heed Warnings:** All warnings on the equipment and in the operating instructions should be adhered to.
8. **Object and Liquid Entry:** Never push objects of any kind into this equipment through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never Spill liquid of any kind on the equipment.
9. **Service:** Do not attempt to service this Equipment yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.
10. **Damage Requiring Service:** Unplug this equipment from the outlet and refer

servicing to qualified service personnel under the following conditions: a) if the power cord or plug is damaged; b) if liquid has penetrated into the equipment; c) if the equipment has been exposed to moisture; d) if the equipment does not work well, or you cannot get it to work according to the user's manual; e) if the equipment has been dropped and damaged; f) if the equipment has obvious signs of breakage.

11. Do not leave this equipment in an environment where the storage temperature is below -10° C or above 70° C. It may damage the equipment.

12. Do not open the sealed enclosure / case of equipment. Once enclosure is disassembled without approval, it will lead in abnormal operating of water proof gel. For Guarantee of water proof function, please make sure configuration / peripheral has been confirmed to install before shipping.

FCC

This device complies with Part 15 FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received including interference that may cause undesired operation.

CE

The product(s) described in this manual complies with all applicable European Union (CE) directives if it has a CE marking. For computer systems to remain CE compliant, only CE-compliant parts may be used. Maintaining CE compliance also requires proper cable and cabling techniques.

INTRODUCTION

PLXX-IPCR series is a fanless Intel Celeron / i5 fully IP65 Industrial stainless steel touch Panel PC. With its fanless, robust, waterproof and stainless steel feature, it is an ideal solution for noise-free operating environment. There are 15" to 21.5" size selections for your choice.

Fully IP65 stainless steel touch panel PCs feature a variety of CPU, flexible memory, rich I/O ports and wireless function, It can work with different operating systems for different Application such as industrial automation, food and medical application, etc.

With high quality stainless steel chassis covered around, full IP65 Industrial Panel Computer is completely water proof. Our system is made of industrial grade motherboard, waterproof IP65 connectors, compact design chassis construction, industrial LCD display, user-friendly touch screen, I/O connection for network support and VESA mounting support.

FEATURES

- Intel Celeron/i5 CPU + Intel HM 75 chipset
- Fully IP65 compliant 6 sides stainless steel chassis with hairy brush finish
- Powerful performance but low power consumption under fanless design
- Compact design
- Great 3D graphic performance
- All IP65 waterproof stainless steel connectors including power switch with green LED indication
- Any combination of up to 4 x COM, 2 x GLAN, 4 x USB but totally no more than 4
- 1024 x 768 dpi (15")
- 1280 x 1024 dpi (17", 19")
- 1920 x 1080 dpi (21.5")
- External heat sink on the backside


MOTHERBOARD SPECIFICATION

CPU	Intel ® Core™ Celeron / i5 (up to 2.7GHz)
Chipset	Intel ® HM76
BIOS	AMI 64 Mbit SPI BIOS
Memory	2 x 204-pin SODIMM socket supports DDR3 1066MHz up to 8GB
Display	Controller: Intel ® HD Graphics Interface: 1 x Dual channel 24-bit LVDS, 1 x DVI (DVI-I), 1 x HDMI
Ethernet	1 x Intel ® 82579LM GbE LAN 10/100/1000 Mbps
Audio	Realtek® ALC886 HD Audio CODEC
Storage	2 x SATA 2.0, 1 x mSATA (optional)
Expansion	2 x Mini PCIe
Rear Panel I/O Port	1 x USB2.0 2 x RS232 COM 1x RJ-45 LAN
Power	DC 12V/19V input
Watchdog Timer	Output System reset, Programmable 1 ~ 255 sec/min
Environment	Operating temperature: 0°C ~ 60°C Storage temperature: -20°C ~ 80°C


SYSTEM SPECIFICATION

SIZE	15"	17"	19"	21"
CPU	Intel Core i5 (up to 2.7GHz) / Celeron 827E			
Chipset	Intel HM76 Express			
Memory	1 x DDR III SODIMM, up to 8 GB			
Power Supply	Full IP65 DC in 12V / 19V external power adapter			
Rear I/O Ports	2 x RS232, 1 x GLAN, 1 x USB, 2 x SATA socket			
Expansion	2 x Mini PCIe slot (1 with mSATA function), 1 x SIM socket			
Size/Type	15" TFT (4:3)	17" TFT (4:3)	19" TFT (4:3)	21.5" TFT (16:9)
Resolution	1024 x 768	1280 x 1024	1280 x 1024	1920 x 1080
Colors	16.2M	16.7M	16.7M	16.7M
Luminance (cd/m2)	400	300	250	300
Contrast Ratio	700:1	800:1	1000:1	5000:1
Viewing Angle (H/V°)	145/125	140/125	140/125	178/178
MTBF	50,000hrs			
Touch Screen	5-Wire Resistive			
Installation	VESA mount 100 x 100mm			
Weight	10.5Kg	15.5Kg	15.5Kg	17.5Kg
Operation Temp.	0°C~ 40°C			
Storage Temp.	-10°C ~ 70°C			
Relative Humidity	0% - 95% non-condensing			
OS	Win 7 Pro, Win 8 Pro, Embedded XP, Embedded 7, Embedded 8			

CONNECTOR LOCATION



VESA MOUNTING INSTALLATION




- Step 1:** Screw the VESA mounting plate to the Panel PC
- Step 2:** Screw the VESA mounting bracket to the front of a wall or the front / back of an object dependently
- Step 3:** Slide the VESA mounting plate onto the VESA mounting bracket

BIOS SETUP

Main

The Main menu is the first screen that you will see when you enter the BIOS Setup Utility.



System Date

The date format is <day>, <month>, <date>, <year>. Day displays a day, from Sunday to Saturday. Month displays the month, from January to December. Date displays the date, from 1 to 31. Year displays the year, from 1980 to 2099.

System Time


The time format is <hour>, <minute>, <second>. The time is based on the 24-hour military-time clock. For example, 1 p.m. is 13:00:00. Hour displays hours from 00 to 23. Minute displays minutes from 00 to 59. Second displays seconds from 00 to 59.

Advanced

The Advanced menu allows you to configure your system for basic operation. Some entries are defaults required

by the system board, while others, if enabled, will improve the performance of your system or let you set some features according to your preference.

Important: Setting incorrect field values may cause the system to malfunction.



Launch PXE OpROM


Enables or disables the boot option for legacy network devices.

Launch Storage OpROM

Enables or disables the boot option for legacy mass storage devices with option ROM.

PCI Subsystem Settings

This section is used to configure the PCI subsystem settings



ACPI Power Management Configuration

This section is used to configure the ACPI Power Management.

ACPI Sleep State

Selects the highest ACPI sleep state the system will enter when the Suspend button is pressed.

S1(POS) Enables the Power On Suspend function.

S3(STR) Enables the Suspend to RAM function.

Resume by PME

Enable this field to use the PME signal to wake up the system.

Wake system with fixed time

Enable or disable system wake on alarm event. When enabled, system will wake on the hr::min::sec specified.

Trusted Computing (optional)

This section configures settings relevant to Trusted Computing innovations.

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.		
Advanced		
Configuration		
TPM Support	[Disabled]	Enables or Disables BIOS support for security device. O.S. will not show Security Device. TCG EFI protocol and INT1A interface will not be available.
Current Status Information		
No Security Device Found		

TPM Support

Enables or Disables TPM. O.S. will not show TPM. Resetting the platform is required.

CPU Configuration

This section is used to configure the CPU. It will also display the detected CPU information.


Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.		
Advanced		
CPU Configuration		Disabled for Windows XP
Node0: AMD G-T56N Processor		
Dual Core Running @ 1678 MHz 1350 mV		
Max Speed: 1650 MHz Intended Speed: 1650 MHz		
Limit CPUID Maximum	[Disabled]	

Limit CPUID Maximum

The CPUID instruction of some newer CPUs will return a value greater than 3. The default is Disabled because this problem does not exist in the Windows series operating systems. If you are using an operating system other than Windows, this problem may occur. To avoid this problem, enable this field to limit the return value to 3 or less than 3.

IDE Configuration

This section is used to configure IDE functions.




OnChip SATA Type

This field is used to configure the SATA devices supported by the AMD T56N/T40N.

- Native IDE** This option configures the Serial ATA drives as Parallel ATA storage devices.
- RAID** This option allows you to create RAID on Serial ATA devices.
- AHCI** This option allows the Serial A TA devices to use AHCI (Advanced Host Controller Interface).
- Legacy IDE** This option configures the Serial A TA drives as Legacy IDE storage devices.

USB Configuration

This section is used to configure USB.



Legacy USB Support

- Enabled** Enables legacy USB.
- Auto** Disables support for legacy when no USB devices are connected.
- Disabled** Keeps USB devices available only for EFI applications.

EHCI Hand -off


This is a workaround for OSes that does not support EHCI hand-off. The EHCI ownership change should be claimed by the EHCI driver.

Device reset time-out

Selects the USB mass storage device start unit command timeout.

Super IO Configuration

This section is used to configure the serial port functions.



Case Open Beep

Set this field to Enabled to allow the system to alert you of a chassis intrusion event.

Watchdog

This field is used to enable or disable the Watchdog Timer function.

AC Power Loss

Turns Off When power returns after an AC power failure, the system's power is off. You must press the Power button to power-on the system.

Turns On When power returns after an AC power failure, the system will automatically power-on.

Former-Sts When power returns after an AC power failure, the system will return to the state where you left off before power failure occurs. If the system's power is off when AC power failure occurs, it will remain off when power returns. If the system's power is on when AC power failure occurs, the system will power-on when power returns.

Serial Port 0 Configuration to Serial Port 1

Configuration

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.		
Advanced		
Serial Port 0 Configuration		Select an Optimal Setting for Super IO device
Serial Port Device Settings	[Enabled] IO=3F8h; IRQ=4;	
Change Settings	[Auto]	

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.		
Advanced		
Serial Port 1 Configuration		Select an Optimal Setting for Super IO device
Serial Port Device Settings	[Enabled] IO=2F8h; IRQ=3;	
Change Settings	[Auto]	

Serial Port

Enables or disables the serial port.

Change Settings

Selects the IO/IRQ setting of the I/O device

PC Health Status

This section displays the SIO hardware health monitor.

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.		
Advanced		
PC Health Status		Smart Fan Function
SYSTIN Temperature	: +32 C	
CPUTIN Temperature	: +40 C	
System FAN Speed	: N/A	
CPU FAN Speed	: 4218 RPM	
CPUVCore	: +1.384V	
+5V	: +4.872 V	
+3.3V	: +3.360V	
CPUVNB	: +0.960 V	
VDIMM	: +1.544 V	
+12V	: +12.335 V	
3VSB	: +3.344 V	
VBAT	: +3.088 V	
		<input checked="" type="checkbox"/> <input checked="" type="checkbox"/> <input checked="" type="checkbox"/> Select Screen <input checked="" type="checkbox"/> <input checked="" type="checkbox"/> <input checked="" type="checkbox"/> Select Item Enter: Select +/-: Change Opt

JMB36X AT A Controller Configuration

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.		
Advanced		
CF Card	Not Present	Select an operative mode for ATA controller.
JMB 368 ATA Controller	[IDE Mode]	
		[F4] Select Screen [F5] Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.		

Chipset

Configures relevant chipset functions.

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.					
Main	Advanced	Chipset	Boot	Security	Save & Exit
▶ North Bridge ▶ North Bridge LVDS Config Select ▶ South Bridge					North Parameters
					[F4] Select Screen [F5] Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.					

North Bridge Configuration

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.	
Chipset	
<p>North Bridge Configuration</p> <p>Memory Information Memory Clock: 533 MHz Total Memory: 2032 MB (DDR3)</p> <ul style="list-style-type: none"> ▶ GFX Configuration ▶ Memory Configuration ▶ Node 0 information 	<p>PCI Express Configuration settings.</p> <hr/> <p> <input type="checkbox"/> Select Screen <input type="checkbox"/> Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit </p>
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.	


GFX Configuration

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.	
Chipset	
<p>GFX Configuration</p> <p>Primary Video Device [IGD Video] NB GPP Core Config [GPP_Core_x4 x4]</p>	<p>Select primary device that BIOS will use for output.</p> <hr/> <p> <input type="checkbox"/> Select Screen <input type="checkbox"/> Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit </p>
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.	

NB GPP Core Config

Selects the NB GPP Core configuration.


North Bridge LVDS Config Select




LVDS

This field is used to enable or disable the LVDS Panel

South Bridge



Boot



Setup Prompt Timeout

Selects the number of seconds to wait for the setup activation key. 65535(0xFFFF) denotes indefinite waiting.

Bootup NumLock State

This allows you to determine the default state of the numeric keypad. By default, the system boots up with NumLock on wherein the function of the numeric keypad is the number keys. When set to Off, the function of the numeric keypad is the arrow keys.

Quiet Boot

Enables or disables the quiet boot function.

Fast Boot

Enables or disables boot with initialization of a minimal set of devices required to launch active boot option. Has no effect for BBS boot options.

GateA20 Active

Upon Request- GA20 can be disabled using BIOS services. Do not allow disabling GA20; this option is useful when any RT code is executed above 1MB.

Option ROM Messages

Set display mode for option ROM.

Interrupt 19 Capture


Enabled: Allows option ROMs to trap Int 19.

Disabled:

CSM Support

Enabled/ disabled CSM support. If auto is selected, based on OS, CSM will be enabled/ disabled automatically.

Save & Exit



Save Changes and Reset

To save the changes, select this field and then press <Enter>. A dialog box will appear. Select Yes to reset the system after saving all changes made.

Discard Changes and Reset

To discard the changes, select this field and then press <Enter>. A dialog box will appear. Select Yes to reset the system setup without saving any changes.

Save Changes

Save the changes done so far to any of the setup options.

Discard Changes

Discard the changes done so far to any of the setup options.

Restore Defaults

To restore and load the optimized default values, select this field and then press <Enter>. A dialog box will appear. Select Yes to restore the default values of all the setup options .

Save as User Defaults

To save changes done so far as user default, select this field and then press <Enter>. A dialog box will appear. Select Yes to save values as user default.

Restore User Defaults

To restore user default to all the setup options, select this field and then press <Enter>. A dialog box will appear. Select Yes to restore user default.

Updating the BIOS

To update the BIOS, you will need the new BIOS file and a flash utility, AFUDOS.EXE. Please contact technical support or your sales representative for the files.

To execute the utility, type:

A:> AFUDOS BIOS_File_Name /b /p /n then press <Enter>.

```

C:\AFU\AFUDOS>afudos filename /B /P /N
-----+-----
                AMI Firmware Update Utility(APTIO) v2.25
                Copyright (C)2008 American Megatrends Inc. All Rights Reserved.
-----+-----

Reading file ..... done
Erasing flash ..... done
Writing flash ..... done
Verifying flash ..... done
Erasing BootBlock ..... done
Writing BootBlock ..... done
Verifying BootBlock ..... done

C:\AFU\AFUDOS>

```

The PLXX-IPCR Series comes with an AutoRun CD-ROM that contains all drivers and utilities that can help you to install the driver automatically.

Insert the driver CD, the driver CD-title will auto start and show the installation guide. If not, please follow the sequence below to install the drivers.

Step 1 – Install Chipset Driver

1. Click on the STEP1-CHIPSET folder and select the OS folder
2. Double click on the .exe file located in each OS folder
3. Follow the instructions that the window shows
4. The system will help you install the driver automatically

Step 2 – Install VGA Driver

1. Click on the STEP2-VGA folder and select the OS folder
2. Double click on the Setup.exe file located in each OS folder
3. Follow the instructions that the window shows
4. The system will help you install the driver automatically

Step 3 –Install LAN Driver

1. Click on the STEP3-LAN folder and select the OS folder
2. Double click on the .exe file located in each OS folder
3. Follow the instructions that the window shows
4. The system will help you install the driver automatically

Step 4 –Install Touch Driver (Optional)

1. Click on the STEP4-TOUCH (Option) folder and select the OS folder
2. Double click on the .exe located in each OS folder
3. Follow the instructions that the window shows
4. The system will help you install the driver automatically

Step 5 –Install Rapid Storage Driver (Optional)

1. Click on the STEP5-RAPID STORAGE (Option) folder and double click on the setup.exe
 2. Follow the instructions that the window shows
 3. The system will help you install the driver automatically
-

CONTACT INFORMATION

If you have any questions, please contact us.

Phone: +1 802 861 2300

Email: support@logicsupply.com