

# MICROSmart

This sheet provides brief operating instructions of the MicroSmart I/O modules. For details, see the MicroSmart User's Manual.

- FC4A-N16B3, FC4A-N32B3, FC4A-T16K3
- FC4A-T16S3, FC4A-T32K3, FC4A-T32S3
- FC4A-M24BR2, FC4A-L03A1, FC4A-L03AP1
- FC4A-J2A1, FC4A-K1A1

## Wiring Example

Use an IEC 60127-approved fuse on the output circuit to meet voltage and current requirements. For details of output module specifications, see the MicroSmart User's Manual.


The following symbols represent a fuse and a load.




Terminal numbers are indicated on the module.

### FC4A-N16B3

#### Source Input Wiring




#### Sink Input Wiring




### FC4A-N32B3


#### Source Input Wiring




#### Sink Input Wiring




#### Sink Input Wiring




#### Sink Input Wiring




### FC4A-T16K3




### FC4A-T16S3




### FC4A-T32K3




### FC4A-T32S3




### FC4A-T32S3



### FC4A-T32S3



### FC4A-M24BR2




# MICROSmart

This sheet provides brief operating instructions of the MicroSmart programmable controller. For details, see the MicroSmart User's Manual.

FC4A-C10R2, FC4A-C16R2, FC4A-C24R2

## Name & Function




## Assembling Modules


Remove the expansion connector Seal from the 24-I/O type CPU module. With the expansion connectors aligned correctly, press the CPU module and I/O module together, and push in the unlatch button to attach the modules together firmly.

## Installation in Control Panel & Mounting Direction

When installing the MicroSmart in a control panel, take the convenience of operation and maintenance, and resistance against environments into consideration.




### Correct Mounting Direction




## Dimensions

FC4A-C24R2



## Applicable Ferrule Dimensions (mm)

To crimp the ferrules shown below, use a special crimping tool (CRIMPFOX ZA 3).



(AI 1-8 RD, AI 1.5-8 BK) (AI-TWIN 2×0.75-8 GY)

( ) indicates the Type No. of Phoenix Contact.

## Recommended Screwdriver

When wiring the Phoenix Contact terminal block, use the recommended screwdriver.

(Phoenix Contact Type No.: SZS 0.6×3.5)

## Safety Precautions


Special expertise is required to use the MicroSmart.

- Read this instruction sheet and the user's manual to make sure of correct operation before starting installation, wiring, operation, maintenance, and inspection of the MicroSmart. Keep this instruction sheet at the end user.
- All MicroSmart modules are manufactured under IDEC's rigorous quality control system, but users must add a backup or failsafe provision to the control system using the MicroSmart in applications where heavy damage or personal injury may be caused in case the MicroSmart should fail.
- Install the MicroSmart according to instructions described in this instruction sheet and the user's manual. Improper installation will result in falling, failure, or malfunction of the MicroSmart.
- Make sure that the operating conditions are as described in the user's manual. If you are uncertain about the specifications, contact IDEC in advance.
- In this instruction sheet, safety precautions are categorized in order of importance to Warning and Caution:

## Warning

(Warning notices are used to emphasize that improper operation may cause severe personal injury or death.)

- Turn power off to the MicroSmart before starting installation, removal, wiring, maintenance, and inspection on the MicroSmart.
- Failure to turn power off may cause electrical shocks or fire hazard.




Note: I/O modules cannot be mounted on the 10- and 16-I/O type CPU modules.

## Mounting Modules

### [DIN Rail Mounting]


Use a 35-mm-wide DIN rail and BNL6 mounting clips to secure the modules.





### [Direct Mounting]

Use M4 mounting screws (6 mm or 8 mm long).


### FC4A-C24R2 and Expansion I/O Modules



### FC4A-C10R2 and FC4A-C16R2



### FC4A-C10R2 and FC4A-C16R2




\* 8.5 mm when the clamp is pulled out.


Dimensions in mm.

## Wiring


### DC Sink Input Wiring



### DC Source Input Wiring




### AC Power and Relay Output Wiring



outside the MicroSmart. If such a circuit is configured inside the MicroSmart, failure of the MicroSmart may cause disorder of the control system, damage, or accidents.

- This equipment is suitable for use in Class I, Division 2, Groups A, B, C, D or non-hazardous locations only.
- Warning - Explosion Hazard - Substitution of components may impair suitability for Class I, Division 2.
- Warning - Explosion Hazard - Do not disconnect equipment unless power has been switched off or the area is known to be non-hazardous.



(Caution notices are used where inattention might cause personal injury or damage to equipment.)

- The MicroSmart is designed for installation in equipment. Do not install the MicroSmart outside equipment.
- Install the MicroSmart in environments described in the user's manual. If the MicroSmart is used in places where the MicroSmart is subjected to high-temperature, high-humidity, condensation, corrosive gases, excessive vibrations, and excessive shocks, then electrical shocks, fire hazard, or malfunction will result.
- The environment for using the MicroSmart is "Pollution degree 2."
- Prevent metal fragments and pieces of wire from dropping inside the MicroSmart housing. Ingress of such fragments and chips may cause fire hazard, damage, or malfunction.
- Use wires of a proper size to meet voltage and current requirements. Tighten terminal screws to a proper tightening torque of 0.5 N-m.
- Use an IEC60127-approved fuse on the power line and output circuit to meet voltage and current requirements. (Recommended fuse: Littelfuse 5x20mm slow-blow type 218000 series/Type T) This is required when exporting equipment containing MicroSmart to Europe.
- Use an EU-approved circuit breaker. This is required when exporting equipment containing MicroSmart to Europe.
- If relays or transistors in the MicroSmart output modules should fail, outputs may remain on or off. For output signals which may cause heavy accidents, provide a monitor circuit outside of the MicroSmart.
- Use the sensor power supply only for supplying power to sensors connected to the MicroSmart.
- Do not disassemble, repair, or modify the MicroSmart modules.

**Operating Instructions**

B-543B

**MICROSmart**

This sheet provides brief operating instructions of the MicroSmart optional cartridges. For details, see the MicroSmart User's Manual.

Memory Cartridge (FC4A-PM32) and Clock Cartridge (FC4A-PT1)

**● Function****Memory Cartridge**

The memory cartridge is used to store a user program. When a memory cartridge is installed on the CPU module, the user program stored on the memory cartridge has priority over the user program in the CPU module EEPROM.

Memory Cartridge	User Program Execution
Installed	The user program stored on the memory cartridge is executed.
Not installed	The user program in the CPU module EEPROM is executed.

**Clock Cartridge**



The clock cartridge makes it possible to use the calendar/clock functions in your user program. For details, see the MicroSmart User's Manual.

Notes: Before using the clock cartridge for the first time, set the date and time in the clock cartridge using WindLDR.


**● Installing a Memory or Clock Cartridge**

Remove the dummy cartridge from the CPU module. Make sure of correct orientation and install a memory or clock cartridge into the cartridge connector securely.

The protruding portion should be bottom.

**● Removing the Memory or Clock Cartridge**

Hold the ribs on top and bottom of the cartridge, and pull the cartridge straight out.

**Caution**

Before installing or removing a memory or clock cartridge, turn off the power to the CPU module. If a memory or clock cartridge is installed or removed while the CPU module is powered up, the cartridge may be damaged.

**Warning**

This equipment is suitable for use in Class I, Division 2, Groups A, B, C, D or non-hazardous locations only.

Warning - Explosion Hazard - Substitution of components may impair suitability for Class I, Division 2.


Warning - Explosion Hazard - Do not disconnect equipment unless power has been switched off or the area is known to be non-hazardous.

# MICROSmart

This sheet provides brief operating instructions of the MicroSmart programmable controller. For details, see the MicroSmart User's Manual.

FC4A-D20K3, FC4A-D20S3, FC4A-D20RK1,  
 FC4A-D20RS1, FC4A-D40K3, FC4A-D40S3

## Name & Function




## Assembling

### [ I/O Modules ]

Remove the expansion connector seal (\*) from the CPU module. With the expansion connectors aligned correctly, press the CPU module and I/O module together, and push in the unlatch button to attach the modules together firmly.


### [ Communication Modules ]

Remove the communication connector cover from the CPU module. With the communication connectors aligned correctly, press the CPU module and communication module together, and push in the unlatch button to attach the modules together firmly.




## Mounting Modules

### [ DIN Rail Mounting ]




### [ Direct Mounting ]

Use M4 mounting screws (6 mm or 8 mm long).  
 FC4A-D20K3 FC4A-D20RK1  
 FC4A-D20S3 FC4A-D20RS1  
 FC4A-D40K3, FC4A-D40S3




## Installation in Control Panel & Mounting Direction




When installing the MicroSmart in a control panel, take the convenience of operation and maintenance, and resistance against environments into consideration.



## Correct Mounting Direction











## Dimensions



\* 8.5 mm when the clamp is pulled out.  
 Dimensions in mm.


## I/O Wiring



The following symbols represent a fuse and a load.  
 Fuse Load

## Applicable Ferrule Dimensions (mm)

To crimp the ferrules shown below, use a special crimping tool (CRIMPFOX ZA 3).



For 1-cable connection For 2-cable connection  
 (AI 1-8 RD, AI 1.5-8 BK) (AI-TWIN 2 x 0.75-8 GY,  
 (AI 0.5-8 WH) (AI-TWIN 2 x 0.5-8 WH)  
 ( ) indicates the Type No. of Phoenix Contact.

## Recommended Screwdriver

When wiring the Phoenix Contact terminal block, use the recommended screwdriver.  
 (Phoenix Contact Type No.: SZS 0.6x3.5; SZS 0.4x2.5)

## Safety Precautions

- Special expertise is required to use the MicroSmart.
- Read this instruction sheet and the user's manual to make sure of correct operation before starting installation, wiring, operation, maintenance, and inspection of the MicroSmart.
- Keep this instruction sheet at the end user.
- All MicroSmart modules are manufactured under IDEC's rigorous quality control system, but users must add a backup or failsafe provision to the control system using the MicroSmart in applications where heavy damage or personal injury may be caused in case the MicroSmart should fail.
- Install the MicroSmart according to instructions described in this instruction sheet and the user's manual. Improper installation will result in falling, failure, or malfunction of the MicroSmart.
- Make sure that the operating conditions are as described in the user's manual. If you are uncertain about the specifications, contact IDEC in advance.
- In this instruction sheet, safety precautions are categorized in order of importance to Warning and Caution:

### Warning

- (Warning notices are used to emphasize that improper operation may cause severe personal injury or death.)
- Turn off the power to the MicroSmart before starting installation, removal, wiring, maintenance, and inspection on the MicroSmart. Failure to turn power off may cause electrical shocks or fire hazard.
- Emergency stop and interlocking circuits must be configured outside the MicroSmart. If such a circuit is configured inside the MicroSmart, failure of the MicroSmart may cause disorder of the control system, damage, or accidents.
- This equipment is suitable for use in Class 1, Division 2, Groups A, B, C, D or non-hazardous locations only.
- Warning - Explosion Hazard - Substitution of components may impair suitability for Class 1, Division 2.
- Warning - Explosion Hazard - Do not disconnect equipment unless power has been switched off or the area is known to be non-hazardous.

### Caution

- (Caution notices are used where installation might cause personal injury or damage to equipment.)
- The MicroSmart is designed for installation in equipment. Do not install the MicroSmart outside equipment.
- Install the MicroSmart in environments described in the user's manual. If the MicroSmart is used in places where the MicroSmart is subjected to high-temperature, high-humidity, condensation, corrosive gases, excessive vibrations, and excessive shocks, then electrical shocks, fire hazard, or malfunction will result.
- The environment for using the MicroSmart is "Pollution degree 2."
- Prevent metal fragments and pieces of wire from dropping inside the MicroSmart housing. Ingress of such fragments and chips may cause fire hazard, damage, or malfunction.
- Use wires of a proper size to meet voltage and current requirements. Tighten terminal screws to a proper tightening torque of 0.5 N-m (power supply terminals) or 0.22 to 0.25 N-m (I/O terminals)
- Use an IEC60127-approved fuse on the power line and output circuit to meet voltage and current requirements.  
 (Recommended fuse: Littelfuse 5x20mm slow-blow type 218000 series/Type T) This is required when exporting equipment containing MicroSmart to Europe.
- Use an EU-approved circuit breaker. This is required when exporting equipment containing MicroSmart to Europe.
- If relays or transistors in the MicroSmart output modules should fail, outputs may remain on or off. For output signals which may cause heavy accidents, provide a monitor circuit outside of the MicroSmart.
- Use the sensor power supply only for supplying power to sensors connected to the MicroSmart.
- Do not disassemble, repair, or modify the MicroSmart modules.


INSTRUCTION SHEET



This sheet provides brief operating instructions of the MicroSmart programmable controller. For details, see the MicroSmart User's Manual.


FC5A-C10R2, FC5A-C16R2, FC5A-C24R2 (AC power supply)  
FC5A-C10R2C, FC5A-C16R2C, FC5A-C24R2C (DC power supply)

Name & Function



Assembling Modules

Remove the expansion connector Seal from the 24-I/O type CPU module. With the expansion connectors aligned correctly, press the CPU module and I/O module together, and push in the unlatch button to attach the modules together firmly.




Note: I/O modules cannot be mounted on the 10- and 16-I/O type CPU modules.

Mounting Modules

[DIN Rail Mounting]


Use a 35-mm-wide DIN rail and BNL6 mounting clips to secure the modules.




[Direct Mounting]

Use M4 mounting screws (6 mm or 8 mm long).

FC5A-C24R2, -C24R2C




FC5A-C10R2, -C16R2, and -C10R2C, -C16R2C




Installation in Control Panel & Mounting Direction

When installing the MicroSmart in a control panel, take the convenience of operation and maintenance, and resistance against environments into consideration.




Correct Mounting Direction (at 55 °C or below)




Dimensions

FC5A-C24R2, C24R2C



FC5A-C10R2, -C16R2, and -C10R2C -C16R2C




\* 8.5 mm when the clamp is pulled out.

Dimensions in mm.


Wiring

DC Sink Input Wiring DC Source Input Wiring




AC power supply type: Support of sensor power which is A-section of above figure is able to use instead of external power. DC power supply type: No support of sensor power. Therefore external power is required.


DC Power Wiring



AC Power Wiring




Relay Output Wiring



Applicable Ferrule Dimensions (mm)

To crimp the ferrules shown below, use a special crimping tool (CRIMPFOX ZA 3).

For 1-cable connection For 2-cable connection



(AI 1-8 RD, AI 1.5-8 BK) (AI-TWIN 2 × 0.75-8 GY)

( ) indicates the Type No. of Phoenix Contact.

Recommended Screwdriver

When wiring the Phoenix Contact terminal block, use the recommended screwdriver.

(Phoenix Contact Type No.: SZS 0.6×3.5)

SAFETY NOTE

Special expertise is required to use the MicroSmart.

- Read this instruction sheet and the user's manual to make sure of correct operation before starting installation, wiring, operation, maintenance, and inspection of the MicroSmart. Keep this instruction sheet at the end user.
- All MicroSmart modules are manufactured under IDEC's rigorous quality control system, but users must add a backup or failsafe provision to the control system using the MicroSmart in applications where heavy damage or personal injury may be caused in case the MicroSmart should fail.
- Install the MicroSmart according to instructions described in this instruction sheet and the user's manual. Improper installation will result in falling, failure, or malfunction of the MicroSmart.
- Make sure that the operating conditions are as described in the user's manual. If you are uncertain about the specifications, contact IDEC in advance.
- In this instruction sheet, safety precautions are categorized in order of importance to Warning and Caution:

WARNING

(Warning notices are used to emphasize that improper operation may cause severe personal injury or death.)

- Turn power off to the MicroSmart before starting installation, removal, wiring, maintenance, and inspection on the MicroSmart.
- Failure to turn power off may cause electrical shocks or fire hazard. Emergency stop and interlocking circuits must be configured outside the MicroSmart. If such a circuit is configured inside the MicroSmart, failure of the MicroSmart may cause disorder of the control system, damage, or accidents.
- This equipment is suitable for use in Class I, Division 2, Groups A, B, C, D or non-hazardous locations only.
- Warning - Explosion Hazard - Substitution of components may impair suitability for Class I, Division 2.
- Warning - Explosion Hazard - Do not disconnect equipment unless power has been switched off or the area is known to be non-hazardous.

CAUTION

(Caution notices are used where inattention might cause personal injury or damage to equipment.)

- The MicroSmart is designed for installation in equipment. Do not install the MicroSmart outside equipment.
- Install the MicroSmart in environments described in the user's manual. If the MicroSmart is used in places where the MicroSmart is subjected to high-temperature, high-humidity, condensation, corrosive gases, excessive vibrations, and excessive shocks, then electrical shocks, fire hazard, or malfunction will result.
- The environment for using the MicroSmart is "Pollution degree 2."
- Prevent metal fragments and pieces of wire from dropping inside the MicroSmart housing. Ingress of such fragments and chips may cause fire hazard, damage, or malfunction.
- Use wires of a proper size to meet voltage and current requirements. Tighten terminal screws to a proper tightening torque of 0.5 N·m.
- Use an IEC60127-approved fuse on the power line and output circuit to meet voltage and current requirements. (Recommended fuse: Littelfuse 5x20mm slow-blow type 218000 series/Type T) This is required when exporting equipment containing MicroSmart to Europe.
- Use an EU-approved circuit breaker. This is required when exporting equipment containing MicroSmart to Europe.
- If relays or transistors in the MicroSmart output modules should fail, outputs may remain on or off. For output signals which may cause heavy accidents, provide a monitor circuit outside of the MicroSmart.
- Use the sensor power supply only for supplying power to sensors connected to the MicroSmart.
- Do not disassemble, repair, or modify the MicroSmart modules.

INSTRUCTION SHEET




FC5A Series

This sheet provides brief operating instructions of the MicroSmart programmable controller. For details, see the MicroSmart User's Manual(FC9Y-B927).

1 Type

FC5A-D16RK1, FC5A-D16RS1  
FC5A-D32K3, FC5A-D32S3

2 Name & Function





3 Assembling

[ I/O Modules ]

Remove the expansion connector seal (\*) from the CPU module. With the expansion connectors aligned correctly, press the CPU module and I/O module together, and push in the unlatch button to attach the modules together firmly.

[ Communication Modules ]


Remove the communication connector cover from the CPU module. With the communication connectors aligned correctly, press the CPU module and communication module together, and push in the unlatch button to attach the modules together firmly.



4 Mounting Modules

[ DIN Rail Mounting ]


Use a 35-mm-wide DIN rail and BNL6 mounting clips to secure the modules.



[ Direct Mounting ]


Use optional direct mounting strip FC4A-PSP1P and M4 mounting screws (6 mm or 8 mm long).

FC5A-D16RK1, FC5A-D16RS1  
FC5A-D32K3, FC5A-D32S3




5 Installation in Control Panel & Mounting Direction



When installing the MicroSmart in a control panel, take the convenience of operation and maintenance, and resistance against environments into consideration.



Always mount the slim type CPU modules horizontally on a vertical plane as shown above. Any other mounting directions are not allowed.



6 Dimensions




\* 8.5 mm when the clamp is pulled out.

Dimensions in mm.

7 Applicable Ferrule Dimensions

To crimp the ferrules shown below, use a special crimping tool (CRIMPFOX ZA3).




8 Recommended Screwdriver

When wiring the Phoenix Contact terminal block, use the recommended screwdriver.


(Phoenix Contact Type No. : SZS 0.6x3.5, SZS 0.4x2.5)

9 I/O Wiring


FC5A-D16RK1




FC5A-D16RS1




FC5A-D32K3




Right side (CN2)




FC4A-D32S3



Right side (CN2)



The following symbols represent a fuse and a load.



COM, COM(-), COM(+), COM1, COM2, and COM3 terminals are not interconnected. COM terminals are interconnected.

10 Safety Precautions

Special expertise is required to use the MicroSmart.

- Read this instruction sheet and the user's manual to make sure of correct operation before starting installation, wiring, operation, maintenance, and inspection of the MicroSmart. Keep this instruction sheet at the end user.
- All MicroSmart modules are manufactured under IDEC's rigorous quality control system, but users must add a backup or failsafe provision to the control system using the MicroSmart in applications where heavy damage or personal injury may be caused in case the MicroSmart should fail.
- Install the MicroSmart according to instructions described in this instruction sheet and the user's manual. Improper installation will result in falling, failure, or malfunction of the MicroSmart.
- Make sure that the operating conditions are as described in the user's manual. If you are uncertain about the specifications, contact IDEC in advance.
- In this instruction sheet, safety precautions are categorized in order of importance to Warning and Caution:

WARNING

(Warning notices are used to emphasize that improper operation may cause severe personal injury or death.)

- Turn off the power to the MicroSmart before starting installation, removal, wiring, maintenance, and inspection on the MicroSmart. Failure to turn power off may cause electrical shocks or fire hazard.
- Emergency stop and interlocking circuits must be configured outside the MicroSmart. If such a circuit is configured inside the MicroSmart, failure of the MicroSmart may cause disorder of the control system, damage, or accidents.
- This equipment is suitable for use in Class I, Division 2, Groups A, B, C, D or non-hazardous locations only.
- Warning - Explosion Hazard - Substitution of components may impair suitability for Class I, Division 2.
- Warning - Explosion Hazard - Do not disconnect equipment unless power has been switched off or the area is known to be non-hazardous.

CAUTION


(Caution notices are used where inattention might cause personal injury or damage to equipment.)

- The MicroSmart is designed for installation in equipment. Do not install the MicroSmart outside equipment.
- Install the MicroSmart in environments described in the user's manual. If the MicroSmart is used in places where the MicroSmart is subjected to high-temperature, high-humidity, condensation, corrosive gases, excessive vibrations, and excessive shocks, then electrical shocks, fire hazard, or malfunction will result.
- The environment for using the MicroSmart is "Pollution degree 2."
- Prevent metal fragments and pieces of wire from dropping inside the MicroSmart housing. Ingress of such fragments and chips may cause fire hazard, damage, or malfunction.
- Use wires of a proper size to meet voltage and current requirements. Tighten terminal screws to a proper tightening torque of 0.5 N·m (power supply terminals) or 0.22 to 0.25 N·m (I/O terminals).
- Use an IEC60127-approved fuse on the power line and output circuit to meet voltage and current requirements. (Recommended fuse: Littelfuse 5x20mm slow-blow type 218000 series/Type T) This is required when exporting equipment containing MicroSmart to Europe.
- Use an EU-approved circuit breaker. This is required when exporting equipment containing MicroSmart to Europe.
- If relays or transistors in the MicroSmart output modules should fail, outputs may remain on or off. For output signals which may cause heavy accidents, provide a monitor circuit outside of the MicroSmart.
- Do not disassemble, repair, or modify the MicroSmart modules.

**32-point Transistor Sink Output Module**

**FC3A-T32K4**

Terminal No. are indicated on the female connector at the cable end.




**FC3A-T32K5**

Terminal No. represent the pin arrangement of the male connector on the module as shown in the diagram.

Note: Be sure to connect two COM(-) terminals and two +V terminals, respectively.


Note: Do not connect any wiring to NC (no connection) terminals.



**2-channel Analog Output Module**

**FC3A-DA1221**

Analog output module can select an output signal range using the rotary switch on the side of the module.




Note: After changing the rotary switch setting while the CPU module is powered up, press the communication enable button on the CPU module for more than 4 seconds until the ERROR LED blinks once; then the new output signal range takes effect.


**Terminal Arrangement**

Terminal No. are indicated on the terminal label on the screw terminal block. Use a two-core twisted pair shielded cable with a minimum core diameter of 0.5mm. Connect the shield wire to a proper frame ground (FG). Ten COM (GND) terminals are connected together internally.

When using voltage output (with the rotary switch set to 0)




When using current output (with the rotary switch set to 4)



**Assembling and Disassembling Modules**


**Assembling Modules**

Place the expansion connectors of two modules together and press the modules together until the latch clicks to combine the modules securely. Improper connection between modules will cause malfunction or damage when power is turned on. Attach end plates to both sides of the module row.



**Disassembling Modules**

Keep the blue release button on top of the module depressed to disengage the latch, and pull the modules apart.




For details about assembling and disassembling modules, see the OpenNet Controller user's manual.

Note: Turn power off to the OpenNet Controller before assembling or disassembling, otherwise modules may be damaged.


**Mounting Modules**

For details about mounting and removing modules, see the OpenNet Controller user's manual. Use the 35-mm-wide DIN rail for mounting the modules, and secure the modules using the BNL6 mounting clips on both sides of the module row.




**Mounting Direction**

Mount the OpenNet Controller modules horizontally on a vertical plane as shown below. Do not mount the modules vertically or upside down.



\*1: When the ambient temperature is 40°C or below, the modules can also be mounted upright.


**Dimensions (mm)**



\*2: Dimension when using the recommended mounting clip (BNL6).  
 \*3: Dimension when the latch is pulled out.  
 \*4: Dimension when using the recommended DIN rail (BAA1000).

**Installation in Control Panel**

When installing the OpenNet Controller modules in a control panel, take the convenience of operation and maintenance, and resistance against environments into consideration.



**Applicable Ferrule Dimensions (mm)**

To crimp the ferrules shown below, use special crimping tool (CRIMPFOX UDG).

For 1-cable connection	For 2-cable connection
5.0	8.0
6.0	7.0
7.0	8.0

(AI 1-8 RD) (AI-TWIN 2X1-8 RD)

( ) indicates the Type No. of Phoenix Contact.

**Recommended Screwdriver**

When wiring the terminal block, use the recommended screwdriver.  
 (Phoenix Contact's Type No.: SZ50, 6x3, 5)

**Safety Precautions**

**Special expertise is required to use the OpenNet Controller.**

- Read this instruction sheet and the user's manual to make sure of correct operation before starting installation, wiring, operation, maintenance, and inspection of the OpenNet Controller. Keep this instruction sheet at the end user.
- All OpenNet Controller modules are manufactured under IDEC's rigorous quality control system, but users must add a backup or failsafe provision to the control system using the OpenNet Controller in applications where heavy damage or personal injury may be caused in case the OpenNet Controller should fail.
- Install the OpenNet Controller according to instructions described in this instruction sheet and the user's manual. Improper installation will result in falling, failure, or malfunction of the OpenNet Controller.
- Make sure that the operating conditions are as described in the user's manual. If you are uncertain about the specifications, contact IDEC in advance.
- In this instruction sheet, safety precautions are categorized in order of importance to Warning and Caution:

**Warning**

Warning notices are used to emphasize that improper operation may cause severe personal injury or death.

**Caution**

Caution notices are used where inattention might cause personal injury or damage to equipment.

**Warning**

- Turn power off to the OpenNet Controller before starting installation, removal, wiring, maintenance, and inspection on the OpenNet Controller. Failure to turn power off may cause electrical shocks or fire hazard.
- Emergency stop and interlocking circuits must be configured outside the OpenNet Controller. If such a circuit is configured inside the OpenNet Controller, failure of the OpenNet Controller may cause disorder of the control system, damage, or accidents.

**Caution**

The OpenNet Controller is designed for installation in equipment. Do not install the OpenNet Controller outside equipment.

- Install the OpenNet Controller in environments described in the user's manual. If the OpenNet Controller is used in places where the OpenNet Controller is subjected to high-temperature, high-humidity, condensation, corrosive gases, excessive vibrations, and excessive shocks, then electrical shocks, fire hazard, or malfunction will result.
- The environment for using the OpenNet Controller is "Pollution degree 2." The pollution degree refers to a degree of pollution in the micro-environment which determines the effect of pollution on the insulation. Pollution degree 2 defines "Only non-conductive pollution occurs except that occasionally a temporary conductivity caused by condensation is to be expected. Do not use the OpenNet Controller in environments inferior to the state specified in IEC60529-1."
- The DC power applicable to the OpenNet Controller is "PS2." PS2 refers to a power supply that has a momentary power failure duration of 10 msec at the maximum and an interval between power failures of 1 second at the minimum.
- Prevent metal fragments and pieces of wire from dropping inside the OpenNet Controller housing. Ingress of such fragments and chips may cause fire hazard, damage, or malfunction.
- Use wires of a proper size to meet voltage and current requirements. Tighten terminal screws to a proper tightening torque of 0.5 to 0.6 N·m.
- Use an IEC60127-approved fuse on the power line and output circuit to meet voltage and current requirements. (Recommended fuse: Littelfuse 5x20mm slow-blow type 218000 series/Type T) This is required when exporting equipment containing OpenNet Controller to Europe.
- Use an EU-approved circuit breaker. This is required when exporting equipment containing OpenNet Controller to Europe.
- If relays or transistors in the OpenNet Controller output modules should fail, outputs may remain on or off. For output signals which may cause heavy accidents, provide a monitor circuit outside of the OpenNet Controller.
- Do not disassemble, repair, or modify the OpenNet Controller modules.