



User Manual

Eproms RKM - RKE

Microface E 24VAC

&

Hiromatic E

INDEX

1	INTRODUCTION.....	2
1.1	FOREWORD.....	2
2	HARDWARE	2
2.1	MICROFACE EVOLUTION 24V AC	2
2.2	LCD DISPLAY	3
2.3	EPROM.....	4
2.4	PTC TEMPERATURE SENSOR.....	4
2.5	HIROMATIC E	5
2.5.1	<i>Hiromatic E direct Connection to Microface.....</i>	<i>5</i>
2.5.2	<i>Hiromatic E Backside View, Jumpers and Eprom Position.....</i>	<i>6</i>
2.6	POWER SUPPLY MODULE FOR HIROMATIC (24V ONLY)	7
2.6.1	<i>PSM Hardware</i>	<i>7</i>
2.6.2	<i>PSM Connection (24V only).....</i>	<i>7</i>
2.7	HIROBUS CABLES AND OTHER CONNECTION CABLES.....	8
2.8	HARDWARE, TECHNICAL SPECIFICATION.....	9
2.9	SPARE PARTS LIST.....	9
3	SOFTWARE	10
3.1	THE LCD DISPLAY	10
3.1.1	<i>How to move through the Values/Parameters of the LCD Display.....</i>	<i>11</i>
3.1.2	<i>How to change Parameters.....</i>	<i>11</i>
3.1.3	<i>How to reset Alarms or Warnings.....</i>	<i>11</i>
3.1.4	<i>Tricks.....</i>	<i>11</i>
3.2	THE LCD PARAMETERS.....	12
3.2.1	<i>The Warnings and Alarms table.....</i>	<i>13</i>
3.3	HIROMATIC E	14
3.3.1	<i>Layout.....</i>	<i>14</i>
3.3.2	<i>Hiromatic E Windows</i>	<i>15</i>
4	CONNECTION GUIDE.....	16

1 Introduction

1.1 Foreword

This User Manual describes the Microface E Control System. It contains information concerning the architectures of the control systems.

In the following sections first the Hardware, and later the Software (Firmware) are explained in detail.

In case of Remote control system only the SNMP is allowed from Microface E and, the related TRAPS identification, are available on SNMP Control manual cod 272703 rev. 12.12.05 or higher

2 Hardware

2.1 Microface Evolution 24V AC

The Microface Evolution is a microprocessor-based electronic card, which is able to manage the devices and the sensors installed in the unit

Microface E is installed in the electrical panel of indoor-units together with a User-interface module ("LCD Display"), which allows to read/set/reset values, parameters and alarms.

To get access to the Microface E connections and Jumpers the LCD Display (if present) has to be removed from its 4 mounting pins.

As the Microface E is the "Heart" of the System, which controls all Functions of the Unit, the Jumpers have to be set in order to set-up the control board according to the requested functions; all jumpers are normally set in the factory as described on the table below.

The meaning of Input and Outputs are available at Connection Guide chapter included inside this manual




Figure 1 – Microface E 24V AC with connectors and jumpers.

Identification	Explanation
1	This Jumpers block is used to define the size of Eprom: Up to 2Mbit = □■ Up to 4mbit = ■■□ (Factory Setting)
2	Sub Group Unit setting: not used, no jumpers set
3	External Access: Never remove this Jumper
4	Analog Input Jumper Block: Not Used
5	Microface ID Jumpers block: Never Set these jumpers (Hirobus Network not available)
6	EEprom Writing Enabled: Enabled = ■■ (Factory Setting; never remove the jumper) Disabled = □□
7	Not Used
A	RS 485 connector for HiSNMP
B	Hirobus Slave 8 poles connector for Remote Display
C	Not Used
D	Hirobus Master 8 poles connector for Hiromatic E
F	I ² C connector for Local Display

2.2 LCD Display

There are two different Displays available:
 "Local" Display
 "Remote" Display

Both Displays have the same Front-View:




Figure 2 – LCD Display Front View (with plastic cover)

Just the backside connections are different, because of the different connection types to the Microface E: Local or Remote Display.




Figure 3 – Local and Remote Display Backside

Never use cables longer than 410 mm (Local Display) or longer than 20m (Remote Display)!

2.3 Eprom

The Eprom is the device, which stores the Program; the Microface has to work with. It doesn't store any user-settings; this is done by the Microface itself (in the RAM and the E²Prom). The Version Name and the Number are printed on the Label of the Eprom.

The following Eproms are today in use for Standard Rack unit (the *.* is a placeholder for the actual Version):

RKM-1.60*.* 4 Mbit Flash for Microface E 24V Ac
RKE-1.60*.* 4 Mbit Flash, for Hiromatic E.




Figure 4 - Eprom

Un-power the Microface before mounting/dismounting the Eprom. Remove Eprom only with special tool; never use a screwdriver. For correct direction of mounting please refer to Figure 1 in Chapter 2.1 for Microface, and Figure 8 in Chapter 2.6.2 for Hiromatic E. Compare the Mark in the Eprom with the direction in the Drawing.

2.4 PTC Temperature Sensor

The PTC Sensor is temperature-sensors, changing the resistance according to the temperature (positive temperature coefficient). The connection is 2 poles. The length of the cable for the sensor ranges from 2 to 10 meters. It is used to monitor the inlet and outlet temperatures of the rack.




Figure 5 – PTC Sensor

2.5 Hiromatic E

Hiromatic E is a microprocessor-based electronic device, which makes possible to control the functions of the Microface devices. Hiromatic E offers numerous advantages of programming the units as well as to optimise their operation using various features, see chapter 3, Software.

2.5.1 Hiromatic E direct Connection to Microface

Hiromatic E can be fixed on the front panel of the unit, simply connecting the HIROBUS cable




Figure 6 – direct Connection between Microface E and Hiromatic E

2.5.2 Hiromatic E Backside View, Jumpers and Eprom Position




Figure 7– Hiromatic Evolution Backside

Description of the Jumpers:

- | | | |
|----|-------------------------------|---|
| A: | Eprom (2M) / Flash Size (4M): | Middle + Upper Jumper: 2 or 4 MBit (std. setting)
Middle + Lower Jumper: not used. |
| C: | Write Disabling: | do not set this Jumper |
| D: | Interface Selection: | both Jumpers as indicated in Drawing: RS 485 (std. setting)
No Jumpers set: RS 422 |
| E: | Contrast Selection: | Middle + Left Jumper: Variable Contrast
Middle + Right Jumper: Fixed Contrast |
| F: | Flash download: | not supported yet. Do not set this Jumper |

Please take special care about the Jumpers when installing a new (Spare Part) Hiromatic!

2.6 Power Supply Module for Hiromatic (24V only)

2.6.1 PSM Hardware

Hiromatic E can be supplied mounted in an independent electrical panel containing a power supply module as well (PSM Power Supply Module), if the Distance to the next Microface E is more than 10 meters. The PSM Module itself needs a power of 24V AC or 24V DC.




Figure 8 – PSM Module

2.6.2 PSM Connection (24V only)

The connection between Hiromatic E and the PSM is carried out in the factory by means of an eight wires HIROBUS cable. The PSM should be connected to Microface E through a six wires screened HIROBUS cable; the screen needs to be grounded in both terminals.




Figure 9 Connection of Microface E LAN to Hiromatic E with PSM.

2.7 Hirobus Cables and other Connection Cables

The connections between Microface E, Hiromatic E, display are carried out with cables having a different number of wires and different connectors. Following you can find how these cables have to be done. For the type of cable and connectors refer to the spare part list included in this manual.

Please note that a wrong connection could cause serious problems to the electronic devices (Microface and Hiromatic); for this reason we strongly recommend to use only first quality products or to buy the cables directly from your sales reps..




Figure 10 Eight-wires; eight poles connector HIROBUS cable, for Hiromatic and remote Display connections




Figure 11 Six-wires eight poles connectors (Pin 1 and 8 not connected) HIROBUS cable, for Microface E and PSM, connection. This cable must be screened.




Figure 12 4 wires flat cable for local LCD Display, four poles connectors.

2.8 Hardware, Technical Specification

MICROFACE E 24V AC	
Power Supply	24VAC, $\pm 10\%$; 50 Hz
Digital Out (Triac)	7
Digital Out (Relay)	2 (max. 24V – 1A)
Analogue Out (0-10V)	2
Analogue In (resistive)	8
Analogue In (resistive / 0-10VDC)	3
Storage Temperature	-10 (not condensing) to +65°C
Operating Temperature Range	0 (not condensing) to +55°C
PTC Temperature sensor	
Cable length	1,5 m and 10m
Temperature range	-28 to 100°C
Point of calibration	2000 Ω at 25.0°C
Hiromatic E	
Power Supply	10VDC (from Hirobus)
Graphic Display	Backlit, 200 x 64 pixels
Mounting hole	175 x 150mm
Power Supply Module (PSM)	
Power supply	24VAC, $\pm 10\%$; 24VDC, $\pm 20\%$
Output	10VDC (Hirobus, stabilised); 24VAC, $\pm 10\%$; 24VDC, $\pm 20\%$ (filtered)

2.9 Spare Parts List

DESCRIPTION	CODE
Switch + Led	255039
Microface E (Evolution) 24 AC board	275297
Local LCD display for Microface	275098
Remote LCD display for Microface	275662
Probe temperature PTC	275183
Probe PTC 2 kohm L = 10 m	275155
EPROM Microface E RKM-160*.*	276226
EPROM Hiromatic E RKE-160*.*	276227
Hiromatic Evolution	275691
Flat cable 8 way M-M L = 1 m	275607
Flat cable 8 way M-M L = 10 m	275610
Flat cable 8 way screened (specify length)	275626
Module PSM 24/24-10 for Hiromatic	275316
Plastic holder for Microface only	270002
Plastic holder for Microface and LCD display	270003
Hirobus / Hironet Cable Tester	480061
Hirobus / Hironet Interface Tester	480060

3 Software

3.1 The LCD Display

The interface module consists of a backlight LCD and of three push buttons that permit an easy access to the unit parameters.




Figure 13 Interface module between Microface and operator (front view).

There are three LED's: the yellow Led to indicate the unit is power supplied, the green one lights up when the unit is in operation and the red one signals either an alarm or a warning condition.

On the LCD the following symbols will be displayed:



The alarm triangle is ON when either a warning or an alarm is active.

SET


The 'SET' string confirms the full access to the displayed parameters.

°C

The „°C“ string appears when temperature is displayed on the LCD.

3.1.1 How to move through the Values/Parameters of the LCD Display

All Values and Parameters are listed up just one after the other. To jump the next parameter, simply the “down” button has to be pressed.



3.1.2 How to change Parameters

To change the value of a parameter scroll the list using the “up” and “down” push-buttons until the desired parameter is displayed and press “Enter” (↵). By pressing the “up” and “down” push buttons, it is possible to change the corresponding value; after having obtained the required value, press enter (↵) again. The display will show again the name of the parameter alternating with the new value.

3.1.3 How to reset Alarms or Warnings

When an alarm is triggered, the red alarm LED is lit on the LCD Display Module and the corresponding symbol is shown in the Display.

The Alarm section can be reached by pressing the “up” push-button when the first parameter is on the display; alarms are pointed out according to their code order.

After having entered the alarm section, the alarm code is displayed and every second the code is replaced by the coded description.

Pressing the “Enter” key (↵), when an alarm code is displayed on the LCD, all the active alarms will be reset. After the reset operation, all the still active alarms will be shown again. If there are no more active alarms, the first parameter / value of the list will be displayed again.

3.1.4 Tricks

To quickly reach the parameter at the bottom of the list, press “Enter” (↵) together with the “down” push-button. To quickly reach the parameter at the top of the list, press “Enter” (↵) together with the “up” push-button.

3.2 The LCD Parameters

LCD	Description	Range	Res.	User Value
<i>t_{in}</i>	Inlet Temperature: this is the average of the 2 inlet sensors temperature values.	--	0.1 (°C)	--
<i>t_{out}</i>	Outlet Temperature: this is the actual outlet temperature value	--	0.1 (°C)	--
<i>Ht1</i>	High Inlet Temperature Level 1: this parameter allows defining at which inlet temperature value the related warning has to be activated. The event is not considered for a time of 5 minutes at each unit ON	No, 1 – 99	1 (°C)	
<i>Ht2</i>	High Inlet Temperature Level 2: this parameter allows defining at which inlet temperature value the related warning has to be activated. The event is not considered for a time of 5 minutes at each unit ON	No, 1 – 99	1 (°C)	
<i>Ht3</i>	High Outlet Temperature: this parameter allows defining at which outlet temperature value the related warning has to be activated. The event is not considered for a time of 5 minutes at each unit ON	No, 1 – 99	1 (°C)	
<i>id1</i>	IP Address 1 for SNMP protocol	0 – 255	1	
<i>id2</i>	IP Address 2 for SNMP protocol	0 – 255	1	
<i>id3</i>	IP Address 3 for SNMP protocol	0 – 255	1	
<i>id4</i>	IP Address 4 for SNMP protocol	0 – 255	1	
<i>idP</i>	Listen Port Address for SNMP protocol	0 – 2000	1	
<i>Std</i>	Standard Settings: forcing to YES all parameters will be set according to the standard factory settings. The parameter changes automatically to NO as soon as the value of one parameter is modified	No, Yes	-	
<i>CA1</i>	Calibration of Inlet Temperature Sensor (SX)	-9.9 - +9.9	0.1 (°C)	
<i>CA2</i>	Calibration of Inlet Temperature Sensor (DX)	-9.9 - +9.9	0.1 (°C)	
<i>CA3</i>	Calibration of Outlet Temperature Sensor	-9.9 - +9.9	0.1 (°C)	

3.2.1 The Warnings and Alarms table

Number	LCD code	Hieromatic E description	Type
008	SL2	Smoke Alarm	Alarm: the event is activated if the unit is ON and the related input is open for 5 seconds minimum: Auto-reset function; the event disappear as soon as the related input is closed
009	rdo	Rear Door Open	Warning: the event is activated if the unit is ON and the related input is open for 5 seconds minimum: Auto-reset function; the event disappear as soon as the related input is closed. The Output 2 of Microface E board (used to disable the Fire Detection Device) will be activated every time the event is active.
010	Fdo	Front Door Open	Warning: the event is activated if the unit is ON and the related input is open for 5 seconds minimum: Auto-reset function; the event disappear as soon as the related input is closed. The Output 2 of Microface E board (used to disable the Fire Detection Device) will be activated every time the event is active.
012	bCo	Backup Cooling Active	Alarm: the event is activated when the backup cooling is active: Auto-reset function; the event disappear as soon as the related input is closed or the Ht2 event is not present
015	FdF	Fire Detection Failure	Warning: the event is activated if the unit is ON and the related input is open for 5 seconds minimum: Auto-reset function; the event disappear as soon as the related input is closed.
018	Hot	High Outlet Temperature	Warning: the event is ignored for 5 minutes at each Unit ON then if the limit set is reached, the event will be activated with a delay of 5 seconds: Manual Reset
022	Ht1	High Inlet Temperature Level 1	Warning: the event is ignored for 5 minutes at each Unit ON then if the limit set is reached, the event will be activated with a delay of 5 seconds: Manual Reset
023	Ht2	High Inlet Temperature Level 2	Alarm: the event is ignored for 5 minutes at each Unit ON then if the limit set is reached, the event will be activated with a delay of 5 seconds: Manual Reset When the event is active the Output 0 and 7 are activated as well as the Backup Cooling (see bCo and Fir)
029	oSF	Outlet Sensor Failure	Warning: the event is activated with a delay of 30 seconds without any influence from the status of the unit: Auto-reset function; the event disappear as soon as the sensor is available
061	iSF	Inlet SX Sensor Failure	Warning: the event is activated with a delay of 30 seconds without any influence from the status of the unit: Auto-reset function; the event disappear as soon as the sensor is available
062	iSF	Inlet DX Sensor Failure	Warning: the event is activated with a delay of 30 seconds without any influence from the status of the unit: Auto-reset function; the event disappear as soon as the sensor is available
065	SL1	Smoke Warning	Warning: the event is activated if the unit is ON and the related input is open for 5 seconds minimum: Auto-reset function; the event disappear as soon as the related input is closed
073	Fir	Fire Alarm	Alarm: the event is activated if the unit is ON and the related input is open for 5 seconds minimum The Outputs 0 and 7 of Microface E board (used to managed the Remote On Off of conditioners) will be activated every time the event is active: Auto-reset function; the event disappear as soon as the related input is closed

3.3 Hiromatic E

3.3.1 Layout

The front panel of Hiromatic E consists of a backlight graphic LCD, of eight push buttons that permit input function and of two LED.

Cursor Buttons: to move inside the Menu;
Up and Down to go to the next or previous window

Push-button to start/stop the unit


Help Key: not used

This LED (orange) will be ON when the unit is power supplied



Alarms and warnings reset.

GREEN when the Unit is in Operation,
YELLOW if the Units is in Warning condition,
RED if the Unit is in Alarm condition

ENTER Button, to set Parameters




3.3.2 Hiromatic E Windows

<p>RACK INLET</p>  <p>20.0°C</p>	<p>RACK OUTLET</p>  <p>35.0°C</p>	<p>On the main page the actual temperatures are displayed. Press Down key for next page</p>														
<p>STATUS OFF</p>																
<p>INPUTS STATUS</p> <table border="0"> <tr> <td>REAR DOOR STATUS</td> <td>CLOSED</td> </tr> <tr> <td>FRONT DOOR STATUS</td> <td>CLOSED</td> </tr> <tr> <td>SMOKE WARNING OK</td> <td>OK</td> </tr> <tr> <td>SKOKE ALARM</td> <td>OK</td> </tr> <tr> <td>FIRE ALARM</td> <td>OK</td> </tr> <tr> <td>EXT.FIRE DETECTION</td> <td>ENABLED</td> </tr> <tr> <td>BACKUP COOLING</td> <td>OFF</td> </tr> </table>		REAR DOOR STATUS	CLOSED	FRONT DOOR STATUS	CLOSED	SMOKE WARNING OK	OK	SKOKE ALARM	OK	FIRE ALARM	OK	EXT.FIRE DETECTION	ENABLED	BACKUP COOLING	OFF	<p>The inputs status page shows the status of each input managed by the Microface E board Press Down key for next page</p>
REAR DOOR STATUS	CLOSED															
FRONT DOOR STATUS	CLOSED															
SMOKE WARNING OK	OK															
SKOKE ALARM	OK															
FIRE ALARM	OK															
EXT.FIRE DETECTION	ENABLED															
BACKUP COOLING	OFF															
<p>OUTPUTS STATUS</p> <table border="0"> <tr> <td>BACKUP COOLING</td> <td>OFF</td> <td>AUTO</td> </tr> <tr> <td>REMOTE UNIT STATUS</td> <td>OFF</td> <td>AUTO</td> </tr> <tr> <td>EXT.FIRE DETECTION</td> <td>ENABLED</td> <td>AUTO</td> </tr> </table>		BACKUP COOLING	OFF	AUTO	REMOTE UNIT STATUS	OFF	AUTO	EXT.FIRE DETECTION	ENABLED	AUTO	<p>The outputs status page shows the actual output status of Microface E board. It is possible also to force each output easily selecting the parameter and change the AUTO string to MANUAL; the related output in this case is forced to ON</p>					
BACKUP COOLING	OFF	AUTO														
REMOTE UNIT STATUS	OFF	AUTO														
EXT.FIRE DETECTION	ENABLED	AUTO														
<p>TEMPERATURE WARNINGS</p> <table border="0"> <tr> <td>HIGH OUTLET TEMPERATURE</td> <td>No°C</td> </tr> <tr> <td>HIGH INLET TEMPERATURE 1</td> <td>38°C</td> </tr> <tr> <td>HIGH INLET TEMPERATURE 2</td> <td>45°C</td> </tr> </table>		HIGH OUTLET TEMPERATURE	No°C	HIGH INLET TEMPERATURE 1	38°C	HIGH INLET TEMPERATURE 2	45°C	<p>The parameters included on this page allow defining the high inlet and outlet temperature limit value Press Down key for next page</p>								
HIGH OUTLET TEMPERATURE	No°C															
HIGH INLET TEMPERATURE 1	38°C															
HIGH INLET TEMPERATURE 2	45°C															
<p>HIROMATIC SETTINGS</p> <table border="0"> <tr> <td>PIEZO FEQUENCYOFF / 2.0</td> <td>LISTEN PORT</td> </tr> <tr> <td>LANGUAGE</td> <td>ENGLISH</td> </tr> <tr> <td>DATE / TIME</td> <td>MO 21/11/2005 16:30</td> </tr> <tr> <td>CONTRAST</td> <td>220</td> </tr> <tr> <td>BACKLIGHT OFF AFTER</td> <td>5 min</td> </tr> <tr> <td>ADDRESS IP</td> <td>129.100.19.115</td> </tr> <tr> <td>LISTEN PORT</td> <td>165</td> </tr> </table>		PIEZO FEQUENCYOFF / 2.0	LISTEN PORT	LANGUAGE	ENGLISH	DATE / TIME	MO 21/11/2005 16:30	CONTRAST	220	BACKLIGHT OFF AFTER	5 min	ADDRESS IP	129.100.19.115	LISTEN PORT	165	<p>On this page is possible to configure the Hiromatic E as well as the address for the SNMP protocol communication. Press Down key for next page</p>
PIEZO FEQUENCYOFF / 2.0	LISTEN PORT															
LANGUAGE	ENGLISH															
DATE / TIME	MO 21/11/2005 16:30															
CONTRAST	220															
BACKLIGHT OFF AFTER	5 min															
ADDRESS IP	129.100.19.115															
LISTEN PORT	165															
<p>SENSORS CALIBRATION</p> <table border="0"> <thead> <tr> <th></th> <th>ACTUAL</th> <th>OFFSET</th> </tr> </thead> <tbody> <tr> <td>INLET TEMPERATURE SX</td> <td>00.0</td> <td>0.0</td> </tr> <tr> <td>INLET TEMPERATURE DX</td> <td>00.0</td> <td>0.0</td> </tr> <tr> <td>OUTLET TEMPERATURE</td> <td>00.0</td> <td>0.0</td> </tr> </tbody> </table>			ACTUAL	OFFSET	INLET TEMPERATURE SX	00.0	0.0	INLET TEMPERATURE DX	00.0	0.0	OUTLET TEMPERATURE	00.0	0.0	<p>If required the offset of sensors mounted on board can be done. Press Down key for next page</p>		
	ACTUAL	OFFSET														
INLET TEMPERATURE SX	00.0	0.0														
INLET TEMPERATURE DX	00.0	0.0														
OUTLET TEMPERATURE	00.0	0.0														
<p>STATUS REPORT PAGE 1 SYSTEM</p> <p>(01) 21.11.2005 16:30 RESET HIGH OUTLET TEMPERATURE</p>		<p>On system status report page all events (up to 200; system and unit) are stored. Press Left or Right key for Status Report of Unit. This page is reachable from the main page easily pressing the Home key</p>														
<p>STATUS REPORT PAGE 0 UNIT</p> <p>(01) 21.11.2005 16:30 RESET HIGH OUTLET TEMPERATURE</p>		<p>On unit status report page; the last 3 events are stored</p>														

4 Connection guide

Microface E (Layout)




Inputs table

- Ptc 0 = Rack Sx Inlet Temperature
- Ptc 1 = Rack Dx Inlet Temperature
- Ptc 2 = Smoke Warning
- Ptc 3 = Smoke Alarm
- Ptc 4= Fire Alarm
- Ptc 5= Backup Cooling Active
- Ptc 6 = Fire Detection Device Faulire
- Ptc 7 = Rack Outlet Temperature
- Ana 0 = Rear Door Status
- Ana 1 = Front Door Status


Outputs table

- Out 1 = Fan & Damper
- Out 2 = Fire Detection device Enable / Disable
- Out 0 = Remote Unit On Off
- Out 7 = Remote Unit On Off

Power supply & Sensors



PTC & Analog inputs



Digital Outputs

