

ATLAS 9600
STRINGING MACHINE
USER'S MANUAL




ANATOMY

The Atlas 9600 is shipped to you in two cartons.

Here is what the two cartons contain:

- 1). Electronic Tension Head
- 2). Racquet Mount and Floor Stand



1. Side Support
3. Rubber Cover
5. Side Support Arm Adjustment Knob
7. Mounting Stock Locking Knob
9. Turntable Track
11. String Clamp Base
13. Rotary String Gripper
15. Upper Housing
17. Control Panel
19. Height Adjustment Knob
21. String Reel Holder
23. Foot (Base)
25. Tension Adjustment Knob
27. Power Cord
2. Center Support
4. Center Support Adjustment Knob
6. Mounting Stock
8. Turntable
10. String Clamp
12. Side Support Arm
14. Green Tension Button
16. Lower Housing
18. Side Panel
20. Tool Tray
22. Column
24. Rubber Foot
26. Foot Paddle

ASSEMBLY

Step 1 :

Secure column to foot using 4 long bolts, washers and nuts by a 6 mm and a 12 mm wrenches.

Screw the string reel holder into the column.

Mount the tool tray on the column with the 4 small bolts by a 10 mm wrench.

Insert the anchor plate in the column and adjust the anchor post to the proper height and lock with the adjustment knob.



Step 2 :

Remove the 4 nuts from the machine body. Place machine body over column and align the 4 studs under the machine with the corresponding holes in the anchor plate. Secure the 4 nuts to the 4 studs.



Step 3 :

Remove the 4 Allen bolts from the bearing pivot and insert turntable in machine body. Tighten the 4 Allen bolts.



Step 4 :

Plug the power cord of the foot paddle into the outlet located beneath metal bottom base of the electronic tension head.



Step 5 :

Screw the brake into the hole of the lower housing. To lock the turntable, rotate the brake clockwise. To unlock the turntable, rotate the brake counter-clockwise.



MOUNTING THE RACQUET FRAME

Inserting the Side Supports & String Clamps

Insert the two string clamps into the string clamp bases and four side supports in the holes of the side support arms. Note the big jaw of the side support is for tennis racquet frame and small jaw is for the badminton racquet frame.




Adjusting the Mounting Stocks

Loosen both mounting stocks by turning the mounting stock knobs counterclockwise. Place the racquet frame properly on both mounting stocks and adjust the distance between the mounting stocks to accommodate the size of the racquet frame. Turn both mounting stock knobs clockwise to lock both mounting stocks in place.




Side Support Adjustment

Turn the knobs at the bottom of each mounting stock clockwise to bring the side supports in the contact with the racquet frame at all four points.



Center Support Adjustment

Turn the knobs at the upper of each mounting stock clockwise until snug against the racquet frame and slight resistance is felt.



SWIVEL CLAMP OPERATION

Different strings and different gauges require different adjustments. Adjustment can usually be done by finger tips. Note that the handle of the swivel clamp should be lifted before adjustment.



SWIVEL CLAMP BASE OPERATION

The lever on the swivel clamp base is turned clockwise to lock the base. To unlock, the lever is turned counterclockwise. If the swivel clamp base doesn't lock well to the turntable or the locking angle of the lever of the clamp base is too big, you may adjust the nut beneath the clamp base by a 17 mm wrench clockwise or counterclockwise.


Closed Position



Open Position



KEYPAD OPERATING INSTRUCTIONS



The keypad is protected by a plastic film that should be removed before using.

POWER ON/OFF

When the machine is turned on, the indicator light of the “POWER ON/OFF” will light up.

REACHED TENSION

When the desired tension is attained, the indicator light of the “REACHED TENSION” will light up.

KG/LB

Selects tension scale. Shown on right of screen.

REVERSE

Releases string tension, although this is normally done by pressing the main green tension button. This key is also used to release the rotary string gripper on occasions when it comes to rest in a dead spot and does not respond to the main green tension button.

START

Initiates string tensioning, although this is normally done by pressing the main green tension button.

PRE-STRETCH

Pulls string, release string and re-pulls to the tension setting.

Presses the key of the “PRE-STRETCH” to set up the function of “PRE-STRETCH” and presses it again to cancel the “PRE-STRETCH” function. The indicator light of the “PRE-STRETCH” lights up to indicate the “PRE-STRETCH” is set.

TENSION CALIBRATION

Turns the machine on while pressing the “TENSION CALIBRATION” button and CAL appears on the display along with a tension such as 5 KG and then the indicator light of the “TENSION CALIBRATION” lights up to indicate the “TENSION CALIBRATION” is set.

MUTE/MODE/MEMORY

MUTE function :

Presses “MUTE/MODE/MEMORY” to cancel the beep sound. Sets up the beep sound by pressing “MUTE/MODE/MEMORY” key again.

MODE function :

For troubleshooting purpose and factory setting only.

MEMORY function :

Stores the new calibrated tension during tension calibration.

POWERING


The main power switch is located on the right of the machine next to the receptacle for the power cord. A 2 amp fuse is located in the power cord receptacle.

Voltage between 100V and 110V (50 Hz to 60 Hz) is acceptable. A grounded outlet must be used.



TENSIONING


To insert the string in the split rotary string gripper, pass over the top half of the gripper, wrap the string clockwise around the gripper drum and position the string between the gripper jaws as shown in the illustration. Excessive slack in the string should be removed before applying tension.



To set the desired tension, rotate the tension adjustment knob clockwise to increase the displayed tension or counter-clockwise to decrease the displayed tension until the desired tension is shown up on screen.



To tension the string, press the main green tension button or "START" key on the keypad or foot paddle. As the rotary string gripper turns and applies tension to the string, the upper jaw is forced down to clamp the string between the jaws.



To release the tensioned string after clamping, press the main green tension button again or foot paddle or "REVERSE" key on the keypad.

NOTE :

If the rotary string gripper does not release the string by pressing the main green tension button, depress the "REVERSE" key on the keypad to release the string.



TENSION CALIBRATION

If your machine is pulling tension inaccurately, please follow the procedures below for the correct tension calibration.

Step 1 :

Turn the machine on and set 5 KG (or 11 lbs) by rotating the tension adjustment knob counterclockwise.



Step 2 :

Turn the machine off.



Step 3 :

Turn the machine on again while pressing "TENSION CALIBRATION" key. CAL appears on the display along with a tension such as 5 KG (or 11 LB). **NOTE :** The indicator light of the "TENSION CALIBRATION" will light up to indicate you have entered into the tension calibration mode successfully. If not, please repeat the procedure step 3 again.



Step 4 :

Pull the string by pressing the main green tension button.

**Step 5 :**

Note the tension reading on the calibrator and release the tensioned string by pressing the main green tension button.

**Step 6 -1 :**

Rotate the tension adjustment knob clockwise to increase the calibrator's value if the tension reading on the calibrator is lower than the tension value shown on the display. (Instead, rotate the tension adjustment knob counterclockwise to decrease the calibrator's value if the tension reading on the calibrator is higher than the tension value shown on the display.)

NOTE :

One turn of the tension adjustment knob is around 1 KG (or 3 LB).

**Step 6 -2 :**

Re-pull the string of the tension calibrator by pressing the tension green button to see if your adjustment has attained the correct tension or not.

Step 6 -3 :

If the tension reading on the calibrator is still different from the tension shown on the display, release the string and repeat the procedure step 6-1 and 6-2 again.

**Step 6 -4 :**

If the tension reading on the calibrator is identical to the tension shown on the display, release the string and press "MEMORY" key to store what you have calibrated and enter into the next calibration mode, such as 10 KG (or 22 LB).



Step 7 :

Before doing the next tension calibration, rotate the tension adjustment knob clockwise first for **5 turns** so as to start testing the next new tension.

Besides the premier 5 kg (or 11 lbs), the machine will provide you with six more tensions (such as 10, 15, 20, 25, 30 and 35 kg) or (22, 33, 44, 55, 66 and 77 lbs) to test against the calibrator. Repeat the procedures outlined in steps 4 to 7 for each of the rested six tensions.



Step 8 :

Press “MEMORY” key to store the last calibrated tension and then press “TENSION CALIBRATION” key to get out the calibration mode or turn power off.