




USER INSTRUCTIONS

Limitorque Master Station III

FCD LMENIM5001-01 – 05/12

*Installation
Operation
Maintenance*



Contents

1. Introduction	5
2. Function Flowchart	9
3. Quick Startup	12
4. Connections	13
5. System Status	18
6. System Control	21
7. Email Configuration	24
8. System Configuration	28
9. Diagnostics	53
10. File Manager	56
11. Troubleshooting Guide	60

Figures

Figure 1.1 - Introduction	6
Figure 1.2 - Enter User Name	6
Figure 1.3 - Login	6
Figure 1.4 - Main Menu	7
Figure 2.1 - Function Flowchart	10-11
Figure 4.1 - Master Station Rear Panel Connections	13
Figure 4.2 - DCS Port Connection	14
Figure 4.3 - Master Station Front Panel Connections	15
Figure 4.4 - Debug Port Connection	15
Figure 4.5 - Modbus Redundant Loop Topology	17
Figure 5.1 - The Main Menu Screen	18
Figure 5.2 - System Status	19
Figure 5.3 - Network Status	19
Figure 5.4 - MOV Status	20
Figure 5.5 - MSIII Status	20
Figure 6.1 - Main Menu	21
Figure 6.2 - System Control	22
Figure 6.3 - MOV Control	22
Figure 6.4 - Emergency Shutdown	22
Figure 6.5 - Emergency Shutdown in Progress	23
Figure 6.6 - Emergency Shutdown Termination	23
Figure 7.1 - Main Menu	24
Figure 7.2 - Email Notification Screen	25
Figure 7.3 - SMTP Address	25
Figure 7.4 - SMTP Configuration without Password	25
Figure 7.5 - SMTP Configuration with Password	26
Figure 7.6 - Email Notification Screen	26
Figure 7.7 - Add Email Listener	26
Figure 7.8 - Alarm Selections	27
Figure 8.1 - Main Menu	28
Figure 8.2 - System Configuration	29
Figure 8.3 - System Information	29
Figure 8.4 - Version	30
Figure 8.5 - Language Menu	30
Figure 8.6 - Clock	31
Figure 8.7 - Time Zone	31
Figure 8.8 - Screen Saver	31
Figure 8.9 - Configure Hot Standby	32
Figure 8.10 - Configuration Transfer Lockout	32
Figure 8.11 - Tag List	33
Figure 8.12 - User Administration	33
Figure 8.13 - DCS Configuration	33
Figure 8.14 - Serial Port Configuration	34
Figure 8.15 - Configure Ethernet Port	35
Figure 8.16 - Configure DCS Data Table	35
Figure 8.17 - FC-02 Read Input Status	35
Figure 8.18 - Modbus Holding Registers	38
Figure 8.19 - FC-03 Sample Data Table	39

Figure 8.20 - Modbus Coils	42
Figure 8.21 - FC-05/15 Sample Data Table	42
Figure 8.22 - Modbus Holding Registers-One Per MOV	44
Figure 8.23 - Modbus Holding Registers-Two Per MOV	45
Figure 8.24 - FC-06/16 Sample Data Table	45
Figure 8.25 - MOV Network Configuration	50
Figure 8.26 - Active MOVs	50
Figure 8.27 - Polling Priority-Active MOVs	50
Figure 8.28 - Configure Files	51
Figure 8.29 - Load Configuration from File	51
Figure 8.30 - Save as Default	52
Figure 8.31 - Restore Factory Defaults	52
Figure 9.1 - Main Menu	53
Figure 9.2 - Diagnostics	54
Figure 9.3 - Event Log	54
Figure 9.4 - Comm/FC Logger	55
Figure 9.5 - Polling Statistics	55
Figure 10.1 - Main Menu	56
Figure 10.2 - File Manager	57
Figure 10.3 - Import Config File	57
Figure 10.4 - Export Config File	57
Figure 10.5 - Export Event Log	58
Figure 10.6 - Import Tag File	58
Figure 10.7 - Update Software	59
Figure 11.1 - Surge Protection Access	62
Figure 11.2 - Main AC Power Input Module	62
Figure 11.3 - Removing Main AC Input Power Module	63
Figure 11.4 - AC Surge Protector	63
Figure 11.5 - Removing Fuse Holder	63
Figure 11.6 - AC Fuse Holder	64
Figure 11.7 - Network Surge Protector	64
Figure 11.8 - Removing Network Surge Protector	64

Tables

Table 4.1 - Network Channel B Connection	14
Table 4.2 - Network Channel A Connection	14
Table 8.1 - Status Bit Definitions	36-37
Table 8.2 - Function Code -02 Example Message Breakdown	38
Table 8.3 - Function Code -03 Example Message Breakdown	39
Table 8.4 - Register Definitions	40-42
Table 8.5 - DDC-100 Coil Assignments, Modbus 05 Command Usage for Digital Outputs	43
Table 8.6 - Function Code -05 Example Message Breakdown	43
Table 8.7 - Function Code -15 Example Message Breakdown	44
Table 8.8 - Function Code -06 First Command Message Breakdown	46
Table 8.9 - Function Code -06 Second Command Message Breakdown	46
Table 8.10 - Function Code -06 Message Breakdown	47
Table 8.11 - Function Code -16 Message Breakdown	47
Table 8.12 - Valid Command Register Operations	48
Table 8.13 - Valid Argument Register Operations	49

1 Introduction

1.1 Overview

The next-generation master station is designed and manufactured by Flowserve Limatorque specifically for use with the Limatorque line of (Modbus) electric actuators. The Master Station III (MSIII) acts as a single-source controller for up to 250 actuators with full redundancy, e-mail alert notification, and multi-lingual support.

The Master Station III is a plug-and-play solution that provides complete control, monitoring, and diagnostics of Limatorque electric actuators through a simple touch-panel display serving as a Human Machine Interface (HMI).

1.2 User Role Overview

The Master Station requires users to login. Four user role levels are configurable for each user: View, Control, Configure, and Administrator. Each role includes the rights of the lesser roles (i.e., Control includes View's rights, and Configure includes Control's rights and View's rights).

VIEW: the user can view the network status and the activity log. No control or configuration functionality is available.

CONTROL: in addition to View rights, the user has the ability to control MOVs.

CONFIGURE: in addition to Control rights, the user has the ability to configure the Master Station and the Network.

ADMINISTRATOR: in addition to Configure rights, the user has the ability to add or delete users, as well as modify user settings.

These roles can be changed by the Administrator user. See Section 8.2.4, User Administration for details.

1.3 Login

When the Master Station completes the boot process, it loads the Introduction screen (Figure 1.1).

Figure 1.1 - Introduction



Touching any part of the screen will load the Enter User Name screen (Figure 1.2).

NOTE: If the screen is blank and the green LED is illuminated the unit is in screen saver mode, touch the display to exit the screen saver mode.

Figure 1.2 - Enter User Name

Enter User Name
Cancel

A	B	C	D	E	F	G	DEL
H	I	J	K	L	M	N	CLR
O	P	Q	R	S	T	U	ENT
Sft	V	W	X	Y	Z	Sft	

Once the user name has been entered, the Enter Password screen will be displayed (Figure 1.3).

NOTE: Each user name must have a unique password.

Figure 1.3 - Login

Enter Password
Cancel

A	B	C	D	E	F	G	DEL
H	I	J	K	L	M	N	CLR
O	P	Q	R	S	T	U	ENT
Sft	V	W	X	Y	Z	Sft	


Passwords and user names are set via the User Administration menu, under System Configuration. The correct password entry for the respective user name will advance the screen to the Main Menu (Figure 1.4).

In the event that passwords are lost or forgotten, please contact your Limitorque service coordinator at (434) 528-4400.

1.4 Main Menu

Once logged in, the user will see the Main Menu (Figure 1.4).

Figure 1.4 - Main Menu



From here, the menu options are displayed based on the current user role. Each button represents a separate logical section of the Master Station:

SYSTEM STATUS (ALL USERS): View information related to the network status, status of the Master Station, and MOV status.

SYSTEM CONTROL (CONTROL, CONFIGURE, AND ADMINISTRATOR): Access to MOV control and emergency shutdown functions.

EMAIL CONFIGURATION (CONFIGURE AND ADMINISTRATOR): View and change settings related to email alerts.

SYSTEM CONFIGURATION (CONFIGURE AND ADMINISTRATOR): Configure the main functions of the Master Station. User Administration functions in this section are accessible only to Administrator users.

DIAGNOSTICS (CONFIGURE AND ADMINISTRATOR): Activate event logging, communication data analysis, or polling statistics.

FILE MANAGER (CONFIGURE AND ADMINISTRATOR): Import or export configuration files, export an event log, import a tag file, or update the Master Station software.

1.5 Technical Data

1. Power supply: 100-240 VAC 50/60HZ or 24 VDC maximum current is 1.5A.
2. Operating temperature: 0-60°C (32-140°F)
3. Enclosure: Desktop/Shelf housing (standard), 19" rack mountable (optional), NEMA 4/4X wall-mountable (optional), or mounted in a stand-alone cabinet (optional). Standard dimensions are 16" (w) x 8.25" (h) x 18.5" (d)
4. Human machine interface: 5.6" diagonal, 640x480 resolution, lighted, TFT color graphic LCD. Supports multiple languages: English, Spanish, Italian, German, and French.
5. Electromagnetic Compatibility (EMC) Compliance:
 - a. Emissions/Immunity – EN 61326-1:2006
 - b. Harmonics – EN 61000-3-2
 - c. Flicker – EN 61000-3-3
6. Communication protocol – MSIII to Field Units: Modbus RTU
7. Communication protocol – MSIII to Host System: Modbus RTU or Modbus TCP/IP
8. Network topology – Bi-directional redundant loop or multi-drop/daisy chain
9. Physical layer – MSIII to field units: EIA-485 (RS-485)
10. Physical layer – MSIII to Host System: TIA-232 (RS-232) / EIA-485 (RS-485) / Ethernet
11. Unit redundancy options: MSIII module redundancy, isolated power connections (standard)
12. Communications Rate – MSIII to field units: 19.2 Kbaud max (Serial)
 Host System to MSIII: 115.2 Kbaud max (Serial)
 Host System to MSIII: 100 Mbits per second max (Ethernet)
 Maximum recommended host system polling rate:
 125 register reads / 500 ms
 44 register writes / 500 ms
13. Network Topology

Network Topology (kbit/s)	Max. Segment Length (Belden 3074F with no repeaters, meters)	Max. Cable Length (kilometers)
Multi-drop/Daisy Chain (with 24 field units)	1200	30
Redundant Loop (with 240 field units)	1200	289.2

2

Function Flowchart

The following flowchart graphics illustrate the functions of the Master Station III.

Figure 2.1 - Function Flowchart





Figure 2.1 - Function Flowchart (continued)



3

Quick Startup

3.1 Master Station Quick Startup Instructions

1. Connect earth ground (#14AWG minimum) wiring, MOV network cables (Belden #3074F/#9841/#3107), and power cable.
2. Apply power to the Master Station.
3. Wait for the Master Station to display the start-up screen.
4. Touch the screen, then enter user name "FLOW". Select Enter.
5. Enter password "100" when prompted. Select Enter.
6. Next select "System Configuration" then "Redundant Configuration".
7. Select current mode to "Active", startup mode to "Active", and redundancy mode to desired setting.
8. Next select the "back" button and in the "System Configuration" select "User Administration".
9. Set up user accounts per Section 8.
10. Select "MOV Network Config" and set up per Section 8.
11. Select "DCS Configuration" and set up per Section 8.

For remote DCS control, the three primary registers of interest are:

- 46001: Register for HS Status (Read Only): 0=idle, 1=standby, 2=hot
- 46002: Register for Host System to toggle (Write Only): 3=toggle state
- 46191: Register for Internal Program Execution Heartbeat/Watchdog (Read Only):
Updates every scan, 8-bit integer

12. Further adjustments may be made by following the procedures outlined in this manual.

4

Connections


4.1 Master Station Rear Panel Connections

Figure 4.1 - Master Station Rear Panel Connections



1. Ethernet Ports, RJ-45 connectors. One port is designated for MNET (Modbus Ethernet TCP/IP). The other port is for the webserver. Either port may be used for either function as they are connected to the same CPU.
2. Main DCS Port. DB-9 Female connector. Port may be RS-232 or RS-422 or RS-485. Each electrical standard uses a different wiring convention.

Figure 4.2 - DCS Port Connection



3. Auxiliary 24 VDC power connection for Main.
4. Main power switch and connector for 120 – 240 VAC.
5. Electrostatic Ground. A good quality earth ground **MUST** be attached to the Master Station. An effective local, low-impedance earth ground (less than 5 ohms) is required.
6. Hot Standby unit main power switch and connector for 120 – 240 VAC.
7. Auxiliary 24 VDC power connection for Hot Standby.
8. Hot Standby DCS Port. DB-9 Female connector. Port may be RS-232 or RS-422 or RS-485. Each electrical standard uses a different wiring convention.
9. Network Connections- Channel A and B. Connections for the network wiring for channels A and B. See Tables 4.1 and 4.2 below for connection details.

NOTE: Each module (Main or Hot Standby) can support up to two of the three power inputs (Main 120-240 VAC, Optional 120-240 VAC, 24 VDC).

Table 4.1 - Network Channel B Connection

Connector	MX/QX	UEC-3-DDC
DATA-A2 (+)	13	TB4 D-S
DATA-A2* (-)	14	TB4 D-S*
Shield	N/C	

Table 4.2 - Network Channel A Connection

Connector	MX/QX	UEC-3-DDC
DATA-A1 (+)	5	TB3 D-M
DATA-A1* (-)	4	TB3 D-M*
Shield	3	


4.2 Master Station Front Panel Connections

Figure 4.3 - Master Station Front Panel Connections



1. Ethernet Port, RJ-45 connector. Can be used for MNET (Modbus Ethernet TCP/IP) or for the webserver.
2. Hot Standby Ethernet Port, RJ-45 connector. Can be used for MNET (Modbus Ethernet TCP/IP) or for the webserver.
3. USB Ports.
4. Hot Standby USB Ports.
5. Printer / Debug Port. DB-9 Female connector. RS-232 port. Used for Master Station diagnostics.

Figure 4.4 - Debug Port Connection



6. Hot Standby Printer / Debug Port. DB-9 Female connector. RS-232 port. Used for Master Station diagnostics.
7. VGA Port. Used for connecting a monitor to the Master Station Main unit.
8. Hot Standby VGA Port. Used for connecting a monitor to the Master Station Hot Standby unit.

4.3 Master Station Wiring Requirements

The network cable connects the field units to the host controller or Master Station. Belden 3074F, 3105A, or 9841 shielded, twisted-pair cable should be used. The use of other cables may result in a reduction of internodal distances or increased error rate, and is the user's responsibility.

BELDEN 3074F SPECIFICATIONS

- Total cable length between repeaters or nodes with repeaters: up to 19.2 kbps: 4000' (1.2 km)

For loop mode, this is the total length between operating field units. If a field unit loses power, the relays internal to the field unit connect the A1 Channel to the A2 Channel, which effectively doubles the length of the cable (assuming a single field unit fails). To ensure operation within specifications in the event of power failure to field units, this consideration must be added. **Example:** To ensure operation within specification when any two consecutive field units lose power, the maximum length of cable up to 19.2 kbps should not exceed 4000' (1.2 km) per every four field units. See Section 3.1.2.3, Network Cable Connection to Host Controller or Master Station.

Key Specifications

- Resistance/1000 ft = 18 AWG (7 x 26) 6.92 ohms each conductor (13.84 ohms for the pair)
- Capacitance/ft = 14 pF (conductor-to-conductor)
- Capacitance/ft = 14 pF (conductor-to-shield)

BELDEN 3105A SPECIFICATIONS

- Total cable length between repeaters or nodes with repeaters: up to 19.2 kbps: 4000' (1.2 km)

For loop mode, this is the total length between operating field units. If a field unit loses power, the relays internal to the field unit connect the A1 Channel to the A2 Channel, which effectively doubles the length of the cable (assuming a single field unit fails). To ensure operation within specifications in the event of power failure to field units, this consideration must be added. **Example:** To ensure operation within specification when any two consecutive field units lose power, the maximum length of cable up to 19.2 kbps should not exceed 4000' (1.2 km) per every four field units. See Section 3.1.2.3, Network Cable Connection to Host Controller or Master Station.

Key Specifications

- Resistance/1000 ft = 22 AWG (7 x 30) 14.7 ohms each conductor (29.4 ohms for the pair)
- Capacitance/ft = 11.0 pF (conductor-to-conductor)
- Capacitance/ft = 20.0 pF (conductor-to-shield)

BELDEN 9841 SPECIFICATIONS

- Total cable length between repeaters or nodes with repeaters: up to 19.2 kbps: 3500' (1 km)

For loop mode, this is the total length between operating field units. If a field unit loses power, the relays internal to the field unit connect the A1 Channel to the A2 Channel, which effectively doubles the length of the cable (assuming a single field unit fails). To ensure operation within specifications in the event of power failure to field units, this consideration must be added. **Example:** To ensure operation within specification when any two consecutive field units lose power, the maximum length of


cable up to 19.2 bkps should not exceed 3500' (1 km) per every four field units. See Section 3.1.2.3, Network Cable Connection to Host Controller or Master Station.

Key Specifications

- Resistance/1000 ft = 24 AWG (7 x 32) 24 ohms each conductor (48 ohms for the pair)
- Capacitance/ft = 12.8 pF (conductor-to-conductor)
- Capacitance/ft = 23 pF (conductor-to-shield)

4.4 Master Station Network Topologies

Figure 4.5 - Modbus Redundant Loop Topology



Notes:

- 1) Belden 3074F, 3105A, or 9841 shielded cable is recommended.
- 2) Correct polarity for field unit and network controller connection is necessary for proper operation.
- 3) Connections shown are typical. The number of MOVs shown may not indicate true system size.
- 4) Earth ground: ground rod
- 5) Earth ground: ground rod or lug in actuator if actuator is grounded.


5

System Status

5.1 Main Menu

Upon successful login as a user assigned to any role level, the System Status button on the Main Menu screen will be present. Simply touching the System Status button will advance the HMI display to the System Status screen (Figure 5.2). By selecting Exit, the user will end the session and log out.


Figure 5.1 - The Main Menu screen



5.2 System Status

The System Status main screen (Figure 5.2) allows the user to view the overall status of the MOV network and Master Station.


Figure 5.2 - System Status



5.2.1 Network Status

The Network Status screen presents an overview of the entire field unit network, up to 25 activated MOVs per page. Only those MOVs that have been activated will be displayed. See MOV Network Config in System Configuration screen to activate desired MOVs.

Figure 5.3 - Network Status




The numeric buttons represent addressed MOVs, while the A and B bars represent associated MOV communication channels A&B. The MOVs and their respective communication channels are constantly being monitored and will display green if OK and red if faulted. The user can advance to the MOV Status screen by either touching an addressed MOV or touching the Back button to return to System Status screen, and then selecting MOV Status.

5.2.2 MOV Status

The MOV Status screen reveals the actual MOV network address, tag name, unit type, and position. In addition, it shows the status of the MOV communication channels and the Modbus holding registers that have been selected to be mapped to the PLC/DCS data table. See Section 8.2.6.3 Configure Data Table for register content details.

Figure 5.4 - MOV Status



MOV Status - Register # 9 Remote Mode

< MOV Address 3 > Go to MOV

Tag MOVFU003

Channel A Unit Type: MXA 73 % Open Channel B

☐ Opened ☐ Jammed ☐ Close T/S Fault
☐ Closed ☒ Local Mode ☐ Manual Op Fault
☒ Stopped ☐ Combined Fault ☐ Phase Error
☐ Opening ☐ O/T Fault
☐ Closing ☐ Open T/S Fault


Back Main Menu Next

5.2.3 MSIII Status

The MSIII Status screen provides Master Station status of the following functional components:

1. CPU Module temperature
2. Available memory for logging data
3. CPU Module up-time
4. Last login time
5. Last configuration change time

Figure 5.5 - MSIII Status



MSIII Status Active

CPU Module Temp: +67.0°C

Logging Memory Size: 128 MB

Module Uptime: 0 Days 0 Hours 5 Minutes

Last Login Time: Thu May 20 11:10:40 EDT 2010

Last Config Change: Thu May 20 10:39:57 EDT 2010

Back Main Menu


6

System Control

6.1 Main Menu

Upon successful login as a user assigned to a Control, Configure, or Administrator role, the System Control button on the Main Menu (Figure 6.1) will be present. Simply touching the System Control button will advance the HMI display to the System Control screen (Figure 6.2). By selecting Exit, the user will end the session and log out.


Figure 6.1 - Main Menu



6.2 System Control

The System Control screen (Figure 6.2) allows for the selection of either MOV Control or Emergency Shutdown, over the network.


Figure 6.2 - System Control



6.2.1 MOV Control

The MOV Control screen (Figure 6.3) allows for a selected MOV to be opened, stopped, closed, or moved to a set position (such as 38% open). As shown in Figure 6.3, if the torque register is selected (see Section 8.2.6.3.2), the MOV Control screen displays the torque reading during MOV operation for the latest generation smart actuators. MOV control relays can also be energized from this screen if the relays are configured for network network control within the MOV.


Figure 6.3 - MOV Control



6.2.2 Emergency Shutdown

Should it be necessary to initiate an Emergency Shutdown of the networked MOVs, this can be accomplished by accessing the Emergency Shutdown screen (Figure 6.4) from the Main Menu.


Figure 6.4 - Emergency Shutdown



Two options are available: Initiate Emergency Shutdown and Clear Emergency Shutdown. Once an emergency shutdown has completed and is no longer necessary, the emergency shutdown state can be cleared by pressing the Clear Emergency Shutdown button.


When an emergency shutdown is initiated, the Emergency Shutdown in Progress screen will be displayed (Figure 6.5).

Figure 6.5 - Emergency Shutdown in Progress



When an emergency shutdown is cleared, the Emergency Shutdown Termination in Progress screen will be displayed (Figure 6.6) until the procedure is complete.

Figure 6.6 - Emergency Shutdown Termination




7

Email Configuration

7.1 Main Menu

Upon successful login as a user assigned to either Configure or Administrator role level, the System Configuration button on the Main Menu screen will be present. Simply touching the Email Configuration button will advance the HMI display to the Email Notification Screen (Figure 7.2). By selecting Exit, the user will end the session and log out.


Figure 7.1 - Main Menu



7.2 Email Configuration

The Email Configuration allows the user to setup and maintain email notification alerts for network faults, DCS port faults, ESD activity, HOT/STANDBY changes, and/or MOV alarms. Each email entry can be independently configured for any/all alarm events. In the event of an alarm, any email addresses configured for that particular fault will be sent a notification email that a fault has occurred.

Figure 7.2 - Email Notification Screen



The 'Email Notification' screen has a title bar with 'Email Notification' on the left and 'Active' on the right. Below the title bar is a large empty rectangular box on the left. To the right of this box is a vertical stack of five buttons: 'Network Fault', 'DCS Port Fault', 'Emergency Shutdown', 'Hot Standby Change', and 'MOV Alerts'. Below these buttons are three input fields for DNS settings. The first is labeled 'SMTP:' and contains 'smtp.gmail.com' with a 'Configure' button to its right. The second is labeled 'Primary DNS:' and contains four '0' digits separated by dots. The third is labeled 'Secondary DNS:' and also contains four '0' digits separated by dots. At the bottom of the screen are four buttons: 'Back', 'Delete', 'Add', and 'Accept'.


7.2.1 SMTP Configuration

NOTE: SMTP Email Setup must be completed before email addresses can be added to the mailing list.

Email notification is enabled by setting up a SMTP server and valid email account in the Master Station III. This can be done either with an accessible private SMTP server and email account or by creating a new email address with Gmail (service provided by Google) and utilizing their public SMTP server.

To set up the email account first enter the SMTP host by selecting the button left of the “Configure” button.


Figure 7.3 - SMTP Address



The 'SMTP Address' screen has a title bar with 'SMTP:' on the left and 'Cancel' on the right. Below the title bar is a large empty rectangular box. Below this box is a grid of buttons for entering the SMTP host address. The grid has four rows and eight columns. The first seven columns contain letters 'a' through 'z' and a period '.'. The eighth column contains 'Del', 'CLR', and 'ENT' buttons. The 'Sft' button is located below the 'a' button.


Once the SMTP host has been configured, select the “Configure” button to finish setting up the outgoing email. Depending on the type of connection the user specifies, the account login may be configured with or without a password as shown in Figures 7.4 and 7.5. The connection type can also be configured with or without SSL.

Figure 7.4 - SMTP Configuration without Password



The 'Email Configuration' screen has a title bar with 'Email Configuration' on the left and 'Active' on the right. Below the title bar are several input fields and buttons. The first is 'Password:' with 'Yes' and 'No' buttons; the 'No' button is highlighted with a green border. The second is 'Port:' with a '25' button. The third is 'User Name:' with a text field containing 'myname@gmail.com'. The fourth is 'Password:' with a text field containing '*****'. The fifth is 'SSL:' with 'No' and 'Yes' buttons; the 'No' button is highlighted with a green border. At the bottom left is a 'Back' button.

Figure 7.5 - SMTP Configuration with Password




The 'Email Configuration' dialog box is shown with the 'Active' status. It contains the following fields and options:

- Password:** A dropdown menu with 'Yes' selected (highlighted with a green box) and 'No' as an alternative option.
- Port:** A text field containing the value '25'.
- User Name:** A text field containing 'myname@gmail.com'.
- Password:** A password field with masked characters '*****'.
- SSL:** A dropdown menu with 'No' selected (highlighted with a green box) and 'Yes' as an alternative option.
- Back:** A button at the bottom left.

Once the SMTP Host Address and SMTP Email Account have been configured, the IP address of the Master Station III must be set in the Email Notification Screen. Set the Primary and Secondary DNS addresses by selecting the octet fields.

Figure 7.6 - Email Notification Screen



The 'Email Notification' screen is shown with the 'Active' status. It includes the following elements:

- Event Selection:** A list of events with checkboxes: Network Fault, DCS Port Fault, Emergency Shutdown, Hot Standby Change, and MOV Alerts.
- SMTP:** A text field containing 'smtp.gmail.com' and a 'Configure' button.
- Primary DNS:** Four octet fields, each containing '0'.
- Secondary DNS:** Four octet fields, each containing '0'.
- Buttons:** 'Back', 'Delete', 'Add', and 'Accept' buttons at the bottom.

7.2.2 Alarm Listener Configuration

Once the SMTP configuration has been completed, alarm listeners can be added to the email notification system so that email alerts are sent when any of the following network events occur: Network Fault, DCS Port Fault, Emergency Shutdown, Hot Standby Change, or MOV Alerts. Any or all of the Master Station III events can be selected for each individual listener.

To add an event listener, click the “Add” button on the Email Notification Screen and enter the desired email address as shown in Figure 7.7.

Figure 7.7 - Add Email Listener




The 'Add Email Listener' dialog box is shown. It features an 'Email Address:' label and a 'Cancel' button. Below is a grid of buttons for entering an email address:

a	b	c	d	e	f	g	Del
h	i	j	k	l	m	n	CLR
o	p	q	r	s	t	u	ENT
Sft	v	w	x	y	z	.	

After entering desired email address, the Master Station will send a confirmation email to the address. Check the email account to verify that the email address was entered correctly.

Following the email verification, the Master Station returns to the Email Notification screen where the email address can be selected and alerts added to the selected email. Click on the desired notifications for the email address. Selections are highlighted in green as seen in Figure 7.8.

Figure 7.8 - Alarm Selections



The screenshot shows the 'Email Notification' screen with the 'Active' status. On the left, an email address 'email@gmail.com' is listed. To the right, a list of alarm types is displayed: 'Network Fault', 'DCS Port Fault', 'Emergency Shutdown', 'Hot Standby Change', and 'MOV Alerts'. The last four items are highlighted with green borders. Below this list, there are fields for 'SMTP:' (smtp.gmail.com), 'Primary DNS:' (0.0.0.0), and 'Secondary DNS:' (0.0.0.0), each with a 'Configure' button. At the bottom, there are four buttons: 'Back', 'Delete', 'Add', and 'Accept'.


8

System Configuration

8.1 Main Menu

Upon successful login as a user assigned to either Configure or Administrator role level, the System Configuration button on the Main Menu screen will be present. Simply touching the System Configuration button will advance the HMI display to the System Configuration screen (Figure 8.2). By selecting Exit, the user will end the session and log out.

Figure 8.1 - Main Menu



8.2 System Configuration

The System Configuration main menu allows the user to view/configure eight distinct areas within the Master Station:

System Information: provides current firmware version and access to settings for language, clock and screensaver.

Redundant Config: provides access to setting the unit's current mode, startup mode, and redundancy mode.

Change MOV Tags: allows for customizing MOV tag names for each addressed unit.


User Administration: present when logged in as Administrator, it permits the addition/deletion of users and their respective roles.

DCS Configuration: enables communication settings to the Host device.

MOV Network Config: enables user to select active MOVs for the RS-485 field network.

Configure Files: enables user to load, save, or restore a system configuration.


Figure 8.2 - System Configuration



8.2.1 System Information

The System Information menu (Figure 8.3) allows the user to view the Master Station's currently loaded firmware version. In addition, the menu provides means for setting the system clock, screen saver, and language parameters.


Figure 8.3 - System Information



8.2.1.1 Version

The Version screen (Figure 8.4) displays the Master Station's currently loaded firmware version.

Figure 8.4 - Version



8.2.1.2 Language

The Language menu (Figure 8.5) allows the user to set the unit's display language by selecting the desired language button.


Figure 8.5 - Language Menu



8.2.1.3 Clock

The Clock menu (Figure 8.6) allows the user to set the unit's clock parameters including the current time and enabling/disabling the use of a time server to retrieve the current time. If the time server option is enabled, the IP address field will become editable and can be used to indicate the desired server IP.


Figure 8.6 - Clock



The screenshot shows the 'Master Station Clock' interface. At the top, it says 'Master Station Clock' and 'Active'. Below this, there are five input fields for time: '1' (Month), '18' (Day), '2012' (Year), '8' (Hours), and '54' (Minutes). Below these fields are labels: 'Month', 'Day', 'Year', 'Hours', and 'Minutes'. Underneath, there is a 'Time Server IP:' field with the value '129 . 6 . 15 . 28'. Below that, there are two buttons: 'Enable/Disable Time Server:' (set to 'Disabled') and 'Configure Local Time Zone:' (set to 'Time Zone'). At the bottom, there is a timestamp 'Wed Jan 18 08:55:05 EST 2012' and three buttons: 'Back', 'Accept', and 'Main Menu'.

Additionally, the Master Station Clock can be set to the correct local time zone by selecting the Time Zone button in the Clock screen. The time zone is configured by selecting the region and locale in which the Master Station is located.

Figure 8.7 - Time Zone




The screenshot shows the 'Master Station Time Zone' interface. At the top, it says 'Master Station Time Zone' and 'Active'. Below this, there is a section titled 'Set Time Zone by Region and Locale'. Inside this section, there are two dropdown menus: 'Select Region' and 'Select Locale'. Below these dropdowns, there is a timestamp 'Wed Jan 18 08:58:03 EST 2012' and three buttons: 'Back', 'Accept', and 'Main Menu'.

8.2.1.4 Screen Saver

The Screen Saver menu (Figure 8.8) allows the user to set the unit's screen saver parameters. The screen saver can be set to activate between one minute and 15 minutes after the last screen use. Alternatively, the screen saver can be disabled entirely.

Figure 8.8 - Screen Saver




The screenshot shows the 'Screen Saver' interface. At the top, it says 'Screen Saver' and 'Active'. Below this, there is a section titled 'Screen Saver Timeout (min):'. Inside this section, there are two buttons: '>' and '<'. Below these buttons, there is a text field with the value '10' and the label 'Minute'. Below the text field, there is a button labeled 'Enabled'. Below the 'Enabled' button, there is a button labeled 'Keypad'. At the bottom, there are three buttons: 'Back', 'Save', and 'Main Menu'.

8.2.2 Redundant Configuration

The Configure Hot Standby screen (Figure 8.9) enables the user to configure the Master Station for Hot Standby operation. The current mode and startup mode can be set to Active, Standby, or Disabled. In addition, if two modules are present, redundancy should be enabled to allow for Hot/Standby swapping.

NOTE: If redundancy is disabled, Standby is not a valid option.


Figure 8.9 - Configure Hot Standby



The screenshot shows the 'Redundant Config' window with a title bar indicating 'Active'. It contains three sections of buttons: 'Current Mode' with 'Active', 'Standby', and 'Disabled' buttons; 'Startup Mode' with 'Active', 'Standby', and 'Disabled' buttons; and 'Redundancy Mode' with 'Enabled' and 'Disabled' buttons. The 'Active' buttons in the first two sections and the 'Disabled' button in the third section are highlighted with green borders. A 'Back' button is located at the bottom left.

When the Redundant Configuration is enabled and changes are saved in the Active unit, the two redundant units perform a configuration file transfer. During the configuration file sync, all user operation is disabled until the synchronization is finished. Once the Active unit is finished sending the files, operation is restored. The Standby unit operation is restored shortly after.

Figure 8.10 - Configuration Transfer Lockout




The screenshot shows a 'Configuration Lockout' window with a title bar. The main text area displays the message 'HMI Disabled for Configuration Transfer.' The window has a light gray background and a darker gray footer area.

8.2.3 Change MOV Tags

This view enables the user to set or modify MOV tag names. Simply select the desired addressed MOV tag name box and a keypad will appear.

Figure 8.11 - Tag List




The Tag List screen displays a grid of 21 tags, each consisting of a numeric ID and a MOVFU code. The tags are arranged in three columns: 001-007, 008-014, and 015-021. Navigation buttons include Cancel, Back, Save, and Next.

Tag ID	MOVFU Code
001	MOVFU001
002	MOVFU002
003	MOVFU003
004	MOVFU004
005	MOVFU005
006	MOVFU006
007	MOVFU007
008	MOVFU008
009	MOVFU009
010	MOVFU010
011	MOVFU011
012	MOVFU012
013	MOVFU013
014	MOVFU014
015	MOVFU015
016	MOVFU016
017	MOVFU017
018	MOVFU018
019	MOVFU019
020	MOVFU020
021	MOVFU021

8.2.4 User Administration

The User Administration screen (Figure 8.12) is accessible when the user is logged in as an Administrator (see User Rights Overview in Section 1). It permits the addition or deletion of individual users, as well as the assignment of user passwords and roles within the Master Station.

Figure 8.12 - User Administration




The User Administration screen features a central column of four buttons: Add User, Delete User, User Settings, and Change Password. At the bottom are Back and Main Menu buttons. The screen is titled 'User Administration' and has an 'Active' status indicator.

8.2.5 DCS Configuration

The DCS Configuration screen (Figure 8.13) allows the user to configure communication port parameters in order to successfully link the Master Station to the control system's Host device (DCS/PLC/etc.). Furthermore, data registry mapping is accomplished by selecting the Configure Data Table button.

Figure 8.13 - DCS Configuration




The DCS Configuration screen includes buttons for Serial Port, Ethernet Port, Configure Data Table, and Exit. Below these are two configuration options: 'HMI State During Comms' (set to Enabled) and 'DCS Comm Lockout Time (ms)' (set to 5000). Navigation buttons at the bottom include Back and Main Menu. The screen is titled 'DCS Configuration' and has an 'Active' status indicator.

8.2.6.1 Serial Port

The DCS serial port on the rear of the Master Station III unit is configured via the Serial Port screen (Figure 8.14). Simply select appropriate settings for desired application, then save.

Settings available for DCS communication include: baud rate, parity, electrical standard, DCS address, timeout, RTS ON delay, and RTS OFF delay. Serial connection requires null modem cable/adaptor.

Figure 8.14 - Serial Port Configuration



The screenshot shows the 'DCS Configuration' window with an 'Active' status indicator. The settings are as follows:

Parameter	Value
Baud Rate	9600
DCS Address	1
Timeout (ms)	5000
RTS ON Delay (ms)	10
RTS OFF Delay (ms)	10
Parity	Even
Electrical	RS-232

Buttons at the bottom: Back, Accept, Cancel.

Baud: Communication rate in bits per second.

Parity: Error checking option for serial communication.

Timeout: Defines the maximum acceptable response delay time from the MODBUS Slaves after request sent by Master.

RTS ON Delay: Delay the timing to start sending the message after the RTS (Request To Send) signal turns ON.

RTS OFF Delay: Delay the timing to turn OFF the RTS (Request To Send) signal after the message sent to the external device is completed.

Electrical: Serial standard interface.

These values are dependent upon the message reply length as well as the poll rate.

8.2.6.2 Ethernet Port

The Ethernet port assigned to the control system's Host device, is configured via the Configure Ethernet Port screen (Figure 8.15) to communicate via Modbus TCP/IP. Simply set the desired IP address, mask, gateway, and Hot Standby IP address (if applicable) and then save entries. Please note that each Master Station processing unit must be configured with a unique IP address, mask, gateway, and Hot Standby IP address (if Hot Standby is installed).

Touching each octet on the configuration screen will allow the user to enter the address.

Figure 8.15 - Configure Ethernet Port

Configure Ethernet Port		Active
IP Address:	255 . 255 . 255 . 255	
Mask:	255 . 255 . 255 . 255	
Gateway:	255 . 255 . 255 . 255	
Hot Standby IP:	255 . 255 . 255 . 255	
Back Save		

NOTE: Use port 4502 for Modbus communications.

8.2.6.3 Configure Data Table

The Master Station data table is configurable for the Modbus Function codes 02, 03, 05/15, 06/16. The Modbus function code 01 has a fixed data table and does not permit user alteration. The data tables are edited by using the Configure DCS Data Table menu (Figure 8.16).

Figure 8.16 - Configure DCS Data Table

Configure DCS Data Table		Active
Modbus FC 02 Read Input Status		
Modbus FC 03 Read Holding Registers		
Modbus FC 05/15 Force Coils		
Modbus FC 06/16 Preset Registers		
Back	Exit	

8.2.6.3.1 Modbus FC 02 Read Input Status

Touching the “Modbus FC 02 Read Input Status” button will take the user to the FC 02 Read Input Status Screen (Figure 8.17) for selection of desired input status bits from field unit holding registers 9-13.

Figure 8.17 - FC-02 Read Input Status

FC 02 Read Input Status		Register # 9
Opened	Over Temperature Fault	
Closed	Unavailable	
Stopped	Channel A Fault	
Opening	Channel B Fault	
Closing	Open T. Switch Fault	
Valve Jammed	Close T. Switch Fault	
Local Mode	Op. Manually Fault	
Combined Fault	Phase Error	
Back	Save	Next

Selecting the “Next” button will advance the screen from registers 9 through 13.

The Function Code -02 mapping is a static mapping of the total input table as shown in Table 8.1 per MOV. A total of 80 bits represent an individual MOV. The use of this function code will provide the user with the input status bits that are used to develop holding registers 9 through 13. Only the enabled bits will be returned as valid data (otherwise, zeros). Address affect is accounted for in MS III decoding process (i.e., 10,000).

Table 8.1 - Status Bit Definitions

Bit Number	Modbus Bit Address	MX/DDC
129	128	Opened
130	129	Closed
131	130	Stopped in mid-travel
132	131	Opening
133	132	Closing
134	133	Valve jammed
135	134	Not in remote
136	135	Combined fault
137	136	Over-temperature fault
138	137	Actuator failing to de-energize
139	138	Channel A fault
140	139	Channel B fault
141	140	Open torque switch fault
142	141	Close torque switch fault
143	142	Valve operated manually fault
144	143	Phase error
145	144	Open inhibit active
146	145	Close inhibit active
147	146	Not used
148	147	Not used
149	148	One or more phases is missing
150	149	Reverse phase sequence is occurring
151	150	ESD conflict
152	151	Inhibit conflict
153	152	Use in local/stop (input must be set for CSE and enabled)
154	153	Not used
155	154	Network emergency shutdown (ESD) is active
156	155	Local emergency shutdown is active
157	156	Field unit microprocessor has reset since the last poll
158	157	MX in stop move
159	158	Opening in local mode
160	159	Closing in local mode
161	160	Close contactor (interlocked)
162	161	Open contactor (interlocked)
163	162	S1 or R1 (opt)
164	163	S2 or R2 (opt)
165	164	R3 (opt)
166	165	R4 (opt)
167	166	R5 (opt)

Table 8.1 - Status Bit Definitions (continued)

Bit Number	Modbus Bit Address	MX/DDC
168	167	R6 (opt)
169	168	R7 (opt)
170	169	Network relay
171	170	R8 (opt)
172	171	Not used
173-176	172-175	Mov series (0=1, A=9)
177	176	Remote switch
178	177	Thermal overload
179	178	Open torque switch
180	179	Open limit switch
181	180	Close torque switch
182	181	Close limit switch
183	182	Not used
184	183	Not used
185	184	User Input 0
186	185	User Input 1
187	186	User Input 2
188	187	Remote stop input
189	188	Remote open input
190	189	Remote close input
191	190	Not used
192	191	Not used
193	192	Analog board 1 present
194	193	Analog board 2 present
195	194	Analog Input #1 lost
196	195	Analog Input #2 lost
197	196	Network Channels A/B timed out
198	197	Relay board R5-R8 present
199	198	DDC board present
200	199	Relay board R1-R4 and RM present
201	200	FF board present
202	201	PB PA board present
203	202	CLE assigned for input 2
204	203	DNET board present
205	204	Lost Phase Input
206	205	Phase Reverse Input
207	206	Not used
208	207	PB DP board present

From DCS, user must address the Master Station III and poll according to the FC-02 data table. See the following example of a request/response exchange between the DCS and the Master Station III.

Example of read inputs command

Poll Master Station for 16 inputs starting at input 81 (i.e., field unit #2)

Query: 01020050001079D7

Response: 0102020408BABE

Table 8.2 - Function Code -02 Example Message Breakdown

Query		Response	
01	MSIII Unit Address	01	MSIII Unit Address
02	Function	02	Function
00	Starting Address Hi	02	Byte Count
50	Starting Address Lo	04 ¹	Data (Inputs 10088 - 10081; MOV2)
00	No. of Points Hi	08 ²	Data (Inputs 10096 - 10089; MOV2)
10	No. of Points Lo	BABE	Error Check (CRC)
79D7	Error Check (CRC)		


NOTE 1: 04h equals 0000 0100 (actuator stopped in mid-travel input bit is ON)

NOTE 2: 08h equals 0000 1000 (actuator Channel B fault input bit is ON)

8.2.6.3.2 Modbus FC 03 Read Holding Registers

Touching the “Modbus FC 03 Read Holding Registers” button will take the user to the Modbus Holding Registers screen (Figure 8.18) for selection of desired field unit holding registers 3-15. Note that registers 8 and 9 are always included in the data table.

Figure 8.18 - Modbus Holding Registers



Modbus Holding Registers		Active
# 3 Analog Output 1	# 11 Digital Outputs	
# 4 Analog Output 2	# 12 Digital Inputs 1	
# 5 Main Power (Volts)	# 13 Digital Inputs 2	
# 6 Analog Input 1	# 14 Compartment Temp.	
# 7 Analog Input 2	# 15 Torque	
# 8 Position		
# 9 Status		
# 10 Fault		
Back	Save	Next

Selecting the “Next” button will advance the screen to the following sample data table screen:

Figure 8.19 - FC-03 Sample Data Table

Data Table Modbus Function Code 03						Active
Reg. #	MOV #	Meaning	Reg. #	MOV #	Meaning	
40001	1	Pos	40011	6	Pos	
40002	1	Status	40012	6	Status	
40003	2	Pos	40013	7	Pos	
40004	2	Status	40014	7	Status	
40005	3	Pos	40015	8	Pos	
40006	3	Status	40016	8	Status	
40007	4	Pos	40017	9	Pos	
40008	4	Status	40018	9	Status	
40009	5	Pos	40019	10	Pos	
40010	5	Status	40020	10	Status	

Back

NOTE: Data table shown with only registers 8 and 9 (Position and Status) selected.

This function code is used to read the binary contents of holding registers. This function code is typically used during the network polling cycle. A network poll must consist of field unit registers 9 (Status) and 10 (Fault) at a minimum. Holding register 8 should also be polled when the actuator is configured for the analog feedback option or position control. See Table 8.4 for a complete listing of the holding registers.

Example of read multiple registers command

Poll Master Station for 2 registers starting at register 27 (i.e., field unit #14)

Query: 0103001A0002E5CC

Response: 010304003200445BCF

Table 8.3 - Function Code -03 Example Message Breakdown

Query		Response	
01	MSIII Unit Address	01	MSIII Unit Address
03	Function	03	Function
00	Starting Address Hi	04	Byte Count
1A	Starting Address Lo	00	Data Hi (Register 40027; MOV14)
00	No. of Points Hi	32 ¹	Data Lo (Register 40027; MOV14)
02	No. of Points Lo	00	Data Hi (Register 40028; MOV14)
E5CC	Error Check (CRC)	44 ²	Data Lo (Register 40028; MOV14)
		5BCF	Error Check (CRC)

NOTE 1: 0032h equals 50 decimal (actuator Analog Input 1 in percent format)

NOTE 2: 0044h equals 68 decimal or 0000 0000 0100 0100 (actuator stopped between limits in local mode)

Table 8.4 - Register Definitions

Register #	Description	Meaning
1	Command	Registers 1 and 2 are write-only registers used for Modbus Function Code 06
2	Argument	Registers 1 and 2 are write-only registers used for Modbus Function Code 06
3	Analog Output 1	Position (APT) Value (Default 0-100) ¹
4	Analog Output 2	Torque (ATT) ⁵ Value (Default 0-100) ¹
5	Analog Input	Main Power (Volts)
6	Analog Input	Analog Input 1 (Default 0-100) ¹ User 4-20 mA / 0-20 mA Input
7	Analog Input	Analog Input 2 (Default 0-100) ¹ User 4-20 mA / 0-20 mA Input
8	Position	Valve Position, Scaled Value (Default 0-100) ¹
9	Status Register	16 Bits of field unit status: Bit 0 Opened Bit 1 Closed Bit 2 Stopped in Mid-Travel Bit 3 Opening Bit 4 Closing Bit 5 Valve jammed Bit 6 Not in Remote ² Bit 7 Combined fault ³ Bit 8 Over temperature fault Bit 9 Future Implementation Bit 10 Network Channel A fault ⁴ (Terminals 5 and 4) Bit 11 Network Channel B fault ⁴ (Terminals 13 and 14) Bit 12 Open torque switch fault Bit 13 Close torque switch fault Bit 14 Valve-operated manually fault Bit 15 Phase error

NOTE 1: Default value is scaled 0-100 of span. Changes made to “Analog Scale” affect analog registers (3, 4, 6, 7, 8) and “move-to” commands. (0-100, 0-255, 0-4095)

NOTE 2: MX/DDC actuators shipped after 2nd QTR, 1999, have the following definition of Register 9 Bit 6. When this bit has a value of 1 or true, the actuator is in LOCAL or STOP (unavailable for network control). The actuator selector switch in REMOTE (available for network control) is indicated by Register 12 Bit 0 having a value of 1 or true.

IMPORTANT: Verify host program when installing an MX/DDC actuator shipped after 2nd QTR, 1999, on a network commissioned before 2nd QTR, 1999, for proper indication of selector switch values. Failure to verify proper selector switch indication at the host may cause unsafe conditions at the facility.

MX/DDC actuators shipped prior to 2nd QTR, 1999, have the following definition for Register 9 Bit 6. When this bit has a value of 1 or true, the actuator selector switch is in LOCAL mode. This bit does not indicate STOP or REMOTE. The actuator selector switch in REMOTE (available for network control) is indicated by Register 12 Bit 0 having a value of 1 or true. Register 9 Bit 6 value 0 (zero) or false AND Register 12 Bit 0 value 0 (zero) or false indicates selector switch is in the STOP position.

NOTE 3: Combined Fault bit is high when Bit 5 or 8 or 9 or 15 or (Bits 10 and 11) is high.

NOTE 4: Channel A is physical connection A1. Channel B is physical connection A2.

NOTE 5: The ATT feature will calculate the percent of torque seen with respect to the configured unit torque setting. This percent torque value will be reflected in modbus register 3, when configured for Analog Out 1, and modbus register 4, when configured for Analog Out 2. Example: If the unit torque setting is 75%, the modbus register will be populated with a percent torque value scaled from 0% to 75% of the unit-rated torque.

Table 8.4 - Register Definitions (continued)

Register #	Description	Meaning
10	Fault Register	16 Bits of field status Bit 0 Open inhibit active Bit 1 Close inhibit active Bit 2 Not Used Bit 3 Not Used Bit 4 One or more phases are missing Bit 5 Reverse phase sequence is occurring Bit 6 ESD conflict Bit 7 Inhibit conflict Bit 8 CSE in local/stop (input must be set for CSE and enabled) Bit 9 Not Used Bit 10 Network emergency shutdown is active Bit 11 Local PB emergency shutdown is active Bit 12 Field unit microprocessor has reset since the last poll Bit 13 MX in stop mode Bit 14 Opening in local mode Bit 15 Closing in local mode
11	Digital Outputs	Value of 16 Digital Outputs Bit 0 Close contactor (Interlocked) Bit 1 Open contactor (Interlocked) Bit 2 S1 or R1 (Opt) Bit 3 S2 or R2 (Opt) Bit 4 R3 (Opt) Bit 5 R4 (Opt) Bit 6 R5 (Opt) Bit 7 R6 (Opt) Bit 8 R7 (Opt) Bit 9 Network Relay Bit 10 R8 (Opt) Bit 11 Not Used BIT 12-15 MOV Series (MX = 1, MXa = 9, QX = 6, UEC-3 = 0, UEX = 10)
12	Digital Inputs 1	Value of 16 Digital Inputs Bit 0 Remote Switch Bit 1 Thermal Overload Bit 2 Open Torque Switch Bit 3 Open Limit Switch Bit 4 Close Torque Switch Bit 5 Close Limit Switch Bit 6 Not Used Bit 7 Not Used Bit 8 User Input 0 (Default=ESD), Terminal 30 Bit 9 User Input 1 (Default=Open Inhibit), Terminal 34 Bit 10 User Input 2 (Default=Close Inhibit), Terminal 35 Bit 11 Remote Stop Input, Terminal 26 Bit 12 Remote Open Input, Terminal 25 Bit 13 Remote Close Input, Terminal 27 Bits 14-15 Not Used
13	Digital Inputs 2	Value of 16 Digital Inputs Bit 0 Analog board 1 present Bit 1 Analog board 2 present Bit 2 Analog Input 1 lost Bit 3 Analog Input 2 lost Bit 4 Network Channels A/B timed out Bit 5 Relay board R5-R8 present Bit 6 DDC board present Bit 7 Relay board R1-R4 and RM present

Table 8.4 - Register Definitions (continued)

Register #	Description	Meaning
21	Field Unit Holding Register	Special Applications Only
22	Field Unit Holding Register	Special Applications Only
23	Field Unit Holding Register	Special Applications Only
24-44	Reserved	Special Applications Only
45-47	Not Named	Special Applications Only
48	TP_START_POSITION	Special Applications Only
49	TP_STOP_POSITION	Special Applications Only
50	TP_SAMPLE	Special Applications Only
51	TP_MID_T_HIGH	Special Torque Applications Only
52	TP_MID_T_POS	Special Applications Only
53	TP_MID_T_AV_VAL	Special Torque Applications Only
54	TP_STOP_VAL	Special Applications Only
55	TP_BEFORE_MID_T_HIGH	Special Torque Applications Only
56	TP_AFTER_MID_T_HIGH	Special Torque Applications Only

Note 1: Range is +90°C to -55°C. High byte 00 indicates positive (+) and 01 indicates negative (-). Low byte indicates temperature value.

Example: 0x0019 = +25°C


0x011E = -30°C

From DCS, user must address the Master Station III and poll according to the table given in the FC -03 configuration. Address affect is accounted for in the MSIII decoding process (i.e., 40,000).

8.2.6.3.3 Modbus FC 05/15 Force Coils

Touching the “Modbus FC 05/15 Force Coils” button will take the user to the Modbus Coils screen (Figure 8.20) for selection of desired field unit coils. Note that the Open and Close Contactor coils are always included in the data table.

Figure 8.20 - Modbus Coils



The screenshot shows the 'Modbus Coils' screen with an 'Active' status indicator. It contains a list of coils: 'Open Contactor' (AR3 / R7), 'Close Contactor' (R8), 'AS1 / S1 / R1', 'AS2 / S2 / R2', 'AS3 / R3', 'AS4 / R4', 'AR1 / R5', and 'AR2 / R6'. The 'AS1 / S1 / R1' and 'AS2 / S2 / R2' coils are highlighted with green borders. At the bottom, there are 'Back' and 'Next' buttons.

Selecting the “Next” button will advance the screen to the sample data table screen shown below:

Figure 8.21 - FC-05/15 Sample Data Table

Data Table Modbus Function Code 05						Active
Reg. #	MOV #	Meaning	Reg. #	MOV #	Meaning	
0001	1	Close	0011	3	S1/R1	
0002	1	Open	0012	3	S2/R2	
0003	1	S1/R1	0013	4	Close	
0004	1	S2/R2	0014	4	Open	
0005	2	Close	0015	4	S1/R1	
0006	2	Open	0016	4	S2/R2	
0007	2	S1/R1	0017	5	Close	
0008	2	S2/R2	0018	5	Open	
0009	3	Close	0019	5	S1/R1	
0010	3	Open	0020	5	S2/R2	

Back

NOTE: Table shown with Open and Close Contactors, S1/R1 and S2/R2 Coils selected.

Function code -05 is used to force a single coil. Forcing the individual coil either ON (1) or OFF (0) will energize or de-energize a coil (digital output). Coil 1 in the field unit closes the actuator and Coil 2 opens the actuator. If the actuator is opening or closing, changing the status of coil 1 or 2 from a value of 1 to 0 will stop the actuator (the coil will automatically be set to zero when the actuator reaches the full open or full close position).

For function code -15 it should be noted that the coils are operated from the lowest coil number to the highest. Forcing coil 1 or 2 OFF (0) is considered a stop command, sending a 15 command to force two coils starting with coil 1, with coil 1 ON and coil 2 OFF, would result in the unit stopping, since coil 2 is forced OFF after coil 1 is forced ON. To prevent inadvertent Stop commands from being issued, it is recommended to force one coil at a time.

Available digital outputs are listed in Table 8.5. Force-coil commands should be issued only once for the desired field unit control. Repeated issuance of an acknowledged command will degrade network performance.

NOTE: See LMENIM2329, Installation and Operation and Maintenance Manual for MX/DDC-100 Field Unit to configure AS and AR Relays for DDC control.

Table 8.5 - DDC-100 Coil Assignments, Modbus 05 Command Usage for Digital Outputs

Coil Number	Bit Number	Function
1	00	Close/Stop
2	01	Open/Stop
3	02	S1 or R1 (Opt) Latched
4	03	S2 or R2 (Opt) Latched
5	04	R3 (Opt) Latched
6	05	R4 (Opt) Latched
7	06	R5 (Opt) Latched
8	07	R6 (Opt) Latched
9	08	R7 (Opt) Latched
10	09	R8 (Opt) Latched

The normal response to the (05) command is an echo of the command.

From DCS, user must address the Master Station III and poll according to the table given in the FC -05 configuration. See the following example of a request/response exchange between the DCS and MSIII.

Example of force coil command

Force coil 17 of Master Station ON (This will close the valve controlled by field unit 5)

Query: 01050010FF008DFF

Response: 01050010FF008DFF

Table 8.6 - Function Code -05 Example Message Breakdown

Query		Response	
01	MSIII Unit Address	01	MSIII Unit Address
05	Function	05	Function
00	Coil Address Hi	00	Coil Address Hi
10 ¹	Coil Address Lo	10	Coil Address Lo
FF	Force Data Hi	FF	Force Data Hi
00 ²	Force Data Lo	00	Force Data Lo
8DFF	Error Check (CRC)	8DFF	Error Check (CRC)

NOTE 1: 0010h equals coil address 0001 0001b (field unit 5, coil 1)

NOTE 2: FF00h requests the coil to be ON (0000h requests the coil to be OFF)

Example of force multiple coils command

Force coil 2 of field unit 23 ON. This will CLOSE the valve controlled by field unit 23. Additionally, force coil 1 of field unit 24 ON. This will OPEN the valve controlled by field unit 24.

Query: 010F002D000201033290

Response: 010F002D00024403

Table 8.7 - Function Code -15 Example Message Breakdown

Query		Response	
01	MSIII Unit Address	01	MSIII Unit Address
0F	Function	0F	Function
00	Coil Address Hi	00	Coil Address Hi
2D	Coil Address Lo	2D	Coil Address Lo
00	Quantity of Coils Hi	00	Quantity of Coils Hi
02	Quantity of Coils Lo	02	Quantity of Coils Lo
01	Byte Count	4403	Error Check (CRC)
03	Force Data Lo		
3290	Error Check (CRC)		

NOTE 1: 002D00020103h equals coil addresses 00101101b (field unit 23, coil 2) and 00101110b (field unit 24, coil 1)

8.2.6.3.4 Modbus FC 06/16 Preset Registers

Touching the “Modbus FC 06/16 Preset Registers” button will take the user to the Modbus Holding Registers screen (Figure 8.22) for configuration of desired number of holding registers to be written per MOV. The 06 command presets a value into a single-holding register (Figure 8.22), while the 16 command presets a value into a block of multiple holding registers (Figure 8.23). The data table for these function codes permit either one or two write registers per field unit.

Figure 8.22 - Modbus Holding Registers-One Per MOV



Figure 8.23 - Modbus Holding Registers-Two Per MOV



Selecting the “Next” button will advance the screen to a sample data table screen as shown below. Please note that a unique data table is created starting at register 45001. Specific field unit registry convention is as follows: DCS Command Write Register = [(MOV address –1) * (selected number of registers per MOV)] + 45001. Address affect is accounted for in MSIII decoding process (i.e., 40,000).

Figure 8.24 - FC-06/16 Sample Data Table

Data Table Modbus Function Code 06						Active
Reg. #	MOV #	Meaning	Reg. #	MOV #	Meaning	
45001	1	CMD	45011	6	CMD	
45002	1	ARG	45012	6	ARG	
45003	2	CMD	45013	7	CMD	
45004	2	ARG	45014	7	ARG	
45005	3	CMD	45015	8	CMD	
45006	3	ARG	45016	8	ARG	
45007	4	CMD	45017	9	CMD	
45008	4	ARG	45018	9	ARG	
45009	5	CMD	45019	10	CMD	
45010	5	ARG	45020	10	ARG	

Back

These function codes are typically used to command Limatorque Modbus field units by writing values directly into command/argument registers. A predetermined value may be used to open/stop/close the actuator, move the actuator to a preset position, activate/deactivate network ESD, reset the field unit, etc. See the following example of a request/response exchange between the DCS and MSIII.

Write register commands should be issued only once for the desired field unit control. Repeated issuance of an acknowledged command will degrade network performance.

Example of a single register write command

Field Unit Command. Start a network ESD operation to field unit number 101. This corresponds to writing the value 1280 to register 45201.

Query: 0106145005008F7B

Response: 0106145005008F7B

Table 8.8 - Function Code -06 First Command Message Breakdown

Query		Response	
01	MSIII Unit Address	01	MSIII Unit Address
06	Function	06	Function
14	Register Address Hi	14	Register Address Hi
50 ¹	Register Address Lo	50	Register Address Lo
05	Force Data Hi	05	Force Data Hi
00 ²	Force Data Lo	00	Force Data Lo
8F7B	Error Check (CRC)	8F7B	Error Check (CRC)

NOTE 1: 1450h equals register address 45201 (field unit 101 command register)

NOTE 2: 0500h requests the register to be preset with 1280d (start network ESD)

Example of a two-command write to a single register

“Move-To” Command. Move an actuator at address 45 to 42% open by first writing the value of 42 to register 45090. After receiving a response, write the value of 6656 to register 45089. The actuator will then move to a position of 42% open. First Command:

Query: 010613E2002AACA7

Response: 010613E2002AACA7

Table 8.9 - Function Code -06 Second Command Message Breakdown

Query		Response	
01	MSIII Unit Address	01	MSIII Unit Address
06	Function	06	Function
13	Register Address Hi	13	Register Address Hi
E2 ¹	Register Address Lo	E2	Register Address Lo
00	Force Data Hi	00	Force Data Hi
2A ²	Force Data Lo	2A	Force Data Lo
ACA7	Error Check (CRC)	ACA7	Error Check (CRC)

NOTE 1: 13E2h equals register address 45090 (field unit 45 argument register)

NOTE 2: 002Ah equals 42d

Second Command:

Query: 010613E11A00D618

Response: 010613E11A00D618

Table 8.10 - Function Code -06 Message Breakdown

Query		Response	
01	MSIII Unit Address	01	MSIII Unit Address
06	Function	06	Function
13	Register Address Hi	13	Register Address Hi
E2 ¹	Register Address Lo	E2	Register Address Lo
1A	Force Data Hi	1A	Force Data Hi
00 ²	Force Data Lo	00	Force Data Lo
D618	Error Check (CRC)	D618	Error Check (CRC)

NOTE 1: 13E1h equals register address 45089 (field unit 45 command register)

NOTE 2: 1A00h equals 6656d

Example of multiple register write command

Write the command to close an actuator (actuator CLOSE) to field units 50, 51, and 52. This corresponds to writing the value 768 into command registers 45050, 45051, and 45052.

Query: 011013B90003060300030003006ABB

Response: 011003B900035569

Table 8.11- Function Code -16 Message Breakdown

Query		Response	
01	MSIII Unit Address	01	MSIII Unit Address
10	Function	10	Function
13	Starting Address Hi	13	Starting Address Hi
B9 ¹	Starting Address Lo	B9	Starting Address Lo
00	Number of Registers Hi	00	Number of Registers Hi
03	Number of Registers Lo	03	Number of Registers Lo
06	Byte Count	5569	Error Check (CRC)
03	Preset Data Hi (MOV 50)		
00 ²	Preset Data Lo (MOV 50)		
03	Preset Data Hi (MOV 51)		
00	Preset Data Lo (MOV 51)		
03	Preset Data Hi (MOV 52)		
00	Preset Data Lo (MOV 52)		
6ABB	Error Check (CRC)		

NOTE 1: 13B9h equals register address 45050 (field unit 50 command register)

NOTE 2: 0300h requests the register to be preset with 768d (Field unit CLOSE)

See Tables 8.12 and 8.13 for valid register operations. For further reference, see DDC (Modbus) Field Unit Installation and Maintenance manual LMENIM2329.

Table 8.12 - Valid Command Register Operations

Host Commands to Field Unit Register 1	Value (Decimal)	Function
Null Command	0	No action
Open	256	Open actuator
Stop	512	Stop actuator
Close	768	Close actuator
Reset Field Unit	1024	Reset processor
Start Network ESD	1280	ESD initiate
Stop Network ESD	1536	ESD terminate
Engage Relay #1	2304	S1 or R1 (opt)
Engage Relay #2	2560	S2 or R2 (opt)
Engage Relay #3	2816	R3 (opt)
Engage Relay #4	3072	R4 (opt)
Engage Relay #5	3328	R5 (opt)
Engage Relay #6	3584	R6 (opt)
Engage Relay #7	3840	R7 (opt)
Disengage Relay #1	4352	S1 or R1 (opt)
Disengage Relay #2	4608	S2 or R2 (opt)
Disengage Relay #3	4864	R3 (opt)
Disengage Relay #4	5120	R4 (opt)
Disengage Relay #5	5376	R5 (opt)
Disengage Relay #6	5632	R6 (opt)
Disengage Relay #7	5888	R7 (opt)
Move-To (Enable) ¹	6656	Initiates "move-to"
Engage Relay #8	6912	R8 (opt)
Disengage Relay #8	7168	R8 (opt)

Note 1: This is a two-step command. A valid value must be written to Register 2 before issuing this command.

Other registers may also be preset to control or change other functions but care must always be taken to properly change these values. An improper value written to a register can cause undesirable actions from the DDC-100 Field Unit.

NOTE: Null Command—The field unit takes no action when this command is received. This command is typically used by a Host to reset the Host output register when required.

From DCS, user must address the Master Station III and poll according to the table given in the FC-06/16 configuration.

This command allows a Host to issue the “move-to” command with a single write utilizing the Modbus function code 06. Register 1 will be used to complete this command.

Rules for utilizing this command:

- Field unit scaling must be configured for 0-100.
- To use the hexadecimal method of determining a single write “move-to” command, 0x4B is always placed into the Hi Byte of Register 1. The desired position value is always placed into the Lo Byte of Register 1.
- To move the actuator to a position of 50%, place the value 0x4B in the high byte and the value of 0x32 (50 decimal) into the low byte.

Example:

Hex format: 0x4B32

To use the decimal method of determining a single write “move-to” command, add the desired position value to 19200.

Example:

Desired position: 50%

$$19200 + 50 = 19250$$

“19200 + Value” (Position Value for units capable of commands accepting 1 write “move-to”)


Table 8.13 - Valid Argument Register Operations

Values	Function
0 – 100	Desired Valve Position

8.2.7 MOV Network Config

The MOV Network Config screen (Figure 8.25) provides access to communication parameters essential for connecting the Master Station to all assigned field units. By selecting the Next button, the screen will advance to Active MOVs display (Figure 8.26) to allow user to activate desired addressed field units to be networked. After completion of MOV activation, simply select the Poll Priority tab to advance to the Polling Priority view (Figure 8.27). This screen enables the user to set the poll cycle interval for each activated MOV. After the MOV network has been configured, please save the settings under the System Configuration screen (Figure 8.28).

Figure 8.25 - MOV Network Configuration



MOV Network Configuration Active

Baud Rate: 4800, 9600, **19200**

Timeout (ms): 500

Prop Delay (ms): 2

RTS ON Delay (ms): 10

Total Active MOVs: 18

First/Last Conf. MOV: 1/18

Auto-Configure

Retries: **1**, 2

Polling Mode: Redundant Loop, **A Channel Only**, B Channel Only

Modbus Mode: **RTU**

Poll Passes: 0


Accept **Cancel** **Next**

For a baud rate of 4800, use the following initial values: Timeout - 200ms, Prop delay - 25 ms, and RTS On delay - 25 ms. These values should be adjusted to best fit the network's configuration.

For a baud rate of 9600, use the following initial values: Timeout – 200 ms, Prop delay - 20 ms, and RTS On Delay – 20 ms. These values should be adjusted to best fit the network's configuration.

For a baud rate of 19200, use the following initial values: Timeout – 200 ms, Prop delay - 15 ms, and RTS On Delay – 15 ms. These values should be adjusted to best fit the network's configuration.

Figure 8.26 - Active MOVs



Active MOVs Active


Press on a MOV to toggle activation

■ MOV Active ■ MOV Not Active

001	002	003	004	005	006	007	008	009
010	011	012	013	014	015	016	017	018
019	020	021	022	023	024	025	026	027
028	029	030	031	032	033	034	035	036
037	038	039	040	041	042	043	044	045
046	047	048	049	050	051	052	053	054

Back **Poll Priority** **Next**

Figure 8.27 - Polling Priority-Active MOVs



Polling Priority - Active MOVs Active

Press on a MOV to view status detail

1 = Poll Every Cycle
N = Poll Every Nth Cycle

Back **Next**


1	1	2	1	3	5		

In order to optimize the network efficiency, lower priority MOVs can be set to be polled at a user defined cycle.

8.2.8 Configure Files


The Configure Files screen (Figure 8.28) permits the user to load the Master Station configuration from a file (Figure 8.29), either previously saved in the device's memory or from an external USB drive.

Figure 8.28 - Configure Files



Selecting Load Config File will advance the display to the following screen:

Figure 8.29 - Load Configuration from File




Select the desired configuration file and hit the “Open” button. This will change the Master Station’s configuration according to the selected file.

In addition, the current configuration can be saved as the default settings (Figure 8.30) or the Master Station’s current configuration can be returned to the factory default settings (Figure 8.31).

To save the current configuration as the default, select the “Save as Default” button and confirm.

Figure 8.30 - Save as Default



To return to the original configuration settings the Master Station started with, select the “Restore Factory Defaults” button and confirm.

Figure 8.31 - Restore Factory Defaults




9

Diagnostics

9.1 Main Menu

Upon successful login as a user assigned to either Configure or Administrator role level, the Diagnostics button on the Main Menu screen will be present (Figure 9.1). Simply touching the Diagnostics button will advance the HMI display to the Diagnostics screen (Figure 9.2). By selecting Exit, the user will end the session and log out.


Figure 9.1 - Main Menu



9.2 Diagnostics

The Diagnostics screen (Figure 9.2) provides the user with accessibility to three core areas of MOV network data collection. The user may select the Event Log, Communication/Function Code Logger, or Polling Statistics tab to acquire data related to the respective diagnostic feature.


Figure 9.2 - Diagnostics



9.2.1 Event Log

The Event Log screen (Figure 9.3) allows the user to display the last 20 events that occurred. Each event is related to changes in login information, configuration, network status, or MOV polling activity. Every entry is defined, numbered, and time-stamped in order to maintain the logged data.

Figure 9.3 - Event Log




9.2.2 Comm/FC Logger

The Comm/FC Logger (Figure 9.4) captures Modbus requests and responses to/from the DCS and MOVs (channel A & B). Additionally, the Logger screen shows configuration changes related to channel A and/or B, Ethernet, and DCS port activity, as well as individual function codes. The channels can be selected individually to filter activity being displayed.

NOTE: The Comm/FC logger is designed for local diagnostic purposes only. While the Comm/FC logger is active, communication from the DCS/host device to the Master Station III is subject to reduced performance.


Figure 9.4 - Comm/FC Logger



9.2.3 Polling Statistics

The Polling Statistics screen (Figure 9.5) allows the user to view the polling history of each activated MOV on the network. This diagnostic feature reveals the total number of polls, errors encountered, and error rate (%) during a user-defined time frame.

Figure 9.5 - Polling Statistics




10

File Manager

10.1 Main Menu

Upon successful login as a user assigned to either Configure or Administrator role level, the File Manager button on the Main Menu screen will be present (Figure 10.1). Simply touching the File Manager button will advance the HMI display to the File Manager screen (Figure 10.2). By selecting Exit, the user will end the session and log out.


Figure 10.1 - Main Menu



10.2 File Manager

The File Manager screen (Figure 10.2) allows the user to import/export the Master Station configuration file, export the event log, and import the MOV name files. In addition, the user can update the unit's software version via this menu.


Figure 10.2 - File Manager



10.2.1 Import Config File

The Import Config File screen (Figure 10.3) allows the user to access the file chooser and select a configuration file to be copied to the default directory for the Config File archives.


Figure 10.3 - Import Config File



10.2.2 Export Config File

The Export Configuration screen (Figure 10.4) enables the user to access the file chooser and save the current configuration to a user-defined location.


Figure 10.4 - Export Config File



10.2.3 Export Event Log

The Export Event Log screen (Figure 10.5) permits the saving of diagnostic events. Each event is related to changes in log-in Information, configuration, network status, or MOV status polling activity. In addition, all captured events are defined, numbered, and time-stamped in order to maintain the logged data.


Figure 10.5 - Export Event Log



10.2.4 Import Tag File

The Import Tag File screen (Figure 10.6) allows the user to access the file chooser and select a MOV tag name file to be copied to the default directory for the tag name file archives.


Figure 10.6 - Import Tag File



10.2.5 Import Software Update

The Import Software Update screen (Figure 10.7) allows the user to access the file chooser and select a software update file to be copied to the default directory for the Master Station device software file archives.

Figure 10.7 - Update Software



11

Troubleshooting Guide

11.1 Front Panel Indicators

There are three LEDs on the front of the Master Station that provide a visual reference of the overall health of the Master Station and MOV network. These LEDs are described as follows:

- A. Network Alarm - A red LED indicates a field network communication fault.
- B. MOV Alarm - A red LED indicates a MOV device alarm is present.
- C. Power – A green LED indicates that the unit has power.

11.2 Network Status Screen

The Network Status screen provides a visual reference of the overall health of the MOV network. See Section 5 for instructions on viewing the MOV and communication channel status. MOV faults can be examined by clicking on the desired box. Communication channel faults can be examined and corrected by reviewing log files (see Section 9), verifying correct configuration parameters (see Section 8), and checking wiring connections and/or network surge protection module on rear of unit.

11.3 Blank Display

A blank display can be the result of the activated screen saver feature. If setting adjustments are required, please see Section 8. Additionally, the lack of AC/DC power to the Master Station will also cause a blank screen. After verifying power is available to the unit, disconnect the power and check the power fuse on the rear of the unit. If it is good, remove the power surge protection module and check for continuity.

11.4 Error Messages

Problem Saving File – Media Error (Full, Write Protected, Corrupted)

No USB Device Selected - Configuration save attempted without a USB device inserted in a USB port, and selected.

Error Adding User - Duplicate User entry

Error Saving To Config File - Media Error (Full, Write Protected, Corrupted)

11.5 Network Communication

11.5.1 DCS communication via RS-232/422/485

Unable to establish comm's with the DCS

- a. Confirm null modem cable connection, if using RS-232
- b. Verify DCS address setting
- c. Verify baud rate, handshaking, start bit settings
- d. Check host system settings
- e. Test the cable, replace if defective

11.5.2 DCS communication via Modbus TCP/IP

Unable to establish comm's with the DCS

- a. Confirm IP address settings
- b. In command mode, ping the MSIII, if no response, verify the MSIII and the host are on the same network
- c. Verify Ethernet path from host to the MSIII


11.5.3 MSIII communication to the MOV network

Unable to establish comm's with the MOV's

- a. Confirm proper cable connections on the first MOV in the loop and the MSIII. RS-485 is polarity sensitive
- b. Confirm RS-485 baud rate settings match MOV baud rate settings
- c. Confirm MSIII is configured for Modbus RTU mode
- d. Verify timing settings (timeout, prop delay, RTS on delay)

11.6 Surge Protection


Figure 11.1 - Surge Protection Access



11.6.1 AC Surge Protection


It is recommended to replace the surge protector if a known primary AC power surge has occurred. For a Hot Standby unit, please ensure that both main AC surge protectors are replaced. Follow the below procedure to ensure proper replacement.

Figure 11.2 - Main AC Power Input Module




Remove two screws on the main AC power input module and then remove the module from the chassis.

Figure 11.3 - Removing Main AC Input Power Module



Locate the AC surge protector, unplug wiring connector on both sides of the protector, and remove it from the cable assembly.

Figure 11.4 - AC Surge Protector



Install replacement protector by following above procedures in reverse order.

11.6.2 AC Fuse Protection

Release clip on bottom of the fuse holder and gently remove holder from main AC power input module.

Figure 11.5 - Removing Fuse Holder



Figure 11.6 - AC Fuse Holder




Check each of the two fuses, located in the holder, for continuity. Replace if necessary and reinstall the holder into the module.

11.6.3 Network Surge Protection

The network surge protector is a three-stage device for protection of the RS-485 data lines. Loss of communication on either channel A or B could result in a faulty surge protector. Please see below traces to verify proper operation of the protector.

Figure 11.7 - Network Surge Protector



If faulty, please replace device by removing the two outer screws and then the assembly. Replace with a new protector assembly.

Figure 11.8 - Removing Network Surge Protector



This page intentionally left blank.

This page intentionally left blank.

This page intentionally left blank.



Flowserve Corporation Flow Control

United States

Flowserve Limatorque
5114 Woodall Road
P.O. Box 11318
Lynchburg, VA 24506-1318
Phone: 434-528-4400
Facsimile: 434-845-9736

England

Flowserve Limatorque
Euro House
Abex Road
Newbury
Berkshire, RG14 5EY
United Kingdom
Phone: 44-1-635-46999
Facsimile: 44-1-635-36034

Japan

Limatorque – Nippon Gear Co., Ltd.
NOF Bldg. 9th Floor
1-11-11, Kita-Saiwai, Nishi-Ku
Yokohama (220-0004)
Japan
Phone: 81-45-326-2065
Facsimile: 81-45-320-5962

Singapore

Flowserve Limatorque
12, Tuas Avenue 20
Singapore 638824
Phone: 65-6868-4628
Facsimile: 65-6862-4940

China

Limatorque Beijing, Pte., Ltd.
RM A1/A2
22/F, East Area, Hanwei Plaza
No. 7 Guanghua Road, Chaoyang District
Beijing 100004, Peoples Republic of China
Phone: 86-10-5921-0606
Facsimile: 86-10-6561-2702

India

Flowserve Limatorque, Ltd.
Plot No 4
Export Promotional Industrial Park
Whitefield, Bangalore 560066
India
Phone: 91-80-40146200
Facsimile: 91-80-28410286

To find your local Flowserve Limatorque representative:

Visit www.flowserve.com/limitorque or call 1-434-528-4400

FCD LMENIM5001-01 05/12 Printed in USA.

Flowserve Corporation has established industry leadership in the design and manufacture of its products. When properly selected, this Flowserve product is designed to perform its intended function safely during its useful life. However, the purchaser or user of Flowserve products should be aware that Flowserve products might be used in numerous applications under a wide variety of industrial service conditions. Although Flowserve can (and often does) provide general guidelines, it cannot provide specific data and warnings for all possible applications. The purchaser/user must therefore assume the ultimate responsibility for the proper sizing and selection, installation, operation, and maintenance of Flowserve products. The purchaser/user should read and understand the Installation Operation Maintenance (IOM) instructions included with the product, and train its employees and contractors in the safe use of Flowserve products in connection with the specific application.

While the information and specifications contained in this literature are believed to be accurate, they are supplied for informative purposes only and should not be considered certified or as a guarantee of satisfactory results by reliance thereon. Nothing contained herein is to be construed as a warranty or guarantee, express or implied, regarding any matter with respect to this product. Because Flowserve is continually improving and upgrading its product design, the specifications, dimensions and information contained herein are subject to change without notice. Should any question arise concerning these provisions, the purchaser/user should contact Flowserve Corporation at any one of its worldwide operations or offices.

© 2012 Flowserve Corporation, Irving, Texas, USA. Flowserve is a registered trademark of Flowserve Corporation.