


**Liebert® Mini-Mate2™**  
User Manual - 5 Tons, 50 & 60Hz





---

# TABLE OF CONTENTS

<b>IMPORTANT SAFETY INSTRUCTIONS</b> .....	<b>1</b>
<b>PRODUCT MODEL INFORMATION</b> .....	<b>3</b>
<b>1.0 INTRODUCTION</b> .....	<b>6</b>
1.1 Designed to Match Computer and Electronic Equipment Needs—From Installation to Operation .....	6
<b>2.0 STANDARD FEATURES—5 TON SYSTEMS</b> .....	<b>7</b>
2.1 Evaporator Section—Split System .....	7
2.2 Condensing Unit Section—Split System .....	7
2.2.1 Indoor Centrifugal Fan Condensing Units .....	7
2.2.2 Outdoor Prop Fan Condensing Units .....	7
2.2.3 Indoor Water/Glycol Condensing Units .....	7
2.3 Chilled Water Units .....	7
2.4 System Controls .....	8
2.4.1 Other Standard Control Features .....	8
<b>3.0 OPTIONAL FACTORY-INSTALLED FEATURES - EVAPORATOR/CHILLED WATER UNITS</b> .....	<b>9</b>
3.1 Reheat .....	9
3.2 Humidifier .....	9
3.3 Sensors .....	9
3.4 Switches and Motors .....	9
3.5 Free-Cooling .....	10
3.6 Optional Configurations—Prop Fan Condensing Units .....	10
3.7 Optional Configurations—Water/Glycol Condensing Units .....	10
3.8 Optional Configurations—Chilled Water Units .....	11
<b>4.0 SHIP-LOOSE ACCESSORIES—FIELD-INSTALLED</b> .....	<b>12</b>
4.1 Remote Monitoring, Autochangeover and Leak Detection Equipment .....	12
<b>5.0 SITE PREPARATION AND INSTALLATION</b> .....	<b>14</b>
5.1 Installation Considerations .....	14
5.1.1 Room Preparation .....	14
5.1.2 Location Considerations .....	15
5.2 Ceiling Unit Weights .....	16
5.3 Equipment Inspection Upon Receipt .....	17
5.4 Installing the Ceiling Units .....	17
5.4.1 Close Coupled Installations .....	17
5.4.2 Evaporator Air Distribution .....	17
5.4.3 Piping Connections and Coolant Requirements .....	18
5.4.4 Electrical Connections .....	23
5.5 Indoor Air-Cooled Centrifugal Fan Condensing Unit Installation .....	27
5.5.1 Location Considerations .....	27
5.5.2 Electrical Connections .....	27
5.5.3 Piping Connections .....	27
5.5.4 Ducting .....	27

5.6	Outdoor Air-Cooled Condensing Unit Installation	31
5.6.1	Location Considerations	31
5.6.2	Piping Connections	32
5.6.3	Electrical Connections	32
5.7	Indoor Water- and Glycol-Cooled Condensing Unit Installation	33
5.7.1	Location Considerations	33
5.7.2	Electrical Connections	33
5.7.3	Piping Connections	33
5.8	Optional Equipment Piping	36
5.8.1	Free-Cooling Coil	36
5.8.2	Hot Water Reheat Coil	37
5.9	Checklist for Completed Installation	38
<b>6.0</b>	<b>MICROPROCESSOR CONTROL</b>	<b>39</b>
6.1	Feature Overview	39
6.2	Main Menu <Menu>	40
6.3	Setpoints	40
6.4	Status	41
6.5	Active Alarms	41
6.6	Time	41
6.7	Date	41
6.8	Setback	41
6.9	Setup Operation	42
6.9.1	Restart Time Delay	42
6.9.2	C/F Degrees	42
6.9.3	Humidity Control Method	42
6.9.4	Show DIP Switch	42
6.9.5	Valve Time (for Systems With a Modulating Chilled Water Valve)	43
6.9.6	CW Flush (for Systems with a Modulating Chilled Water Valve)	43
6.10	Change Passwords	43
6.11	Calibrate Sensors	43
6.12	Alarm Enable	44
6.13	Alarm Time Delay	44
6.14	Common Alarm Enable	44
6.15	Custom Alarms	45
6.15.1	Standard Custom Alarm Messages	45
6.16	Custom Text	45
6.17	Run Diagnostics (Available On Rev 1.001.0 and higher)	46
<b>7.0</b>	<b>SYSTEM PERFORMANCE MICROPROCESSOR CONTROLS</b>	<b>50</b>
7.1	Temperature Control	50
7.1.1	Cooling/Heating Required	50
7.1.2	Cooling Operation (Compressorized Direct Expansion and Chilled Water)	50
7.1.3	Heating Operation	50
7.2	Humidity Control	50
7.2.1	Dehumidification/Humidification Required	50
7.2.2	Dehumidification Operation, Compressorized Direct Expansion (DX) Systems	50
7.2.3	Humidification Operation	51

7.3	Load Control Features . . . . .	51
7.3.1	Communications . . . . .	51
<b>8.0</b>	<b>ALARMS . . . . .</b>	<b>52</b>
8.1	Alarms: Definitions and Troubleshooting . . . . .	52
8.1.1	Custom Alarms . . . . .	52
8.1.2	High Head Pressure . . . . .	52
8.1.3	Humidity Level . . . . .	53
8.1.4	Temperature . . . . .	53
8.1.5	Humidifier Problem Alarm . . . . .	53
8.1.6	High Water Alarm . . . . .	53
8.1.7	Loss of Power . . . . .	54
8.1.8	Short Cycle . . . . .	54
8.2	Optional/Custom Alarms . . . . .	54
8.2.1	Change Filter . . . . .	54
8.2.2	High Temperature Sensor . . . . .	54
8.2.3	Smoke Sensor . . . . .	54
<b>9.0</b>	<b>SYSTEM OPERATION, TESTING AND MAINTENANCE . . . . .</b>	<b>55</b>
9.1	System Testing . . . . .	55
9.1.1	Environmental Control Functions . . . . .	55
9.1.2	Cooling . . . . .	55
9.1.3	Heating . . . . .	55
9.1.4	Humidification . . . . .	55
9.1.5	Dehumidification . . . . .	55
9.1.6	Remote Shutdown . . . . .	55
9.2	Maintenance and Component Operation . . . . .	55
9.2.1	Electric Panel . . . . .	55
9.2.2	Filters . . . . .	55
9.2.3	Blower System . . . . .	56
9.2.4	Blower Removal . . . . .	56
9.2.5	Refrigeration System . . . . .	56
9.3	Replacement Procedures . . . . .	59
9.3.1	Compressor Replacement . . . . .	59
9.3.2	Electrical Failure . . . . .	59
9.3.3	Steam Generating Humidifier-Operation Procedures . . . . .	61
9.3.4	Humidifier Circuit Board Adjustments . . . . .	62
<b>10.0</b>	<b>MAINTENANCE INSPECTION CHECKLIST . . . . .</b>	<b>63</b>
<b>11.0</b>	<b>TROUBLESHOOTING . . . . .</b>	<b>64</b>

## FIGURES

Figure 1	Split system evaporators . . . . .	3
Figure 2	Air-cooled systems—indoor centrifugal condensing units . . . . .	3
Figure 3	Air-cooled systems—outdoor prop fan condensing units . . . . .	4
Figure 4	Water/glycol-cooled systems—indoor condensing units . . . . .	4
Figure 5	Chilled water systems . . . . .	5
Figure 6	Wall-box . . . . .	8
Figure 7	Free-cooling arrangement . . . . .	10
Figure 8	Air-cooled systems . . . . .	15
Figure 9	Water/glycol cooled systems . . . . .	16

Figure 10	Chilled water systems . . . . .	16
Figure 11	Refrigerant piping diagram . . . . .	20
Figure 12	Evaporator unit dimensional data . . . . .	22
Figure 13	Threaded rod and hardware kit installation . . . . .	23
Figure 14	Evaporator unit electrical connections . . . . .	25
Figure 15	Close coupled installation . . . . .	26
Figure 16	Indoor air-cooled centrifugal condensing unit dimensions and pipe connections . . . . .	28
Figure 17	Indoor air-cooled centrifugal condenser electrical connections . . . . .	29
Figure 18	System piping with indoor or outdoor air-cooled condensing unit . . . . .	30
Figure 19	Dimensions—Air-cooled systems, standard ambient outdoor condensing module . . . . .	31
Figure 20	Dimensions—Air-cooled systems, high ambient and Quiet-Line condensing module . . . . .	32
Figure 21	Indoor water/glycol condensing unit dimensional data . . . . .	34
Figure 22	Indoor water/glycol condensing unit electrical field connections . . . . .	35
Figure 23	System piping with indoor water/glycol cooled condensing unit . . . . .	36
Figure 24	Optional free-cooling coil (3-way valve) on water/glycol units . . . . .	37
Figure 25	Optional hot water reheat (two-way valve) . . . . .	37
Figure 26	Wall box . . . . .	39
Figure 27	Control menu . . . . .	48
Figure 28	Control board—inside evaporator . . . . .	49
Figure 29	Wall box board . . . . .	49
Figure 30	Hot gas bypass . . . . .	58

## TABLES

Table 1	System configurations—60 Hz . . . . .	5
Table 2	System configurations—50 Hz . . . . .	5
Table 3	Application limits, evaporator and chilled water units* . . . . .	14
Table 4	Application limits, indoor and outdoor air-cooled condensing units . . . . .	14
Table 5	Application limits, indoor water/glycol cooled condensing units . . . . .	14
Table 6	Unit weights . . . . .	16
Table 7	Evaporator external static pressure . . . . .	18
Table 8	Recommended refrigerant line sizes . . . . .	19
Table 9	Equivalent lengths for various pipe fittings, ft (m) . . . . .	19
Table 10	Pipe length and condenser elevation relative to evaporator . . . . .	20
Table 11	Refrigerant charge . . . . .	21
Table 12	Line charges - refrigerant per 100 ft. (30m) of Type L copper tube . . . . .	21
Table 13	Refrigerant quick connect sizes and torque . . . . .	21
Table 14	Weights for standard ambient outdoor condensing modules, air-cooled systems . . . . .	31
Table 15	Net weight, high ambient and Quiet-Line condensing modules, air-cooled systems . . . . .	32
Table 16	Night and weekend setback plan . . . . .	41
Table 17	Default setpoints and allowable ranges . . . . .	41
Table 18	Setup functions, default values and allowable ranges . . . . .	43
Table 19	Alarm default time delays . . . . .	44
Table 20	Equipment switch settings (unit control board) . . . . .	46
Table 21	Switch settings (wall box board) . . . . .	46
Table 22	Cooling and dehumidification load response of hot gas bypass . . . . .	50
Table 23	Typical discharge pressure . . . . .	57
Table 24	Humidifier control board DIP switch settings . . . . .	62
Table 25	Troubleshooting . . . . .	64

---

## IMPORTANT SAFETY INSTRUCTIONS

---

### SAVE THESE INSTRUCTIONS

This manual contains important safety instructions that should be followed during the installation and maintenance of the Liebert Mini-Mate2. Read this manual thoroughly before attempting to install or operate this unit. Only properly trained and qualified personnel should move, install or service this equipment. Adhere to all warnings, cautions and installation, operating and safety instructions on the unit and in this manual. Follow all installation, operation and maintenance instructions and all applicable national and local building, electrical and plumbing codes.



#### WARNING

Arc flash and electric shock hazard. Disconnect all electric power supplies and wear protective equipment per NFPA 70E before working within electric control enclosure. Failure to comply can cause serious injury or death.

Customer must provide earth ground to unit, per NEC, CEC and local codes, as applicable.

Before proceeding with installation, read all instructions, verify that all the parts are included and check the nameplate to be sure the voltage matches available utility power.

The Liebert microprocessor control does not isolate power from the unit, even in the Unit Off mode. Some internal components require and receive power even during the Unit Off mode.

The line side of the disconnect switch on the front of the unit contains live high voltage. The only way to ensure that there is NO voltage inside the unit is to install and open a remote disconnect switch and check the internal power supply wires with a voltmeter. Refer to unit electrical schematic. Follow all applicable national and local electric codes.



#### WARNING

Risk of explosive discharge from high-pressure refrigerant. Can cause injury or death.

This unit contains fluids and gases under high pressure. Relieve pressure before working with piping.



#### WARNING

Risk of refrigerant system rupture or explosion from overpressurization. Can cause equipment damage, injury or death.

If a pressure relief device is not provided with the condenser unit, the system installer must provide and install a discharge pressure relief valve per national and local codes in the high side refrigerant circuit. Do not install a shutoff valve between the compressor and the field-installed relief valve. Do not isolate any refrigerant circuits from overpressurization protection.



#### WARNING

Risk of high-speed moving parts. Can cause injury or death.

Open all local and remote electrical power disconnect switches, verify with a voltmeter that power is Off and the blower, pulleys and belts have stopped moving before working in the unit cabinet.



#### CAUTION

Risk of contact with hot surfaces. Can cause injury.

The refrigerant discharge lines, humidifiers and reheats are extremely hot during unit operation. Allow sufficient time for them to cool before working within the unit cabinet. Use extreme caution and wear protective gloves and arm protection when working on or near hot discharge lines, humidifiers and reheats.



## **CAUTION**

Risk of sharp edges, splinters and exposed fasteners. Can cause injury.

Only properly trained and qualified personnel wearing appropriate safety headgear, gloves, shoes and glasses should attempt to move the unit, lift it, remove packaging from or prepare the unit for installation.

## **NOTICE**

Risk of leaking water. Can cause equipment and building damage.

Improper installation, application and service practices can result in water leakage from the unit. Do not mount this unit over equipment or furniture that can be damaged by leaking water. Install a watertight drain pan with a drain connection under the cooling unit and the ceiling mounted water/glycol condenser unit. Route the drain line to a frequently used maintenance sink so that running water can be observed and reported in a timely manner. Post a sign to alert people to report water flowing from the secondary drain pan. Emerson recommends installing monitored leak detection equipment for unit and supply lines and in the secondary drain pan. Check drain lines periodically for leaks, sediment buildup, obstructions, kinks and/or damage and verify that they are free running.

## **NOTICE**

Risk of a leaking coil due to freezing and/or corrosion. Can cause equipment and building damage.

Cooling coils and piping systems that are connected to open cooling towers or other open water/glycol systems are at high risk for freezing and premature corrosion. Fluids in these systems must contain the proper antifreeze and inhibitors to prevent freezing and premature coil corrosion. The water or water/glycol solution must be analyzed by a competent water treatment specialist before startup to establish the inhibitor requirement. The water or water/glycol solution must be analyzed every six months to determine the pattern of inhibitor depletion. The complexity of water-caused problems and their correction makes it important to obtain the advice of a water treatment specialist and follow a regularly scheduled maintenance program.

## **NOTICE**

Risk of damage from forklift. Can cause unit damage.

Keep tines of the forklift level and at a height suitable to fit below the skid and/or unit to prevent damage.

## **NOTICE**

Risk of improper storage. Can cause unit damage.

Keep the Liebert Mini-Mate2 upright, indoors and protected from dampness, freezing temperatures and contact damage.



**PRODUCT MODEL INFORMATION**

Figure 1 Split system evaporators




Figure 2 Air-cooled systems—indoor centrifugal condensing units




Figure 3 Air-cooled systems—outdoor prop fan condensing units




Figure 4 Water/glycol-cooled systems—indoor condensing units




Figure 5 Chilled water systems




Table 1 System configurations—60 Hz

Nominal Capacity	Cooling Unit	Condensing Unit		
		Indoor Air-Cooled Centrifugal Fan	Outdoor Air-Cooled Propeller Fan	Indoor Water/Glycol
5 Tons	MMD60E	MCD65A	PFH067A	MCD69W
5 Tons	MMD92C	Self Contained – Chilled Water		

Table 2 System configurations—50 Hz

Nominal Capacity	Cooling Unit	Condensing Unit		
		Indoor Air-Cooled Centrifugal Fan	Outdoor Air-Cooled Propeller Fan	Indoor Remote Water/Glycol
5 Tons	MMD59E	MCD64A	PFH066A	MCD68W
	MMD91C	Self-Contained – Chilled Water		

---

## 1.0 INTRODUCTION

---

### 1.1 Designed to Match Computer and Electronic Equipment Needs—From Installation to Operation

Installed above the ceiling, Liebert Mini-Mate2 Precision Cooling systems control the cooling, humidity and air distribution required by sensitive electronic equipment. A range of sizes and configurations is available to meet varying sites' needs.

The Liebert Mini-Mate2 is also easy to use. Advanced microprocessor technology allows easy, precise control, and menu-driven monitoring keeps you informed of system operation through the LCD readout. These features, combined with Emerson quality construction and reliable components, guarantee satisfaction from installation through operation.

#### Liebert Precision Cooling

Liebert Precision Cooling systems are designed to control the environment required for computers and other sensitive electronic equipment. The Liebert Mini-Mate2 provides complete control on an around-the-clock basis and the high sensible heat ratio required by sensitive electronic equipment.

#### Easy Installation

The Liebert Mini-Mate2 is a split-system evaporator combined with an air-, water- or glycol-cooled condensing unit or is a self-contained, chilled water unit. Each split system has thermostat-type wiring to controls and condensing unit. Optional sweat adapters assist with field refrigerant piping.

#### Easy to Service

Low-maintenance components are easily accessed through removable front panels. Spare parts are always in Emerson inventory and available on short notice.

#### Advanced Control Technology

A menu-driven microprocessor control system provides precise temperature and humidity control and accurate alarm setpoints. Using touch-sensitive buttons, the wall-mounted monitor/control panel allows you to select and display temperature and other monitored parameters.

#### High Efficiency

High sensible heat ratio, scroll compressor and precise microprocessor control allow the system to operate efficiently.

#### Space Saving Design

All indoor components are installed above the ceiling, so no floor space is required.

#### Reliable

The Liebert Mini-Mate2 family installed base is a testimony to the system reliability. Components include a rugged scroll compressor, high-efficiency copper tube, aluminum-fin evaporator coil and a double inlet, direct drive fan.

#### Agency Listed

Standard 60Hz units are CSA certified to the harmonized U.S. and Canadian product safety standard, CSA C22.2 No 236/UL 1995 for "Heating and Cooling Equipment" and are marked with the CSA c-us logo.



#### Location

When considering installation locations, consider that these units contain water and that water leaks can cause damage to sensitive equipment below. Do not mount these units above sensitive equipment. A field-supplied pan with drain must be supplied beneath cooling units and water/glycol condensers.

Do not mount units in areas where normal unit operating sound might disturb the working environment.

---

## 2.0 STANDARD FEATURES—5 TON SYSTEMS

---

### 2.1 Evaporator Section—Split System

The evaporator section is designed for ceiling installation. The cabinet and chassis are constructed of heavy gauge galvanized steel. The unit can be serviced using only one side increasing its versatility in mounting locations. Mounting brackets are factory-attached to the cabinet. Internal cabinet insulation meets ASHRAE 62.1 requirements for Mold Growth, Humidity & Erosion, tested per UL 181 & ASTM 1338 standards. The evaporator section includes the evaporator coil, R-407C unit charge, filter-drier, factory-mounted disconnect switch, adjustable belt-drive blower assembly and microprocessor control with wall-mounted control box. The unit is provided with supply and return air openings for field-supplied ducting. Evaporators can be configured with canister humidifier and/or reheat. An indoor or outdoor condensing unit must be selected for each evaporator.

### 2.2 Condensing Unit Section—Split System

#### 2.2.1 Indoor Centrifugal Fan Condensing Units

Indoor Air-Cooled Centrifugal Fan Condensing Units include scroll compressor, factory-mounted disconnect switch, condenser coil, R-407C unit charge, belt-driven centrifugal blower assembly, high-pressure switch, Liebert Lee-Temp™ head pressure control system, hot gas bypass and liquid-line solenoid valve. Unit must be mounted indoors. Condensing unit is designed to use outdoor air with temperatures ranging from -30°F to 95°F (-34°C to 35°C).

#### 2.2.2 Outdoor Prop Fan Condensing Units

Outdoor Prop Fan Condensing Units include scroll compressor, condenser coil, R-407C unit charge, prop fan, liquid-line solenoid valve, high pressure switch, Liebert Lee-Temp head pressure control and hot gas bypass. Condensing unit is designed for outdoor locations with operating ambients ranging from -30°F to 95°F (-34°C to 35°C).

#### 2.2.3 Indoor Water/Glycol Condensing Units

Indoor Water/Glycol Condensing Units includes scroll compressor, R-407C unit charge, factory-mounted disconnect, coaxial condenser, hot gas bypass, high head pressure switch and two-way water regulating valve designed for 150psi (1034.3kPa). Condensing units can be used on either a water or glycol cooling loop.

### 2.3 Chilled Water Units


Chilled Water Units are designed for ceiling installation. The cabinet and chassis are constructed of heavy gauge galvanized steel. The unit can be serviced using only one side increasing its versatility in mounting locations. Mounting brackets are factory-attached to the cabinet. Internal cabinet insulation meets ASHRAE 62.1 requirements for Mold Growth, Humidity & Erosion, tested per UL 181 & ASTM 1338 standards. Chilled water models are self-contained and include a chilled water coil, belt-driven centrifugal blower, factory-mounted disconnect switch and two-way, slow-close motorized valve. Design pressure is 300psi (2068kPa), 60psi (414kPa) close-off differential.

## 2.4 System Controls

**System controls** include a microprocessor control board mounted in the evaporator/chilled water unit and a wall-mounted interface with a two-line, 16-character liquid crystal display. A seven-key, membrane keypad for setpoint/program control, unit On/Off and alarm silence is below the LCD screen. It provides temperature setpoint and sensitivity adjustment, humidity setpoint and sensitivity adjustment, digital display of temperature, humidity, setpoints, sensitivities and alarm conditions.

The **wall-box** is field-wired to the microprocessor control using standard four-conductor thermostat wire (field-supplied). The temperature and humidity sensors are in the wall box, which can be installed up to 300 feet (91.4m) from the evaporator unit. The unit-mounted control board also includes common alarm terminals and shutdown terminals. The unit automatically restarts after a power outage.

**Figure 6 Wall-box**



### 2.4.1 Other Standard Control Features

- Adjustable auto restart
- 5 day/2 day setback
- Password protection
- Alarm enable/disable
- Self-diagnostics
- Calibrate sensors
- Predictive humidity control
- Common alarm output
- Remote shutdown terminals

## 3.0 OPTIONAL FACTORY-INSTALLED FEATURES - EVAPORATOR/CHILLED WATER UNITS

### 3.1 Reheat

**Electric Reheat** includes 304/304 stainless steel finned tubular reheat elements, with high limit safety switch.

**SCR Electric Reheat** uses an SCR controller and unit control software to provide full cooling with modulating of the electric reheat elements to control air temperatures. Reheat capacity is up-sized to offset the cooling capacity. (The SCR Electric Reheat is not available on chilled water, free-cooling or 575V units.)

**Hot Water Reheat** includes hot water coil, two-way solenoid valve and Y-strainer.



#### NOTE

*This option is available only on chilled water units, but not with other reheat options.*

### 3.2 Humidifier

The **Canister Humidifier** includes a steam-generating type humidifier with automatic flushing circuit, inlet strainer, drain, 1" (25.4mm) air gap on fill line and solenoid valves. Humidifier problem alarm annunciates at the wall-mounted display panel.

**Remote Humidifier Contact** allows the unit's humidity controller to control a humidifier outside the unit. Power to operate the remote humidifier does not come from the Liebert Mini-Mate2. Available on units with or without internal humidifier.

### 3.3 Sensors

**Smoke Sensor** checks return air, shuts down the unit upon sensing smoke and activates visual and audible alarms at the wall-box display. This smoke sensor is not intended to function as or replace any smoke sensor system that may be required by local or national codes.

**High-Temperature Sensor** senses the return air temperature and shuts down unit if the temperature reaches 125°F (52°C). This device is not meant to replace any fire detection system that may be required by local or national codes.

### 3.4 Switches and Motors

**Filter Clog** senses pressure drop across the filters and activates visual and audible alarms at the wall-box display. The wall-box display annunciates the alarm audibly and flashes a notification upon reaching a customer setpoint.

A **Factory-Installed Non-Fused Disconnect Switch** allows unit to be turned off for maintenance. A disconnect switch is standard for the evaporators, chilled water units and indoor condensing units, but these units may be specified without the switch.

**2hp Blower Motor** is available for high static applications (0.9 to 1.5 in. [23 to 38 mm] w.g.).

### 3.5 Free-Cooling


Free-cooling option includes separate cooling coil, three-way slow-close valve and separate supply and return piping. Free-cooling is activated when the water temperature reaches a field-adjustable temperature, typically 45°F (7°C). The valve is rated for 300psi (2068kPa) working pressure.

Air-cooled condensing units can be matched with evaporators using free-cooling coils with chilled water sources to serve as backup cooling. When matched with a water/glycol condensing unit, a three-way water regulating valve is recommended for the condensing unit to simplify piping to the main supply pipes. The coil is designed for closed-loop applications using properly treated and circulated fluid. Not available with SCR reheat options.

**Figure 7 Free-cooling arrangement**

**Free-cooling option: A second cooling coil allows the system to take advantage of colder outdoor temperatures and bypass compressor operation.**

**When the water temperature goes below 45°F (7°C), cooling switches over to free-cooling operation. A separate chilled water source can also be used with air-cooled systems.**



#### NOTE

*If free-cooling is applied to an open water tower, an optional copper-nickel (CuNi) coil is required to prevent premature corrosion, or a heat exchanger must separate the tower water from the free-cooling loop. The copper-nickel coil requires an extended lead time.*

### 3.6 Optional Configurations—Prop Fan Condensing Units

**Outdoor Prop Fan Condensing Units** are also available in the following optional configurations:

- High ambient, top discharge models for catalog capacities at ambient temperatures up to 105°F (40°C).
- Quiet-Line models for low noise level conditions (below 56 dBA) and catalog capacities for ambient temperatures up to 95°F (35°C).
- Condenser coil(s) can be phenolic-coated for extended coil life in coastal areas.

### 3.7 Optional Configurations—Water/Glycol Condensing Units

**Indoor Water/Glycol Condensing Units** are also available with the following piping options:

- Two-way water reg. valve with 350 psi (2413kPa) design pressure.
- Three-way water reg. valve with 150psi (1034kPa) design pressure.
- Three-way water reg. valve with 350psi (2413kPa) design pressure.



### **3.8 Optional Configurations—Chilled Water Units**

**Chilled Water Units** are also available with the following valve options:

- Three-way, slow-close, motorized chilled water valve rated for 300 psi (2068kPa) working pressure. Valve is non-spring return.
- Two-way modulating chilled water valve, rated for 400psi (2758kPa) operating pressure, 72psi (496kPa) close-off rating. Valve is non-spring return.
- Three-way modulating chilled water valve, rated for 400psi (2758kPa) operating pressure. Valve is non-spring return.

## 4.0 SHIP-LOOSE ACCESSORIES—FIELD-INSTALLED

**Filter Box** includes filter box with 1" (25.4mm) duct flange connection, quantity 2, 20" x 20" x 4" nominal (508mm x 508mm x 102mm) filters and a 1" (25.4 mm) duct flange for use on the supply air opening. Filters are MERV 8 efficiency per ASHRAE Standard 52.2-2007.

**Condensate Pump** is equipped with a discharge check valve. The pump is supplied with a mounting bracket for field-mounting onto ductwork and can be field-wired to the unit power block. A secondary float can be field-wired to shut down the unit upon high condensate level.

**Condensate Pump Mounting Bracket** is available for a mounting condensate pump on the end of the unit instead of on the duct work for easy alignment and installation of the condensate pump.

**Remote Temperature and Humidity Sensors** include sensors mounted in an attractive case with 30 ft. (9m) of cable. Installing the remote temperature and humidity sensor module disable the temperature and humidity sensors mounted in the wall box.

**Field-installed kits** are available for filter clog, smoke sensor, high temperature sensor, electric reheat and humidifier. The kits include installation instructions and are designed to be added to the evaporator unit before it is installed in the ceiling. Electric reheat kits cannot be installed in units with free-cooling.

**Refrigerant-line sweat adapter kit** contains two suction and two liquid-line compatible fittings that allow use of field-supplied, interconnecting refrigerant lines.

**Single Point Power Kit** contains the necessary electrical components to interconnect the high voltage sections of a close-coupled evaporator and indoor condensing unit.

### 4.1 Remote Monitoring, Autochangeover and Leak Detection Equipment

The **Liebert RCM4™** is a four-point, normally open, dry contact monitoring panel. One Form-C, dry contact common alarm relay output (rated at 24VAC, 3A) is provided. Four red LEDs illuminate on the respective alarm and the alarm buzzer is silenced by a front panel switch. The RCM4 requires a 24VAC or 24VDC power source. Power supply is not included.

The **Liebert AC4™ Autochangeover Controller** provides autochangeover and autosequence control for up to four Liebert Mini-Mate2 units within a room. The Liebert AC4 will enable redundant units in an alarm condition, balance usage and test standby units at programmed intervals. Two common alarm relay outputs are available. A built-in LCD and RS-232 port for direct PC/terminal connection provides two options for configuration and monitoring of the product. The Liebert AC4 requires 24VAC input power.

The **Liebert AC8™** is ideal for coordinated control of systems with redundant units. The Liebert AC8 enables redundant devices during an alarm condition, balances usage of devices and tests standby devices at programmable intervals. Supports four zones and can use the 4-20mA temperature sensor (TW420) for temperature staging in each zone. Two programmable output control relays are available for auxiliary control such as humidity lockout. Emergency power operation input provided for device control during an emergency. Two common alarm relay outputs are available. A built-in LCD and RS-232 port for direct PC/terminal connection provides two options for configuration and monitoring of the product.

The **Liebert ENV-DO™** interface card provides 16 discrete outputs, corresponding to status and major alarm conditions of Environmental units. The Liebert ENV-DO-ENCL1 packages one Environmental DO interface card in its own steel enclosure and the ENV-DO-ENCL2 packages two Environmental DO interface cards in one enclosure for installation external to the Liebert Mini-Mate2. The self-contained kit includes an external 120VAC-to-24VAC power transformer. Wiring harnesses are not provided. Power and communication wiring is field-provided.

**The Liebert Liqui-tect® 410 Point Leak Detection Sensor** detects the presence of conductive liquid using a pair of corrosion-resistant, gold-plated probes mounted in a painted, height-adjustable enclosure. Dual Form-C, dry contact common alarm relays (rated at 24VAC, 3A) signal a leak detected as well as loss of power and cable fault. The Liebert Liqui-tect 410 requires an external 24VAC or 24VDC power source.

**Liebert LT460 Zone Leak Detection Kits** include one LT460 sensor, a specified length of LT500-xxY cable (maximum length is 100 ft [30.5m]) and a corresponding number of hold-down clips. The Liebert LT460 requires an external 24VAC, 0.12A power source, such as EXT-XFMR or XFMR24.

**Liebert SiteScan**<sup>®</sup> is a monitoring solution that gives you decision-making power to effectively manage the equipment critical to your business.

Liebert SiteScan enables communication from Liebert Precision Cooling and Power Protection units, as well as many other pieces of analog or digital equipment, to a front-end software package that provides real-time status and alarms so you can react quickly to changing situations.

Liebert SiteScan is designed with flexibility for both small systems and large, complex systems such as those in computer rooms, telecommunications facilities or industrial process control rooms. Contact your local Emerson representative for assistance with a Liebert SiteScan system.

The **NIC-ENCL1 and NIC-ENCL2** package one or two Liebert IntelliSlot<sup>®</sup> Web/485 Cards with Adapters, respectively, in one steel enclosure for installation external to the Liebert Mini-Mate2. The Liebert IntelliSlot Web/485 Card with Adapter provides communication with the Liebert Mini-Mate2<sup>™</sup> via SNMP, HTTP, RTU Modbus 485 and BACnet IP. The self-contained kit includes an external 120VAC-to-24VAC transformer as a power source. Wiring harnesses are not provided. Power and communication wiring are field-provided.

## 5.0 SITE PREPARATION AND INSTALLATION



**NOTE**

Before installing unit, determine whether any building alterations are required to run piping, wiring and duct work. Carefully follow all unit dimensional drawings and refer to the submittal engineering dimensional drawings of individual units for proper clearances.

### 5.1 Installation Considerations

The evaporator unit is usually mounted above the suspended ceiling in the space to be conditioned. Ducted systems may be located in a different room. Refer to **Figure 8** and **Figure 9** for possible configurations. The condensing unit may be:

- Indoor Air-Cooled Centrifugal Fan Condensing Unit mounted remotely or close coupled to the evaporator in the ceiling space.
- Outdoor Air-Cooled Propeller Fan Condensing Unit.
- Water/Glycol Cooled Condensing Unit, mounted remotely or close coupled to the evaporator.

**Table 3 Application limits, evaporator and chilled water units\***

Input Voltage		Range of Return Air Conditions to Unit	
Min	Max	Dry Bulb Temperature	Relative Humidity
-5%	+10%	65°F to 85°F (18°C to 29°C)	20% to 80%

\*Unit will operate at these conditions but will not control to these extremes.

**Table 4 Application limits, indoor and outdoor air-cooled condensing units**

Input Voltage		Condensing Units	Entering Dry Bulb Air Temperature	
Min	Max		Min	Max
-5%	+10%	Outdoor Prop Fan Condensing Unit	-30°F (-34°C)	120°F (49°C)
		Indoor Air-Cooled Centrifugal Condensing Unit	-20°F (-29°C)	115°F (46°C)

**Table 5 Application limits, indoor water/glycol cooled condensing units**

Input Voltage		Entering Fluid Temperature	
Min	Max	Min	Max
-5%	+10%	65°F (18.3°C) *	115°F (46°C)

\*Operation below 65°F (18°C) may result in reduced valve life and fluid noise.

#### 5.1.1 Room Preparation

The room should be well insulated and must have a sealed vapor barrier. The vapor barrier in the ceiling and walls can be a polyethylene film. Paint on concrete walls and floors should contain either rubber or plastic.



**NOTE**

The single most important requirement for maintaining environmental control in the conditioned room is the vapor barrier.

Outside or fresh air should be kept to a minimum when tight temperature and humidity control is required. Outside air adds to the cooling, heating, dehumidifying and humidifying loads of the site. Doors should be properly sealed to minimize leaks and should not contain ventilation grilles.

### 5.1.2 Location Considerations



## CAUTION

Risk of leaking water/glycol. Can cause equipment, furniture and building damage. Do not mount units over equipment or furniture that can be damaged by leaking water /glycol. Install a watertight drain pan with a drain connection under the cooling unit and ceiling mounted water-cooled condensing unit. Route the drain line to a frequently used maintenance sink so that running water can be observed and reported in a timely manner. Post a sign to alert people to report water flowing from the secondary drain pan.



## NOTE

Do **NOT** mount units in areas where normal unit operating sound may disturb the working environment.

Locate the evaporator unit over an unobstructed floor space if possible. This will allow easy access for routine maintenance or service. Do not attach additional devices (such as smoke detectors, etc.) to the housing, as they could interfere with the maintenance or service.



## NOTE

Temperature and humidity sensors are located in the wall box. Carefully select a position for the box where discharge air **DOES NOT** blow directly on the sensors.

**Figure 8 Air-cooled systems**




Figure 9 Water/glycol cooled systems





Figure 10 Chilled water systems



## 5.2 Ceiling Unit Weights

Table 6 Unit weights

Cooling Units *	lb.	kg
MMD60E	498	226
MMD59E	498	226
MMD92C	498	226
MMD91C	498	226
Condensing Units	lb.	kg.
MCD65A	449	204
MCD64A	449	204
MCD69W	282	128
MCD68W	282	128

\*Add 32 lb. (14 kg.) to units with free cooling or hot water reheat coils.

### 5.3 Equipment Inspection Upon Receipt

When the unit arrives, do not uncrate equipment until it is close to its final location. All required assemblies are banded and shipped in corrugated containers. If you discover any damage when you uncrate the unit, report it to the shipper immediately. If you later find any concealed damage, report it to the shipper and to your Liebert supplier.

### 5.4 Installing the Ceiling Units



#### WARNING

Risk of ceiling collapse and heavy unit falling. Can cause building damage, serious injury or death.

Verify that the supporting roof structure is capable of supporting the weight of the unit(s) and the accessories during installation and service. (See **5.2 - Ceiling Unit Weights**.)

Securely anchor the top ends of the suspension rods and verify that all nuts are tight.

The evaporator unit and indoor condensing unit are usually mounted above the ceiling and must be securely mounted to the roof structure. The ceiling and ceiling supports of existing buildings may require reinforcements. Be sure to follow all applicable national and local building codes. Use field-supplied threaded suspension rods and 3/8"–16 factory hardware kit.

Recommended clearance between ceiling grids and building structural members is unit height plus three inches (76.2mm).

Install the four field-supplied rods by suspending them from suitable building structural members. Locate the rods so that they will align with the four mounting holes in the flanges that are part of the unit base.

Using a suitable lifting device that is rated for the weight of the unit (see **5.2 - Ceiling Unit Weights**), raise the unit up and pass the threaded rods through the four mounting holes in the flanges that are part of the unit base.

Attach the threaded rods to the unit flanges using the supplied nuts and grommets (see **Figure 13**). The rubber grommets provide vibration isolation.

1. Use the plain nuts to hold unit in place. Adjust these nuts so that the weight of the unit is supported evenly by the four rods, does not rest on the ceiling grid and is level.



#### NOTE

*The units must be level in order to drain condensate properly.*

2. Use the Nylock nuts to “jam” the plain nuts.

#### 5.4.1 Close Coupled Installations

If the evaporator and condensing units are to be mounted side-to-side (close coupled), hang each unit before connecting them together (see **Figure 15**). Align bolt holes in the condensing unit and in the evaporator. Insert rubber spacers and secure four (4) sets of hardware provided. Align the refrigerant connections and tighten them as described in **5.4.3 - Piping Connections and Coolant Requirements**.

#### 5.4.2 Evaporator Air Distribution

##### Filter Box

The optional filter box mounts directly to the return air opening of the evaporator. The filter box is supplied with 1" (25.4mm) duct flange connection, quantity two, 20" x 20" x 4" nominal (508mm x 508mm x 102mm) filters and a 1" (25.4 mm) duct flange for use on the supply air opening. Filters are MERV 8 efficiency per ASHRAE Standard 52.2-2007.



#### NOTE

*Do not operate the unit without filters installed in return air system.*

## Connections for Ducted Systems

Use flexible duct work or non-flammable cloth collars to attach duct work to the unit and to help control the transmission of vibrations to building structures. Insulation of duct work is vital to prevent condensation during the cooling cycle. The use of a vapor barrier is required to prevent absorption of moisture from the surrounding air into the insulation.

If the return air duct is short or if noise is likely to be a problem, sound-absorbing insulation should be used inside the duct. Duct work should be fabricated and installed in accordance with national and local codes.

**Table 7 Evaporator external static pressure**

Turns Open	1.5 hp Motor (60hz)		2.0 hp Motor (60hz)	
	Blower rpm	External Static, in.	Blower rpm	External Static, in.
1	n/a	n/a	1329	n/a
1.5	n/a	n/a	1296	n/a
2	1037	0.9	1264	n/a
2.5	1005	0.7	1231	1.5
3	972	0.6	1199	1.4
3.5	940	0.5	1164	1.3
4	907	0.4	1134	1.2
4.5	875	0.3	1102	1.1
5	843	0.2	1069	1.0
5.5	810	0.1	1037	0.9
6	778	0.0	1005	0.7

Additional components such as a free-cooling coil, hot water reheat coil or high efficiency filters will reduce available static pressure.

### 5.4.3 Piping Connections and Coolant Requirements

#### Drain Line

## NOTICE

Risk of water backing up in the evaporator coil drain line and overflowing the drain pan. Can cause building and equipment damage.

Do not install an external trap in the drain line. This line already has a factory-installed trap inside the cabinet.

This line may contain boiling water. Use copper or other suitable material for the drain line.

A 3/4 in. (19.1 mm) NPT-female connection is provided for the evaporator coil condensate drain. This line also drains the humidifier, if applicable. The drain line must be located so it will not be exposed to freezing temperatures. The drain should be the full size of the drain connection.

The evaporator drain pan includes a float switch to prevent unit operation if drain becomes blocked.

The optional condensate pump kit is required when the evaporator is installed below the level of the gravity-fed drain line.

#### Humidifier Water Supply Line

Units supplied with the optional humidifier package have a 1/4 in. (6.4 mm) copper compression fitting connection for water inlet. Supply pressure range is 10 psig to 150 psig. Required flow rate is 1 gpm (3.8 lpm). A shut-off valve should be installed in this line to isolate the humidifier for maintenance.



#### NOTE

Do NOT route humidifier supply line in front of filter box access panel.



**Chilled Water Piping**—On chilled water units install manual service shut-off valves at the supply and return lines of each unit. These shut-off valves are used for routine service or emergency isolation of the unit.

Chilled water supply and return lines must be insulated. Insulating them will prevent condensation of the water supply and return lines to the unit.

The minimum recommended water temperature is 42°F (5.5°C). Connection sizes are 1-1/8" (28.6mm) OD copper.

**Water/Glycol Piping**—Water- and glycol-cooled systems require coolant loop connections as specified in the condensing unit installation instructions.

**Refrigerant R-407C Piping**—All split systems require two refrigerant lines (an insulated copper suction line and a copper liquid line) between the evaporator and the condensing unit.



## WARNING

Risk of explosive discharge of high pressure refrigerant. Can cause serious injury.  
Relieve refrigerant system pressure before working with piping/connections.

Two possible methods exist for installing the copper suction and liquid lines.

- Close coupling the units together using the quick connects. (See **Figure 15**).
- Using an optional sweat adapter kit and hard piping between the two units.

All refrigeration piping should be installed with high temperature brazed joints. Prevailing good refrigeration practices should be employed for piping supports, leak testing, evacuation, dehydration and charging of the refrigeration circuits. The refrigeration piping should be isolated from the building by the use of vibration isolating supports. To prevent tube damage when sealing openings in walls and to reduce vibration transmission, use a soft flexible material to pack around the tubes.

When installing remote condensing units above the evaporator, the suction gas line should be trapped at the evaporator. This trap will retain refrigerant oil in the off cycle. When the unit starts, oil in the trap is carried up the vertical riser and returns to the compressor.

**Table 8 Recommended refrigerant line sizes**

Equivalent Pipe Length, ft (m)	Liquid	Suction
50 (15)	1/2"	1-1/8"
100 (30.5)	5/8"	1-1/8"
150 (45.7)	5/8"	1-3/8"


Suction line and liquid line sizing based on < 3 psi pressure drop in each and suction line refrigerant velocities >1000FPM (5.1m/s) for proper oil return.

**Table 9 Equivalent lengths for various pipe fittings, ft (m)**

Copper Pipe OD, in.	90 Degree Elbow Copper	90 Degree Elbow Cast	45 Degree Elbow	Tee	Gate Valve	Globe Valve	Angle Valve
1/2	0.8 (0.24)	1.3 (0.39)	0.4 (0.12)	2.5 (0.76)	0.26 (0.07)	7.0 (2.13)	4.0 (1.21)
5/8	0.9 (0.27)	1.4 (0.42)	0.5 (0.15)	2.5 (0.76)	0.28 (0.08)	9.5 (2.89)	5.0 (1.52)
3/4	1.0 (0.3)	1.5 (0.45)	0.6 (0.18)	2.5 (0.76)	0.3 (0.09)	12.0 (3.65)	6.5 (1.98)
7/8	1.45 (0.44)	1.8 (0.54)	0.8 (0.24)	3.6 (1.09)	0.36 (0.1)	17.2 (5.24)	9.5 (2.89)
1-1/8	1.85 (0.56)	2.2 (0.67)	1.0 (0.3)	4.6 (1.4)	0.48 (0.14)	22.5 (6.85)	12.0 (3.65)
1-3/8	2.4 (0.73)	2.9 (0.88)	1.3 (0.39)	6.4 (1.95)	0.65 (0.19)	32.0 (9.75)	16.0 (4.87)
1-5/8	2.9 (0.88)	3.5 (1.06)	1.6 (0.48)	7.2 (2.19)	0.72 (0.21)	36.0 (10.97)	19.5 (5.94)

Refrigerant trap = Four times equivalent length of pipe per this table

Figure 11 Refrigerant piping diagram



**NOTE**

*If field supplied refrigerant piping is installed, refrigerant must be added to the system.*

**Table 10 Pipe length and condenser elevation relative to evaporator**

Nominal System Size Tons	Maximum Equivalent Pipe Length, ft. (m)	Maximum PFH Level Above Evaporator, ft. (m)	Maximum PFH Level Below Evaporator, ft. (m)
5	150 (45)	50 (15)	15 (4.6)

Maximum recommended total equivalent pipe length is 150 ft (46m). Suction and liquid lines may require additional specialty items when vertical lines exceed 20 ft. (6m) and/or condensing unit installation is more than 15 ft. (4.6m) below the evaporator. Contact Emerson Application Engineering for assistance.

**Refrigerant Charge Requirements**—Total refrigerant charge will be required only if units are evacuated during installation or maintenance. For safe and effective operation, refer to **5.4.3 - Piping Connections and Coolant Requirements**.

**Total refrigerant = Units and Lines\***

**Table 11 Refrigerant charge**

Model #		R-407C, oz (kg)
60Hz	50Hz	
MM*60E	MM*59E	4 (0.11)
MM*60K	MM*59K	4 (0.11)
MC*65A	MC*64A	432 (12.3)
MC*69W	MC*68W	94 (2.7)
PFH067A-_L7	PFH066A-_L7	426 (12.1)
PFH067A-_H7	PFH066A-_H7	827 (23.4)
PFHZ67A-_L7	PFHZ66A-_L7	827 (23.4)

All evaporator units and condensing units are fully factory-charged with refrigerant. If field-supplied refrigerant piping is installed, refrigerant must be added; refer to **Table 12** to determine the additional charge.

**Table 12 Line charges - refrigerant per 100 ft. (30m) of Type L copper tube**

Line Size, O.D., in.	R-407C, lb/100 ft. (kg/30m)	
	Liquid Line	Suction Line
3/8	3.7 (1.7)	—
1/2	6.9 (3.1)	—
5/8	11.0 (5.0)	0.4 (0.2)
3/4	15.7 (7.1)	0.6 (0.3)
7/8	23.0 (10.4)	1.0 (0.4)
1-1/8	—	1.7 (0.7)
1-3/8	—	2.7 (1.1)

**Quick Connect Fittings**



**NOTE**

*When hard piping is used, complete all piping and evacuate lines before connecting quick connects.*

Be especially careful when connecting the quick connect fittings. Read through the following steps before making the connections.

1. Remove protector caps and plugs.
2. Carefully wipe coupling seats and threaded surfaces with a clean cloth.
3. Lubricate the male diaphragm and synthetic rubber seal with refrigerant oil.
4. Thread the coupling halves together by hand to insure that the threads mate properly.
5. Tighten the coupling body hex nut and union nut with the proper size wrench until the coupling bodies “bottom out” or until a definite resistance is felt.
6. Using a marker or pen, make a line lengthwise from the coupling union nut to the bulkhead.
7. Tighten the nuts an additional quarter-turn; the misalignment of the lines shows how much the coupling has been tightened. This final quarter-turn is necessary to insure that the joint will not leak. Refer to **Table 13** for torque requirements.

**Table 13 Refrigerant quick connect sizes and torque**

Size O.D. Cu	Coupling Size	Torque lb-ft
1/2"	#10	35-45
1-1/8"	#12	50-65

**Figure 12 Evaporator unit dimensional data**





Figure 13 Threaded rod and hardware kit installation



#### 5.4.4 Electrical Connections

Each unit is shipped from the factory with internal wiring completed. Refer to electrical schematic when making connections. Electrical connections to be made at the installation site are:

- Power supply to each ceiling unit.



### WARNING

Arc flash and electric shock hazard. Disconnect all electric power supplies and wear protective equipment per NFPA 70E before working within electric control enclosure. Failure to comply can cause serious injury or death.

The Liebert microprocessor control does not isolate power from the unit in the Unit Off mode. Some internal components require and receive power even during the Unit Off mode. The line side of the disconnect switch on the front of the unit contains live high voltage. The only way to ensure that there is NO voltage inside the unit is to install and open a remote disconnect switch and check the internal power supply wires with a voltmeter.

- Control wiring between the evaporator unit and the condensing unit, if applicable.
- Control wiring between the control panel (wallbox) and the evaporator unit control board.

## Power Connections

All power and control wiring and ground connections must be in accordance with the National Electrical Code (NEC) and local codes. Refer to Unit serial tag data for electrical requirements.



### WARNING

Risk of loose electrical wiring connections. Can cause overheating of wire, smoke and fire resulting in building and equipment damage, serious injury or death.

Use copper wiring only. Verify periodically that all connections are tight.

Voltage supplied must agree with the voltage specified on the unit serial tag. If a field supplied disconnect switch is required, it may be bolted to the ceiling unit, but not to any of the removable panels. This would interfere with access to the unit. Make sure that no refrigerant lines are punctured when mounting the disconnect switch.

Route the electrical service conduit through the hole provided in the cabinet and terminate it at the electric box. Make connections at the factory terminal block or disconnect switch, L1, L2, L3. Connect earth ground to lug provided. See transformer label for primary tap connections. Installer will need to change transformer primary taps if applied unit voltage is other than pre-wired tap voltage.

An optional single point power kit is available for units that are close coupled (See **5.4.3 - Piping Connections and Coolant Requirements**). This kit should be mounted inside the condensing unit before installing the unit in the ceiling. Specific installation instructions are included with the single point power kit.

## Control Connections

A field-supplied, 4-wire control connection (24 VAC) is required between the evaporator and the condensing unit. Control wiring must be installed in accordance with the National Electrical Code (NEC) Class 2 circuit. Glycol cooled units also require a two-wire control connection to the drycooler and pump. A Class 1 circuit is required for Water/Glycol units.

Control wiring between the evaporator and the condensing unit must not allow a voltage drop in the line of more than 1 volt (16 gauge minimum for 75 feet). Do not connect additional electrical devices to the control circuit. The circuit breaker, contained in the transformer housing, is sized only for the factory-supplied control system.

Additional control wiring will be required if your system includes other optional monitoring and control devices.

Four (4) wire (thermostat type) must be connected between the evaporator control board and the wall box. See **Figure 14**.

**Figure 14 Evaporator unit electrical connections**





Figure 15 Close coupled installation





## 5.5 Indoor Air-Cooled Centrifugal Fan Condensing Unit Installation



### NOTE

*Follow all national and local building, electrical and plumbing codes.*

### 5.5.1 Location Considerations

The centrifugal fan air-cooled condensing unit may be located above the dropped ceiling or any remote indoor area. If noise is of concern, the condensing unit should be located away from personnel. Normal operating sound may be objectionable if the condensing unit is placed near quiet work areas.

To mount the unit in the ceiling, refer to **5.4 - Installing the Ceiling Units**.

### 5.5.2 Electrical Connections

Refer to **5.4.4 - Electrical Connections** for general wiring requirements and cautions. Refer to electrical schematic when making connections. Refer to unit serial tag for full load amp and wire size amp ratings.

#### Power Connections

The condensing unit requires its own power source and earth ground, with a disconnect switch to isolate the unit for maintenance.



### NOTE

*Refer to serial tag for full load amp and wire size amp ratings*

#### Control Connections

Field-supplied control wires must be connected between the evaporator and the condensing unit (See **Figure 14** and **Figure 17**) and the electrical schematic on the units for more details.) Four wires are required between the evaporator and condensing unit.

### 5.5.3 Piping Connections

Details for refrigerant loop piping are in **5.4.3 - Piping Connections and Coolant Requirements**.

### 5.5.4 Ducting

Fan operation is designed for 3500 CFM (5947 CMH) at 0.5" (0.12kPa) external static pressure.

#### General Considerations

Use flexible ductwork or nonflammable cloth collars to attach ductwork to the unit and to control vibration transmission to the building. Attach the ductwork to the unit using the flanges provided. Locate the unit and ductwork so that the discharge air does not short circuit to the return air inlet.

Ductwork that runs through a conditioned space or is exposed to areas where condensation may occur must be insulated. Ductwork should be suspended using flexible hangers. Ductwork should not be fastened directly to the building structure.

For multiple unit installations, space the units so that the hot condensing unit exhaust air is not directed toward the air inlet of an adjacent unit.

#### Considerations for Specific Applications

**In applications where the ceiling plenum is used as the heat rejection domain**, the discharge air must be directed away from the condensing unit air inlet and a screen must be added to the end of the discharge duct to protect service personnel. Locate the air discharge a minimum of 4 feet from an adjacent wall. Failure to do so may result in reduced air flow and poor system performance.

**If the condensing unit draws air from the outside of the building**, rain hoods must be installed. Hood intake dimensions should be the same as the condensing unit duct dimensions. In addition, install a triple layer bird screen over rain hood openings to eliminate the possibility of insects, birds, water or debris entering the unit. Avoid directing the hot exhaust air toward adjacent doors or windows.

Figure 16 Indoor air-cooled centrifugal condensing unit dimensions and pipe connections






Figure 17 Indoor air-cooled centrifugal condenser electrical connections




NOTES:

1. Refer to specification sheet for full load amp. and wire size amp ratings.
2. Control voltage wiring must be a minimum of 16GA (1.3mm) for up to 75'(23m) or not to exceed 1 volt drop in control line.

DPN000226  
Rev. 2

Figure 18 System piping with indoor or outdoor air-cooled condensing unit



\* Use Liebert sweat adapter kit with field hard piping. Close-coupling option available with MCD.  
 \*\* Components are not supplied by Liebert but are recommended for proper circuit operation and maintenance.

--- FIELD PIPING  
 === FACTORY PIPING  
 DPN000215  
 Rev. 3

## 5.6 Outdoor Air-Cooled Condensing Unit Installation



**NOTE**

Follow all national and local building, electrical and plumbing codes.


### 5.6.1 Location Considerations

To ensure a satisfactory air supply, locate air-cooled propeller fan condensing units in an environment providing clean air, away from loose dirt and foreign matter that may clog the coil. Condensing units must not be located in the vicinity of steam, hot air or fume exhausts or closer than 18 inches from a wall, obstruction or adjacent unit. Avoid areas where heavy snow will accumulate at air inlet and discharge locations.

The condensing unit should be located for maximum security and maintenance accessibility. Avoid ground-level sites with public access.

Install a solid base, capable of supporting the weight of the condensing unit. The base should be at least 2 inches higher than the surrounding grade and 2 inches larger than the dimensions of the condensing unit base. For snowy areas, a base of sufficient height to clear snow accumulation must be installed.


**Figure 19 Dimensions—Air-cooled systems, standard ambient outdoor condensing module**



**Table 14 Weights for standard ambient outdoor condensing modules, air-cooled systems**

Model #		Weight, lb (kg)
60Hz	50Hz	
PFH067A-L	PFH066A-L	351 (159)

**Figure 20 Dimensions—Air-cooled systems, high ambient and Quiet-Line condensing module**



**Table 15 Net weight, high ambient and Quiet-Line condensing modules, air-cooled systems**

Model #		Module Net Weight lb. (kg)
60Hz	50Hz	
PFH067A- H PFHZ67A- L	PFH066A- H PFHZ66A- L	488 (222)

### 5.6.2 Piping Connections

Details for refrigerant loop piping are in 5.4.3 - Piping Connections and Coolant Requirements.

### 5.6.3 Electrical Connections

Refer 5.4.4 - Electrical Connections for general wiring requirements and cautions. Refer to electrical schematic when making connections.

#### Power Connections

The outdoor condensing unit requires its own power source and earth ground, with a disconnect switch (field supplied) to isolate the unit for maintenance.

#### Control Connections

Field-supplied control wires must be connected between the evaporator and the condensing unit. (See Figure 14 and the electrical schematic on the units for more details.) Four wires are required between the evaporator and condensing unit.

## 5.7 Indoor Water- and Glycol-Cooled Condensing Unit Installation



### NOTE

*Follow all national and local building, electrical and plumbing codes.*

### 5.7.1 Location Considerations

The condensing unit may be located above the dropped ceiling or any remote indoor area. If noise is of concern, the condensing unit should be located away from personnel. Normal operating sound may be objectionable if the condensing unit is placed near quiet work areas.

To mount the unit in the ceiling, refer to **5.4 - Installing the Ceiling Units**.

### 5.7.2 Electrical Connections

Refer to **5.4.4 - Electrical Connections** for general wiring requirements and cautions. Refer to electrical schematic when making connections. Refer to serial tag for full load amp and wire size amp ratings.

#### Control Connections

A 4-wire control connection is required from the evaporator unit to the condensing unit. **Glycol cooled units also require a two-wire control connection to the drycooler and pump package.**

### 5.7.3 Piping Connections

Details for refrigerant loop piping are in **5.4.3 - Piping Connections and Coolant Requirements**.

#### Water/Glycol Piping Considerations

Manual service shut-off valves must be installed at the supply and return line to each unit. This enables routine service and/or emergency isolation of the unit. When the condensing unit fluid quality is poor, filters that can be easily serviced should be placed in the supply line. These filters extend the service life of the condensing unit.

#### Condensing Unit Fluid Requirements

The maximum fluid pressure is 150 PSI standard pressure and 350 PSI for high pressure units (Refer to unit serial tag and model number description page at beginning of this manual).


**Automotive antifreeze must not be used in glycol systems.** Prepare glycol solution using customary practices.

#### Regulating Valve


Water/Glycol cooled units include a coolant flow regulating valve that is factory-adjusted and should not need field adjustment.

Standard pressure and high pressure valves are adjusted differently. Contact Emerson's Precision Cooling Support before making any adjustments.

**Figure 21 Indoor water/glycol condensing unit dimensional data**




**WATER/GLYCOL DIMENSIONAL DATA**





**Figure 22 Indoor water/glycol condensing unit electrical field connections**




**NOTES:**

1. Refer to specification sheet for full load amp. and wire size amp ratings.
2. Control voltage wiring must be a minimum of 16GA (1.3mm) for up to 75'(23m) or not to exceed 1 volt drop in control line.

DPN000228  
Rev. 2

Figure 23 System piping with indoor water/glycol cooled condensing unit



## 5.8 Optional Equipment Piping

### 5.8.1 Free-Cooling Coil

The free-cooling coil is a secondary coil located downstream of the DX coil. The free-cooling coil does not operate at the same time as the DX coil. A temperature sensor is factory-mounted to the free-cooling piping. If the water temperature is less than the set temperature (usually 45°F [7.2°C]), the 3-way valve opens to allow chilled water flow to the free-cooling coil and the compressor is locked off. If the water temperature is above the set temperature, the 3-way valve closes (bypasses) and enables the compressor. To keep deposits from building up in the free-cooling coil, an adjustable timer is factory-set to flush every 400 minutes.




#### NOTE

*If the free-cooling coil is piped to an open water tower, a CU/Ni (copper-nickel) type coil must be ordered to prevent corrosion of the copper tubes; or a heat exchanger must separate the tower water from the free-cooling loop.*

On water-cooled systems, the free-cooling coil outlet can be field piped to the condensing unit inlet, provided a 3-way regulating valve has been installed within the water/glycol condensing unit (see Figure 24).

**Figure 24 Optional free-cooling coil (3-way valve) on water/glycol units**



NOTE: RECOMMENDED PIPING FOR UNITS WITH FREE-COOLING COIL OPTION AND WATER/GLYCOL CONDENSER.

--- FIELD PIPING  
 === FACTORY PIPING


\* Components are not supplied by Emerson but are recommended for proper circuit operation and maintenance.

DPN000219  
 Rev. 3

### 5.8.2 Hot Water Reheat Coil

Building hot water can be piped to a factory-installed hot water reheat coil, located downstream of the cooling coil. A factory-installed solenoid valve opens upon a call for reheat.

**Figure 25 Optional hot water reheat (two-way valve)**



Note: Hot water reheat available only on chilled water units.

\* Components are not supplied by Emerson but are recommended for proper circuit operation and maintenance.

DPN000219  
 Rev. 3

## 5.9 Checklist for Completed Installation

- 1. Proper clearance for service access has been maintained around the equipment.
- 2. Equipment is level and mounting fasteners are tight.
- 3. Piping completed to refrigerant or coolant loop (if required). Refrigerant charge added (if required).
- 4. Condensate pump installed (if required).
- 5. Drain line(s) connected and checked for leaks.
- 6. Water supply line connected to humidifier (if required). Route to allow air filter removal.
- 7. Field provided drain pan with drain installed under all cooling units and ceiling-mounted water/glycol condensing units.
- 8. Filter box installed.
- 9. Ducting completed.
- 10. Filter(s) installed in return air duct.
- 11. Line voltage to power wiring matches equipment serial tag.
- 12. Power wiring connections completed between disconnect switch, evaporator and condensing unit, including earth ground.
- 13. Power line circuit breakers or fuses have proper ratings for equipment installed.
- 14. Control wiring connections completed to evaporator and condensing unit (if required, including wiring to wall-mounted control panel and optional controls).
- 15. Control panel DIP switches set based on customer requirements.
- 16. All wiring connections are tight.
- 17. Foreign materials have been removed from in and around all equipment installed (shipping materials, construction materials, tools, etc.)
- 18. Fans and blowers rotate freely without unusual noise.
- 19. Inspect all piping connections for leaks during initial operations. Correct as needed.
- 20. Rubber band is removed from evaporator condensate pan float switch.

## 6.0 MICROPROCESSOR CONTROL

The Microprocessor Control for the Liebert Mini-Mate2 unit features an easy to use menu-driven LCD display. The menus, control features and circuit board details are described in this section. Detailed information concerning controls (**7.0 - System Performance Microprocessor Controls**) and alarms (**8.0 - Alarms**) are provided.

### 6.1 Feature Overview

To turn the unit ON, press the ON/OFF (I/O) key after power is applied. To turn the unit OFF, press the ON/OFF (I/O) key before power is disconnected.

The following control keys may be used to move through the menus, as prompted on the LCD display:

- I/O—turns unit On or Off (top far left).
- MENU—Enables user to access the program menu to change control parameters, alarms, setback schedule, etc. (top near left).
- UP ARROW—Increases the value of displayed parameter while in a set mode (setpoints, time, etc.) (top near right).
- ESC—Escape; allows user to move back to a previous menu (top far right).
- Alarm Silence/? (Help)—If an alarm is present, pressing this key will silence the alarm. If this key is pressed when no alarms are present, help text will appear (bottom near left).
- DOWN ARROW—Decreases the value of displayed parameter while in a set mode (bottom near right).
- ENTER—After setting a control point, press ENTER to store the information in the microprocessor (bottom far right).

**Figure 26 Wall box**



Active alarms are displayed on the LCD screen and sound an audible beeper. To silence an alarm, press the Alarm Silence/Help key as prompted on the display.

Setpoints, DIP switch settings and other selections were made during factory testing of your unit and are based on typical operating experience. (Other default selections were made according to options included with your unit). **MAKE ADJUSTMENTS TO THE FACTORY DEFAULT SELECTIONS ONLY IF THEY DO NOT MEET YOUR SPECIFICATIONS.**

Allowable ranges are displayed by pressing the Help key. A password will be required (if enabled) to change setpoints, time delays, etc.

The display normally shown includes the present room temperature, humidity, active status functions (cooling, heating, dehumidifying, humidifying) and active alarms. The Status Display may also be selected from the Main Menu.

## 6.2 Main Menu <Menu>

Press the MENU key to display the Main Menu. The menu selections (in the following order) include:

- SETPOINTS
- STATUS
- ACTIVE ALARMS
- TIME
- DATE
- SETBACK
- SETUP OPERATION
- SET PASSWORD
- SETUP PASSWORD
- CALIBRATE SENSOR
- ALARM ENABLE
- ALARM TIME DELAY
- COM ALARM ENABLE
- CUSTOM ALARMS
- CUSTOM TEXT
- DIAGNOSTICS
- END OF MENU

Use the UP and DOWN arrows to scroll through the selections; when ready to select a particular function press Enter.

## 6.3 Setpoints

Setpoints and system setup parameters are kept in nonvolatile memory. Selecting SETPOINTS from the Main Menu will display the following selections:

- TEMPERATURE SETPOINT
- TEMPERATURE SENSITIVITY
- HUMIDITY SETPOINT
- HUMIDITY SENSITIVITY
- HIGH TEMPERATURE ALARM
- LOW TEMPERATURE ALARM
- HIGH HUMIDITY ALARM
- LOW HUMIDITY ALARM

Scroll through this sub-menu by using the Up and Down arrows, then press Enter to select a particular function. To change a particular value, press Enter and use the Up and Down arrows to change the value. When the value has been changed press Enter to store the value. For example to change the temperature setpoint from the main status display.

1. Press Menu key to display main menu.
2. Scroll to “SETPOINTS” using the Up and Down arrows. Press Enter.
3. Scroll to “TEMP SETPOINT” using the Up and Down arrows. Press Enter.
4. Use the Up and Down arrows to change the value. Press Enter.

**Table 16 Default setpoints and allowable ranges**

Setpoint	Default	Range
Temperature Setpoint	72°F	40-90°F (5-32°C)
Temperature Sensitivity	2.0°F	1-9.9°F (0.6-5.6°C)
Humidity Setpoint	50%	20-80% RH
Humidity Sensitivity	5%	1-30% RH
High Temperature Alarm	80°F	35-95°F (2-35°C)
Low Temperature Alarm	65°F	35-95°F (2-35°C)
High Humidity Alarm	60%	15-85% RH
Low Humidity Alarm	40%	15-85% RH

## 6.4 Status

The operator can monitor the percentage heating, cooling, dehumidifying and humidifying status of the unit by selecting the “STATUS” sub-menu.

## 6.5 Active Alarms

The operator can monitor the alarms status by selecting “ALARMS” which will display a “No Alarm Present” or “Alarm XX of YY” alert and description. If more than one alarm is activated, use the UP or DOWN arrow to scroll through the alarms list. (“XX” reference is the number of the alarm shown, while the “YY” reference is the total number of alarms activated).

## 6.6 Time

The controller time clock must be set to allow for the setback control. The clock uses the 24-hour system (i.e., midnight is entered as 24:00). To change the time press Enter to select the function, then use the Up and Down arrows to change the first character, press Enter to store, then press the Up or Down arrows to change the character, press Enter to store, etc. THERE IS A BATTERY BACKUP FOR THE DATE AND TIME FEATURES.

## 6.7 Date

The controller date must be set to allow for setback control. To change the date press Enter, then use the Up and Down arrows to change the first character, press enter to store, press the Up and Down arrows to change the second character, etc.

## 6.8 Setback

The microprocessor can be programmed for night and weekend setback. Two (2) events can be programmed for a five-day work week and two (2) events can be programmed for a two-day weekend. The following table can be used to devise a setback plan.

**Table 17 Night and weekend setback plan**

Event	Weekend	Weekday
Time 1		
Temperature1		
Sensitivity 1		
Humidity 1		
Humidity Sensitivity 1		
Time 2		
Temperature 2		
Sensitivity 2		
Humidity 2		
Humidity Sensitivity 2		

## 6.9 Setup Operation

Selecting Setpoint/Setup from the Main Menu will display the following selections:

- RESTART TIME DELAY
- C/F DEGREES
- HUMIDITY CONTROL METHOD
- SHOW DIPSWITCH
- CW FLUSH
- VALVE TIME

Use the Up and Down arrows to scroll through the submenu. Press **Enter** to select a particular function.

### 6.9.1 Restart Time Delay

This function delays unit restart after main power is restored to the unit. If several systems are operating, the time delays should be set to different values to cause a sequential start. Delay can be set from 0.1 minutes to 9.9 minutes (6 seconds to 594 seconds). Setting the value to zero (0) will prevent the unit from restarting when power is restored. In this case, the unit must be restarted manually by pressing the “ON/OFF” button on the keypad.

### 6.9.2 C/F Degrees

The control may be selected to show readings and setpoints in either degrees Fahrenheit (°F) or Celsius (°C). To change the value use Enter to select this function, then use the Up and Down arrows to change the value. Press Enter to store the value.

### 6.9.3 Humidity Control Method

The operator may select either relative (direct) or absolute (predictive) humidity control. If “relative” is selected, the RH control is taken directly from the RH sensor. If “absolute” is selected, the RH control is automatically adjusted whenever return air temperature deviates from the desired temperature setpoint (i.e., predictive humidity control). The LCD display will indicate percentage relative humidity for both methods of control. If the “absolute” feature is selected, the adjusted humidity reading will also be shown. When utilizing the predictive humidity control feature, the humidity level is automatically adjusted ~2% RH for each degree difference between the return air temperature and the temperature setpoint.

Unnecessary dehumidification can result when overcooling occurs during a dehumidification cycle. This is due to a higher than normal RH reading caused by overcooling the room (about 2% RH for each degree of overcooling). This drop in temperature extends the dehumidification cycle. Later, when the dehumidification ends and the temperature rises to the setpoint, the RH reading falls. The final RH reading will then be lower than actually desired. If the temperature drop was significant enough, the percentage RH could be low enough to activate the humidifier.

If the absolute humidity control is selected, over-dehumidification may be avoided. When overcooling occurs (i.e., causing an increase in the RH reading) the humidity control program estimates what the RH will be when the dehumidification cycle ends and temperature returns to the setpoint. This allows the dehumidification cycle to end at the proper time. Predictive humidity control can greatly reduce energy consumption by minimizing both compressor/reheat operation. Use the UP or DOWN arrow key to select the desired humidity control method.

### 6.9.4 Show DIP Switch

This function shows the position of the DIP switches, which are located on the control board in the unit; 1 = Switch is “ON” and 0 = Switch is “OFF.” For more information on the DIP switches and their functions, see **Table 20**.



### 6.9.5 Valve Time (for Systems With a Modulating Chilled Water Valve)

This function shows the full valve travel time of the modulating valve on a chilled water system. This is the time it takes for the valve to travel from full closed to full open. It is programmable from 50 to 250 seconds; factory default time is 165 seconds and should not be changed. The full valve travel time is used by the control to determine the appropriate valve position. For example, if the valve travel time is 165 seconds and 50% cooling is being called for, the valve will open for 83 seconds to achieve 50% open.

### 6.9.6 CW Flush (for Systems with a Modulating Chilled Water Valve)

This function shows the interval time at which the system will perform a modulating chilled water valve system flush cycle. The factory default is 24 (hours) and is programmable from 0 (hours) which signifies to never flush, to 99 (hours) which signifies to flush after every 99 hours of valve non-use. If the valve is called on by the control to open within the programmed interval time, the timer will be reset to 0. The flush cycle is active even when the fan is turned off, but power is applied to the unit. When the interval timer reaches the programmed time, the valve will be opened for 3 minutes to flush any contaminants that may have collected in the system.

**Table 18 Setup functions, default values and allowable ranges**

Function	Default	Range
Restart Time Delay	0.1	0 to 9.9 min (0 = manual restart)
C/F Degrees	°F	°C or °F
Humidity Control	Rel	Relative or Absolute
Valve Time	165	50 to 250 seconds
CW Flush	24	0 to 99 hours

## 6.10 Change Passwords

The display will prompt the operator to enter a three digit password when attempting to make changes. The system includes two (2) passwords, one for setpoints and one for setup. The system allows the password to be changed by first entering the default password set at the factory (1-2-3) for setpoints and (3-2-1) for setup. The password function provides system security so that only authorized personnel are allowed to make changes to the system. (If unauthorized changes are being made, the passwords may be compromised and new ones should be selected). The password function can be disabled by setting DIP switch 8 in the wall box to OFF, then resetting power to the unit.

## 6.11 Calibrate Sensors

The temperature and humidity sensors can be calibrated by selecting the CALIBRATE SENSORS menu item. The temperature sensor can be calibrated  $\pm 5^{\circ}\text{F}$ , while the humidity sensor can be calibrated  $\pm 10\%$  RH. When calibrating the humidity sensor, the value shown will always be % RH, even though absolute humidity control may be selected. If absolute humidity control is selected, the Normal Status Display will display the adjusted reading. This reading may not agree with the relative humidity reading displayed while in calibration.

If the sensors are subject to frequent wide temperature and humidity swings, it may be necessary to shorten the cycling by increasing the sensor time delay. If the sensors are located too close to the air discharge, they will likely experience rapid swings in measurement. Another method in reducing compressor cycling is to increase the temperature and/or humidity sensitivity.

## 6.12 Alarm Enable

Each alarm can be disabled or enabled. Use the Up and Down arrows to select a particular alarm, press Enter to select either Enable or Disable. Press Enter again to store the change. When the alarm is disabled it will NOT report to either the wall box beeper or to the common alarm relay.



### NOTE

*The high-water alarm will automatically shut the unit Off, even if the alarm is disabled. Similarly, optional factory-installed smoke sensor is wired to shut off the evaporator unit, regardless of the enable/disable status.*

## 6.13 Alarm Time Delay

Each individual alarm can be programmed with a time delay, causing the unit to delay a specified amount of time (0-255 seconds) before recognizing the alarm. See **Table 19** for the default times. The alarm condition must be present for the full amount of the time before the alarm will sound. If the alarm condition is diverted prematurely, the alarm will not be recognized and the time delay will automatically reset.



### NOTE

*For software alarms such as “loss of power” and “short cycle,” the time delay should be left at the factory default of 0.*

**Table 19 Alarm default time delays**

Alarm	Default Time Delay (seconds)
Custom Alarm #1	0
Custom Alarm #2	6
High Temperature	30
Low Temperature	30
High Humidity	30
Low Humidity	30
Short Cycle	0
Loss of Power	0

## 6.14 Common Alarm Enable

Each individual alarm can be selected to activate or deactivate the common alarm relay. If the energize common alarm function is set to Yes, the relay is energized immediately as the alarm is annunciated and de-energized when the alarm condition has been recognized. If the alarm is completely Disabled, the alarm has no effect on the common alarm relay. Use the Up and Down arrows to scroll to a particular alarm, press the Enter button to select it, then press the Enter button again to select Yes or No.

## 6.15 Custom Alarms

The custom alarm messages can be selected from a list of standard alarm messages or the operator can write his/her own message. A MAXIMUM OF TWO (2) ALARM MESSAGES CAN BE CUSTOMIZED. The two custom alarm messages will initially display the previously programmed message but can be changed.

The text for custom alarms can be changed at any time by selecting Custom Alarm. To change the text for a custom alarm, select the alarm you would like to change, 1 or 2. Using the Up and Down arrows, step through the list of five standard alarm messages (listed below) and two custom alarms. Select the alarm message desired and store it by pressing Enter.

### 6.15.1 Standard Custom Alarm Messages

- WATER FLOW LOSS
- SMOKE DETECTED
- LOSS OF AIR FLOW
- HUMIDIFIER PROBLEM
- FILTER CLOG

## 6.16 Custom Text

To modify the two custom alarm messages select "CUSTOM TXT". Then select "CUS TXT #1" or "CUS TXT #2". Text can be up to 20 characters in length and can be either a blank space or any of the following alphanumeric characters and symbols:

- A,B,C,D,E,F,G,H,I,J,K,L,M,N,O,P,Q,R,S,T,U,V,W,X,Y,Z
- #,%,\*,-
- 0,1,2,3,4,5,6,7,8 or 9

Use the Up and Down arrows to select a character, then press Enter. The cursor will move to the next space where you may once use the Up and Down arrows to select another character, etc.

### LCD Display Contrast

The level of contrast due to the viewing angle of the LCD display can be adjusted using a potentiometer screw, inside the wall box next to the display.

### Nonvolatile Memory

All critical information is stored in nonvolatile memory. Setpoints and setup parameters are kept inside the microcontroller in EEPROM.

## Equipment Options Switches

Equipment options are selected and enabled using DIP switches 1 through 7. These are located on the control board near TB1. These switches are factory-set and should not require any user changes. The setting and function of the switches can be individually read on the LCD display.



### NOTE

*In order to update the dip switch settings, power must be cycled off, then on, from the unit disconnect switch.*

**Table 20 Equipment switch settings (unit control board)**

Switch	OFF Position	ON Position
1	Compressor	Chilled Water
2	Standard Reheat	SCR Reheat
3	No Modulating Valve	Modulating CW Valve
4	Not Used	Not Used
5	Enable Reheat	Disable Reheat
6	Enable Humidifier	Disable Humidifier
7	Enable Dehumidifier	Disable Dehumidifier
8	Electric Reheat	Gas Reheat

**Table 21 Switch settings (wall box board)**

Switch	OFF Position	ON Position
1	Disable Beeper	Enable Beeper
2	Not Used	Not Used
3	Not Used	Not Used
4	Not Used	Not Used
5	Not Used	Not Used
6	Not Used	Not Used
7	Disable Setback	Enable Setback
8	Enable Password	Disable Password

## 6.17 Run Diagnostics (Available On Rev 1.001.0 and higher)

By selecting Run Diagnostics, maintenance personnel can check system inputs, outputs and conduct a test of the microcontroller circuit board from the wall box control. A review of the system inputs and the microcontroller test can be done without interrupting normal operation.

### Show Inputs

With the unit on and the fan running, the input states may be displayed for the following devices:

- High Water Alarm: Normally off unless High Water Alarm is active.
- High Head Pressure Alarm: Normally off unless High head Pressure alarm is active.
- Custom alarm #1: Normally off unless this special customer selectable alarm is active.
- Custom alarm #2: Normally off unless this special customer selectable alarm is active.
- Power: Normally on unless unit is turned off through the wall box or any of the following optional devices: High Temperature Sensor, Smoke Sensor, High Water Alarm or Remote Shutdown

## Test Outputs

When this feature is selected, the controller is effectively turned off. When stepping from one load to the next, the previous load is automatically turned off. The loads can also be toggled On and Off by selecting “ENTER.” Once turned on, the output will remain on for five minutes unless toggled off or the test outputs function is exited by selecting “MENU/ESC” (Compressor is limited to 15 seconds On to prevent damage.)

### NOTICE

Risk of overheating the compressor during the Test Outputs mode. Can cause compressor damage.

Testing the compressor output for more than a few seconds can damage the compressor. Do not operate the unit in the Test Outputs mode any longer than is necessary for troubleshooting.

### NOTICE

Risk of extended unit operation in the Test Outputs mode for troubleshooting. Can cause damage to unit.

DO NOT operate unit in the Test Outputs mode any longer than is necessary for troubleshooting

The outputs are as follows:

- Normal Fan: Normal speed fan contactor
- Humidifier: Humidifier contactor
- Cool: Compressor contactor (Valve opens on chilled water units)
- HGBP: Hot gas bypass valve
- Reheat: Reheat contactor
- Common Alarm: Common alarm relay




#### NOTE

*Fan turned on with all loads.*

## Test Control Board

By selecting this function, the microcontroller will perform a self test lasting approximately 10 seconds. When the test is complete, the display will show the ROM checksum, ROM part number and firmware revision number.

Figure 27 Control menu



**Status Display**  
75 F 50%RH  
NO ALARMS

- Menu**  
Setpoints  
Status  
Active Alarms  
Time  
Date  
Setback  
Setup Operation  
Setup Password  
Setup Password  
Calibrate Sensors  
Alarm Enable  
Alarm Time Delay  
Common Alarm Enable  
Custom Alarms  
Custom Text  
Diagnostics  
End of Menu

**Setpoints/Setup**  
Temp Setpt  
Temp Sens  
Hum Setpt  
Hum Sens  
Hi Temp Alm  
Lo Temp Alm  
Hi Hum Alm  
Lo Hum Alm

**Status**  
Heat % 0  
Dx Cool % 0  
Dehumidify % 0  
Humidify % 0

**Active Alarms**  
No Alarms  
or  
Alarm 01 of 01  
High Head

**Time**

**Date**

**Setback**  
Wknd Time 1  
Wknd Temp 1  
Wknd Tsens 1  
Wknd Humd 1  
Wknd Hsens 1  
Wknd Time 2  
Wknd Temp 2  
Wknd Tsens 2  
Wknd Humd 2  
Wknd Hsens 2  
Wkdy Time 1  
Wkdy Temp 1  
Wkdy Humd 1  
Wkdy Hsens 1  
Wkdy Time 2  
Wkdy Temp 2  
Wkdy Tsens 2  
Wkdy Humd 2  
Wkdy Hsens 2

**Setup Operation**  
Restart TD  
C/F Degrees  
Humidity Control  
Dipswch 00000000  
Pos 12345678

**Setup Password**  
Enter New PSW  
Setpt PSW = 000

**Setup Password**  
Enter New PSW  
Setup PSW = 000

**Calibrate sensors**  
Temp Cal  
Hum Cal  
Temp Delay  
Hum Delay

**Alarm Enable**  
Custom #1  
Custom #2  
High Temp  
Low Temp  
High Hum  
Low Hum  
Short Cycle  
Loss Pwr

**Alarm Time Delay**  
Custom #1  
Custom #2  
High Temp  
Low Temp  
High Hum  
Low Hum  
Short Cyc  
Loss Pwr


**Common Alarm Enable**  
Hi Water  
Hi Head  
Custom #1  
Custom #2  
High Temp  
Low Temp  
High Hum  
Low Hum  
Short Cyc  
Loss Pwr

**Custom Alarms**  
Custom Alarm #1  
Custom Alarm #2

**Custom Text**  
Custom Text #1  
Custom Text #2


**Diagnostics**  
Test Inputs  
Test Outputs  
Test Microcontroller

Figure 28 Control board—inside evaporator



- TB2-4 — Hot Gas Bypass
  - TB2-3 — High Head Alarm Connection
  - TB2-2 — Heat Rejection
  - TB2-1 — Heat Rejection
- TB1-9 — Condensate Pump Aux Alarm
  - TB1-8 — Condensate Pump Aux Alarm
  - TB1-7 — Common Alarm Connection
  - TB1-6 — Common Alarm Connection
  - TB1-5 — Remote Shutdown
  - TB1-4 — Remote Shutdown
  - TB1-3 — Customer Alarm Connection #2
  - TB1-2 — Customer Alarm Connection #1
  - TB1-1 — Customer Alarm Connection (common)
- TB3-4 Connection to TB3 Pin 4 of Wall Box
  - TB3-3 Connection to TB3 Pin 3 of Wall Box
  - TB3-2 Connection to TB3 Pin 2 of Wall Box
  - TB3-1 Connection to TB3 Pin 1 of Wall Box
- TB4-2 Site Monitoring Connection (-)
  - TB4-1 Site Monitoring Connection (+)
- P16 Remote Sensor Connection

Figure 29 Wall box board



- TB3 — 1
- TB3 — 2
- TB3 — 3
- TB3 — 4

Wall Box  
DIP Switches (1-8)

## 7.0 SYSTEM PERFORMANCE MICROPROCESSOR CONTROLS

This section describes in detail how the Mini-Mate2 responds to operator inputs and room conditions.

### 7.1 Temperature Control

#### 7.1.1 Cooling/Heating Required

The temperature control program for the microprocessor is based on a calculated percentage requirement for cooling/heating.

#### 7.1.2 Cooling Operation (Compressorized Direct Expansion and Chilled Water)

Cooling is ACTIVATED when the temperature control calculates a requirement for cooling of 100%. It is DEACTIVATED when the cooling requirement drops below 50%. Hot gas bypass is energized on DX units when a call for cooling occurs unless there is also a call for dehumidification.

**Table 22 Cooling and dehumidification load response of hot gas bypass**

Situation	Hot Gas Bypass
Cooling only	ON
Dehumidification only	OFF
Cooling with Dehumidification	OFF

#### 7.1.3 Heating Operation

##### Electric Heat or Hot Water

The reheat stage is ACTIVATED when the temperature control calculates a requirement of 100%. Conversely, the reheat is DEACTIVATED when the heat requirement is 50% less than the activation point.

##### SCR Electric Reheat

The SCR (Silicon Controlled Rectifier) controller proportionally controls the stainless steel reheat feature to maintain the selected room temperature. The rapid cycling made possible by the SCR controller provides precise temperature control, while the constant element temperature improves heater life. During operation of the SCR control, THE COMPRESSOR OPERATES CONTINUOUSLY. The heaters are modulated to provide temperature control. The display status will show when the unit is cooling and heating. The control will automatically lock the compressor cooling to "ON" position, except when the temperature falls below the low temperature alarm set point. Cooling will then be disabled until the room temperature reaches the temperature set point.

### 7.2 Humidity Control

#### 7.2.1 Dehumidification/Humidification Required

The humidity control is based on a calculated percentage requirement for dehumidification or humidification (i.e., the difference between the return air humidity and the humidity set point). As the return air humidity rises above the humidity set point, the percent dehumidification required increases proportionally from 0 to 100% over a humidity band equal to the humidity sensitivity setting. The converse is true for percent humidification requirement.

#### 7.2.2 Dehumidification Operation, Compressorized Direct Expansion (DX) Systems

Dehumidification with the standard configuration is accomplished by operating the compressor without the hot gas bypass active. Dehumidification will be disabled if the heating requirement exceeds 125%. It is re-enabled when the heating requirement reaches 50%.



### 7.2.3 Humidification Operation

The canister humidifier is activated when the humidity control calculates a requirement of 100% humidification; and is deactivated when the humidification requirement falls below 50%.

## 7.3 Load Control Features

The control system monitors the compressor and prevents it from turning on within a 3 minute period of being off. If this on-off-on cycle occurs too often (e.g., 10 times in one hour) a Short Cycle Alarm will occur.

### 7.3.1 Communications

The control system uses a two-wire, RS-422 channel to communicate with Liebert Site Products via a proprietary protocol. A converter board (ECA2) is available to allow communications with a “dumb” terminal or a computer using RS-232 channel. More details are provided in the Site Products and ECA2 User Manual.

The communications channel provides both monitoring and control options, including:

- TEMPERATURE/HUMIDITY: Current temperature and humidity readings.
- STATUS (%), Cooling/heating and humidify/dehumidify operating status.
- PRESENT ALARMS: Alarms currently activated.
- SET POINTS:
  - Temperature Set point
  - Temperature Sensitivity
  - Humidity Set point
  - Humidity Sensitivity
  - High Temperature Alarm
  - Low Temperature Alarm
  - High Humidity Alarm
  - Low Humidity Alarm
- ON/OFF STATUS and CONTROL
- SILENCE ALARM

---

## 8.0 ALARMS

---

The microprocessor control system will audibly and visually signal all ENABLED Alarms (including two (2) custom alarms). These special alarms can be chosen from the optional alarm list and/or can have their own fully custom text. The custom alarm inputs are contact closures wired from terminal TB1-1 through a normally open contact to either TB1-2 (alarm 1) or TB1-3 (alarm 2). The alarms can be enabled or disabled (refer to **6.0 - Microprocessor Control**) and a time delay of 0-255 seconds can be set. The alarms can also be programmed to either sound the alarm & activate the common alarm relay OR to sound the alarm only.

When a new alarm occurs, it is displayed on the screen and the audible alarm is activated. (If communicating with a Liebert Site Product, the alarm is also transmitted.) The message “PRESS ALARM SILENCE” will prompt the operator to silence the alarm. After the alarm is silenced, the display will return to the Normal Status Display. Alarms can be reviewed by selecting the “ACTIVE ALARMS” feature. The alarms can also be silenced through communications with a Liebert Site Product unit.

Many alarms will reset automatically when the alarm condition is no longer represented and only after it has been acknowledged by being “Silenced.” The exceptions are:

1. software alarms, i.e., Loss of Power and Short Cycle alarms will reset automatically 30 seconds after being silenced or acknowledged
2. specific alarms monitoring overload or high pressure switches may require a manual reset depending upon the model

### 8.1 Alarms: Definitions and Troubleshooting

The following list provides a definition and troubleshooting suggestions for each type of alarm. Refer to **11.0 - Troubleshooting** for additional details. If you need further assistance, contact your Liebert supplier. **THE CUSTOMER MUST SPECIFY ALARM(S) AT THE TIME OF ORDER. OTHER DEVICES AND WIRING MAY BE REQUIRED AT THE FACTORY FOR SOME OF THE ALARMS.**

#### 8.1.1 Custom Alarms

Custom alarm(s) messages are programmed at the LCD display. The message displayed may be included in a list of provided alarms or it may be customized text (for up to 2 alarms). **IF CUSTOMIZED TEXT IS USED, MAINTENANCE PERSONNEL SHOULD BE INFORMED OF THE ALARM FUNCTION AND THE REQUIRED ACTION.**

#### 8.1.2 High Head Pressure

Compressor head pressure is monitored with a pressure-sensor switch. (One SPDT pressure switch is used) for the compressor in the unit.

If head pressure exceeds 400 psig (2785 kPa), the switch opens the compressor contactor and sends an input signal to the control. The high head pressure condition is acknowledged by pressing the Alarm Silence button on the wall box, which will clear the alarm if the high head pressure condition no longer exists. If the compressor is Off for 1 hour, the control goes into a special cold start mode. In the cold start mode on a call for cooling or dehumidification, the liquid line solenoid valve (LLSV) is energized. If the high pressure switch does NOT trip within 10 seconds, the control returns to normal operation of monitoring the high head pressure switch for three occurrences in a 12 hour period. It is a rolling timer, and after the third high head alarm occurs and is acknowledged by the user, it will lock Off the compressor.

If while in the cold start mode, the high head pressure switch DOES trip within 10 seconds of the activation of the LLSV, the control does not annunciate the alarm. The control will turn Off the LLSV and delay 10 seconds. The control will permit this occurrence two more times or a total of three times. If on the fourth try, the high head pressure switch trips within 10 seconds, the control will annunciate the alarm, turn Off the LLSV, wait for the user to acknowledge the alarm and hold the compressor Off for 3 minutes, the length of the normal short cycle control. The control will permit this occurrence three times. On the third occurrence, the control will lock the compressor Off until the control power is reset.

## Air-Cooled Systems

Check for power shut Off to the condensing unit, condenser fans not working, defective head pressure control valves, closed service valves, dirty condenser coils and crimped lines. Also, make sure that when the compressor contactor is energized, the side switch on the contactor closes to energize the control circuit on the condensing unit.

## Water/Glycol/ Systems

Check water regulating valves. Verify water/glycol flow (i.e., pumps operating and service valves open). Is water tower or drycooler operating? Is the coolant temperature entering the condenser at or below design conditions? Is AUX relay (terminals 70 & 71) operating during cooling to turn on the drycooler?

### 8.1.3 Humidity Level

The humidity level alarm may be activated under the following conditions:

- **High:** The room return air humidity exceeds the pre-set high humidity alarm set point. Is the unit set up for dehumidification? Check DIP switch.
- **Low:** The room return air humidity decreases to the low humidity alarm set point. Is the unit setup for humidification? Check DIP switch.
- **High and Low Humidity (simultaneously):** The simultaneous display of two alarms results in loss of the humidity input signal. DASHES WILL BE DISPLAYED IN THE HUMIDITY READING DISPLAY. Under these conditions, the control system deactivates both humidification and dehumidification. Check for a disconnected cable or failed sensor.



#### NOTE

*Check for proper setpoints. Does the room have a vapor barrier to seal it from outdoor humidity? Are doors or windows open to outside air?*

### 8.1.4 Temperature

The temperature level alarm may be activated under the following conditions:

- **High:** The room return air temperature increases to the high temperature alarm set point. Check for proper set point value. Is the room load more than the unit can handle (i.e., capacity too small)? Make sure cooling components are operating (compressor or valves).
- **Low:** The room return air temperature decreases to the low temperature alarm set point. Check for proper set point value. Make sure all heating components are operating (e.g., contactors, reheats, etc.). Are reheats drawing the proper current (refer to amp rating on nameplate).
- **High and Low (simultaneously):** The simultaneous display of these two alarms results in loss of the temperature input signal (or the humidity is out of sensor range-15 to 85% RH). Dashes will be displayed for the temperature reading. The control system will initiate 100% cooling. Check for a disconnected cable or a failed sensor.

### 8.1.5 Humidifier Problem Alarm

The Humidifier Problem Alarm will sound and display a message if any of the following humidifier conditions occur: overcurrent detection; fill system fault or end of cylinder life.

Check fault indicator LED on humidifier control board:

- Constant LED on = Overcurrent
- 1 second LED Flash = Fill System
- 1/2 second LED Flash = Replace Tank

### 8.1.6 High Water Alarm

A float switch in the evaporator pan will shutdown the evaporator on a high water level. Clear the drain and reset power to the unit in order to clear the alarm.

### **8.1.7 Loss of Power**

The Loss of Power Alarm will activate (after power is restored to the unit) if the unit has lost power or the disconnect switch was incorrectly turned off before the unit ON/OFF switch was pressed. A Liebert remote monitoring unit (optional) will immediately indicate loss of power.

### **8.1.8 Short Cycle**

A Short Cycle Alarm will occur if the compressor system has exceeded 10 cooling start attempts in a one-hour period. This can be caused by low refrigerant level or room cooling load is small compared to capacity of the unit. Check for leaks, crimped lines and defective components. If room load is low, increase temperature sensitivity to reduce cycle.

## **8.2 Optional/Custom Alarms**

### **8.2.1 Change Filter**

Periodically, the return air filters in the evaporator must be changed. The Change Filter alarm notifies the user that filter replacement is necessary. A differential air pressure switch closes when the pressure drop across the filters becomes excessive. The switch is adjustable using the procedure on the switch label.

### **8.2.2 High Temperature Sensor**

The optional high temperature sensor is a bi-metal operated sensing device with a closed switch under normal conditions. Connected between pins 1-8 and 1-9, this device will shut down the entire unit.

### **8.2.3 Smoke Sensor**

The optional smoke sensor constantly samples return air through a tube. Its power supply is located in the electric panel. The smoke sensor shuts down the unit upon detecting smoke, and activates visual and audible alarms. This smoke sensor is not intended to function as or replace any room smoke detection system that may be required by local or national codes. Locate the source of the smoke and follow appropriate emergency procedures.

---

## 9.0 SYSTEM OPERATION, TESTING AND MAINTENANCE

---

This section describes system testing, maintenance and replacement procedures. Use copies of the Maintenance Inspection Checklist to record preventive maintenance inspections.



### WARNING

Risk of electric shock. Can cause injury or death.

Open all local and remote electric power disconnect switches before working within the electrical enclosures.

The Liebert microprocessor control does not isolate power from the unit in the Unit Off mode. Some internal components require and receive power even during the Unit Off mode. The line side of the disconnect switch on the front of the unit contains live high voltage. The only way to ensure that there is NO voltage inside the unit is to install and open a remote disconnect switch and check the internal power supply wires with a voltmeter.

### 9.1 System Testing

#### 9.1.1 Environmental Control Functions

The performance of all control circuits can be tested by changing the set points, which activates each of the main functions.

#### 9.1.2 Cooling

To test the cooling function, set the set point to a temperature of 10°F (5°C) below room temperature. A call for cooling should register and prompt the equipment to begin cooling cycle. (Disregard any temperature alarms). Upon completion of testing, return set point to the desired temperature.

#### 9.1.3 Heating

Reheat may be tested by setting the set point 10°F (5°C) above room temperature. A call for heating should register and prompt the equipment to begin heating cycle. (Disregard any temperature alarms). Upon completion of testing, return set point to the desired temperature.

#### 9.1.4 Humidification

To check humidification, set the humidity set point at R.H. 10% above the room humidity reading. After a short delay, the canister will fill with water and steam will be produced. Upon completion of testing, return the humidity set point to the desired humidity.

#### 9.1.5 Dehumidification

The dehumidification performance can be tested by setting the humidity set point at R.H. 10% below room relative humidity. The compressor should turn on. Upon completion of testing, return humidity set point to the desired humidity.

#### 9.1.6 Remote Shutdown

A connection point is provided for remote shutdown devices supplied by the customer. This terminal strip is located on the printed circuit board. (Terminals TB1-4 and TB1-5 are fitted with a jumper when no remote shutdown device is installed).

### 9.2 Maintenance and Component Operation

#### 9.2.1 Electric Panel

The electric panel should be inspected on a semi-annual basis for any loose electrical connections.

#### 9.2.2 Filters

Filters are usually the most neglected item in an environmental control system. In order to maintain efficient operation, they should be checked monthly and changed as required. ALWAYS TURN POWER OFF BEFORE REPLACING FILTERS.

Filters are replaced by opening the hinged door on the return air filter box.

### 9.2.3 Blower System

Monthly inspection of the blower package include: motor mounts, belts, fan bearings and impellers.

Fan impellers should be thoroughly inspected and any debris removed. Check to see if they are tightly mounted on the fan shaft and do not rub against the fan housing during rotation. Motor bearings are permanently sealed and self-lubricating and do NOT need lubricated.

The drive belt should be checked monthly for signs of wear and proper tension. Pressing on belts midway between the sheave and pulley should produce from 1/2" to 1" (12 to 25 mm) of deflection. Belts that are too tight can cause excessive bearing wear.

Belt tension can be adjusted by raising or lowering the fan motor base. Loosen nut above motor mounting plate to remove belt. Turn nut below motor mounting plate to adjust belt tension. If belt appears cracked or worn, it should be replaced with a matched belt (identically sized). With proper care, a belt should last several years.



#### NOTE

*After adjusting or changing the belt, always be certain that motor base nuts are tightened. The bottom adjustment nut should be finger tight. The top locking nut should be tightened with a wrench.*

#### Air Distribution

Since all unit models are designed for constant volume air delivery, any unusual restrictions within the air circuit must be avoided. High efficiency filters can reduce air performance and evaporator capacity.

### 9.2.4 Blower Removal

If the blower or bearings must be removed or serviced, use the following procedure.

## NOTICE

Risk of refrigerant and water/glycol piping damage. Can cause leaks that result in equipment and building damage and loss of cooling.

Use caution and do not contact piping when removing the blower motor and blower sled.

1. Remove the main center section of the three-piece electric panel by first marking and disconnecting all power and control wiring entering the panel.
2. Remove the panel by removing screws from top and bottom sections
3. Remove the blower motor from the blower sled.
4. Remove the four bolts holding the blower sled to the base isolators.
5. Slide the blower/sled assembly forward and rotate 90°.
6. Slide the blower/sled assembly from unit after ensuring that the refrigerant and water piping are protected from damage.
7. Reinstall by reversing this procedure.

### 9.2.5 Refrigeration System

Each month the components of the refrigeration system should be inspected for proper function and signs of wear. Since in most cases evidence of malfunction is present prior to component failure, periodic inspections can be a major factor in the prevention of most system failures. Refrigerant lines must be properly supported and not allowed to vibrate against ceilings, floors or the unit frame. Inspect all refrigerant lines every six months for signs of wear and proper support. Inspect the capillary and equalizer lines from the expansion valve.

#### Suction Pressure

Suction pressure will vary with load conditions. Suction pressure normally ranges from 58 psi to 75 psi (405 kPa to 517 kPa).

## Discharge Pressure

The discharge pressure will vary greatly with load and ambient conditions (Table 23). The high-pressure switch will shut the compressor down at its cut-out setting.

**Table 23 Typical discharge pressure**

System Design	Discharge Pressure, psig (kPa)
Air-Cooled	200-300 (1380-2070)
Water-Cooled 65 to 85°F water (18 to 29.4°C)	200-250 (1380-1725)
Glycol-Cooled	250-350 (1725-2415)
High-Pressure Cut-Out	400 (2760)

## Thermostatic Expansion Valve

The thermostatic expansion valve keeps the evaporator supplied with enough refrigerant to satisfy load conditions. Proper valve operation can be determined by measuring superheat level. If too little refrigerant is being fed to the evaporator, then the superheat will be high. Conversely, if too much refrigerant is being supplied, then the superheat will be low. The correct superheat setting is between 10 and 15°F (5.6 and 8.3°C).

## Air-Cooled Condensing Units

Restricted airflow through the condenser coil will reduce the operating efficiency of the unit. Additionally, it can result in high compressor head pressure and loss of cooling. Using compressed air or commercial coil cleaner, clean the condenser coil of all debris that will inhibit airflow. In winter, do not permit snow to accumulate around the side or underneath the condenser. At the same time check for bent or damaged coil fins and repair as necessary. Check all refrigerant lines and capillaries for vibration and support as necessary. Carefully inspect all refrigerant lines for signs of oil leaks.

## Coaxial Condensers (Water/Glycol-Cooled Condensing Units)

Each water- or glycol-cooled condensing unit has a coaxial condenser consisting of an exterior steel tube and an interior copper tube. If the water supply is clean, coaxial condensers do not normally require maintenance or replacement. Should your system begin to operate at high head pressure with reduced capacity and all other causes have been eliminated, the condenser may be obstructed or fouled and should be replaced.

## Regulating Valves (Water/Glycol Condensing Units)

The water regulating valve automatically regulate the amount of fluid necessary to remove the heat from the refrigeration system, permitting more fluid to flow when load conditions are high and less fluid to flow when load conditions are low.

The water regulating valve is designed to begin opening at 180 psi (1240 kPa) and to be fully opened at 240 psi (1655 kPa). The valve is factory-set and should not need adjustment.

## Glycol Solution Maintenance

It is difficult to establish a specific schedule of inhibitor maintenance since the rate of inhibitor depletion depends upon local water conditions. Analysis of water samples at time of installation and every six (6) months should help to establish a pattern of depletion. A visual inspection of the solution and filter residue is often helpful in judging whether or not active corrosion is occurring. The complexity of problems caused by water requires expert advice from a water treatment specialist plus a regular maintenance program schedule. It is important to note that improper use of water treatment chemicals can cause severe problems.

Proper inhibitor maintenance must be performed in order to prevent corrosion of the glycol system. Consult your glycol manufacturer for proper testing and maintenance procedures. Do not mix products from different manufacturers.

## Hot Gas Bypass

### Operation

The hot gas bypass valve is installed between the compressor discharge piping and suction piping, bypassing the condenser and evaporator coils. The discharge gas mixes with the suction gas, raising the suction temperature and pressure and decreasing the mass flow through the evaporator. The higher suction temperatures could cause compressor overheating, therefore a separate liquid quenching valve is provided to mix refrigerant from the system liquid line with the discharge gas before mixing with the suction gas entering the compressor.


During normal operation, when the evaporator is under full load the hot gas bypass equalizer pressure will remain high enough to keep the valve port closed. If the evaporator load decreases, the evaporator temperature and pressure will drop. When the suction pressure reduces below the hot gas bypass valve setting the hot gas bypass valve opens diverting some of the refrigerant flow back to the compressor suction. The liquid quenching valve bulb senses this increased superheat and opens, allowing liquid refrigerant to mix with the discharge gas, desuperheating it.

Proper mixing of the three refrigerant paths ensures stable operation and system performance. The liquid quenching valve bulb must be located downstream of all these connections to control superheat at the compressor inlet. Superheat settings for the liquid quenching valve are chosen to maintain consistency with the system expansion valve. During hot gas bypass operation higher superheats, 50-60°F (19 to 15°C), may be observed at the compressor. The liquid quenching valve is internally equalized and superheat is not adjustable.

### Adjustment

1. Install the suction and discharge pressure gauge.
2. Adjust temperature setpoint to call for cooling so that the refrigeration compressor will run continuously.
3. Remove the TOP adjusting nut from the valve.
4. Insert an Allen wrench in the brass hole at top of valve in adjusting port and turn CLOCKWISE if a higher evaporator temperature is required. Adjust no more than 1/4 turn at a time. Let the system stabilize for 15 minutes before determining if additional adjustment is necessary.
5. After obtaining the suction pressure required, reinstall cap tightly making sure there are no leaks.
6. Let the evaporator operate for approximately 10 to 15 minutes to make sure the suction pressure is within the range desired.
7. There may be a fluctuation of approximately 3 to 6 PSIG (21 to 41 kPa) on the evaporator due to the differential on the hot gas bypass.
8. Return temperature setpoint to the desired setting.

Figure 30 Hot gas bypass





## 9.3 Replacement Procedures

### 9.3.1 Compressor Replacement

Infrequently a fault in the motor insulation may result in a motor burnout (if system is properly installed, motor burnout rarely occurs). Primarily this type of failure is due to mechanical or lubrication problems, where the burnout is a secondary consequence.

Early detection can prevent a large percentage of the problems that can cause compressor failures. Periodic maintenance inspections by alert service personnel (i.e., identification of abnormal operation) can be a major factor in reducing maintenance costs. It is easier and more cost-effective to implement the necessary preventative steps that ensure proper system operation; rather than ignore a problem until it results in compressor failure and costly replacement. When troubleshooting a compressor problem, check all electrical components for proper operation:



#### **WARNING**

Risk of explosive discharge from high-pressure refrigerant. Can cause injury or death.

This unit contains fluids and gases under high pressure. Relieve pressure before working with piping.



#### **CAUTION**

Risk of contacting caustic substances. Can cause injury.

Do not touch or contact the gas or oils with exposed skin. Severe burns will result. Wear protective clothing, safety goggles and long rubber gloves when handling contaminated parts.

- Check all fuses and circuit breakers.
- Check pressure switch operation.
- If a compressor failure has occurred, determine whether its cause is an electrical or mechanical problem.

#### **Mechanical Failure**

If you have determined that a mechanical failure has occurred, the compressor must be replaced. If a burnout occurs, correct the problem and clean the system. It is important to note that successive burnouts OF THE SAME SYSTEM are usually caused by improper cleaning. If a severe burnout has occurred, the oil will be black and acidic.

### 9.3.2 Electrical Failure

In the event of an electrical failure and subsequent burnout of the refrigeration compressor motor, proper procedures must be followed to thoroughly remove any acids that would cause a future failure. There are two kits that can be used with a complete compressor burnout - Sporlan System Cleaner and Alco Dri-Kleener. Follow the manufacturer's procedure. **DAMAGE TO A REPLACEMENT COMPRESSOR DUE TO IMPROPER SYSTEM CLEANING CONSTITUTES ABUSE UNDER THE TERMS OF THE WARRANTY, THEREBY VOIDING THE WARRANTY**

Replacement compressors are available from your Emerson supplier and will be shipped to the job site in a reusable crate (as required by the service contractor). If the compressor is under warranty, it must be returned to Emerson, in order to receive proper warranty credit. It should be returned in the same container it was shipped in. The possible cause(s) or condition(s) of the damage should be recorded on the provided return tag.

## Replace a Failed Compressor

Proper procedures to remove and replace the failed compressor are:

1. Disconnect power
2. Attach suction and discharge gauges to access fittings.
3. Recover refrigerant using standard recovery procedures and equipment. Use a filter-drier when charging the system with recovered refrigerant.



### NOTE

*Release of refrigerant to the atmosphere is harmful to the environment and unlawful. Refrigerant must be recycled or discarded in accordance with federal, state and local regulations.*

4. Remove failed compressor.
5. Install replacement compressor and make all connections. Use a flow of dry nitrogen through the piping during brazing to prevent formation of copper oxide scale inside the piping. Copper oxide forms when copper is heated in the presence of air. POE oil will dissolve these oxides from inside the copper pipes and deposit them throughout the system, clogging filter driers and affecting other system components.  
A pure dry nitrogen flow of 1-3 ft<sup>3</sup>/min (0.5-1.5 l/s) inside the pipe during brazing is sufficient to displace the air. Control the flow using a suitable metering device. Pressurize and leak test the system at approximately 150 psig (1034kPa) pressure.
6. Follow manufacturer's instructions for clean out kits.
7. Evacuate the system twice to 250 microns. Break the vacuum each time with clean, dry nitrogen.
8. Evacuate the system a third time to 250 microns.
9. Charge the system with refrigerant (R-407C) based on requirements of the evaporator, condensing unit and lines. Refer to the unit nameplate.
10. Apply power and operate the system. Check for proper operation. Refer to **Table 23**.

### 9.3.3 Steam Generating Humidifier-Operation Procedures

Steam generating humidifiers operate efficiently over a wide range of water quality conditions and automatically adjust to changes in the conductivity of water. The system will automatically drain and refill to maintain a current set point and alert the operator when the humidifier canister needs to be replaced.

The humidifier RUN/DRAIN switch is located in the humidifier assembly. This switch should be in the RUN position when the humidifier is in normal operation and in the DRAIN position during service. The electronic control board for the humidifier is also located in the humidifier assembly. When the unit is energized, power is available to humidifier. Operation involves the following steps:

1. During start-up, when the humidity control calls for humidification, the fill valve will open, allowing water to enter the canister. When the water level reaches the electrodes, current flows and the water will begin to warm. The canister fills until the amperage reaches the set point and the fill valve closes. As the water warms, its conductivity increases and the current flow, in turn, rises. If the amperage reaches 115% of the normal operating amperage, the drain valve opens and flushes some of the water out of the canister. This reduces electrode contact with the water and lowers the current flow to the amperage set point. Boiling soon commences and the canister operates normally.
2. If the conductivity of the water is low, the canister fills and the water level reaches the canister full electrode before the amperage set point is reached. The humidifier stops filling to prevent overflow. Boiling should commence in time. As water is boiled off, the mineral concentration in the canister increases and current flow also increases. The canister eventually reaches full output and goes to normal operation. No drain is permitted until then.
3. When full output is reached the circuit board starts a time cycle which is factory-set at 60 seconds. During this repeating time cycle, the fill valve will open periodically to replenish the water being boiled off and maintain a “steady state” output at the set point. The amperage variance will depend on the conductivity of the water.
4. After a period of time, the mineral concentration in the canister becomes too high. When this occurs, the water boils too quickly. As the water quickly boils off and less of the electrode is exposed, the current flow decreases. When the current crosses the low threshold point (factory-set at 85%) before the end of the time cycle, the drain valve opens, draining the mineral laden water out and replacing it with fresh water. This lowers the mineral concentration and returns the canister to “steady state” operation and prolongs canister life. The frequency of drains depends on water conductivity.
5. Over a period of time, the electrode surface will become coated with a layer of insulating material, which causes a drop in current flow. As this happens, the water level in the canister will slowly rise exposing new electrode surface to the water to maintain normal output. Eventually, the steady state water level will reach the canister full electrode and indicate so by activating the canister full alarm. At this point, all of electrode surface has been used up and the canister should be replaced.
6. After the entire electrode surface has been coated, the output will slowly decrease. This allows for maintenance scheduling. During these last hours of electrode life, the mineral concentration can increase and arcing can occur. If the electrodes start to arc, turn off the humidifier immediately and replace the canister with the identical part.

## Replacing the Humidifier Canister



### CAUTION

Risk of contact with extremely hot surfaces. Can cause injury.

Canister and steam hose may be hot. Do not attempt to replace parts until the humidifier has cooled down to a temperature that is safe for human contact. Use extreme caution and wear thermally insulated gloves and arm protection when replacing the humidifier canister.

The proper procedure to replace the humidifier canister is:

1. Turn off the humidifier by lowering the humidity setpoint below the ambient humidity level. Record the original setpoint.
2. Place the RUN/DRAIN switch in the DRAIN position to drain the water from the canister.
3. Return the RUN/DRAIN switch to the RUN position after the canister has drained.
4. Turn OFF the power at the main unit.
5. Remove the cover from the humidifier cabinet.
6. Locate the power wires to the steam canister. They are connected to the canister with 1/4" quick connects. Make note of the wiring configuration before removing any wires. Refer to schematic on unit. Slide the rubber boot back to expose the connections. Remove the two (2) power wires and the canister-full wire. Do not loosen the screws that secure the electrodes.
7. Loosen the steam outlet hose clamps and slide the steam hose away from the canister fitting. Release the canister clamp along the base of the canister.
8. Remove the canister.
9. Reverse previous steps to re-assemble humidifier, paying special attention to the following:
  - When replacing the wiring, connect the red wire from terminal #1 on the interface to the red tip terminal on the canister. Reconnect the power wires as before (#2 on the left and #1 on the right)
  - When replacing the canister, always check the fill and drain solenoids for proper operation.

### 9.3.4 Humidifier Circuit Board Adjustments



### WARNING

Risk of electric shock. Can cause injury or death.

Open all local and remote electric power disconnect switches before working on the humidifier printed circuit board.

Verify that electric power is Off with a voltmeter prior to the procedure.

The humidifier control board governs humidifier operation. There are three potentiometers mounted on the board and can be used to adjust for extreme water conductivity conditions.

POT2 controls the amperage at which the drain will energize and is clearly marked in percentages. This adjustment is factory-set at 85%, which indicates that the unit will drain when the amperage falls off to 85% of the capacity set point. Raising the value increases the frequency of drain cycles. Lowering the value decreases the frequency of drain cycles.

The frequency should be increased for highly conductive water and decreased for less conductive water. If adjustment is necessary and a change of three to four percent in either direction does not permit normal operation of the unit, consult your Liebert supplier.

The POT1 controls the duration of the drain cycle. This adjustment is factory-set at 60 seconds (1 VDC) and should not be readjusted without consulting your Liebert supplier.

The DIP switch settings are used to set the capacity of the humidifier. If the humidifier is replaced in the field the DIP switches should be set to the required settings described below.

**Table 24 Humidifier control board DIP switch settings**

Voltage	SW1	SW2	SW3	SW4	Amps
208	On	On	On	Off	8.9
240	Off	On	On	Off	8.5
380/415	Off	Off	Off	Off	5.2
460	On	On	On	Off	4.5
575	On	On	Off	Off	3.4

## 10.0 MAINTENANCE INSPECTION CHECKLIST

### Liebert Mini-Mate2

Date: \_\_\_\_\_

Prepared By: \_\_\_\_\_

Model #: \_\_\_\_\_

Serial Number: \_\_\_\_\_



#### NOTE

*Reheat element sheaths and fins are manufactured with stainless steel. Regular inspections are necessary to assure proper cleanliness of the reheating element. Should inspection reveal corrosion particles on the reheating element or adjoining surfaces (including ducts and plenums), appropriate cleaning should be performed. Periodic reheating element replacement may be required to meet specific application requirements.*

#### Monthly

##### Filters

- \_\_\_ 1. Check for restricted airflow
- \_\_\_ 2. Check for filter
- \_\_\_ 3. Wipe section clean

##### Fan Section

- \_\_\_ 1. Impellers free of debris and move freely
- \_\_\_ 2. Bearings in good condition
- \_\_\_ 3. Check belt tension and condition

#### Semiannually

##### Compressor Section

- \_\_\_ 1. Signs of oil leaks
- \_\_\_ 2. Vibration isolation

##### Refrigeration Cycle

- \_\_\_ 1. Suction pressure
- \_\_\_ 2. Head pressure
- \_\_\_ 3. Superheat
- \_\_\_ 4. Evaporator coil clean
- \_\_\_ 5. Insulation intact

##### Air-Cooled Condensing Unit (if applicable)

- \_\_\_ 1. Condenser coil clean
- \_\_\_ 2. Motor mount tight
- \_\_\_ 3. Refrigerant lines properly supported

##### Humidifier

- \_\_\_ 1. Check canister for mineral deposits
- \_\_\_ 2. Check condition of electrodes
- \_\_\_ 3. All hoses and fittings tight
- \_\_\_ 4. Check water make-up valve for leaks

##### Drain lines

- \_\_\_ 1. Check for obstructions and sediment buildup.
- \_\_\_ 2. Check for damage and/or corrosion.
- \_\_\_ 3. Check for leaks

##### Flood Back Head Pressure Control

- \_\_\_ 1. Check refrigerant level

##### Water- or Glycol-Cooled Condensing Unit

- \_\_\_ 1. Water valve adjustment
- \_\_\_ 2. Water flow
- \_\_\_ 3. Water leaks

##### Glycol Pump (if applicable)

- \_\_\_ 1. Glycol leaks
- \_\_\_ 2. Pump operation
- \_\_\_ 3. Glycol solution
- \_\_\_ 4. pH level

##### Electric Panel

- \_\_\_ 1. Check electrical connections
- \_\_\_ 2. Operational sequence

##### Electric Reheat

- 1. Check element for corrosion

Signature: \_\_\_\_\_

Make photocopies of this form for your records

## 11.0 TROUBLESHOOTING

**Table 25 Troubleshooting**

Symptom	Possible Cause	Check Or Remedy
<b>Unit will not start</b>	No power to unit	Check voltage at input terminal block.
	Control voltage circuit breaker (at transformer) open	Locate short and reset circuit breaker.
	Float switch relay closed because of high water in the condensate pan	Has rubber band been removed from float switch? Check drain and line. Access through left panel. Power must be cycled at the disconnect to reset.
	Jumper not in place	Check terminal TB1-4 and TB1-5 for jumper or N/C contact. Check pins 1-8 and 1-9 for jumper or N/C high temperature sensor contact. Check pins 5-4 and 5-5 for jumper or N/C smoke sensor contact.
<b>No cooling</b>	<b>Cooling</b> not displayed at the control panel	Adjust TEMP control set point and sensitivity to require cooling.
	Short cycle prevention control	Control software delays compressor 3 minutes cooling, from stop to start
	Compressor contactor not pulling in	Check for 24 VAC $\pm$ 2 VAC at terminals P4-8 and P4-4. If voltage, check contactor. If no voltage at P4-8 and P4-4, check at terminals P2-3 and P2-8. If voltage, check freeze stat.
	Compressor high head pressure	See below for cause.
	Plugged filter/dryer	Replace filter/dryer
	Low refrigerant charge	Check pressure gauges. At low ambient temperatures, proper refrigerant charge is very important on units with Lee-Temp receivers.
<b>Compressor high head pressure</b>	Insufficient air flow across condenser coil	Remove debris from coil and air inlets.
	Water/Glycol Cooled only: No fluid flowing through condenser	Check fluid supply to regulating valve. Adjust valve if necessary.
	Condenser fan not operating	Check fan operation.
<b>Humidifier does not operate</b>	DIP switch not set to enable humidifier option	See DIP switch settings <b>Table 24</b> .
	"HUMIDIFY" not displayed at control panel	Increase humidity control set point and sensitivity to require humidification.
	Defective board	Check voltage at P3-1 and P1-9 on interface board for 24 VAC $\pm$ 2 VAC. If no voltage, check wiring and/or replace board. Check wiring from control panel to board.
	Failed humidity sensor	Humidity display will indicate dashes. Check wiring from temperature/humidity board to the control board and from the wall box to the control board. Replace wallbox or temperature/humidity circuit board (if remote).
	No water flow	Make sure switch is in Run position. Check humidifier water supply (including filter screen) and check nylon overflow line if canister is full.
	Canister fill rate is not keeping up with the steam output	Check fill valve screen opening and capillary tube for obstructions. Check water supply pressure (minimum 10 PSIG).
<b>Reheat will not operate</b>	DIP switch not set to enable reheat option	See DIP switch settings <b>Table 24</b> .
	<b>HEAT</b> not displayed at the control panel	Increase temperature set point to require heating.
	Reheat safety open, defective reheat contact or defective board	Check voltage at P2-1 and P1-9 on interface board for 24 VAC $\pm$ 2 VAC. If voltage, check reheat contactor and reheat safety. If no voltage, check wiring and/or replace board.
	Element is burned out	Turn off power. Check element continuity with an Ohmmeter.

**Table 25 Troubleshooting**

Symptom	Possible Cause	Check Or Remedy
<b>Cooling cycle too short</b>	Sensor response delay too short	Increase sensor response delay. See <b>6.11 - Calibrate Sensors</b> .
<b>Display freezes and control pads do not respond</b>	Static discharge	During period of low humidity, static electricity can cause the control program to freeze or display incorrect information. Although this is unlikely, the control can be reset by cycling power from the disconnect switch.
<b>Condensate pump does not operate</b>	Open or short circuit in wiring	Find open or short circuit and repair power to pump.
<b>Continuous Cooling</b>	Failed temperature sensor	Temperature display will indicate dashes. Check wiring from temperature/humidity board (remote sensors) to the control board or from control board to wallbox. Replace temperature/humidity circuit board (remote sensors) or wallbox.
<b>Continuous Heating Dehumidification Humidification</b>	Shorted wiring or failed control board	Check wiring and/or replace control board.
<b>Display Problem</b>	Incorrect wiring	Review <b>5.4.4 - Electrical Connections</b> . Verify VDC between 5 to 6 Volts at TB-3 Pin 1 (Ground) and TB-3 Pin 2 of the control board and wall box. If the transmit lines (TB-3 Pin 3 & 4) are not connected, only the POWER LED will be lit. It will flash once every 10-12 sec. If T- is connected, but not T+, TX1 will flash approximately every 2-3 sec. And the POWER LED will flash once every 10-12 sec. If T+ and T- are reversed, the POWER LED and RX1 Will be lit and flash every 10-12 sec. NOTE: Erratic operation of the unit could occur. If no LED is lit, there is no power or the +5VDC polarity is reversed. If any of these conditions occur, remove power from the evaporator using the disconnect switch, and correct wiring from the control board to the wall box. <b>NOTE:</b> It may take up to 20 seconds for the display to appear on the wall box LCD after power is applied.

# Ensuring The High Availability Of Mission-Critical Data And Applications.

Emerson Network Power, a business of Emerson (NYSE:EMR), is the global leader in enabling *Business-Critical Continuity™* from grid to chip for telecommunication networks, data centers, health care and industrial facilities. Emerson Network Power provides innovative solutions and expertise in areas including AC and DC power and precision cooling systems, embedded computing and power, integrated racks and enclosures, power switching and controls, infrastructure management, and connectivity. All solutions are supported globally by local Emerson Network Power service technicians. Liebert AC power, precision cooling and monitoring products and services from Emerson Network Power deliver Efficiency Without Compromise™ by helping customers optimize their data center infrastructure to reduce costs and deliver high availability.

While every precaution has been taken to ensure the accuracy and completeness of this literature, Liebert Corporation assumes no responsibility and disclaims all liability for damages resulting from use of this information or for any errors or omissions.

© 2009 Liebert Corporation

All rights reserved throughout the world. Specifications subject to change without notice.

® Liebert is a registered trademark of Liebert Corporation.

All names referred to are trademarks or registered trademarks of their respective owners.

SL-10532\_REV3\_02-13

## Technical Support / Service

### Web Site

[www.liebert.com](http://www.liebert.com)

### Monitoring

[liebert.monitoring@emerson.com](mailto:liebert.monitoring@emerson.com)

800-222-5877

Outside North America: +00800 1155 4499

### Single-Phase UPS & Server Cabinets

[liebert.upstech@emerson.com](mailto:liebert.upstech@emerson.com)

800-222-5877

Outside North America: +00800 1155 4499

### Three-Phase UPS & Power Systems

800-543-2378

Outside North America: 614-841-6598

### Environmental Systems

800-543-2778

Outside the United States: 614-888-0246

## Locations

### United States

1050 Dearborn Drive

P.O. Box 29186

Columbus, OH 43229

### Europe

Via Leonardo Da Vinci 8

Zona Industriale Tognana

35028 Piove Di Sacco (PD) Italy

+39 049 9719 111

Fax: +39 049 5841 257

### Asia

29/F, The Orient Square Building

F. Ortigas Jr. Road, Ortigas Center

Pasig City 1605

Philippines

+63 2 687 6615

Fax: +63 2 730 9572

## Emerson Network Power.

The global leader in enabling *Business-Critical Continuity™*

■ AC Power

■ Embedded Computing

■ Outside Plant

■ Racks & Integrated Cabinets

■ Connectivity

■ Embedded Power

■ Power Switching & Controls

■ Services

■ DC Power

■ Infrastructure Management & Monitoring

■ Precision Cooling

■ Surge Protection