

ProSYS / WaveSYS* QUICK START INSTRUCTIONS GUIDE

(For full comprehensive instructions refer to the ProSYS Installer Manual 5IN128IM)

www.rokonet.com

ISRAEL
Rokonet Electronics, Ltd.
14 Hachoma st. 75655
Rishon Letzion
Tel: +972-3-961-6555
Fax: +972-3-961-6584
e-mail: info@rokonet.co.il
www.rokonet.com

ITALY
Rokonet Electronics SRL
Tel: +39-02-392-5354
Fax: +39-02-392-5131
e-mail: info@rokonet.it

BRAZIL
Rokonet Brasil Ltda.
Tel: +55-21-2496.3544
Fax: +55-21-2496.3547
e-mail: rokonet-brasil@uol.com.br

USA
Rokonet Industries, Inc.
Tel: +1-305-592-3820
Fax: +1-305-592-3825
Toll Free: 1-800-344-2025
e-mail: sales@rokonetusa.com

UK
Rokonet U.K. Ltd.
Tel: +44-1527-576-765
Fax: +44-1527-576-816
Free Phone: 0800-269881
e-mail: info@rokonet.co.uk

* WaveSYS Installation & Programming Instructions in this document are equivalent to ProSYS 40.
5IN128IMQ



Introduction
ProSYS is a modular integrated system that combines access control, security protection, and home automation, with the advantage of controlling the whole system through one interface. ProSYS is available in three models that use the same accessories, but have different maximum capabilities (ProSYS 128, ProSYS 40, ProSYS 16). Through its 4-wire BUS, it can support a variety of optional modules, including multiple Keypads, Zone Expanders, a Wireless Interface, supplemental Power Supplies, a Voice module, capabilities for Access Control, an X-10 Interface, Event Log, and Utility Outputs. All these devices communicate with the system by sending commands and data over the BUS, which originates at the Main Panel.

We recommend reading and fully understanding the ProSYS Installation manual and User's manual before any installation of the system is carried out. The Quick Start instructions guide is intended for those who have experience in installing Rokonet security panels. For additional information refer to the ProSYS Installer Manual (p/n 5IN128IM).

STEP 1: Mounting the Main Panel

- Consideration in locating the fixing of the main panel should be given to:
 - Dry place near an AC power supply (switched off).
 - With a good earth connection.
 - With access to the customer's phone lines.
 - Access for the routing of cables for the system from detection devices.

STEP 2: Wiring the Main Panel


1. BUS Connection

A: Wiring External Modules

The set of four terminals on the left of the Main Panel represents the Expansion BUS. These support the connection of keypads and expansion modules. The connections are terminal-to-terminal with color-coded wires, as follows:

BUS Terminal	Description
AUX RED	+12V power
COM BLK	Black 0V common
BUS YEL	Yellow DATA
BUS GRN	Green DATA

The parallel wiring system supports parallel connections from any point along the wiring. The maximum wire run permitted is 300 meters (1000 feet) for all legs of the BUS. To prevent a possible drop in voltage due to multiple keypads and long wire runs, use a quality 4-conductor cable with an appropriate gauge size.



page 2

When connecting the Power Supply Module do **NOT** make any connection to the AUX (RED) terminal from the Main Panel. It is used for the outgoing BUS to supply voltage to other modules. The module supplies power to all modules and/or keypads located AFTER the point that it is connected to the BUS.

Notes:

In the ProSYS 16 and the ProSYS 40, there is only one BUS, which can be connected to the BUS 1 terminal block or to one of the two BUS 1 plugs (J1 and J5). In the ProSYS 128, there is also a BUS 2, which is separate from BUS 1. You can connect to the BUS 2 terminal block or to the BUS 2 plug (J6). In addition, if one of the BUSES is shorted or there is any kind of problem that interrupts the BUS data, the other one will continue to operate normally.

B: Defining Modules ID number


Each accessory has its ID category number, which is defined by dipswitches. ID numbers are defined per category and the first module in each category is defined as ID=1. Before setting power on, define each module's ID number by setting the dipswitches as follows:

ID	Dipswitches				Category	Modules ID Range		
	1	2	3	4		ProSYS 16	ProSYS 40	ProSYS 128
01	OFF	OFF	OFF	OFF	Zone Expanders (include wireless)	1	1-4	1-8
02	ON	OFF	OFF	OFF	Keypads	1-8	1-12	1-16
03	OFF	ON	OFF	OFF	Output Modules	1-2	1-4	1-8
04	ON	ON	OFF	OFF	Supervised Power Supply	1-8	1-8	1-8
05	OFF	OFF	ON	OFF	Access Control Modules	1-2	1-4	1-8
06	ON	OFF	ON	OFF	Memory Expansion	-	ID=1	ID=1
07	OFF	ON	ON	OFF			(512 events)	(512 or 999)
08	ON	ON	ON	OFF	Digital Key Readers	1-16	1-16	1-16
09	OFF	OFF	OFF	ON	Voice Module	1	1	1
10	ON	OFF	OFF	ON	Wireless Key Buttons	1	1-4	1-4
11	OFF	ON	OFF	ON				
12	ON	ON	OFF	ON				
13	OFF	OFF	ON	ON				
14	ON	OFF	ON	ON				
15	OFF	ON	ON	ON				
16	ON	ON	ON	ON				

2. Zone Inputs Connection

To connect a hardwired zone use a 4-conductor cable wiring. Connect each zone to the appropriate Zone (Z) terminal and its related COM terminal. Each pair of zones shares a COM terminal. It is recommended that you use an End-of-Line Resistor at the far end of each hardwired zone to prevent short-circuits (16 resistors are supplied). For a zone with a tamper switch, you can use a Double End-of-Line Resistor to save additional Main Panel connections.



Zone Terminations



page 3

3. Wiring Auxiliary Devices


The main panel has 2 aux terminals. Use the Auxiliary Power AUX (+) COM (-) terminals to power PIRs, glass-break detectors (4-wire types), smoke detectors, audio switches, photoelectric systems and/or any device that requires a 12V DC power supply. The total power from the AUX terminals should not exceed 600mA. If the auxiliary outputs are overloaded (exceed 600mA) and are shut down, you must disconnect all loads from the outputs for a period of at least 10 seconds before you reconnect any load to the auxiliary outputs.



page 4


4. Bell Sounder Wiring

The BELL/LS terminal determines the output for the bell or external sounder. When connecting the internal sounding device pay attention to the polarity. To avoid Bell Loop Trouble, if NO connection is made to an internal sounder, use a 2.2KΩ resistor in its place. It is important to position the BELL/LS Jumper (J3) correctly. The position varies depending on the type of internal sounder. A maximum of 900 mA may be drawn from this terminal.




5. Bell Tamper Wiring

Connect the bell tamper to the BELL TMP and COM terminals on the Main Panel, as illustrated.



6. Box Tamper Wiring

Connect the box tamper to the BOX TMP and COM terminals on the Main Panel, as illustrated.



page 5

7. Utility Output Wiring

UO1: Relay output (3 Amps). Usually used for an external siren connection. Use the J10 jumper located on the main board to determine the UO1 (behaviour) as follows:

Positive (POS): When the J10 connector is placed on POS, the C terminal on UO1 supplies 13.8V.


Negative (NEG): When the J10 connector is placed on NEG, the C terminal on UO1 supplies COM.

Single pin: If the J10 connector is placed only on 1 pin, the UO1 acts as a dry contact.

UO2-UO6: Transistor outputs (UO2 — 500 mA, UO3-UO6 70 mA). Connect the positive connection of the device to AUX (+) and the negative (-) connection to the UO's terminals.

8. Telephone Line Connection

Connect the incoming telephone line to the Main Panel's LINE terminals. Connect any telephone on the premises to the SET terminals.



page 6

9. Setting Jumpers

Use the following table to position the jumpers located on the ProSYS main board

Jumper	Jumper Description	Jumper Operation
J2	Default jumper	For regular operation position the default jumper over one of the J2 connector pins for safekeeping. To default the system position the jumper over the 2 pins (bell or loudspeaker).
J3	Bell/Loudspeaker	Set this jumper according to the type of siren connected to the system (bell or loudspeaker).
J4	SIG IN	Connect to the voice module p/n RP200VC
J6	Voice Connector	This connector transmits signals from the Advanced Digital Voice module to the telephone line during remote communication, and is essential for normal operation of the Digital Voice module.

J1, J5, J8 are used as quick BUS connectors. Use the 4 pin BUS plugs for easy connection of the BUS Adapter Cable (RP296EBA) or the Memory Transfer Card.

10. Ground Connection


Connect the metal box and the door of the metal box to main earth (ground).

Note: Connecting to ground must be performed according to the local National Electrical Code.

11. Main Power Connection

Connect the 230V AC to the mains fuse input terminal block (N.L.). Fasten the AC cord to the metal box using adjustable clamps.

Note: Be sure to connect the live wire of the AC power through the AC fuse. The size of the conductors must not be less than 0.75mm² (18AWG).



page 7

STEP 3: Installer Programming

The ProSYS can be programmed from local or remote Upload/Download software or from the LCD Keypad used as an interface tool. The following keys are used in the programming procedure. For additional information refer to the Installer manual.

Key	Programming Mode Function
*	Use this key to exit the current programming selection and move up to the next higher level in the programming hierarchy catalog.
Status	Press either one of these keys to move back and forth through the programming level functions. These keys also change the position of the flashing cursor. When editing a selection, the cursor moves to the left or right respectively.
By pass	Use this key to toggle forward through the programming choices within a selection.
St a y	Use this key to toggle backward through the programming choices within a selection.
A r m	Use this key to enter selected information into the system or to accept the current selection and access the lower level of options in the programming hierarchy.
# Disarm	

page 8

Initial Setting

1. When defaulting the panel (position J2 on both pins and then power on the system) you enter the installer Programming menu and the Auto Install feature (Automatic Module recognition). The first display will be:



2. After a short delay the following display appears:



3. Press [*]. The keypad prompts you for the Installer code.

- Enter the default Installer Code followed by [Disarm] depending on the ProSYS Model:
 - ProSYS 128:** [0][1][2][9]
 - ProSYS 40:** [0][1][4][0]
 - ProSYS 16:** [0][1][1][6]

5. The system enters the automatic accessories recognition process. Press [#Disarm] to acknowledge each module. 6. To exit Installer programming press "0" from the Installer's main menu. 7. Position the J2 default jumper on one pin to save data.

To access the Installer Programming Menu from the regular operation mode: (J2 is on one pin)

- From the regular (user) operation mode press: [-][7][1]
- The keypad prompts you for the Installer code.
- Enter the Installer Code followed by [Disarm] for accessing the Installer menu.

Reset to default modes

- Disconnect all power from the Main Panel.
- Position the J2 default jumper on both of the J2 pins.
- Reconnect the power to the main and backup battery to the Main Panel. The keypad sounds a long beep and all of the LEDs flash once. After 20 seconds the following message is displayed: "To Install Press *"
- On the Main Panel, reposition the J2 default jumper on one of the J2 pins (where it resides for safekeeping).
- Remember that the Installer Code has been restored to the manufacturer's default setting.

Note:

To enable the restore of the manufacturer's default, the system bit "Default Enable/Disable" (defined in quick key [1][7] in the main Installer menu) must be defined as Enable.

INSTALLER PROGRAMMING MENUS

[1]	SYSTEM			
Quick Key	Parameter	Default	Range	
[1][1]	System: Time Define			
[1][1][1]	Exit Entry Delay 1			
[1][1][1][1]	Entry Delay 1	30	0-255 sec	
[1][1][1][2]	Exit Delay 1	45	0-255 sec	
[1][1][2]	Exit Entry Delay 2			
[1][1][2][1]	Entry Delay 2	45	0-255 sec	
[1][1][2][2]	Exit Delay 2	60	0-255 sec	
[1][1][3]	Bell Time Out	04	01-90 min	
[1][1][4]	Bell Delay	00	00-90 min	
[1][1][5]	Switched Auxiliary Break	10	01-90 sec	
[1][1][6]	Wireless Module Times			
[1][1][6][1]	Jamming Time	None	None, 10,20,30 sec	
[1][1][6][2]	Supervisory (S.V) Time	0		
[1][1][7]	Zone Test Times			
[1][1][7][1]	Start Test	HR:00:MIN:00	00-24 Hours, 00-59 Min	
[1][1][7][2]	Zone Test Period	00	00-24 Hours	
[1][1][8]	AC Off Delay	30	0-255 Min	
[1][1][9]	More Times			
[1][1][9][1]	Phone Line Cut Delay	04	01-20 Min	
[1][1][9][2]	Guard Delay	30	01-99 Min	
[1][2]	System: System Control			
[1][2][01..34]	Parameter	Default	Parameter	Default
01) Quick Arm	YES	13) Alarm Zone	NO	25) Engineer Tamper
		Expander Cut		
02) Quick UO	YES	14) Fire Temporal Alarm	NO	26) Blank Display
03) Allow Bypass	YES	15) Grand Master Code	NO	27) 24 Hour Bypass
04) Quick Bypass	NO	16) Audible Jamming	NO	28) IMQ Install
05) False Code	NO	17) Technical Tamper	NO	29) Grand Master
		Authority/Partition		YES
06) Bell Squawk	YES	18) Technical Reset	NO	30) Double Code
07) Bell 30/10	NO	19) Abort Alarm	NO	31) Disarm Stop
		Follow Me		YES
08) Alarm Phone Cut	NO	20) Summer/Winter Clock	NO	32) Global Follower
09) 3 Minutes Bypass	YES	21) Forced Keyswitch Arming	YES	33) Area
10) Double Verification	NO	22) Pager	NO	34) Disable Keypad when
		Fire Alarm		Auto Disarm exist
11) Audible Panic	NO	23) Arm Pre Warning	YES	
12) Buzzer+Bell	NO	24) Low Battery Arm	YES	
[1][3]	System: Set Clock			
[1][3][1]	System Date	JAN 01 2000 (SAT)	DD MM YYYY (DAY)	
[1][3][2]	System Time	00:00	HH:MM	
[1][4]	System: Windowing			
[1][4][1]	Window Start	HR:00:MIN:00	00-24 Hours, 00-59 Min	
[1][4][2]	Window Stop	HR:00:MIN:00	00-24 Hours, 00-59 Min	
[1][4][3]	Window Days	All	SUN(Y/N)-SAT(Y/N)	
[1][5]	System: Labels			
[1][5][0]	Global	Rokonet	12 Characters	
[1][5][1..8]	Partition 1 — Partition 8	Partition 1 — Partition 8	12 Characters	
[1][6]	System: Tamper Sound			
		Bell/Arm Buzzer/Disarm	1) Silent 2) Bell Only	
			3) Buzzer Only 4) Bell +Buzzer	
			5) Bell/Arm 6) Buzzer/Disarm	
[1][7]	System: Default Enable			
[1][8]	System: Service Information			
[1][8][1]	Service Name	ProSYS Security	16 Characters	
[1][8][2]	Service Phone	System	16 Characters	
[1][9]	System: System Version			

[2]	ZONES			
Quick Key	Parameter	Options		
[2][1]	Zones: One By One			
[2][2]	Zones: Partitions			
[2][3]	Zones: Zone Type			
	[2][3][ZZ] + [DISARM] +[00-22]	00) Not Used	09) Interior + Entry Follower	18) Exit Termination
		01) Exit Entry 1	10) Interior + Instant	19) Latched Keyswitch
		02) Exit Entry 2	11) Utility Output Trigger	20) Entry Follower + Stay
		03) Exit (Open)/Entry	12) Day Zone	21) Latched Delay
		04) Entry Follower	13) 24 Hours	22) Latched Keyswitch
		05) Instant	14) Fire	Delay
		06) Interior + Exit Entry 1	15) Panic	
		07) Interior + Exit Entry 2	16) Special Emergency	
		08) Interior + Exit (Open)/Entry	17) Pulsed Keyswitch	
[2][4]	Zones: Zone Sound			
	[2][4][ZZ] + [DISARM] +[1-6]	1) Silent	4) Bell + Buzzer	
		2) Bell Only	5) Door Chime	
		3) Buzzer Only	6) Bell/Arm Buzzer/Disarm	
[2][5]	Zones: Zone Termination			
	[2][5][ZZ] + [DISARM] +[1-4]	1) Normally Close	3) Double End Of Line	
		2) End Of Line	4) Normally Open	
[2][6]	Zones: Loop Response			
	[2][6][ZZ] + [DISARM] +[1-12]	1) Normal (400 ms)	05) 0.5 Hour	09) 2.5 Hours
		2) Slow (1 sec)	06) 1 Hour	10) 3 Hours
		3) Fast (10 ms)	07) 1.5 Hours	11) 3.5 Hours
		4) Very Fast (1 ms)	08) 2 Hours	12) 4 Hours
		Note:		
		1.The loop response 1 ms (option 4) is usually used for shutters or other devices that require very quick responses. This loop response time can be defined only for zones located on the zone expander RP128EZ8F00A.		
		2.The loop response times defined in locations 5 to 12 can be assigned only to zones 1 to 8 on the Main Panel or to zones located on the zone expander RP128EZ8F00A.		
[2][7]	Zones: Cross Zones			
		1) None		
		2) Ordered		
		3) Not Ordered		
[2][8]	Zones: Zone Labels			
[2][9]	Zones: Maintenance			
[2][9][1]	Copy to a Zone			
[2][9][2]	Delete a Zone			
[2][9][3]	Add/Copy Partition			
[2][9][4]	Delete a Partition			
[2][9][5]	Wireless Module Calibration			
[2][9][6]	Wireless Zone Allocation			
[2][9][7]	Wireless Communication Test			
[2][9][8]	Zone Self Test			
[2][9][9]	Soak Test			
[2][0]	Zones: Miscellaneous			
[2][0][1]	Forced Arming			
[2][0][2]	Pulsed Count			

[3]	UTILITY OUTPUT			
Quick Key	Parameter	Options		
[3][0]	Utility Output: Follow Nothing			
[3][1]	Utility Output: Follow System Event			
		01) Bell Follow	08) Sensors Test	
		02) No Telephone Line	09) Voice Module	
		03) Communication Failure	10) Battery Test	
		04) Trouble Follow	11) Bell Burglary	
		05) Ground Pulse	12) Scheduler	
		06) Low Battery	13) Digital Reader Communication	
		07) Ac Loss Follow	14) Switched Auxiliary	
[3][2]	Utility Output: Follow Partition Event			
		01) Ready Follow	08) Dures Follow	15) Stay Follow
		02) Alarm follow	09) Buzzer Follow	16) Tamper Follow
		03) Arm Follow	10) Chime Follow	17) Disarm Follow
		04) Burglary Follow	11) Exit/Entry Follow	18) Bell Follow
		05) Fire Follow	12) Fire Trouble	19) Bell Stay Off
		06) Panic Follow	13) Day zone Trouble	20) Zone Bypass
		07) Special Emergency Follow	14) General Trouble	
[3][3]	Utility Output: Follow Zone			
		01) Zone Follow	03) Arm Follow	
		02) Alarm Follow	04) Disarm Follow	
		Note: Each utility output can be activated by a group of up to five zones.		
[3][4]	Utility Output: Follow Code			

[4]	CODE			
Quick Key	Parameter	Options		
[4][1]	Code Maintenance: Authority Level			
		Grand Master	Arm Only	User Unbypass
		Manager	Cleaner	Guard
		User	Utility Output Activation	
[4][2]	Code Maintenance: Partition			
[4][3]	Code Maintenance: Grand Master			
[4][4]	Code Maintenance: Installer			
[4][5]	Code Maintenance: Sub Installer			
[4][6]	Code Maintenance: Code Length			
		1) 4 Digits		
		2) 6 Digits		

[5]	DIALER			
Quick Key	Parameter	Default	Range	
[5][1]	Dialer: Telephone Numbers			
[5][1][1]	MS Phone 1		32 characters	
[5][1][2]	MS Phone 2			
[5][1][3]	MS Phone 3			
[5][1][4]	Remote Upload/Download Phone			
[5][2]	Dialer: Customer Account Number			
[5][3]	Dialer: Communication Format			
[5][3][1]	Format for MS Phone 1			
[5][3][2]	Format for MS Phone 2			
[5][3][3]	Format for MS Phone 3			

[5][4]	Dialer: Access and ID			
Quick Key	Parameter	Default	Range	
[5][4][1]	Access Code	5678		
[5][4][2]	ID Code	0001		
[5][4][3]	MS Lock	000000		
[5][5]	Dialer: Controls			
[5][5][01..14]	Parameter	Default	Parameter	Default
01) MS Enable	YES	08) Call Back Upload/Download	YES	
02) Follow Me Enable	YES	09) Auto Batch	NO	
03) Upload/Download Enable	YES	10) Answering Machine Override	YES	
04) Call Delay	NO	11) UL Installation	NO	
05) Dial Tone Wait	YES	12) Show Kiss Off	NO	
06) Call Save	No	13) Show Handshake	NO	
07) User Initiated Call	YES	14) Audible KISSOFF	NO	
[5][6]	Dialer: Parameters			
[5][6][1]	Monitoring Station Retries	08	01-15	
[5][6][2]	Follow Me Retries	03	01-15	
[5][6][3]	Ring to Upload/Download	12	01-15	
[5][6][4]	Dial Tone Time	6	1) 6 seconds	
			2) 9 seconds	
[5][6][5]	Redial Wait	30	1) 30 sec	
			2) 60 sec	
[5][6][6]	Dialing Method	DTMF	1) DTMF	
			2) Pulse @ 20 BPS	
			3) Pulse @ 10 BPS	
[5][6][7]	Pulse Duty Cycle	61/39	1) 67/33	
			2) 61/39	
[5][6][8]	Swinger Shutdown Limit	00	00-15	
[5][7]	Dialer: Report Split			
[5][7][1]	Monitoring Station Arm/Disarm	1 st Backup 2 nd	1) Do not call	
			2) Call 1 st	
			3) Call 2 nd	
			4) Call 3 rd	
			5) Call All	
			6) 1 st Backup 2 nd	
[5][7][2]	Monitoring Station Urgent	1 st Backup 2 nd	1) Do not call	
			2) Call 1 st	
			3) Call 2 nd	
			4) Call 3 rd	
			5) Call All	
			6) 1 st Backup 2 nd	
[5][7][3]	Monitoring Station Non Urgent	1 st Backup 2 nd	1) Do not call	
			2) Call 1 st	
			3) Call 2 nd	
			4) Call 3 rd	
			5) Call All	
			6) 1 st Backup 2 nd	
[5][7][4]	Follow Me			
[5][7][4][1..8][1]	Phone Partition			
[5][7][4][1..8][2]	Phone Event			
	Event	Default	Event	Default
	01) Intruder	YES	10) Disarm	NO
	02) Fire	YES	11) Bypass	NO
	03) Emergency	YES	12) Wireless lost	NO
	04) Panic	YES	13) Wireless Low Battery	NO
	05) Tamper	NO	14) Bell Trouble	NO
	06) Remote Programming	NO	15) False Code	NO
	07) AC Off	NO	16) Low Battery	NO
	08) Dures	YES	17) Wireless Jamming	NO
	09) Arm	NO	18) BUS Trouble	NO

[5][7][4][1..8][3]	Phone Restore Events			
Event	Default	Event	Default	
01) Intruder	YES	06) Bell Trouble	NO	
02) Tamper	NO	07) Low Battery	NO	
03) AC Off	NO	08) Wireless Jamming	NO	
04) Wireless lost	NO	09) BUS Trouble	NO	
05) Wireless Low Battery	NO			
[5][8]	Dialer: Alarm Restore			
[5][8][1..3]	Alarm Restore	On Bell Time out	1) On Bell Time put	
			2) Follow Zone	
			3) At Disarm	
[5][9]	Dialer: Periodic test			
[5][9][1]	Monitoring Station Test			
[5][9][2]	Upload Download Test			
[5][0]	Dialer: Auto Codes			
[5][0][1]	Contact ID			
[5][0][2]	SIA			
[5][0][3]	Delete All			

[6]	REPORT CODES			
Quick Key	Parameter	Options		
[6][1]	Report Codes: Emergency Key			
[6][1][1][1..4]	Emergency Key Alarm	1) Auxiliary Emergency	3) Fire	
		2) Panic	4) Dures	
[6][1][2][1..4]	Emergency Key Alarm Restore	1) Auxiliary Emergency	3) Fire	
		2) Panic	4) Dures	
[6][2][1..9]	Report Codes: Zones			
		1) Alarm	5) Bypass	
		2) Alarm Restore	6) Zone Tamper	
		3) Day zone Trouble/ Wireless	7) Zone Tamper Restore	
		4) Zone Supervision	8) Low Battery	
		5) Day zone Trouble/ Wireless	9) Low Battery Restore	
		6) Zone Supervision Restore		
[6][3][1..7]	Report Codes: Accessory Tamper			
		1) Keypad	5) Wireless Button Accessory	
		2) Utility Output	6) Wireless Zone Module	
		3) Power Supply	7) Advanced Voice Module	
		4) Event Logger		
[6][4]	Report Codes: Main Trouble			
[6][4][1][1..0]	Main Trouble	1) Low Battery	6) Clock Not Set	
		2) Bell	7) BUS Fail	
		3) Phone	8) False Code	
		4) AC Loss	9) Bell Tamper	
		5) Aux Fail	0) Box Tamper	
[6][4][2][1..0]	Main Trouble Restore	1) Low Battery	6) Clock Not Set	
		2) Bell	7) BUS Fail	
		3) Phone	8) False Code	
		4) AC Loss	9) Bell Tamper	
		5) Aux Fail	0) Box Tamper	
[6][5]	Report Codes: Power Supply Module Trouble			
[6][5][1][1..4]	Trouble Condition	1) Low Battery	3) AC Loss	
		2) Bell	4) AUX Fail	
[6][5][2][1..4]	Trouble Condition Restore	1) Low Battery	3) AC Loss	
		2) Bell	4) AUX Fail	
[6][6]				