


User manual

Hoof trimming crush

SA0095/SA0096



Manufacturer:

Wopa Constructiebedrijf BV
Rector Hulshofstraat 10
7135 JV Harreveld
The Netherlands

☎: +31-(0)544 372415
💻: +31-(0)544 372445
Email: info@wopa.com
Website: www.wopa.com

© Copyright 2014

No part of this publication may be reproduced, stored in a search system or transferred in any form whatsoever, either electronically or mechanically, or by photocopying or recording, or in any other way whatsoever without prior written consent from Wopa Constructiebedrijf BV (hereinafter in this manual also referred to as "Wopa").

Introduction

Wopa Constructiebedrijf BV specialises in development and manufacture of hoof trimming and treatment crushes for cows and bulls for professional users as well as for cattle farmers.

Our crushes are developed and manufactured in the highest possible quality, according to the strictest requirements as far as safety, user convenience, animal welfare and hygiene are concerned, always striving for an optimum.

This manual contains information and instructions relevant to installation, operation and maintenance of the machine.



- The machine is not suitable for use in explosive hazardous environments.
- All persons responsible for operation must, at minimum, read and comprehend the sections on operation and safety of these operating instructions.
- All persons responsible for assembly, installation, maintenance and/or repair must read and comprehend all these operating instructions.
- The user is responsible for interpretation and use of this manual under all conditions. Should you have any doubts or questions regarding the correct interpretation, please contact the owner or the supervisor.
- Keep this manual nearby the installation and within the users' reach.
- Keep a log of all major maintenance work, adaptations to the installations and observations, see Annex 8.1.
- Changes to the installation/machine are not permitted without prior written approval from the supplier.
- Contact the supplier for any special maintenance work not included in this manual.
- Comply with the safety requirements as given in Section 3 at all times.
- Proper functioning as well as the safety of the system can only be guaranteed if the recommended maintenance is carried out correctly and on time.

Warranty

The warranty is subject to the following limitations. The warranty period for products supplied by Wopa is 12 months from the date on the purchasing document. The warranty is limited to production and material errors and therefore does not cover any breakdowns due to a part of the product exposed to any type of wear. Normal wear as can be expected from using this product is therefore excluded.

1. Wopa's responsibility remains limited to replacing defective parts; we recognise no claims to any other type of loss or costs.
2. The warranty is automatically void in case of overdue or poorly implemented maintenance.
3. Should you have any doubts regarding maintenance work or should the machine fail to operate correctly, contact the supplier.
4. The warranty does not apply if the defect is the result of incorrect or negligent use or of maintenance carried out contrary to the instructions in this manual.
5. The warranty is void if any repairs or adaptations are made to the product by third parties.
6. Defects ensuing from damage or accidents caused by external factors are excluded from the warranty.
7. If we replace any parts in accordance with the obligations ensuing from this warranty, the parts we replaced become our property.

Table of Contents

INTRODUCTION.....	3
WARRANTY	4
TABLE OF CONTENTS	5
EC CONFORMITY DECLARATION (COPY).....	6
OVERVIEW OF SYMBOLS.....	7
PICTOGRAMS.....	8
1. TECHNICAL INFORMATION.....	9
2. DESCRIPTION OF THE INSTALLATION.....	10
2.1. DESCRIPTION OF THE MAIN COMPONENTS SA0095/SA0096.....	10
2.2. ELECTRICAL INSTALLATION.....	12
3. SAFETY	13
3.1. GENERAL	13
3.2. DURING NORMAL USE	14
3.3. OPERATING PERSONNEL	14
4. INSTALLATION	15
4.1. LOCATION	15
4.2. CONNECT THE MACHINE.....	16
4.3. PREPARING FOR TRANSPORTATION.....	16
5. OPERATION.....	17
5.1. STARTING UP.....	17
5.2. EMERGENCY STOP.....	17
5.3. PRODUCTION.....	18
5.4. HOOK UP THE FRONT LEG.....	19
6. MAINTENANCE.....	20
6.1. MAINTENANCE DIAGRAM	20
6.2. CLEAN THE MACHINE.	21
6.3. LUBRICATION OF REAR GATE	21
6.4. CHECK PLAY IN THE WHEELS.	22
6.5. PARTS	22
7. DISPOSAL AS WASTE.....	23
8. APPENDIX.....	24
8.1. LOGBOOK.....	24

LIJST MET AFBEELDINGEN

FIGURE 1: OVERVIEW SA0095/SA0096.....	10
FIGURE 2: OVERVIEW OF THE ELECTRICAL INSTALLATION (THE TYPE OF HOOF TRIMMING CRUSH IN THE PHOTO MAY DIFFER FROM YOUR INSTALLATION).	12
FIGURE 3: DETAILS OF CONVERSION FROM TRANSPORT SET-UP TO WORKING SET-UP (SA0095)	15
FIGURE 4: DETAIL OF HOOKING UP FRONT LEG	19
FIGURE 5: LUBRICATION OF REAR GATE.....	21

EC conformity declaration (copy)

We,

Wopa Constructiebedrijf BV
Rector Hulshofstraat 10
7135 JV Harreveld
The Netherlands

☎: +31-(0)544 372415
✉: +31-(0)544 372445
Email: info@wopa.com
Website: www.wopa.com

declare, entirely under our own responsibility, that the product:

machine : Hoof trimmingcrush
type: SA0095/SA0096

to which this declaration pertains, is consistent with the stipulations in Directives:

2006/42/EC (Machine Directive)
2004/108/EC (EMC Directive)

the following standards were taken into account:

NEN-EN-ISO 12100	Safety of machinery. Basic definitions, general design principles.
NEN-EN 349	Safety of machinery – Minimum gaps to avoid crushing of parts of the human body.
NEN-EN ISO 13849-1	Safety of machinery – Parts of the control systems with a safety function – Section 1: General design principles
NEN-EN 60204-1	Safety of machinery – Electrical equipment of machines Section 1: General requirements





The undersigned is authorised to compile the Technical Dossier:

The Netherlands - Harreveld, September 2014

J.W.A. Wopereis
Managing Director






Overview of symbols

The following symbols are used for all actions that jeopardise the safety of the user and/or technician and require caution.

	Attention!
	Hazard: High voltage!
	Hazard: High temperature!
	Tip: Offers quick insight or tips to carry out certain actions more easily and simply.

Pictograms

A number of pictograms and alerts are affixed to the installation to indicate possible risks to users, among other things.


Pictogram	Description	Location
	<ul style="list-style-type: none"> Type plate 	<ul style="list-style-type: none"> On the machine frame
	<ul style="list-style-type: none"> Read the user manual Wear safety goggles when operating machine Wear hearing protection when operating machine. 	<ul style="list-style-type: none"> On the machine frame
	<ul style="list-style-type: none"> Warning pictograms for mechanical and electrical hazards 	<ul style="list-style-type: none"> On the machine frame
	<ul style="list-style-type: none"> Crushing hazard 	<ul style="list-style-type: none"> By the rear gate, if present.
	<p>ATTENTION!</p> <ul style="list-style-type: none"> Check regularly whether the pictograms and signs are still clearly recognisable and legible. Replace if this is no longer the case. 	

1. Technical information


	SA0095	SA0096	
General			
Ambient temperature during operation	- 5 to 40	- 5 to 40	°C
Noise production	< 70	< 70	dB(A)
Machine dimensions			
Length	2450	2450	mm
Width	1900	1722	mm
Height	2220	2220	mm
Weight	600	440	kg
Maximum product dimensions			
Length	3626	2450	mm
Width	1900	1720	mm
Height	2476	2220	mm
Weight	750	590	kg
Electrical connection (optional)			
Power supply	1 phase/ AC	1 phase/ AC	-
National voltage	230	230	V
Required fuse	5.5	5.5	A
Connected value	0.66	0.66	kVA
Data for road transport			
axial load	750	-	kg
Maximum drawbar load	100	-	kg
coupling	ISO 55 mm	-	-
connection plug	7 or 13	-	pole

* see electrical diagram

2. Description of the installation

	<p style="text-align: center;">FUNCTION</p> <ul style="list-style-type: none"> • This section gives an overview of the most important components and functions. If detailed information is available elsewhere in the manual, you are referred to the specific sections. • The design of your crush may differ from the figures below.
---	---

2.1. Description of the main components SA0095/SA0096

	<p style="text-align: center;">FUNCTION</p> <ul style="list-style-type: none"> • The SA0095 and SA0096 were developed especially for bull hoof trimming. • Version SA0095 is equipped with an axle with a draw bar and is suitable for transport on public roads.
---	--

The main components of the crush are shown in the illustration below:
The backbar and a motor as extra options are also shown.





Figure 1: Overview SA0095/SA0096

Main components SA0095/SA0096:

Figure 1	Component	Description	See Section
1	Front gate operating lever	<ul style="list-style-type: none"> The front gate is opened or closed by turning the lever. Open counter-clockwise, close clockwise. 	
2	Manual hind leg winch	<ul style="list-style-type: none"> After the belt is attached round the hind leg, the leg can be lifted with the hydraulic winch so the hoof can be treated. As an option, this operation can be done with an electric motor. 	-
3	Transport set (light bar) (SA0095)	<ul style="list-style-type: none"> A light bar with a license plate is attached to the crush for transport on public roads 	
4	Rump chain	<ul style="list-style-type: none"> After the bull is moved into the crush, the rump chain is stretched tightly behind the animal and attached. A rear gate can be mounted as an option. 	-
5	Transport set (axle) (SA0095)	<ul style="list-style-type: none"> An axle with mudguards is attached to the crush for transport on public roads. 	
6	Transport set (manual winch) (SA0095)	<ul style="list-style-type: none"> The crush can be lifted out of and into the transport position with the manual winch. 	
7	Manual belly strap winch	<ul style="list-style-type: none"> Once the bull is moved into the crush, the belly strap is attached behind the front legs. The belly strap can be lifted using the manual hoist. As an option, this operation can be done with an electric motor. 	
8	Front gate	<ul style="list-style-type: none"> The front gate can be set to 3 positions using the operating rope: Entirely open: the bull can exit the crush at the front. Partially open: the bull can move its head through the front gate but not its shoulders. Stationary position. Closed: the front gate is closed behind the animal's head. 	-
9	Front leg support	<ul style="list-style-type: none"> The bull's front leg can be secured to the front leg support with a rope and hook so the leg is secured and can be treated. Another option is to equip the crush with a front leg support with electric winch. 	5.4
10	Transport set (draw bar arm) (SA0095)	<ul style="list-style-type: none"> A draw bar arm is attached to the crush for transport on public roads. 	

2.2. Electrical installation

	<p style="text-align: center;">FUNCTION</p> <ul style="list-style-type: none"> • The electrical installation provides power to the electric winches and the sockets (as an option). • See the electrical diagram in the switch box on the crush for the rest of the structure and controls of the electrical installation included in the delivery. • The placement of the control components on your installation may differ from the photo below.
---	---

	<p style="text-align: center;">ATTENTION!</p> <ul style="list-style-type: none"> • Work on the electrical installation can only be carried out by a technical expert.
---	---






Figure 2: Overview of the electrical installation (the type of hoof trimming crush in the photo may differ from your installation).

The installation consists of the following components

Figure 2	Component	Description	Section / location
1	Power supply cable with plug	<ul style="list-style-type: none"> • To connect the machine to the power supply. 	
2	Emergency stop	<ul style="list-style-type: none"> • The emergency stop switches off all operations. 	
3	Relay box	<ul style="list-style-type: none"> • A relay box is installed for each drive. It contains the control components of the relevant drive. 	
4	Control buttons	<ul style="list-style-type: none"> • Each drive has 1 or 2 control panels to operate the following functions, depending on the version and/or the options available. <ul style="list-style-type: none"> ○ Front legs up/down ○ Belly strap up/down ○ Hind legs up/down ○ Front legs and hind legs up/down 	

3. Safety

3.1. General

	<ul style="list-style-type: none"> • The guarantee will lapse and no liability will be accepted in the event of damage caused by repairs and/or modifications not authorised by the supplier. • In the event of faults please contact the supplier. • The working area around the installation must be safe. The owner of the installation must take the necessary precautionary measures in order to operate the installation safely. • Starting up the installation in an area with a risk of explosion is prohibited. • The installation has been so designed that production is safe under normal ambient conditions. • The owner of the installation must ensure that the instructions in this manual are followed in practice. • The safety features provided must not be removed. • Correct operation and safety of the system can only be guaranteed where maintenance is carried out correctly and in good time, as prescribed. • Where work is to be carried out on the installation it must be disconnected from the power supply, the power supply must be locked off and the system must be depressurised. • There is a risk of trapping when operating driven moving parts. It is the operator's responsibility to ensure that the installation is only started up when no parts of his own or other people's bodies are in the vicinity of the trapping zone.
	<ul style="list-style-type: none"> • Only authorised persons appointed by the owner may carry out work on the electrical installation. • Ensure by means of internal procedures and supervision that all applicable power supplies have been switched off. • The installation must not be used during cleaning, inspection, repairs or maintenance, and must be disconnected from the electrical supply by means of the plug and/or the main switch. • Welding work must not be carried out on the installation unless the cable connection to the electrical components has first been disconnected. • The power supply to the control cabinet must not be used for the connection of machinery other than the hand tools provided for.

3.2. During normal use




- Check before commencing operations that no work is being carried out on the installation and that it is ready for use.
- Unauthorised persons must not enter the operational area of the installation. It is the operator's task to check this.

3.3. Operating personnel




- Operating personnel must be aged 18 or above.
- Only authorised persons may carry out work with or on the installation.
- Only work for which proper training has been received must be carried out. This applies both to maintenance activities and normal use.
- The operating personnel must be familiar with all potential situations, so that rapid and effective action can be taken in an emergency.
- Where a member of operational staff observes defects or risks or is not in agreement with the safety measures, this must be reported to the owner or the manager.
- Safety footwear is mandatory.
- Suitable work clothing is mandatory.
- All employees must observe the safety instructions to avoid presenting a risk to themselves and others. Comply strictly with the operating instructions at all times.

4. Installation

	<p style="text-align: center;">EXPLANATION</p> <ul style="list-style-type: none"> Consult the technical data and the circuit diagram provided for the correct specifications.
---	--

4.1. Location

	<p style="text-align: center;">CAUTION</p> <ul style="list-style-type: none"> The machine must be transported and installed upright. Place the machine on a level and stable substrate Take account of the instructions in Section 3 when carrying out any activity. Failure to follow these may lead to serious injury.
---	---





Figure 3: details of conversion from transport set-up to working set-up (SA0095)


No.	What to do	Action	Result
1.	Remove the locking pin.	<ul style="list-style-type: none"> Lift pin (Figure 3:1) and withdraw it to the side. 	
2.	Raise the nose wheel.	<ul style="list-style-type: none"> Raise the nose wheel so that the crush rests on the point of the drawbar. 	
3.	Remove the mudguards.	<ul style="list-style-type: none"> Loosen the locking elements (Figure 3:3) and lift the mudguard out of the adapter. 	

4.	Allow the crush to sink.	<ul style="list-style-type: none"> Take the tension off the locking pin (Figure 3:10) by bringing the hand winch (Figure 3:4) up to tension. Remove the locking pin (Figure 3:10). Turn the winch until the weight is off the wheels and there is no longer any tension on the lever (Figure 3:5). Remove the locking pin (Figure 3:6) from the lever. Place the lever (Figure 3:5) in the storage position (Figure 3:7) and secure with the locking pin. Rotate the winch again until the cable is under tension. 	
5.	Open the front gate.	<ul style="list-style-type: none"> Turn the handle (Figure 1:1) until the front gate is fully opened. 	
6.	Unlock the drawbar.	<ul style="list-style-type: none"> Rotate the locking knob (Figure 3:2) and unlock the clamp situated in the middle of the drawbar, then slide the nose wheel of the crush off until the drawbar comes free from the crush. 	
7.	Remove the drawbar from the crush.	<ul style="list-style-type: none"> Disconnect the drawbar ball mounting and remove the drawbar from the crush. 	
8.	Remove the lighting board.	<ul style="list-style-type: none"> Remove the lighting board from the crush. 	


4.2. Connect the machine.

	<p style="text-align: center;">CAUTION</p> <ul style="list-style-type: none"> Check that the voltage specified on the machine plate matches the mains supply. The machine must always be connected to an earthed socket to avoid the risk of fire or electric shocks (the earth connection is coded green/yellow). The electrical installation including the sockets must be connected in accordance with local regulations. The power cable must always be free and nothing must be placed on top of it. Replace the power cable immediately if it is damaged.
---	---

4.3. Preparing for transportation.

	<p style="text-align: center;">CAUTION</p> <ul style="list-style-type: none"> Preparing for transportation is the reverse procedure to making ready for use (see 4.1). With crushes equipped with an axle and drawbar it is essential that all locking mechanisms are correctly installed.
---	---


5. Operation

	<p style="text-align: center;">CAUTION</p> <ul style="list-style-type: none"> Take account of the instructions in Section 3 when carrying out any activity. Failure to follow these instructions may lead to serious injury.
---	--

5.1. Starting up

No.	What to do	Action	Result
1.	Switch on the power.	<ul style="list-style-type: none"> Insert the plug in the socket. 	
2.	Reset the emergency stop.	<ul style="list-style-type: none"> Pull out the emergency stop buttons. 	The control unit is now ready for use.


5.2. Emergency stop.

	<p style="text-align: center;">CAUTION</p> <ul style="list-style-type: none"> The emergency stop button must always be pressed in in the event of an emergency. All motions will cease following operation of the emergency stop button. In order to take the machine back into use after an emergency stop the emergency stop button must first be reset. Before resetting the emergency stop button it must be ensured that restarting the moving parts of the machine will not lead to a hazardous situation.
---	---

- Reset the emergency stop**

No.	What to do	Action	Result
1.	Reset the emergency stop button.	<ul style="list-style-type: none"> Reset the emergency stop button by pulling it out or rotating it (depending on the type installed) so that it returns to its original position. 	The machine is now ready for use.

5.3. Production

No.	What to do	Action	Result
1.	Check that the crush is ready for use.	<ul style="list-style-type: none"> See Section 5.1. 	
2.	Place the front gate ready.	<ul style="list-style-type: none"> Open the front gate so that the head of the animal can pass through but not its withers. 	
3.	Place the cow in the crush.	<ul style="list-style-type: none"> Lead the cow into the crush until its head has passed through the front gate. Close the front gate. 	
4.	Attach the rump chain or rear gate.	<ul style="list-style-type: none"> Tighten the rump chain around the animal and secure it. (SA0018/SA0022) Lower the rear gate and secure it with the chain (SA0026). In order to avoid the risk of damage to the rear leg, ensure that the rear gate is pressed up tightly against the animal. 	
5.	Apply the belly belt	<ul style="list-style-type: none"> Place the belly belt under the belly behind the front legs and tighten it. Where the (optional) electrical drive to the belly belt is present, the belt remains connected and is raised from the floor until it comes up under the belly. 	
6.	Process a rear hoof.	<ul style="list-style-type: none"> Place the belt around the rear leg and raise the leg. Process the rear hoof. Allow the leg to drop and release it. 	
7.	Process a front hoof.	<ul style="list-style-type: none"> Pass the long, soft rope around the front leg below the dew claw and pull the leg up to the block. Wrap it around a couple of times and fasten the end to the hook on the side of the support. Where the front leg support is provided with a winch the front leg is hooked on as shown in 5.4. Turn the winch until the leg is fixed to the block, then run the short tension rope past the knee of the front leg and fasten it to the side of the front leg support using the hook. Process the front hoof. Release the short tension rope. Pull the pin on the side winch towards the hand grip with the index finger to release the rope. Unhook the rope. 	See 5.4

No.	What to do	Action	Result
8.	Loosen the belly belt.	<ul style="list-style-type: none"> Reverse the winch and loosen the belt, or: Allow the belt to drop to the floor (electrically, optional). 	
9.	Release the crush.	<ul style="list-style-type: none"> Check that all ropes and belts have been freed. Open the front gate. Lead the cow out of the crush. 	
10.	Release the rump chain or raise the rear gate.	<ul style="list-style-type: none"> Release the rump chain or raise the rear gate. 	

5.4. Hook up the front leg.



	<p style="text-align: center;">CAUTION</p> <ul style="list-style-type: none"> To avoid injury to the front leg the rope must be applied correctly. (see Figure 4)
--	--



Figure 4: detail of hooking up front leg

6. Maintenance


	<p style="text-align: center;">CAUTION!</p> <ul style="list-style-type: none"> • Always disconnect the machine from the power supply by pulling out the plug. Where a hydraulic accumulator is present this must be depressurised. • Test the installation on completion of maintenance work or repairs to ensure that it can be used again safely. • Only trained technical personnel may carry out the maintenance activities described or repair work.
---	---

6.1. Maintenance diagram


The diagram below shows the maintenance activities to be carried out.

Activity	note	Daily	weekly	Every 100 animals	Annually	Every 2 years	See Section
General							
Check on panic locks and hooks.	Renew where damage is visible.						
Check ropes and chains.	Renew where damage is visible.						
Check plugs, cables, controls and connections.	Alert a competent fitter where damage is visible.						
Check that the left and right front leg ropes are hanging at equal lengths.	Where these are driven by a single motor.						
Cleaning							
Clean the machine.							6.2
Lubrication							
Grease nipples on rear gate sliding section.	Bearing grease.						6.3
Other grease nipples.	Bearing grease.						
Axle and wheels							
Check play in the wheels.							6.4
Check the tyre profile.	Have this inspected by a competent person.						
Check the tyre pressures.	Have this inspected by a competent person.						
Drawbar							
Play in ball mounting.	Replace where minor play is evident, or see markers on the side of the ball mounting.						
Check the shaft bolts.	Every 10,000 km.						

6.2. Clean the machine.

	<p style="text-align: center;">EXPLANATION</p> <ul style="list-style-type: none"> • A high-pressure cleaner may be used for cleaning. • Avoid bearings, winches and motors when cleaning with a high-pressure cleaner. Spraying in these areas may result in a sharp reduction in service life.
---	---


6.3. Lubrication of rear gate

	<p style="text-align: center;">EXPLANATION</p> <ul style="list-style-type: none"> • The rear gate is slid out with the aid of gas springs fitted to the gate. • To prevent grease entering the gas springs and causing damage, the gate must only be lubricated when it is fully drawn back.
---	--



1

2




3


Figure 5: lubrication of rear gate

No.	What to do	Action	Result
1.	Retract the rear gate.	<ul style="list-style-type: none"> • Attach the rear leg winch to the rear gate and tighten until the gate is fully retracted. 	
2.	Grease the nipples.	<ul style="list-style-type: none"> • Lubricate the rear gate nipples using a grease gun. 	

6.4. Check play in the wheels.

	<p style="text-align: center;">EXPLANATION</p> <ul style="list-style-type: none">• Raise the wheels from the ground and feel if any play is present.• If play can be detected this must be corrected by a competent person, or otherwise the bearings and seals must be replaced.
---	--

6.5. Parts

	<p style="text-align: center;">EXPLANATION</p> <ul style="list-style-type: none">• Consult the website at www.wopa.com for information on the available options and the parts available to order.
---	---

7. Disposal as waste

Oil and components must not be disposed of as domestic waste. When replacing components or oil or at the end of the machines service life, ensure that all materials are collected and destroyed or reused in a legal and environmentally friendly manner.



Page 25 of 25