

# HF-LPB100U

## Low Power Wi-Fi Module User Manual

V1.1



### Overview of Characteristic

- ✧ Support IEEE802.11b/g/n Wireless Standards
- ✧ Support UART/USB1.1/GPIO Data Communication Interface
- ✧ Support Work As STA/AP/AP+STAMode
- ✧ Support Smart Link Function (APP program provide)
- ✧ Support Audio In(MIC) and Audio Output(Speaker) Interface
- ✧ Support Audio SmartLink Function.
- ✧ Support Wireless and Remote Firmware Upgrade Function
- ✧ Support WPS Function
- ✧ Support Soft Key Power Control(Reserved)
- ✧ Support SDK Development Kit
- ✧ Support Internal/External(I-PEX) Antenna Option
- ✧ Smallest Size: 23.1mm x 32.8mm x2.7mm
- ✧ FCC/CE Certificated

## TABLE OF CONTENTS

<b>LIST OF FIGURES .....</b>	<b>6</b>
<b>LIST OF TABLES .....</b>	<b>7</b>
<b>HISTORY.....</b>	<b>8</b>
<b>1. PRODUCT OVERVIEW .....</b>	<b>9</b>
<b>1.1. General Description.....</b>	<b>9</b>
1.1.1 Device Features.....	9
1.1.2 Device Parameters .....	10
1.1.3 Key Application .....	10
<b>1.2. Hardware Introduction.....</b>	<b>11</b>
1.2.1. Pins Definition .....	11
1.2.2. Electrical Characteristics .....	13
1.2.3. Mechanical Size.....	14
1.2.4. On-board Chip Antenna.....	14
1.2.5. External Antenna .....	15
1.2.6. Evaluation Kit.....	16
1.2.7. Order Information.....	17
<b>1.3. Typical Application .....</b>	<b>18</b>
1.3.1. Hardware Typical Application .....	18
<b>1.4. Audio SmartLink Function .....</b>	<b>19</b>
1.4.1. Audio SmartLink Hardware Reference Design .....	19
<b>2. FUNCTIONAL DESCRIPTION .....</b>	<b>20</b>
<b>2.1. Wireless Networking.....</b>	<b>20</b>
2.1.1. Basic Wireless Network Based On AP (Infrastructure) .....	20
2.1.2. Wireless Network Based On AP+STA.....	20
<b>2.2. Work Mode : Transparent Transmission Mode.....</b>	<b>21</b>
<b>2.3. UART Frame Scheme .....</b>	<b>22</b>
2.3.1. UART Free-Frame .....	22
2.3.2. UART Auto-Frame .....	22
<b>2.4. Encryption .....</b>	<b>23</b>
<b>2.5. Power Save Scheme(Reserved) .....</b>	<b>23</b>
<b>2.6. Parameters Configuration .....</b>	<b>24</b>
<b>2.7. Firmware Update .....</b>	<b>24</b>
<b>2.8. GPIO/PWM Function .....</b>	<b>25</b>
<b>2.9. SOCKET B Function .....</b>	<b>25</b>
<b>2.10. Multi-TCP Link Connection .....</b>	<b>26</b>
<b>3. OPERATION GUIDELINE .....</b>	<b>27</b>
<b>3.1. Configuration via Web Accessing .....</b>	<b>27</b>
3.1.1. Open Web Management Interface .....	27
3.1.2. System Page.....	28

3.1.3. Work Mode Page .....	28
3.1.4. STA Setting Page .....	28
3.1.5. AP Setting Page .....	29
3.1.6. Other Setting Page .....	29
3.1.7. Account Management Page .....	30
3.1.8. Upgrade Software Page .....	30
3.1.9. Restart Page .....	31
3.1.10. Restore Page .....	31
3.1.11. Internal Webpage.....	32
<b>3.2. HF-LPB100U Usage Introduction .....</b>	<b>32</b>
3.2.1. Software Debug Tools .....	32
3.2.2. Network Connection .....	33
3.2.3. Default Parameter Setting .....	33
3.2.4. Module Debug.....	33
<b>3.3. Typical Application Examples .....</b>	<b>35</b>
3.3.1. Wireless Control Application.....	35
3.3.2. Remote Management Application.....	35
3.3.3. Transparent Serial Port Application.....	36
<b>4. AT+INSTRUCTION INTRODUCTION .....</b>	<b>37</b>
<b>4.1. Configuration Mode .....</b>	<b>37</b>
4.1.1. Switch to Configuration Mode.....	37
<b>4.2. AT+Instruction Set Overview .....</b>	<b>38</b>
4.2.1. Instruction Syntax Format.....	38
4.2.2. AT+Instruction Set .....	39
4.2.2.1. AT+E .....	41
4.2.2.2. AT+WMODE .....	42
4.2.2.3. AT+ENTM .....	42
4.2.2.4. AT+TMODE.....	42
4.2.2.5. AT+MID .....	42
4.2.2.6. AT+VER .....	43
4.2.2.7. AT+LVER .....	43
4.2.2.8. AT+FWSZ .....	43
4.2.2.9. AT+RELD .....	43
4.2.2.10. AT+FCLR.....	43
4.2.2.11. AT+Z .....	44
4.2.2.12. AT+H .....	44
4.2.2.13. AT+CFGRD .....	44
4.2.2.14. AT+CFGWR .....	44
4.2.2.15. AT+CFGFR.....	44
4.2.2.16. AT+CFGTF .....	44
4.2.2.17. AT+UART .....	45
4.2.2.18. AT+UARTF .....	45
4.2.2.19. AT+UARTFT.....	46
4.2.2.20. AT+UARTFL .....	46

4.2.2.21.	AT+UARTTE .....	46
4.2.2.22.	AT+SEND .....	46
4.2.2.23.	AT+RECV .....	47
4.2.2.24.	AT+PING .....	47
4.2.2.25.	AT+NETP .....	47
4.2.2.26.	AT+MAXSK .....	48
4.2.2.27.	AT+TCPLK .....	48
4.2.2.28.	AT+TCPPTO .....	48
4.2.2.29.	AT+TCPDIS .....	49
4.2.2.30.	AT+SOCKB .....	49
4.2.2.31.	AT+TCPDISB .....	50
4.2.2.32.	AT+TCPPTOB .....	50
4.2.2.33.	AT+TCPLKB .....	50
4.2.2.34.	AT+UDPLCPT .....	51
4.2.2.35.	AT+SNDB .....	51
4.2.2.36.	AT+RCVB .....	51
4.2.2.37.	AT+WSSSID .....	51
4.2.2.38.	AT+WSKEY .....	52
4.2.2.39.	AT+WANN .....	52
4.2.2.40.	AT+WSMAC .....	52
4.2.2.41.	AT+WSLK .....	53
4.2.2.42.	AT+WSLQ .....	53
4.2.2.43.	AT+WSCAN .....	53
4.2.2.44.	AT+WSDNS .....	53
4.2.2.45.	AT+LANN .....	54
4.2.2.46.	AT+WAP .....	54
4.2.2.47.	AT+WAKEY .....	54
4.2.2.48.	AT+WAMAC .....	55
4.2.2.49.	AT+WADHCP .....	55
4.2.2.50.	AT+WADMN .....	55
4.2.2.51.	AT+WALK .....	56
4.2.2.52.	AT+WALKIND .....	56
4.2.2.53.	AT+PLANG .....	56
4.2.2.54.	AT+UPURL .....	57
4.2.2.55.	AT+UPFILE .....	57
4.2.2.56.	AT+LOGSW .....	57
4.2.2.57.	AT+LOGPORT .....	58
4.2.2.58.	AT+UPST .....	58
4.2.2.59.	AT+WEBU .....	58
4.2.2.60.	AT+MSLP .....	58
4.2.2.61.	AT+NTPRF .....	59
4.2.2.62.	AT+NTPEN .....	59
4.2.2.63.	AT+NTPTM .....	59
4.2.2.64.	AT+NTPSER .....	60

4.2.2.65. AT+WRMID .....	60
4.2.2.66. AT+RLDEN .....	60
4.2.2.67. AT+ASWD .....	60
4.2.2.68. AT+MDCH .....	61
4.2.2.69. AT+TXPWR .....	61
4.2.2.70. AT+SMTLK .....	61
4.2.2.71. AT+WPS .....	61
4.2.2.72. AT+WPSBTNEN .....	62
4.2.2.73. AT+LPTIO .....	62
<b>5. PACKAGE INFORMATION .....</b>	<b>63</b>
5.1. Recommended Reflow Profile .....	63
5.2. Device Handling Instruction (Module IC SMT Preparation) .....	63
5.3. Shipping Information .....	64
<b>APPENDIX A: HW REFERENCE DESIGN .....</b>	<b>65</b>
<b>APPENDIX B: CONTROL GPIO/PWM FUNCTION WITH NETWORK COMMANDS(RESERVED).....</b>	<b>66</b>
B.1 Network Command .....	66
B.2 Hexadecimal Network Command .....	69
<b>APPENDIX C: HTTP PROTOCOL TRANSFER .....</b>	<b>72</b>
C.1. HTTP AT command.....	72
C.1.1. AT+HTTPURL .....	72
C.1.2. AT+HTTPPTP .....	72
C.1.3. AT+HTTPPPH .....	72
C.1.4. AT+HTTPCN .....	73
C.1.5. AT+HTTPUA .....	73
C.1.6. AT+HTTPDT .....	73
C.2. HTTP Example .....	73
<b>APPENDIX D: REFERENCES .....</b>	<b>75</b>
D.1. High-Flying Mass Production Tool .....	75
D.2. SmartLink APP Config Tool .....	75
D.3. EVK Quick Start Guide .....	75
D.4. SDK Download .....	75
<b>APPENDIX E: CONTACT INFORMATION .....</b>	<b>76</b>

## LIST OF FIGURES

Figure 1.	HF-LPB100U View .....	11
Figure 2.	HF-LPB100U Pins Map .....	11
Figure 3.	HF-LPB100U Mechanical Dimension.....	14
Figure 4.	HF-LPB100U PCB Symbol Size.....	14
Figure 5.	Suggested Module Placement Region.....	15
Figure 6.	HF-LPB100U Evaluation Kit .....	16
Figure 7.	HF-LPB100U Order Information.....	17
Figure 8.	HF-LPB100U Hardware Typical Application .....	18
Figure 9.	Audio SmartLink Hardware Reference Desi .....	19
Figure 10.	HF-LPB100U Basic Wireless Network Structure.....	20
Figure 11.	HF-LPB100U AP+STA Network Structure.....	21
Figure 12.	Socket B function demo.....	26
Figure 13.	Multi-TCP Link Data Transmition Structure .....	26
Figure 14.	Open Web Management page.....	27
Figure 15.	System Web Page .....	28
Figure 16.	Work Mode Page .....	28
Figure 17.	STA Setting Page .....	29
Figure 18.	AP Setting Page .....	29
Figure 19.	Other Setting Page .....	30
Figure 20.	Account Page.....	30
Figure 21.	Upgrade SW page .....	31
Figure 22.	Restart Page .....	31
Figure 23.	Restore Page .....	32
Figure 24.	Internal Webpage .....	32
Figure 25.	STA Interface Debug Connection .....	33
Figure 26.	AP Interface Debug Connection .....	33
Figure 27.	“CommTools” Serial Debug Tools .....	33
Figure 28.	“TCPUDPDbg” Tools Create Connection .....	34
Figure 29.	“TCPUDPDbg” Tools Setting .....	34
Figure 30.	“TCPUDPDbg” Tools Connection .....	34
Figure 31.	Wireless Control Application.....	35
Figure 32.	Remote Management Application.....	35
Figure 33.	Transparent Serial Port Application .....	36
Figure 34.	HF-LPB100U Default UART Port Parameters.....	37
Figure 35.	Switch to Configuration Mode.....	37
Figure 36.	“AT+H” Instruction for Help .....	38
Figure 37.	Reflow Soldering Profile .....	63
Figure 38.	Shipping Information .....	64

## LIST OF TABLES

Table 1	HF-LPB100U Module Technical Specifications .....	10
Table 2	HF-LPB100U Pins Definition .....	11
Table 3	HF-LPB100U External Antenna Parameters.....	15
Table 4	HF-LPB100U Evaluation Kit Interface Description.....	16
Table 6	Standby Mode Status and Wake Up .....	23
Table 7	HF-LPB100U GPIO/PWM Pin Mapping Table .....	25
Table 8	HF-LPB100U Web Access Default Setting .....	27
Table 9	Error Code Describtion .....	39
Table 10	AT+Instruction Set List .....	39
Table 11	Reflow Soldering Parameter .....	63

## HISTORY

**Ed.V1.0** 03-29-2014

**Ed. V1.105-29-2014.** Update SDK download. Add “AT+UDPLCPT”, “AT+NTPSER” command.  
Update Shipping information.

High-Flying

# 1. PRODUCT OVERVIEW

## 1.1. General Description

The HF-LPB100U is a fully self-contained small form-factor, single stream, 802.11b/g/n Wi-Fi module, which provide a wireless interface to any equipment with a Serial/SPI interface for data transfer. HF-LPB100U integrate MAC, baseband processor, RF transceiver with power amplifier in hardware and all Wi-Fi protocol and configuration functionality and networking stack, in embedded firmware to make a fully self-contained 802.11b/g/n Wi-Fi solution for a variety of applications.

The HF-LPB100U employs the world's lowest power consumption embedded architecture. It has been optimized for all kinds of client applications in the home automation, smart grid, handheld device, personal medical application and industrial control that have lower data rates, and transmit or receive data on an infrequent basis.

The HF-LPB100U integrates all Wi-Fi functionality into a low-profile, 23.1x32.8x 2.7mm SMT module package that can be easily mounted on main PCB with application specific circuits. Also, module provides built-in antenna, external antenna option.

### 1.1.1 Device Features

- Single stream Wi-Fi @ 2.4 GHz with support for WEP security mode as well as WPA/WPA2
- Based on Self-developed High Cost Performance MCU
- Ultra-low-power operation with all kinds of power-save modes.
- Includes all the protocol and configuration functions for Wi-Fi connectivity.
- Support STA/AP/AP+STA Mode
- Support Audio In(MIC) and Audio Output(speaker) Interface
- Support Smart Link Function
- Support Audio SmartLink Function
- Support Wireless and Remote Firmware Upgrade Function
- Support USB1.1/GPIO Output
- Integrated chip antenna, antenna connector options.
- Compact surface mount module 23.1mm x 32.8mm x 2.7mm.
- Single supply – 3.3V operation.
- Low power RTOS and drivers.
- CE/FCC Certified.
- RoHS compliant.

### 1.1.2 Device Parameters

Table 1HF-LPB100U Module Technical Specifications

Class	Item	Parameters
Wireless Parameters	Certification	FCC/CE
	Wireless standard	802.11 b/g/n
	Frequency range	2.412GHz-2.484GHz
	Transmit Power	802.11b: +16 +/-2dBm (@11Mbps)
		802.11g: +14 +/-2dBm (@54Mbps)
		802.11n: +13 +/-2dBm (@HT20, MCS7)
	ReceiverSensitivity	802.11b: -93dBm (@11Mbps ,CCK)
		802.11g: -85 dBm (@54Mbps, OFDM)
		802.11n: -82 dBm (@HT20, MCS7)
	Antenna Option	External:I-PEX Connector
		Internal:On-board PCB antenna
Hardware Parameters	Data Interface	UART USB, PWM, GPIO
	Operating Voltage	2.8~3.6V
	Operating Current	Peak [Continuous TX]: ~200mA Normal [WiFi ON/OFF, DTIM=100ms]: Average. ~12mA, Peak: 200mA Standby: <200uA( <b>Reserved</b> ) Power Down Switch: <10uA( <b>Reserved</b> )
	Operating Temp.	-40°C - 85°C
	StorageTemp.	-45°C - 125°C
	Dimensions and Size	23.1mmx32.8mmx2.7mm
	Network Type	STA/AP/STA+AP
Software Parameters	Security Mechanisms	WEP/WPA-PSK/WPA2-PSK
	Encryption	WEP64/WEP128/TKIP/AES
	Update Firmware	Local Wireless, Remote
	Customization	Web Page Upgrade Support SDK for application develop
	Network Protocol	IPv4, TCP/UDP/FTP/HTTP
	User Configuration	AT+instruction set.Android/ iOS Smart Link APP tools

### 1.1.3 Key Application

- Remote equipment monitoring
- Asset tracking and telemetry
- Security
- Industrial sensors and controls
- Home automation
- Medical devices

## 1.2. Hardware Introduction



Figure 1. HF-LPB100UView

### 1.2.1. Pins Definition




Figure 2. HF-LPB100U Pins Map

Table 2HF-LPB100U Pins Definition

Pin	Description	Net Name	Signal Type	Comments
1,17,32,48	Ground	GND	Power	
2	Debug Pin	SWCLK	I, PD	Debug functional pin, No connect if not use.
3		NC		
4		NC		
5	Debug Pin	SWD	I/O,PU	

Pin	Description	Net Name	Signal Type	Comments
6		N.C		No connect
7	GPIO/AD	Sleep_RQ	I.PU	GPIO7, No connect if not use.
8	GPIO/AD	Sleep_ON	O	GPIO8, No connect if not use.
9	+3.3V Power	DVDD	Power	
10		N.C		No connect
11	Speaker R	DAC_RO	Analog	GPIO11, 不用请悬空
12	Speaker L	DAC_LO	Analog	GPIO12, 不用请悬空
13	MIC_IN	MIC_IN	Analog	GPIO13, 不用请悬空
14		N.C		No connect
15	GPIO	GPIO15	I/O	GPIO15, WPS Function Pin.
16		N.C		No connect
18	PWM/GPIO	PWM_3	I/O	GPIO18, No connect if not use.
19		N.C		No connect
20	PWM/GPIO	PWM_4	I/O	GPIO20, No connect if not use.
21		N.C		No connect
22		N.C		No connect
23	Power Control Switch	PWR_SW	I,PU	“0” – Power Down Mode “1” – Normal mode( <b>Reserved</b> )
24		N.C		No connect
25	USB1.1 D+	USB_DP	I/O	GPIO25, No connect if not use.
26	USB1.1 D-	USB_DM	I/O	GPIO26, No connect if not use.
27	GPIO	PWM_27	I/O	GPIO27, No connect if not use.
28		N.C		No connect
29	UART1/AD	UART1_RX	I	GPIO29, No connect if not use.
30	UART1/AD	UART1_TX	O	GPIO30, No connect if not use.
31	+3.3V Power	DVDD	Power	
33		N.C		No connect
34	+3.3 Power	DVDD	Power	
35	WPS	WPS	I/O	GPIO35, No connect if not use.
36		N.C		No connect
37		N.C		No connect
38		N.C		No connect
39	UART0	UART0_TX	O	GPIO39, No connect if not use.
40	UART0	UART0_RTS	I/O	GPIO40, No connect if not use.
41	UART0	UART0_RX	I	GPIO41, No connect if not use.
42	UART0	UART0_CTS	I/O	GPIO42, No connect if not use.
43	Wi-Fi Status/AD	nLink	O	<b>Detailed functions see &lt;Notes&gt;</b>
44	Module Boot Up Indicator/AD	nReady	O	“0” – Boot-up OK; “1” – Boot-up No OK;
45	Multi-Function /AD	nReload	I,PU	<b>Detailed functions see&lt;Notes&gt;</b>
46		N.C		No connect

Pin	Description	Net Name	Signal Type	Comments
47	Module Reset	EXT_RESETn	I,PU	"Low" effective reset input.

**<Notes>**

**nReload Pin(Button) function:**

- When this pin is set to "low" during module boot up, the module will enter wireless firmware and config upgrade mode. This mode is used for customer manufacture. (See Appendix D to download software tools for customer batch configuration and upgrade firmware during mass production)
- After module is powered up, short press this button ("Low" < 3s) to make the module go into "SmartLink" config mode, waiting for APP to set password and other information. (See Appendix D to download SmartLink APP)
- After module is powered up, long press this button ("Low" > 3s) to make the module recover to factory setting.

High-Flying strongly suggest customer fan out this pin to connector or button for "Manufacture" and "Smart Link" application.

**nLinkPin (LED) function:**

- At wireless firmware and config upgrade mode , this LED used to indicate configure and upgrade status.
- At "Smart Link" config mode, this LED used to indicate APP to finish setting.
- At normal mode, it's Wi-Fi link status indicator

High-Flying strongly suggest customer fan out this pin to LED.

### 1.2.2. Electrical Characteristics

Absolute Maximum Ratings:

Parameter	Condition	Min.	Typ.	Max.	Unit
Storage temperature range		-45		125	°C
Maximum soldering temperature	IPC/JEDEC J-STD-020			260	°C
Supply voltage		0		3.8	V
Voltage on any I/O pin		0		3.3	V
ESD (Human Body Model/HBM)	TAMB=25°C			2	kV
ESD (Charged Device Model, CDM)	TAMB=25°C			1	kV

Power Supply & Power Consumption:

Parameter	Condition	Min.	Typ.	Max.	Unit
Operating Supply voltage		2.8	3.3	3.8	V
Supply current, peak	Continuous Tx		200		mA
Supply current, IEEE PS	DTIM=100ms		12		mA
Output high voltage	Sourcing 6mA	2.8			V
Output low voltage	Sinking 6mA			0.2	V
Input high voltage		2.2			V
Input low voltage				0.8	V
GPIO Input pull-up resistor		200			kΩ
GPIO Input pull-down resistor		200			kΩ

### 1.2.3. Mechanical Size

HF-LPB100U modules physical size (Unit: mm) as follows:




Figure 3. HF-LPB100U Mechanical Dimension

HF-LPB100U Module PCB symbol size (mm) as follows:




Figure 4. HF-LPB100U PCB Symbol Size

### 1.2.4. On-board Chip Antenna

HF-LPB100U module support internal on-board chip antenna option. When customer select internal antenna, you shall comply with following antenna design rules and module location suggestions:

- For customer PCB, RED color region (8.3x18.4mm) can't put component or paste GND net;
- Antenna must away from metal or high components at least 10mm;
- Antenna can't be shielded by any metal enclosure; All cover, include plastic, shall away from antenna at least 10mm;




Figure 5. Suggested Module Placement Region

High-Flying suggest HF-LPB100U module better locate in following region at customer board, which to reduce the effect to antenna and wireless signal, and better consult High-Flying technical people when you structure your module placement and PCB layout.

### 1.2.5. External Antenna

HF-LPB100U module supports internal antenna and external antenna(I-PEX) option for user dedicated application.

If user select external antenna, HF-LPB100U modules must be connected to the 2.4G antenna according to IEEE 802.11b/g/n standards.

The antenna parameters required as follows:

Table 3 HF-LPB100UExternal Antenna Parameters

Item	Parameters
Frequency range	2.4~2.5GHz
Impedance	50 Ohm
VSWR	2 (Max)
Return Loss	-10dB (Max)
Connector Type	I-PEX or populate directly

### 1.2.6. Evaluation Kit

High-Flying provides the evaluation kit to promote user to familiar the product and develop the detailed application. The evaluation kit shown as below, user can connect to HF-LPB100U module with the RS-232 UART, RS485, USB (Internal USB to UART converter) or Wireless port to configure the parameters, manage the module or do the some functional tests.




Figure 6. HF-LPB100U Evaluation Kit

**Notes:** User need download USB to UART port driver from High-Flying web or contact with technical support people for more detail.

The external interface description for evaluation kit as follows:

Table 4 HF-LPB100U Evaluation Kit Interface Description

Function	Name	Description
External Interface	COM1	Main data/command RS-232 interface 1
	COM2	RS-232 interface 2
	JTAG	JTAG data debug interface (Not for user use)
	Microphone	MIC input, used for Audio SmartLinkconfig or Audio record
	Speaker	Audio output interface(for Speaker)
	USB	USB 1.1 data interface
	DC Jack	DC jack for power in, 5~18V input.
	DC5-18V	DC jack for power in, 5~18V input.
	BAT	2 Li-Battery Power Supply.
LED	EXT PORT	HF-LPB100U GPIO function extend interface connector
	Power	3.3V Power Indicator
	nLink	nLink - WiFi LINK Indicator See 1.2.1
	nReady	nReady – Module Bootup Ready Indicator On (“low”)- Module bootup OK;

Function	Name	Description
		Off ("high")- Mouulebotup failed; <b>Twinkle- Remote Upgrade Ongoing;</b>
	Sleep_ON	Sleep_ON-Module asleep or awake <b>Indicator(Reserved)</b> On ("low")- Module in shundown(deep sleep) status; Off ("high")- Mouule in normal status;
Button	nReset	Used to reset the module.
	nReload	Restore factory default configuration after push this pin more than 3s. See 1.2.1
	WPS	WPS Button
	Sleep_RQ	Pin Sleep Control button, more than 3s to put module in standby mode. <b>(Reserved)</b>

#### 1.2.7. Order Information

Base on customer detailed requirement, HF-LPB100U series modules provide different variants and physical type for detailed application.




Figure 7. HF-LPB100U Order Information

## 1.3. Typical Application

### 1.3.1. Hardware Typical Application




Figure 8. HF-LPB100U Hardware Typical Application

#### Notes:

**nReset-** Module hardware reset signal. Input. Logics “0” effective.

There is pull-up resister internal and no external pull-up required. When module power up or some issue happened, MCU need assert nRST signal “0” at least 10ms, then set “1” to keep module fully reset.

**nLink-** Module WIFI connection status indication. Output.

(This pin is recommend to connect to LED, indicate status when the module in wireless upgrade mode)

When module connects to AP (AP associated), this pin will output “0”. This signal used to judge if module already at WiFi connection status. Thers is pull-up resister internal and no external pull-up required. If nLink function not required, can leave this pin open.

**nReady-** Module boot up ready signal. Output. Logics “0” effective.

The module will output “0” after normal boot up. This signal used to judge if module finish boot up and ready for application or working at normal mode. If nReady function not required, can leave this pin open.

**nReload-** Module restore to factory default configuration. Input. Logics “0” effective.

(This pin is recommend to connect to button, is used to enter wireless upgrade mode)

User can de-assert nReload signal “0” more than 3s through button or MCU pin, then release, module will restore to factory default configuration and re-start boot up process.. If nReload function not required, can leave this pin open.

#### **Sleep\_RQ-Module Pin Sleep Control. Input. (Reserved)**

The user should de-assert this pin low “0”, after 3’s assert to high “1” to put the module to sleep status. Also at the deep sleep/standby mode, user can de-assert this pin low “0”, after 1’s assert to high “1” to put the module to wake up the module. If Sleep\_RQ function not required, can leave this pin open.

#### **Sleep\_ON- Module Pin Sleep Indicator. Output. (Reserved)**

This pin is used to indicate that the module is asleep (Module output “0”) or awake (Module output “1”) status. If user doesn’t use pin sleep function, can leave this pin open.

#### **UART0\_TXD/RXD- UART port data transmit and receive signal.**

### **1.4. Audio SmartLink Function**

#### **1.4.1. Audio SmartLink Hardware Reference Design**




Figure 9. Audio SmartLink Hardware Reference Desi

## 2. FUNCTIONAL DESCRIPTION

### 2.1. Wireless Networking

HF-LPB100U module can be configured as both wireless STA and AP base on network type. Logically there are two interfaces in HF-LPB100U. One is for STA, and another is for AP. When HF-LPB100U works as AP, other STA equipments are able to connect to HF-LPB100U module directly. Wireless Networking with HF-LPB100U is very flexible.

**Notes:**

**AP:** that is the wireless Access Point, the founder of a wireless network and the centre of the network nodes. The wireless router we use at home or in office may be an AP.

**STA:** short for Station, each terminal connects to a wireless network (such as laptops, PDA and other networking devices) can be called with a STA device.

#### 2.1.1. Basic Wireless Network Based On AP (Infrastructure)

Infrastructure: it's also called basic network. It built by AP and many STAs which join in.

The characters of network of this type are that AP is the centre, and all communication between STAs is transmitted through the AP. The figure following shows such type of networking.




Figure 10. HF-LPB100U Basic Wireless Network Structure

#### 2.1.2. Wireless Network Based On AP+STA

HF-LPB100U module support AP+STA network mode, means module support one AP interface and one STA interface at the same time, as following figure,




Figure 11. HF-LPB100U AP+STA Network Structure

When module enables AP+STA function, Module's STA interface can connect with router and connect to TCP server in the network. At the same time, module's AP interface is also active and permit phone/PAD to connect through TCPB, then phone/PAD can control user device and and setting the module parameters,

The advantage of AP+STA mode is:

- Users can easily setting and track user device through Phone/PAD and not change the orginal network setting.
- Users can easily setting module's parameters through WiFi when module works as STA mode.

## 2.2. Work Mode : Transparent Transmission Mode

HF-LPB100U module support serial interface transparent transmission mode. The benefit of this mode is achieves a plug and play serial data port, and reduces user complexity furthest. In this mode, user should only configure the necessary parameters. After power on, module can automatically connect to the default wireless network and server.

As in this mode, the module's serial port always work in the transparent transmission mode, so users only need to think of it as a virtual serial cable, and send and receive data as using a simple serial. In other words, the serial cable of users' original serial devices is directly replaced with the module; user devices can be easy for wireless data transmission without any changes.

The transparent transmission mode can fully compatible with user's original software platform and reduce the software development effort for integrate wireless data transmission.

The parameters which need to configure include:

- **Wireless Network Parameters**
  - Wireless Network Name (SSID)
  - Security Mode
  - Encryption Key

- **TCP/UDP Linking Parameters**
  - Protocol Type
  - Link Type (Server or Client)
  - TargetPort ID Number
  - TargetPort IP Address
- **Serial Port Parameters**
  - Baud Rate
  - Data Bit
  - Parity (Check) Bit
  - Stop Bit
  - Hardware Flow Control

## 2.3. UART Frame Scheme

### 2.3.1. UART Free-Frame

HF-LPB100U support UART free-frame function. If user select open this function, module will check the intervals between any two bytes when receiving UART data. If this interval time exceeds defined value (50ms default), HF-LPB100U will think it as the end of one frame and transfer this free-frame to WiFi port, or HF-LPB100U will receive UART data until 1000 bytes, then transfer 1000 bytes frame to WiFi port.

HF-LPB100U's default interval time is 50ms. User can also set this interval to fast (10ms) through AT command. But user have to consider if user MCU can send UART data with 10ms interval ,or the UART data may be divided as fragment.

Through AT command: AT+UARTTE=fash/normal, user can set the interval time: fast (10ms) and normal (50ms).

### 2.3.2. UART Auto-Frame

HF-LPB100U support UART auto-frame function. If user select open this function and setting auto-frame trigger length and auto-frame trigger time parameters, then module will auto framing the data which received from UART port and transmitting to the network as pre-defined data structure.

- **Auto-frame trigger length:** The fixed data length that module used to transmitting to the network.
- **Auto-frame trigger time:** After the trigger time, if UART port received data can't reach auto-frame trigger length, then module will transmitting available data to the network and bypass the auto-frame trigger length condition.

Detailed UART auto-frame function can refer to AT+instruction set “UARTF/UARTFT/UARTFL” introduction.

## 2.4. Encryption

Encryption is a method of scrambling a message that makes it unreadable to unwanted parties, adding a degree of secure communications. There are different protocols for providing encryption, and the HF-LPB100U module supports following:

- ◆ WEP
- ◆ WPA-PSK/TKIP
- ◆ WPA-PSK/AES
- ◆ WPA2-PSK/TKIP
- ◆ WPA2-PSK/AES

## 2.5. Power SaveScheme(Reserved)

HF-LPB100U module can work at two modes based on different power save scheme:

- **Normal (Active/Sleep) Mode** - AP Associated, WiFi ON/OFF based on internal control
- **Standby Mode**- Non AP Associated, WiFi Shut down

**Normal (Active/Sleep) Mode** Normal mode is no DTIM related (Default mode), module will monitor the interval to Active/Sleep.

**Standby Mode** allows the WiFi circuitry to be powered down, which results in the lowest sleep current, but at the expense of longer wake up times. This is due to the module associating with the access point every time when it wakes up. The intent of this option is to allow for longer sleep times. Standby mode can through AT+MSLP command or trigger “Sleep\_RQ” pin to go in.

The standby mode status and wakeup method as follows: For standby mode, module provides two wakes up options, user can select one or whole as the module wake up option. Refer to AT Instruction (Power Management Instruction Set) for more detailed setting.

- “Sleep\_RQ” Pin Wake Up
- “Reset” Pin Wake Up

Table 6 Standby Mode Status and Wake Up

	Status				Wake Up Method			
	Wi-Fi	MCU	Current	UART	GPIO	Timeout	AT Command	Reset Pin
Standby	OFF	OFF	<80uA	OFF	Yes	No	No	Yes

**Sleep\_RQ Pin Wake UpOption** allows an external microcontroller to determine when HF-LPB100U should sleep and when it should wake by controlling the “Sleep\_RQ” and “Sleep\_ON” pin. at the standby mode, user can de-assert this pin low “0”, after 1’s assert to high “1” to put the module to wake up the module. If user doesn’t use pin sleep function, can leave this pin open.

**Sleep\_RQ Pin Wake UpOption** allows an external microcontroller to de-assert “Reset” pin to low “0” to reset the module.

## 2.6. Parameters Configuration

HF-LPB100U module supports two methods to configuration parameters: **Web Accessing** and **AT+instruction set**.

Web accessing means users can configure parameters through Web browser. When HF-LPB100U module connected to wireless network, parameters configuration is done on a PC connected to the same wireless network.

AT+instruction set configuration means user configure parameters through serial interface command. Refer to “AT+instruction set” chapter for more detail.

## 2.7. Firmware Update

HF-LPB100U module supports two on-line upgrade methods:

- Webpage Wi-Fi Upgrade
- Remote Upgrade

Webpaged based Wi-Fiupgrade,please refer to 3.1.8 firmware upgrade page , user can upload firmware file from PC to HF-LPB100U.

HF-LPB100U module also support upgrade from remote HTTP server, keep module connects to AP router before excuate remote HTTP upgrade. Remote upgrade have two methods: **Direct Download and Upgrade**, **Configure File Based Upgrade**.

### ◆ Configure File Based Upgrade

AT+UPURL command to set the remote directory which the configuration file located, such as AT+UPURL=http://www.hi-flying.com/admin/down/

Notes: The last '/' can't be remove

AT+UPFILE command to set the configuration file name, such as AT+UPFILE=config.txt

AT+UPST command to start remote Application upgrade. After excuate this command, the module will firstly download configuration file (“config.txt”), then download the upgrade file base on the URL address listed in the configure file.

General “config.txt” file format as following example:

[URL]=<http://10.10.100.100:80/lpb.bin>

[URL]= the URL address of Application.

### ◆ Direct Download and Upgrade

AT+UPURL command to set the remote directory and file name, such as:

AT+UPURL=http://www.hi-flying.com/admin/down/,lpb.bin

After excuate this command, the module will directly download the “lpb.bin” file from remote directory and start upgrade Application.

**Notes:** please contact with high-flying technical people before upgrade firmware, or maybe damage the module and can't work again.

## 2.8. GPIO/PWM Function

HF-LPB100U module can provide many GPIOs, which includemax 6 PWM/GPIO control pins.User devices can read/write GPIO/PWM pins status.

Table 7HF-LPB100U GPIO/PWM Pin Mapping Table

GPIO	Configured Function	Description	Default Setting	Type
GPIO7	GPIO Channel	Sleep_RQ	GPIO11	I/O
GPIO8	GPIO Channel	Sleep_ON	GPIO12	I/O
GPIO15	GPIO Channel	GPIO15	GPIO15	I/O
GPIO18	PWM/GPIO Channel	PWM_3	GPIO18	I/O
GPIO20	PWM/GPIO Channel	PWM_4	GPIO20	I/O
GPIO25	GPIO/USB Channel	USB_DP	USB_DP	I/O
GPIO26	GPIO/USB Channel	USB_DM	USB_DM	I/O
GPIO27	GPIO Channel	GPIO27	GPIO27	I/O
GPIO29	GPIO/UART1 Channel	UART1_RX	GPIO29	I/O
GPIO30	GPIO/UART1 Channel	UART1_TX	GPIO30	I/O
GPIO35	GPIO/WPS Channel	WPS	GPIO35	I/O

When module works at PWM mode, PC and other devices can setup connection (TCP/UDP) through WiFi, then read/write GPIO/PWM information through command data.


- GPIO n OUT 0, Set GPIOn as output and output '0', Response GPIO OK or GPIO NOK;
- GPIO n OUT 1, Set GPIOn as output and output '1', Response GPIO OK or GPIO NOK;
- GPIO n GET, ReadGPIOn pin status, Response +ok=1 or GPIO NOK
- GPIO n SET, Save GPIOn set, Response GPIO OK or GPIO NOK
- PWM n frequency duty, Set PWMn Channel output, Response GPIO OK or GPIO NOK
- PWM n GET, Read PWMn Channel set, Response +ok=frequency duty or PWM NOK
- PWM n SET, Save PWMn Channel set, Response PWM OK or PWM NOK

**Notes:**Please refer to Appendix B for details to use GPIO/PWM.

## 2.9. SOCKET B Function

HF-LPB100U support double socket communication, the socket B function is disabled by default.

After the module is started, send command “AT+SOCKB” to set the connection parameter, send command “AT+TCPDISB=on” to try to connect with TCP server, the module will stop connecting after three failures. Send command “AT+TCPDISB=on” to make connection. Send command “AT+TCPDISB=off” to close connection. Send command “AT+TCPLKB” to inquire TCP connection.



```

Serial-COM4 - SecureCRT
File Edit View Options Transfer Script Tools Help
| Serial-COM4 | X
AT+SOCKB=tcp,8899,192.168.10.100
+ok

AT+TCPDISB=on
+ok

AT+RCVB=100
+ok=0

AT+RCVB=10
+ok=10,ddddddssdd

AT+SNDB=10
>+ok=1

AT+TCPLKB
+ok=on

AT+TCPTOB
+ok=0

AT+TCPDISB=off
+ok
■

```

Ready      Serial: COM4    26, 1    26 Rows, 72 Cols    VT100

Figure 12. Socket B function demo

## 2.10. Multi-TCP Link Connection

When HF-LPB100U module configured as TCP Server, it supports Multi-TCP link connection, and maximum 5 TCP clients permitted to connect to HF-LPB100U module. User can realize multi-TCP link connection at each work mode.

Multi-TCP link connection will work as following structure:

Upstream: All dates from different TCP connection or client will be transmitted to the serial port as a sequence.

Downstream: All data from serial port (user) will be duplicate and broadcast to every TCP connection or client.

Detailed multi-TCP link data transmission structure as following figure:




Figure 13. Multi-TCP Link Data Transmission Structure

## 3. OPERATION GUIDELINE

### 3.1. Configuration via Web Accessing

When first use HF-LPB100U modules, user may need some configuration. User can connect to HF-LPB100U module's wireless interface with following default setting information and configure the module through laptop.

Table 8HF-LPB100U Web Access Default Setting

Parameters	Default Setting
SSID	HF-LPB100U
IP Address	10.10.100.254
Subnet Mask	255.255.255.0
User Name	Admin
Password	Admin

#### 3.1.1. Open Web Management Interface

There is internal webpage and external webpage in modules. The external webpage is for web management. The internal webpage is only for upgrading.

- Step 1: Connect laptop to SSID “HF-LPB100U” of HF-LPB100U module via wireless LAN card;
- Step 2: After wireless connection OK. Open Wen browser and access “<http://10.10.100.254>”;
- Step 3: Then input user name and password in the page as following and click “OK” button.



Figure 14. Open Web Management page

The HF-LPB100U web management page support English and Chinese language. User can select language environment at the top right corner and click “Apply” button.

The main menu include nine pages: “System”, “Work Mode”, “STA Setting”, “AP Setting”, “Other Setting”, “Account”, “Upgrade SW”, “Restart”, “Restore”.

### 3.1.2. System Page

At this page, user can check current device's important information and status such as: device ID (MID), software version, wireless work mode and related Wi-Fi parameters.




Figure 15. System Web Page

### 3.1.3. Work Mode Page

HF-LPB100U module can works at AP mode to simplify user's configuration, can also works at STA to connect remote server through AP router. Also, it can configure at AP+STA mode which provide very flexible application for customers.





Figure 16. Work Mode Page

### 3.1.4. STA Setting Page

User can push "Scan" button to auto search Wi-Fi AP router nearby, and can connect with associate AP through some settings. Please note the encryption information input here must be fully same with Wi-Fi AP router's configuration, and then it can link with AP correctly.




The screenshot shows the STA Setting page of the HF-LPB100U configuration interface. The left sidebar has options: System, Work Mode, STA Setting (selected), AP Setting, Other Setting, Account, Upgrade SW, Restart, and Restore. The main area has fields for Network Name (SSID) set to 'SuSu', Encryption Method set to 'Disable', Obtain an IP address automatically set to 'Enable', IP Address set to '192.168.1.100', Subnet Mask set to '255.255.255.0', Gateway Address set to '192.168.1.1', and DNS Server Address set to '192.168.1.1'. A 'Save' button is at the bottom right.

Figure 17. STA Setting Page

### 3.1.5. APSetting Page

When user select module works at AP and AP+STA mode, then need setting this page and provide wireless and network parameters. Most of the system support DHCP to achieve IP address, so we suggest to “Enable”DHCP server in most applications.




The screenshot shows the AP Setting page of the HF-LPB100U configuration interface. The left sidebar has options: System, Work Mode, STA Setting (selected), AP Setting (selected), Other Setting, Account, Upgrade SW, Restart, and Restore. The main area is divided into three sections: Wireless AP Setting (Network Mode: 11bgn, Network Name(SSID): HF-LPB1, Module MAC Address: AECF23FF0020, Select Channel: 2412MHz(channel 1)), Wireless AP Security Setting (Encryption Mode: Disable), and Network Parameters Setting (IP Address (DHCP Gateway Setting): 10.10.100.254, Subnet Mask: 255.255.255.0, DHCP Server: Enable). Each section has a 'Save' button at the bottom right.

Figure 18. AP Setting Page

### 3.1.6. Other Setting Page

HF-LPB100U usually works at data transparent transmission mode. At this mode, the user device which connected with HF-LPB100U will connect and communicate with remote PC or server. At this page, user need setting serial port communication parameters and defines TCP related protocal parameters.




The screenshot shows the 'Other Setting' page of a web-based configuration interface. On the left, a sidebar lists various settings: System, Work Mode, STA Setting, AP Setting, Other Setting (which is selected), Account, Upgrade SW, Restart, and Restore. The main content area is divided into two sections: 'Serial Port Parameters Setting' and 'Network Parameters setting'. Under 'Serial Port Parameters Setting', the following fields are shown: Baud Rate (115200), Data Bit (8), Parity Bit (None), Stop Bit (1), and CTSRTS (Disable). A 'Save' button is located at the bottom right of this section. Under 'Network Parameters setting', the following fields are shown: Protocol (TCP-Server), Port ID (8899), Server Address (10.10.100.254), and TCP Time Out Setting (300). Another 'Save' button is located at the bottom right of this section.

Figure 19. Other Setting Page

### 3.1.7. Account Management Page

This page set web server's user name and password.



The screenshot shows the 'Account' page of a web-based configuration interface. On the left, a sidebar lists various settings: System, Work Mode, STA Setting, AP Setting, Other Setting, Account (which is selected), Upgrade SW, Restart, and Restore. The main content area is titled 'Set a New Account and Password'. It contains four input fields: 'Current User Name' (admin), 'Current Password' (admin), 'New User Name' (empty), and 'New Password' (empty). A 'Save' button is located at the bottom right of the form.

Figure 20. Account Page

### 3.1.8. Upgrade Software Page

User can upgrade new software (firmware) version through Wi-Fi.




Figure 21. Upgrade SW page

### 3.1.9. Restart Page

Most of the setting and configuration can only effective after system restart. User shall restart after finish all setting.




Figure 22. Restart Page

### 3.1.10. Restore Page

After module restore factory default setting, all user configuration profile will lose.

User can access <http://10.10.100.254> to set again, and user name and password is "admin". HF-LPB100U will restore to AP mode for factory default setting.




Figure 23. Restore Page

### 3.1.11. InternalWebpage

After wireless connection is OK. Open Wen browser and access “<http://10.10.100.254/iweb.html>”; It is for upgrading application and external webpage. Please contact High-Flying if need support on customization for external webpage.




Figure 24. Internal Webpage

## 3.2. HF-LPB100U Usage Introduction

### 3.2.1. Software Debug Tools

High-Flying use two common software tools debugging and applying HF-LPB100U module.  
(User can also select other tools used to debug serial port).

- Serial Debugging Software: ComTools 
- Ethernet Debugging Software: TCPUDPDbg 

### 3.2.2. Network Connection

User can select two methods to connect HF-LPB100U module base on dedicated application.

- **Use HF-LPB100U STA interface.** HF-LPB100U and debug PC2 connect to a wireless AP, another PC1 (or user device) connect to HF-LPB100U module with serial port:



Figure 25. STA Interface Debug Connection

- **Use HF-LPB100U AP interface.** Debug PC2 connect to HF-LPB100U through wireless connection, another PC1 (or user device) connect to HF-LPB100U module with serial port.



Figure 26. AP Interface Debug Connection

### 3.2.3. Default Parameter Setting

- Default SSID: HF-LPB100U;
- Deault security mode: open,none;
- User UART parameter setting:115200,8,1,None;
- Default network parameter setting:TCP,Server,8899,10.10.100.254;
- Module IP address: dhcp,0.0.0.0,0.0.0.0,0.0.0.0;

### 3.2.4. Module Debug

PC1 open “CommTools” program, setting the same serial port parameters with HF-LPB100U module and open serial port connection.



Figure 27. “CommTools” Serial Debug Tools

PC2 open “TCPUDPDbg” program, and create a new connection. If HF-LPB100U configured as Server mode, “TCPUDPDbg” Tools shall create “Client” mode connection. Or otherwise, create a “Server” mode connection.




Figure 28. “TCPUDPDbg” Tools Create Connection

Then setting the TCP/UDP connection parameters. Default as following:




Figure 29. “TCPUDPDbg” Tools Setting

Then, click “Create” button to create a connection.




Figure 30. “TCPUDPDbg” Tools Connection

Now, in transparent transmission mode, data can be transferred from “CommTools” program to “TCPUDPDBG” program, or in reverse. You can see data in receiver side will keep same as in sender side.

### 3.3. Typical Application Examples

#### 3.3.1. Wireless Control Application



Figure 31. Wireless Control Application

For this wireless control application, HF-LPB100U works as AP mode. Module's serial port connects to user device. So, control agent (Smart phone for this example) can manage and control the user device through the wireless connection with HF-LPB100U module.

#### 3.3.2. Remote Management Application




Figure 32. Remote Management Application

For this remote management application, HF-LPB100U works as STA mode and connects to Internet through wireless AP. Module configured as TCP Client and communicates with remote TCP server at Internet. Module's serial port connects to user device.

So, user device's data or sampling information can send to remote TCP server for storage or processing. Also remote TCP server can send command to control and manage the user device through the wireless network.

### 3.3.3. Transparent SerialPort Application

For this transparent serial port application, two HF-LPB100U modules connect as below figures to build up a transparent serial port connection. One HF-LPB100U works as AP mode, another HF-LPB100U works as STA mode. Make the STA device connect to AP.



Figure 33. Transparent SerialPort Application

High-Flying

## 4. AT+INSTRUCTION INTRODUCTION

### 4.1. Configuration Mode

When HF-LPB100U power up, it will default works as transparent transmission mode, then user can switch to configuration mode by serial port command. HF-LPB100U UART default parameters setting as below figure,




Figure 34. HF-LPB100UDefaultUARTPort Parameters

In configuration mode, user can setting the module through AT+instruction set, which cover all web page setting function.

#### 4.1.1. Switch to Configuration Mode

Two steps to finish switching from transparent transmission mode to configuration mode.

- **UART input “+++”, after module receive “+++”, and feedback “a” as confirmation.**
- **UART input “a”, after module receive “a” and feedback “+ok” to go into AT+instruction set configuration mode.**





Figure 35. Switch to Configuration Mode

#### Notes:

1. When user input “+++” (No “Enter” key required), the UART port will display feedback information “a”, and not display input information“+++” as above UART display.

2. Any other input or wrong step to UART port will cause the module still works as original mode (transparent transmission).
3. “+++” and “a” should be input in a certain period of time to make the module switch to configuration mode. Like the following sequence.



## 4.2. AT+Instruction Set Overview

User can input AT+Instruction through hyper terminal or other serial debug terminal, also can program the AT+Instruction to script. User can also input “AT+H” to list all AT+Instruction and description to start.

```

AT+H
+ok

AT+: NoNE command, reply "+ok".
AT+ASWD: Set/Query WiFi configuration code.
AT+E: Echo ON/off, to turn on/off command line echo function.
AT+ENTM: Goto Through MODE.
AT+NETP: Set/Get the Net Protocol Parameters.
AT+UART: Set/Get the UART Parameters.
AT+UARTF: Enable/disable UART AutoFrame function.
AT+UARTFT: Set/Get time of UART AutoFrame.
AT+UARTFL: Set/Get frame length of UART AutoFrame.
AT+UARTTE: Set/Query UART free-frame triggerf time between two byte.
AT+PING: General PING command.
AT+WAP: Set/Get the AP parameters.
AT+WAKEY: Set/Get the Security Parameters of WIFI AP Mode.
AT+MMODE: Set/Get the WIFI Operation Mode (AP or STA).
AT+WSKEY: Set/Get the Security Parameters of WIFI STA Mode.
AT+WSSID: Set/Get the AP's SSID of WIFI STA Mode.
AT+WSLK: Get Link status of the Module (only for STA Mode).
AT+WSLQ: Get Link quality of the Module (only for STA Mode).
AT+WSCAN: Get The AP site Survey (only for STA Mode).
AT+WEBU: Set/Get the Login Parameters of WEB page.
AT+TCPPLK: Get The state of TCP link.
AT+TCPITO: Set/Get TCP time out.
AT+TCPDIS: Connect/Dis-connect the TCP client link
AT+RECV: Recv data from UART
AT+SEND: Send data to UART
AT+WANN: Set/Get The WAN setting if in STA mode.
AT+LANN: Set/Get The LAN setting if in ADHOC mode.
AT+RELD: Reload the default setting and reboot.
AT+RLDEN: Put on/off the GPIO12.
AT+Z: Reset the Module.
AT+MID: Get The Module ID.
AT+VER: Get application version.
AT+H: Help.

```

Figure 36. “AT+H” Instruction for Help

### 4.2.1. Instruction Syntax Format

AT+Instruction protocol is based on the instruction of ASCII command style, the description of syntax format as follow.

- **Format Description**
  - <>: Means the parts must be included
  - [ ]: Means the optional part
- **Command Message**

**AT+<CMD>[op][para-1,para-2,para-3,para-4...]<CR>**

- AT+: Prefix of command message;
- CMD: Command string;
- [op]: Symbol of command operator,
  - ◆ “=” : The command requires parameters input;
  - ◆ “NULL”: Query the current command parameters setting;
- [para-n]: Parameters input for setting if required;
- <CR>: “Enter” Key, it's 0x0a or 0x0d in ASCII;

**Notes:** When input AT+Instruction, “AT+<CMD>” character will display capital letter automatic and otherparts will not change as you input.

➤ **Response Message**

**+<RSP>[op] [para-1,para-2,para-3,para-4...]<CR><LF><CR><LF>**

- +: Prefix of response message;
- RSP: Response string;
  - ◆ “ok” : Success
  - ◆ “ERR”: Failure
- [op] :=
- [para-n]: Parameters if query command or Error code when error happened;
- <CR>: ASCII 0xd;
- <LF>: ASCII 0xa;

➤ **Error Code**

Table 9 Error Code Description

Error Code	Description
-1	Invalid Command Format
-2	Invalid Command
-3	Invalid Operation Symbol
-4	Invalid Parameter
-5	Operation Not Permitted

#### 4.2.2. AT+Instruction Set

Table 10AT+Instruction Set List

Instruction	Description
<null>	NULL
<b>Management Instruction Set</b>	
E	Open/Close show back function
WMODE	Set/Query Wi-Fi work mode (AP/STA/APSTA)
ENTM	Set module into transparent transition mode
TMODE	Set/Query module data transfer mode

<b>Instruction</b>	<b>Description</b>
MID	Query moduleID information
VER	Query module software version information
LVER	Query module detailed software version
FWSZ	Query Wi-Fi driver size
RELD	Restore to factory default setting
FCLR	Erase factory setting
Z	Re-start module
H	Help
<b>Configure Parameters Instruction Set</b>	
CFGRD	Batch Read User Configure Parameters
CFGWR	Batch Write Configure Parameters
CFGFR	Batch Read Factory Default Configure Parameters
CFGTF	Copy User Parameters to Factory Default Parameters
<b>UART Instruction Set</b>	
UART	Set/Query serial port parameters
UARTFT	Open/Close UART auto-frame function
UARTFTT	Set/Query UART auto-frame trigger time
UARTFL	Set/Query UART auto-frame trigger length
UARTTE	Set/Query UART free-frame trigger time between two bytes
<b>Command Mode Set</b>	
SEND	Send Data at Command Mode
RECV	Receive Data at Command Mode
<b>Network Instruction Set</b>	
PING	Network "Ping" Instruction
NETP	Set/Query network protocol parameters
MAXSK	Set/Query TCP Client connection number
TCPLK	Query if TCP link already build-up
TCPTO	Set/Query TCP timeout
TCPDIS	Open/Close TCP link
SOCKB	Set/Query SOCKB parameters
TCPDISB	Open/Close SOCKB TCP link
TCPTOB	Set/Query SOCKB TCP timeout
TCPLKB	Query if SOCKB TCP link already build-up
UDPLCPT	Set/Query UDP local port
SNDB	Send data to SOCKB in Command Mode
RCVB	Receive data from SOCKB in Command Mode
<b>Wi-Fi STA Instruction Set (Effective when module works as STA)</b>	
WSKEY	Set/Query STA security parameters
WSSID	Set/Query associated AP SSID parameters
WANN	Set/Query STA's network parameters
WSMAC	Set/Query STA's MAC address
WSLK	Query STA Wi-Fi link status
WSLQ	Query STA Wi-Fi signal strength
WSCAN	Scan AP
WSDNS	Set/Query STA's Static DNS server address
<b>Wi-Fi AP Instruction Set (Effective when module works as AP)</b>	
LANN	Set/Query AP's network parameters
WAP	Set/Query AP Wi-Fi parameters
WAKEY	Set/Query AP security parameters

<b>Instruction</b>	<b>Description</b>
WAMAC	Set/Query AP MAC address
WADHCP	Set/Query AP DHCP Server status
WADMN	Set/Query AP webpage domain name
WALK	Query MAC address of STA device connecting to module AP
WALKIND	Enable/Disable indication of connection status.
<b>Webpage Management Instruction Set</b>	
PLANG	Set/Query Webpage Language Option
WEBU	Set/Query Webpage User name and Code
<b>Remote Upgrade Instruction Set</b>	
UPURL	Set/Query remote upgrade URL address
UPFILE	Set/Query remote upgrade configure file name
LOGSW	Open/Close remote upgrade log
LOGPORT	Set/Query UDP port of remote upgrade log
UPST	Start remote Application upgrade
<b>Power Management Instruction Set</b>	
MSLP	Set/Query deep sleep/standby mode parameters
<b>Network Time Set</b>	
NTPRF	Set/Query time calibration interval
NTPEN	Enable/Disable time calibration function
NTPTM	Query time
NTPSER	Set/Query NTP server IP
<b>Others Instruction Set</b>	
WRMID	Set module ID
RLDEN	Set/Query GPIO45 status
ASWD	Set/Query WiFi configuration code
MDCH	Set Wi-Fi Auto Switch Function
TXPWR	Set/Query Wi-Fi Transmit Power
SMTLK	Start SmartLink function
WPS	Start WPS function
WPSTNEN	Enable/Disable GPIO 15 WPS function
LPTIO	nRead/nLink/WPS function mapping

WIFI Config Tools don't support "CFG RD" command yet.

#### 4.2.2.1. AT+E

- Function: Open/Close show back function;
- Format:

- ◆ Set Operation

**AT+E=<status><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ status: Echo status
    - ❖ on: Open echo
    - ❖ off: Close echo

When HF-LPB100 module firstly switch from transparent transmission to configuration mode, show back status is open, input "AT+E" to close show back function, input "AT+E" again to open show back function.

#### 4.2.2.2. AT+WMODE

- Function: Set/Query Wi-Fi work mode. Setting is valid after reset;
- Format:
  - ◆ Query Operation

**AT+WMODE<CR>**

**+ok=<mode><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+WMODE=<mode><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ mode:Wi-Fi work mode
    - ❖ AP
    - ❖ STA
    - ❖ APSTA

#### 4.2.2.3. AT+ENTM

- Function: Set module into transparent transmission mode;
- Format:

**AT+ENTM<CR>**

**+ok<CR><LF><CR><LF>**

When operate this command, module switch from configuration mode to transparent transmission mode.

#### 4.2.2.4. AT+TMODE

- Function: Set/Query module data transfer mode. Setting is valid after reset.
- Format:
  - ◆ Query Operation

**AT+TMODE<CR>**

**+ok=<tmode><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+TMODE=<tmode><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ tmode: data transfer mode, include:
    - ❖ throughput: throughput mode
    - ❖ cmd: command mode
    - ❖ pwm: PWM/GPIO mode

#### 4.2.2.5. AT+MID

- Function: Query module ID information;
- Format:
  - ◆ Query Operation

**AT+MID<CR>**

**+ok=<module\_id><CR><LF><CR><LF>**

- Parameters:
  - ◆ module\_id: Module ID information;
    - ✧ HF-LPB100;

Notes: User can set this parameter through AT+WRMID.

#### 4.2.2.6. AT+VER

- Function: Query module software version information;
- Format:
  - ◆ Query Operation

**AT+VER<CR>**

**+ok=<ver><CR><LF><CR><LF>**

- Parameters:
  - ◆ ver: Module software version information;

#### 4.2.2.7. AT+LVER

- Function: Query module detailed software version information;
- Format:
  - ◆ Query Operation

**AT+LVER<CR>**

**+ok=<ver><CR><LF><CR><LF>**

- Parameters:
  - ◆ ver: Module software detailed version information;

#### 4.2.2.8. AT+FWSZ

- Function: Query Wi-Fi driver size;
- Format:
  - ◆ Query Operation

**AT+FWSZ<CR>**

**+ok=<size><CR><LF><CR><LF>**

- Parameters:
  - ◆ size: Wi-Fi driver size.(Byte)

#### 4.2.2.9. AT+RELD

- Function: module restore to factory default setting;
- Format:
  - ◆ Set Operation

**AT+RELD<CR>**

**+ok=rebooting...<CR><LF><CR><LF>**

When operate this command, module will restore to factory default setting and reboot.

#### 4.2.2.10. AT+FCLR

- Function: Erase factory setting;
- Format:
  - ◆ Query Operation

**AT+FCLR<CR>**

**+ok=<status><CR><LF><CR><LF>**

#### 4.2.2.11. AT+Z

- Function: Re-start module;
- Format:

**AT+Z<CR>**

#### 4.2.2.12. AT+H

- Function: Help;
- Format:
  - ◆ Query Operation

**AT+H<CR>**

**+ok=<command help><CR><LF><CR><LF>**

- Parameters:
  - ◆ command help: command introduction;

#### 4.2.2.13. AT+CFGRD

- Function: Batch Read User Configure Parameters;
- Format:
  - ◆ Query Operation

**AT+CFGRD<CR>**

**+ok=<config><CR><LF><CR><LF>**

- Parameters:
  - ◆ config: the first two bytes means the length of configuration parameters;

#### 4.2.2.14. AT+CFGWR

- Function: Batch Write User Configure Parameters;
- Format:
  - ◆ Set Operation

**AT+CFGWR=<config><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ config: the first two bytes means the length of configuration parameters;

#### 4.2.2.15. AT+CFGFR

- Function: Batch Read Factory Default Configure Parameters;
- Format:
  - ◆ Query Operation

**AT+CFGFR<CR>**

**+ok=<config><CR><LF><CR><LF>**

- Parameters:
  - ◆ config: the first two bytes means the length of configuration parameters;

#### 4.2.2.16. AT+CFGTF

- Function: Copy User Parameters to Factory Default Parameters;

- Format:
  - ◆ Query Operation

**AT+CFGTF<CR>****+ok=<status><CR><LF><CR><LF>**

- Parameters:
  - ◆ status: feedback operation status;

#### 4.2.2.17. AT+UART

- Function: Set/Query serial port parameters. Setting is valid after reset.
- Format:
  - ◆ Query Operation

**AT+UART<CR>****+ok=<baudrate,data\_bits,stop\_bit,parity><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+UART=<baudrate,data\_bits,stop\_bit,parity><CR>****+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ baudrate:
    - ❖ 300,600,1200,1800,2400,4800,9600,19200,38400,57600,115200,230400,380400,460800,921600
  - ◆ data\_bits:
    - ❖ 8
  - ◆ stop\_bits:
    - ❖ 1,2
  - ◆ parity:
    - ❖ NONE
    - ❖ EVEN
    - ❖ ODD
  - ◆ Flowctrl: (CTSRTS)
    - ❖ NFC: No hardware flow control
    - ❖ FC: hardware flow control

#### 4.2.2.18. AT+UARTF

- Function: Open/Close UART auto-frame function;
- Format:
  - ◆ Query Operation

**AT+UARTF<CR>****+ok=<para><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+UARTF=<para><CR>****+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ para:
    - ❖ disable - Close auto-frame function;

❖ enable - Open auto-frame function;

#### 4.2.2.19. AT+UARTFT

- Function: Set/Query UART auto-frame trigger time;
- Format:
  - ◆ Query Operation

**AT+UARTFT<CR>**

**+ok=<time><CR><LF><CR><LF>**

◆ Set Operation

**AT+UARTFT=<time ><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ time: Range 100 ~10000; Unit: ms. Auto-frame trigger time

#### 4.2.2.20. AT+UARTFL

- Function: Set/Query UART auto-frame trigger length;
- Format:
  - ◆ Query Operation

**AT+UARTFL<CR>**

**+ok=<len><CR><LF><CR><LF>**

◆ Set Operation

**AT+UARTFL=<len><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ len: Range 8 ~1000; Unit: Byte. Auto-frame trigger length;

#### 4.2.2.21. AT+UARTTE

- Function: Set/Query UART free-frame trigger time between two bytes;
- Format:
  - ◆ Query Operation

**AT+UARTTE<CR>**

**+ok=<mode><CR><LF><CR><LF>**

◆ Set Operation

**AT+UARTTE=<mode><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ mode:
    - ❖ fast: free-frame trigger time between two bytes is 10ms;
    - ❖ normal: free-frame trigger time between two bytes is 50ms;

#### 4.2.2.22. AT+SEND

- Function: Send Data to SOCKA at Command Mode.
- Format:

**AT+SEND=<data\_lenth><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ data\_lenth: Lenth of send data. Range: 0~1000 Byte

The UART port will wait 3 seconds for input after this command is sent OK. The data received from UART port is sent to SOCKA. If the interval of two bytes is more than 10ms, the data will be sent instantly.

#### 4.2.2.23. AT+RECV

- Function: Receive Data from SOCKA at Command Mode.
- Format:

```
AT+RECV=<data_lenth><CR>
+ok=<data_lenth, data_content><CR><LF><CR><LF>
```

- Parameters:
  - ◆ data\_lenth: Lenth of receive data. Range: 0~1000 Byte
  - ◆ data\_content: contents of receive data.

If not receive any data in 3 second, then feedback +ok=0.

#### 4.2.2.24. AT+PING

- Function: Network “PING” Instruction.
- Format:
  - ◆ Set Operation

```
AT+PING=<IP_address><CR>
+ok=<sta><CR><LF><CR><LF>
```

- Parameters:
  - ◆ sta: feedback result
    - ◊ Success
    - ◊ Timeout
    - ◊ Unknown host

#### 4.2.2.25. AT+NETP

- Function: Set/Query network protocol parameters,Setting is valid after reset.
- Format:
  - ◆ Query Operation

```
AT+NETP<CR>
+ok=<protocol,CS,port,IP><CR><LF><CR><LF>
      ◆ Set Operation
```

```
AT+NETP=<protocol,CS,port,IP><CR>
+ok<CR><LF><CR><LF>
```

- Parameters:
  - ◆ protocol:
    - ◊ TCP
    - ◊ UDP
  - ◆ CS: Network mode:
    - ◊ SERVER
    - ◊ CLIENT

- ◆ Port: protocol port ID: Decimal digit and less than 65535
- ◆ IP: Server's IP address when module set as client

If set as UDP SERVER, the module will save the IP address and port of the latest UDP packet received. The data will be sent to the saved IP address and port. If the module hasn't saved any IP address and port when power up. The data will be sent to the IP address and port which is set by this command.

If set as UDP,CLIENT, the data will always be sent to the IP address and port set by this command.

#### 4.2.2.26. AT+MAXSK

- Function: Set/ Query TCP Client connection number.
- Format:
  - ◆ Query Operation

**AT+MAXSK<CR>**

**+ok=<num><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+MAXSK=<num><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ num: TCP Client connection number. Range: 1~5. 5 is the default value it means when the module work in TCP server , it accepts max 5 TCP client connect to it.

#### 4.2.2.27. AT+TCPLK

- Function: Query if TCP link already build-up;
- Format:

**AT+TCPLK<CR>**

**+ok=<sta><CR><LF><CR><LF>**

- Parameters:
  - ◆ sta.: if module already setup TCP link;
    - ◊ on: TCP link setup;
    - ◊ off: TCP link not setup;

#### 4.2.2.28. AT+TCPPTO

- Function: Set/Query TCP timeout; Setting is valid after reset.
- Format:
  - ◆ Query Operation

**AT+TCPPTO<CR>**

**+ok=<time><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+TCPPTO=<time ><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ time: TCP timeout time.
    - ◊ <= 600, (600s);

- ❖ >=0, (0 means no timeout);
- ❖ Default, 300s;

Module begin to count time when TCP channel don't receive any data, clear the time counter when TCP channel receive any data. If the time counter reaches the TCPTO, the TCP channel will be broken. If the module work in TCP Client, it will connect the TCP server instantly and when the module work in TCP Server, the TCP client device should make the connection itself.

#### 4.2.2.29. AT+TCPDIS

- Function: Open/Close TCP link;
- Format:
  - ◆ Query Operation

**AT+TCPDIS<CR>**

**+ok=<sta><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+TCPDIS=<on/off><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:

When query, sta.: Feedback if TCP Client can be linked,

- ❖ On, TCP link close
- ❖ off, TCP link open

When setting, "off" means close TCP link. After finish this command, module disconnect TCP link and not connect again. "On" means open TCP link. After finish this command, module reconnect TCP server right away.

#### 4.2.2.30. AT+SOCKB

- Function: Set/Query SOCKB parameters. Setting is valid after reset.
- Format:
  - ◆ Query Operation

**AT+SOCKB<CR>**

**+ok=<protocol,port,IP><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+SOCKB=<protocol,port,IP><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:

- ◆ Protocol: Protocol type:
  - ❖ TCP: Only for TCP Client
  - ❖ UDP: UDP Client
  - ❖ UDPS: UDP Server
- ◆ Port: Protocol Port in decimal, less than 65535
- ◆ IP: Destination IP address, domain name is supported

If set as UDP SERVER, the module will save the IP address and port of the latest UDP packet received. The data will be sent to the saved IP address and port. If the module hasn't

saved any IP address and port when power up. The data will be sent to the IP address and port which is set by this command.

If set as UDP,CLIENT, the data will always be sent to the IP address and port set by this command.

#### 4.2.2.31. AT+TCPDISB

- Function: Open/Close SOCKB connection
- Format:
  - ◆ Query Operation

**AT+TCPDISB<CR>**

**+ok=<sta><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+TCPDISB=<on/off><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:

When setting, “off” means close TCP link. After finish this command, module disconnect TCP link and not connect again. “On” means open TCP link. After finish this command, module re-connect TCP server right away.

#### 4.2.2.32. AT+TCPTOB

- Function: Set/Query Operation SOCKB timeout. Setting is valid after reset.
- Format:
  - ◆ Query Operation

**AT+TCPTOB<CR>**

**+ok=<time><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+TCPTOB=<time ><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters

- ◆ Time: TCP timeout
  - ◊ <= 600:600s
  - ◊ >=0:0 means no timeout
  - ◊ Default:300s

The module will not connect SOCKB after TCP timeout. The module will make connection after another “TCPDISB” command.

#### 4.2.2.33. AT+TCPLKB

- Function:QuerySOCKB connection status
- Format:

**AT+TCPLKB<CR>**

**+ok=<sta><CR><LF><CR><LF>**

- Parameters:

- ◆ sta.: SOCKB connection status
  - ◊ on: TCP connected

- ❖ off: TCP disconnected

#### 4.2.2.34. AT+UDPLCPT

- Function: Set/Query UDP local port of Socket A and Socket B..
- Format:
  - ◆ Query Operation

**AT+UDPLCPT<CR>**

**+ok=<porta,portb><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+UDPLCPT=<porta,portb><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters
  - ◆ porta: UDP local port of Socket A, 0: do not fix local UDP port.
  - ◆ porta: UDP local port of Socket B, 0: do not fix local UDP port.

#### 4.2.2.35. AT+SNDB

- Function: Send datas to SOCKB at Command Mode
- Format:

**AT+SNDB=<data\_lenth><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ data\_lenth: Lenth of send data. Range: 0~1000 Byte

The UART port will wait 3 seconds for input after this command is sent OK. The data received from UART port is sent to SOCKB. If the interval of two bytes is more than 10ms, the data will be sent instantly.

#### 4.2.2.36. AT+RCVB

- Function: Receive datas from SOCKB at Command Mode
- Format:

**AT+RCVB=<data\_lenth><CR>**

**+ok=<data\_lenth, data\_content><CR><LF><CR><LF>**

- Parameters:
  - ◆ data\_lenth: Lenth of receive data. Range: 0~1000 Byte
  - ◆ data\_content: contents of receive data.

If not receive any data in 3 second, then feedback +ok=0.

#### 4.2.2.37. AT+WSSID

- Function: Set/Query Wi-Fi associated AP SSID parameters. Setting is valid after reset.
- Format:
  - ◆ Query Operation

**AT+WSSID<CR>**

**+ok=<ap'ssid><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+WSSID=<ap'ssid><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ ap'ssid: AP's SSID (Within 32 character);

#### 4.2.2.38. AT+WSKEY

- Function: Set/Query STA security parameters. Setting is valid after reset.
- Format:
  - ◆ Query Operation

**AT+WSKEY<CR>**

**+ok=<auth,encry,key><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+WSKEY=<auth,encry,key><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ auth: Authentication mode
    - ✧ OPEN
    - ✧ SHARED
    - ✧ WPAPSK
    - ✧ WPA2PSK
  - ◆ encry:Encryption algorithm
    - ✧ NONE: When "auth=OPEN", effective
    - ✧ WEP: When "auth=OPEN" or "SHARED", effective
    - ✧ TKIP: When "auth= WPAPSK" or "WPA2PSK", effective
    - ✧ AES: When "auth= WPAPSK" "WPA2PSK", effective
  - ◆ key: password, ASCII code, shall less than 64 bit and greater than 8bit

#### 4.2.2.39. AT+WANN

- Function: Set/Query STA network setting. Setting is valid after reset.
- Format:
  - ◆ Query Operation

**AT+WANN<CR>**

**+ok=<mode,address,mask,gateway><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+WANN=<mode,address,mask,gateway><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ mode: STA's IP network setting
    - ✧ static: Static IP
    - ✧ DHCP: Dynamic IP
  - ◆ address: STA IP address;
  - ◆ mask: STA subnet mask;
  - ◆ gateway: STA gateway address;

#### 4.2.2.40. AT+WSMAC

- Function: Set/Query STA MAC address parameters. Setting is valid after reset.

- Format:
  - ◆ Query Operation

**AT+WSMAC<CR>**

**+ok=<mac\_address><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+WSMAC=<code,mac\_address><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ code: security code
    - ✧ 8888 (default value)
  - ◆ Mac\_address: STA MAC address, such as ACCF23FF1234

#### 4.2.2.41. AT+WSLK

- Function: Query STA WiFi link status
- Format:
  - ◆ Query Operation

**AT+WSLK<CR>**

**+ok=<ret><CR><LF><CR><LF>**

- Parameters:
  - ◆ ret
    - ✧ "Disconnected", if no WiFi connection;
    - ✧ "AP' SSID (AP's MAC)" , if WiFi connection available;

#### 4.2.2.42. AT+WSLQ

- Function: Query STA WiFi signal strength;
- Format:
  - ◆ Query Operation

**AT+WSLQ<CR>**

**+ok=<ret><CR><LF><CR><LF>**

- Parameters:
  - ◆ ret
    - ✧ "Disconnected", if no WiFi connection;
    - ✧ "AP's WiFi signal strength" , if WiFi connection available;

#### 4.2.2.43. AT+WSCAN

- Function: Scan AP;
- Format:

**AT+WSCAN<CR>**

**+ok=<ap\_site><CR><LF><CR><LF>**

- Parameters:
  - ◆ ap\_site: AP searched;

#### 4.2.2.44. AT+WSDNS

- Function: Set/Query STA static DNS server address;
- Format:

- ◆ Query Operation

**AT+WSDNS<CR>**

**+ok=<address><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+WSDNS =<address><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:

- ◆ address: STA's DNS server address; Effective right away.

#### 4.2.2.45. AT+LANN

- Function: Set/Query AP's network parameters. Setting is valid after reset.

- Format:

- ◆ Query Operation

**AT+LANN<CR>**

**+ok=<ipaddress,mask><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+LANN=<ipaddress,mask><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:

- ◆ ipaddress: AP's IP address;
- ◆ mask: AP's net mask;

#### 4.2.2.46. AT+WAP

- Function: Set/Query AP Wi-Fi parameters. Setting is valid after reset.

- Format:

- ◆ Query Operation

**AT+WAP<CR>**

**+ok=<wifi\_mode,ssid,channel><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+WAP =<wifi\_mode,ssid,channel><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:

- ◆ wifi\_mode: Wi-Fi mode, include:
  - ❖ 11B
  - ❖ 11BG
  - ❖ 11BGN (Default Value)
- ◆ ssid:SSID at AP mode
- ◆ channel: Wi-Fi channel selection:
  - ❖ AUTO
  - ❖ CH1~CH11; (Default CH1)

#### 4.2.2.47. AT+WAKEY

- Function: Set/Query AP Wi-Fi security parameters. Setting is valid after reset.

- Format:

- ◆ Query Operation

**AT+WAKEY<CR>**

**+ok=<auth,encry,key><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+WAKEY=<auth,encry,key><CR>**

**+ok<CR><LF><CR><LF>**

■ Parameters:

- ◆ auth: include
  - ◊ OPEN
  - ◊ WPA2PSK
- ◆ Encry: include
  - ◊ NONE: When “auth=OPEN” available;
  - ◊ AES: When “auth=WPA2PSK” available;
- ◆ key: security code, ASCII code, smaller than 64bit and bigger than 8 bit;

#### 4.2.2.48. AT+WAMAC

- Function: Query AP MAC address parameters;
- Format:
  - ◆ Query Operation

**AT+WAMAC<CR>**

**+ok=<mac\_address><CR><LF><CR><LF>**

■ Parameters:

- ◆ mac\_address:AP’s MAC address;

Note: Module AP mode’s MAC address is related to STA mode’s MAC address. If user need change to others, please contact with high-flying technical people.

#### 4.2.2.49. AT+WADHCP

- Function: Set/Query AP DHCP server status; Setting is valid after reset.
- Format:
  - ◆ Query Operation

**AT+WADHCP<CR>**

**+ok=<status><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+WADHCP=<status><CR>**

**+ok<CR><LF><CR><LF>**

■ Parameters:

- ◆ status:AP’s DHCP server function status:
  - ◊ on:DHCP Server Open;
  - ◊ off:DHCP Server Close;

#### 4.2.2.50. AT+WADMN

- Function: Set/Query AP webpage domain name;
- Format:
  - ◆ Query Operation

**AT+WADMN<CR>****+ok=<domain\_name><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+WADMN=<domain\_name><CR>****+ok<CR><LF><CR><LF>**

- Parameters:

- ◆ Domain\_name: Webpage domain name (within 20 characters, can't all numbers).

**4.2.2.51. AT+WALK**

- Function: Query MAC address of STA device connecting to module AP

- Format:

- ◆ Query Operation

**AT+WALK<CR>****+ok=<status><CR><LF><CR><LF>**

- Parameters:

- ◆ status: MAC address of STA device connecting to module AP.

- ◊ No Connection: No STA device connecting to module AP;

**4.2.2.52. AT+WALKIND**

- Function: Enable/Disable indication of module APconnection status.

- Format:

- ◆ Query Operation

**AT+WALKIND<CR>****+ok=<status><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+WALKIND=<status><CR>****+ok<CR><LF><CR><LF>**

- Parameters:

- ◆ status: indication of module APconnection status.

- ◊ on: Enable nLink indication function. When STA device connecting to module AP, nLink output Low, otherwise output High.

- ◊ off: Disable nLink indication function. (**default mode**).

**4.2.2.53. AT+PLANG**

- Function: Set/Query webpage language option;

- Format:

- ◆ Query Operation

**AT+PLANG<CR>****+ok=<language><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+PLANG=<language><CR>****+ok<CR><LF><CR><LF>**

- Parameters:

- ◆ language: webpage's language

- ❖ CN: Chinese Version (Default);
- ❖ EN: English Version;

#### 4.2.2.54. AT+UPURL

- Function: Set/ Query remote upgrade URL address;
- Format:
  - ◆ Query Operation

**AT+UPURL<CR>**

**+ok=<url><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+UPURL=<url,filename><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ url: the upgrade file url address; the last charter shall be "/" (within 20 characters).
  - ◆ filename: the upgrade file name, it's optional and not saved parameter. If provide this file name here, the module will start upgrade right away;

#### 4.2.2.55. AT+UPFILE

- Function: Set/ Query remote upgrade configure file name;
- Format:
  - ◆ Query Operation

**AT+UPFILE<CR>**

**+ok=<filename><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+UPFILE=<filename><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ filename: the upgrade configure file name (within 20 characters).

#### 4.2.2.56. AT+LOGSW

- Function: Open/Close remote upgrade logfile
- Format:
  - ◆ Query Operation

**AT+LOGSW<CR>**

**+ok=<status><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+LOGSW=<status><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ status:
    - ❖ on: Open. The UART Port will print some upgrade status when upgrading. the log file will be sent to UDP Port after successfully
    - ❖ off: Close.

#### 4.2.2.57. AT+LOGPORT

- Function: Set/Query remote upgrade UDP port of log file.
- Format:
  - ◆ Query Operation

**AT+LOGPORT<CR>**

**+ok=<port><CR><LF><CR><LF>**

- ◆ Set Operation:

**AT+LOGPORT =<port><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ port: The remote upgrade UDP port of log file.

#### 4.2.2.58. AT+UPST

- Function: Start remote upgrade;
- Format:
  - ◆ Query Operation

**AT+UPST<CR>**

**+ok=<log><CR><LF><CR><LF>**

- Parameters:
  - ◆ log: feedback the status of remote upgrade;

**Note:** After execute this command, the HF-LPB100 will automatic start upgrade base on the setting of UPURL, UPFILE command contents;

#### 4.2.2.59. AT+WEBU

- Function: Set/ Query webpage user name and password; Setting is valid after reset.
- Format:
  - ◆ Query Operation

**AT+WEBU<CR>**

**+ok=<username,password><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+WEBU=<username,password><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ username: User Name, within 15 characters, not support empty.
  - ◆ password: password, within 15 characters, support empty.

#### 4.2.2.60. AT+MSLP

- Function: Set/Query deep sleep/standby mode parameters;
- Format:
  - ◆ Query Operation

**AT+MSLP<CR>**

**+ok=<ret><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+MSLP=<mode><CR><LF><CR><LF>**

- Parameters:
  - ◆ ret:
    - ◇ normal: normal mode (100ms interval)
  - ◆ mode:
    - ◇ normal: normal mode (100ms interval)
    - ◇ standby: WiFi shut down mode. **(Reserved)**

#### 4.2.2.61. AT+NTPRF

- Function: Set /Query time calibration interval
- Format:
  - ◆ Query Operation

**AT+NTPRF<CR>**

**+ok=<num><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+NTPRF=<num><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ num: time calibration interval, range:0~720, default:30 minutes, 10 minutes for each step, set 0 means no time calibration automatically.

#### 4.2.2.62. AT+NTPEN

- Function: Enable/Disable time calibration function. Setting is valid after reset.
- Format:
  - ◆ Query Operation

**AT+NTPEN<CR>**

**+ok=<status><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+NTPEN=<status><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ status: status of time calibration
    - on: Enable time calibration
    - off: Disable time calibration

#### 4.2.2.63. AT+NTPTM

- Function: Query network time
- Format:
  - ◆ Query Operation

**AT+NTPTM<CR>**

**+ok=<time><CR><LF><CR><LF>**

- Parameters:
  - ◆ time: networ time, for example: 2013-10-9 16:10:42 Wed, if it shows Not Available means that the time calibration function is not enabled or the module doesn't connect to the internet.

#### 4.2.2.64. AT+NTPSER

- Function: Set/QueryNTP server IP address..
- Format:
  - ◆ Query Operation

**AT+NTPSER<CR>**

**+ok=<ipaddress><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+NTPSER=<ipaddress><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ ipaddress: NTP network server IP address, 61.164.36.105(default value).

#### 4.2.2.65. AT+WRMID

- Function: Set module ID;
- Format:
  - ◆ Set Operation

**AT+WRMID=<wrmid><CR><LF><CR><LF>**

- Parameters:
  - ◆ wrmid: set module's ID (within 20 characters).

#### 4.2.2.66. AT+RLDEN

- Function: Set/Query nReload Pin function status
- Format:
  - ◆ Query Operation

**AT+RLDEN<CR>**

**+ok=<status><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+RLDEN=<status><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ status: The status of module'snReload pin function
    - ❖ on: nReloadpin function is enabled.
    - ❖ off: nReload pin function is disabled

#### 4.2.2.67. AT+ASWD

- Function: Set/Query WiFi Configuration Password;
- Format:
  - ◆ Query Operation

**AT+ASWD<CR>**

**+ok=<aswd><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+ASWD=<aswd><CR><LF><CR><LF>**

- Parameters:
  - ◆ aswd: WiFi Configuration Password (within 20 characters).

#### 4.2.2.68. AT+MDCH

- Function: Set Wi-Fi Auto Switch Function. Setting is valid after reset.

- Format:

- ◆ Query Operation

**AT+MDCH<CR>**

**+ok=<mode><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+MDCH=<mode><CR><LF><CR><LF>**

- Parameters:

- ◆ mode: Wi-Fi Auto Switch Mode

- ◆ off: Disable Wi-Fi auto switch.
- ◆ on: Enable Wi-Fi auto switch. When the module(STA mode) fail to connect to router, it will switch to AP mode itself in one minute.
- ◆ auto: Enable Wi-Fi auto detect function. The module will reset itself when encounter any abnormal. The default time interval is 10 minutes. (**default mode**)
- ◆ 3-120: unit: minute. Set the time interval to reset itself when abnormal.

#### 4.2.2.69. AT+TXPWR

- Function: Set/Query Wi-Fi Transmit Power, Real Transmit Power=Default Transmit Power(16dBm) – [Setting Value] \* 0.5dBm. Setting is valid after reset.

- Format:

- ◆ Query Operation

**AT+TXPWR <CR>**

**+ok=<num><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+TXPWR=<num><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:

- ◆ num: [Setting Value]. The default is 0, it can be sent from 0 ~ 24. If set to 24, the module transmit power will be at a minimum of 4dBm. Reboot to make this setting change valid. It will not restore to default if reload the module.

#### 4.2.2.70. AT+SMTLK

- Function: Start WPS function

- Format:

- ◆ Query Operation

**AT+SMTLK<CR>**

SmartLink is a One-Key config function. Config the module connecting to router easily. After start SmartLink function , the module work in SmartLink status and nLink LED is fast flashing waiting for APP to push information. See the Appendix for more details.

#### 4.2.2.71. AT+WPS

- Function: Start WPS function

- Format:
  - ◆ Query Operation

**AT+WPS<CR>**

**+ok=<status><CR><LF><CR><LF>**

- Parameters:
  - ◆ status: Start WPS Scan function. The module will reboot and work in STA mode connecting to specific router when WPS communication is OK.
  - ◆ WPS Scan Failed: WPS communication is failed.

Note: The router WPS function must be open first then enable module WPS Scan function. The module will quit WPS scan status if there is no WPS router in 5 seconds.

#### 4.2.2.72. AT+WPSBTNEN

- Function: Enable/DisableWPS function.
- Format:
  - ◆ Query Operation

**AT+WPSBTNEN<CR>**

**+ok=<status><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+WPSBTNEN =<status><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ status:
    - ◆ on: Enable WPS function
    - ◆ off: Disable WPS function.

Note: The router WPS function must be open first then enable module WPS Scan function. The module will quit WPS scan status if there is no WPS router in 5 seconds.

#### 4.2.2.73. AT+LPTIO

- Function: nReady,nLink, WPS function mapping. Setting is valid after reset.
- Format:
  - ◆ Query Operation

**AT+LPTIO<CR>**

**+ok=<status><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+LPTIO =<status><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ status: nReady,nLink, WPS function mapping.
    - ◆ off/lpb100: nReady,nLink, WPS function are mapping to HF-LPB100 corresponding pin.(Pin44, Pin43, Pin15)
    - ◆ on/lpt100: nReady,nLink, WPS function are mapping to HF-LPT100 corresponding pin.(Pin9, Pin10, Pin8)
    - ◆ lpt200: nReady,nLink, WPS function are mapping to HF-LPT200 corresponding pin.(Pin11, Pin13, Pin14)

## 5. PACKAGE INFORMATION

### 5.1. Recommended Reflow Profile




Figure 37. Reflow Soldering Profile

Table 11 Reflow Soldering Parameter

NO.	Item	Temperature (Degree)	Time(Sec)
1	Reflow Time	Time of above 220	35~55 sec
2	Peak-Temp	260 max	

- Note:**
1. Recommend to supply N2 for reflow oven.
  2. N2 atmosphere during reflow ( $O_2 < 300\text{ppm}$ )

### 5.2. Device Handling Instruction (Module IC SMT Preparation)

1. Shelf life in sealed bag: 12 months, at  $<30^\circ\text{C}$  and  $<60\%$  relative humidity (RH)
2. After bag is opened, devices that will be re-baked required after last baked with window time 168 hours.
3. Recommend to oven bake with N2 supplied
4. Recommend end to reflow oven with N2 supplied
5. Baked required with 24 hours at  $125\pm 5^\circ\text{C}$  before rework process for two modules, one is new module and two is board with module
6. Recommend to store at  $\leq 10\%$  RH with vacuum packing
7. If SMT process needs twice reflow:
  - (1) Top side SMT and reflow
  - (2) Bottom side SMT and reflow

Case 1: Wifi module mounted on top side. Need to bake when bottom side process over 168 hours window time, no need to bake within 168 hours

Case 2: Wifi module mounted on bottom side, follow normal bake rule before process

**Note:** Window time means from last bake end to next reflow start that has 168 hours space.

### 5.3. Shipping Information

#### TAPE

Size: 340\*340\*70 mm



#### BOX

Size: 340\*340\*350 mm (inside)




Figure 38. Shipping Information

#### Note:

1 tape = 500pcs

1 box = 5 tapes = 5 \* 500 pcs = 2500pcs

# APPENDIX A: HW REFERENCE DESIGN



Detailed HF-LPB100U Evaluation Board design source files, pls access High-Flying web download page or contact with High-Flying technical support people to acquire.


# APPENDIX B: CONTROL GPIO/PWM FUNCTION WITH NETWORK COMMANDS(RESERVED)

Send command data to control module's GPIO, PWM port after make network connection with TCP or UDP protocol. The status of GPIO won't be changed if the module is reset

## B.1 Network Command

### B.1.1 GPIO <channel> OUT <value>


- Function: Set GPIO Channel value temporarily..
- Parameters:
  - ◆ channel:GPIO Channel number, it can be 11、12、15、18、20、23(GPIO Pin number)
  - ◆ value:GPIO Channel value,1(high voltage), 0(low voltage)
- Return Data:
  - ◆ GPIO OK: Command successful
  - ◆ GPIO NOK: Command failed



### B.1.2 GPIO <channel> GET

- Function: Query GPIO Channel value
- Parameters:
  - ◆ channel:GPIO Channel number,it can be 11、12、15、18、20、23(GPIO Pin number)
- Return Data:
  - ◆ +ok=<value>

- value:GPIO Channel value
- ◆ GPIO NOK: Command failed




### B.1.3 GPIO <channel> SET

- Function: Save GPIO Channel setting
- Parameters:
  - ◆ channel:GPIO Channel number,it can be 11、12、15、18、20、23(GPIO Pin number)
- Return Data:
  - ◆ GPIO OK: Command successful
  - ◆ GPIO NOK: Command failed


### B.1.4 PWM <channel frequency duty>

- Function: Set PWM Channel output temporarily
- Parameters:
  - ◆ channel:PWM Channel number, it can be 11、12、18、20(GPIO Pin number)
  - ◆ frequency:PWM Channel frequency, it can be 500~60000
  - ◆ duty:PWM Channel duty, it can be 0~100.
- Return Data:
  - ◆ PWM OK: Command successful
  - ◆ PWM NOK: Command failed



### B.1.5 PWM <channel> GET

- Function: Query PWM Channel output
- Parameters:
  - ◆ channel: PWM Channel number, it can be 11、12、18、20(GPIO Pin number)
- Return Data:
  - ◆ +ok=<frequency duty>
    - frequency: PWM Channel frequency
    - duty: PWM Channel duty
  - ◆ PWM NOK: Command failed



### B.1.6 PWM <channel> SET


- Function: Save PWM Channel setting
- Parameters:
  - ◆ channel:PWM Channel number, it can be 11、12、18、20(GPIO Pin number)
- Return Data:
  - ◆ PWM OK: Command successful
  - ◆ PWM NOK: Command failed

## B.2 Hexadecimal Network Command

Send hexadecimal data to fastly read module's port status.


### B.2.1 Read all GPIO Channel

- Send Data 【0a】 :
- Return Data: 【8a <value>】
  - ◆ value:bit0、bit1 represent GPIO15、GPIO23 value.



### B.2.2 Reverse GPIO Channel value

- Send Data 【03 <channel>】 :
  - ◆ channel:GPIO Channel number, it can be 01、02(GPIO15、GPIO23)
- Return Data: 【83 <channel value>】
  - ◆ channel:GPIO Channel number, it can be 01、02(GPIO15、GPIO23)
  - ◆ value: GPIO Channel value, 0 or 1



### B.2.3 Read All PWM Channel Frequency

- Send Data: 【30】 :
- Return Data: 【b0 <value1 value2 value3 value4 value5 value6 value7 value8>】
  - ◆ value1: High byte of PWM Channel 0(GPIO11) frequency
  - ◆ value2: Low byte of PWM Channel 0(GPIO11) frequency
  - ◆ value3: High byte of PWM Channel 1(GPIO12) frequency
  - ◆ value4: Low byte of PWM Channel 1(GPIO12) frequency
  - ◆ value5: High byte of PWM Channel 2(GPIO18) frequency
  - ◆ value6: Low byte of PWM Channel 2(GPIO18) frequency
  - ◆ value7: High byte of PWM Channel 3(GPIO20) frequency
  - ◆ value8: Low byte of PWM Channel 3(GPIO20) frequency

### B.2.4 Write PWM Channel Frequency

- Send Data: 【32 <channel value1 value2>】
  - ◆ channel: PWM Channel number
  - ◆ value1: High byte of PWM Channel frequency
  - ◆ value2: Low byte of PWM Channel frequency
- Return Data: 【b2 <channel value1 value2>】
  - ◆ Channel: PWM Channel number
  - ◆ value1: High byte of PWM Channel frequency
  - ◆ value2: Low byte of PWM Channel frequency

### B.2.5 Read All PWM Channel Duty

- Send Data: 【20】 :
- Return Data: 【a0 <value1 value2 value3 value4>】
  - ◆ value1: Duty of PWM Channel 0
  - ◆ value2: Duty of PWM Channel 1
  - ◆ value3: Duty of PWM Channel 2

- ◆ value4: Duty of PWM Channel 3

#### B.2.6 Write All PWM Channel Duty

- Send Data: 【24<value1 value2 value3>】 :
- Return Data: 【a4<value1 value2 value3>】
  - ◆ value1: Duty of PWM Channel 0
  - ◆ value2: Duty of PWM Channel 1
  - ◆ value3: Duty of PWM Channel 2

#### B.2.6 Write PWM Channel Duty

- Send Data: 【22 <channel value1>】 :
  - ◆ channel:PWM Channel number
  - ◆ value1:Duty of PWM Channel
- Return Data: 【a2 <channel value1>】
  - ◆ Channel:PWM Channel number
  - ◆ value1:Duty of PWM Channel

#### B.2.7 Save Present GPIO,PWM Setting

- Send Data: 【7a】 :
- Return Data: 【fa】

#### B.2.8 Assert All GPIO Channel Low

- Send Data: 【04】 :
- Return Data: 【84 00】

#### B.2.9 Assert All GPIO Channel High

- Send Data: 【05】 :
- Return Data: 【85 01】

#### B.2.10 Read Resources of module

- Send Data: 【7e】 :
- Return Data: 【fe<value1 value2 value3>】
  - ◆ value1: Module's GPIOoutput pin number .
  - ◆ value2:Module's GPIO input pin number
  - ◆ value3:Module's PWM pin number

## APPENDIX C: HTTP PROTOCOL TRANSFER

HF-LPB100U module support http data transfer in command mode. If any detailed HTTP protocol, contact us and we may support customization.

### C.1. HTTP AT command

#### C.1.1. AT+HTTPURL

- Function: Set /Query HTTP server IP address and Port Number.
- Format:
  - ◆ Query Operation

**AT+HTTPURL<CR>**

**+ok=<IP,Port><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+HTTPURL=<IP,Port><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ IP: IP address.
  - ◆ Port: Port number.

#### C.1.2. AT+HTTPTP

- Function: Set /Query HTTP request type
- Format:
  - ◆ Query Operation

**AT+HTTPTP<CR>**

**+ok=<Type><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+HTTPTP=<Type><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ Type: GET(default) or POST.

#### C.1.3. AT+HTTPPH

- Function: Set/Query HTTP protocol header path.
- Format:
  - ◆ Query Operation

**AT+HTTPPH<CR>**

**+ok=<Path><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+HTTPPH=<Path><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:

- ◆ Path: Max length is 50 bytes.

#### C.1.4. AT+HTTPCN

- Function: Set/Query Connection of HTTP protocol header
- Format:
  - ◆ Query Operation

**AT+HTTPCN<CR>**

**+ok=<Connection><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+HTTPCN=<Connection><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ Connection: Max length is 20 bytes.

#### C.1.5. AT+HTTPUA

- Function: Set/Query User-Agent of HTTP protocol header.
- Format:
  - ◆ Query Operation

**AT+HTTPUA<CR>**

**+ok=<Parameter><CR><LF><CR><LF>**

- ◆ Set Operation

**AT+HTTPUA=<Parameter><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ Parameter: Max length is 20 bytes.

#### C.1.6. AT+HTTPDT

- Function: Send HTTP request or data.
- Format:
  - ◆ Set Operation

**AT+HTTPDT=<Data><CR>**

**+ok<CR><LF><CR><LF>**

- Parameters:
  - ◆ Data: HTTP request data, send AT+HTTPDT directly if no data to be sent.

### C.2. HTTP Example

HTTP parameter settings are as follows:

AT+HTTPURL=192.168.1.1,80	Set HTTP server address and port
AT+HTTPTP=POST	Set HTTP request type
AT+HTTPPH=/abcd	Set HTTP protocol header path
AT+HTTPCN= keep-alive	Set HTTP Connection area
AT+HTTPUA= lwig1.3.2	Set HTTP User-Agent area

If send "AT+HTTPD", the data packet will be sent as the following instance including the two new line:

```
POST /abcd HTTP/1.1
Connection:keep-alive
User-Agent:Iwip1.3.2
Content-Length:0
Host:192.168.0.127:8999
```

If send AT+HTTPDT=abcd, the data packet will be sent as the following instance:

```
POST /abcd HTTP/1.1
Connection:keep-alive
User-Agent:Iwip1.3.2
Content-Length:4
Host:192.168.0.127:8999
```

abcd

The data received from HTTP server will be output to serial port and end with "+ok".

If the module hasn't received data from HTTP server for 5 second, it will cut the TCP link with HTTP server.

## APPENDIX D:REFERENCES

### D.1. High-Flying Mass Production Tool

Download Address: [http://www.hi-flying.com/download\\_detail\\_dc/&downloadsId=07bc0a59-0a0d-4fb4-a5e5-c3403f09ab08&comp\\_stats=comp-FrontDownloads\\_list01-dc.html](http://www.hi-flying.com/download_detail_dc/&downloadsId=07bc0a59-0a0d-4fb4-a5e5-c3403f09ab08&comp_stats=comp-FrontDownloads_list01-dc.html)

### D.2. SmartLink APP Config Tool

IOS Platform : [http://www.hi-flying.com/download\\_detail\\_dc/&downloadsId=5cc0c241-77b4-48c1-bf9c-2ad2954b3b50&comp\\_stats=comp-FrontDownloads\\_list01-dc.html](http://www.hi-flying.com/download_detail_dc/&downloadsId=5cc0c241-77b4-48c1-bf9c-2ad2954b3b50&comp_stats=comp-FrontDownloads_list01-dc.html)

Android Platform:[http://www.hi-flying.com/download\\_detail\\_dc/&downloadsId=9a0d0290-477e-4184-8636-18510eaed6b1&comp\\_stats=comp-FrontDownloads\\_list01-dc.html](http://www.hi-flying.com/download_detail_dc/&downloadsId=9a0d0290-477e-4184-8636-18510eaed6b1&comp_stats=comp-FrontDownloads_list01-dc.html)

### D.3. EVK Quick Start Guide

Download Address: [http://www.hi-flying.com/download\\_detail\\_dc/&downloadsId=b545c662-4ec7-49a4-aea4-e0997f062a62&comp\\_stats=comp-FrontDownloads\\_list01-dc.html](http://www.hi-flying.com/download_detail_dc/&downloadsId=b545c662-4ec7-49a4-aea4-e0997f062a62&comp_stats=comp-FrontDownloads_list01-dc.html)

### D.4. SDK Download

Download Address: [http://www.hi-flying.com/download\\_detail\\_sdk/&downloadsId=8dd69136-6e5c-4bac-9b2d-9a1c381450a6.html](http://www.hi-flying.com/download_detail_sdk/&downloadsId=8dd69136-6e5c-4bac-9b2d-9a1c381450a6.html)

## APPENDIX E: CONTACT INFORMATION

---

**Address:** Room.511/510, Building 7, No.365, Chuanhong Road,Pudong New Area, Shanghai, China, 201202

**Web:**[www.hi-flying.com](http://www.hi-flying.com)

**Service Online:** 400-189-3108

**Sales Contact:** [sales@hi-flying.com](mailto:sales@hi-flying.com)

---

For more information about High-Flying modules, applications, and solutions, please visit our web site  
<http://www.hi-flying.com/en/>

**<END OF DOCUMENT>**

---

© Copyright High-Flying, May, 2011

The information disclosed herein is proprietary to High-Flying and is not to be used by or disclosed to unauthorized persons without the written consent of High-Flying. The recipient of this document shall respect the security status of the information.

The master of this document is stored on an electronic database and is "write-protected" and may be altered only by authorized persons at High-Flying. Viewing of the master document electronically on electronic database ensures access to the current issue. Any other copies must be regarded as uncontrolled copies.