



Controls User Manual

Zone Comfort[™]
hot water air handler
and zoned distribution system
with 4 zone iStat6 electronic
controller

Vortex Source Systems

45 Cowansview Rd.
Cambridge, Ontario
N1R 7L2

Phone: 888-781-8151
Fax: 888-670-2544
info@vortexsource.com
www.vortexsource.com

Table of Contents

Controller Basics	3
Controller Keypad	4
USER MODE	4
ADMIN MODE	4
Initial Controls Setup.....	5
Zone heating/cooling loads	5
Cooling Control Mode	6
Two-Stage Air-Conditioning	7
Cycle Timer (Pump Exerciser)	7
Freeze Protection	7
Troubleshooting	8
Table 3 User Mode	11
Table 4 Admin Mode	12

This document describes proper setup and use of the electronic controller for the Vortex Zone Comfort™ air handler with the iStat6 controller. Although the system will function when left at factory default settings, it is recommended that the installer read through this short manual in order to ensure the system has been setup to match the required heating and cooling loads and air-conditioning equipment installed, and to take advantage of the various features available. This control is capable of up to four zones though only two or three may be connected. Settings for unconnected zones can be ignored.

Controller Basics

The controller automatically adjusts blower motor speeds and engages relays for control of the system components. Through its LCD display and keypad, important system parameters may be configured and operating conditions may be monitored.

When the controller keypad has not been pressed for a few minutes, the backlight will turn off and the display may go blank. Simply press any one of the buttons to wake up the controller. By default, the controller will display a short message describing the operating status of the system. *Table 1* provides a list of the different possible status messages and their meaning. There are also a number of small icons that may appear around the edges of the display according to the current operating status. *Table 2* gives an explanation of the different icons.

Table 1 - status messages

Message	Meaning
NO CALL	System is not currently receiving a call, all functions are off.
HEATING	There is currently a call for heating
COOLING	There is currently a call for cooling
FanOnly	There is currently a call for continuous fan only and no heating or cooling
TST ERR	Thermostat error (simultaneous heating & cooling calls from zone 1). Check wiring & ensure heat/cool thermostats are used
FROZEN	Supply air is too cold, freeze protection has been activated. Compressor calls will be suspended until temperature rises and time delays are satisfied
TEST	Pressing the button on the bottom of the control will operate the fan and pump for 20 seconds to verify operation. After 20 seconds, it returns to normal.


Table 2 - display icons

Icon	Meaning
	system is in heating mode
	system is in cooling mode
	blower is running below 50%
	blower is running above 50%

Controller Keypad

By using the *option* and *setting* keys, different parameters and their current settings may be displayed and modified. Use the outer *option* keys to scroll through the available parameters, and use the inner *setting* keys to modify the parameter's current setting (if available). By default, the control will remain in 'user' mode, in which a limited selection of parameters may be accessed. By entering 'admin' mode, additional parameters may be made available. Please exercise caution while in 'admin' mode, as these settings are meant to be accessed by the experienced user or installing contractor. A description of each of the modes is found below.

iStat6 User Interface



USER MODE

This is the basic display and operating mode, in which only a limited selection of parameters may be displayed. Refer to *Table 3* for a description of each item displayed.

ADMIN MODE

This is the advanced display and configuration mode. It is intended only for the properly trained contractor. To enter 'admin' mode, press any button to illuminate the display backlight, then press and hold the two *option* (outer) buttons at the same time ('user' will be displayed at first, hold until 'admin' is displayed). You can now scroll through the display items by using the outer two *option* buttons, and adjust certain values using the inner two *setting* buttons. To return the control to 'user' mode simply wait a few minutes or press and hold both *option* buttons.

Use *Table 4* as a quick reference on the items available in this mode. Detailed descriptions on important parameters are found below.

Initial Controls Setup

When first powering up the Zone Comfort air handler during commissioning, enter 'admin' mode on the controller and adjust the following settings to match the installed equipment.

ZC_MODL – the model number of the Zone Comfort air handler. Options are ZC24, ZC30, ZC36, ZC42, ZC48, ZC60, and ZC100. This is used to set maximum airflow per zone based on damper size and total maximum airflow based on fan and motor capacity. This will be preset in the factory but should be verified by the installer. Refer to the table below.

Model	Max. Tonnage	Damper Size	Max. one zone airflow (cfm)	Max. Airflow (cfm)
ZC24, ZC30	2 1/2	8 in.	840	1200
ZC36	3	8 in.	840	1200
ZC42	3 1/2	10 in.	1440	1400
ZC48, ZC60, ZC100	5	10 in.	1440	1800

AC_CAP – the capacity (in tons) of the air-conditioning equipment. This setting impacts the amount of airflow when the system is in cooling mode. If a two-stage air-conditioner is installed, use the nominal (full capacity) tonnage. If air-conditioning is not installed, it is recommended to set this to match the maximum capacity of the Zone Comfort air handler (i.e. ZC24 = 2 tons, ZC48 = 4 tons). Refer to the table above. **Caution!:** An improper setting may result in coil freeze, excess noise or poor performance.

GFAN_PC – the amount of airflow used for a continuous fan call, as a percentage of the maximum system airflow. The default setting is 50%.

H_MIN – minimum heating airflow, as a percentage of the maximum system airflow. Default is 20%.

H_MAX – maximum heating airflow, as a percentage of the maximum system airflow. Lower settings will mean longer heating cycles and improved air distribution throughout the home. Default setting is 100%.

Zone heating/cooling loads

With the Zone Comfort system, the amount of heating and cooling airflow supplied to each individual zone may be adjusted. This may be desired on systems which have a large difference in actual heating & cooling loads for each zone. Since many basements have a much lower cooling load, for example, it may make sense to

decrease the basement zone's cooling airflow in order to increase cycle times and improve comfort. Modify the variables below to adjust these airflows. Ideally, zones should be of similar size or capacity.

Z1_HL, Z2_HL, Z3_HL, Z4_HL – Heating loads for each zone, as a percentage of maximum heating airflow (**H_MAX**). Default for each is 50%. The total for all zones may exceed 100%. Note that a single zone calling will receive at least **H_MIN**. Multiple zones calling will not exceed **H_MAX**.

Z1_CL, Z2_CL, Z3_CL, Z4_CL – Cooling loads for each zone, as a percentage of maximum cooling airflow (based on air-conditioner capacity **AC_CAP**). Default for each is 50%. The total for all zones may exceed 100%. Note that a single zone calling will receive at least the calculated minimum of **MIN_TON** (270 cfm default) x **AC_CAP** for single stage AC condensers and (**MIN_TON-AC2_ADJ** (270-90 cfm default)) x **AC_CAP** for 2-stage AC condensers. Multiple zones calling will not exceed **MAX_TON** (420 cfm default) x **AC_CAP**.

D8_MAX, D10_MAX – Set the maximum airflow in cfm for 8 inch and 10 inch dampers respectively. **D8_MAX** is used by ZC24, ZC30 and ZC36. **D10_MAX** is used by the larger models. They should not be adjusted unless there are operational issues that cannot be fixed with the other settings. Consult the factory.

Cooling Control Mode

There are two modes of operation available for controlling cooling airflow: “fixed” and “auto”. Descriptions for each mode are found below.

C_SPD – Cooling speed control mode, options are “fixed” and “auto”. Controls are in “fixed” mode by default. Note that in either mode, the cooling airflow will always be maintained between **MIN_TON** 270 (minimum default) and **MAX_TON** 420 cfm per ton (maximum default) of air-conditioner capacity (**AC_CAP**).

In “fixed” mode, the cooling airflow will operate similar to that used in heating mode, adjusting based on the zones currently calling for cooling and the corresponding settings for zone cooling loads (**Z1_CL, Z2_CL, Z3_CL** and **Z4_CL**).

In “auto” mode, the airflow will adjust to maintain the supply air temperature at the chosen cooling setpoint (**COOL_SP**). This mode can provide better control of indoor comfort, helping to ensure adequate dehumidification is taking place. **Caution:** for proper operation, the supply air temperature sensor must be installed downstream of the cooling coil and measuring well-mixed cold air.

COOL_SP – The cooling setpoint temperature for auto cooling mode. Default setting is 11°C (52°F). Lower setpoint temperatures will lead to lower airflow, increased dehumidification and comfort, but may decrease overall cooling capacity and efficiency.

PID_PROP, PID_INT, PID_DB, PID_RAMP – These settings affect the proportional,

integral, deadband, and ramp rate used for the P.I.D. cooling speed control when in auto mode. It is recommended that these settings only be changed by someone who has a firm understanding of P.I.D. control schemes and only if the response rate of the fan is unsatisfactory. Contact Vortex if you believe there's an issue with these settings.

MIN_TON, MAX_TON – These settings affect the minimum and maximum airflow respectively. They should not be adjusted unless there are operational issues in cooling mode. Consult the factory.

Two-Stage Air-Conditioning

An output is available on the low-voltage terminal strip for the control of a two-stage air-conditioner. When a cooling call is present, second stage will be activated in **fixed** mode if the cooling demand exceeds **AC2_MIN**, determined based on the current zone calls and their respective cooling loads **Z1_CL**, **Z2_CL**, **Z3_CL** and **Z4_CL**. If in **auto** mode, second stage will be activated if the number of current cooling calls (dampers open) equals or exceeds **AC2_DMP**.

AC2_ADJ – Adjusts the air flow down when the first stage of a two-stage AC system is active. The default is 90 cfm/ton which is approx. a 1/3 reduction in airflow (most 2-stage condensers reduce capacity by 1/3 during first stage). This should not be adjusted unless there are operational issues in cooling mode. Consult the factory.

AC2_MIN – In **fixed** mode, the cooling airflow at which 2nd stage is activated, set by default to 80%. Decreasing this value will cause 2nd stage to be activated sooner, leading to full capacity and colder supply air temperatures.

AC2_DMP – In **auto** mode, the minimum number of dampers open at which 2nd stage is activated, set by default set to 2 dampers open (any 2 zones calling). Decreasing this value will cause 2nd stage to be activated sooner, leading to full cooling capacity and higher airflow.

Note that higher values increases run time in first stage which will improve efficiency and may reduce airflow noise.

Cycle Timer (Pump Exerciser)

The Zone Comfort includes an optional cycle timer or pump exerciser feature which may need to be enabled depending on the hot water source and local regulations. When enabled, the cycle timer will run the heating circulating pump for 30 seconds every 24 hours.

CT_MODE – Cycle timer mode. Set to 1 to enable, 0 to disable. Cycle timer is disabled by default.

Freeze Protection

In order to prevent the heat exchanger coils from freezing during cooling, the Zone

Comfort includes a freeze protection feature. If the measured supply air temperature drops below the freeze protection temperature **FRZ_TMP**, the signal to the air-conditioner contactor is interrupted. In order to prevent short-cycling of the compressor, this feature includes two settable delay intervals: **FRZ_DLY** sets the amount of time the supply air temperature has to remain below **FRZ_TMP** before the alarm is triggered; and **FRZ_DLY2** sets the amount of time until the compressor is allowed to come back on, once the supply air temperature has returned to above **FRZ_TMP**. **Note:** This feature will only turn off the AC compressor signal. It will not protect the home or air handler from freezing house temperatures or improper fresh air connections such as from a heat recovery ventilator.

FRZ_TMP – The freeze protection setpoint temperature. Default value is 3 °C. Lowering this value will decrease sensitivity of the freeze protection feature.

FRZ_DLY – Amount of time (in minutes) to wait before acknowledging a freeze protection condition. Default setting is 3 minutes. Increasing this value will decrease sensitivity of the freeze protection feature.

FRZ_DLY2 – Amount of time in minutes to wait before bringing the A/C compressor back on, once the measured supply air temperature has returned to a safe value. Default setting is 2 minutes.

Troubleshooting

Warning: The homeowner can diagnose many issues from the main controller on the front of the air handler but any diagnostics or servicing inside the air handler (blower compartment) should only be performed by a qualified service person. High voltages are present.

No Display – If pushing one of the four front buttons does not refresh the display, there may be no power to the air handler, or the transformer has failed or the controller has failed.

No Heating – Note the controller display icons: flame = heating mode. If the flame icon is not displayed, heating calls on zones 2,3 and 4 are ignored. A brief heating call from zone 1 is required to switch the controller to heating mode. If in doubt, turn the heat on all zones.


Test Mode – pushing the button on the bottom (underneath) of the control will run the pump and fan for 20 seconds. Damper position will not change.

No Cooling - Note the controller display icons: snowflake = cooling mode. If the snowflake is not displayed, cooling calls on zones 2, 3 and 4 are ignored. A brief cooling call from zone 1 is required to switch the controller to cooling mode. If in doubt, turn the cooling on all zones.

Thermostat calls – The status screen (default) will show any calls detected from any thermostat including continuous fan ON (Table 1). Using the outer keys, the user can scroll through the screens to see individual thermostat calls and fan speed (Table 3).

If a thermostat is calling but not detected by the control:

1. Check the thermostat and its connections
2. Check thermostat wiring at the thermostat and air handler.
3. Check the 8gang relay indicator lights.




W1, Y1 and G1 are connected directly from the thermostat terminal strip. W2, Y2, W3, Y3, W4 and Y4 are filtered through the 24vac relay (left) allowing only heating calls during heating mode and only cooling calls during cooling mode. The 8gang relay converts 24vac thermostat signals to digital signals for input to the iStat6 controller. If the lights are on but the controller does not respond, the problem is the wiring to the control or the control has failed.

Blower motor never fully stops, even with no demand signal

Ensure the thermostats have been wired according to the Zone Comfort Installation Instructions.

Ensure the blower motor speed control board has a jumper installed across the terminals labeled “P”. The motor speed control board and the jumpers are shown below.



Note: The green signal light of the EVO motor control flashes according to its speed output to the motor. Ex. 5 long 3 short blinks = 53%

Tip: The fan can be tested from 0-100% by placing the primary thermostat in FAN ON with no other calls on any zone. Then, adjust **GFAN_PC** up and down within ADMIN mode.

Pump Does Not Run – For any heating call, the controller provides a 12vdc output to the

pump relay. The relay runs the pump (120vac) and provides a 24vac signal to the 8gang relay board. If the light is on at the 8 gang relay, the wiring to the pump or the pump itself is the problem.

Air Conditioning Does Not Run – For any cooling call, the controller provides a 24vac signal directly to the Y1out connection to the A/C condenser and also to the 8gang relay indicator light. If the light is on, the problem is not in the air handler. If the light is off, the problem would be wiring or controller.

Second Stage Air Conditioning Does Not Run – Check settings in Table 4. For second stage, the controller provides a 12vdc output to the 2nd stage relay. The relay provides 24vac to the terminal strip Y2out.

Dampers get stuck when changing position

When a zone damper tries to change position under high airflow or static pressure, it may become stuck in a half-open position. The controller provides a delay on damper closing in order to prevent this from occurring. If this is an issue, increase the delay setting (**DMP_DLY**) in 'admin' mode (default delay is 20 seconds). Also, check that the following values are correct in the program: **ZC_MODL**, **AC_CAP**, **H_MIN**, **MIN_TON**, **D8_MAX**, **D10_MAX** and all zone settings **Z1_HL**, **Z1_CL** etc.

Too much airflow to a single zone, causing noise

This can occur due to undersized ductwork or improper setup of the air handler zone heating/cooling loads. The problem may be fixed by reducing the amount of airflow designated to the problem zone. See above section on zone heating/ cooling loads to adjust the airflow used for each zone. Note that **H_MIN**, **MIN_TON** and **AC_CAP** will override zone settings. Installing a 2-stage air conditioner will reduce the minimum cooling airflow for single zones.

Alarm message “TST ERR”

There is a simultaneous call for heating and cooling on zone one, indicating an error with thermostat wiring or setup. Ensure that all the zone thermostats are wired as per the Zone Comfort Installation Instructions, and are configured for 1 heat / 1 cool systems. Note that when zone one has set the system in heating mode, cooling calls on all other zones are ignored. Likewise, when zone one has set the system in cooling mode, heating calls on all other zones are ignored.

Not enough humidity removal in cooling mode

The Zone Comfort air handler controls humidity during cooling through use of the “auto” cooling speed mode (set **C_SPD** to “auto”). See the Cooling Control Mode section above.

Supply or return air temperature (SA_TMP or RA_TMP) reads -50 °C

This indicates the supply air temperature sensor is not properly connected to the controller. Ensure that the sensor is connected as per the wiring diagram found in the Zone Comfort Installation Instructions and that no wires have become loose.

RA_TMP is not used and can be ignored. A failed supply air temperature sensor will put the system into freeze protection.

Freeze protection errors (alarm message “FROZEN”)

This usually occurs when there is inadequate airflow for a given air-conditioner.

- Ensure that the air filter is not plugged and all ductwork is open
- Ensure the setting **ZC_MODL** matches the air handler model and **AC_CAP** has been selected to match the installed air-conditioner capacity
- Ensure supply air temperature sensor is located after cooling coil and in the supply air stream, not touching the cooling coil, heat source, plumbing, etc.
- Ensure the cooling setpoint temperature **COOL_SP** is not set too low
- Decrease sensitivity of the freeze protection feature (see Freeze Protection above). Set **FRZ_TMP** lower and/or **FRZ_DLY** higher.

Table 3 User Mode (default)

Line 1	Line 2	Set.	Type	Description	Default
ZoneComf	#####	D	Display	Display status of system	NO CALL
SA_TMP	####.# C	D	Input	Supply air temperature	
RA_TMP	####.# C	D	Input	Return air temperature (display only, not used in calcs.)	
FAN_PC	##### %	D	calc	Convert FAN_CFM into percentage 0-100	
Z1_H	(0)Off/(1)On	D	Input	Zone 1 thermostat heating input	
Z1_C	(0)Off/(1)On	D	Input	Zone 1 thermostat cooling input	
Z2_CALL	(0)Off/(1)On	D	Input	Zone 2 valid thermostat call	
Z3_CALL	(0)Off/(1)On	D	Input	Zone 3 valid thermostat call	
Z4_CALL	(0)Off/(1)On	D	Input	Zone 4 valid thermostat call	
ZC4	###.## REV	D	Display	Program name and revision number	3.00

* note: "D" in set. indicates variable is for display only and is not settable

Table 4 Admin Mode

Line 1	Line 2	Set.	Type	Description	Default
ZoneComf	####	D	Display	Display status of system	NO CALL
ZC_MODL	####		Text Setting	Set the Zone Comfort Model	ZC24
AC_CAP	####		Text Setting	Capacity of air-conditioner in tons, select from available choices.	1
SA_TMP	####.# C	D	Input	Supply air temperature	
RA_TMP	####.# C	D	Input	Return air temp. (display only, not used in calcs.)	
FAN_PC	#### %	D	calc	Convert FAN_CFM into percentage 0-100	
GFAN_PC	#### %		Setting	Continuous Fan airflow as a percent of maximum.	50
H_MIN	#### %		Setting	Setpoint of minimum heating airflow as a percentage	25
H_MAX	#### %		Setting	Setpoint of maximum heating airflow as a percentage	100
Z1_HL	#### %		Setting	Zone 1 heating speed percentage	50
Z1_CL	#### %		Setting	Zone 1 cooling speed percentage	50
Z2_HL	#### %		Setting	Zone 2 heating speed percentage	50
Z2_CL	#### %		Setting	Zone 2 cooling speed percentage	50
Z3_HL	#### %		Setting	Zone 3 heating speed percentage	50
Z3_CL	#### %		Setting	Zone 3 cooling speed percentage	50
Z4_HL	#### %		Setting	Zone 4 heating speed percentage	50
Z4_CL	#### %		Setting	Zone 4 cooling speed percentage	50
Z1_H	(0)Off/(1)On	D	Input	Zone 1 thermostat heating input	
Z1_C	(0)Off/(1)On	D	Input	Zone 1 thermostat cooling input	
Z2_CALL	(0)Off/(1)On	D	Input	Zone 2 valid thermostat call	
Z3_CALL	(0)Off/(1)On	D	Input	Zone 3 valid thermostat call	
Z4_CALL	(0)Off/(1)On	D	Input	Zone 4 valid thermostat call	
C_SPD	####		Text Setting	Cooling airflow control mode (FIXED = based on demand from zones, AUTO = controlled based on measured supply air temperature)	FIXED
AC_STG2	(0)Off/(1)On		Setting	Is the air conditioner 2-stage?	OFF
AC2_MIN	#### %		Setting	Minimum airflow to activate 2nd stage cooling.	80
AC2_DMP	####		Text Setting	How many dampers must be open to activate 2nd stage cooling?	2 Dampr
COOL_SP	#### C		Setting	Cooling setpoint of supply air temperature	11
DMP_DLY	#### sec		Setting	Damper Delay to close damper in seconds	20
CT_MODE	(0)Off/(1)On		Setting	Cycle Timer On or Off (Once per day pump exerciser)	OFF
PID_PROP	####.# %/C		Setting	Cooling PID Proportional value	3
PID_INT	###.### %/sec/C		Setting	Cooling PID Integral value	0.2
PID_DB	###.# C		Setting	Cooling PID Deadband value	0.5
PID_RAMP	###.# %/sec		Setting	Cooling PID Ramp Rate value	5
FRZ_TMP	#### C		Setting	Freeze alarm setpoint	2
FRZ_DLY	#### min		Setting	Freeze Delay 1 - wait time to activate freeze alarm	3
FRZ_DLY2	#### min		Setting	Freeze Delay 2 - wait time to restore operation after a freeze alarm	2
ZC4	###.### REV	D	Display	Program name and revision number	3.00
Modbus	####		Setting	Modbus address	136

* note: "D" in set. indicates variable is for display only and is not settable