



**IntelliPack Configuration Software
Model 5030-881**

TRANSMITTER CONFIGURATION MANUAL

ACROMAG INCORPORATED

30765 South Wixom Road

P.O. BOX 437

Wixom, MI 48393-7037 U.S.A.

Tel: (248) 295-0880

Fax: (248) 624-9234

Email: sales@acromag.com

Web: <http://www.acromag.com>

Copyright 1997, Acromag, Inc., Printed in the USA.
Data and specifications are subject to change without notice.

8500-570-C09H016

The information contained in this manual is subject to change without notice. Acromag, Inc. makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Further, Acromag, Inc., assumes no responsibility for any errors that may appear in this manual and makes no commitment to update, or keep current, the information contained in this manual. No part of this manual may be copied or reproduced in any form, without the prior written consent of Acromag, Inc.

Table of Contents	Page
1.0 INTRODUCTION	2
DESCRIPTION	2
Key IntelliPack Software Features.....	3
ACCESSORY ITEMS	3
IntelliPack Serial Adapter	3
IntelliPack Cable.....	3
2.0 GETTING STARTED	4
PROGRAM INSTALLATION.....	4
CONNECTING THE SERIAL ADAPTER.....	4
MODULE CONNECTIONS.....	4
MODULE PUSH-BUTTONS AND LEDS.....	4
3.0 PROGRAMMING	5
TRANSMITTER/ALARM CONFIG PARAMETERS..	5
Transmitter Configuration Parameters.....	5
Alarm Configuration Parameters.....	5
TRANSMITTER/ALARM CONFIGURATION.....	6
Before You Begin.....	6
Starting the Program.....	7
Creating a Configuration File.....	8
Scaling Input-to-Output.....	9
Alarm Configuration (801T-1500 Models).....	10
Testing Your Configuration.....	11
Printing Your Configuration.....	11
Saving Your Configuration.....	11
MODULE CALIBRATION.....	12
Module Input Calibration.....	12
Reference Temperature Calibration.....	14
Output Calibration.....	15
4.0 FIELD RECONFIGURATION	16
5.0 TROUBLESHOOTING	17
SELF DIAGNOSTICS.....	17
TROUBLESHOOTING HINTS.....	18

List of Drawings	Page
Configuration Print Page Sample.....	19
Computer to IntelliPack Connections (4501-635).....	21
Failsafe/Non-Failsafe Alarm Conditions (4501-623).....	22
Limit Alarm Operation (4501-623).....	23
TC Input Calibration Connections (4501-699).....	24

IMPORTANT SAFETY CONSIDERATIONS

It is very important for the user to consider the possible adverse effects of power, wiring, component, sensor, or software failures in designing any type of control or monitoring system. This is especially important where economic property loss or human life is involved. It is important that the user employ satisfactory overall system design. It is agreed between the Buyer and Acromag, that this is the Buyer's responsibility.

1.0 INTRODUCTION

These instructions cover the software configuration of Acromag IntelliPack Series 800T Transmitters and combination Transmitter/Alarms. This manual provides detailed information regarding software operation, transmitter and alarm configuration parameters, and operating functions. Specific information pertaining to transmitter hardware and electrical specifications is provided in the User's Manual that came with your module. Please refer to the IntelliPack Alarm Configuration Manual 8500-563 for specific details on configuring IntelliPack Series 800A Alarms.

IntelliPack transmitters, alarms, and combination transmitter/alarms are configured using the IntelliPack Configuration Software (5030-881), Serial Interface Adapter (5030-913), USB-to-RS232 Serial Adapter (4001095), and inter-connecting cable (5030-902). These items are available as a kit by ordering the IntelliPack Software Interface Package (Model 800C-SIP).

DESCRIPTION

IntelliPack transmitters and combination transmitter/alarms support a variety of input types and provide isolated process current and voltage outputs, plus an optional SPDT alarm relay. These transmitters are configured using the Acromag Windows 95® or NT® IntelliPack Configuration Software. All transmitter and alarm functions are reprogrammable and downloadable to the module via the Configuration Software. In addition to providing configurability of all IntelliPack features, the Configuration Software also provides controls to read input and output values, calibrate input and output ranges, independently control the output, monitor the alarm status, reset a latched alarm, reset the module, plot a graph of input versus output, document a configuration, upload the current configuration & calibration parameters, and restore the original factory calibration. Field reprogrammability of transmitter zero and full-scale, plus alarm setpoint and deadband is also possible using the IntelliPack module's front panel push-buttons and LED's, without having to connect a computer. Non-volatile memory within the IntelliPack provides secure storage of program and configuration data.

Each transmitter module converts an analog input signal to a digitized value. This digitized value is then used to control a Digital-to-Analog Converter (DAC) which provides a voltage or current output signal. The customer-programmed alarm setpoint is compared to this digitized value and used to control an alarm relay ("1500" units). The relay may have a high or low setpoint, plus deadband configured. Relay actuation is user-selected for failsafe or non-failsafe operation. The relay may also be configured as latching, in which case a push button reset is required to reset the latch (this may also be accomplished via software control). Additionally, a programmed relay time delay may be applied to filter transients and minimize nuisance alarms.

Use of this software makes configuring IntelliPack alarms and transmitters quick and easy. There are no special commands to memorize or complicated program routines to follow. All configuration information is organized for you in easy to use Windows screens. Configuration of your transmitter/alarms only takes a few minutes with this software.

Windows 95 & NT are registered trademarks of Microsoft Corp.

Acromag offers both standard and custom transmitter and alarm types to serve a wide range of applications. Other I/O functions are also possible—please consult the factory.

Key IntelliPack Configuration Software Features

- **Easy Windows® Configuration** - The IntelliPack Configuration Software provides a user-friendly Windows 95® or NT® program interface that you can use to completely configure a module in just a few minutes.
- **Software Monitor** - The IntelliPack software may be used to monitor input and output readings and optional alarm status.
- **Convenient Upload Function** - Allows the module's current configuration and calibration to be recalled (including user comments, tag names, and ID strings). Upload will automatically detect the model of the connected module and load the proper configuration screens for that model.
- **Remote Reset of Latched Alarm** - The IntelliPack software provides controls to reset a latched alarm relay, without having to press the reset latch button of the transmitter.
- **Show Graph Function** - Allows you to view or print a graphical representation of input (x) versus output (y).
- **Software Print Function Makes Documentation Easy** - This built-in self-documenting function will provide a printout of your complete module configuration in an easy to read, single-page format, including a graphical representation of input (x) versus output (y).
- **Easy Calibration Function** - The IntelliPack software includes an easy to understand input calibration function. The current calibration may be uploaded and controls are provided to restore the original factory calibration.
- **Software Supports Tag Names, ID Strings, & Comments** - The software provides documentation fields for optional tag names, identification strings, and comments. These items are stored within the module and may be uploaded.
- **On-Line HELP Function** - The software includes online Help with a specific help search function.
- **Download Firmware Feature** - This feature is useful for downloading custom alarm functionality, repairing failed modules, or replacing the module's microcontroller.

IntelliPack Transmitter Module Features

- **Wide Transfer Function Variability** - IntelliPack transmitters may produce a proportional, 24-segment linearized, or square-root output response. Other functions are possible—please consult the factory.
- **Alarm Functionality** - Some transmitter models include an alarm relay which may be programmed for limit alarms with deadband, latching/non-latching contacts, and failsafe/non-failsafe operation.
- **True Embedded Monitoring and Control** - Once configured, modules may operate independent of the host computer and IntelliPack software. The program configuration and calibration parameters are downloaded to non-volatile memory within the module and only the functions required by an application are actually stored.
- **Programmable Setpoint With Deadband** - The relay of these transmitters has programmable alarm setpoint and deadband. Deadband is desirable to eliminate relay "chatter" and prolong contact life.
- **Failsafe or Non-Failsafe Relay Operation** - The unit may be configured for failsafe or non-failsafe relay operation.
- **Programmable Relay Delay Filters Transients** - Alarm includes programmable relay time delay to filter transients.

IntelliPack Transmitter Module Features...continued

- **Programmable Latching or Momentary Alarm** - The alarm relay of these transmitters may be configured for automatic alarm reset, or as a latching alarm with manual push-button reset. A latching alarm may also be reset remotely via the IntelliPack Configuration Software.
- **Convenient Field Reprogrammability of Key Parameters** - IntelliPack modules include push-buttons and status LED's to facilitate in-field zero and full-scale adjustments, plus optional setpoint and deadband changes, without having to connect to a host computer.

ACCESSORY ITEMS

The following IntelliPack accessories are available from Acromag and are required to program your IntelliPack module. Note that all necessary documentation and accessories can be obtained by ordering the IntelliPack Software Interface Package (Model 800C-SIP) noted below.

IntelliPack Serial Port Adapter (Model 5030-913)

The IntelliPack Serial Port Adapter serves as an isolated interface converter between the EIA232 serial port of the host computer and the Serial Peripheral Interface (SPI) port of the IntelliPack module. It is used in conjunction with the Acromag IntelliPack Configuration Software to program and configure the modules. This adapter requires no user adjustment, no external power, and operates transparent to the user. The adapter has a DB9S connector that mates to the common DB9P serial port connector of a host computer. The adapter also has a 6-wire RJ11 phone jack to connect to the IntelliPack alarm module via a separate interconnecting cable (described below). Refer to Drawing 4501-635 for computer to IntelliPack connection details.

IntelliPack Cable (Model 5030-902)

This 6-wire cable is used to connect the SPI port of the IntelliPack Serial Port Adapter to the IntelliPack. This cable carries the SPI data and clock signals, reset signal, and +5V power and ground signals. The cable is 7 feet long and has a 6-wire RJ11 plug connector at both ends. These plugs snap into jacks on the Serial Port Adapter and the IntelliPack module.

IntelliPack USB-to-RS232 Serial Adapter (P/N 4001095)

This adapter is used to add a traditional RS232 serial port to newer personal computers or laptops that do not support legacy RS232 serial ports, but may have USB serial support. This adapter requires no user adjustment, no external power, and operates transparent to the user. The adapter has a USB connector at one end of a 6 foot cable for connection to a host computer, and a DB9P connector at the other end for connection to serial port adapter 5030-913 of this kit. Refer to Drawing 4501-635 for computer to IntelliPack connection details.

IntelliPack Software Interface Package (Model 800C-SIP)

The IntelliPack Software Interface Package combines the Configuration Software (5030-881), Transmitter Configuration Manual (8500-570), Alarm Configuration Manual (8500-563), Serial Port Adapter (5030-913), USB-to-RS232 Serial Adapter, and Cable (5030-902), into a complete kit for interfacing with IntelliPack Transmitters and Alarms.

2.0 GETTING STARTED

PROGRAM INSTALLATION - USING SETUP.EXE

1. Start Windows 95/NT® and insert the IntelliPack Configuration Software Disk 1 into drive A: (or B:).

IMPORTANT: Before continuing with the installation sequence, be sure to exit any other Windows programs that may be running.
2. Click on the [START] button in the lower left hand corner of the Windows screen. Then click on the "Run..." icon.
3. In the Run dialogue box, type **a:\setup** (or **b:\setup**) in the Open field and click on [OK]. The setup program will execute the Installshield Wizard.

You may need to click on the "Setup.exe" icon of the install shield to proceed. On some machines, the setup.exe program is not started automatically.
4. From the introductory Acromag IntelliPack Setup Screen, click on [Next>] to proceed.
5. At this point, the IntelliPack Setup program will prompt you for your "Name" and "Company". Fill in this information, then click on [Next>].
6. Now you will be prompted for a destination directory. You may click on [Browse] to change the default directory, or [Next>] to accept "C:\ProgramFiles\Acromag\IntelliPack" as the default. You may also click on [Back] to return to the prior screen and make any changes.
7. At this point you will be prompted for a program folder name. You may type a new name, use the scroll bar to select an existing program folder, or click on [Next>] to accept the "Acromag IntelliPack" default folder name.
8. Now you will be presented with your selections and you should verify if they are correct. Press [Next>] to continue and begin copying files, or press [Back] to return to prior screens and make any changes.

Periodically, the setup program will prompt you to insert the next disk into your floppy drive and click on [OK] after doing so, until all disks have been installed and installation is complete.
9. After the Configuration Program files have been copied to your hard drive, you will be prompted to click on [Finish] to complete the setup.
10. Now click on the [Acromag IntelliPack] program folder icon at the bottom of your windows screen, then click on the Acromag IntelliPack program icon to start the Configuration Program (Programs-Acromag IntelliPack-Acromag IntelliPack Configuration icon).

Note that the Configuration Program will search the serial ports for the IntelliPack Serial Port Adapter after you boot the program, if it detects the adapter at a certain COM port, then you will be asked if you wish to make that COM port the default COM port for the Configuration Program. Since the Serial Port Adapter receives its power from the IntelliPack, be sure to apply power to your module before booting the program.

CONNECTING THE SERIAL ADAPTER

The Serial Port Adapter is an isolated interface converter required to fully program and configure IntelliPack modules.

Connect the DB9S connector of the serial port adapter to the DB9P serial port connector on the back of your PC. If you do not have a DB9P connector on your PC, then use the USB-to-RS232 adapter to add one by connecting it to your USB port. Next, connect the 6-wire RJ11 jack of the interface adapter to the 6-wire RJ11 jack of the IntelliPack module using Acromag cable 5030-902, or equivalent. Refer to Drawing 4501-635 for connection details. Note that serial adapter 5030-913 receives its power from the IntelliPack module.

At the lower right hand corner of the Configuration Program screen, "SPA" will be displayed when the software detects that the Serial Port Adapter has been properly connected to the serial port and it is powered. Further, "MODULE" will be displayed next to it when the program has established communication with the module and the appropriate configuration screen for that model is open.

MODULE CONNECTIONS

Refer to the User's Manual that came with your IntelliPack module for complete information regarding electrical connections. After you make all necessary connections, apply power to the module before continuing with the Configuration Program. Review operation of the module's push-buttons and LED's below before proceeding to the MODULE CONFIGURATION section.

MODULE PUSH-BUTTONS AND LEDS

You should become familiar with the operation of the transmitter module's push-buttons and LED's in the normal operating mode. Note that field reprogrammability of transmitter zero & full-scale (scaling parameters), plus alarm setpoint and deadband can be accomplished via these controls and indicators in Field Configuration Mode.

Each transmitter module includes four front-panel push-buttons as follows:

- **Mode** - Used to change mode to field configuration.
- **Set** - Used to enter input data during field calibration.
- **Up/Reset Latch** - Used to increment output level during field configuration. Also used to reset a latched alarm relay in operating mode.
- **Down/Reset Latch** - Used to decrement output level during field configuration. Also used to reset a latched alarm relay in operating mode.

Each transmitter module also includes three or four LED indicators that operate as follows:

- **Run (Green)** - Constant ON indicates power is applied and the unit is operating normally. Flashing ON/OFF indicates that the unit is performing diagnostics (first second following power-up), or has failed diagnostics (after a few seconds). This LED is turned OFF in field configuration mode.

- **Status (Yellow)** - Flashing ON/OFF indicates an over-range or under-range condition exists at an input, or lead break detection is in effect (thermocouple and RTD units).
- **Zero/Full-Scale (Red)** - ON or FLASHING in field configuration mode if zero or full-scale is being adjusted. LED is OFF in operating mode.
- **Relay (Yellow)** - Constant ON indicates alarm condition for relay ("-1500" units only). During field configuration, this LED has a different function.

The functionality of the push-buttons and LED indicators noted above will be different in Field Configuration Mode (see the FIELD RECONFIGURATION section for more details).

3.0 PROGRAMMING

TRANSMITTER/ALARM CONFIG PARAMETERS

The following transmitter and alarm attributes are completely configurable via the IntelliPack Configuration Software. Applicable attributes and their application may differ with respect to the transmitter model.

Transmitter Configuration Parameters

- Input Range Selection:** Select one of several input ranges according to your model number.
- Temperature Units (RTD & Thermocouple Units Only):** Select °C, °F, or K (Kelvin) units.
- Cold Junction Compensation (Thermocouple Units Only):** Enable or disable Cold Junction Compensation (CJC) for thermocouple units.
- Sensor Break Direction (RTD & Thermocouple Units Only):** Select upscale or downscale lead break detection for thermocouple and RTD units (except 822A models).
- Analog Output Range:** You may select one of the following analog output ranges: 0-20mA DC, 4-20mA DC, 0-1mA DC, 0-10V DC, or 0-5V DC. If your application requires voltage output, you must also install a jumper between the output "I+" and "JMP" terminals. Remove this jumper for current output applications.
- Analog Output Signal Direction:** Select a normal (ascending) or reverse (descending) output signal.
- Input Averaging:** Set the number of input signal A/D conversions to be used to compute an average. Input averaging can be set to 1 (default), or 2, 4, 8, or 16 samples and is used to help filter out transients. Note that the response time will be increased by the factor selected.
- Scaling:** Scaling is performed after averaging and converts the engineering units of the input range (or a portion of the input range) to 0 to 100%. That is, scaling allows virtually any part of the selected input range to be scaled to 0% and 100% at the output.

Transmitter Computation Functions: The following gives a brief description of current available transmitter transfer functions:

- **Normal Function:** Each input sample is converted into a directly proportional output update.
- **Square Root Function:** Each input sample is converted into a corresponding output update that is the square root of the input signal. The output in percent is computed as the square root of the product of the input in percent and 100 percent.
- **Linearizer Function:** Permits the entry of up to 25 user-defined input-to-output break points to facilitate up to 24 segment linearization of a non-linear sensor signal.

Transmitter Visual Indicator: A yellow zero/full-scale LED (labeled "Z/FS") provides visual status indication of which parameter, zero or full-scale, is being calibrated in field configuration mode.

Transmitter Configurability: All transmitter operating functions are programmable using the Acromag Windows 95® or NT® IntelliPack Configuration Program and Serial Port Adapter. Additionally, reprogrammability of the transmitter zero and full-scale levels, plus optional alarm and dropout levels, is accomplished via front-panel push buttons and status LED's on the module.

Alarm Configuration Parameters ("-1500" units):

- Alarm Operating Function - Limit Alarm:** Refer to Drawing 4501-623, Figure 2 on Page 23. This model may be configured for simple high or low limit alarms. The relay will enter the alarm state when either the user-defined high or low setpoint is exceeded for the specified amount of time (this allows input transients to be filtered). Relay remains in the alarm state until the input signal has retreated past the defined setpoint, plus any deadband, for the specified amount of time. Please refer to the IntelliPack 800A alarm family for dedicated alarm modules that support other operating functions.
- Alarm Setpoint:** A high or low setpoint may be assigned to the relay and is programmable over the entire input range. The relay will trip on an increasing input signal for a high setpoint, and on a decreasing input signal for a low setpoint.
- Alarm Deadband:** Deadband is associated with the setpoint and is programmable over the entire input range. Deadband determines the amount the input signal has to return into the "normal" operating range before the relay contacts will transfer out of the "alarm" state. Deadband is normally used to eliminate false trips or alarm "chatter" caused by fluctuations in the input near the alarm point. Note that deadband may also apply to latched alarms—latched alarms will not reset until the input signal has retreated outside of the alarm region, plus the deadband. As such, deadband should be kept to a minimum for latched alarms.

IMPORTANT: Noise and/or jitter on the input signal has the effect of reducing (narrowing) the instrument's deadband and may produce contact chatter. Another long term effect of contact chatter is a reduction in the life of the mechanical relay contacts. To reduce this undesired effect, increase the deadband setting.

Relay Failsafe/Non-Failsafe Operating Mode: User configurable for “failsafe” operation (relay deenergized in alarm state), or non-failsafe operation (relay energized in alarm state). Failsafe mode provides the same contact closure for the alarm state as for power loss, while non-failsafe mode uses alarm contact closure opposite to power loss conditions. Refer to Drawing 4501-623, Figure 1.

Relay Time Delay: Programmable from 0 milliseconds to 4 seconds in 200ms increments (typically used to help filter input transients and avoid nuisance alarming). A minimum delay of 200ms (default) is recommended for increased noise immunity and conformance to applicable safety standards. Note that this delay applies to both relay activation and deactivation.

Automatic Reset or Latching Relay Action: The relay may be configured to automatically reset when the input retreats past its setpoint and deadband, or the relay may latch into its alarm state. A push-button reset switch is located on the front of the module (use the up or down arrow buttons) and is used to exit the latched state (this may also be accomplished from the Test page of this software). A latched relay cannot be reset until its input signal has returned into its normal operating range with deadband applied and after the relay time delay. Note that when the input returns to, or leaves the normal operating range, the relay and its LED will transfer after the relay time delay has expired.

Alarm Indicator: A yellow LED for the relay (labeled “RLY”) provides a visual status indication of when the relay is in alarm (LED is ON in alarm). This LED is also used in field configuration mode to indicate whether setpoint or deadband is being adjusted.

Alarm Configurability: All alarm parameters are programmable using the Acromag Windows 95® or NT® IntelliPack Configuration Program. Additionally, limited field reprogrammability of zero & full-scale, plus alarm setpoint and deadband levels, is accomplished via front panel push buttons and status LED’s.

Other IntelliPack Configuration Software Capabilities

In addition to configuring all features of the module described above, this software includes additional capabilities for testing and control of this module as follows:

- Monitors input and output values and allows polling to be turned on or off. Also monitors the reference temperature of the CJC circuit (thermocouple models).
- Allows the configuration to be uploaded or downloaded to/from the module and provides a means to rewrite a module’s firmware if the microcontroller is replaced or a module’s functionality is updated.
- Provides controls to separately calibrate the input & output stages, and the temperature reference. Also provides controls to restore the original factory input, output, or reference calibration in case of error.
- Provides controls to reset a module and a latched alarm.
- Provides a control to adjust a transmitter’s output signal independent of the input signal.
- Allows optional user documentation to be written to the module. Documentation fields are provided for tag number, comment, configured by, location, and identification information. This information can also be uploaded from the module and printed via this software.

- Allows a module’s complete configuration to be printed in an easy to read, two-page format, including user documentation.

TRANSMITTER/ALARM CONFIGURATION

This section describes how to use the IntelliPack Configuration Software to program and control transmitter/alarm parameters and operating modes. The IntelliPack software is easy to use and self explanatory. Complete configuration only takes a few minutes. On-line help is built in and context sensitive help is included. As such, a comprehensive guide to this program is not necessary. However, to begin configuration, you should already be familiar with Windows operation and have a basic understanding of transmitter and alarm terminology as it relates to the IntelliPack.

As shipped from the factory, each IntelliPack module has a default configuration that is detailed in the module’s User’s Manual. Your application will likely differ from the default configuration and the module will need to be reconfigured.

Configuration is normally done prior to field installation since in-field reconfigurability via the module’s push-buttons (described in the following section) is generally limited to zero & full-scale adjustment, plus setpoint and deadband adjustment on “-1500” models. Complete configuration of these transmitters can only be accomplished via the IntelliPack Configuration Software which provides full program access to all configurable features of the IntelliPack.

Before You Begin

1. Have you installed the IntelliPack Configuration Program? If not, then you should complete Section 2.0 of this manual before proceeding.
2. Check that all necessary electrical connections have been made to the module and that power is applied. Note that the Serial Port Adapter receives its power from the IntelliPack.
3. Check that the IntelliPack Serial Port Adapter is connected to an RS232 serial port on your computer and to the IntelliPack module to be programmed.

Refer to the figure of the following page and note that “SPA” is indicated in the lower right hand corner of the Configuration Program screen to indicate that the software has detected a properly connected (and powered) Serial Port Adapter.

Note that the software will not detect the serial port adapter unless a module is connected to it and powered-up, and a serial port has been set within the program or upon booting the program.


The following steps guide you through the property sheets used to configure an IntelliPack Transmitter. The Model 801T-1500 is used as an example. The property sheets for your model may differ, but the general approach is the same. If you have trouble understanding configuration parameters unique to your model, refer to your User’s Manual, or the on-line help feature.

Starting the Program

1. After clicking on the Acromag IntelliPack program icon to boot the Configuration Program, a screen will be displayed as shown at right.
2. To begin, click on "Settings", followed by "SerialPort" to tell the Configuration Software which communication port is connected to the IntelliPack Module. Use the scroll arrow to select the correct COM port.

Note that "COM2" is indicated in the lower right hand corner of the screen to indicate that the COM2 port has been selected.

In the lower right hand corner of the screen, note that "SPA" is displayed next to COM2 to indicate that the program has detected a properly connected Serial Port Adapter and it is powered-up (it receives its power from the IntelliPack module).



↑ ↑
COM2 ↑
Serial Port Adapter Connected

Available menu selections are listed below.

File

- New...
- Open...
- Save
- Save As...
- Print...
- Print Preview
- Print Setup...
- Recent File Indicated
- Exit

Use **File-New** to create a new configuration file. You will be prompted to select a model number. Use **File-Open** to open an existing configuration file.

Use **File-Save** to save the current configuration file to disk. Use **File-Save As** to save the current configuration file to a new file name.

Use **File-Print** to get a printout of the currently loaded configuration file. Use **File-Print Preview** to view the current configuration or preview the print documentation. Use **File-Print Setup** to select a printer and font style.

Module

- Upload Configuration
- Download Configuration
- Firmware Download...

Use **Module-Upload Configuration** to upload the module's current configuration and calibration.

Use **Module-Download Configuration** to write the currently loaded configuration to the module.

Use **Module-Firmware Download** to change a module's operation (custom units), repair a failed module, or after replacing the microcontroller. Module-Firmware Download is normally not required and may take several minutes to complete. The firmware file name specific to your model is indicated on the General property sheet.

Settings

- SerialPort...

Use **Settings-SerialPort** to tell the software which serial communication port the module is connected to.

The selected serial port is indicated in the lower right hand corner of the screen.

Note that the Configuration Program will search the serial ports for the IntelliPack Serial Port Adapter after you boot the program, if it detects the adapter at a certain COM port, then you will be asked if you wish to make that COM port the default COM port setting for the Configuration Program.

Help

- Configuration Help Topics
- Your Model Help Topics
- Alarm Configuration Help
- About IntelliPack Configuration
- About Your Model

Use **Help** to obtain information about using this software, configuring alarms, or configuring transmitters. Note that context sensitive help (↑?) is also available for help on a specific field or topic. Simply click on the [↑?] button, then click on the field or topic of interest to obtain help on that subject. You may also click the right mouse button to copy or print the help screen while it is being displayed.

The following sections review the configuration of a Model 801T-1500 transmitter/alarm module. Configuration of your model will be similar.

Creating a Configuration File

1. You may use **File-New** to create a new configuration file, or **File-Open** to open an existing configuration file. You may also use **Module-Upload Configuration** to retrieve the current active configuration from the module connected (recommended).

Uploading first is recommended as it will automatically detect the correct model connected and load the property sheets for that model.

Once you create, open, or upload a configuration file, a screen similar to the one shown at right will be displayed. The model number is indicated at the top of the screen. Your screen will vary according to your model number.

Note that 7 property sheets define this transmitter's configuration: General, Xmtr Configuration, Alarm Configuration, Test, Input Calibration, T-Ref Calibration (TC units only), and Output Calibration.

"MODULE" is indicated in the lower right hand corner of the screen to indicate that a module is connected.

The current model and configuration file name is indicated at the top of the screen.

Module

For "**Tag:**", enter up to 15 alphanumeric characters (optional).

You may also add a "**Comment:**" up to 31 alphanumeric characters (optional).


For "**Configured By:**", enter your name up to 15 alphanumeric characters (optional).

You can also add a "**Location:**" note up to 25 alphanumeric characters (optional).

The Serial Number, Firmware Number, and Last Modified information is fixed and cannot be modified.

In the "**ID:**" field of Input 1, you may enter an alarm identification string up to 15 alphanumeric characters long (optional).

Note that these documentation notes are optional and stored in non-volatile memory within the IntelliPack module and may be recalled (uploaded).



Module Present

Begin defining your application by entering the configuration parameters of the "General" folder shown in the screen above. Your screen may look slightly different depending on your model.

Input 1

Use the "**Range:**" scroll bar to pick one of the following ranges according to your model (Model 801T-1500 ranges shown):

TC Type J	+/-1.0V DC
TC Type K	+/-500mV DC
TC Type T	+/-250mV DC
TC Type R	+/-125mV DC
TC Type S	+/-62.5mV DC
TC Type E	+/-31.3mV DC
TC Type B	+/-15.6mV DC
TC Type N	
RTD Pt 100, 1.3850	
RTD Pt 100, 1.3910	
RTD Ni 120, 1.6720	
RTD Cu 10, 1.4272	
0-500 Ohm	

Available ranges will vary according to your model number. All input ranges have been factory calibrated. To begin configuring your module, start by selecting an input range as required.

Use the "**Temp Units:**" scroll bar to select °C, °F, or K units (TC & RTD inputs only).

For "**RTD Wiring**", select 2-Wire, 3-Wire, 4-Wire Kelvin, or 4-Wire Compensated Loop (RTD units only).

For "**Samples**", select 1 (default), or 2, 4, 8, or 16 to specify the number of input signal A/D conversions to be used to compute an average. This is useful to help filter transients. Note that the response time will be increased by the factor selected.

Click on the "**CJC On**" box to enable Cold Junction Compensation (TC units only).

For "**Sensor Break**", use the scroll bar to select Upscale or Downscale break detection (TC & RTD units only).

Output 1

For Output 1, use the "**Range**" scroll bar to select one of the following ranges: 0-20mA DC, 4-20mA DC, 0-1mA DC, 0-10V DC, or 0-5V DC.

For Output 1 "**Mode**", use the scroll bar to select **Normal Acting** (ascending response) or **Reverse Acting** (descending response), as required.

The next section covers transmitter scaling of the input range to 0-100% at the output, plus optional computation functions.

Transmitter (Xmtr) Configuration

1. Clicking on the Xmtr Configuration property sheet tab will display a screen similar to the one at right. Your screen may vary according to your input type and model.

The scaling screen for a Model 801T-1500 Transmitter/Alarm with a Type J thermocouple input is shown here.

This screen allows you to specify input-to-output scaling, plus any optional computations to be performed. Computation options vary with the model.

A Show Graph feature allows you to view a graphical representation of input signal (x) versus output signal (y), including computation. This graph may also be printed.


You may go ahead and complete the information of this screen according to your application. Refer to the scaling property sheet field descriptions included below to complete the information.

Transmitter Configuration Sheet Field Descriptions

Scaling: Scaling is performed after averaging and converts the engineering units of the input value range (or a portion of the input range) to 0 to 100%. Scaling allows virtually any part of the selected input range to be scaled to 0% and 100% at the output. For example, the Type J TC range is -210°C to +760°C. We can select a 0 to 200°C J TC input span to correspond to a 0 to 100% output control for the 4 to 20mA output range. Simply enter the input signal endpoints for 0% and 100% at the output. Be sure to enter values within the selected input range and of the same units. Scaling parameters may also be modified via field configuration.

Computation: Computation is performed after scaling and operates on the 0 to 100% output of the scaling block.

Computation allows the following input-to-output transfer functions to be implemented:



- **None (Default)** - If "None" is selected, then a Proportional Function is assumed. That is, each input sample is converted into a directly proportional output update.
- **Square Root Function** - Each input sample is converted into a corresponding output update that is the square root of the input signal. The output in percent is computed as the square root of the product of input in percent and 100%.
- **Linearizer** - A 24 Segment Linearization Function is applied which permits the entry of a maximum of 25 user-defined breakpoints to facilitate segmented linearization of a non-linear sensor signal. Use the "Breakpoints" field to specify from 3 to 25 signal breakpoints for segmented input to output transfer. Use the scroll window of the breakpoint table to enter up to 25 input and corresponding output break points that define up to 24 linear segments of the input and output ranges. Input and output break points are specified in percent-of-span units. That is, the 0-100% output range from the scaling block is mapped to 0-100% of the output range.

Note that the non-linear function must be a single-valued function of x. That is, for each input value x, there must exist only one output value y. The slope of the last segment is used to interpolate an output response for inputs beyond 100%.

Note that you can use the Show Graph button to view a graphical representation of input signal (x) versus output signal (y) with the effect of computation included.


The next section covers Alarm 1 Configuration for "-1500" units which include an alarm relay.

Alarm Configuration
 (“-1500” Units Only)

Transmitters with a “-1500” model suffix include an isolated SPDT alarm relay.

1. Clicking on the Alarm 1 Configuration property sheet tab will display a screen similar to the one at right. Your screen may vary according to the input range type you selected on the General property sheet and your model. The 801T-1500 Alarm 1 Configuration screen is shown here.

For Limit Alarms, a High or Low limit must be selected, a setpoint value, and deadband (optional). You can also specify Failsafe or Non-Failsafe contacts, Automatic or Latching alarm, plus a relay Time Delay for filtering transients and preventing nuisance alarms in noisy environments.



You may go ahead and complete the information of this screen according to your application. Refer to the limit alarm configuration field descriptions noted at right to complete this information.

Writing Your Configuration

2. Select **Module-Download Configuration** to write your configuration to the module.

Module

- Upload Configuration
- Download Configuration

Firmware Download

Note that you can select Module-Upload Configuration to retrieve the module’s current alarm configuration and calibration, or to review and verify its configuration.

Firmware Download is not normally used and only provided to change a module’s operation (non-standard units), repair a failed module, or after replacing a microcontroller. Firmware Download takes several minutes to complete.

Note that configuration data is stored in non-volatile memory within the IntelliPack module.

Alarm Config Field Descriptions

Limit Alarm

Setpoint: A setpoint level may be assigned to the relay and is programmable over the entire input range. The setpoint is entered in engineering units the same as the input. The relay will trip on an increasing input signal for a high setpoint, and on a decreasing input signal for a low setpoint.

Deadband: Deadband may be associated with the setpoint and is programmable over the entire input range. The deadband is entered in engineering units the same as the input. Deadband determines the amount the input signal has to return into the “normal” operating range before the relay contacts will transfer out of the “alarm” state. Deadband is normally used to eliminate false trips or alarm “chatter” caused by fluctuations in the input near the alarm point. Note that deadband also applies to latched alarms.

Note: If the alarm is latching, it is recommended that deadband be set to a minimum.

Relay

Time Delay: Programmable from 0 milliseconds to 4 seconds in 200ms (0.2000ms) increments for this model. Useful to help filter input transients and avoid nuisance alarming by noisy input signals. A minimum delay of 200ms (default) is recommended.

Operating Mode: In “Failsafe” mode, the relay is de-energized in the alarm state. In “Non-failsafe” mode, the relay is energized in the alarm state. Failsafe mode provides the same contact closure for alarm states as for power loss, while non-failsafe mode uses alarm contact closure opposite to power loss conditions.

Reset: The relay may be configured to automatically reset (momentary) when the input retreats past its setpoint and deadband, or the relay may latch into the alarm state. A push-button reset switch is located on the front of the module (up or down arrow button) and is used to reset a latched relay. Reset latch may also be accomplished under software control via the Test property sheet. Note that when the input returns to, or leaves the normal operating range, the relay and its LED will transfer after the Time Delay has expired. That is, time delay applies to both activating and deactivating the relay.

Testing Your Configuration

The “Test” portion of this program allows you to enable/disable polling, reset a latched alarm relay, reset the module, monitor the input and output, read the reference junction temperature, check alarm status, check scaling and optional computation, and independently control the output.

Test Operation

1. Click on the “Test” property sheet tab to test the configuration just written to your module and a screen similar to the one at the right will be displayed.

Note the flashing green Status lamp in the polling box. This indicates that the software is communicating with the module and polling its input reading. You can also turn polling “OFF”, or back “ON” here.

If Cold Junction Compensation has been enabled (thermocouple units only), “CJC On” will be indicated to the right of Input 1.


You may reset a latched alarm by clicking on “Reset Latch” of Relay 1. Note that a latched alarm may also be reset via the up or down push-buttons on the front of the transmitter.

You can also reset the module by clicking the “Reset” button (same effect as power-on reset).

The current selected input 1 range, input value (“Value:”), averaged input value (“Average Value”), and reference temperature (“T-Ref:”) is indicated. If polling is OFF, then the last received value is indicated. If module is not connected or powered, “No Module” is indicated.

The input signal to output scaling is shown in the scaling box. The averaged value is indicated here along with the scaled value in percent, plus a computed value if you have selected an optional computation function.

You may adjust the output current or voltage independent of the input signal by dragging the Min/Max slide control with your mouse.



This control will temporarily override input control of the output, allowing you to verify output operation.

After 10 seconds, the software will return control of the output to the input. The selected output range and the output current or voltage (as measured by the module) is indicated in the Output “Value:” field. You can verify this value by independently measuring the output signal with a current or volt meter.

Print Your Configuration

1. If you wish to document your transmitter configuration, then select **File-Print** to get a two page printout of all of your selected configuration parameters.

A sample printout of the Transmitter Configuration Report is included at the back of this manual (pages 19 and 20).

Saving Your Configuration

1. You should select **File-Save As** to save your configuration file to disk and give it a new file name.

Use **File-Save** to save the current file without renaming it.

Note that the currently loaded configuration file name is indicated at the top of the screen to the right of the model number.

In the event that you lose a configuration file, you can always upload it from the module via **Module-Upload Configuration**.

Now wasn’t that easy! That’s all there is to using the Configuration software to configure your module.

The module is now ready for installation in the field. Note that later, if you need to make adjustments to transmitter zero and full-scale (scaling parameters), or alarm setpoint and deadband, you can use the module’s push-buttons and LED’s to perform Field Configuration, without having to restart this program or connect to a computer.

Note that the configuration process may vary slightly for other model types. For example, T-Ref Calibration only applies to models that support thermocouple inputs.

The next three sections cover calibration of your module. Note that calibration has already been done at the factory and adjustment is not generally required. However, periodic recalibration may be performed to correct for component aging, or as part of your maintenance requirements.

MODULE CALIBRATION

Calibration of your transmitter is performed in two or three parts. The input is calibrated first, then the reference junction (TC inputs only), then the output.

Note: Calibration of all supported input ranges has already been done on your module at the factory. Recalibration is normally not required, except as necessary to correct for long term component aging or to satisfy your company's maintenance requirements.

This portion of the program will allow you to calibrate an input range of your module, or restore the original factory calibration if a module has been miscalibrated.

For best results, you will need a precision input signal source capable of reproducing input range endpoint signals at least as accurate as the module itself. Allow the module to warmup prior to calibration.

It is recommended that TC inputs be calibrated with a precision millivolt source with CJC off. After calibration, CJC can be turned back on. Refer to Drawing 4501-699.


If Cold Junction Compensation has been enabled (thermocouple units only), "CJC On" will be indicated to the right of Input.

Module Input Calibration

1. Click on the Input Calibration property sheet tab to display the screen shown at right (your screen may be slightly different according to your model).

Note that Module-Upload Configuration will recall the module's current calibration for review or to make minor adjustments.

It is a good idea to recall the last calibration before entering new values by performing an upload. After upload, the current Low and High calibration values will then be indicated in the Calibration Value fields. Uploading will help prevent entering erroneous values which may produce erratic results.



If you make a mistake, or your calibration appears in error, you can use the "Restore Factory Calibration" button to restore a module's original factory input calibration (only the input calibration will be affected).

2. You may adjust the Low and High Calibration Value field entries roughly $\pm 10\%$ from nominal range endpoints (see Table 3).
3. Adjust your input signal to precisely match the Low Calibration Value field entry. Observe proper polarity.
4. Then press the Low "Calibrate" button to set the Low Calibration Value.
5. Next, adjust your input source to precisely match the High Calibration Value field entry. Observe proper polarity.
6. Then press the High "Calibrate" button to set the High Calibration Value.

Please Note:

For best results, you should always calibrate the low value first before the high value.

It is a good idea to allow the module to warmup several minutes prior to calibration.

You must restrict calibration points to values within $\pm 10\%$ of span from nominal range endpoint values.

You do not need to recalibrate a module if you select Module-Firmware Download.

However, you must recalibrate the module if you replace the microcontroller.

Refer to Drawing 4501-699 at the back of this manual for example thermocouple input calibration connections.

Tables 1, 2, and 3 of the next page includes conversions for thermocouple voltage versus temperature, and RTD resistance versus temperature, plus recommended input calibration values for supported ranges.

The following section covers temperature reference calibration for thermocouple transmitters. If your model does not support thermocouple inputs, then you will not be given access to the T-Ref Calibration property sheet and you can skip ahead to Output Calibration.

Table 1: Thermocouple milliVoltage Versus Temperature¹

TEMP °C	Thermoelectric Voltage In millivolts (With Ref Junction at 0°C)						
	J	K	T	E	R	S	B
- 250	---	-6.404	-6.181	-9.719	---	---	---
- 200	-7.890	-5.891	-5.603	-8.824	---	---	---
- 150	-6.499	-4.912	-4.648	-7.279	---	---	---
- 100	-4.632	-3.553	-3.378	-5.237	---	---	---
- 50	-2.431	-1.889	-1.819	-2.787	---	---	---
0	0.000	0.000	0.000	0.000	0.000	0.000	0.000
+ 50	2.585	2.022	2.035	3.047	0.296	0.299	---
+ 100	5.268	4.095	4.277	6.317	0.647	0.645	---
+ 150	8.008	6.137	6.702	9.787	1.041	1.029	---
+ 200	10.777	8.137	9.286	13.419	1.468	1.440	---
+ 250	13.553	10.151	12.011	17.178	1.923	1.873	---
+ 300	16.325	12.207	14.860	21.033	2.400	2.323	---
+ 350	19.089	14.292	17.816	24.961	2.896	2.786	---
+ 400	21.846	16.395	20.869	28.943	3.407	3.260	---
+ 450	24.607	18.513	---	32.960	3.933	3.743	1.002
+ 500	27.388	20.640	---	36.999	4.471	4.234	1.241
+ 550	30.210	22.772	---	41.045	5.021	4.732	1.505
+ 600	33.096	24.902	---	45.085	5.582	5.237	1.791
+ 650	36.066	27.022	---	49.109	6.155	5.751	2.100
+ 700	39.130	29.128	---	53.110	6.741	6.274	2.430
+ 800	---	33.277	---	61.022	7.949	7.345	3.154
+ 900	---	37.325	---	68.783	9.203	8.448	3.957
+1000	---	41.269	---	76.358	10.503	9.585	4.833
+1200	---	48.828	---	---	13.224	11.947	6.783
+1400	---	---	---	---	16.035	14.368	8.952
+1600	---	---	---	---	18.842	16.771	11.257
+1700	---	---	---	---	20.215	17.942	12.462
+1750	---	---	---	---	20.878	18.504	13.008
+1800	---	---	---	---	---	---	13.585

Table 2: RTD Resistance Versus Temperature²

TEMP °C	Resistance Temperature Detector (RTD)			
	Temperature in Ohms			
	100Ω Platinum		10Ω Cu	Nickel
	Pt385	Pt3911	9.035Ω/0°C	Note 3
- 200	18.52	17.26	1.058	---
- 150	39.72	38.79	3.113	---
- 100	60.26	59.64	5.128	---
- 50	80.31	80.00	7.104	86.17
0	100.00	100.00	9.035	120.0
+ 50	119.40	119.70	10.966	157.74
+ 100	138.51	139.11	12.897	200.64
+ 150	157.33	158.22	14.828	248.95
+ 200	175.86	177.04	16.776	303.46
+ 250	194.10	195.57	18.726	366.53
+ 300	212.05	213.81	---	439.44
+ 350	229.72	231.76	---	---
+ 400	247.09	249.41	---	---
+ 450	264.18	266.77	---	---
+ 500	280.98	283.84	---	---
+ 550	297.49	300.61	---	---
+ 600	313.71	317.09	---	---
+ 650	329.64	333.29	---	---
+ 700	345.28	349.18	---	---
+ 750	360.64	364.79	---	---
+ 800	375.70	380.10	---	---
+ 850	390.48	395.12	---	---

Use these tables as an aid in calibrating IntelliPack Model 801T Transmitter/Alarms. Refer to Drawing 4501-699 at the back of this manual for an example of thermocouple module calibration connections.

Table 3: Input Calibration Values For Supported Input Ranges

Available Input Ranges	RECOMMENDED INPUT CALIBRATION VALUES (801T)					
	MIN LOW Cal	NOMINAL LOW	MAX LOW Cal	MIN HIGH Cal	NOMINAL HIGH	MAX HIGH Cal
Type J TC	-220°C	0.0° (0.000mV)	25°C	650°C	700.0° (39.130mV)	770°C
Type K TC	-210°C	0.0° (0.000mV)	25°C	1250°C	1300.0° (52.398mV)	1382°C
Type T TC	-270°C	0.0° (0.000mV)	25°C	350°C	390.0° (20.252mV)	410°C
Type R TC	-60°C	0.0° (0.000mV)	25°C	1650°C	1700.0° (20.215mV)	1778°C
Type S TC	-60°C	0.0° (0.000mV)	25°C	1650°C	1700.0° (17.942mV)	1778°C
Type E TC	-210°C	0.0° (0.000mV)	25°C	900°C	950.0° (72.593mV)	1010°C
Type B TC	+250°C	260° (0.317mV)	270°C	1650°C	1700° (12.426mV)	1830°C
Type N TC	-240°C	0.0° (0.000mV)	25°C	1150°C	1200.0° (43.836mV)	1310°C
Pt 100 1.385	-210°C	0.0°C (100.00Ω)	25°C	800°C	850.0°C (390.48Ω)	860°C
Pt 100 1.3911	-210°C	0.0°C (100.00Ω)	25°C	800°C	850.0°C (395.12Ω)	860°C
Ni 120 1.6720	-90°C	0.0°C (120.00Ω)	25°C	250°C	300.0°C (439.44Ω)	330°C
Cu 10 1.4272	-210°C	0.0°C (9.035Ω)	25°C	200°C	250.0°C (18.726Ω)	270°C
0-500Ω	0Ω	10Ω	50Ω	425Ω	450Ω	511Ω
±1.0 VDC	-1.25 VDC	-1.00 VDC	-0.75 VDC	0.75 VDC	1.00 VDC	1.25 VDC
±500 mVDC	-625 mVDC	-500 mVDC	-375 mVDC	375 mVDC	500 mVDC	625 mVDC
±250 mVDC	-312.5 mVDC	-250 mVDC	-187.5 mVDC	187.5 mVDC	250 mVDC	312.5 mVDC
±125 mVDC	-156.25 mVDC	-125 mVDC	-93.75 mVDC	93.75 mVDC	125 mVDC	156.25 mVDC
±62.5 mVDC	-78.125 mVDC	-62.5 mVDC	-46.875 mVDC	46.875 mVDC	62.5 mVDC	78.125 mVDC
±31.3 mVDC	-39.063 mVDC	-31.3 mVDC	-23.438 mVDC	23.438 mVDC	31.3 mVDC	39.063 mVDC
±15.6 mVDC	-19.531 mVDC	-15.6 mVDC	-11.719 mVDC	11.719 mVDC	15.6 mVDC	19.531 mVDC

Notes (Tables 1 & 2):

- From the National Institute of Standards and Technology (NIST) thermocouple tables.
- For Pt385 (Platinum), Alpha = 0.00385 Ohms/ohm/°C. For Pt3911 (Platinum), Alpha = 0.003911 Ohms/ohm/°C. 1. Alpha (α) is used to identify the particular RTD curve. The value of alpha is derived by dividing the resistance of the sensor at 100°C by the resistance at 0°C (α = R_{100°C}/R_{0°C}). For Pt 100Ω, this is 138.5Ω/100.0Ω, or 1.385 (also shown as 0.00385Ω/Ω/°C).
- For Nickel RTD, range endpoints are not shown in table, but given here: Nickel is 66.60Ω at -80°C and 471.20Ω at +320°C.

Reference Temperature Calibration (Model 801T Transmitters Only)

This portion of the program will allow you to calibrate the reference junction temperature sensor for accurate cold junction compensation of thermocouple inputs.

Note: Calibration of the temperature reference (T-Ref) has already been done on your module at the factory. Recalibration is normally not required, except as necessary to correct for long term component aging or to satisfy your company's maintenance requirements.

Before attempting to calibrate T-Ref, you should configure your thermocouple module for a J, K, or T thermocouple type, °C temperature units, and enable CJC (Cold Junction Compensation). Also, the input range must be accurately calibrated before proceeding (all input ranges are initially calibrated at the factory).


A thermocouple will output a voltage proportional to the difference in temperature at each end. Cold junction compensation is used to derive the measured temperature by precisely measuring the temperature at one end (the input terminals, T-Ref) and computing an offset. Thus, the ability of the CJC circuit to compensate for the junction temperature is evident by connecting a thermocouple at 0°C and noting the temperature indicated. The resultant reading with CJC enabled should be $0.0^{\circ}\text{C} \pm 0.1^{\circ}\text{C}$.

In order to calibrate the temperature reference, you may use J, K, or T type thermocouple wire and a matching electronic ice-point temperature reference, or a thermocouple placed directly in an ice-water bath, to simulate a thermocouple signal at 0°C.

Module-Upload Configuration will recall the module's current calibration for review or to make minor adjustments. Using the uploaded calibration parameters as a guide will help prevent you from entering erroneous values which may produce erratic results.

Always allow the module to warmup several minutes prior to calibration.

Recall the current calibration by performing an upload.



Reference Temperature Calibration

1. Click on the T-Ref Calibration property sheet tab to display a screen similar to the one shown above. The current input "Value", and "T-Ref" temperature will be indicated in the appropriate fields following upload. "CJC on" will be indicated if Cold Junction Compensation has been enabled.

If you make a mistake, or your calibration appears in error, you can use "Restore Factory Calibration" to restore a module's original T-Ref factory calibration (only T-Ref calibration will be affected).

2. Connect the input to the calibration source at 0°C (i.e. the extension wires from an electronic ice-point reference, or a J, K, or T type thermocouple placed in ice water).
3. Read the input value from the "Value:" field.

If the temperature reference is properly calibrated and CJC is ON, this should read $0.0^{\circ}\text{C} \pm 0.1^{\circ}\text{C}$, and further calibration is not required.

If the absolute magnitude of "Value" is greater than 0.1°C , then continue with calibration in the following steps.

4. Read the reference temperature from the "T-Ref:" field.

Calculate the T-Ref low Calibration Value by subtracting the input reading ("Value") from the reference temperature ("T-Ref").

5. Enter the value calculated above into the T-Ref Low Calibration Value field, then click on the "Calibrate" button.

Note: The entered value must be in the range $15\text{-}35^{\circ}\text{C}$ ($59\text{-}95^{\circ}\text{F}$). If the Low Calibration Value is outside of this range, you will be prompted to enter a valid value within range.

After clicking on "Calibrate", the module will be reset and new "Value" & "T-Ref" values will be indicated. The input "Value" should read $0.0^{\circ}\text{C} \pm 0.1^{\circ}\text{C}$ if properly calibrated. If the absolute magnitude of "Value" is greater than 0.1°C , return to Step 3 and recalibrate T-Ref if desired.

Note: Only the low calibration point for T-Ref may be calibrated. The high calibration point is set at the factory.


The next section covers transmitter output stage calibration.

Transmitter Output Calibration

This portion of the program will allow you to calibrate the output of your module, or restore the original factory output calibration if the module has been miscalibrated.

Note: Calibration of the output ranges has already been done on your module at the factory. Recalibration is normally not required, except as necessary to correct for long term component aging or to satisfy your company's maintenance requirements.

This screen allows you to adjust the output current or voltage, independent of the input signal by dragging the Min/Max slide control with your mouse. Control of the output is returned to the module's input upon leaving this screen. The selected output range is indicated. The output current or voltage as measured by the module is indicated in the "Value:" field. You calibrate the output by comparing this value to the value measured independently by a precision current or volt meter.



For best results, you will need a precision milliammeter or voltmeter capable of resolving the selected output current or voltage range and at least as accurate as the module itself. A properly calibrated output stage will indicate a screen "Value:" matching the value measured via the meter.

Module-Upload Configuration will recall the module's current calibration for review or to make minor adjustments.

Output Calibration Procedure

1. Click on the Output Calibration property sheet tab to display the screen shown above.

It is a good idea to recall the last calibration before entering new values by first performing an upload. After upload, the current Low & High calibration values will be indicated in the Calibration Value fields. Using the uploaded calibration as a guide will help prevent entering erroneous values which may produce erratic results.

If you make a mistake or your calibration appears off, you can use "Restore Factory Calibration" to restore a module's original factory output calibration (only the output calibration will be affected).

2. Connect the ammeter to the current output terminals and in series with your load. If you are calibrating the voltage output (jumper installed), connect a voltmeter to the voltage output terminals, preferably in parallel with your load. Observe proper polarity.
3. Adjust output near the suggested Low Calibration Value by dragging the slide control with your mouse. Make note of the output "Value:" as measured by your module. Does "Value:" precisely match the measured output signal on your meter within 0.1% of output span? If not, then enter the meter measured output value in the Low Calibration Value field and click on the "Calibrate" button to set the Low Calibration Value.

Note: The entered value must be within 10% of the nominal output range endpoint. If the Low Calibration Value is more than 10% from nominal, you will be prompted to enter a valid value.
4. Adjust output near the suggested High Calibration Value by dragging the slide control with your mouse. Make note of the output "Value:" as measured by your module.

Does the indicated "Value:" precisely match the measured output signal on your meter within 0.1% of output span? If not, then enter the meter measured output value in the High Calibration Value field and click on "Calibrate" to set the High Calibration Value.

Note: For best results, you should always calibrate the low value first before the high value. Always allow the module to warmup several minutes prior to calibration.

You must restrict calibration points to values within $\pm 10\%$ of span from nominal output range endpoint values.

You do not need to recalibrate the output module if you select Module-Firmware Download.

The next section covers field configuration via front panel push-buttons and LED's. This mode is useful for making adjustments to transmitter zero, full-scale, and alarm parameters in the absence of a host computer running IntelliPack software. It also provides a means of calibrating from input to output in one step, rather than separately for each stage (Input, T-Ref, Output). It is included here for reference, but may also be found in the User's Manual that came with your module.

4.0 FIELD RECONFIGURATION

This program mode allows adjustment to key transmitter calibration and alarm parameters in the field, without having to connect a host computer or having to use the Configuration Software. Field reconfigurability of transmitter zero & full-scale/span, plus optional alarm setpoint & dropout/deadband is accomplished via the module's "SET", "MODE", "UP", and "DOWN" push-buttons, and the zero/full-scale and relay LED's. Note that field reconfiguration via the module's push-buttons is limited to zero and full-scale, plus optional setpoint and dropout adjustments only.

Table 4 shows which parameters can be adjusted in the field and how the yellow zero/full-scale LED (Z/FS) and relay LED (RLY) are used to indicate which program parameter is being adjusted. A constant ON zero/full-scale LED refers to zero calibration, a flashing ON/OFF zero/full-scale LED refers to full-scale/span calibration. A constant ON relay LED indicates setpoint adjustment, a flashing ON/OFF relay LED indicates dropout/deadband adjustment.

Table 4: Field Configuration LED Program Indication

LED INDICATOR	CONSTANT ON	FLASHING ON/OFF
Yellow Zero/Full-Scale (labeled "Z/FS")	Zero	Full-Scale
Yellow Relay (labeled "RLY")	High or Low Setpoint	High or Low Dropout

Note that adjustment of the module's zero and full-scale configuration (scaling parameters) provides another method of calibration that works from input to output in one step, rather than separately calibrating the input, output, and T-Ref stages as previously described.

Equipment Required

- An accurate input source (voltage or resistance) adjustable over the range required for alarm setpoint and dropout. A thermocouple (or mV source with an ice-point reference), or RTD calibrator may be used. This source must be accurate beyond the module's specifications for best results. For voltage inputs, use a voltage source with an output impedance of 100Ω or less.
- An accurate current or voltage meter is required to monitor the output level. This meter must be accurate beyond the module's specifications for best results.

Note: The module's input range must already be set via the IntelliPack Configuration Software. Input levels outside of the configured input range will not be accepted for zero, full-scale, setpoint, or dropout calibration. Since input levels cannot be validated during field programming, entering incorrect signals can produce an undesired output response.

General Field Programming Procedure

CAUTION: Do not insert sharp or oversized objects into the module's push-button switch openings, as this may damage the unit. When depressing the push-buttons, use a blunt-tipped object and apply pressure gradually until you feel or hear the tactile response.

Note: The transmitter's input type, temperature units, sensor break direction, CJC on/off (TC units), input wiring (RTD units), and output range can only be set via the configuration program (Example: Type J, thermocouple, units: degrees Celsius, CJC ON, normal acting output, 4 to 20mA output). However, the front panel push-buttons allow virtually any part of the selected input range to be scaled to the configured output range (Example: Type J, 0 to 200°C input span, 4 to 20mA output - this configuration will be used as an example in the procedure below).

- Connect a precision voltage source; thermocouple calibrator, or RTD calibrator to the input, as required (refer to the Electrical Connections Drawing in your module's User's Manual, Drawing 4501-681 for our example). Also, per the module's output configuration, connect a precise milliampere or voltage meter to read the output signal required from the transmitter.
- Apply power and the module's green "Run" LED will light.
- Press and hold the "MODE" push button until the green "Run" LED turns OFF and the yellow "Zero/Full-Scale" LED turns ON. In this mode, the unit is ready to accept a zero input for the transmitter (see Table 4). If you do not wish to change the zero parameter, skip to step 7.
- Adjust the input source to the zero value. This value must be within the input range selected—for example: 0°C.
- Press the "UP" or "DOWN" push-button once. Refer to Functional Block Diagram 4501-689 and note that internally, the output of the Range Adjust Box is now set for 0.0% corresponding to our input zero value of 0°C. The transmitter will automatically adjust its output to the minimum output value (4.000mA). If the measured output is not exactly at the zero level (4.000mA), press the UP or DN switches to precisely adjust the output signal.

Note: After the first press of the UP & DN push-buttons, they will function as trim adjustments for the output stage. Each successive depression of the "UP" or "DN" switch will increment or decrement the output signal by a small amount. Holding the switch depressed will increase the amount of increment or decrement. The output trim adjustment should be limited to ±10% of nominal endpoint values.
- Press the "SET" push-button to accept the zero value. Note that every time "SET" is pressed, the yellow "Status" LED will flash once and the zero output will be captured.
- Press the "MODE" push button one time. The yellow "Zero/Full-Scale" LED will flash on/off, indicating that the unit is ready to accept the full-scale value. If you do not wish to change this parameter, skip to step 11.
- Adjust the input source to the full-scale value (the value must be within the input range selected). For Example: 200°C.

Note: The full-scale value must be greater than the zero value. If the zero and full-scale points are too close together, relative performance will be degraded.
- Press the "UP" or "DOWN" push-button once. Refer to Functional Block Diagram 4501-689 and note that internally, the output of the Range Adjust Box is now set for 100.0%, corresponding to our input full-scale value of 200°C. The transmitter will automatically adjust its output to the maximum output value (20.000mA). If the output is not exactly at the full-scale level (20.000mA), press the UP or DN switches to precisely adjust the output signal.

Transmitter/Alarm Programming Procedure...continued

Note: After the first press of the UP & DN push-buttons, they will function as trim adjustments for the output stage. Each successive depression of the "UP" or "DN" switch will increment or decrement the output signal by a small amount. Holding the switch depressed will increase the amount of increment or decrement. The output trim adjustment should be limited to $\pm 10\%$ of nominal endpoint values.

10. Press the "**SET**" push-button to accept the full-scale value. Note that every time "SET" is pressed, the yellow "Status" LED will flash once and the full-scale output will be captured.
11. If you are configuring an 801T-0500 model, which has no alarm function, then you should skip steps 12-17 and jump ahead to step 18.
12. Press the "**MODE**" push button one time until the yellow zero/full-scale LED goes out and the yellow relay LED turns ON (see Table 3). In this mode, the unit is ready to accept an input setpoint level for the alarm. If you do not wish to change the setpoint, skip to step 15.

Note: The setpoint can be set to any value covered by the input range selected. If you selected the TC Type J input type, you can program the setpoint from -200°C to 760°C . The zero and full-scale input values for the transmitter are independent of the setpoint. For example, you can have a setpoint of 300°C and a transmitter calibration of 0 to 200°C .
13. Adjust the input source to the High or Low alarm setpoint level.
14. Press the "**SET**" push button to accept the setpoint. Note that every time the "SET" button is pressed, the yellow status LED will flash once and the value at the input will be captured.
15. Press the "**MODE**" push button one time and the yellow relay LED should start flashing (see Table 3). This means that the unit is ready to accept the dropout level for the alarm relay. If you do not wish to change the dropout, skip to step 18.
16. Adjust the input source to the desired dropout level.
17. Press the "**SET**" push button to accept the input dropout level. Note that every time the "SET" button is pressed, the yellow status LED will flash once and the value at the input will be captured. The module will use the difference between the setpoint and dropout values to calculate the deadband.
18. Press the "**MODE**" push button one time to complete the program sequence and return to run mode. The green "RUN" LED will turn ON, the yellow "Zero/Full-Scale" LED will be OFF, and the yellow alarm LED will be on or off according to the alarm status. The module will now assume its transfer function based on the zero and full-scale values just set. Note that if no push-buttons are depressed for a period greater than 2 minutes, then the module will automatically revert to run mode (green "Run" LED will light) and no changes will be made to the original zero & full-scale, or optional setpoint & dropout settings.

Notes (Field Program Procedure):

1. To summarize, the green "Run" LED is turned off in field configuration mode. The yellow zero/full-scale LED is ON or FLASHING when the corresponding zero or full-scale value is being set in field configuration mode and turned OFF in run mode. The yellow alarm LED is ON or FLASHING when the corresponding setpoint or dropout/deadband level is being set in field configuration mode.
2. If the transmitter/alarm is in field configuration mode and no push buttons are pressed after 2 minutes, then the module will return to the run mode, the green "Run" LED will light, and no changes to any configuration parameters will be made.
3. Latching alarms require a push-button reset to exit the alarm state (this may also be accomplished under software control). Use the up or down push-buttons on the front of the module to reset a latched alarm relay.
4. The module's push-buttons and LED's operate differently in Field Configuration Mode as follows:

Module Push Buttons:

Mode - Used to change mode of field configuration.

Set - Used to accept input data during field calibration.

LED Indicators:

Run (Green) - Turned OFF in field configuration mode.

Status (Yellow) - Blinks each time SET is pressed to capture an I/O signal during field configuration.

Zero/Full-Scale (Yellow) - Constant ON or flashing ON/OFF indicates whether zero or full-scale is being adjusted (see Table 4).

Relay (Yellow) - Constant ON or flashing ON/OFF indicates whether alarm setpoint or dropout is being adjusted during field configuration (see Table 4).

5.0 TROUBLESHOOTING**SELF DIAGNOSTICS**

IntelliPack modules routinely perform internal diagnostics following power-up or upon reset. During this period, all LED's will turn ON momentarily, and the green "Run" LED will flash. If the diagnostics complete successfully, the "Run" LED will stop flashing after approximately two seconds, then remain ON. This indicates that the unit is operating normally. A continuously flashing green LED is indicative of a problem with the microcontroller or an unprogrammed module. A flashing "ST" status LED indicates an input signal is over or under range.

The IntelliPack Serial Port Adapter also contains a red LED visible at the small opening in the enclosure to the right of the RJ11 receptacle. If this LED is OFF or flashing, then a communication interface problem exists. A constant ON LED indicates a properly working and powered serial interface adapter.

TROUBLESHOOTING HINTS

1. **Cannot Communicate With Module** - ¹Does the Configuration Software indicate COMx (x is port number selected) in the lower right hand corner of the screen? If it is not indicated, have you selected "Settings-Serialport" since booting the Configuration Program? ²Does the Configuration Software indicate "SPA" in the lower right hand corner of the screen? If not, do you have the Serial Port Adapter connected to the correct serial port of the host computer? ³Is the red LED of the serial adapter OFF or FLASHING? Have you applied power to the module (the serial port adapter receives its power from the module)? ⁴Do you have the correct property sheets loaded for the model connected to the serial port adapter? You can select Module-Upload Configuration to auto-detect the model number and load the correct property sheets for your model.
2. **Continuously Flashing Green "Run" LED** - This indicates that there is a problem with the IntelliPack module or that it has not been initially programmed. First use the Configuration Software to reconfigure the module using Module-Download Configuration. If the problem persists, then use Module-Firmware Download to rewrite the modules code into its reprogrammable flash memory. If this fails to correct the problem, the microcontroller may need to be replaced. An effective and convenient fault diagnosis method is to exchange the questionable module with a known good unit.
3. **Green "Run" LED Fails To Light** - This may indicate that there is a problem with the power supply. This LED is also turned OFF in field configuration mode. Verify power connections to the alarm. Is power wired in the correct polarity? Is power level within the recommended 10-36V range? Is your power supply current being current-limited below 0.5A?
4. **Pushbutton Reset Fails to Reset Latched Contacts** - Is input level within normal operating range for the alarm (deadband applies)? Is your deadband too large? Has the correct failsafe or non-failsafe convention been applied? Will the module reset remotely via the Configuration Software?
5. **Continuously Flashing Yellow "ST" Status LED** - This indicates that an input signal is under or over range, or upscale/downscale lead break detection is in effect (thermocouple/RTD units). If the input signal measures correctly, then check that you have selected the correct input range. Is your input signal connected properly? If the problem persists, then you may have to recalibrate the input. Note that you can always use the Restore Factory Calibration button of the calibration property sheets to restore a module's original factory input, T-Ref, or output calibration.

If you continue to have problems with your IntelliPack hardware or software, Acromag's Application Engineers can provide further technical assistance at (248) 624-1541.

Notes:

TAG NO:

Acromag Inc. IntelliPack Configuration Report

Model: 801T-1500

General Information

TAG NO:

Location:

Comment:

Configured By:

Last Modified:

Serial Number:

Firmware Number:

Software Version: 9500-143B

Input 1 Configuration

Input ID:		Sensor Break:	Up
Input Range:	TC Type J, -210 to 760 °C	CJC:	On
Samples:	1		

Output 1 Configuration

Output Range:	0-10V DC	Output Mode:	Normal Acting
---------------	----------	--------------	---------------

Alarm 1 Configuration (Input 1)

Alarm Type:	Limit	Relay Number 1	
Mode:	High Limit	Reset Type:	Automatic (momentary)
Setpoint:	200.0000 °C	Operating Mode:	Failsafe
Deadband:	1.0000 °C	Time Delay:	0.2000 Seconds

User Notes: _____

Page ____ of ____.

TAG NO:

Acromag Inc. IntelliPack Configuration Report

Model: 801T-1500


Scaling

Input for 0% Output: -210.0000 °C
Input for 100% Output: 760.000 °C

Computation


Type: None

Module Transfer Characteristic




Page ___ of ___.



Acromag Inc., 30765 S. Wixom Road P.O. Box 437, Wixom Mich, 48393, U.S.A.
Tel: 248-624-1541, FAX: 248-624-9234, E-Mail: sales@acromag.com
©Copyright 1997, Acromag Inc., All Rights Reserved.



SERIES 8XXA COMPUTER CONNECTIONS





FAILSAFE ALARM CONDITIONS (RELAY NORMALLY ENERGIZED)



LIMIT TYPE	CONDITION	RELAY LED	RELAY CONTACTS
HIGH	NORMAL	OFF	ENERGIZED
HIGH	ALARM	ON	DE-ENERGIZED
LOW	NORMAL	OFF	ENERGIZED
LOW	ALARM	ON	DE-ENERGIZED

NON-FAILSAFE ALARM CONDITIONS (RELAY NORMALLY DE-ENERGIZED)




LIMIT TYPE	CONDITION	RELAY LED	RELAY CONTACTS
HIGH	NORMAL	OFF	DE-ENERGIZED
HIGH	ALARM	ON	ENERGIZED
LOW	NORMAL	OFF	DE-ENERGIZED
LOW	ALARM	ON	ENERGIZED


FAILSAFE / NON-FAILSAFE ALARM CONDITIONS

4501-623B
FIGURE 1

HIGH LIMIT ALARM



LOW LIMIT ALARM



LIMIT ALARM FUNCTION:

RELAY WILL ENTER THE ALARM STATE WHEN EITHER THE USER DEFINED HIGH OR LOW SETPOINT IS EXCEEDED FOR THE SPECIFIED AMOUNT OF TIME. RELAY REMAINS IN THE ALARM STATE UNTIL THE INPUT SIGNAL HAS RETREATED PAST THE DEFINED SETPOINT AND ANY APPLIED DEADBAND VALUE FOR THE SPECIFIED AMOUNT OF TIME.


NOTES:

1. AUTOMATIC RESET (NON LATCHING) ALARM IS SHOWN.
2. LATCHING ALARMS REQUIRE A PUSH BUTTON RESET TO EXIT THE ALARM STATE.
3. MINIMUM RELAY ALARM DELAY IS SHOWN.

LIMIT ALARM OPERATION




4501-623B
FIGURE 2

THERMOCOUPLE INPUT CALIBRATION CONNECTIONS



NOTE THAT CJC IS TURNED OFF FOR INPUT CALIBRATION AND TURNED ON FOR TEMPERATURE REFERENCE CALIBRATION.

TEMPERATURE REFERENCE CALIBRATION CONNECTIONS



INPUT CONNECTIONS (SEE INPUT CONNECTIONS AT LEFT)

NOTE: TB2-21,22 ARE RESERVED FOR THE CJC TEMPERATURE SENSOR AND SHOULD NOT BE CONNECTED TO.

THERMOCOUPLE INPUT CALIBRATION CONNECTIONS MODELS 801T-0500 AND 801T-1500

4501-699A