# FUJIFILM

# FINEPIX XP170 FINEPIX XP150/XP160 FINEPIX XP100/XP110

## **Owner's Manual**

Thank you for your purchase of this product. This manual describes how to use your FUJIFILM digital camera and the supplied software. Be sure that you have read and understood its contents and the warnings in "For Your Safety" ( ii) before using the camera.



Before You Begin
First Steps
Basic Photography and Playback
More on Photography
More on Playback
Movies
Connections
Menus
Technical Notes
Troubleshooting
Appendix

For information on related products, visit our website at http://www.fujifilm.com/products/digital\_cameras/index.html



BL01735-200 EN

## **IMPORTANT SAFETY INSTRUCTIONS**

- <u>Read Instructions</u>: All the safety and operating instructions should be read before the appliance is operated.
- <u>Retain Instructions</u>: The safety and operating instructions should be retained for future reference.
- <u>Heed Warnings</u>: All warnings on the appliance and in the operating instructions should be adhered to.
- Follow Instructions: All operating and use instructions should be followed.

#### Installation

Power Sources: This video product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your appliance dealer or local power company. For video products intended to operate from battery power, or other sources, refer to the operating instructions.

Grounding or Polarization: This video product is equipped with a polarized alternatingcurrent line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug. Alternate Warnings: This video product is equipped with a three-wire grounding-type plug, a plug having a third (grounding) pin. This plug will only fit into a grounding-type power outlet. This is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the grounding type plug.

**Overloading**: Do not overload wall outlets and extension cords as this can result in a risk of fire or electric shock.

Ventilation: Slots and openings in the cabinet are provided for ventilation, to ensure reliable operation of the video product and to protect it from overheating, and these openings must not be blocked or covered. The openings should never be blocked by placing the video product on a bed, sofa, rug, or other similar surface.

This video product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to. This video product should never be placed near or over a radiator or heat register.

**Attachments**: Do not use attachments not recommended by the video product manufacturer as they may cause hazards.

Water and Moisture: Do not use this video product near water—for example, near a bath tub, wash bowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool, and the like (excluding waterproof products).

Power-Cord Protection: Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the appliance.

Accessories: Do not place this video product on an unstable cart, stand, tripod, bracket, or table. The video product may fall, causing serious injury to a child or adult, and serious damage to the appliance. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the video product. Any mounting of the appliance should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.

An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.




### For Your Safety

#### Antennas

Outdoor Antenna Grounding: If an outside antenna or cable system is connected to the video product, be sure the antenna or cable system is grounded so as to provide some protection against voltage surges and builtup static charges. Section 810 of the National Electrical Code, ANS//NFPA No. 70, provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna discharge unit, connection to grounding electrodes, and requirements for the grounding electrode.

#### EXAMPLE OF ANTENNA GROUNDING AS PER NATIONAL FLECTRICAL CODE



Power Lines: An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.

### Use

**Cleaning:** Unplug this video product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

Object and Liquid Entry: Never push objects of any kind into this video product through openings as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the video product (excluding waterproof products).

Lightning: For added protection for this video product receiver during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the video product due to lightning and power-line surges.

### Service

Servicing: Do not attempt to service this video product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

Damage Requiring Service: Unplug this video product from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- When the power-supply cord or plug is damaged.
- If liquid has been spilled, or objects have fallen into the video product.
- If the video product has been exposed to rain or water (excluding waterproof products).
- If the video product has been dropped or the cabinet has been damaged.

Downloaded from ManualsCamera.com Manuals

If the video product does not operate normally follow the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the video product to its normal operation.

When the video product exhibits a distinct change in performance—this indicates a need for service.

Replacement Parts: When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other hazards.

Safety Check: Upon completion of any service or repairs to this video product, ask the service technician to perform safety checks to determine that the video product is in proper operating condition.

### Be sure to read these notes before use

### Safetv Notes

- · Make sure that you use your camera correctly. Read these safety notes and your Owner's Manual carefully before use.
- After reading these safety notes, store them in a safe place.

### About the lcons

The icons shown below are used in this document to indicate the severity of the injury or damage that can result if the information indicated by the icon is ignored and the product is used incorrectly as a result



This icon indicates that death or serious injury can result if the information is ignored.



This icon indicates that personal injury or material damage can result if the information is ignored.

The icons shown below are used to indicate the nature of the instructions which are to be observed.



Triangular icons tell you that this information requires attention ("Important").

Circular icons with a diagonal bar tell you that the action indicated is prohibited ("Prohibited").

Filled circles with an exclamation mark indicate an action that must be performed ("Required").





If a problem arises, turn the camera off, remove the battery, and disconnect and unplug the AC power adapter. Continued use of the camera when it is emitting smoke, is emitting any unusual odor, or is in any other abnormal state can cause a fire or electric shock. Contact your FUJIFILM dealer.



Do not allow water or foreign objects to enter the camera. If water or foreign objects get inside the camera, turn the camera off, remove the battery, and disconnect and unplug the AC power adapter. Continued use of the camera can cause a fire or electric shock. Contact your FUJIFILM dealer.

Downloaded from ManualsCamera.com Manuals

## 

### Do not use the camera in the bathroom or shower (excludina water-

proof products). This can cause a fire or electric shock Do not use in the hathroom or shower



Never attempt to change or take apart the camera (never open the case). Failure to observe this precaution can cause fire or electric shock



Should the case break open as the result of a fall or other accident. do not touch the exposed parts. Failure to observe this precaution could result in electric shock or in injury from touching the damaged parts. Remove the battery immediately, taking care to avoid injury or electric shock, and take the product to the point of purchase for consultation.



Do not change, heat or unduly twist or pull the connection cord and do not place heavy objects on the connection cord. These actions could damage the cord and cause a fire or electric shock. If the cord is damaged, contact your FUJIFILM dealer.



Do not place the camera on an unstable surface. This can cause the camera to fall or tip over and cause injury.

Never attempt to take pictures while in motion. Do not use the camera while you are walking or driving a vehicle. This can result in you falling down or being involved in a traffic accident.



Do not touch any metal parts of the camera during a thunderstorm. This can cause an electric shock due to induced current from the lightning discharge.



Do not use the battery except as specified. Load the battery as shown by the indicator.





Use only the battery or AC power adapters specified for use with this camera. Do not use voltages other than the power supply voltage shown. The use of other power sources can cause a fire.



If the battery leaks and fluid gets in contact with your eyes, skin or clothina. flush the affected area with clean water and seek medical attention or call an emeraency number right away.

### For Your Safety

VARNING			<b>CAUTION</b>
	Do not use the charger to charge batteries other than those speci- fied here. The supplied battery charger is for use only with the		eep out of the reach of small children. This product could cause jury in the hands of a child.
$\bigcirc$	type of battery supplied with the camera. Using the charger to charge conventional batteries or other types of rechargeable batteries can cause the battery to leak fluid, overheat or burst.		o not place heavy objects on the camera. This can cause the eavy object to tip over or fall and cause injury.
	Danger of explosion if battery is incorrectly replaced. Replace only		o not move the camera while the AC power adapter is still connect
U	with the same or equivalent type.		1. Do not pull on the connection cord to disconnect the AC power dapter. This can damage the power cord or cables and cause
	Do not use in the presence of flammable objects, explosive gases,		fire or electric shock.
0	or dust.		o not use the AC power adapter when the plug is damaged or the
•	When carrying the battery, install it in a digital camera or keep it in the hard case. When storing the battery, keep it in the hard case.		l <b>ug socket connection is loose.</b> This could cause a fire or electric nock.
U	When discarding, cover the battery terminals with insulation tape. Contact with other metallic objects or batteries could cause the battery to ignite or burst.		o not cover or wrap the camera or the AC power adapter in a cloth (blanket, This can cause heat to build up and distort the cas g or cause a fire.
0	Keep memory cards out of the reach of small children. Because memory cards are small, they can be swallowed by children. Be sure to store memory cards out of the reach of small chil- dren. If a child swallows a memory card, seek medical atten- tion or call an emergency number.		then you are cleaning the camera or you do not plan to use the imera for an extended period, remove the battery and disconnect and unplug the AC power adapter. Failure to do so can cause a e or electric shock.
0	Turn the camera off in crowds. The camera emits radio-frequency radiation that may interfere with pacemakers.	Le Le	then charging ends, unplug the charger from the power socket eaving the charger plugged into the power socket can cause fire
0	Turn the camera off in the vicinity of automatic doors, public address systems, and other automatically controlled devices. The camera emits radio-frequency radiation that may cause these devices		sing a flash too close to a person's eyes may temporarily affect the resight. Take particular care when photographing infants and
	to malfunction.	yc yc	bung children.
0	Keep the camera at least 22 cm away from people wearing pace- makers. The camera emits radio-frequency radiation that may interfere with pacemakers.		then a memory card is removed, the card could come out of the slow or quickly. Use your finger to hold it and gently release the card jury could result to those struck by the ejected card.
	interfere man pacemakers.		equest regular internal testing and cleaning for your camera
	AUTION		uild-up of dust in your camera can cause a fire or electric nock. Contact your FUJIFILM dealer to request internal clean
$\bigcirc$	<b>Do not use this camera in locations affected by oil fumes or steams.</b> This can cause a fire or electric shock.		g every two years. Please note that this service is not free f charge.
0	Do not use this camera in locations affected by humidity or dust		
$(\mathbf{n})$	(excluding waterproof products). This can cause a fire or elec-		

tric shock.

Do not leave this camera in places subject to extremely high temperatures. Do not leave the camera in locations such as a sealed vehicle or in direct sunlight. This can cause a fire.

### For Your Safety

### The Battery and Power Supply

**Note:** Check the type of battery used in your camera and read the appropriate sections.

The following describes the proper use of batteries and how to prolong their life. Incorrect use can shorten battery life or cause leakage, overheating, fire, or explosion.

#### Li-ion Batteries

Read this section if your camera uses a rechargeable Li-ion battery.

The battery is not charged at shipment. Charge the battery before use. Keep the battery in its case when not in use.

#### Notes on the Battery

The battery gradually loses its charge when not in use. Charge the battery one or two days before use.

Battery life can be extended by turning the camera off when not in use.

Battery capacity decreases at low temperatures; a depleted battery may not function at when cold. Keep a fully charged spare battery in a warm place and exchange as necessary, or keep the battery in your pocket or other warm place and insert it in the camera only when shooting. Do not place the battery in direct contact with hand warmers or other heating devices.

### Charging the Battery

Charge the battery in the supplied battery charger. Charging times will increase at ambient temperatures below +10°C (+50°F) or above +35°C (+95°F). Do not attempt to charge the battery at temperatures above 40°C (+104°F); at temperatures below 0°C (+32°F), the battery will not charge.

Do not attempt to recharge a fully charged battery. The battery does not however need to be fully discharged before charging.

The battery may be warm to the touch immediately after charging or use. This is normal.

#### Battery Life

At normal temperatures, the battery can be recharged about 300 times. A noticeable decrease in the length of time the battery will hold a charge indicates that it has reached the end of its service life and should be replaced.

#### Storage

Performance may be impaired if the battery is left unused for extended periods when fully charged. Run the battery flat before storing it.

If the camera will not be used for an extended period, remove the battery and store it in a dy place with an ambient temperature of from  $+15^{\circ}C$  to  $+25^{\circ}C$  ( $+59^{\circ}F$  to  $+77^{\circ}F$ ). Do not store in locations exposed to extremes of temperature.

#### Cautions: Handling the Battery

- Do not transport or store with metal objects such as necklaces or hairpins.
- · Do not expose to flame or heat.
- · Do not disassemble or modify.
- Use with designated chargers only.
- Do not drop or subject to strong physical shocks.
- · Do not expose to water.
- · Keep the terminals clean.
- The battery and camera body may become warm to the touch after extended use. This is normal.

#### AA Alkaline/Rechargeable NiMH Batteries

Read this section if your camera uses AA alkaline or rechargeable AA NiMH batteries. Information on compatible battery types may be found elsewhere in the camera manual.

#### Cautions: Handling the Batteries

- Do not expose to water, flame, or heat, or store in warm or humid conditions.
- Do not transport or store with metal objects such as necklaces or hairpins.
- Do not disassemble or modify the batteries or battery casing.
- · Do not subject to strong physical shocks.
- Do not use batteries that are leaking, deformed, or discolored.
- Keep out of reach of infants and small children.
- · Insert in the correct orientation.

- Do not mix old and new batteries, batteries with different charge levels, or batteries of different types.
- If the camera will not be used for an extended period, remove the batteries. Note that the camera clock will be reset.
- The batteries may be warm to the touch immediately after use. Turn the camera off and allow the batteries to cool before handling.
- Battery capacity tends to decrease at low temperatures. Keep spare batteries in a pocket or other warm place and exchange as necessary. Cold batteries may recover some of their charge when warmed.
- Fingerprints and other stains on the battery terminals can impair battery performance. Thoroughly clean the terminals with a soft, dry cloth before inserting them in the camera.



If the batteries leak, clean the battery compartment thoroughly before inserting new batteries.



If fluid from the battery comes into contact with skin or clothing, flush the affected area with water. If fluid enters your eyes, immediately flush the affected area with water and seek medical attention. Do not rub your eyes. Failure to observe this precaution could result in permanent visual impairment

#### NiMH Batteries

The capacity of Ni-MH batteries may be temporarily reduced when new, after long periods of disuse, or if they are repeatedly recharged before being fully discharged. This is normal and does not indicate a malfunction. Capacity can be increased by repeatedly discharging the batteries using the discharge option in the camera setup menu and recharging them using a battery charger.

① CAUTION: Do not use the discharge option with alkaline batteries.

The camera draws a small amount of current even when off. Ni-MH batteries that have been left in the camera for an extended period may be drawn down to the point that they no longer hold a charge. Battery performance may also drop if the batteries are run down in a device such as a flashlight. Use the discharge option in the camera setup menu to discharge Ni-MH batteries. Batteries that no longer hold a charge even after repeatedly being discharged and recharged have reached the end of their service life and must be replaced.

Ni-MH batteries can be recharged in a battery charger (sold separately). Batteries may become warm to the touch after charging. Refer to the instructions provided with the charger for more information. Use the charger with compatible batteries only.

Ni-MH batteries gradually lose their charge when not in use.

#### Disposal

Dispose of used batteries in accord with local regulations.

### AC Power Adapters (Available Separately)

This section applies to all camera models. Use only FUJIFILM AC power adapters designated for use with this camera. Other adapters could damage the camera.

- · The AC power adapter is for indoor use only.
- Be sure the DC plug is securely connected to the camera.
- Turn the camera off before disconnecting the adapter. Disconnect the adapter by the plug, not the cable.
- · Do not use with other devices.
- · Do not disassemble.
- · Do not expose to high heat and humidity.
- · Do not subject to strong physical shocks.
- The adapter may hum or become hot to the touch during use. This is normal.
- If the adapter causes radio interference, reorient or relocate the receiving antenna.

#### Using the Camera

Do not aim the camera at extremely bright light sources, such as the sun in a cloudless sky. Failure to observe this precaution could damage the camera image sensor.

#### Take Test Shots

Before taking photographs on important occasions (such as at weddings or before taking the camera on a trip), take a test shot and view the result in the LCD monitor to ensure that the camera is functioning normally. FUJIFILM Corporation can not accept liability for damages or lost profits incurred as a result of product malfunction.

### Notes on Copyright

Unless intended solely for personal use, images recorded using your digital camera system cannot be used in ways that infringe copyright laws without the consent of the owner. Note that some restrictions apply to the photographing of stage performances, entertainments, and exhibits, even when intended purely for personal use. Users are also asked to note that the transfer of memory cards containing images or data protected under copyright laws is only permissible within the restrictions imposed by those copyright laws.

#### Handling

To ensure that images are recorded correctly, do not subject the camera to impact or physical shocks while images are being recorded.

### Liquid Crystal

In the event that the LCD monitor is damaged, care should be taken to avoid contact with liquid crystal. Take the urgent action indicated should any of the following situations arise:

- If liquid crystal comes in contact with your skin, clean the area with a cloth and then wash thoroughly with soap and running water.
- If liquid crystal enters your eyes, flush the affected eye with clean water for at least 15 minutes and then seek medical assistance.
- If liquid crystal is swallowed, rinse your mouth thoroughly with water. Drink large quantities of water and induce vomiting, then seek medical assistance.

Although the display is manufactured using extremely high-precision technology, it may contain pixels that are always lit or that do not light. This is not a malfunction, and images recorded with the product are unaffected.

### Trademark Information

xD-Picture Card and \_\_\_\_\_ are trademarks of FUJIFILM Corporation. The typefaces included herein are solely developed by Dyna-Comware Taiwan Inc. Macintosh, OuickTime, and Mac OS are trademarks of Apple Inc. in the U.S.A. and other countries. Windows 7. Windows Vista, and the Windows logo are trademarks of the Microsoft group of companies. Adobe and Adobe Reader are either trademarks or registered trademarks of Adobe Systems Incorporated in the U.S.A. and/ or other countries. The SDHC and SDXC logos are trademarks of SD-3C, LLC. The HDMI logo is a trademark. YouTube is a trademark of Google Inc. All other trade names mentioned in this manual are the trademarks or registered trademarks of their respective owners.

Downloaded from ManualsCamera.com Manuals

#### Electrical Interference

This camera may interfere with hospital or aviation equipment. Consult with hospital or airline staff before using the camera in a hospital or on an aircraft.

### **Color Television Systems**

NTSC (National Television System Committee) is a color television telecasting specification adopted mainly in the U.S.A., Canada, and Japan. PAL (Phases Alternation by Line) is a color television system adopted mainly in European countries and China.

### Exif Print (Exif Version 2.3)

Exif Print is a newly revised digital camera file format in which information stored with photographs is used for optimal color reproduction during printing.

### IMPORTANT NOTICE: Read Before Using the Software

Direct or indirect export, in whole or in part, of licensed software without the permission of the applicable governing bodies is prohibited. **IMPORTANT**: Read this section before using the toponyms included in this product.

### Toponym Data License Agreement

Personal Use Only, You agree to use this Data together with this digital camera for the solely personal, non-commercial purposes for which you were licensed, and not for service bureau, time-sharing or other similar purposes. Accordingly, but subject to the restrictions set forth in the following paragraphs, you may copy this Data only as necessary for your personal use to (i) view it, and (ii) save it, provided that you do not remove any copyright notices that appear and do not modify the Data in any way. You agree not to otherwise reproduce, copy, modify, decompile, disassemble or reverse engineer any portion of this Data, and may not transfer or distribute it in any form, for any purpose, except to the extent permitted by mandatory laws. Multi-disc sets may only be transferred or sold as a complete set as provided by FUJIFILM Corporation and not as a subset thereof.

Restrictions, Except where you have been specifically licensed to do so by FUJFILM Corporation, and without limiting the preceding paragraph, you may not (a) use this Data with any products, systems, or applications installed or otherwise connected to or in communication with vehicles, capable of vehicle navigation, positioning, dispatch, real time route guidance, fleet management or similar applications; or (b) with or in communication with any positioning devices or any mobile or wireless-connected electronic or computer devices, including without limitation cellular phones, palmtop and handheld computers, pagers, and personal digital assistants or PDAs.

Warning. The Data may contain inaccurate or incomplete information due to the passage of time, changing circumstances, sources used and the nature of collecting comprehensive geographic data, any of which may lead to incorrect results.

<u>No Warranty</u>. This Data is provided to you "as is," and you agree to use it at your own risk. FUJIFILM Corporation and its licensors (and their licensors and suppliers) make no guarantees, representations or warranties of any kind, express or implied, arising by law or otherwise, including but not limited to, content, quality, accuracy, completeness, effectiveness, reliability, fitness for a particular purpose, usefulness, use or results to be obtained from this Data, or that the Data or server will be uninterrupted or error-free.

Disdaimer of Warranty: FUJIFILM Corporation AND ITS LICENSORS (INCLUDING THEIR LICENSORS AND SUPPLIERS) DISCLAIM ANY WARRANTES, EXPRESS OR IMPLIED, OF QUALITY, PERFORMANCE, MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT. Some States, Territories and Countries do not allow certain warranty exclusions, so to that extent the above exclusion may not apply to you.

Disclaimer of Liability: FUJIFILM Corporation AND ITS LICENSORS (IN-CLUDING THEIR LICENSORS AND SUPPLIERS) SHALL NOT BE LIABLE TO YOU: IN RESPECT OF ANY CLAIM, DEMAND OR ACTION, IRRESPECTIVE OF THE NATURE OF THE CAUSE OF THE CLAIM, DEMAND OR ACTION ALLEGING ANY LOSS, INJURY OR DAMAGES, DIRECT OR INDIRECT, WHICH MAY RESULT FROM THE USE OR POSSESSION OF THE INFOR-MATION: OR FOR ANY LOSS OF PROFIT, REVENUE, CONTRACTS OR SAVINGS, OR ANY OTHER DIRECT, INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF YOUR USE OF OR INABILITY TO USE THIS INFORMATION, ANY DEFECT IN THE INFORMA-TION, OR THE BREACH OF THESE TERMS OR CONDITIONS, WHETHER IN AN ACTION IN CONTRACT OR TORT OR BASED ON A WARRANTY. EVEN IF FUJIELI M Corporation OR ITS LICENSORS HAVE BEEN ADVISED. OF THE POSSIBILITY OF SUCH DAMAGES. Some States. Territories and Countries do not allow certain liability exclusions or damages limitations, so to that extent the above may not apply to you.

Export Control, You agree not to export from anywhere any part of the Data provided to you or any direct product thereof except in compliance with, and with all licenses and approvals required under, applicable export laws, rules and regulations.

Entire Agreement. These terms and conditions constitute the entire agreement between FUJIFILM Corporation (and its licensors, including their licensors and suppliers) and you pertaining to the subject matter hereof, and supersedes in their entirety any and all written or oral agreements previously existing between us with respect to such subject matter.

### For Your Safety

<u>Governing Law.</u> The above terms and conditions shall be governed by the laws of the State of Illinois, Netherlands, without giving effect to (i) its conflict of laws provisions, or (ii) the United Nations Convention for Contracts for the International Sale of Goods, which is explicitly excluded. You agree to submit to the jurisdiction of the State of Illinois, The Netherlands for any and all disputes, claims and actions arising from or in connection with the Data provided to you hereunder.

<u>Geodetics</u>. The geodetic system used by this device to record latitude and longitude is WGS 84.

<u>Copyright</u>. The map data included in this device are protected under copyright law and except for personal use may not be employed without the permission of the copyright holder.

Navigation. This device can not be used for purposes of navigation.

#### Licensed Software Copyright Holders



© 2010 NAVTEQ All rights reserved.



This service uses POI (Points Of Interest) of ZENRIN CO., LTD. "POWERED BY ZENRIN" is a trademark of ZENRIN CO., LTD. © 2010 ZENRIN CO., LTD. All rights reserved.

© Her Majesty the Queen in Right of Canada, © Queen's Printer for Ontario, © Canada Post Corporation, GeoBase<sup>®</sup>, © Department of Natural Resources Canada, ZIP+4<sup>®</sup>, © United States Postal Service<sup>®</sup> 2010. the USPS<sup>®</sup>.

Australia	Copyright. Based on data provided under license from PSMA Australia Limited (www.psma.com.au).
Austria	"© Bundesamt für Eich- und Vermes- sungswesen"
Croatia, Cyprus, Estonia, Latvia, Lithuania, Moldova, Poland, Slovenia and/ or Ukraine	"© EuroGeographics"
France	The following notice must appear on all copies of the Data, and may also appear on packaging: "source: © IGN France – BD TOPO®"
Germany	"Die Grundlagendaten wurden mit Genehmigung der zuständigen Behörden entnommen" or "Die Grundlagendaten wurden mit Genehmigung der zustaendi- gen Behoerden entnommen."
Great Britain	"Based upon Crown Copyright material."
Greece	"Copyright Geomatics Ltd."
Hungary	"Copyright © 2003; Top-Map Ltd."
Italy	"La Banca Dati Italiana è stata prodotta usando quale riferimento anche cartografia numerica ed al tratto prodotta e fornita dalla Regione Toscana."
Norway	"Copyright © 2000; Norwegian Mapping Authority"
Portugal	"Source: IgeoE – Portugal"
Spain	"Información geográfica propiedad del CNIG"
Sweden	"Based upon electronic data Ó National Land Survey Sweden."
Switzerland	"Topografische Grundlage: Ó Bundesamt für Landestopographie."

### Governing Law

<u>POL information in Japan</u>: The above terms and conditions shall be governed by the laws of Japan, without giving effect to (i) its conflict of laws provisions, or (ii) the United Nations Convention for Contracts for the International Sale of Goods, which is explicitly excluded. You agree to submit to the exclusive jurisdiction of the Tokyo District Court in the first instance for any and all disputes, claims and actions arising from or in connection with the Data provided to you hereunder.

**POI information outside Japan:** The above terms and conditions shall be governed by the laws of the State of Illinois, without giving effect to (i) its conflict of laws provisions, or (ii) the United Nations Convention for Contracts for the International Sale of Goods, which is explicitly excluded. You agree to submit to the jurisdiction of the State of Illinois for any and all disputes, claims and actions arising from or in connection with the Data provided to you hereunder.

Government End Users: If the Data is being acquired by or on behalf of the United States government or any other entity seeking or applying rights similar to those customarily claimed by the United States government, this Data is a "commercial item" as that term is defined at 48 C.F.R. ("FAR") 2.101, is licensed in accordance with these End-User Terms, and each copy of Data delivered or otherwise furnished shall be marked and embedded as appropriate with the following "Notice of Use;" and shall be treated in accordance with such Notice:

### NOTICE OF USE

CONTRACTOR (MANUFACTURER/ SUPPLIER) NAME: NAVTEQ

CONTRACTOR (MANUFACTURER/SUPPLIER) ADDRESS: 425 West Randolph Street, Chicago, Illinois 60606

This Data is a commercial item as defined in FAR 2.101 and is subject to these End-User Terms under which this Data was provided.

© 2010 NAVTEQ - All rights reserved.

If the Contracting Officer, federal government agency, or any federal official refuses to use the legend provided herein, the Contracting Officer, federal government agency, or any federal official must notify NAVTEQ prior to seeking additional or alternative rights in the Data.

## **About This Manual**

icon or error message in the display.


Before using the camera, read this manual and the warnings in "For Your Safety" (📖 ii). For information on specific topics, consult the sources below.

Table of Contents 💷 xvi	Troubleshooting 🕮 103
The "Table of Contents" gives an overview of the entire manual. The principal camera operations are listed here.	Having a specific problem with the camera? Find the answer here.
Warning Messages and Displays 💷 110	
Find out what's behind that flashing	

## Memory Cards

Pictures can be stored in the camera's internal memory or on optional SD, SDHC, and SDXC memory cards (IIII), referred to in this manual as "memory cards." Downloaded from ManualsCamera.com Manuals

## Frequently-Used Buttons



## **Product Features and Precautions for Use**

### Water, Dust, and Shock Resistance

① The camera complies with JIS Class 8 water resistance and JIS Class 6 (IP68) dust resistance standards, and has passed FUJIFILM drop tests (drop height: 2.0 m/6.5 ft.; impact surface: plywood, thickness 5 cm/2.0 in.) compliant with MIL-STD 810F Method 516.5: Shock. These results were obtained through in-house testing and are not a blanket guarantee of water resistance or invulnerability to damage or destruction. The accessories supplied with the camera are not water resistant.

### Before Use

- ${\rm \oplus}$  The front surface of the camera lens is protected by a sheet of glass. Foreign matter on the glass will appear in photographs; keep the glass clean at all times.
- ${\rm I\!D}$  Be sure that the battery-chamber is fully latched. The presence of water, mud, or sand in the camera could cause malfunction.
- ${\scriptstyle \oplus}$  Do not open or close the battery-chamber with wet hands or near water, for example while on or by a body of water.
- $\oplus$  Be sure the camera is completely dry before inserting or removing batteries or memory cards or connecting the USB or A/V cable.

### During Use

- ① Restrict underwater use to depths of 10 m (32 ft.) or less and periods shorter than 120 minutes.
- ${\scriptstyle \oplus}\,$  Do not open or close the battery-chamber cover while under water.
- ① Do not use in hot springs or heated pools.
- ${\scriptstyle \oplus}\,$  Do not dive into water with the camera or otherwise subject it to excessive force.
- ${\rm I}\!\!\!\!$  If the camera is left on the sand, its temperature may exceed operating limits and sand may get into the speaker or microphone.
- ${\rm \oplus}\,$  Sunscreen, suntan lotion, or other oily substances may discolor the camera body and should be removed with a damp cloth.
- ① The camera may lose water resistance if subjected to excessive force or vibration. Consult your retailer or a FUJIFILM-authorized repair technician.

### After Use

- ① After using the camera underwater or in locations where foreign matter might adhere to the camera body, rinse the camera under the tap or leave it in a basin of fresh water for two to three minutes.
- ① Liquid soaps, detergents, alcohol, and other cleansers may affect water resistance and should never be used.
- ① After use, remove water droplets and foreign matter with a dry cloth, firmly latch the batterychamber cover, and soak the camera in fresh water for about ten minutes. Dry the camera thoroughly after removing it from the water.

### Storage and Maintenance

- $\oplus$  Do not store at temperatures below 0 °C (32 °F) or above 40 °C (104 °F).
- ① To ensure continued water resistance, it is recommended that you have the water-resistant seal replaced about once a year (a fee is charged for this service). Contact your retailer or a FUJIFILM-authorized repair technician for more information.

## Cold Climates

- Battery performance drops at low temperatures, reducing the number of pictures that can be taken. Insulate the camera to keep it warm or place it in your clothing.
- ① Use an NP-50A battery.
- ① Display response may slow at low temperatures. This is not a malfunction.

## **Table of Contents**

For Your Safety	ii
IMPORTANT SAFETY INSTRUCTIONS	ii
Safety Notes	iv
About This Manual	xii
Frequently-Used Buttons	xiii
Product Features and Precautions for Use	

## **Before You Begin**

Symbols and Conventions	1
Supplied Accessories	1
Parts of the Camera	
Camera Displays	4
Shooting	
Playback	

## **First Steps**

Charging the Battery	7
Inserting the Battery and a Memory Card	
Compatible Memory Cards	14
Turning the Camera on and Off	16
Shooting Mode	16
Playback Mode	16
Basic Setup	

## **Basic Photography and Playback**

Taking Pictures in 🔊 (Scene Recognition) Mode	19
Viewing Pictures	23

More on Photography	
Shooting Mode	24
Choosing a Shooting Mode	
Shooting Mode Options	
nter pro low-light	27
THOR D-RANGE PRIORITY	28
MOTION PANORAMA 360	
Recording GPS Data with Pictures (Only XP150/160)	31
The GPS Menu	32
GPS Tracking	34
🕰 Intelligent Face Detection	36
Focus Lock	37
🔀 Exposure Compensation	39
S Macro Mode (Close-ups)	40
<b>4</b> Using the Flash (Intelligent Flash)	41
ి Using the Self-Timer	43
More on Playback	
Playback Options	44
★ Favorites: Rating Pictures	
Playback Zoom	45
Multi-Frame Playback	
Deleting Pictures	47
🐯 Image Search	48
PhotoBook Assist	49
Creating a PhotoBook	49
Viewing Photobooks	50
Editing and Deleting Photobooks	50
Viewing Panoramas	51

Downloaded from ManualsCamera.com Manuals

## Table of Contents

Photo Navigation54	CONTINUOUS
Copying GPS Data to Other Images55	🖸 FACE DETECTION
Viewing the GPS Track56	<b>AF MODE</b>
Deleting Track Logs57	MOVIE AF MODE

Usi

U

P

### Movies

Recording Movies	58
Movie Frame Size	
Viewing Movies	60

### Connections

Viewing Pictures on TV	6
Viewing Pictures on High-Definition TVs	62
Printing Pictures via USB	6
Printing the DPOF Print Order	6
Viewing Pictures on a Computer	6
Windows: Installing MyFinePix Studio	6
Macintosh: Installing FinePixViewer	69
Connecting the Camera	7

## Menus

Using the Menus: Shooting Mode	74
Using the Shooting Menu	74
Shooting Menu Options	74
SHOOTING MODE	
 ISO	
■ IMAGE SIZE	
🛋 IMAGE QUALITY	

Ìr	FINEPIX COLOR	.76
WB	WHITE BALANCE	.77
<u>Q</u>	CONTINUOUS	.78
2	FACE DETECTION	.78
[]	AF MODE	.79
[]	MOVIE AF MODE	.79
) <sup>20</sup>	MOVIE MODE	.79
Ð	LED ILLUMINATOR	.80
	he Menus: Playback Mode	
sing	the Playback Menu	.81
	ack Menu Options	
Ĺ	PHOTOBOOK ASSIST	.81
	IMAGE SEARCH	
亩	ERASE	.81
\$	EDIT	.82
**	MOVIE EDIT	.83
	MARK FOR UPLOAD TO	
	SLIDE SHOW	
	RED EYE REMOVAL	
	PROTECT	
	CROP	.87
	RESIZE	.87
	IMAGE ROTATE	
	СОРҮ	
_	PRINT ORDER (DPOF)	
_	DISP ASPECT	

## Table of Contents

The Setup Menu	90
Using the Setup Menu	90
Setup Menu Options	
DATE/TIME	
time difference	91
থා 言語/LANG	91
SILENT MODE	91
🕵 RESET	92
🕞 FORMAT	92
🖃 IMAGE DISP	92
🖭 FRAME NO	
OPERATION VOL.	94
SHUTTER VOLUME	94
🗪 SOUND	
PLAYBACK VOLUME	
🔅 LCD BRIGHTNESS	94
ffs LCD MODE	
auto Power OFF	
🐲 DUAL IS MODE	
RED EYE REMOVAL	
🔍 DIGITAL ZOOM	
🗠 MOVIE ZOOM TYPE	
SAVE ORIGINAL IMAGE	
AUTOROTATE PB (XP150/XP160 Only)	
GUIDANCE DISPLAY	
NTSC VIDEO SYSTEM	
date DATE STAMP	
GFS DEMONSTRATION (XP150/XP160 Only)	98

Technical Notes	
Optional Accessories	99
Accessories from FUJIFILM	100
Caring for the Camera	
Storage and Use	101
Condensation	101
Cleaning	
Traveling	102
Troubleshooting	
Problems and Solutions	103
Warning Messages and Displays	110
Appendix	
Tips and Tricks	114
Internal Memory/Memory Card Capacity	
FinePix XP150/XP160	117
FinePix XP170/XP100/XP110	118
Specifications	119

🖙 Uploading Pictures to a Smartphone (Tablet)	
(XP170 Only)	.125

## **Before You Begin**

## Symbols and Conventions


The following symbols are used in this manual:

- $\ensuremath{\mathbbm O}$  : This information should be read before use to ensure correct operation.
- > : Additional information that may be helpful when using the camera.
- 🖽 : Other pages in this manual on which related information may be found.

Menus and other text in the LCD monitor are shown in **bold**. In the illustrations in this manual, displays may be simplified for explanatory purposes.

## Supplied Accessories


The following items are included with the camera:



\* Shape of adapter varies with region of sale.

## Parts of the Camera

For more information, refer to the page listed to the right of each item.



\* The illustrations in this manual have been simplified for explanatory purposes.

## Downloaded from ManualsCamera.com Manuals

Before You Begin

### Parts of the Camera

1 Zoom control20, 45	12 • (movie recording) button
2 Shutter button	13 Indicator lamp (see below)
<b>3 ON/OFF</b> button	14 Latch9, 12
4 Flash	15 Safety lock9, 12
5 🖙 button (XP170 only) 125	16 Strap eyelet 1
GPS button (XP150/XP160 only)	17 DISP (display)/BACK button6, 18
↔ (brightness) button (XP100/XP110 only)6	d∉ (silent mode) button <sup>*</sup> xiii
6 Self-timer lamp	18 🕨 (playback) button
LED illuminator 80	19 Tripod mount
7 Built-in GPS antenna (XP150/XP160 only)	20 Battery chamber9
8 Lens/protective glass	21 USB multi-connector63, 71
9 Speaker	22 Memory card slot 11
10 Microphone	23 Micro HDMI connector
11 LCD monitor	24 Battery latch
*Press and hold the <b>DISP/BACK</b> button until <b>4</b> ¢ is displayed	

## The Indicator Lamp

The indicator lamp shows camera status as follows:

Indicator lamp	Camera status
Glows green	Focus locked.
Blinks green	Blur, focus, or exposure warning. Picture can be taken.
Blinks green and orange	Recording pictures. Additional pictures can be taken.
Glows orange	Recording pictures. No additional pictures can be taken at this time.
Blinks orange	Flash charging; flash will not fire when picture is taken.
Blinks red	Lens or memory error.

## Camera Displays


The following types of indicator may be displayed during shooting and playback. Indicators vary with camera settings.

## Shooting

	<b>E</b> 11 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
1 2 3 4 5 6 7 8	8 Movie mode59
	9 Number of available frames 117
	10 Sensitivity74
	11 Image size and quality75, 76
	12 Temperature warning 111
	13 FINEPIX color
	14 White balance77
12/31/2050 10:00 AM	15 Battery level
<sup>(19)</sup> 250 F4.5 <b>(27</b> $-1\frac{2}{3}$ <b>(11)</b> $-1\frac{1}{10}$	16 Dual IS mode
°	17 GPS signal strength (XP150/XP160 only)
1 Shooting mode	18 Exposure compensation
2 Intelligent Face Detection indicator	19 Date and time 18
3 Continuous shooting mode78	20 Blur warning42, 110
4 Silent mode indicator	21 Focus warning21, 110
5 Date stamp	22 Self-timer indicator
6 Focus frame	23 Macro (close-up) mode 40
7 Internal memory indicator*	24 Flash mode 41
The indicator that no momenty card is incerted and that nictures will	II ha stared in the samera's internal memory (FF) 11)

 $\mathbb{R}$  : indicates that no memory card is inserted and that pictures will be stored in the camera's internal memory (🕮 11).

## Playback



1	Playback mode indicator	23, 44
2	Intelligent Face Detection indicator	36, 86
3	Red-eye removal indicator	86
4	Portrait enhancer	25
5	Edit	82
6	Gift image	44
7	Frame number	93
8	GPS data (XP150/XP160 only)	52
9	Silent mode indicator	3, 91
10	Mark for upload to	84
11	Photobook assist	49
12	Favorites	44
13	DPOF print indicator	65
	Protected image	
_	· –	

## Battery Level

Battery level is shown as follows:

Indicator	Description	
(white)	Battery partially discharged.	
(white)	Battery more than half discharged.	
<b>⊈</b> (red)	(red) Low battery. Charge as soon as possible.	
d (blinks red)	$\Box$ (blinks red) Battery exhausted. Turn camera off and charge battery.	


## Hiding and Viewing Indicators

Press **DISP/BACK** to cycle through shooting and playback indicators as follows:

- Shooting: Indicators displayed/indicators hidden/best framing/HD framing/ GPS infomation (XP150/XP160 only; Ell 32)
- **Playback**: Indicators displayed/indicators hidden/★ favorites/GPS information (XP150/XP160 only; III) 52)

## 🗫 The 🔅 (Brightness) Button (XP100/XP110 Only)

Press the 🌣 button to temporarily increase monitor brightness when shooting outdoors or in bright ambient light. Normal brightness is restored when a picture is taken.



## **First Steps**


## **Charging the Battery**

The battery is not charged at shipment. Charge the battery before use.

## 1 Attach the plug adapter.

Attach the plug adapter as shown, making sure that it is fully inserted and clicks into place on the charger terminals.


① The plug adapter is exclusively for use with the supplied battery charger. Do not use it with other devices.



## 2 Place the battery in the supplied battery charger.

Insert the battery in the orientation indicated by the  $\bigcirc \oplus \oplus$  labels.

The camera uses an NP-50A rechargeable battery.



## **3** Plug the charger in.

Plug the charger into an indoor power outlet. The charging indicator will light.

## The Charging Indicator

The charging indicator shows battery charge status as follows:

Charging indicator	Battery status	Action
Off	Battery not inserted.	Insert the battery.
On (green)	Battery fully charged.	Remove the battery.
On (orange)	Battery charging.	—
Blinks (orange)	Battery fault.	Unplug the charger and remove the battery.

## **4** Charge the battery.

Remove the battery when charging is complete. See the specifications (
123) for charging times (note that charging times increase at low temperatures).

① Unplug the charger when it is not in use.


## Inserting the Battery and a Memory Card

Although the camera can store pictures in internal memory, optional SD, SDHC, and SDXC *memory cards* (sold separately) can be used to store additional pictures. After charging the battery, insert the battery and memory card as described below.

## 1 Open the battery-chamber cover.

Release the latch (①) and safety lock (②) and open the battery-chamber cover (③).

- Be sure the camera is off before opening the battery-chamber cover.
- ① Do not open the battery-chamber cover when the camera is on. Failure to observe this precaution could result in damage to image files or memory cards.




- ${\scriptstyle \oplus}\,$  Do not use excessive force when handling the battery-chamber cover.

## 2 Insert the battery.

Insert the battery with the terminal first and in the orientation shown by the label inside the battery chamber, keeping the battery latch pressed to one side. Confirm that the battery is securely latched.


① Insert the battery in the correct orientation. Do NOT use force or attempt to insert the battery upside down or backwards. The battery will slide in easily in the correct orientation.



## 3 Insert the memory card.


Holding the memory card in the orientation shown at right, slide it in until it clicks into place at the back of the slot.

- Description
   Be sure card is in the correct orientation; do not insert at an angle or use force. If the memory card is not correctly inserted or no memory card is inserted, in will appear in the LCD monitor and internal memory will be used for recording and playback.
- ① SD/SDHC/SDXC memory cards can be locked, making it impossible to format the card or to record or delete images. Before inserting an SD/SDHC/SDXC memory card, slide the writeprotect switch to the unlocked position.




Write-protect switch

- **4** Close and latch the battery-chamber cover. Close the cover (①) and then close the latch (②) and safety lock (③).
  - Before closing the cover, confirm that there is no dust, sand, or other foreign matter on the water-resistant seal or adjacent surfaces.
  - ① When closing the battery-chamber cover, do not subject it to excessive horizontal forces.



Failure to observe this precaution could cause the water-resistant seal to become misaligned, allowing water into the camera.



Make sure that the strap is not caught in the cover and that both the latch and safety lock are closed.





### Inserting the Battery and a Memory Card

## Removing the Battery and Memory Card

Before removing the battery or memory card, *turn the camera off* and open the battery-chamber cover.

To remove the battery, press the battery latch to the side, and slide the battery out of the camera as shown.

To remove the memory card, press it in and release it slowly. The card can then be removed by hand. When a memory card is removed, the card could come out of the slot too quickly. Use your finger to hold it and gently release the card.





Battery latch



## Compatible Memory Cards

FUJIFILM and SanDisk SD, SDHC, and SDXC memory cards have been approved for use in the camera. A complete list of approved memory cards is available at *http://www.fujifilm.com/support/digital\_cameras/compatibility/*. Operation is not guaranteed with other cards. The camera can not be used with *xD-Picture Cards* or MultiMediaCard (MMC) devices.

## ① Memory Cards

- Do not turn the camera off or remove the memory card while the memory card is being formatted or data are being recorded to or deleted from the card. Failure to observe this precaution could damage the card.
- Format SD/SDHC/SDXC memory cards before first use, and be sure to reformat all memory cards after using them in a computer or other device. For more information on formatting memory cards, see " FORMAT" (E 92).
- Memory cards are small and can be swallowed; keep out of reach of children. If a child swallows a memory card, seek medical assistance immediately.
- miniSD or microSD adapters that are larger or smaller than the standard dimensions of an SD/SDHC/SDXC card may not eject normally; if the card does not eject, take the camera to an authorized service representative. Do not forcibly remove the card.
- Do not affix labels to memory cards. Peeling labels can cause camera malfunction.
- Movie recording may be interrupted with some types of SD/SDHC/SDXC memory card. Use a **CLASS** card or better when shooting HD or high-speed movies.

- The data in internal memory may be erased or corrupted when the camera is repaired. Please note that the repairer will be able to view pictures in internal memory.
- Formatting a memory card or internal memory in the camera creates a folder in which pictures are stored. Do not rename or delete this folder or use a computer or other device to edit, delete, or rename image files. Always use the camera to delete pictures from memory cards and internal memory; before editing or renaming files, copy them to a computer and edit or rename the copies, not the originals.


## ① Batteries

- Remove dirt from the battery terminals with a clean, dry cloth. Failure to observe this precaution could prevent the battery from charging.
- Do not affix stickers or other objects to the battery. Failure to observe this precaution could make it impossible to remove the battery from the camera.
- Do not short the battery terminals. The battery could overheat.
- Read the cautions in "The Battery and Power Supply" (🕮 vi).
- Use only battery chargers designated for use with the battery. Failure to observe this precaution could result in product malfunction.
- Do not remove the labels from the battery or attempt to split or peel the outer casing.
- The battery gradually loses its charge when not in use. Charge the battery one or two days before use.

## Turning the Camera on and Off

## Shooting Mode

Press the **ON/OFF** button to turn the camera on.




Press **ON/OFF** again to turn the camera off.

## Switching to Playback Mode

Press the **b** button to start playback. Press the shutter button halfway to return to shooting mode.

## Playback Mode

To turn the camera on and begin playback, press the **D** button for about a second.



Press the **▶** button again or press the **0N/OFF** button to turn the camera off.

## Switching to Shooting Mode

To exit to shooting mode, press the shutter button halfway. Press the **>** button to return to playback.

- ${\rm \@Delta}$  Fingerprints and other marks on the protective glass covering the lens can affect pictures. Keep the glass clean.
- ① The **ON/OFF** button does not completely end the supply of power to the camera.

### Auto Power Off

The camera will turn off automatically if no operations are performed for the length of time selected for **T AUTO POWER OFF** (**E** 95). To turn the camera on, use the **ON/OFF** button or press the **D** button for about a second.

## Basic Setup

A language-selection dialog is displayed the first time the camera is turned on. Set up the camera as described below (you can reset the clock or change languages at any time using the **③ DATE/TIME** or **③** 言語/LANG. options in the setup menu; for information on displaying the setup menu, see page 91).

1 Highlight a language and press MENU/OK.

- Press DISP/BACK to skip the current step. Any steps you skip will be displayed the next time the camera is turned on.
- 2 The date and time will be displayed. Press the selector left or right to highlight the year, month, day, hour, or minute and press up or down to change. To change the order in which the year, month, and day are displayed, highlight the date format and press the selector up or down. Press **MENU/OK** when settings are complete.

## The Camera Clock

18

If the battery is removed for an extended period, the camera clock will be reset and the language-selection dialog will be displayed when the camera is turned on.



START MENU
図言語/LANG.
ENGLISH
FRANCAIS
DEUTSCH
ESPAŇOL
PORTUGUÊS
OK SET BACK NO


# **Basic Photography and Playback**

### Taking Pictures in 跪 (Scene Recognition) Mode

This section describes how to take pictures in 👪 (scene recognition) mode. The camera automatically analyzes the composition and adjusts settings appropriately.

### **1** Turn the camera on.

Press the **ON/OFF** button to turn the camera on. Shooting indicators will be displayed.



#### 🖢 The 😫 Icon

This icon indicates that the camera continuously searches for faces to select the appropriate scene, increasing the drain on the battery.




#### The Scene Icon

The camera selects the scene according to shooting conditions and the type of subject: O PORTRAIT (portraits), O LANDSCAPE (landscapes), O NIGHT (poorly-lit landscapes), O MACRO (close ups), O NIGHT PORTRAIT (poorly-lit portraits), O BACKLIT PORTRAIT (backlit portraits), O AUTO (all other scenes)

### 2 Frame the picture.

Use the zoom control to frame the picture in the display.



#### Holding the Camera

Hold the camera steady with both hands and brace your elbows against your sides. Shaking or unsteady hands can blur your shots.



To prevent pictures that are out of focus or too dark (underexposed), keep your fingers and other objects away from the flash and from the protective glass covering the lens.

### 3 Focus.

Press the shutter button halfway to focus.

The lens may make a noise when the camera focuses; this is normal.



If the camera is able to focus, it will beep twice and the indicator lamp will glow green.

If the camera is unable to focus, the focus frame will turn red, **!AF** will be displayed, and the indicator lamp will blink green. Change the composition or use focus lock (🖽 37).

### 4 Shoot.

Smoothly press the shutter button the rest of the way down to take the picture.



### The Shutter Button

The shutter button has two positions. Pressing the shutter button halfway sets focus and exposure; to shoot, press the shutter button the rest of the way down.

# **Viewing Pictures**

Pictures can be viewed in the LCD monitor. When taking important photographs, take a test shot and check the results.

### 1 Press the 🕨 button.


The most recent picture will be displayed.

### 2 View additional pictures.

Press the selector right to view pictures in the order recorded, left to view pictures in reverse order.

Press the shutter button halfway to exit to shooting mode.





# More on Photography

### Shooting Mode

Choose a shooting mode according to the scene or type of subject.

### Choosing a Shooting Mode

**1** Press **MENU/OK** to display the shooting menu.


2 Highlight **SHOOTING MODE** and press the selector right to display shooting mode options.

3 Highlight the desired mode and press MENU/OK.

Downloaded from ManualsCamera.com Manuals

4 Press DISP/BACK to exit to shooting mode.





SHOOTING MODE	ஃஃ⊪
°	
·	
مر SFT	
321	
CACCO EXIT	
L	
品品 SCENE RECOGNITION	AB

SHOOTING MENU



### **Shooting Mode Options**

Mode	Description
品品 SCENE RECOGNITION	The camera automatically analyzes the composition and selects a scene according to shooting conditions and the type of subject.
🗗 AUTO	Choose for crisp, clear snapshots. This mode is recommended in most situations.
P PROGRAM AE	The camera sets exposure automatically.
PRO LOW-LIGHT	Choose when photographing stationary subjects under low light or with the camera zoomed in (🕮 27).
TER D-RANGE PRIORITY	Choose when photographing high-contrast scenes. The camera varies exposure over a series of shots and blends the results to preserve details in highlights and shadows (🕮 28).
©\$ NATURAL & \$	The camera takes two shots: one without the flash and one with.
NATURAL LIGHT	Capture natural lighting under low-light conditions.
PORTRAIT	Choose for portraits.
PORTRAIT ENHANCER	Choose for a smooth skin effect when shooting portraits.
LANDSCAPE	Choose for daylight shots of buildings and landscapes.
MOTION PANORAMA	Pan the camera to record a series of shots that are joined together to form
360	a panorama (🕮 29).
🦗 SPORT	Choose when photographing moving subjects.

#### Shooting Mode

Mode	Description
C NIGHT	Choose this mode for poorly lit twilight or night scenes.
<sup>®</sup> (TRIPOD)	Choose this mode for slow shutter speeds when shooting at night.
🚢 SUNSET	Choose this mode to record the vivid colors in sunrises and sunsets.
* <b>§</b> * SNOW	Choose for crisp, clear shots that capture the brightness of scenes domi- nated by shining white snow.
.≱ி́ BEACH	Choose for crisp, clear shots that capture the brightness of sunlit beaches.
<b>∲</b> ∗ UNDERWATER	Choose for underwater photography.
UNDER WATER (WIDE)	Choose for wide-angle underwater shots that include more of the back- ground behind the main subject.
♦ UNDER WATER (MACRO)	Choose for underwater close-ups of small objects.
▼ PARTY	Capture indoor background lighting under low-light conditions.
券 FLOWER	Choose for vivid close-ups of flowers.
TEXT TEXT	Take clear pictures of text or drawings in print.

### 📕 🌆 PRO LOW-LIGHT

Each time the shutter button is pressed, the camera makes four exposures and combines them into a single photograph. Use to reduce noise and blur when photographing poorly lit subjects or static subjects at high zoom ratios.



A single combined photograph may not be created with some scenes or if the subject or camera moves during shooting. Do not move the camera until shooting is complete.

### PRO LOW-LIGHT

To save unprocessed copies of pictures taken in this mode, select **ON** for the **III SAVE ORIGINAL IMAGE** option in the setup menu (IIII 97).

- ${\scriptstyle \textcircled{O}}$  Keep the camera steady during shooting.
- ① Frame coverage is reduced.
- ${\scriptstyle \oplus}\,$  The camera may make fewer than four exposures in some situations.

### Ima D-RANGE PRIORITY

Each time the shutter button is pressed, the camera takes a series of shots, each with different exposure. These are combined into a single image, preserving detail in highlights and shadows. Choose for high-contrast scenes. Press the selector left or right to choose the exposure range before shooting.

A single combined photograph may not be created with some scenes or if the subject or camera moves during shooting. Do not move the camera until shooting is complete.



#### D-RANGE PRIORITY

To save unprocessed copies of pictures taken in this mode, select **ON** for the SAVE ORIGINAL IMAGE option in the setup menu (🕮 97).

- Keep the camera steady during shooting.
- ① Frame coverage is reduced.

### PRINCE MOTION PANORAMA 360

Follow an on-screen guide to take photos that will automatically be joined to form a panorama. The camera zooms all the way out and remains fixed at the widest angle until shooting is complete.

- **1** To select the angle through which you will pan the camera while shooting, press the selector down. Press the selector left or right to highlight an angle and press **MENU/OK**.
- **2** Press the selector right to view a choice of pan directions. Press the selector left or right to highlight a pan direction and press **MENU/OK**.
- **3** Press the shutter button all the way down to start recording. There is no need to keep the shutter button pressed during recording.
- **4** Pan the camera in the direction shown by the arrow. Shooting ends automatically when the progress bar is full and the panorama is complete.
  - Shooting ends if the shutter button is pressed all the way down during shooting. No panorama will be recorded if the shutter button is pressed before the camera has been panned through 120°.

Downloaded from ManualsCamera.com Manuals

More on Photography



Progress bar



#### Shooting Mode

- ① Panoramas are created from multiple frames. The camera may in some cases record an greater or lesser angle than selected or be unable to stitch the frames together perfectly. The last part of the panorama may not be recorded if shooting ends before the panorama is complete.
- ① Shooting may be interrupted if the camera is panned too quickly or too slowly. Panning the camera in a direction other than that shown cancels shooting.
- ① The desired results may not be achieved with moving subjects, subjects close to the camera, unvarying subjects such as the sky or a field of grass, subjects that are in constant motion, such as waves and waterfalls, or subjects that undergo marked changes in brightness. Panoramas may be blurred if the subject is poorly lit.

#### For Best Results

For best results, move the camera in a small circle at a steady speed, keeping the camera horizontal and being careful only to pan in the direction shown by the guides. If the desired results are not achieved, try panning at a different speed.

- GPS data is not updated at battery levels of **C** or below.
- Ze WHEN SWITCHED ON: The camera updates GPS data only when on. The camera may need some time to acquire GPS data when turned on. This option is selected automatically at battery levels of 🗖 and below.
- GPS works best outdoors under clear skies.

During shooting, GPS data are displayed in the monitor as shown at right. Signal strength is indicated by the number of bars; 🚜 is displayed when the camera is searching for a signal, 🐔 if the camera is in GPS demo mode, and 🗵 if no signal is detected. The current location is shown by a place name or (if no place name is available) by the longitude and latitude.

The display of GPS information can be turned off by selecting OFF for LOCATION INFO ( 32).


# Recording GPS Data with Pictures (Only XP150/160)

To record GPS data with new pictures, press the GPS

button to display the GPS menu and select one of the following options for **LOCATION SEARCH**:

• **M PERMANENTLY ON**: The camera continues to update GPS data for up to 3 hours after being turned off. The camera will be quicker to display GPS data when turned on, but the drain on the battery will increase. Note that





#### The GPS Menu

The options in the GPS menu are detailed below.

Option	Description
	Immediately update GPS data.
POWER SEARCH ON	GPS data are not updated if OFF for LOCATION SEARCH.
	GPS data can be updated by pressing and holding the <b>GPS</b> button.
LOCATION SEARCH	Turn the GPS receiver on or off (💷 31).
TRACKING DATA	Record GPS data (🕮 34).
MY LANDMARK REGISTER	Add custom landmarks to or delete them from the map database.
AUTO TIME CORRECTION	Use GPS data to set the camera clock (💷 35).
LOCATION INFO	Display GPS data (🕮 31).
km/mile	Choose the units used to display GPS information (🗐 54).

### Viewing GPS Data

To view GPS data, press **DISP/BACK** until GPS data appear in the monitor. If the compass heading is not correct, it will flash yellow in the GPS display. Recalibrate the compass by moving the camera slowly in a large figure eight while rotating your wrist as shown on page 35.



h.

- ${\ensuremath{\mathbb O}}$  Using GPS increases the drain on the battery, causing battery performance to drop at low temperatures.
- ① The receiver may have an error of a few hundred meters (yards).
- ① The camera may be unable to receive GPS data in some locations. If possible, choose an outdoor location with few obstructions when turning the camera on.
- ① The position recorded when a photo is taken may differ from the actual location if some time has passed since the camera was last able to update GPS data.
- ① Select OFF for LOCATION SEARCH (■ 32) and TRACKING DATA (■ 32) in the setup menu when in a hospital and before takeoff and landing if traveling by air.
- Place names are current as of the date on which the map database was created ( 121) and will not be updated to reflect any changes after that date.
- ① Place name data are unavailable in some countries and regions. If no name is available, the latitude and longitude will be displayed for a few seconds.

### GPS

The camera may be unable to receive GPS data if the antenna ( $\blacksquare$  2) is obstructed or when underground, underwater, under a bridge or overpass, inside a vehicle, building, tunnel, or metal briefcase, between tall buildings, or in the vicinity of cell phones or other devices that broadcast in the 1.5 GHz band.

Obey all local regulations regarding the use of GPS devices. Note that the use of GPS devices is restricted in some countries, including the People's Republic of China. Before going abroad, consult with the embassy or a travel agent. The camera may display  $\mathbb{M}$  (no signal) in locations in which restrictions apply.

<u>Downloaded from ManualsCamera.com Manuals</u> More on Photography

### **GPS Tracking**

To record a GPS track log to a file on the memory card, select **ON** for **TRACKING DATA** (I) 32; be sure the clock is set to the correct time and date as described on page 18). A new log file is created when **ON** is selected and once every 24 hours thereafter. Note that the camera will continue to update GPS data even when off, increasing the drain on the battery.

- ① GPS logs can be viewed using MyFinePix Studio or the DISP TRACKING DATA option (■ 53).
- ① See "GPS" (🕮 33) for information on using GPS.
- ① The indicator lamp glows orange during recording GPS data even when the camera is turned off while **ON** is selected. Select **OFF** before removing the battery or memory card. Failure to observe this precaution could damage the card.
- ${\scriptstyle \oplus}$  Tracking ends after the camera has been off for 3 hours consecutively.
- $\oplus\,$  GPS tracking may be interrupted during movie recording and playback.

### Using GPS to Set the Camera Clock


The **AUTO TIME CORRECTION** item can be used to synchronize the camera clock to the time provided by GPS satellites. Select **ON (W/o SUMMERTIME)** to set the clock to local standard time or **ON (W/ SUMMERTIME)** to set the clock to local daylight saving time. If daylight saving time is in effect, time will automatically be advanced one hour.

- ${\scriptstyle \oplus}\,$  If the camera is able to receive GPS data, the clock will be synchronized when the camera is turned off.
- ① Selecting ← LOCAL for INTE DIFFERENCE turns AUTO TIME CORRECTION off. Note that GPS may not provide the correct time in some locations; if necessary select OFF for AUTO TIME CORRECTION and set the clock using INTE/TIME (INTE).

### Compass Error

If the compass heading is not correct, it will flash yellow in the GPS display. Recalibrate the compass by moving the camera slowly in a large figure eight while rotating your wrist as shown.






If the compass heading continues to flash, choose a different location and try again.

 $\oplus$  To ensure that you do not drop the camera, use the strap ( $\boxplus\,$  1).

# 🛛 Intelligent Face Detection

Intelligent Face Detection sets focus and exposure for human faces anywhere in the frame, preventing the camera from focusing on the background in group portraits. Choose for shots that emphasize portrait subjects.

To use Intelligent Face Detection, press **MENU/OK** to display the shooting menu and select **ON** for **PACE DETECTION** (**P** 78). Faces can be detected with the camera in vertical or horizontal orientation; if a face is detected, it will be indicated by a green border. If there is more than one face in the frame, the camera will select the face closest to the center; other faces are indicated by white borders.





- ${\rm \oplus}\,$  In some modes, the camera may set exposure for the frame as a whole rather than the portrait subject.
- ${\rm I}$  If the subject moves as the shutter button is pressed, their face may not be in the area indicated by the green border when the picture is taken.

### Focus Lock

To compose photographs with off-center subjects:

- **1** Focus: Position the subject in the focus frame (r<sup>t</sup><sub>2</sub>+<sup>3</sup>-1) and press the shutter button halfway to lock focus and exposure. Focus and exposure will remain locked while the shutter button is pressed halfway (AF/AE lock).
- **2 Recompose**: Keep the button pressed halfway.

**3 Shoot**: Press the button all the way down.





#### Focus Lock


### Autofocus


Although the camera boasts a high-precision autofocus system, it may be unable to focus on the subjects listed below. If the camera is unable to focus, focus on another subject at the same distance and use focus lock to recompose the photograph.

<ul> <li>Very shiny subjects such as mirrors or car bodies.</li> </ul>	• Subjects that show little contrast with the background
Fast-moving subjects.	(for example, subjects in clothing that is the same color
• Subjects photographed through a window or other re-	as the background).
flective object.	• Subjects positioned in front of or behind a high-contrast
• Dark subjects and subjects that absorb rather than reflect	object that is also in the focus frame (for example, a
light, such as hair or fur.	subject photographed against a backdrop of highly con-
<ul> <li>Insubstantial subjects, such as smoke or flame.</li> </ul>	trasting elements).

# **Exposure Compensation**

To adjust exposure compensation when photographing very bright, very dark, or high-contrast subjects, press the selector up (2). Press the selector up or down to choose an exposure compensation value and then press **MENU/OK**.





- A ☑ icon and exposure indicator are displayed at settings other than ±0. Exposure compensation is not reset when the camera is turned off; to restore normal exposure control, choose a value of ±0.
- Turn the flash off when using exposure compensation.
- Exposure compensation is available only when P (PROGRAM AE) is selected for shooting mode.

Downloaded from ManualsCamera.com Manuals


### 🗱 Macro Mode (Close-ups)

For close-ups, press the selector left (♥) and select ♥. When macro mode is in effect, the camera focuses on subjects near the center of the frame. Use the zoom control to compose pictures (■ 20).

To exit macro mode, press the selector left (B) and select  $\textcircled{B}_{F}$ .

Use of a tripod is recommended to prevent blur caused by camera shake.






# 4 Using the Flash (Intelligent Flash)

When the flash is used, the camera's *Intelligent Flash* system instantly analyzes the scene based on such factors as the brightness of the subject, its position in the frame, and its distance from the camera. Flash output and sensitivity are adjusted to ensure that the main subject is correctly exposed while preserving the effects of ambient background lighting, even in dimly-lit indoor scenes. Use the flash when lighting is poor, for example when shooting at night or indoors under low light.

Press the selector right (\$) and choose from the following flash modes:





Option	Description
AUTO/ 🏵 (AUTO FLASH)	The flash fires when required. Recommended in most situations.
<b>\$∕@\$</b> (FORCED FLASH)	The flash fires whenever a picture is taken. Use for backlit subjects or for natural coloration when shooting in bright light.
(SUPPRESSED FLASH)	The flash does not fire even when the subject is poorly lit. Use of a tripod is recommended.
	Capture both the main subject and the background under low light (note that brightly lit scenes may be overexposed).


- If the flash will fire, 1 will be displayed when the shutter button is pressed halfway. At slow shutter speeds, 1 will appear in the display to warn that pictures may be blurred; use of a tripod is recommended.
- The flash may fire several times with each shot. Do not move the camera until shooting is complete.
- The flash may cause vignetting.

### Red-Eye Removal



# 👏 Using the Self-Timer

To use the self-timer, press the selector down (  $\circlearrowright$  ) and choose from the following options:





Option	Description
Sef (OFF)	Self-timer off.
ć❤ (COUPLE TIMER)	The camera starts the timer when it detects two portrait subjects close together. Press the selector up to choose how close the subjects must be together before the timer starts (the more hearts, the closer the subjects must be together). To stop the timer before the picture is taken, press <b>DISP/BACK</b> .
الله (GROUP TIMER)	The camera will start the timer when it detects the selected number of portrait subjects. Press the selector up to choose the number of subjects. To stop the timer before the picture is taken, press <b>DISP/BACK</b> .
යි (10 SEC)	The shutter is released ten seconds after the shutter button is pressed. Use for self-portraits. The self-timer lamp on the front of the camera blinks while the timer counts down.
🍪 (2 SEC)	The shutter is released two seconds after the shutter button is pressed. Use to reduce blur caused by the camera moving when the shutter-release button is pressed. The self-timer lamp will blink as the timer counts down.

# **More on Playback**

### Playback Options

To view the most recent picture in the LCD monitor, press the  $\blacktriangleright$  button.



Press the selector right to view pictures in the order recorded, left to view pictures in reverse order. Keep the selector pressed to scroll rapidly to the desired frame.

Pictures taken using other cameras are indicated by a # ("gift image") icon during playback.

### **★** Favorites: Rating Pictures

To rate the picture currently displayed in full-frame playback, press **DISP/BACK** and press the selector up and down to select from zero to five stars.

### <u>Playback Zoom</u>

Select **T** to zoom in on pictures displayed in single-frame playback; select **W** to zoom out. When the picture is zoomed in, the selector can be used to view areas of the image not currently visible in the display.



Zoom indicator


Navigation window shows portion of image currently displayed in LCD monitor

Press **DISP/BACK** to exit zoom.

The maximum zoom ratio varies with image size. Playback zoom is not available with cropped or resized copies saved at a size of 600 or smaller.

### Multi-Frame Playback

Selecting **W** when a picture is shown full-frame in the LCD monitor displays the current image with previous and following images in the background. Select **W** to increase the number of images displayed to two, nine, or one hundred, **T** to view fewer images.



When two or more images are displayed, use the selector to highlight images and press **MENU/OK** to view the highlighted image full frame. In the nine- and hundred-frame displays, use the selector to view more pictures.

# **Deleting Pictures**

To delete individual pictures, multiple selected pictures, or all pictures, press **MENU/OK**, select **Im ERASE** (Im 81), and choose from the options be-

low. Note that deleted pictures can not be recov-



ered. Copy important pictures to a computer or other storage device before proceeding.

Option	Description
FRAME	Press the selector left or right to scroll through pictures and press <b>MENU/OK</b> to delete the current picture (a confirmation dialog is not displayed).
SELECTED FRAMES	Highlight pictures and press <b>MENU/OK</b> to select or deselect (pictures that are protected or in a print order are shown by <b>II</b> ). When the operation is complete, press <b>DISP/BACK</b> to display a confirmation dialog, then highlight <b>OK</b> and press <b>MENU/OK</b> to delete the selected pictures.
ALL FRAMES	A confirmation dialog will be displayed; highlight <b>OK</b> and press <b>MENU/OK</b> to de- lete all unprotected pictures (if a memory card is inserted, only the pictures on the memory card will be affected; the pictures in internal memory are only de- leted if no memory card is inserted). Pressing <b>DISP/BACK</b> cancels deletion; note that any pictures deleted before the button was pressed can not be recovered.

Protected pictures can not be deleted. Remove protection from any pictures you wish to delete (
\$\vee\$ 86).

If a message appears stating that the selected images are part of a DPOF print order, press MENU/OK to delete the pictures.

### 🛃 Image Search

Search for pictures.

- 1 Select 
  <sup>IMAGE SEARCH</sup> in the playback menu (
  <sup>IIII</sup> 81), highlight one of the following search criteria, and press **MENU/OK**:
  - BY DATE: Search by date.
  - **BY GPS LOCATION NAME** (XP150/XP160 only): Search by location name (location names that do not begin with a letter from A to Z are listed in the search conditions under "#").
  - BY FACE: Search for faces from the face recognition database.
  - **BY** ★ **FAVORITES**: Search by rating.
  - BY SCENE: Search by scene.
  - BY TYPE OF DATA: Find all still pictures, all movies, or edited pictures.
  - **BY UPLOAD MARK**: Find all pictures selected for upload to a specified destination.
- 2 Select a search condition. Only pictures that match the search condition will be displayed. To delete or protect selected pictures or to view the search results in a slide show, press MENU/OK and choose I ERASE (■ 47),
   I PROTECT (■ 86), or I SLIDE SHOW (■ 85).

## 🗳 PhotoBook Assist

Create books from your favorite photos.

### Creating a PhotoBook

- 1 Select **NEW BOOK** for **□ PHOTOBOOK ASSIST** in the playback menu (□ 81) and choose from the following options:
  - SELECT FROM ALL: Choose from all available pictures.

  - Neither photographs 🚳 or smaller nor movies can be selected for photobooks.
- 2 Scroll through the images and press the selector up to select or deselect. To display the current image on the cover, press the selector down. Press MENU/OK to exit when the book is complete.
  - The first picture selected becomes the cover image. Press the selector down to select a different image for the cover.
- **3** Select **COMPLETE PHOTOBOOK** (to select all photos or all photos matching the specified search conditions for the book, choose **SELECT ALL**). The new book will be added to the list in the photobook assist menu.
- ① Books can contain up to 300 pictures.
- ${\ensuremath{\textcircled{}}}$  Books that contain no photos are automatically deleted.

### Viewing Photobooks

Highlight a book in the photobook assist menu and press **MENU/OK** to display the book, then press the selector left or right to scroll through the pictures.

### Editing and Deleting Photobooks

Display the photobook and press **MENU/OK**. The following options will be displayed; select the desired option and follow the on-screen instructions.


- EDIT: Edit the book as described in "Creating a PhotoBook" (🕮 49).
- **ERASE**: Delete the book.

#### Photobooks

Photobooks can be copied to a computer using the supplied MyFinePix Studio software.

## Viewing Panoramas

If you press the selector down when a panorama is displayed full frame, the camera will play back the picture from left to right or from bottom to top. To pause playback, press the selector down; press the selector down again to resume. To exit to full-frame playback, press the selector up while panorama playback is in progress.



# Viewing GPS Data (Only XP150/160)

During playback, pictures for which GPS data exist are indicated by a **GPS** icon. GPS data are shown for a few seconds each time the picture is displayed.

GPS icon



### Viewing GPS Data

To view the compass heading at the time the picture was taken, press **DISP/BACK** until GPS data appear in the monitor.




12/31/2050 10:00 AM N 10°00'00" E 10°00'00"

1.1

### The GPS Menu

The GPS menu can be displayed by pressing the **GPS** button.



Option	Description
POWER SEARCH ON	Immediately update GPS data.
	GPS data are not updated if OFF for LOCATION SEARCH.
	GPS data can be updated by pressing and holding the <b>GPS</b> button.
LOCATION SEARCH	Turn the GPS receiver on or off (💷 31).
TRACKING DATA	Record GPS data (🕮 34).
DISP TRACKING DATA	View the GPS track (💷 56).
ERASE TRACKING DATA	Delete the GPS track (🕮 57).
PHOTO NAVIGATION	View the approximate direction and distance to the location where cur-
PHOTO NAVIGATION	rent the picture was taken (🕮 54).
LOCATION INFO COPY	Copy GPS data from one picture to another (💷 55).
AUTO TIME CORRECTION	Use GPS data to set the camera clock (💷 35).
LOCATION INFO	Display GPS data (🕮 31).
km/mile	Choose the units used to display GPS information (💷 54).

### **Photo Navigation**

To show the direction and distance from your present position to the location where a picture was taken:

- 2 Display a picture with a GPS icon.
- 3 Select PHOTO NAVIGATION (■ 53) in the 
  memory me
- Photo navigation ends when the next picture is displayed.

#### Calibration

A Section indicates that the camera's internal sensor requires calibration. Move the camera slowly in a large figure eight while rotating your wrist as shown on page 35. If the icon does not clear from the display, choose a different location and try again.

① To ensure that you do not drop the camera, use the strap (💷 1).





#### Copying GPS Data to Other Images

GPS data can be copied from other pictures to images that lack correct GPS information.

- 1 Select LOCATION INFO COPY in the 🚯 menu (🕮 53).
- **2** Press the selector left or right to display the source image for the GPS data and press **MENU/OK**.
- **3** Press the selector left or right to display the destination and press **MENU/OK** to copy the data to the image.
- ① Once copied, the new GPS data can not be deleted and the original GPS data can not be recovered. Note, however, that copying data from a picture with GPS data to a picture with GPS data will delete the original GPS data recorded with the destination picture.
- $\ensuremath{\mathbbm O}$  The camera may be unable to copy GPS data to or from images created on other devices.

#### Viewing the GPS Track

To view the track created with **TRACKING DATA** (🕮 53):

- 1 Select DISP TRACKING DATA in the 🕮 menu.
- **2** Press the selector up or down to highlight the desired track log.

- 3 The track is shown by a line with dots (●) representing the locations where photographs were taken. Press the selector left or right to highlight a location (the highlighted location is shown by ●).
- **4** Press **MENU/OK** to view the photograph taken at the highlighted location. Press the selector left or right to view additional photographs or press **DISP/BACK** to return to the track. Press **MENU/OK** to exit to normal playback.



Select a location





S DISP TRACKING DATA

### **Deleting Track Logs**

To delete track logs recorded with **TRACKING DATA** (🕮 53):

## 1 Select ERASE TRACKING DATA in the 🖽 menu.

**2** Press the selector up or down to highlight the desired track log and press **MENU/OK**.




- **3** A confirmation dialog will be displayed; highlight **OK** and press **MENU/OK** to delete the selected log.
- Images are not deleted when track logs are erased.

# Movies

# **Recording Movies**

Press () to shoot a movie. During recording, () **REC** and the time remaining will be displayed in the LCD monitor and sound will be recorded via the built-in microphone (be careful not to cover the microphone during recording).





Time available is displayed in monitor

To end recording, press the  $\odot$  button again. Recording ends automatically when the movie reaches maximum length or memory is full.

- Zoom can be adjusted while recording is in progress. The type of zoom can be selected using the MOVIE ZOOM TYPE option in the setup menu (1997).
- Focus, exposure and white balance are adjusted automatically throughout recording (the focus mode can be selected using the **MOVIE AF MODE** option in the shooting menu; **1** 79). The color and brightness of the image may vary from that displayed before recording begins.
- Sounds made by the camera may be recorded.

- ① The indicator lamp lights while movies are being recorded. Do not open the battery chamber during shooting or while the indicator lamp is lit. Failure to observe this precaution could prevent the movie from being played back.
- ① Vertical or horizontal streaks may appear in movies containing very bright subjects. This is normal and does not indicate a malfunction.
- ${\rm \oplus}$  The temperature of the camera may rise if it is used to record movies for an extended period or if the ambient temperature is high. This is normal and does not indicate a malfunction.

#### Movie Frame Size

Before recording, select a frame size using the **MOVIE MODE** option in the shooting menu (**1** 79).

Option	Description	
<b>1920</b> (1920 × 1080)	Full HD ( <b>H</b> igh <b>D</b> efinition).	
HD 1280 (1280×720)	High Definition.	
<b>640</b> (640 × 480)	Standard definition.	
<b>HS 640 × 480</b> (80 fps)	High speed movie. Sound is not recorded, and focus, exposure, and white	
<b>161 320 X 240</b> (100 lps)	balance are not adjusted automatically.	
<b>HS</b> 320 × 240 (240 fps)		

① Do not cover the speaker during playback.

shown by the number of arrows ( $\triangleright$  or  $\triangleleft$ ).

Downloaded from ManualsCamera.com Manuals

# Viewing Movies

Option


Playback Speed

During playback, movies are displayed in the LCD monitor as shown at right. The following operations can be performed while a movie is displayed:

Description

	Press the selector down to start playback. Press again to		
playback	pause.		
End playback/	Press the selector up to end playback. If playback is not in		
delete progress, pressing the selector up will delete the movie			
Adjust speed	Press the selector left or right to adjust playback speed dur-		
	ing playback.		
Adjust volume Adjust volume from the setup menu.			






# Connections

# Viewing Pictures on TV

Connect the camera to a TV to show pictures to a group.

**1** Turn the camera off and connect an optional A/V cable as shown below.




- ${\scriptstyle \textcircled{O}}$  When connecting cables, be sure the connectors are fully inserted.
- Image quality may drop during movie playback.
- **2** Tune the television to the video input channel. See the documentation supplied with the television for details.
- 3 Press the ▶ button for about a second to turn the camera on. The camera monitor turns off and pictures and movies are played back on the TV. Note that the camera volume controls have no effect on sounds played on the TV; use the television volume controls to adjust the volume.

# Viewing Pictures on High-Definition TVs

The camera can be connected to High-Definition (HD) devices using an HDMI cable (available separately from third-party sources).

**1** Turn the camera off and connect the HDMI cable as shown below.




- ${\scriptstyle \textcircled{O}}$  When connecting cables, be sure the connectors are fully inserted.
- When an HDMI cable is connected, pictures and sound are played back on the TV.
- **2** Tune the television to the HDMI input channel. See the documentation supplied with the television for details.
- 3 Press the ▶ button for about a second to turn the camera on. The camera monitor turns off and pictures and movies are played back on the TV. Note that the camera volume controls have no effect on sounds played on the TV; use the television volume controls to adjust the volume.
  - The USB cable can not be used while an HDMI cable is connected.
  - Some televisions may briefly display a black screen when movie playback begins.

#### Downloaded from ManualsCamera.com Manuals

# **Printing Pictures via USB**

If the printer supports PictBridge, the camera can be connected directly to the printer as shown below and pictures can be printed without first being copied to a computer. Note that depending on **PictBridge** the printer, not all the functions described below may be supported.

1 Connect the supplied USB cable as shown and turn the printer on.



- **2** Turn the camera on.
- 3 Press the selector left or right to display a picture you wish to print.
- **4** Press the selector up or down to choose the number of copies (up to 99).
- **5** Repeat steps 3–4 to select additional pictures. Press **MENU/OK** to display a confirmation dialog when settings are complete.

- **6** Press **MENU/OK** to start printing. Printing can be interrupted by pressing **DISP/BACK**, but note that some printers may not respond immediately. If the printer stops before printing is complete, turn the camera off and then on again.
- **7** After confirming that **PRINTING** has cleared from the camera display, turn the camera off and disconnect the USB csable.
- Pictures can be printed from internal memory or a memory card that has been formatted in the camera.
- If no pictures are selected, the camera will print one copy of the current picture.
- Page size, print quality, and border selections are made using the printer.

#### Printing the Date of Recording

To print the date of recording on pictures, press **DISP/BACK** in the PictBridge display and select **PRINT WITH DATE** in the PictBridge menu (to print pictures without the date of recording, select **PRINT WITHOUT DATE**).

Downloaded from ManualsCamera.com Manuals

### Printing the DPOF Print Order

The **PRINT ORDER (DPOF)** option in the playback menu can be used to create a digital "print order" for PictBridge-compatible printers (🗐 99) or devices that support DPOF.

#### DPOF

DPOF (Digital Print Order Format) is a standard that allows pictures to be printed from "print orders" stored in internal memory or on a memory card. The information in the order includes the pictures to be printed and the number of copies of each picture.

- **1** Select playback mode and press **MENU/OK** to display the playback menu.
- 2 Highlight PRINT ORDER (DPOF) and press MENU/OK.
- 3 Highlight one of the following options and press MENU/OK:
  - WITH DATE C: Print the date of recording on pictures.
  - WITHOUT DATE: Do not print the date of recording on pictures.
  - Some printers do not support date printing. See the printer manual for details.
- **4** Press the selector left or right to display a picture you wish to add to or remove from the print order.

- **5** Press the selector up or down to choose the number of copies (up to 99). To remove a picture from the print order, press the selector down until the number of copies is zero.
- **6** Repeat Steps 4–5 to complete the print order and press **MENU/OK** when settings are complete.
- **7** A confirmation dialog will be displayed. Press **MENU/OK** to save the print order.
  - Remove the memory card to create or modify a print order for the pictures in internal memory.
  - Print orders can contain a maximum of 999 pictures.
  - If a memory card is inserted containing a print order created by another camera, a message will be displayed. Create a new print order as described above.

# Viewing Pictures on a Computer

The supplied software can be used to copy pictures to a computer, where they can be stored, viewed, organized, and printed. Before proceeding, install the software as described below. **Do NOT connect the camera to the computer until installation is complete**.

#### Windows: Installing MyFinePix Studio

1 Confirm that the computer meets the following system requirements:

	Windows 7 (SP 1)/Windows Vista (SP 2) <sup>1</sup>	Windows XP (SP 3) <sup>1</sup>	
CPU	3 GHz Pentium 4 or better	2 GHz Pentium 4 or better	
Cru	(2.4 GHz Core 2 Duo or better) <sup>2</sup>	(2.4 GHz Core 2 Duo or better) <sup>2</sup>	
RAM	1 GB or more	512 MB or more	
NAM	I GB OF ITIOLE	(1 GB or more) <sup>2</sup>	
Free disk space	2 GB or more		
GPU	Supports DirectX 9 or later	Supports DirectX 7 or later	
dru	(recommended)	(required; performance not guaranteed with other GPUs)	
Video	1,024 × 768 pixels or more with 24-bit color or better		
	Built-in USB port recommended. Operation is not guaranteed with other		
	USB ports.		
	<ul> <li>• .NET Framework 3.5 Service Pack 1 required when uploading images or u ing Map Viewer.</li> <li>• Internet connection (broadband recommended) required to install .NET Framework (if necessary), to use auto update feature, and when performing such tasks as sharing pictures on-line or via e-mail.</li> </ul>		
Other			

- 1 Other versions of Windows are not supported. Only pre-installed operating systems are supported; operation is not guaranteed on home-built computers or computers that have been upgraded from earlier versions of Windows.
- 2 Recommended when displaying HD movies.

#### Downloaded from ManualsCamera.com Manuals Connections

- **2** Start the computer. Log in to an account with administrator privileges before proceeding.
- **3** Exit any applications that may be running and insert the installer CD in a CD-ROM drive.

#### Windows 7/Windows Vista

If an AutoPlay dialog is displayed, click **SETUP.EXE**. A "User Account Control" dialog will then be displayed; click **Yes** (Windows 7) or **Allow** (Windows Vista).

The installer will start automatically; click **Install MyFinePix Studio** and follow the on-screen instructions to install MyFinePix Studio.

#### If the Installer Does Not Start Automatically

If the installer does not start automatically, select **Computer** or **My Computer** from the Start menu, then double-click the **FINEPIX** CD icon to open the FINEPIX CD window and double-click **setup** or **SETUP.EXE**.

- **4** If prompted to install Windows Media Player or DirectX, follow the onscreen instructions to complete installation.
- **5** Remove the installer CD from the CD-ROM drive when installation is complete. Store the installer CD in a dry location out of direct sunlight in case you need to re-install the software.

Installation is now complete. Proceed to "Connecting the Camera" (🕮 71).

#### Downloaded from ManualsCamera.com Manuals

#### Macintosh: Installing FinePixViewer

**1** Confirm that the computer meets the following system requirements:

CPU	PowerPC or Intel (Core 2 Duo or better)*
05	Pre-installed copies of Mac OS X version 10.3.9–10.6 (visit <i>http://www.fujifilm. com/support/digital_cameras/compatibility/</i> for more information). Mac OS X version 10.7 and later not supported.
RAM	256 MB or more (1 GB or more)*
Froo dick charo	A minimum of 200 MB required for installation with 400 MB available when FinePixViewer is running
Video	$800 \times 600$ pixels or more with thousands of colors or better
Other	Built-in USB port recommended. Operation is not guaranteed with other USB ports.

\* Recommended when displaying HD movies.

- 2 After starting the computer and quitting any applications that may be running, insert the installer CD in a CD-ROM drive and double-click **Installer for Mac OS X**.
- **3** An installer dialog will be displayed; click **Installing FinePixViewer** to start installation. Enter an administrator name and password when prompted and click **OK**, then follow the on-screen instructions to install FinePixViewer. Click **Exit** to quit the installer when installation is complete.


- **4** Remove the installer CD from the CD-ROM drive. Note that you may be unable to remove the CD if Safari is running; if necessary, quit Safari before removing the CD. Store the installer CD in a dry location out of direct sunlight in case you need to re-install the software.
- **5** Mac OS X 10.5 or earlier: Open the "Applications" folder, start Image Capture, and select **Preferences...** from the Image Capture application menu. The Image Capture preferences dialog will be displayed; choose **Other...** in the **When a camera is connected, open** menu, then select **FPVBridge** in the "Applications/FinePixViewer" folder and click **Open**. Quit Image Capture.

**Mac OS X 10.6**: Connect the camera and turn it on. Open the "Applications" folder and start Image Capture. The camera will be listed under **DEVICES**; select the camera and choose **FPVBridge** from the **Connecting this camera opens** menu and click **Choose**. Quit Image Capture.

Installation is now complete. Proceed to "Connecting the Camera" (🕮 71).

#### **Connecting the Camera**

- 1 If the pictures you wish to copy are stored on a memory card, insert the card into the camera.
  - Windows users may require the Windows CD when starting the software for the first time.
  - ① Loss of power during transfer could result in loss of data or damage to internal memory or the memory card. Charge the battery before connecting the camera.
- **2** Turn the camera off and connect the supplied USB cable as shown, making sure the connectors are fully inserted. Connect the camera directly to the computer; do not use a USB hub or keyboard.



- Be sure the battery-chamber cover is open
   before attempting to open or close the connector cover.
- 3 Press the ► button for about a second to turn the camera on and follow the on-screen instructions to copy pictures to the computer. To exit without copying pictures, click **Cancel**.

For more information on using the supplied software, start the application and select the appropriate option from the **Help** menu.

- ① If a memory card containing a large number of images is inserted, there may be a delay before the software starts and you may be unable to import or save images. Use a memory card reader to transfer pictures.
- ① Make sure that the computer does not display a message stating that copying is in progress and that the indicator lamp is out before turning the camera off or disconnecting the USB cable (if the number of images copied is very large, the indicator lamp may remain lit after the message has cleared from the computer display). Failure to observe this precaution could result in loss of data or damage to internal memory or the memory card.
- ${\scriptstyle \oplus}\,$  Disconnect the camera before inserting or removing memory cards.
- ${\rm I}$  In some cases, it may not be possible to access pictures saved to a network server using the supplied software in the same way as on a standalone computer.

#### Disconnecting the Camera

After confirming that the indicator lamp is out, follow the on-screen instructions to turn the camera off and disconnect the USB cable.

#### Uninstalling the Supplied Software

Only uninstall the supplied software when it is no longer required or before beginning reinstallation. After quitting the software and disconnecting the camera, drag the "FinePixViewer" folder from "Applications" into the Trash and select **Empty Trash** in the **Finder** menu (Macintosh), or open the control panel and use "Programs and Features" (Windows 7/Windows Vista) or "Add or Remove Programs" (Windows XP) to uninstall MyFinePix Studio. Under Windows, one or more confirmation dialogs may be displayed; read the contents carefully before clicking **OK**.

74

# Menus

# Using the Menus: Shooting Mode

#### <u>Using the Shooting Menu</u>

To display the shooting menu, press **MENU/OK** in shooting mode. Highlight items and press the selector right to view options, then highlight an option and press **MENU/OK**. Press **DISP/BACK** to exit when


Choose a shooting mode according to the type of subject ( $\blacksquare$  24).

settings are complete. The options available vary with the shooting mode selected.

# Shooting Menu Options


ISO ISO

				(anan
Control the camera's set tling may appear in pie	, ,	9	n reduce blur; n	ote, however, that mot-
100	←	ISO	$\longrightarrow$	3200
Bright	·	Scene		Dark
Less noticeable	←	Noise (mottling)	$\longrightarrow$	More noticeable
Option		Des	cription	
AUTO	Sensitivity is ad	justed automatica	lly in response t	to shooting conditions.
3200/1600/800/400/         Sensitivity is set to the specified value, which is shown in the display.				



(defaults to 🚠 )

(defaults to AUTO)



#### Downloaded from ManualsCamera.com Manuals Menus

#### IMAGE QUALITY

Choose how much image files are compressed.

Option	Description	
FINE	Low compression. Select for higher image quality.	
NORMAL	High compression. Select this option to store more pictures.	

#### FINEPIX COLOR

Enhance contrast and color saturation or take pictures in black and white.

Option	Description	
STANDARD	Standard contrast and saturation. Recommended in most situations.	
©₽ CHROME	Vivid contrast and color. Choose for vivid shots of flowers or enhanced greens and blues in landscapes.	
₿ <b>₽</b> B&W	Take pictures in black and white.	
Der SEPIA	Take pictures in sepia.	

Settings other than for STANDARD are shown by an icon in the LCD monitor.

Depending on the subject, the effects of CHROME may not be visible in the LCD monitor.

(defaults to 🔤 )

#### **WB** WHITE BALANCE

(defaults to AUTO)

For natural colors, choose a setting that matches the light source.

Option	Description	
AUTO	White balance adjusted automatically.	
*	For subjects in direct sunlight.	
*	For subjects in the shade.	
₩í	Use under "daylight" fluorescent lights.	
<b>岸</b> 2	Use under "warm white" fluorescent lights.	
₩3	Use under "cool white" fluorescent lights.	
-Å-	Use under incandescent lighting.	

Results vary with shooting conditions. Play pictures back after shooting to check colors in the LCD monitor.

#### CONTINUOUS

Capture motion in a series of pictures.

Option	Description
TEH FINAL	The comprestation up to 40 choice while the chutter butter is proceed and records
FINAL	The camera takes up to 40 shots while the shutter button is pressed and record the last 12 pictures.
FINAL	
ក្នុង Continuous	The camera takes up to 12 pictures while the shutter button is pressed.
ี่ M⊇ิ่ CONTINUOUS	
CONTINUOUS	
OFF	One photograph is taken each time the shutter button is pressed.

- Focus and exposure are determined by the first frame in each series.
- IMAGE SIZE is fixed at S.
- The flash turns off automatically. The previously selected flash mode is restored when OFF is selected for CONTINUOUS.
- Frame rate varies with shutter speed.
- The number of pictures that can be recorded depends on the memory available.
- Only one photo is taken if the self-timer is used.

#### FACE DETECTION

Choose whether the camera automatically detects and sets focus and exposure for human portrait subjects (🕮 36).

#### AF MODE

This option controls how the camera selects the focus area. Regardless of the option selected, the camera will focus on the subject in the center of the LCD monitor when macro mode is on.

Option	Description
CENTER	The camera focuses on the subject in the center of the frame.
C. IRACKING	Position the subject in the center focus area and press the selector left. Focus will track the subject as it moves through the frame.

Note that in L mode, the camera focuses continuously, increasing the drain on the battery, and that the sound of the camera focusing may be audible.

This option controls how the camera selects the focus area for movies.

Option	Description
	The camera focuses on the subject in the center of the frame.
	The camera continuously adjusts focus to reflect changes in the distance to subjects near the center of the frame.

Note that in mu mode, the camera focuses continuously, increasing the drain on the battery, and that the sound of the camera focusing may be audible.

#### MOVIE MODE

(defaults to HD)

(defaults to 🔳)

Choose a frame size for movies (💷 59).

#### LED ILLUMINATOR

Choose whether the LED (🕮 2) lights to illuminate nearby subjects when lighting is poor.


Option	Description
ON	The LED lights during shooting.
OFF	LED off.

- The LED will not light when ON is selected for SILENT MODE in the setup menu (1999).
- Selecting ON increases the drain on the battery. Select OFF when the LED is not in use.
- ELED ILLUMINATOR is automatically reset to OFF when the camera is turned off.
- The LED turns off if no operations are performed for a short period. Operating any of the camera controls reactivates the LED.

# Using the Menus: Playback Mode

#### Using the Playback Menu

To display the playback menu, press **MENU/OK** in playback mode. Highlight items and press the selector right to view options, then highlight an option and press **MENU/OK**. Press **DISP/BACK** to exit when settings are complete.



### Playback Menu Options

#### PHOTOBOOK ASSIST

Create books from your favorite photos (🕮 49).

#### IMAGE SEARCH

Search for pictures (🕮 48).

#### ERASE

Delete all or selected pictures (🕮 47).

#### 🖌 EDIT

Create a retouched copy of the current picture.

1 Display the desired picture.

2 Select 🗾 EDIT in the playback menu and choose from the following options:

Option	Description
CROP	Crop the copy.
ASPECT RATIO	Choose the aspect ratio.
BRIGHTNESS	Adjust brightness.
CONTRAST	Adjust contrast.
COLOR	Choose positive values for "warmer" colors, negative values for "cooler" colors.
SEPIA	Convert the copy to sepia or black and white.
FACE MOSAIC	If the original was taken with Intelligent Face Detection, a mosaic effect can be applied to up to four faces. If Intelligent Face Detection was off or no faces were detected, the mosaic effect will be applied to the center of the image.

- 3 Press MENU/OK to create a retouched copy (in some cases, additional options will be displayed; adjust settings as desired and press MENU/OK to save the copy).
- Retouched copies can not be further retouched, cropped, or rotated.
- Retouched copies are 640 × 480 pixels in size.

#### MOVIE EDIT

Edit movies.

#### MOVIE TRIMMING

Remove opening or ending footage to create an edited copy of the current movie.

- 1 Display the desired movie.
- 2 Select I MOVIE EDIT > MOVIE TRIMMING in the playback menu. To remove footage from the start of the copy, proceed to Step 3; otherwise, proceed to Step 4.
- **3** Press the selector down to begin playback and press it down again when the new opening frame is reached.
- **4** Press **MENU/OK**. To remove footage from the end of the copy, proceed to Step 5; otherwise, proceed to Step 6 (to exit without creating an edited copy, press **DISP/BACK**).
- **5** Press the selector down to begin playback and press it down again when the new closing frame is reached.
- 6 Press MENU/OK to save the copy.

#### MOVIE JOIN

Add existing footage to the end of the current movie to create an edited copy.

1 Display the desired movie.

- 2 Select 🖾 MOVIE EDIT > MOVIE JOIN in the playback menu.
- 3 Press the selector left or right to highlight a movie.
- 4 Press MENU/OK to add the highlighted footage to the end of the current movie and save the resulting copy, or press DISP/BACK to exit without creating a copy.
- Both movies must have been recorded at the same frame size and frame rate.

#### MARK FOR UPLOAD TO

Select pictures for upload to YouTube or Facebook using MyFinePix Studio (Windows only).

#### Selecting Pictures for Upload


- 1 Select YouTube to choose movies for upload to YouTube, FACEBOOK to choose photos and movies for upload to Facebook.
- 2 Press the selector left or right to display pictures and press **MENU/OK** to select or deselect. Press **DISP/BACK** to exit when all the desired pictures are selected.
- Only movies can be selected for upload to YouTube.
- During playback, selected pictures are indicated by Marchaeler or Selected pictures are indicated by Selected pictures.

#### RESET ALL: Deselecting All Pictures

Choose **RESET ALL** to deselect all pictures. If the number of pictures affected is very large, a message will be displayed while the operation is in progress. Press **DISP/BACK** to exit before the operation is complete.

#### Uploading Pictures (Windows Only)

Selected pictures can be uploaded using the **YouTube/Facebook Upload** option in MyFinePix Studio.



For information on installing MyFinePix Studio and connecting the camera to a computer, see "Viewing Pictures on a Computer" (🗐 67).

#### Downloaded from ManualsCamera.com Manuals

#### **SLIDE SHOW**

View pictures in an automated slide show. Choose the type of show and press **MENU/OK** to start. Press **DISP/BACK** at any time during the show to view on-screen help. The show can be ended at any time by pressing **MENU/OK**.

Option	Description
NORMAL	Press selector left or right to go back or skip ahead one frame. Select FADE-IN
FADE-IN	for fade transitions between frames.
NORMAL 😫	As above, except that camera automatically zooms in on faces selected with
FADE-IN 😫	Intelligent Face detection.
MULTIPLE	Display several pictures at once.
SCRAP BOOK VIEW	Display multiple pictures in random positions and sizes.
SELECT BGM	Choose background music.

The camera will not turn off automatically while a slide show is in progress.

#### RED EYE REMOVAL

If the current picture is marked with a 🔄 icon to indicate that it was taken with Intelligent Face Detection, this option can be used to remove red-eye. The camera will analyze the image; if redeye is detected, the image will be processed to create a copy with reduced red-eye.

- 1 Display the desired picture.
- 2 Select 💿 RED EYE REMOVAL in the playback menu.

#### 3 Press MENU/OK.

- Red eye may not be removed if the camera is unable to detect a face or the face is in profile. Results may differ depending on the scene. Red eye can not be removed from pictures that have already been processed using red-eye removal or pictures created with other devices.
- > The amount of time needed to process the image varies with the number of faces detected.
- Copies created with 💿 **RED EYE REMOVAL** are indicated by a 💿 icon during playback.

#### ■ PROTECT

Protect pictures from accidental deletion.

1 Select **PROTECT** in the playback menu.

2 Highlight one of the following options and press MENU/OK:

- FRAME: Protect selected pictures. Press the selector left or right to view pictures and press MENU/OK to select or deselect. Press DISP/BACK when the operation is complete.
- SET ALL: Protect all pictures.
- RESET ALL: Remove protection from all pictures.

### Downloaded from ManualsCamera.com Manuals

#### CROP

Create a cropped copy of the current picture.

- 1 Display the desired picture.
- 2 Select 🖾 CROP in the playback menu.
- **3** Use the zoom control to zoom in and out and use the selector to scroll the picture until the desired portion is displayed.
- 4 Press MENU/OK to display a confirmation dialog.
- 5 Press MENU/OK again to save the cropped copy to a separate file.
- Larger crops produce larger copies; all copies have an aspect ratio of 4:3. If the size of the final copy will be Ø, YES will be displayed in yellow.

#### RESIZE

Create a small copy of the current picture.

1 Display the desired picture.

- 2 Select 🔚 RESIZE in the playback menu.
- 3 Highlight a size and press **MENU/OK** to display a confirmation dialog.

4 Press MENU/OK to save the resized copy to a separate file.

The sizes available vary with the size of the original image.

#### IMAGE ROTATE

Rotate pictures taken in tall orientation so that they are displayed in tall orientation in the LCD monitor.

- **1** Display the desired picture.
- 2 Select **2 IMAGE ROTATE** in the playback menu.
- **3** Press the selector down to rotate the picture 90° clockwise, up to rotate it 90° counterclockwise.
- **4** Press **MENU/OK**. The picture automatically be displayed in the selected orientation whenever it is played back on the camera.
- Protected pictures can not be rotated. Remove protection before rotating pictures (I 86).
- The camera may not be able to rotate pictures created with other devices.

#### **COPY**

Copy pictures from internal memory to a memory card.


- 1 Select I COPY in the playback menu.
- 2 Highlight one of the following options and press the selector right:
  - 🚯 INTERNAL MEMORY → 🖸 CARD: Copy pictures from internal memory to a memory card.
  - S CARD → INTERNAL MEMORY: Copy pictures from a memory card to internal memory.
- 3 Highlight one of the following options and press MENU/OK:
  - FRAME: Copy selected pictures. Press the selector left or right to view pictures and press MENU/OK to copy the current picture.
  - ALL FRAMES: Copy all pictures.
- Copying ends when the destination is full.
- DPOF print information is not copied (E 65).

#### PRINT ORDER (DPOF)

Select pictures for printing on DPOF- and PictBridge-compatible devices (🕮 65).

#### DISP ASPECT

Choose how High Definition (HD) devices display pictures with an aspect ratio of 4:3 (this option is available only when an HDMI cable is connected). Select **16:9** to display the image so that it fills the screen with its top and bottom cropped out, **4:3** to display the entire image with black bands at either side.



Photographs with an aspect ratio of 16:9 are displayed full screen, those with an aspect ratio of 3:2 in a black frame.

# The Setup Menu

#### Using the Setup Menu

- 1 Display the setup menu.
  - **1.1** Press **MENU/OK** to display the menu for the current mode.
  - **1.2** Press the selector left to highlight the tab for the current menu.

- 1.3 Press the selector down to highlight 💒.
- 1.4 Press the selector right to place the cursor in the setup menu.

#### 2 Adjust settings.

Highlight items and press the selector right to view options, then highlight an option and press **MENU/OK**. Press **DISP/BACK** to exit when settings are complete.





SET-UF

# Setup Menu Options

## O DATE/TIME

Set the camera clock (🕮 18).

## **TIME DIFFERENCE**

Switch the camera clock instantly from your home time zone to the local time at your destination when traveling. To specify the difference between local time and your home time zone:

- **1** Highlight **+ LOCAL** and press the selector right.
- **2** Use the selector to choose the time difference between local time and your home time zone in increments of 15 minutes.

### 3 Press MENU/OK.

To switch between local time and your home time zone, highlight **+ LOCAL** or **• HOME** and press **MENU/OK**.

Option	Description
合 HOME	Switch to the time currently selected for <b>G DATE/TIME</b> (see above).
	Switch to local time. If this option is selected, $+$ and the time and date will be displayed in yellow for three seconds each time the camera is turned on.

#### 💿 言語/LANG.

Choose a language (🕮 121).

#### **SILENT MODE**

Select **ON** to disable the speaker, flash, and LED illuminator in situations in which camera sounds or lights may be unwelcome (note that the flash will still fire in  $\Phi$  mode).

# Downloaded from ManualsCamera.com Manuals

# (defaults to OFF)

(defaults to ENGLISH)

(defaults to 🛆)

## **C** RESET

Reset all settings except **(C) DATE/TIME**, **(D) TIME DIFFERENCE**, and **(D) VIDEO SYSTEM** to default values.

- 1 Highlight 🖼 **RESET** and press the selector right to display a confirmation dialog.
- 2 Highlight OK and press MENU/OK.

## FORMAT

If a memory card is inserted in the camera, this option will format the memory card. If no memory card is inserted, this option will format internal memory. Select **OK** to begin formatting.

- ① All data—including protected pictures—will be deleted from the memory card or internal memory. Be sure important files have been copied to a computer or other storage device.
- ① Do not open the battery cover during formatting.

#### IMAGE DISP.

(defaults to 1.5 SEC)

Choose how long pictures are displayed in the LCD monitor after shooting.

Option	Description	
3 SEC	Pictures are displayed for three seconds ( <b>3 SEC</b> ) or 1.5 seconds ( <b>1.5 SEC</b> ).	
1.5 SEC	Colors may differ slightly from those in the final image.	
ZOOM (CONTINUOUS)	Pictures are displayed until the <b>MENU/OK</b> button is pressed.	
OFF	Pictures are not displayed after shooting.	

• OFF has no effect in continuous shooting mode.

The Setup Menu

🖾 FRAME NO. (defaults to CONT.			
New pictures are stored in image files named using a four-digit file number assigned by adding one to the last file number used. The file number is displayed during playback as shown at right. The file <b>Frame Note:</b> controls whether file numbering is reset to 0001 when a new memory <i>Directory</i>		Directory File	
Option	Description		
CONTINUOUS	Numbering continues from the last file number used on number, whichever is higher. Choose this option to red		

	tures with duplicate file names.
RENEW	Numbering is reset to 0001 after formatting or when a new memory card is inserted.

♦ If the frame number reaches 999-9999, the shutter release will be disabled (🕮 112).

Selecting RESET (B) 92) sets FRAME NO. to CONTINUOUS but does not reset the file number.

Frame numbers for pictures taken with other cameras may differ.

The Setup Menu

#### OPERATION VOL.

Adjust the volume of the sounds produced when camera controls are operated. Choose **40FF** (mute) to disable control sounds.

#### **M SHUTTER VOLUME**

Adjust the volume of the sounds produced when the shutter is released. Choose **40FF** (mute) to disable the shutter sound.

#### **ON SOUND**

94

Choose the sounds used for the shutter, at startup, and for camera controls.

#### PLAYBACK VOLUME

Adjust the volume for movie playback.

#### ICD BRIGHTNESS

Control the brightness of the display.

Option	Description	
	Display brightness is automatically adjusted during shooting in response to am- bient lighting conditions. Brightness is not adjusted during playback.	
	Press the selector up or down to adjust brightness and then press $\ensuremath{MENU/OK}$ . Choose from values between $-5$ and $+5$ .	

(defaults to 📢 💵)

(defaults to 1)

(defaults to <

(defaults to 7)

(defaults to AUTO)

Downloaded from ManualsCamera.com Manuals Menus

#### LCD MODE

Choose whether the display automatically dims to save power in shooting mode. This option does not take effect during playback.

Option	Description	
🖾 POWER SAVE ON	The display dims to save power if no operations are performed for a few seconds. Normal brightness can be restored by pressing the shutter button halfway.	
POWER SAVE OFF	Automatic dimming off.	

#### AUTO POWER OFF

Choose the length of time before the camera turns off automatically when no operations are performed. Shorter times increase battery life; if **OFF** is selected, the camera must be turned off manually. Note that in some situations the camera turns off automatically even when **OFF** is selected.

#### DUAL IS MODE

Choose whether image stabilization is performed at all times when the camera is in shooting mode ((⊕), CONTINUOUS), or only when the shutter button is pressed halfway ((⊕)<sub>≥</sub> SHOOTING ONLY). Choose OFF to turn image stabilization off when using a tripod.

#### The Setup Menu

#### (defaults to 2 MIN)

(defaults to ()))

#### (defaults to 🖾 ON)

RED EYE REMOVAL


The Setup Menu

Choose **ON** to remove red-eye effects caused by the flash when shooting with Intelligent Face Detection.

Red-eye reduction is performed only when a face is detected.

## **Q** DIGITAL ZOOM

If  $\mathbf{ON}$  is selected, selecting  $\mathbf{T}$  at the maximum optical zoom position will trigger digital zoom, further magnifying the image.



 ${\scriptstyle \textcircled{O}}$  Digital zoom produces lower quality images than optical zoom.

Downloaded from ManualsCamera.com Manuals

(defaults to ON)

(defaults to OFF)

#### KOVIE ZOOM TYPE

Choose the type of zoom available during movie recording: Di DIGITAL or OPTICAL.

Movies recorded using digital zoom may be slightly "grainy".

#### **SAVE ORIGINAL IMAGE**

Choose ON to save unprocessed copies of pictures taken using **RED EYE REMOVAL**, **REMOVAL**, **REMOVAL**, or **RED LOW-LIGHT**, or **REMOVAL** 

#### AUTOROTATE PB (XP150/XP160 Only)

Choose ON to automatically rotate "tall" (portrait-orientation) pictures during playback.

#### **GUIDANCE DISPLAY**

Choose whether to display tool tips.

#### **WIDEO SYSTEM**

Choose a video mode for connection to a TV. SECAM is not supported.

Option	Description	
	Select this mode for connection to video devices in North America, the Caribbean, parts of Latin America, and some East Asian countries.	
	Select this mode for connection to video devices in the United Kingdom and much of Europe, Australia, New Zealand, and parts of Asia and Africa.	

(defaults to ON)

(defaults to OFF)

(defaults to NTSC)

(defaults to ON)

(defaults to Opt)

#### DATE DATE STAMP

Stamp the time and/or date of recording on photographs as they are taken.

Option	Description
31+0	Stamp new photographs with the date and time of recording.
31	Stamp new photographs with the date of recording.
OFF	Do not stamp the time and date on new photographs.

- ① Time and date stamps can not be deleted. Turn M DATE STAMP off to prevent time and date stamps appearing on new photographs.
- ① If the camera clock is not set, you will be prompted to set the clock to the current date and time (□ 18).
- ① We recommend that you turn the DPOF "print date" option off when printing images with a time and date stamp (□ 65).
- ① Time and date stamps do not appear on movies or panoramas.

#### DEMONSTRATION (XP150/XP160 Only)


Choose ON for a GPS demo. This option should normally be left OFF.

(defaults to OFF)

# **Technical Notes**

# **Optional Accessories**

The camera supports a wide range of accessories from FUJIFILM and other manufacturers.



\* Available separately.

# **Accessories from FUJIFILM**

The following optional accessories are available from FUJIFILM. For the latest information on the accessories available in your region, check with your local FUJIFILM representative or visit *http://www.fujifilm.com/products/digital\_ cameras/index.html*.

Kechargeable	<b>NP-50</b> : Additional large-capacity NP-50 rechargeable bat- teries can be purchased as required. Note that the NP-50 may record fewer photos per charge than the NP-50A.	
sattery	<b>BC-45W</b> : Replacement battery chargers can be purchased as required. The BC-45W charges NP-50A and NP-50 batteries in about 150 minutes at +20°C (+68°F).	
A/V cable	<b>AV-C1</b> : Use for viewing pictures on TV.	

# Caring for the Camera

To ensure continued enjoyment of the product, observe the following precautions.

# Storage and Use

If the camera will not be used for an extended period, remove the battery and memory card. Do not store or use the camera in locations that are:

- exposed to rain, steam, or smoke
- very humid or extremely dusty
- exposed to direct sunlight or very high temperatures, such as in a closed vehicle on a sunny day
- extremely cold
- subject to strong vibration
- exposed to strong magnetic fields, such as near a broadcasting antenna, power line, radar emitter, motor, transformer, or magnet
- in contact with volatile chemicals such as pesticides
- next to rubber or vinyl products

# Condensation

Sudden increases in temperature, such as occur when entering a heated building on a cold day, can cause condensation inside the camera. If this occurs, turn the camera off and wait an hour before turning it on again. If condensation forms on the memory card, remove the card and wait for the condensation to dissipate.

# <u>Cleaning</u>

Use a blower to remove dust from the protective glass covering the lens and LCD monitor, then gently wipe with a soft, dry cloth. Any remaining stains can be removed by wiping gently with a piece of FUJIFILM lens-cleaning paper to which a small amount of lens-cleaning fluid has been applied. Care should be taken to avoid scratching the protective glass or LCD monitor. The camera body can be cleaned with a soft, dry cloth. Do not use alcohol, thinner, or other volatile chemicals.

# **Traveling**

Keep the camera in your carry-on baggage. Checked baggage may suffer violent shocks that could damage the camera.

# Troubleshooting

# **Problems and Solutions**

## Water in the Camera

Problem	Solution
Water in the camera	The battery-chamber cover was not fully closed before the camera was immersed, or was opened under water: Take the camera to a FUJIFILM-authorized service technician for repairs. Do not turn the camera on.

## **Power and Battery**

Problem	Solution	
The camera does not turn on.	<ul> <li>The battery is exhausted: Charge the battery or insert a fully-charged spare battery (= 7, 9).</li> <li>The battery is inserted incorrectly: Reinsert in the correct orientation (= 10).</li> <li>The battery-chamber cover is not latched: Latch the battery-chamber cover (= 12).</li> </ul>	
The battery runs down quickly.	<ul> <li>The battery is cold: Warm the battery by placing it in a pocket or other warm place and reinsert it in the camera immediately before taking a picture.</li> <li>There is dirt on the battery terminals: Clean the terminals with a soft, dry cloth.</li> <li></li></ul>	

Problem	Solution	
The camera turns off suddenly.	Charge the battery or insert a fully-charged spare battery (🗐 7, 9).	
Charging does not start.	Reinsert the battery in the correct orientation and make sure that the charger is plugged in ( $\square$ 7).	
Charging is slow.	Charge the battery at room temperature (💷 vi).	
The charging lamp lights, but the battery does not charge.	<ul> <li>There is dirt on the battery terminals: Clean the terminals with a soft, dry cloth.</li> <li>The battery has been charged many times: The battery has reached the end of its charging life. Purchase a new battery. If the battery still fails to charge, contact your FUJIFILM dealer.</li> <li>The battery is too hot or too cold: Wait for the battery temperature to stabilize (         7).</li> </ul>	

## **Menus and Displays**

Problem	Solution
Menus and displays are	Select ENGLISH for 🔯 言語/LANG. (🗐 18, 91).
not in English.	

## Shooting

Problem	Solution
No picture is taken when the shutter button is pressed.	• Memory is full: Insert a new memory card or delete pictures (💷 11, 47).
	<ul> <li>Memory is not formatted: Format the memory card or internal memory (I 92).</li> </ul>
	• There is dirt on the memory card contacts: Clean the contacts with a soft, dry cloth.
	<ul> <li>The memory card is damaged: Insert a new memory card (III).</li> </ul>
	• The battery is exhausted: Charge the battery or insert a fully-charged spare battery (🕮 7, 9).
	• The camera has turned off automatically: Turn the camera on ( 💷 16).
	• The indicator lamp was orange when you attempted to record a panorama: Wait until
	the indicator lamps turns off (💷 3).

Problem	Solution
The LCD monitor goes dark after shooting.	The LCD monitor may darken while the flash charges. Wait for the flash to charge (🗐 41).
The camera does not focus.	<ul> <li>The subject is close to the camera: Select macro mode (== 40).</li> <li>The subject is far away from the camera: Cancel macro mode (== 40).</li> <li>The subject is not suited to autofocus: Use focus lock (== 37).</li> </ul>
Macro mode is not available	Choose a different shooting mode (🗐 24).
GPS	<ul> <li>The camera is slow to acquire GPS data: Some time may be needed to acquire GPS data immediately after the camera or LOCATION SEARCH is turned on or if the camera has been unable to acquire GPS data for an extended period.</li> <li>Location data are incorrect: Select OFF for I DEMONSTRATION (III) 98).</li> </ul>
Intelligent Face Detection is not available.	Choose a different shooting mode (💷 24).
No face is detected.	<ul> <li>The subject's face is obscured by sunglasses, a hat, long hair, or other objects: Remove the obstructions.</li> <li>The subject's face occupies only a small area of the frame: Change the composition so that the subject's face occupies a larger area of the frame (== 36).</li> <li>The subject's head is tilted or horizontal: Ask the subject to hold their head straight.</li> <li>The camera is tilted: Keep the camera level (== 20).</li> <li>The subject's face is poorly lit: Shoot in bright light.</li> </ul>
Wrong subject is	The selected subject is closer to the center of the frame than the main subject. Recompose the
selected.	picture or turn face detection off and frame the picture using focus lock (💷 37).

Problem	Solution
The flash does not fire.	<ul> <li>The flash is not available in the current shooting mode: Choose a different shooting mode (= 24).</li> <li>The battery is exhausted: Charge the battery or insert a fully-charged spare battery (= 7, 9).</li> <li>The camera is in continuous mode: Select OFF for ONTINUOUS (= 78).</li> <li>The camera is in silent mode: Turn silent mode off (= 91).</li> <li>The flash is off (③): Choose a different flash mode (= 41).</li> </ul>
Some flash modes are not available.	<ul> <li>The desired flash mode is not available in the current shooting mode: Choose a different shooting mode (1) 24).</li> <li>The camera is in silent mode: Turn silent mode off (1) 91).</li> </ul>
The flash does not fully light the subject.	<ul> <li>The subject is not in range of the flash: Position the subject in range of the flash (== 121).</li> <li>The flash window is obstructed: Hold the camera correctly (== 20).</li> </ul>
Pictures are blurred.	<ul> <li>The protective glass covering the lens is dirty: Clean the glass (== 102).</li> <li>The protective glass covering the lens is blocked: Keep objects away from the lens (== 20).</li> <li>!AF is displayed during shooting and the focus frame is displayed in red: Check focus before shooting (== 110).</li> <li>!Or is displayed during shooting: Use the flash or a tripod (== 42).</li> </ul>
Pictures are mottled.	<ul> <li>A slow shutter speed is selected at high temperatures. This is normal and does not indicated a malfunction.</li> <li>The camera has been used continuously at high temperatures or a temperature warning is displayed. Turn the camera off and wait for it to cool down.</li> </ul>
Vertical lines appear in pictures.	The camera has been used continuously at high temperatures. Turn the camera off and wait for it to cool down.

Problem	Solution
"Smear" in the form of	Vertical purple or white lines may appear after the camera has been used continuously at high
vertical purple or white	temperatures or when a very bright object is in the frame; this phenomenon is common to all CCD
lines appears in the	image sensors and does not indicate a malfunction. These lines are recorded in movies but do not
display.	appear in photographs. Avoid framing bright objects when filming movies.
Sounds made by the camera are recorded with	• CONTINUOUS is selected for <b>MOVIE AF MODE</b> : Select a different AF mode ( 79).
	• Zoom was adjusted during shooting: Do not adjust zoom during shooting.
movies.	Intelligent Face Detection is on: Turn Intelligent Face Detection off (     36).

# Playback

Problem	Solution
Pictures are grainy.	The pictures were taken with a different make or model of camera.
Playback zoom is unavail- able.	The current picture is a resized copy with a size of 💯.
No sound in movie playback.	• Playback volume is too low: Adjust playback volume (💷 94).
	• The microphone was obstructed: Hold the camera correctly during recording (🗐 20, 58).
	• The speaker is obstructed: Hold the camera correctly during playback (🗐 60).
Selected pictures are not	Some of the pictures selected for deletion are protected. Remove protection using the device with
deleted.	which it was originally applied (💷 86).
File numbering is unexpectedly reset.	The battery-chamber cover was opened while the camera was on. Turn the camera off before opening the battery-chamber cover ( $\boxplus$ 16).

connections/miscenaneous	
Problem	Solution
No picture or sound.	<ul> <li>The camera is not properly connected: Connect the camera properly (== 61).</li> <li>An A/V cable was connected during movie playback: Connect the camera once movie playback has ended.</li> <li>Input on the television is set to "TV": Set input to "VIDEO".</li> <li>The camera is not set to the correct video standard: Match the camera IM VIDEO SYSTEM setting to the TV (== 97).</li> <li>The volume on the TV is too low: Adjust the volume.</li> </ul>
No color	Match the camera 🚟 VIDEO SYSTEM setting to the TV (💷 97).
The computer does not recognize the camera.	Be sure the camera and computer are correctly connected (💷 71).
Pictures can not be printed.	<ul> <li>The camera is not properly connected: Connect the camera correctly (== 63).</li> <li>The printer is off: Turn the printer on.</li> </ul>
Only one copy is printed/ the date is not printed.	The printer is not PictBridge compatible.
The camera is unre- sponsive.	<ul> <li>Temporary camera malfunction: Remove and reinsert the battery (= 9).</li> <li>The battery is exhausted: Charge the battery (= 7) or insert a fully-charged spare battery (= 9).</li> </ul>
The camera does not function as expected.	Remove and reinsert the battery (🕮 9). If the problem persists, contact your FUJIFILM dealer.
No sound.	Turn silent mode off (💷 91).

### Connections/Miscellaneous

Problem	Solution
Time and date stamps	<ul> <li>Time and date stamps are not correct: Set the camera clock (</li></ul>
	• Time and date stamps appear on photographs: Time and date stamps can not be deleted. To prevent stamps appearing on new photographs, select OFF for <b>DATE STAMP</b> ( <b>EP 98</b> ).
FinePixViewer can not be installed or does not start.	FinePixViewer does not support Mac OS X version 10.7 or later. Use one of the applications supplied with Mac OS X or purchase other software.

# Warning Messages and Displays

# The following warnings are displayed in the LCD monitor:

Warning	Description
<b>□</b> (red)	Low battery. Charge the battery (💷 7) or insert a fully-charged spare battery (💷 9).
💶 (blinks red)	Battery exhausted. Charge the battery (💷 7) or insert a fully-charged spare battery (💷 9).
ļ <b>o</b> r	Slow shutter speed. Pictures may be blurred; use the flash or a tripod.
<b>?AF</b> (displayed in red with red focus frame)	<ul> <li>The camera can not focus. Try one of the following solutions:</li> <li>Use focus lock to focus on another subject at the same distance, then recompose the picture (== 37).</li> <li>Use macro mode to focus when taking close-ups (== 40).</li> </ul>
!AE	The subisetistic has beink avera dayl and the visture will be sure an under summer of light subiset
Aperture or shutter speed displayed in red	The subject is too bright or too dark and the picture will be over- or under-exposed. If the subject is dark, use the flash ( 1).
FOCUS ERROR	
TURN OFF THE CAMERA AND TURN ON AGAIN	Camera malfunction or moving parts of lens obstructed. Turn the camera off and then on again, taking care not to touch the lens. If the message persists, contact a FUJIFILM dealer.
LENS CONTROL ERROR	
CARD NOT INITIALIZED	<ul> <li>The memory card or internal memory is not formatted or the memory card was formatted in a computer or other device: Format the memory card or internal memory using the EFFORMAT option in the camera setup menu (EFF 92).</li> <li>The memory card contacts require cleaning: Clean the contacts with a soft, dry cloth. If the message is repeated, format the card (EFF 92). If the message persists, replace the card.</li> <li>Camera malfunction: Contact a FUJIFILM dealer.</li> </ul>
PROTECTED CARD	The memory card is locked. Unlock the card (💷 11).
BUSY	The memory card is incorrectly formatted. Use the camera to format the card (🗐 92).

Warning	Description
!	Turn the camera off and wait for it to cool. If no action is taken, the camera will turn off auto- matically.
CARD ERROR	The memory card is not formatted for use in the camera. Format the card (🗐 92).
	The memory card contacts require cleaning or the memory card is damaged. Clean the contacts with a soft, dry cloth. If the message is repeated, format the card (🗐 92). If the message persists, replace the card.
	Incompatible memory card. Use a compatible card (🕮 14).
	Camera malfunction. Contact a FUJIFILM dealer.
IN MEMORY FULL	
SD MEMORY FULL	The memory card or internal memory is full and pictures can not be recorded or copied. Delete
INTERNAL MEMORY IS FULL	pictures or insert a memory card with more free space.
INSERT A NEW CARD	
WRITE ERROR	Memory card error or connection error: Reinsert the card or turn the camera off and then     on again. If the message persists, contact a FUJIFILM dealer.
	Not enough memory remaining to record additional pictures: Delete pictures or insert     a memory card with more free space.
	• The memory card or internal memory is not formatted: Format the memory card or internal memory (🗐 92).
READ ERROR	<ul> <li>The file is corrupt or was not created with the camera: The file can not be viewed.</li> <li>The memory card contacts require cleaning: Clean the contacts with a soft, dry cloth. If the message is repeated, format the card (EB 92). If the message persists, replace the card.</li> <li>Camera malfunction: Contact a FUJIFILM dealer.</li> </ul>

Warning	Description
FRAME NO. FULL	The camera has run out of frame numbers (current frame number is 999-9999). Format the memory card and select <b>RENEW</b> for <b>PRAME NO.</b> in the setup menu. Take a picture to reset frame numbering to 100-0001, then select <b>CONTINUOUS</b> for <b>PRAME NO.</b> (E) 93).
PRESS AND HOLD THE DISP BUTTON TO DEACTIVATE SILENT MODE	An attempt was made to choose a flash mode or adjust the volume with the camera in silent mode. Exit silent mode before choosing a flash mode or adjusting the volume (📖 91).
TOO MANY FRAMES	A search has returned more than 5,000 results, or more than 999 frames were selected for dele- tion. Perform a different search or select fewer pictures.
PROTECTED FRAME	An attempt was made to delete to a protected picture. Remove protection and try again (🗐 86).
640 CAN NOT CROP	640 pictures can not be cropped.
CAN NOT CROP	The picture is damaged or was not created with the camera.
M CANNOT EXECUTE	An attempt was made to greate a resized convict a size equal to an larger than the evisional
S CANNOT EXECUTE	An attempt was made to create a resized copy at a size equal to or larger than the original. Choose a smaller size.
640 CANNOT EXECUTE	
CAN NOT ROTATE	An attempt was made to rotate a picture that can not be rotated.
😫 CAN NOT ROTATE	Movies can not be rotated.
CANNOT EXECUTE	Retouch and red-eye removal are not available with movies, pictures taken with other cameras,
😫 CANNOT EXECUTE	or pictures that can not be played back.

Warning	Description
NO CARD	No memory card inserted when 🗱 COPY is selected in the playback menu. Insert a memory card.
SD NO IMAGE	
NO IMAGE	The source selected for I COPY contains no images. Select a different source.
DPOF FILE ERROR	The DPOF print order on the current memory card contains more than 999 images. Copy the pictures to internal memory and create a new print order.
CAN NOT SET DPOF	The picture can not be printed using DPOF.
😫 CAN NOT SET DPOF	Movies can not be printed using DPOF.
COMMUNICATION ERROR	A connection error occurred while pictures were being printed or copied to a computer or other device. Confirm that the device is turned on and that the USB cable is connected.
PRINTER ERROR	Printer out of paper or ink, or other printer error. Check printer (see printer manual for details). To resume printing, turn the printer off and then turn it back on.
PRINTER ERROR RESUME?	Printer out of paper or ink, or other printer error. Check printer (see printer manual for details). If printing does not resume automatically, press <b>MENU/OK</b> to resume.
CANNOT BE PRINTED	An attempt was made to print a movie, a picture not created with the camera, or a picture in a format not supported by the printer. Movies and some pictures created with other devices can not be printed; if the picture is a still picture created with the camera, check the printer manual to confirm that the printer supports the JFIF-JPEG or Exif-JPEG format. If it does not, the pictures can not be printed.

# Appendix

# **Tips and Tricks**

The following tips and tricks will help you get the most from your camera.

# Pattery Performance

Choose the following settings for improved battery performance:

- LOCATION SEARCH (🕮 32, 53): OFF
- TRACKING DATA (🗐 32, 53): OFF
- 🖾 FACE DETECTION (🕮 78): OFF
- 🖪 AF MODE (🕮 79): 回 CENTER
- 🗈 LED ILLUMINATOR (🕮 80): OFF
- 📾 LCD MODE (🕮 95): 🖬 POWER SAVE ON
- 🚺 DUAL IS MODE (📖 95): OFF

# 🍟 The Self-timer

- To prevent blur caused by the camera moving when the shutter button is pressed, use the two-second timer.
- To take a group portrait that includes the photographer, use the group timer. The timer will not start until the person who has pressed the shutter button appears in the frame.

💿 Intelligent Face Detection
When <b>ON</b> is selected for 🖾 FACE DETECTION (🗐 78), you can:
Shooting • Zoom in on faces when ZOOM (CONTINUOUS) is selected for  Imes IM-AGE DISP. (
• Remove red-eye by selecting ON for 💿 RED EYE REMOVAL (🕮 96).
Playback • Zoom in on faces during slide shows (🗐 85) or by pressing the selector down during playback.
• Search for faces using 🥶 IMAGE SEARCH (💷 48).
• Crop the background from portraits using 🖪 CROP (🗐 87).
<b>Printing</b> • <b>Print</b> one copy for each person in the photo.

# Tips and Tricks

- To photograph the same scene both with and without the flash, select **•\$ NATURAL & \$** for **•SHOOTING MODE** (**•**25). Use multi-frame playback (**•**46) to compare the two shots.
- To photograph subjects that are in motion, select 🖽 TRACK-ING for 🗊 AF MODE (🕮 79).
- To photograph poorly-lit subjects close to the camera, select **ON** for **□ LED ILLUMINATOR** (□ 80).
- To fine-tune brightness of a photograph, select **PPROGRAM AE** (■ 25) for **SHOOTING MODE**, choose an appropriate white balance option (■ 77), and adjust exposure compensation (■ 39).









# Internal Memory/Memory Card Capacity

The following table shows the recording time or number of pictures available at different image sizes. All figures are approximate; file size varies with the scene recorded, producing wide variations in the number of files that can be stored. The number of exposures or length remaining may not diminish at an even rate. A limited number of test pictures can be taken when no memory card is inserted.

/	Medium	Internal	memory							
<b>e</b>		(approx	. 47 MB)	4	GB	8 GB				
		FINE	FINE NORMAL		NORMAL	FINE	NORMAL			
	4:3	7	14	650	1220	1290	2420			
-	3:2	7	16	720	1400	1430	2760			
Photographs	16:9	9	18	810	1560	1610	3100			
	M 4:3	14	28	1250	2450	2480	4840			
	M 16:9	19	37	1660	3130	3280	6200			
	<b>S</b> 4:3	34	57	2900	4900	5740	9690			
	S 16:9	50	71	4260	6120	8420	12110			
	1920 <sup>1</sup>	-	_	34	min.	51 min.				
	1280 <sup>1</sup>	-	_	69	min.	104 min.				
Movies	640 <sup>2</sup>	1 min.	39 sec.	147	min.	222 min.				
vies	<b>IS</b> 640 × 480 <sup>3</sup>	_	_	69	min.	146 min.				
	<b>IS</b> 320 × 240 <sup>3</sup>	-	_	192	min.	291 min.				
	<b>IS</b> 320 × 240 <sup>3</sup>	_	_	96	min.	145 min.				

# FinePix XP150/XP160

1 Use a **CLASS** card or better. Individual movies can not exceed 29 minutes in length. FULL HD and HD movies can not be recorded to internal memory.

2 Individual movies can not exceed 115 minutes in length.

3 Use a chread card or he tor Individual meyies can not exceed 30 seconds in length. Appendix

$\langle$	Medium	Internal	memory							
ŧ		(approx	. 95 MB)	40	5B	8 G B				
		FINE	NORMAL	FINE	NORMAL	FINE	NORMAL			
	4:3	15	29	650	1220	1290	2420			
-	3:2	17	33	720	1400	1430	2760			
Photographs	16:9	20	37	810	1560	1610	3100			
	M 4:3	31	59	1250	2450	2480	4840			
	M 16:9	41	76	1660	3130	3280	6200			
	S 4:3	70	120	2900	4900	5740	9690			
	S 16:9	104	150	4260	6120	8420	12110			
	🖽 1920 <sup>1</sup>	_		34	min.	51 min.				
	1280 <sup>1</sup>	_	_	69	min.	104 min.				
Movies	640 <sup>2</sup>	3 min.	11 sec.	147	min.	222 min.				
vies	<b>IS 640 × 480</b> <sup>3</sup>	_	_	69	min.	146 min.				
	<b>IS</b> 320 × 240 <sup>3</sup>		_	192	min.	291 min.				
	<b>IS</b> 320 × 240 <sup>3</sup>	_	_	96	min.	145 min.				

# FinePix XP170/XP100/XP110

1 Use a **CLASS** card or better. Individual movies can not exceed 29 minutes in length. FULL HD and HD movies can not be recorded to internal memory.

2 Individual movies can not exceed 115 minutes in length.

3 Use a CLASS Card or better. Individual movies can not exceed 30 seconds in length.

# Specifications

System											
Model	Digital Camera FinePix XP170, XP150/XP160, XP100/XP110										
Effective pixels	4.4 million										
CCD	1/2.3 - in. square pixel CMOS with primary color filter										
Storage media	Internal memory • SD/SDHC/SDXC memory cards										
	XP150/XP160: approx. 47 MB										
	XP170/XP100/XP110: approx. 95 MB										
File system	Compliant with Design Rule for Camera File System (DCF), Exif 2.3, and Digital Print Order										
	Format (DPOF)										
File format	Still pictures: Exif 2.3 JPEG (compressed)										
	Movies: MOV (H.264)										
Image size (pixels)	• • • • • • • • • • • • • • • • • • •										
	• M <b>4:3</b> : 3,072 × 2,304 • M <b>16:9</b> : 3,072 × 1,728										
	• <b>S</b> 4:3: 2,048 × 1,536 • <b>S</b> 16:9: 1,920 × 1,080										
Lens	Fujinon 5 × optical zoom lens, F3.9 (wide angle) – F4.9 (telephoto)										
Focal length	<b>f=5.0 mm-25.0 mm</b> (35-mm format equivalent: 28 mm-140 mm)										
Digital zoom	• <b>4:3</b> : Approx. 6.8 × (up to 34 × when combined with optical zoom)										
	<ul> <li>16:9: Approx. 5.1 × (up to 25 × when combined with optical zoom)</li> </ul>										
Aperture	F3.9/F6.2 (wide angle), F4.9/F8.0 (telephoto)										
Focus range	Approx. 60 cm (2.0 ft.)-infinity (wide angle); 1.0 m (3.3 ft.)-infinity (telephoto)										
(distance from front of lens)	• Macro: approx. 9 cm–80 cm/3.5 in.–2.6 ft. (wide angle); 40 cm–80 cm/1.3 ft.–2.6 ft. (telephoto)										

## Specifications

System	
Sensitivity	Standard output sensitivity equivalent to ISO 100, 200, 400, 800, 1600, 3200; AUTO
Metering	256-segment through-the-lens (TTL); MULTI
Exposure control	Programmed AE
Exposure compensation	$-2 \text{ EV} - +2 \text{ EV}$ in increments of $\frac{1}{3} \text{ EV}$
Image stabilization	Optical stabilization
Shutter speed	• AUTO mode: ¼ s-½,000 s
(combined mechanical and electronic shutter)	• <b>Other modes:</b> 4 s-1/2,000 s
Continuous	• 🖕: up to 3 fps; max. 12 frames
continuous	• A to to 5 fps; max. 12 frames
	• P: up to 10 fps; max. 12 frames
	• 🚡 : up to 3 fps; last 12 frames recorded
	• Text : up to 5 fps; last 12 frames recorded
	• 🔁: up to 10 fps; last 12 frames recorded
Focus	Mode: Single AF, continuous AF
	Focus-area selection: CENTER, TRACKING
	Autofocus system: Contrast-detect TTL AF
White balance	Auto, direct sunlight, shade, daylight fluorescent, warm white fluorescent, cool white fluores-
	cent, incandescent
Self-timer	Off, 2 sec., 10 sec., 🌤 (COUPLE TIMER), ć≥ (GROUP TIMER)

System	
Flash	Auto flash; effective range when sensitivity is set to <b>AUTO</b> is approx. 70 cm $-3.1$ m/2.3 ft. $-10.2$ ft. (wide angle), 70 cm $-2.7$ m/2.3 ft. $-8.9$ ft. (telephoto); effective range in macro mode is approx. 30 cm $-80$ cm/1.0 ft. $-2.6$ ft.
Flash mode	Auto, fill flash, off, slow sync (red-eye removal off); auto with red-eye removal, fill flash with red- eye removal, off, slow sync with red-eye removal (red-eye removal on)
LCD monitor	2.7-in., 230 k-dot color LCD monitor; frame coverage approx. 96 %
Movies	• 〒 1920: 1,920 × 1,080 (1080p), 30 fps       • □ 1280: 1,280 × 720 (720p), 30 fps         • ⊡ 1640 × 480 (VGA), 30 fps       • □ 1660 × 480: 80 fps         • □ 320 × 240: 160 fps       • □ 320 × 240: 240 fps         Note: 日刊, □D, and ⊡D movies are recorded with monaural sound.
Languages	Arabic, Bulgarian, Simplified Chinese, Traditional Chinese, Czech, Danish, Dutch, English, Farsi, Finnish, French, German, Greek, Hebrew, Hungarian, Indonesian, Italian, Japanese, Kazakh, Korean, Latvian, Lithuanian, Norwegian, Polish, Portuguese, Romanian, Russian, Serbian, Slovak, Spanish, Swedish, Thai, Turkish, Ukrainian, Vietnamese
Date map database was created (XP150/XP160 only)	October 2010
Input/output terminals	
<b>A/V OUT</b> (audio/video output)	NTSC or PAL output with monaural sound
Digital input/output	USB 2.0 High-Speed; shares A/V OUT connector, MTP/PTP
HDMI output	Micro HDMI connector

## Specifications

Power supply/other								
Power supply	NP-50A rechargeable battery							
Battery life (approximate	Battery type	Approximate number of frames						
number of frames that can	NP-50A (type supplied with camera)	300						
be taken with a fully-charged battery)	CIPA standard, measured in  (auto) mode us ory card.	ing battery supplied with camera and SD mem-						
	<b>Note</b> : Number of shots that can be taken with decline at low temperatures.	battery varies with battery charge level and will						
Camera dimensions $(W \times H \times D)$	102.7 mm $\times$ 71.3 mm $\times$ 27.4 mm/4.0 in. $\times$ 2.8 in. $\times$ 1.0 in., excluding projections							
Shooting weight	<ul> <li>XP170/XP150/XP160: Approx. 205 g/7.2 oz.</li> <li>XP100/XP110: Approx. 195 g/6.8 oz., includi</li> </ul>	<i>3</i> , , ,						
Camera weight	KP170: Approx. 180 g/6.3 oz., excluding batteres      XP150/XP160: Approx. 185 g/6.5 oz., excludientes      XP100/XP110: Approx. 175 g/6.1 oz., excludientes      XP100/XP110: Approx.1 0 g/6.1 oz., excludientes      XP100/XP110: Approx.1 0 g/6.1 oz., excludientes      XP100/XP110: Approx.1 0 g/6.1 oz., excludientes      XP100/XP100: Approx.1 0 g/6.1 oz., excludientes      XP1	ng battery, accessories, and memory card						
Operating conditions	<ul> <li>Temperature: -10 °C - +40 °C/+14 °F - +1</li> <li>Humidity: 10% - 80% (no condensation)</li> </ul>	04 °F						
Wireless transmitter (XP	170 only)							
Standards	IEEE 802.11b/g/n (standard wireless protocol)							
Operating frequency	• U.S.A., Canada, Taiwan: 2,412 MHz–2,462	. ,						
	• Other countries: 2,412 MHz–2,472 MHz (13	channels)						
Access protocols	Infrastructure							

NP-50A rechargeable bat	ttery
Nominal voltage	DC 3.7 V
Nominal capacity	1000 mAh
Operating temperature	0 °C - +40 °C/+32 °F - +104 °F
<b>Dimensions</b> ( $W \times H \times D$ )	$35.4 \text{ mm} \times 40.0 \text{ mm} \times 6.6 \text{ mm}/1.3 \text{ in.} \times 1.5 \text{ in.} \times 0.2 \text{ in.}$
Weight	Approx. 20 g/0.7 oz.
BC-50A battery charger	
Rated input	100 V-240 V AC, 50/60 Hz
Input capacity	5.5 V (100 V/240 VA)
Rated output	4.2 V DC, 550 mA
Supported batteries	NP-50A and NP-50 rechargeable batteries
Charging time	Approx. 180 minutes (+20 °C/+68 °F)
Operating temperature	0 °C - +40 °C/+32 °F - +104 °F
<b>Dimensions</b> ( $W \times H \times D$ )	48 mm $\times$ 94 mm $\times$ 26 mm/1.8 in. $\times$ 3.7 in. $\times$ 1.0 in., excluding projections
Weight	Approx. 65 g/2.2 oz., excluding battery

Weight and dimensions vary with the country or region of sale.


# Notices

- Specifications subject to change without notice. FUJIFILM shall not be held liable for damages resulting from errors in this manual.
- Although the LCD monitor is manufactured using advanced high-precision technology, small bright points and anomalous colors may appear, particularly in the vicinity of text. This is normal for this type of LCD monitor and does not indicate a malfunction; images recorded with the camera are unaffected.
- Digital cameras may malfunction when exposed to strong radio interference (e.g., electric fields, static electricity, or line noise).
- Due to the type of lens used, some distortion may occur at the periphery of images. This is normal.


# 🖙 Uploading Pictures to a Smartphone (Tablet) (XP170 Only)

To upload pictures to a smartphone over a wireless network:

- 1 Start the FUJIFILM Photo Receiver app on your smartphone. For information on downloading the free FUJIFILM Photo Receiver app, visit: http://app.fujifilm-dsc.com/
- 2 Display a still picture and press the E button on the camera and tap 🔄 icon on the smartphone (movies can not be selected for upload).
- **3** When the smartphone is detected, the camera will display a message. Verify the destination on both the camera and smartphone and press MENU/OK.
- 4 When upload is complete, the camera will display the message "TRANSMISSION COMPLETED". Press the selector left or right to view more images and press MENU/OK to upload additional still pictures, or press **DISP/BACK** to terminate the connection







SMARTPHONE-123456

FUJIFILM-XXXX-1234 OK TRANSMIT BACK CANCE

SEND OK?

## 🖙 Uploading Pictures to a Smartphone (Tablet) (XP170 Only)

- Be sure that the battery is charged before beginning upload. Do not remove the battery, turn the camera off, or remove the memory card until upload is complete.
- If you are unable to upload still pictures, check the smartphone's settings.
- Personal information may be revealed by the titles, dates, GPS data (where applicable), and other information included with pictures. Verify the destination before beginning upload.
- The time needed for upload varies with file size and the distance to the destination. At default settings (recommended), ON is selected for SWIRELESS SETTING > RESIZE IMAGE ON SENDING SWI and images are resized to SWI for upload (the setting can be changed from the setup menu).
- The camera may be unable to upload images created or modified on other devices.
- The camera can connect to only one smartphone at a time.
- Upload may not succeed depending on signal quality.
- The camera will end the connection to the smartphone automatically if no operations are performed for a set period.

# Playback Menu Options

#### **WIRELESS IMAGE TRANSFER**

Upload pictures to a smartphone over a wireless network (🕮 125).

# Setup Menu Options

## WIRELESS SETTING

Adjust settings for connection to a smartphone over a wireless network.

- NAME: Enter a name for the camera (the default name is unique to the camera).
- RESIZE IMAGE ON SENDING W: Choose ON (the default setting, recommended in most circumstances) to resize larger images to W for upload, OFF to upload images at their original size. Resizing applies only to the copy uploaded to the smartphone; the original is not affected.

# **Problems and Solutions**

## Connections/Miscellaneous

Problem	Solution
Problem connecting or	The smartphone is too far away: Move the devices closer.
uploading pictures to smartphone.	• Nearby devices are causing radio interference: Move the camera and smartphone away from microwave ovens or cordless phones.
Can not upload images.	<ul> <li>The smartphone is connected to another device: The smartphone and camera can connect to only one device at a time. End the connection and try again.</li> <li>Are there several smartphones in the vicinity: Try connecting again. The presence of mul- tiple smartphones can make connection difficult.</li> </ul>
	The current image is a movie or was created on another device and can not be uploaded to a smart- phone.
Smartphone will not display pictures.	Select <b>ON</b> for <b>WIRELESS SETTING</b> > <b>RESIZE IMAGE ON SENDING EVAL</b> . Selecting <b>OFF</b> increases upload times for larger images; in addition, some phones may not display images over a certain size.

# **IMPORTANT**: Read the following notices before using the camera's built-in wireless transmitter.

- ① This product, which contains encryption function developed in the United States, is controlled by the United States Export Administration Regulations and may not be exported or re-exported to any country to which the United States embargoes goods.
- Use only as part of a wireless network. FUJIFILM does not accept liability for damages resulting from unauthorized use. Do not use in applications requiring a high degree of reliability, for example in medical devices or other systems that may directly or indirectly impact human life. When using the device in computer and other systems that demand a greater degree of reliability than wireless networks, be sure to take all necessary precautions to ensure safety and prevent malfunction.
- Use only in the country in which the device was purchased. This device conforms to regulations governing wireless network devices in the country in which it was purchased. Observe all location regulations when using the device. FUJIFILM does not accept liability for problems arising from use in other jurisdictions.
- Wireless data (images) may be intercepted by third parties. The security
  of data transmitted over wireless networks is not guaranteed.
- Do not use the device in locations subject to magnetic fields, static electricity, or radio interference. Do not use the transmitter in the vicinity of microwave ovens or in other locations subject to magnetic fields, static electricity, or radio interference that may prevent reception of wireless signals. Mutual interference may occur when the transmitter is used in the vicinity of other wireless devices operating in the 2.4 GHz band.
- <u>The wireless transmitter operates in the 2.4 GHz band using DSSS and OFDM modulation.</u>

#### Wireless Network Devices: Cautions

 This device operates on the same frequency as commercial, educational, and medical devices and wireless transmitters. It also operates on the same frequency as licensed transmitters and special unlicensed lowvoltage transmitters used in RFID tracking systems for assembly lines and in other similar applications.

 To prevent interference with the above devices, observe the following precautions. Confirm that the RFID transmitter is not in operation before using this device. Should you observe that the device causes interference in licensed transmitters used for RFID tracking, immediately choose a new operating frequency for this device to prevent additional interference. If you notice that this device causes interference in low-voltage RFID tracing systems, contact a FUJIFILM representative.

# FUJIFILM


## **FUJIFILM Corporation**

7-3, AKASAKA 9-CHOME, MINATO-KU, TOKYO 107-0052, JAPAN

http://www.fujifim.com/products/digital\_cameras/index.html Downloaded from ManualsCamera.com Manuals

# **Restrictions on Camera Settings**

The options available in each shooting mode are listed below.



														Sho	ootin	g M	ode							Shooting Mode													
Option			SR AUIO	Ô	Ρ		I HDR	@\$		۰	8		Provel	*	Ċ	۶¢*	*	-8-	£1	¢⊮	** **	¢	Y	*	TEXT												
			단	~	V	V				~	V	V	V		~	V	V	~	V	~	V	V	~	V	V	V											
		İ	Г <mark>с</mark> М	~	~	~				~	V	~	~		~	V	~	~	V	~	~	~	~	V	~	~											
		Ì	Ō	~	V	V				V	V	V	V		V	V	V	V	V	~	V	V	V	V	V	V											
	Q	Ì	ĥ	~	V	V				V	V	V	V		V	V	V	V	V	~	V	V	V	V	V	V											
		ĺ	₩Ĵ	V	V	V				V	V	V	V		~	V	V	V	V	~	V	V	~	V	V	~											
	1         1         1         1         1           1	V				V	V	~	V		~	V	V	V	V	~	V	V	~	V	V	~															
		[	OFF	V	V	~				V	V	~	V		~	V	V	V	V	~	V	~	~	V	V	~											
	101		ON	V	V	~			~	V	V	~				V	~	V	V	~				V													
	8		OFF		V	~	~	V	~	V	V	~	<b>1</b>	$\checkmark^1$	$\checkmark^1$	V	~	V	V		<b>1</b>	$\checkmark^1$	$\checkmark^1$	V	$\checkmark^1$	$\checkmark^1$											
			Ð		~	~	$\checkmark^1$	$\mathbf{V}^1$	$\checkmark^1$	$\checkmark^1$	<b>1</b>	$\checkmark^1$	$\mathbf{V}^1$	$\checkmark^1$	$\checkmark^1$	$\mathbf{V}^1$	$\checkmark^1$	$\checkmark^1$	<b>1</b>	$\checkmark^1$	$\mathbf{V}^1$	$\checkmark^1$	$\checkmark^1$	$\mathbf{V}^1$	$\checkmark^1$	$\checkmark^1$											
			C.,		~	~																															
	E	ib 1	1920																								~										
	640		1280																								~										
			640																								V										
		640×480																									~										
	HS																										~										
		32	0×240																								~										
																											~										
(																											~										
		D		-	-	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~											
		ļ		-	-	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~										
	a( <b>1</b> 11)0	ļ		· ·		~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~										
			OFF	~	~	~	~	~	~	~	V	~	~	~	~	~	~	~	V	~	~	~	~	~	~	~	~										
		۵		✓ <sup>2</sup>	1	~	~	~	~	~	V	~	•		1	~	~	~	~	~	•	~	~	V	~	~	~										
		ő		~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~										
		٩		~	~	~	~	~	~		~	~				~	~	~	~	~	~	~	~	~													
fps		~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	~	V	~	~	~	~	~	~	~												

#### Restrictions on Camera Settings

1 Automatically optimized for selected shooting mode.

2 OFF only.