

ASM2 Module

Instructions for installation & use

PRODUCT LISTING

APPLICATION

IMPORTANT SAFETY INFORMATION

INSTALLATION

INSTALLATION DRAWINGS

WARRANTY AND SERVICE

PRODUCT LISTING

Code	Product description and rating
90850	ASM2 12V/140A (e11022447)
90851	ASM2 24V/140A (e11022447)
90852	ASM2 12V/250A (e11022447)
90853	ASM2 24V/250A (e11022447)
70431	ASM2 12V/140A
	Options (e11022447)
90870	ASM2 Assured Starting 12V or 24V
90871	ASM2 Load Shed 12V
90872	ASM2 Load Shed 24V
90873	ASM2 Deep Discharge Protection 12V
90874	ASM2 Deep Discharge Protection 24V
90875	ASM2 Remote Indication 12V
90876	ASM2 Remote Indication 24V
70128	ASM2 Mod for Bosch Regulator, Part Number F 00M 145 248
70285	ASM2 Mod for Bosch Regulator, Part Number 1 197 311 558
70286	ASM2 Mod for Prestolite Regulator, Part Number 8RG3119
70288	ASM2 Service Aid for Modified Regulators
70312	ASM2 Mod for BES Alternator
70313	ASM2 Mod for Bosch Regulator, Part Number 1 197 311 213
70339	ASM2 Mod for Bosch Regulator, Part Number 1 197 311 300
70346	ASM2 Mod for Valeo Alternator, Part Number 254531A, A14 VI 42+
70358	ASM2 Mod for Bosch Regulator, Part Number F 00M 145 256/302
70360	ASM2 Mod for Bosch Regulator, Part Number F 00M 145 299
70362	ASM2 Interface for Twin Bosch Regulators, Part Number F 00M 145 256
70416	ASM2 Mod for Prestolite Regulator, Type 594A-9
70422	ASM2 Mod for Bosch Regulator, Part Number F 00M 145 233
71032	ASM2 to Twin N-type Alternator Interface
71033	ASM2 to Twin P-type Alternator Interface

APPLICATION

(ASC) Automatic Split Charge (charge source connected to MAIN stud)

The MAIN stud connection is monitored by a voltage sensing circuit, which controls the linking of the main and auxiliary batteries together. When a charging voltage (V_c) is detected at the MAIN stud, the Split Charge closes, allowing charging current from the alternator/charger to pass to the auxiliary battery. The Split Charge remains closed until the (combined) battery voltages fall to a level (V_h or V_o), indicating significant depth of discharge. The Split Charge will then open preserving a high level of charge in the main battery.

Notes:

1. The following switching thresholds apply: -

12V/140A (70431/90850) 12V/250A (90852)	24V/140A (90851) 24V/250A (90853)
V_c 12.9V +/- 0.1V	25.8 V +/- 0.2V
V_h 12.7V +/- 0.1V	25.4V +/- 0.2V
V_o 12.3V +/- 0.1V	24.6V +/- 0.2V

2. When the ASC is closed and the MAIN/AUX battery voltage falls to between V_h and V_o the ASC remains closed for approximately 30 sec before opening. Thus small short-term voltage reductions are ignored and the phenomenon of split charge cycling is minimised.
3. When the ASC is closed and the MAIN/AUX battery voltage falls to be less than V_o , the ASC opens in less than 3 seconds.

(ASC) Automatic Split Charge (charge source connected to AUX stud)

The AUX stud connection is monitored by a voltage sensing circuit, which controls the linking of the main and auxiliary batteries together. When a charging voltage (V_c) is detected at the AUX stud, the Split Charge closes, allowing charging current from the alternator/charger to pass to the main battery. The Split Charge remains closed until the (combined) battery voltages fall to a level (V_h or V_o), indicating significant depth of discharge. The Split Charge will then open preserving a high level of charge in the auxiliary battery.

Notes:

1. The following switching thresholds apply: -

12V/140A (70431/90850) 12V/250A (90852)	24V/140A (90851) 24V/250A (90853)
V_c 12.9V +/- 0.1V	25.8V +/- 0.2V
V_h 12.7V +/- 0.1V	25.4V +/- 0.2V
V_o 12.3V +/- 0.1V	24.6V +/- 0.2V

2. When the ASC is closed and the MAIN/AUX battery voltage falls to between V_h and V_o the ASC remains closed for approximately 30 sec before opening. Thus small short term voltage reductions are ignored and the phenomena of split charge cycling is minimised
3. When ASC is closed and the MAIN/AUX battery voltage falls to be less than V_o , the ASC opens in less than 3 seconds.

(APC) Alternator Power Controller (Alternator Regulator Disabled)

Note: This mode of operation should not be applied with regulators that have an internally generated warning lamp output. Please refer to Antares (Europe) Limited for further advice.

If the alternator regulator is disabled the APC can fully control the alternator output voltage. Thus, aided by remote sensors the battery charging voltage is optimised over the temperature range -40degC to +55degC.

If the full temperature compensated voltage range is required:

12V/140A (70431/90850)	24V/140A (90851)
12V/250A (90852)	24V/250A (90853)
13.0V +/- 0.1V to 15.8V +/-0.1V	26.0V +/- 0.2V to 31.6V +/- 0.2V

(controlled at the MAIN stud) the orange wire at S3 pin 6 must be connected to chassis (0V).

If the full temperature compensated voltage range requires to be limited:

12V/140A (70431/90850)	24V/140A (90851)
12V/250A (90852)	24V/250A (90853)
to 14.4V +/- 0.1V maximum	to 28.8V +/- 0.2V maximum

(controlled at the MAIN stud) then the orange wire at S3 pin 6 should be left unconnected and insulated.

(APC) Alternator Power Controller (Alternator Regulator Enabled)

Note: This mode of operation should not be applied with regulators that have an internally generated warning lamp output. Please refer to Antares (Europe) Limited for further advice.

In this case, the APC will operate as above, except when its controlled voltage falls **below** that of the alternator regulator. When this happens the alternator regulator will take control of the alternator output voltage. The APC will resume operation only when its controlled voltage rises **above** that of the alternator regulator.

(ASC) Automatic Split Charge Override (70431 only)

If the interlock input (S2 pin 2) is driven low (by an HCMOS output) the split charge will be opened and/or remain open for the duration of this condition. In this way, conducted mode emissions from the main vehicle electrical system (e.g. from the alternator) can be reduced at the auxiliary system. Note that the duty cycle of this feature should be minimised to ensure that the auxiliary battery continues to receive sufficient charge from the alternator.

If the interlock input (S2 pin 2) is driven high (by an HCMOS output) or is open circuit, the ASC operates normally for the duration of this condition.

**Assured Starting (AST) Option
(Not applicable to ASM2 70431/90850/90851)**

ASM2	AST Part No
12V/250A Pt No 90852	90870
24V/250A Pt No 90853	90870

If the main battery does not have enough charge to start the vehicle, depression of the AST momentary action switch causes the AST to operate closing the split charge contractor for a 30-second period. During this time, the auxiliary battery is connected to support the main battery when powering the starter motor.

The 30-second period of operation is initiated each time the AST switch is depressed. Therefore, closure of the split charge contractor cannot be extended beyond this time by holding the switch continuously depressed. Thus the ASC system can continue to operate normally and the contacts of the contractor are protected from excessive periods of starter motor current.

Load Shed (LS) Option

ASM2	Load Shed Option Part No
12V	98071
24V	90872

Selected auxiliary loads may be connected via the LS contactor to the auxiliary battery. When the auxiliary battery voltage remains at less than:

- 11.5V (12V ASM2)
- 23.0V (24V ASM2)

for a 30-sec period the LS contactor will open to disconnect the loads thus reducing the battery discharge rate. The LS contactor will remain open until a charging voltage greater than or equal to:

- 12.9V (12V ASM2)
- 25.8V (24V ASM2)

is detected at the "AUX" stud.

Deep Discharge Protection (DDP) Option

ASM2	Deep Discharge Protection Part No
12V	90873
24V	90874

Selected auxiliary loads may be connected via the DDP contactor. When the auxiliary battery voltage remains at less than:

- 10.5V (ASM2 12V)
- 21.0V (ASM2 24V)

for a 60-sec period the DDP contactor will open to protect the auxiliary battery from further discharge. The DDP contactor will remain open until a charging voltage greater than or equal to:

- 12.9V (ASM2 12V)
- 25.8V (ASM2 24V)

is detected at the "AUX" stud.

System Monitoring, Enclosure Indication (not available on 70431) and Remote Indication Option

SUMMARY

Condition	Enclosure Indicators (not available on 70431)		Remote Display Indicators (optional)		
	Status 1	Status 2	Alternator	System link	Disconnect
Aux. system short circuit or no battery present		flashes	flashes	flashes	
Main system short circuit		flashes	flashes	flashes	
Main battery terminal temperature out of range		flashes	flashes		
Main system over voltage detected		flashes	flashes		
Aux. system high voltage		flashes	flashes		
Internal Split charge contacts damaged	on	flashes	flashes	flashes	
Aux. battery terminal temperature out of range	on	flashes	flashes	flashes	
Load shed will operate in 30 seconds					flash every second
Load shed has operated					flash every ten seconds
Deep discharge protection will operate in 60 seconds					flash five per second
Deep discharge has operated					flash every three seconds
Alternator Power Control Operating		on	on		
Split Charge "system link"	on			on	

System Monitoring, Enclosure Indication (not available on 70431) and Remote Indication Option (Cont.)

ASM2	Part No
12V	90875
24V	90876

1. The ASC will not close when the AUX stud voltage is less than:
 (12V ASM2) 1.0V +/- 0.1V
 (24V ASM2) 2.0V +/- 0.2V.
 This protects the ASC from damage if a short circuit develops in the auxiliary system.

Status Indicator 1 off Status Indicator 2 flashes

Remote Indicators:
 "system link" led flashes "alternator" led flashes

2. The ASC will not close and the AST (90852 and 90853 versions) will not operate when the MAIN stud voltage is greater than:
 (12V ASM2) 16.0V +/- 0.1V
 (24V ASM2) 32.0V +/- 0.2V.
 This protects the auxiliary system from overvoltage conditions.

Status Indicator 1 off Status Indicator 2 flashes

Remote Indicators:
 "system link" led off "alternator" led flashes

3. When the ASC is closed or the AST (90852 and 90853 versions) is operating and the MAIN stud voltage rises above:
 (12V ASM2) 16.0V +/- 0.1V
 (24V ASM2) 32.0V +/- 0.2V
 the split charge will open within 3 seconds. This protects the auxiliary system from overvoltage conditions.

Status Indicator 1 off Status Indicator 2 flashes

Remote Indicators:
 "system link" led off "alternator" led flashes

4. The ASC will not close when the MAIN stud voltage is less than:
 (12V ASM2) 1.0V +/- 0.1V
 (24V ASM2) 2.0V +/- 0.2V.
 This protects the ASC from damage if a short circuit develops in the main system.

Status Indicator 1 off Status Indicator 2 flashes

Remote Indicators:
 "system link" led flashes "alternator" led flashes

5. The ASC will not close and the AST (90852 and 90853 versions) will not operate when the AUX stud voltage is greater than:
 (12V ASM2) 16.0V +/- 0.1V
 (24V ASM2) 32.0V +/- 0.2V.
 This protects the main system from overvoltage conditions.

Status Indicator 1 off Status Indicator 2 flashes

Remote Indicators:
 "system link" led off "alternator" led flashes

6. When the ASC is closed or the AST (90852 and 90853 versions) is operation and the AUX stud voltage rises above:
(12V ASM2) 16.0V +/- 0.1V
(24V ASM2) 32.0V +/- 0.2V
the split charge will open within 3 seconds. This protects the main system from overvoltage conditions.

Status Indicator 1 off

Status Indicator 2 flashes

Remote Indicators:

“system link” led off

“alternator” led flashes

7. When the ASC is closed or the AST (90852 and 90853 versions) is operating and the voltage at the MAIN stud is not within:
(12V ASM2) 0.5V +/- 0.1V
(24V ASM2) 1.0V +/- 0.2V
of the voltage at the AUX stud then a fault is indicated. Thus, damage to the contacts of the split charge switch can be detected.

Status Indicator 1 on

Status Indicator 2 flashes

Remote Indicators:

“system link” led flashes

“alternator” led flashes

8. A fault will be indicated if the following conditions occur at the main battery temperature sensor.

Temperature is greater than	+58 degC +/-3 degC
Temperature is less than	-43 degC +/- 3 degC
Temperature sensor fault	

In addition the APC will control the alternator voltage at the default setting of:
(12V ASM2) 13.0V +/- 0.1V
(24V ASM2) 26.0V +/- 0.2V
measured at the MAIN stud.

Status Indicator 1 off

Status Indicator 2 flashes

Remote Indicators:

“system link” led off

“alternator” led flashes

9. A fault will be indicated if the following conditions occur at the auxiliary battery temperature sensor.

Temperature is greater than	+58 degC +/-3 degC
Temperature is less than	-43 degC +/- 3 degC
Temperature sensor fault	

In addition the APC will control the alternator voltage at the default setting of:
(12V ASM2) 13.0V +/- 0.1V
(24V ASM2) 26.0V +/- 0.2V
measured at the MAIN stud if the split charge contactor is closed.

Status Indicator 1 on

Status Indicator 2 flashes

Remote Indicators:

“system link” led flashes

“alternator” led flashes

10. "disconnect" Led

Duty cycle	Period	Conditions
100ms	1s	Indicates for 30 seconds before LS operates
100ms	10s	Indicates LS has operated and DDP has not operated.
100ms	200ms	Indicates for 60 seconds before DDP operates.
100ms	3s	Indicates LS and DDP have operated.

IMPORTANT SAFETY INFORMATION

Please read and observe the installation instructions.

WARNING Explosive gasses may be generated by a battery on charge. To prevent ignition, allow time for gasses to disperse before attempting to connect this unit.

INSTALLATION

Choosing a location

The system should not be directly exposed to road spray or water jet cleaning. Build up of road debris such as mud will impair cooling, so locations where this may occur should be avoided. Areas subject to high temperature or vibration must also be avoided if performance and reliability are not to be impaired.

Mounting

The system may be mounted in any orientation.

Electrical Connections (Note: refer also to Figs. 1, 2, 3 and 4)

Note: This connection information should not be applied with alternator regulators that have an internally generated warning lamp output. In these cases please refer to Antares (Europe) Limited for alternative advice.

1. REMOVE THE VEHICLE MAIN BATTERY POSITIVE CONNECTION.
2. Remove the regulator/brush assembly from the alternator (this is usually attached to the alternator end plate with screws or bolts).
3. Identify which type of regulator brush system is involved (see page 19), i.e. type N or type P, then follow **type N** instructions (3.1) or **type P** instructions (3.2) as detailed below:

3.1. Type N units:

- 3.1.1. Break the connection between the S- connection of the alternator regulator and chassis (0V).
- 3.1.2. Connect the green wire from S1-1 to the regulator S+ terminal. Note: it may be possible to solder this connection, or it may be necessary to drill a small hole and attach a wire using a small self tapping screw and terminal. Whatever method is used, great care should be taken to obtain a good quality and reliable connection, and avoid damaging the regulator/brush assembly.
- 3.1.3. Connect the brown wire from S1-2 and the yellow wire from S1-3 to the alternator case. Alternatively, these wires may be connected to the vehicle chassis (negative earth only).

3.2. Type P units:

- 3.2.1. Break the connection between the S+ connection of the alternator regulator and D+.

- 3.2.2. Connect the brown wire from S1-2 to the D+ terminal.
- 3.2.3. Connect the yellow wire from S1-3 to the regulator S- terminal. Note: it may be possible to solder this connection, or it may be necessary to drill a small hole and attach a wire using a small self tapping screw and terminal. Whatever method is used, great care should be taken to obtain a good quality and reliable connection, and avoid damaging the regulator/brush assembly.
- 3.2.4. Connect the green wire from S1-1 to the alternator case. Alternatively, this wire may be connected to the vehicle chassis (negative earth only).
4. Refit the regulator/brush assembly to the alternator.
5. Connect wire S2-3 (orange) to the ignition-on position of the vehicle ignition switch.
6. Connect the temperature sensor ring terminal from S1-4 and S1-5 to the negative terminal of the main battery.
7. Connect the temperature sensor ring terminal from S3-4 and S3-5 to the negative terminal of the auxiliary battery.
8. **This section relates only to Pt No 70431 / 90850 / 90851. For Pt Nos. 90852 / 90853 please move on to section 10**
 - 8.1. Connect the "AUX" stud to the auxiliary battery positive terminal, together with the feed to the auxiliary circuits. This connection must be made such that it is able to carry the full alternator output current.
 - 8.2. Connect the "MAIN" stud to the main battery positive terminal together with the connections removed at step 1. This connection must be made such that it is able to carry the full alternator output current.
 - 8.3. Connect the blue cable from S1-6 to chassis (0V). **NB this cable must be less than 1m in length but ideally should be as short as possible.**
9. **This section relates to Pt No 70431 only**
 - 9.1 Connect S2 pin 2 to ASC override output of external equipment.

ELECTRICAL CONNECTIONS COMPLETE FOR 70431, 90850 AND 90851

10. **This section relates only to Pt No 90852 and Pt No 90853**
 - 10.1. Connect the contactor "-" stud to the auxiliary battery positive terminal, together with the feed to the auxiliary circuits. This connection must be made such that it is able to carry the full alternator output current and the starter motor current.
 - 10.2. Connect the contactor "+" stud to the main battery positive terminal together with the connections removed at step 1. This connection must be made such that it is able to carry the full alternator output current and the starter motor current.
 - 10.3. Connect the "AUX" stud to the auxiliary battery positive terminal using cable of 1mm² minimum size.
 - 10.4. Connect the "MAIN" stud to the main battery positive terminal using cable of 1mm² minimum size.
 - 10.5. Connect the red cable from S3-1 to the ASC contactor coil +ve.
 - 10.6. Connect the ASC contactor coil -ve to chassis (0V).

10.7. Connect the blue cable from S1-6 to the chassis (0V). **NB this cable must be less than 1m in length, but ideally as short as possible.**

ASSURED STARTING (AST) OPTION

Part No 90870

1. Connect cable from S2-1 (yellow) to the normally open contact of the momentary action switch.
2. Connect the common contact of the switch to chassis (0V).

REMOTE INDICATION OPTION

ASM2	Remote Indication Option Part No
12V	90875
24V	90876

1. Connect wire S2-4 (brown) to the display socket pin 3.
2. Connect wire S2-5 (red) to the display socket pin 2.
3. Connect wire S2-6 (green) to the display socket pin 1.
4. Connect the display socket pin 4 to chassis (0V).

LS (LOAD SHED) OPTION

ASM2	Load Shed Option Part No
12V	90871
24V	90872

1. Disconnect the selected loads from the auxiliary battery +ve terminal.
2. Connect the LS contactor + stud to the auxiliary battery +ve terminal. This connection must be made such that it is able to carry the full current of the selected loads.
3. Connect the loads disconnected at step 1 to the – stud of the LS contactor.
4. Connect the LS contactor coil +ve to S3-2 (green).
5. Connect the LS contactor coil –ve to chassis (0V).

DDP (DEEP DISCHARGE PROTECTION) OPTION

ASM2	DDP Option Part No
12V	90873
24V	90874

1. Disconnect the selected loads from the auxiliary battery +ve terminal.
2. Connect the DDP contactor + stud to the auxiliary battery +ve terminal. This connection must be made such that it is able to carry the full current of the selected loads.

3. Connect the loads disconnected at step 1 to the – stud of the DDP contactor.
4. Connect the DDP contactor coil +ve to the auxiliary battery positive terminal.
5. Connect the DDP contactor coil –ve to S3-3 (black).

MECHANICAL SPECIFICATIONS

ASM

Footprint 131mm x 171mm, including flanges. Height 35mm. Fixings on 118mm centres, 6mm clearance holes.

ASC Contactor

Footprint 152 mm x 112 mm. Height 82 mm.
Fixings on 2 slots 6.5mm wide.

LS and DDP Contactors

Footprint 97mm x 57 mm. Height 54 mm.
Fixings on 6mm clearance holes.

System Connections for 70431 / 90850 / 90851

Notes

- I. “ * ” These connect optional features and should be connected to chassis (0V) if not in use.
- II. “ ** ” These connect optional features and should be unconnected and insulated if not in use.
- III. **Note: This connection information should not be applied with alternator regulators that have an internally generated warning lamp output. In these cases please refer to Antares (Europe) Limited for alternative advice.**

From	To	cable size	colour
Main battery +ve	MAIN	see Table 1	red
Auxiliary battery +ve	AUX	see Table 1	red
Type N reg. S+	*S1-1	1mm ²	green
Type P reg. D+	*S1-2	1mm ²	brown
Type P regulator S-	*S1-3	1mm ²	yellow
Main batt –ve	M8 ring from S1-4 & S1-5	1mm ²	white/vio
Main batt –ve	S1-6	1mm ²	blue
Interlock	**S2-2	1mm ²	black
Ign sw (on position)	**S2-3	1mm ²	orange
Display conn. Pin 3	**S2-4	1mm ²	brown
Display conn. Pin 2	**S2-5	1mm ²	red
Display conn. Pin 1	**S2-6	1mm ²	green
Display conn. Pin 4	chassis (0V)	1mm ²	black
LS contactor +ve	Aux. batt +ve	see Table 1	red
LS contactor coil +ve	**S3-2	1mm ²	green
LS contactor coil –ve	chassis (0V)	1mm ²	black
DDP contactor +ve	Aux. batt +ve	see Table 1	red
DDP contactor coil +ve	Aux. batt +ve	1mm ²	red
DDP contactor coil –ve	**S3-3	1mm ²	black
Aux. batt –ve term.	M8 ring from S3-4 & S3-5	1mm ²	white/vio
Chassis (0V)	**S3-6	1mm ²	orange

System Connections for 90852 / 90853

Notes

- I. “ * ” These connect optional features and should be connected to chassis (0V) if not in use.
- II. “ ** ” These connect optional features and should be unconnected and insulated if not in use.
- III. **Note: This connection information should not be applied with alternator regulators that have an internally generated warning lamp output. In these cases please refer to Antares (Europe) Limited for alternative advice.**

From	To	cable size	colour
Main battery +ve	MAIN	1mm ²	red
Auxiliary battery +ve	AUX	1mm ²	red
Type N reg. S+	*S1-1	1mm ²	green
Type P reg. D+	*S1-2	1mm ²	brown
Type P regulator S-	*S1-3	1mm ²	yellow
Main batt –ve	M8 ring from S1-4& S1-5	1mm ²	white/vio
Main batt –ve	S1-6	1mm ²	blue
AST switch (n.o.)	**S2-1	1mm ²	yellow
AST switch (com.)	chassis (0V)	1mm ²	black
Interlock	**S2-2	1mm ²	black
Ign sw (on position)	**S2-3	1mm ²	orange
Display conn. Pin 3	**S2-4	1mm ²	brown
Display conn. Pin 2	**S2-5	1mm ²	red
Display conn. Pin 1	**S2-6	1mm ²	green
Display conn. Pin 4	chassis (0V)	1mm ²	black
ASC contactor +ve	Main batt +ve	see Table 1	red
ASC contactor –ve	Aux. batt +ve	see Table 1	red
ASC contactor coil +ve	**S3-1	1mm ²	red
ASC contactor coil –ve	chassis (0V)	1mm ²	black
LS contactor +ve	Aux. batt +ve	see Table 1	red
LS contactor coil +ve	**S3-2	1mm ²	green
LS contactor coil –ve	chassis (0V)	1mm ²	black
DDP contactor +ve	Aux. batt +ve	see Table 1	red
DDP contactor coil +ve	Aux. batt +ve	1mm ²	red
DDP contactor coil –ve	**S3-3	1mm ²	black
Aux. batt –ve term.	M8 ring from S3-4 & S3-5	1mm ²	white/vio
Chassis (0V)	**S3-6	1mm ²	orange

Table 1

(applies only to tri-rated switchgear wire at an ambient temperature of 30 degC)

Cable size (mm2)	Current rating (A)
1	18
2.5	31
4	41
6	53
10	75
16	100
25	136
35	167
50	190
70	240

ELECTRICAL SPECIFICATIONS (TYPICAL)

ASM2 Part No	90850/ 70431	90851	90852	90853
Power draw, active (without options)	5W	5W	13W	13W
Power draw, active (with options)	17W	17W	25W	25W
Power draw, inactive:	160mW	320mW	160mW	320mW

ASC (Automatic Split Charge) Current Capacity

Part No 70431 / 90850 / 90851

Continuous current: 140A (NB. Dependent on cable size, see Tab.1)

Part No 90852 / 90853

Continuous current: 250A (NB. Dependent on cable size, see Tab.1)

AST (Assured Starting) Option Current Capacity

Part No 90852/90853

Starter motor current: 1200A for 30 seconds (NB Dependent on cable size)

LS (Load Shed) Option Current Capacity

Continuous current: 100A (NB. Dependent on cable size, see Tab.1)

DDP (Deep Discharge Protection) Option Current Capacity

Continuous current: 100A (NB. Dependent on cable size, see Tab.1)

ENVIRONMENTAL SPECIFICATIONS

ASM

Protection: IP66
Temp range: -40 deg C to +85 deg C.

ASC Contactor

Protection: dust ingress

LS and DDP Contactors

Protection: IP54

IDENTIFYING ALTERNATOR REGULATOR TYPE (Note: refer also to Fig.2)

Note: This connection information should not be applied with alternator regulators that have an internally generated warning lamp output. In these cases please refer to Antares (Europe) Limited for alternative advice.

The type of regulator can be determined by identifying the connections to the alternator brushes. This can often be determined by simple visual examination of the regulator brush and assembly. Alternatively, a continuity tester can be used.

It is necessary to remove the regulator/brush assembly from the alternator, having first disconnected the vehicle battery. The assembly is usually screwed to the rear face of the alternator.

The logic is as follows:

if one of the brushes is connected to the alternator D+ terminal then the regulator is type **N**, otherwise the unit is type **P**.

Alternatively;

if one of the brushes is connected to the alternator case (negative earth) then the unit is type **P**, otherwise the unit is type **N**.

Either of these two conditions may be examined in order to determine the regulator type. Note also that the connection to D+ is sometimes made via a spring clip, which will break contact when the regulator assembly is removed from the alternator.

IF IN DOUBT, CONSULT A COMPETANT AUTO-ELECTRICIAN. INCORRECT CONNECTION CAN CAUSE DAMAGE.




Fig 1b: Installation - Pt No 90852/90853

13183-62.cdr




Fig 4a: Installation - Pt Nos 70431/90850/90851
13181-6




Fig 4b: Installation - Pt Nos 90852/90583
13183-7.cdr

WARRANTY

The ASM comes with a full parts and labour 'return to base' warranty, held for two years from the date of invoice from Antares (Europe) Limited. In case of any problem, please telephone first in order to confirm that the problem lies with the unit, and obtain a Returns Authorisation Reference. Units will normally be repaired or replaced, and shipped within 5 days of receipt, subject to availability of parts. Full details of the warranty provisions are contained in our 'Terms and Conditions of Sale'.

SERVICE

Service contracts may be taken out to provide cover in case of failure outside of warranty, or to extend the warranty cover available. Please contact Antares (Europe) Limited for details.

© 2004 Antares (Europe) Limited
Chiltern Hill, Chalfont St Peter, Gerrards Cross, Bucks. SL9 9UQ
Tel: 01753 890888 Fax: 01753 891260
E-mail: support@antares.co.uk sales@antares.co.uk info@antares.co.uk
Web: <http://www.antares.co.uk>