



MANUAL

Dual Function
E-Series



MME-060809
SUNSTAR PRECISION CO., LTD.

1. THIS IS AN INSTRUCTION FOR SAFE USE OF **SWF**® DUAL FUNCTION AUTOMATIC EMBROIDERY MACHINES. READ THOROUGHLY BEFORE USE.
2. CONTENTS OF THIS INSTRUCTION ARE SUBJECT TO CHANGE WITHOUT PRIOR NOTICE FOR HIGHER QUALITY OF THE MACHINES. FOR ANY INQUIRIES ON THE MACHINE OR THE INSTRUCTION, CALL YOUR SWF DEALERSHIP.
3. MAKE SURE TO PASS THIS INSTRUCTION TO YOUR NEXT WORKER.
4. FOR INFORMATION RELATED TO ELECTRICITY AND ELECTRONIC PARTS (X-Y DRIVE, CONTROL BOX, OPERATION BOX), PLEASE REFER TO “SWF DUAL FUNCTION ELECTRICITY MANUAL.”
5. THIS IS DESIGNED AND MANUFACTURED AS AN INDUSTRIAL MACHINE. IT SHOULD NOT BE USED FOR OTHER THAN INDUSTRIAL PURPOSE.

TABLE OF CONTENTS

<u>CHAPTER 1</u>	SAFETY RULES	1-1
	1-1. MACHINE DELIVERY	1-1
	1-2. MACHINE INSTALLATION	1-2
	1-3. MACHINE OPERATION	1-3
	1-4. REPAIR	1-3
	1-5. PLACEMENT OF WARNING STICKERS	1-4
	1-6. CONTENTS OF WARNING STICKERS	1-5
<u>CHAPTER 2</u>	MACHINE INSTALLATION AND ASSEMBLY	2-1
	2-1. INSTALLATION ENVIRONMENT	2-1
	2-2. ELECTRICITY INSTALLATION	2-1
	2-3. LEVELING THE MACHINE	2-2
	2-4. PERIPHERALS ASSEMBLY	2-4
	2-5. TABLE ASSEMBLY	2-5
	2-6. FRAME ASSEMBLY (UH1506D-45)	2-7
	2-6-1. TUBULAR FRAME	2-7
	2-6-2. BORDER FRAME	2-8
	2-7. FRAME ASSEMBLY (UH1504D-45, UH1208D-45, UH1512D-45)	2-9
	2-7-1. TUBULAR FRAME	2-9
	2-7-2. BORDER FRAME	2-10
<u>CHAPTER 3</u>	NAMES OF MACHINE PARTS	3-1
	3-1. SWF/E-UH1506D-45	3-1
<u>CHAPTER 4</u>	FUNCTIONS FOR BASIC MACHINE OPERATION	4-1
	4-1. LAMP ON THREAD TENSION ADJUSTMENT BOARD	4-1
	4-2. NEEDLE STOP CLUTCH	4-2
	4-3. UPPER THREADING AND TENSION ADJUSTMENT	4-3
	4-4. LOWER (BOBBIN) THREADING AND TENSION ADJUSTMENT	4-7
	4-5. BOBBIN WINDER	4-8
	4-6. PRECAUTIONS IN USING FLOPPY DISKS OR USB MEMORY STICKS	4-11
	4-7. INSERTING FLOPPY DISKS AND USB MEMORY STICKS	4-11
	4-8. DELETING FLOPPY DISKS AND USB MEMORY STICK	4-11
	4-9. READING AND WRITING OF EMBROIDERY DESIGNS	4-11
	4-10. NEEDLE-HOOK TIMING CONTROL	4-12
	4-11. ASSEMBLY AND FUNCTIONS OF THREAD DETECTOR	4-17
<u>CHAPTER 5</u>	MAINTENANCE AND INSPECTION	5-1
	5-1. CHECK POINTS FOR REGULAR INSPECTION	5-1
	5-2. CLEANING	5-1
	5-3. OIL SUPPLY	5-3
	5-4. DRIVE BELT TENSION	5-7

<u>CHAPTER 6</u>	MAJOR MACHINE ADJUSTMENTS	6-1
	6-1. ADJUSTING THE TRIMMERS	6-1
	6-1-1. ADJUSTING THE POSITION OF THE TRIMMING CAM (INSERT ANGLE OF MOVABLE BLADE)	6-1
	6-1-2. ADJUSTING BLADE TENSION	6-2
	6-1-3. ADJUSTING THE TRIMMER RETURN SPRING	6-2
	6-2. ADJUSTING UPPER THREAD HOLDING UNIT	6-3
	6-3. PICKER ADJUSTMENT	6-4
	6-4. ADJUSTING UPPER THREAD HOLDER	6-5
	6-5. ADJUSTING LOW-NOISE PRESSER FOOT	6-6
	6-6. RELATIONSHIP BETWEEN PRESSER FOOT AND NEEDLE	6-7
	6-7. CORRECT POSITION OF NEEDLE	6-8
	6-8. ADJUSTING HALF-TURN FILM FOR COLOR CHANGE	6-9
	6-9. ENCODER ADJUSTMENT	6-9
	6-10. JUMP MOTOR ADJUSTMENT	6-10
	6-11. ADJUSTING DRIVER BELT TENSION	6-11
	6-11-1. SPECIFICATIONS OF DRIVER BELT TENSION ADJUSTERS	6-11
	6-11-2. Y-AXIS TIMING BELT	6-11
	6-11-3. X-AXIS TIMING BELT	6-12
	6-11-4. TIMING BELT ON MAIN SHAFT MOTOR	6-13
	6-12. LAMP (OPTIONAL)	6-13
	6-12-1. ADJUSTING LAMP SOCKET	6-13
<u>CHAPTER 7</u>	TROUBLE SHOOTING	7-1
<u>CHAPTER 8</u>	BLOCK DIAGRAM	8-1

1

SAFETY RULES


The following set of safety rules categorized as **DANGER**, **WARNING**, and **CAUTION** indicates possibilities of physical or property damages if not fully observed.

DANGER : These safety instructions **MUST** be observed to be safe from danger when installing, delivering, or repairing the machine.

WARNING : These safety instructions **MUST** be observed to be safe from machine injuries.

CAUTION : These safety instructions **MUST** be observed to prevent predictable machine errors.

1-1) MACHINE DELIVERY




※ Make sure all persons and obstacles are out of the way of the moving equipment.

ONLY TRAINED AND EXPERIENCED PERSONS, FAMILIAR WITH THE RELEVANT SAFETY INSTRUCTIONS, SHOULD HANDLE THE MACHINE. MAKE SURE TO FULLY OBSERVE THE FOLLOWING INSTRUCTIONS.

1) Using a crane


Make sure that the crane is large enough to hold the machine. Use a nylon rope of sufficient strength. Place a wooden block at either side of the machine before tying the rope. The angle should be 40° or less. Make sure that the rope does not touch the table.



[Fig.1-1]

2) Using a Forklift


Make sure that size and weight of the forklift is sufficient to support the machine. Use the pallet to place the machine so that its center is on the forklift arm (see [Fig.1-2]). Lift the machine carefully so that the machine does not tilt to either side.



[Fig.1-2]

[WARNING]

Make sure to maintain the weight balance in machine deliveries, especially when unloading the machine from a forklift or crane, in order to prevent injury or machine damages.



1-2) MACHINE INSTALLATION





Installation environment may incur machine malfunction or breakdown. Make sure to meet the following conditions.

- 1) The foundation under the machine, i.e. table or desk, must be strong enough to support the weight of the machine (approximately 1 ton).
- 2) Air conditioning can eliminate dust and humidity that can cause pollution and corrosion of the machine. Make sure your machine is regularly cleaned.
- 3) Long exposure to direct sunlight can cause the paint of the machine to fade or change of the machine shape.
- 4) Allow at least 50cm (20 inches) of space on each side of the machine for convenient maintenance.

※ Please refer to **2. Machine Installation and Assembly** for installation details.

1-3) MACHINE OPERATION



The SWF Automatic Embroidery Machine is designed for applying embroidery to fabric and other similar materials.

Pay careful attention to the **WARNING** and **CAUTION** stickers on certain parts of the machine. Make sure to observe the following when operating the machine:

- 1) Read thoroughly and fully understand the manual before operating the machine.
- 2) Dress for safety. Long and unbound hair, jewelry such as necklaces, bracelets, and wide sleeves can get caught in the machine. Wear shoes with non-slip soles.
- 3) Clear all persons from the machine before turning on the power.
- 4) Keep your hands or head away from the moving parts of the machine such as needle, hook, take-up lever, and pulley when the machine is in operation.
- 5) Do not remove the safety cover on the pulley or shaft when the machine is in operation.
- 6) Be sure the main power is turned off and the power switch is set to OFF before opening the cover of any electrical component or control box.
- 7) Be sure the main switch is OFF before manually turning the main shaft.
- 8) Turn the machine off when threading needles or inspecting the finished embroidery.
- 9) Do not lean against the cradle or place your fingers near the guide grooves of the frame.
- 10) The machine noise may exceed 85db when it is run at a maximum speed. It is not higher than the standard level, but you may need earplugs or sound-proof facilities for the operator and other workers.

1-4) REPAIR



Only SWF-trained and selected repair engineers should do repair work.




- 1) Turn OFF the power before cleaning or repairing the machine. Wait for 4 minutes so the machine electricity is completely discharged.

[CAUTION]

It takes about 10 minutes after turning off the main switch before the electricity is fully discharged from X/Y main shafts and the drive box.


- 2) Do not change the settings or any parts on the machine without confirmation from SWF. Such change may cause safety accidents.
- 3) Use only SWF parts when repairing your machine.
- 4) Replace all safety covers when you are finished with your repair.

1-5) Placement of Warning Stickers




Observe the directions on ALL warning stickers placed on the machine as reminders for your safety.

1) Location of Warning Stickers



[Fig.1-3 Front]





[Fig.1-4 From Top]

1-6) Contents of Warning Stickers

1) Warning



Ⓐ

 WARNING	
	<p>Injury may be caused by winding.</p> <p>Be sure to turn off the power before cleaning, lubricating, adjusting or repairing.</p>



[CAUTION]

Safety cover refers to all covers near the operating parts of the machine.

Ⓑ

 WARNING	
	<p>Injury may be caused by moving needle.</p> <p>Ensure that the machine is in a stop condition before changing, threading or rethreading of needles or changing of needles.</p>

Ⓒ

 WARNING	
	<p>Fire or death may be caused by high voltage electric shock.</p> <p>Don't open the cover except for service man assigned by SWF.</p> <p>When open the cover turn off power and wait for 6 minutes.</p>

MACHINE INSTALLATION AND ASSEMBLY

Install your machine in an appropriate environment and with adequate electrical supply. Failure to follow the directions may result in machine malfunction.

2-1) INSTALLATION ENVIRONMENT

- 1) Temperature: ① 0~40°C (32~104°F) when the machine is in operation
② -25~55°C (-13~131°F) when the machine is not in operation
- 2) Humidity: 45~90% (relative)

[CAUTION]

- ① Do not let moisture drops on the machine.
- ② Provide air conditioning to control humidity and to prevent dust and corrosion.

- 3) Grounding: Ensure the electricity is properly grounded.



Properly ground the machine to avoid the possibility of electric shock. Use three-wire grounding (grounding resistance below 100 ohms).

- 4) Close any doors and windows near the machine to prevent direct light, dust, and humidity.
- 5) Foundation under the machine must be a sufficiently strong and flat concrete to support the weight of the machine.

2-2) ELECTRICITY INSTALLATION

Check if the input voltage of the machine is in the right range of the voltage supply before installing or operating the machine. The voltage required is as follows:

- 1) Input voltage (to be adjusted when installing): 110V, 220V
- 2) Allowed range of voltage: within 10% of the voltage set
- 3) Electric capacity and voltage consumption: 600VA 400W
- 4) Insulation resistance: over 10M ohms (measured with 500V insulation tester)




- ① Check the voltage supply where the machine will be installed.
- ② Install the cable away from the operator's work space to prevent accident or injury.

2-3) LEVELING THE MACHINE


The machine must be accurately leveled (especially front and back) to prevent the needle from moving out of position.

- 1) Use the adjusting bolts installed at the four stands to level the machine (front, rear, left, and right). Use a level gauge.
 - ① Check the voltage supply where the machine will be installed.
 - ② Install the cable away from the operator's work space to prevent accident or injury.
 - ③ If the difference in heights of the four bolts is over 10mm, place spacers beneath the lower supporting bolts to make the heights even.



[Fig.2-1]


- 2) The machine must be horizontally balanced on all four sides - front, rear, right, and left.



[Fig.2-2]

- 3) Using the level gauge

Use a nut to fully fasten the adjusting bolts when the machine is leveled.




[Fig.2-3]

[CAUTION]

The level gauge does not measure accurately on a square pipe or a table.

4) Using the body supporter [UH1506D-45]

Adjust the supporting bolt of the body supporter at the center of the machine after you are finished with leveling. When adjusting the bolt, turn it until the bolt touches the level base and turn an additional quarter round. Fasten the bolt with a nut.




[Fig.2-4]

[CAUTION]

The supporter reduces the machine vibration.
Make sure not to adjust the bolt too high - it may lift the machine.

5) Using the auxiliary balance supporting bolt [UH1508-45, UH1512D-45]

Adjust the supporting bolt at the center of the machine after the balancing of the machine is finished. When adjusting the supporting bolt, turn the bolt until it touches the level base and turn an additional quarter round. Fasten the supporting bolt with a nut.




[Fig.2-5]

[CAUTION]

The use of a supporting bolt for the auxiliary body supporter reduces the machine vibration and maintains the balance of the machine.
Make sure not to adjust the bolt too high. It may lift the machine.

2-4) PERIPHERALS ASSEMBLY


1) Assembling Upper Thread Stand



[Fig.2-6]


2-5) TABLE ASSEMBLY

1) Unscrew the eight clamps underneath the table and the bolts to disassemble the table.




[Fig.2-8]

2) Adjust the table support at an appropriate height and fasten the bolts.



[Fig.2-9]


3) Insert the table and fasten the bolts and the clamps.



[Fig.2-10]

[CAUTION]

The table should not be higher than the upper side of the needle plate by 0.5mm for board frame work. If the height difference is over 0.5mm, unfasten the table support bolts, adjust the height, and fasten the bolts back.




[Fig.2-11]

2-6) FRAME ASSEMBLY (UH1506D-45)

2-6-1) Tubular Frame

- 1) Adjust the table height appropriate for tubular frame work (see 2-5 Table Assembly).
- 2) Unfasten the fixing bolt of the tubular frame. Align it on the fixing position on the X frame, insert the frame fixing bolt, and fix.




[Fig.2-12]

[CAUTION 1]

When inserting the frame onto the arm of the tubular frame, adjust the space between the two. To adjust, use the screw on the tubular frame arm.


- 3) In case using the tubular round frame



[Fig.2-13]


2-6-2) Border Frame

- 1) Unfasten screws on the tubular frame and remove the frame from the X frame.



[Fig.2-14]

- 2) Adjust the table height appropriate for border frame work.
(See 2.5 Table Assembly)
- 3) Unfasten screws on the border frame and align the border frame in the fixing position on the X frame.
- 4) Fix the border frame onto the X frame with a fixing bolt.




[Fig.2-15]

2-7) FRAME ASSEMBLY (UH1504D-45, UH1208D-45, UH1512D-45)

2-7-1) Tubular Frame

- 1) Unfasten screws on the tubular frame 2/3, install the tubular frame in the groove of the frame connection plate, and fasten the bolt.

[CAUTION] Do not install the tubular frame too close from the X frame. Keep the space at around 2mm.




[Fig.2-16]

- 2) Insert the frame into the tubular frame. Use the screws to adjust the space.


2-7-2) Border Frame

- 1) Unfasten screws on the tubular frame 2/3 and remove the frame.



[Fig.2-17]


- 2) Adjust the table height at an appropriate level for border frame work. (See 2.5) TABLE ASSEMBLY)
- 3) Unfasten screws on the border frame 2/3 and install the border frame in the groove of the X frame connection plate. Fasten the bolt.



[Fig.2-18]

NAMES OF MACHINE PARTS

3-1) SWF/E-UH1506D-45



[Fig.3-1]

- | | |
|-----------------------------------|--------------------------|
| ① Machine Body | ⑭ Y-axis driving system |
| ② Table | ⑮ Emergency stop |
| ③ Upper thread stand | ⑯ S/B button |
| ④ Main shaft drive motor | ⑰ Tubular frame |
| ⑤ Rotary hook base | ⑱ Border frame |
| ⑥ Trimming cam box | ⑲ Controller box |
| ⑦ Arm | ⑳ Operation box |
| ⑧ Color Change | ㉑ Encoder |
| ⑨ Upper thread holder | ㉒ Main power switch |
| ⑩ Head | ㉓ Leveling base |
| ⑪ Thread tension adjustment board | ㉔ Thread detector |
| ⑫ Sub-controller | ㉕ Emergency power switch |
| ⑬ X-axis driving system | |

FUNCTIONS FOR BASIC MACHINE OPERATION

4-1) LAMP ON THREAD TENSION ADJUSTMENT BOARD

1) Switch

- ① For normal operation, turn the toggle switch on to turn on the indicator lamp.
- ② If the machine stopped after detecting a thread break, move the frame back to the location of the thread break using STOP button and restart the machine to pick up stitching (design edit).

[NOTE]

If you want to move the frame back for any reason when a thread break has not occurred, press the toggle twice (OFF and ON again).


- ③ To set the needle bar so a specific head does not work, turn the toggle switch off.

[NOTE]

The upper thread holding device fixes the threads of the heads, whose toggle switches are turned off or the heads, which are not working now, thus preventing any unthreading.

2) Thread Break Detector Lamp

Lamp on a specific head will blink when thread break is detected at the head, while lamps on other heads will be turned off. You cannot turn the lamp ON or OFF on the other heads using the toggle switch.



[Fig.4-1]

[CAUTION]


Foreign substances around the thread detector roller may block smooth rotation of the roller and cause wrong detection of thread break.

3) Deletion of Thread-Break Detection Function

Poor function of the thread detecting roller due to foreign substances around it may result in wrong and frequent detections, causing inefficiency of work. In this case, you can turn off the detecting function by turning off the toggle switch at the end of the thread tension adjustment board. This will turn off the detecting function on the head you are working with. It can not detect thread break, however thread break occurs to the head you are working with.

4-2) NEEDLE STOP CLUTCH

As illustrated in [Fig.4-2], the needle bar will not move when you pull the jump clutch lever. Push the level to the opposite direction of the operator to do move needle bar up and down.




[Fig.4-2]





- ① The trimmer and the take-up lever continue to move even when the needle bar is stopped by the clutch. Avoid any operations, i.e. threading the needle or changing thread.
- ② Long-time operation of the needle bar with the clutch may damage the bar controller.

4-3) UPPER THREADING AND TENSION ADJUSTMENT



1) Upper Threading



[Fig.4-3]

Threading the sub tension adjuster	Threading the thread detector roller
 <p>Thread guide disk (crosses the center of the axis)</p>	 <p>Thread detector roller</p> <p>1-round rotation</p>
Thread between the thread guide plates and through the hole on the axis of the thread adjustment device.	Wrap the thread around the detector roller one time.

[Fig.4-4]

Threading the main tension adjuster	Threading around the needle
 <p>Rotary tension disk</p> <p>1.5-round rotation</p>	 <p>Upper thread holder plate</p>
Wrap the thread 1.5 times around the rotary tension disk (V-shaped groove.)	Thread between the upper thread holder plate. Thread the thread guide of the needle and the needle. Fix between the holder plate of the upper thread holding unit.


[Fig.4-5]

2) Upper Thread Tension Adjustment

[CAUTION]

Thread tension adjustment is critical for producing high quality of the embroidery. A balance of 2/3 upper thread and 1/3 lower thread generally indicates good tension. If the tension is too loose, the upper thread will loop, causing thread tangles or breaks. If the tension is too tight, puckering may occur as well as thread and needle breaks.

- ① The upper thread tension is controlled by the sub and main thread tension adjusters. Turn clockwise to increase the tension and counterclockwise to decrease the tension.
- ② The sub-tension adjusters should control about 2/3 of the thread tension while the main adjuster should handle the other 1/3. Set the sub-tension adjuster so the upper thread flows smoothly through the rotary tension disks and into the rollers of the main tension adjuster.



[Fig.4-6]

[CAUTION]

- ① If tension at the sub adjuster is too loose, the detector roller may not rotate well and make wrong detections.
- ② After adjusting the tension, check if the upper thread tension is what can be pulled with little force of around 100-120g.


[CAUTION]

- ① After adjusting the tension, pull the upper thread to see if the detector roller rotates well.
- ② Adjust the tension according to the type of thread and fabric used.

[CAUTION]

As the upper thread is always fixed by the upper thread holding device, when adjusting the thread tension, make sure to pull the upper thread holder plate toward yourself for feeding of the thread. (Threading around the needle)

3) Take-Up Spring



[Fig.4-7]

① Take-up Spring Functions


Difference in the length of the upper thread pulled by the take-up lever and pulled by the hook creates tension or looping. When the tension is too weak, the take-up spring handles the leftover length of the upper thread. Increase the tension or the stroke of the spring to form tight stitches on the embroidery.

② Take-up Spring Adjustment

① Tension of the take-up spring affects the thread tension. You can increase the spring tension by turning the thread adjusting stud clockwise as shown in the figure. You can decrease the tension by turning the stud counterclockwise.

② To adjust the stroke of the take-up spring:

To adjust the stroke of the spring during embroidery work, move the take-up spring stopper to right or left as shown in [Fig.4-8].



[Fig.4-8]


4-4) LOWER (BOBBIN) THREADING AND TENSION ADJUSTMENT

1) Lower Threading

① Use cotton yarn (#80-#120) for your lower thread.

② Threading the bobbin:

- Insert the threaded bobbin into the bobbin case with the thread coming out from the case slot. Pull the thread through the thread guide. Check if the bobbin is rotating ([Fig.4-9]).
- Thread the lower thread holder and trim the thread to 3-4cm before inserting the bobbin and the case into the hook assembly. Long tail can cause the thread to tangle during stitching.



[Fig.4-9]

[CAUTION]

Direction of the Bobbin Rotation


Make sure that the bobbin rotates clockwise when you pull the thread holding the bobbin case in your left hand, as shown in [Fig.4-9].

2) Lower Thread Tension Adjustment

Adjust the tension of the lower thread using the nut on the tension spring on the bobbin case. Turn the nut clockwise to increase the tension and counterclockwise to decrease the tension.

[CAUTION]


For adequate bobbin thread tension, hold a thread from the bobbin and jiggle the bobbin case lightly up and down as shown in [Fig.4-10]. The case should drop and the tension should be 25-35g.



[Fig.4-10]

4-5) BOBBIN WINDER

1) Major Parts and Functions



[Fig.4-11]


- ① POWER SW: main power switch
- ② TIME: adjusts the volume of thread on the bobbin (MIN ↔ MAX)
- ③ STOP: stop button
- ④ START: start button
- ⑤ BOBBIN WINDER AXIS: holds the bobbin
- ⑥ AC CABLE: cable for power supply
- ⑦ MOTOR
- ⑧ CIRCUIT BOARD
- ⑨ BASE
- ⑩ TRANSISTOR
- ⑪ FUSE BOX: for changing fuse
- ⑫ VOLTAGE SWITCH: selects voltage supply (AC 110V ↔ AC 220V)
- ⑬ CERAMIC ISLET: hole for thread
- ⑭ TENSION ADJUSTER NUT HOLDER
- ⑮ NUT: fixes thread holder stand
- ⑯ BOBBIN PLATE:
 - ※ includes bobbin plate, plate nut, sponge, bobbin holder, bobbin shaft
- ⑰ TENSION ADJUSTER: adjusts thread tension on the bobbin
- ⑱ THREAD HOLDER STAND
- ⑲ THREAD HOLDER: prevents tangles in thread from the bobbin
- Ⓐ Bobbin Stand: unravels thread remains on the used-up bobbin
- Ⓑ Manual Lever: manually turns the bobbin

2) Bobbin Winding

- ① Insert the bobbin onto the shaft and manually wind the thread 5-6 times around the bobbin in the desired direction. Press [START] to rotate the bobbin.
- ② Bobbin should stop winding according to the embedded timer. If you want to stop winding before the bobbin automatically stops, press [STOP].

3) Adjusting Thread Volume on Bobbin

- ① Fill the bobbin 80% and make sure the thread is parallel to the bobbin as shown in [Fig.4-12].
- ② You can adjust the volume of the thread on the bobbin using a timer dial. Set it at MAX to increase the volume.




[Fig.4-12]

[CAUTION]

- Overfilling the bobbin may interfere with the smooth pull of the thread.
- For normal bobbin, 80% fill will render around 80m of thread.

4) Adjusting the Bobbin Wind


- ① Make sure to wind the thread parallel to the bobbin.
If not, unfasten the screw on the thread guide body and adjust it left or right (see [Fig.4-13]).
- ② Adjust the thread tension on the bobbin using a tension adjuster nut.



[Fig.4-13]

[CAUTION 1]

Winding the bobbin off-center or uneven as shown below can cause thread breaks, skipped stitches, or thread tangles. [Fig.4-14]



[Fig.4-14]

[CAUTION 2]

Too tight tension of the bobbin thread may block smooth pulling of the thread and cause thread breaks or short tails.

5) Product Information

MODEL NAME	SPEED	POWER	SPECIFICATION	PACKAGE SIZE (TOTAL WEIGHT)
BW-02 (Bobbin Winder)	3,200rpm	AC 110/220V 50/60Hz 10W	420 × 155 × 125 3.9kg	450 × 190 × 170 4.5kg

6) Precautions

- ① Make sure to check the power/voltage supply before use (voltage is set at 220V but 110V can also be used. To use 110V, adjust the voltage switch underneath the machine).

7) Emergency Measures

- ① If the winder does not start, check and replace the fuse or switch.
- ② If the bobbin shaft does not stop, replace “TR1” on the TIME switch or the circuit board.
- ③ If the winder does not start or stop, replace the start/stop switch or IC.
- ④ Wrong voltage may cause the machine to stop with a “thud” sound. Replace “Q1” on the circuit board.

4-6) Precautions in using floppy disks or USB memory sticks

Make sure to meet the following conditions when using the above devices.



CAUTION

- 1) You can use pre-formatted disks, but be sure to use disks of recognized quality.
- 2) You can use USB memory sticks of FAT 16 (file system). The machine does not accommodate FAT 32.

► When using floppy disks


- Keep the disks away from objects with magnetic fields, i.e. televisions, radios.
- Protect the disks from excess heat, humidity, and direct sunlight.
- Do not place heavy objects on the disks.
- Do not remove the disk from the drive while formatting, reading, or writing the disk.
- Do not open the cover of the disk drive.
- Data cannot be written onto the write-protected disks.
- Repetitious reading and writing on a single disk may cause errors.
- Save your important data on more than one disk for back up.

► When using USB memory sticks

- Do not delete USB memory from the USB port when reading and writing with USB.

4-7) Inserting floppy disks and USB memory sticks

- Inserting floppy disks
Insert the disk in the indicated direction.
- Inserting USB memory sticks
Insert the USB memory into the USB port.



[Fig.4-15]

4-8) Deleting floppy disks and USB memory stick

- To take out the disk from the floppy drive, press the OUT button.
- For USB, close the input/output window and delete the USB memory.



CAUTION

Be careful not to remove the floppy disk from the drive when formatting, reading, or writing in order to prevent loss of data.

4-9) Reading and writing of embroidery designs

- You can use external devices, such as floppy disks, USB memory, CF cards, and serial port to read designs into the operation box. For writing the designs onto floppy disks and USB memory sticks are available.

4-10) NEEDLE-HOOK TIMING CONTROL

1) Needle

- ① It is very important to select the right needle for the type of thread and fabric used.
- ② Inappropriate needle may cause bad embroidery, thread breaks, skipped stitches, etc.
- ③ For normal embroidery, use a DB × K5 needle.

[CAUTION]

DB × K5 needle has an eye twice larger than that of DB1 (used for normal sewing). Use DB × K5 for normal embroidery.

2) Relationship between Needle and Thread

- ① Inadequate selection of thread and needle may result in thread breaks, skipped stitches, as well as in bad-quality embroidery.
- ② Refer to the following table of threads and needles used for normal embroidery.

Needle Size			Thread Size			
US	Japan	Germany	Cotton #	Silk	Nylon	Rayon
0.25	9	65	70~80	100~120	130~150	70~100
0.27	10	70				
0.29	11	75	50~60	80~100	100~130	100~130
0.32	12	80				
0.34	13	85	50~60	60~70	80~100	130~150
0.36	14	90				

[CAUTION]

Needle and thread most commonly used in embroidery are DB X K5 #11 and rayon yarn 120d/2.



3) Changing the Needle

- ① Make sure the needle is completely clear of the needle plate before attempting to change it. If the needle is not clear of the plate, manually turn the main shaft with a hand lever to put the needle in the right location for change.




CAUTION

STOP the machine before turning the shaft manually. Immediately remove the lever afterward: it is dangerous to operate the machine with the lever inserted.



[Fig.4-16]


- ② When inserting the needle, make sure that the groove of the needle is facing front. Shaft of the needle should be inserted completely into the needle bar.



[Fig.4-17]

[CAUTION 1]

For special threads such as artificial silk, turn the needle slightly to the right to prevent thread breaks (see [Fig.4-18]).



[Fig.4-18]


[CAUTION 2]

If the needle is not inserted all the way to the top of the needle bar hole, timing of the machine will go off, causing broken needles and thread breaks.

4) Needle and Hook

① Adjusting Timing between Needle and Hook

Default timing of the needle and the hook is set by the main shaft angle of 200° and varies as below.




[Fig.4-19]

a. At lower dead stop of the needle bar	2.3~3.7 mm	The figures may change according to needle specification/number.
b. At needle-hook timing	1.8~2.2 mm	
c. At needle-hook timing	0.5~1.5 mm	


[CAUTION]

The hook can move right and left if there is an allowance in the lower shaft gear. Eliminate the allowance (gap) by turning the hook clockwise. Then adjust the timing.



[Fig.4-20]


② Adjusting Gap between Needle and Hook Point



[Fig.4-21]

- Gap between the hook point and the scarf of the needle should be 0.1-0.3 mm minimum.
- Thread skip occurs due to thread looping or inadequate balance/gap between the needle and the hook. The closer the hook point is to the needle, the hook point will be inside the loop and threading will be more stable.

[CAUTION] Functions by Needle Shape




[Fig.4-22]

① Size of the hole and groove differs by needle.

- Front groove: protects the thread from the heat of the sewing friction (which may cause thread breaks).
- Back groove: helps regulate the hook timing and prevents looping.

Prevention of looping is important for stitching. Adjust the hook point as close to the needle as possible to achieve the perfect thread position.


② If thread breaks or stitches are unstable, turn the needle slightly to the right.



[Fig.4-23]

[NOTE]



Shape of the loop varies by the type of thread or fabric. Unstable shape of the loop may result in skipped stitches. The following pictures show different shapes of loop formed by different types of thread.




[Fig.4-24]

5) Relationship between the Take-up Lever and the Hook

Hook point timing is directly related to thread tension and thread breaks. The following pictures show the location of hook when the take-up lever starts to move up from the lower dead stop (main shaft rotation angle: 292°).

<p style="text-align: center;">Fast Hook Timing</p>  <p style="text-align: right;">[Fig.4-25]</p>	<p>Groove of the hook is in the (A) range.</p> <p>The hook point will take up the thread when the loop is too small. Stitching will be faster than the take-up movement. As a result, the thread tension will be too loose, upper thread loop will be too small, and skipped stitches will occur.</p>
<p style="text-align: center;">Slow Hook Timing</p>  <p style="text-align: right;">[Fig.4-26]</p>	<p>Groove of the hook is in the (B) range.</p> <p>The hook point will take up the thread when the loop is too large, so there may not be skipped stitches. However, the take-up movement will be faster than the stitching and thread breaks may occur.</p>

[CAUTION] In normal hook timing, the hook should be in the (C) range in the picture below.



[Fig.4-27]


4-11) ASSEMBLY AND FUNCTIONS OF THREAD DETECTOR

1) FUNCTIONS OF THREAD DETECTOR

Detection of the breaks of upper or lower threads prevents ill quality embroidery. The thread- break detector unit contains rollers that sense the smooth feeding of the thread. Any dust, thread remnants, etc. will interfere the rollers' rotation and may cause wrong detection.

2) DISASSEMBLING THREAD DETECTOR

You will need to disassemble the thread-break detector unit to clean. Remove the cover of the thread tension adjusting plate, separate the cables and unfasten the roller base joint screw. The entire unit will be disassembled including the rollers and bush bearing.



[Fig.4-28]

[CAUTION]

Make sure to correctly place the thread detecting roller to have the unit properly function. Check between the sensor groove and the film. If needed, unfasten the board base screw to adjust the board.

MAINTENANCE AND INSPECTION

5-1) CHECK POINTS FOR REGULAR INSPECTION



CAUTION

Safety rules must be observed during the inspection.

- 1) Clean, oil, and grease the set parts of the machine on a regular basis.
- 2) Inspect tension of each driver belt.
- 3) Failure to perform regular inspections may cause the following:
 - Corrosion of P/C circuit board
 - Damage to the semi-conductor on P/C circuit board
 - Malfunction of the floppy disk drive
 - Ill connection of the connector
 - Abnormal wear-out of machine parts due to insufficient oiling and greasing

5-2) CLEANING



CAUTION


SWF is not responsible for machine damages or malfunctions caused by insufficient cleaning or oiling.



CAUTION



Turn OFF the main power before inspecting or cleaning of the following parts.

NO	Important Parts for Cleaning	Cleaning cycle	Reference Fig.
1	Around the hook	Every day	①
2	Guide rail to the take-up lever	Once a week	②
3	Around the movable blade and the fixed blade <div style="border: 1px dashed black; padding: 10px;"> <p>(NOTE) How to Clean</p> <ul style="list-style-type: none"> <input type="checkbox"/> Remove the needle plate and pull the movable blade forward (see picture). <input type="checkbox"/> Use the SWF brush to remove dirt and dust. </div>	Once in 3-7 days	③



[Fig.5-1]

5-3) OIL SUPPLY

 CAUTION	<p>Make sure to turn the power OFF during oil supply.</p>
 CAUTION	<p>SWF is not responsible for machine damages or wear-outs caused by insufficient oiling.</p>

1) Oil supply


Use the SWF sewing machine oil (Spindle Oil) or ISO-standard VG18.

2) Manual oil supply

No.	Where to Oil	Oiling cycle	Ref. Fig.
1	Take the bobbin case out of the hook. Feed small amount of oil on the raceway.	3-4 times a day <div data-bbox="951 779 1326 864" style="border: 1px dashed black; padding: 2px;">Note 1) Over twice a day for the first month</div>	①
2	Needle bar and needle bar shaft	Once a week	②
3	Inside the arm	Once a week	③, ④
4	Guide rail to the take-up lever	Once a week	⑤
5	3 oil holes on the bed cover	Once in 3 days	⑥
6	Juncture of the movable blade and the fixed blade in the trimming unit	Once in 2-3 weeks	⑦

[CAUTION]

- ① Excess oil may stain the thread and the fabric.
- ② Run the machine without stitching for 2-3 minutes after oiling.
- ③ Excessive oiling in the hook may cause trimming problems and thread breaks.




[Fig.5-2]

3) Oiling

① Cored drip-feed lubrication [Standard Type]

② Location and Cycle of Oiling

No.	Where to oil	Oiling cycle
1	Inside arm a. driver pin of take-up lever b. driver pin of presser foot c. driver shaft of needle bar	Once in 2 days



[Fig.5-3]

[CAUTION]

- 1) Use the SWF sewing machine oil (Spindle Oil) or ISO-standard VG18.
- 2) Oil just enough to damp the tape in the oil tank.

② Grease supply



CAUTION


Make sure to turn OFF the main power during the grease supply.

Use high-quality mineral-based lithium grease.

NO	Where to Grease	Greasing cycle	Reference Fig.
1	Inside the arm	Once in 3 months	①
	Take-up lever drive cam		②
	Needle bar drive cam		③
	Needle bar controller		③
2	Color change cam	Once in 3 months	④
3	Hook gear and lower gear in the rotary hook base	Once in 3 months	⑤
			⑥
4	Gears in the blade cam and trimming cam box	Once in 3 months	⑦

[CAUTION]

Regular greasing prevents machine noise and abnormal wear-out.



[Fig.5-4]



Turn OFF the main power during the grease supply.


Use lithium-type grease (JIS No.2) - Albania No.2.

NO	Where to Grease	Greasing cycle	Reference Fig.
1	X-axis LM guide	Once in 2 months	①
2	Y-axis LM guide	Once in 2 months	②
3	Sub Y drive LM guide	Once in 2 months	③
4	Head drive LM guide	Once in 2 months	④


[CAUTION]

Do not grease the parts not indicated (needle bar, hook, etc.)


① X-axis LM guide




② Y-axis roller guide



③ Sub Y drive LM guide



④ Head drive LM guide (upper cover opened)



[Fig.5-5]

5-4) DRIVE BELT TENSION


Turn OFF the main power when inspecting drive belt tension.

Too weak or too tight tension on the drive belt may cause machine malfunction or damages (abnormal wear-out of drive unit). Inspect the driver belt on a regular basis.

NO	Location for inspection	Inspection cycle	Reference
1	Belt on main shaft motor	Once in 3 months	① check belt tension ② check for belt crack ③ check for belt wear-out ④ check for bearing damage ⑤ check for wear-outs of rotating & sliding parts
2	Upper/Lower shaft belt	Once in 3 months	
3	X-axis timing belt	Once in 3 months	
4	Y-axis timing belt	Once in 3 months	

[CAUTION]

Inspect the tension in the direction of the arrows in the picture below.



[Fig.5-6]

MAJOR MACHINE ADJUSTMENTS



WARNING

Turn OFF the main power when adjusting the machine.


6-1) ADJUSTING THE TRIMMERS

6-1-1) Adjusting the Position of the Trimming Cam (Insert Angle of Movable Blade)

The movable blade is started by the trimmer cam in the angle it is inserted. As one of the basic trimming functions, it arranges the upper thread tails in the needle after trimming.

1) Adjusting the position of the movable blade


- ① Check if the movable blade is in the correct position.
- ② Cutting point of the movable blade should be inserted 1mm at the end of the fixed blade. Incorrect position of the movable blade can cause trimming errors or deviation of the upper thread.
- ③ Unfasten the crank screw to adjust the location of the movable blade (see [Fig.6-1]).



[Fig.6-1]

2) Adjusting the angle of the movable blade

- ① Unfasten two screws on the blade cam. Adjust the upper shaft rotary angle at 290° .
- ② Insert the trimming cam roller into the trimming cam. Turn the cam and when the roller aligns with the curve of the cam, fasten the two screws back.
- ③ Run the manual handle and check if the movable blade is well-inserted at 290° . Always check after the adjustment.



[Fig.6-2]

6-1-2) Adjusting Blade Tension


Make sure to check and adjust the cross-tension of the movable and the fixed blades after replacement or repair.

① Checking the cross tension

Manually move the movable blade and cut the upper and the lower threads. Check the cross-section of the thread cut.

② Adjusting the cross tension

Adjust the cross tension using fixed blade tension control screws (see [Fig.6-3]). Manually move the movable blade and adjust that it crosses in parallel with the cutting line of the fixed blade from its entry point to its return point.



[Fig.6-3]

[NOTE]

Avoid excess cross-tension. It may cause the movable blade to wear out from overload at its entry or return point.


6-1-3) ADJUSTING THE TRIMMER RETURN SPRING

1) Function

The trimmer return spring detects if the movable blade returns to the correct position after trimming. If the machine operates without the blade returned to its correct position, the needle and the blade may be damaged. The trimmer return spring detects and stops the machine if the blade has not returned.

2) Adjustment

- ① Unfasten the spring shaft screw so that the center of the spring hole is around 2mm away from the surface to which the screw is attached (see [Fig.6-4]). Save the location of the spring.
- ② Adjust the return spring so that the surface and the spring are around 1mm apart.



[Fig.6-4]


6-2) ADJUSTING UPPER THREAD HOLDING UNIT

1) Checking the assembly of upper thread holding lever and upper thread holder plate

- ① Stroke of the upper thread holder driver plate in the upper thread holder base should be 1mm from the base when the upper thread holding solenoid is on.
- ② If the space is shorter than 1mm, adjust the position of the upper thread holding solenoid up and down so that the stroke of the plate is 1mm.
- ③ If the solenoid is not adjusted with the above measure, you must adjust the position of the upper thread holding lever.
- ④ To adjust the upper thread holding lever, remove the arm protection plate from the arm. Adjust the upper thread holding solenoid over the center, and unscrew the lever. Support the arm protection plate with a flat plate so the lever touches the flat plate. Fasten the screw of the upper thread holding lever. Make sure that the upper thread holding lever is touching the axis of the upper thread holding solenoid.
- ⑤ Check if the lever moves smoothly left and right when you manually operate it.
- ⑥ Install the arm protection plate and go through ① and ② to complete.

[CAUTION]

If the upper thread holding unit does not function well, check if the upper thread holder driver plate of the unit moves smoothly when you manually move it. If not, adjust the position of the upper thread holding base.




[Fig.6-5]

6-3) PICKER ADJUSTMENT

If the position or the starting height of the picker is incorrect, the machine may not be able to separate the upper and the lower thread and cut them both, resulting in short upper thread.

① Adjusting the picker position


Manually move the picker so it touches the bobbin. Using the picker screws, adjust so the tip of the picker is in the correct position as in [Fig.6-6].



[Fig.6-6]

② Adjusting the starting height

Unfasten the screw on the picker stopper. Adjust so that the picker softly touches the bobbin when pressed by hand.




[Fig.6-7]

③ Adjusting picker standby position

Unfasten the screws on the picker solenoid cover. Adjust the position of the solenoid cover so that the tip of the picker is around 20mm away from the bobbin.

[CAUTION]

After adjusting the picker standby position, check if the bobbin case moves smoothly.




[Fig.6-8]

6-4) ADJUSTING UPPER THREAD HOLDER

① Adjusting Sensor Adjustment Rings


Make the following adjustments if you find errors in the wiper return system.

- a. Open the cover of the wiper motor. Of the two sensor adjustment rings, align the center of the sensor screw in the rear ring with the #1 carve point on the fixed block on the cam shaft. Align the center of the sensor screw in the front ring with the #2 carve point on the fixed block on the shaft.
- b. Adjust so the wiper return sensor is 1-1.2mm from the upper head of the sensor screw. Make sure to check if the wiper return sensor turns on.




[Fig.6-9]

- ② If the wiper does not operate smoothly, unfasten the screws on the drive link. Move the wiper lever up and down and unfasten the bracket screws so the wiper is not loaded by the upper thread holder bracket. Fasten the screws back when the wiper moves smoothly.
- ③ After the adjustment, run the color change function to check if the wiper operates well at each needle bar.



[Fig.6-10]

- ④ If trimming error or jump error occurs on a certain head during the embroidery, run the wiper clutch to protect the embroidery and the wiper.
 - Press and turn the wiper clutch counterclockwise to run it. Turn it clockwise to stop.



[Fig.6-11]


6-5) ADJUSTING LOW-NOISE PRESSER FOOT

1) Assembly of Presser Foot Cam

- ① Set the main shaft at 178° and install two reference pins ($\phi 3$) into the assembly hole of the presser foot driver cam ($\phi 3$) as shown in [Fig.6-12]. Insert the pins then into the assembly hole of the take-up lever driver cam.
- ② Adjust the presser foot driver cam to where the reference pins freely move left and right. Fix the three screws (M4 \times L35).

[CAUTION]


1. The assembly pin should smoothly move right and left with the three screws fastened.
2. The assembly unit and the assembly pin are not for commercial sale.
3. Contact your SWF dealer if you must adjust the location of the cam.



[Fig.6-12]

2) Adjusting the Height of the Presser Foot

- ① Check the relationship between the presser foot and the needle/embroidery material. Turn the main shaft lever to position the needle at the lowest point (178°). Remove the head cover and unfasten the screws on the presser foot so it moves up and down. Place a 1mm-thick gauge on the needle plate and lightly press the presser foot. Fasten the screws snugly when the presser foot touches the gauge.



[Fig.6-13]

6-6) Relationship between Presser Foot and Needle


1) Relationship between Presser Foot, Needle, and Embroidery Material

For stable stitching, the presser foot must be pressing the embroidery material before the needle pierces into the material. The same is true for when the needle comes out of the material.

2) When the Presser Foot is Too High

① Needle In


[Fig.6-15] shows the presser foot fails to press the work material when the needle pierces into the fabric, causing an unstable needlework.




[Fig.6-14]

② Needle Out

[Fig.6-16] shows the presser foot fails to press the work material when the needle comes out of the fabric. The embroidery material is lifted up along with the needle, making a gap between the fabric and the needle plate. This may cause thread breaks, skipped stitches, or unstable stitching.



[Fig.6-15]



[Fig.6-16]


6-7) CORRECT POSITION OF NEEDLE

- ① Make sure to check the position of the needle - it may change during machine delivery or leveling. First check if the needle is bent. Then turn the main shaft lever to set the shaft at around 130°. Position the needle at the lower dead stop and check if the needle is at the center of the needle hole on the plate.

[CAUTION]

Check the needle position on all heads.


- ② If the needle is not in the correct position, unscrew the brackets (two screws) to adjust the head and the needle (see [Fig.6-17]).



[Fig.6-17]

6-8) ADJUSTING HALF-TURN FILM FOR COLOR CHANGE

- ① (For automatic color change) If the needle is not at the center of the needle hole on the plate, turn the lever and adjust so that the roller is on the center of the color change cam on the straight line. Open the cover of the half-turn sensor and align the center of the half-turn sensor with the center of the film (see [Fig.6-18]).



[Fig.6-18]


[CAUTION]

Manual color change must be performed at the upper shaft angle of 100°. Manual color change at the upper shaft angles other than 100° may cause damage on the controller and the take-up unit.

6-9) ENCODER ADJUSTMENT

Adjust the encoder as below if the needle bar stops at an incorrect position.

- ① Unfasten the two encoder coupling screws.
- ② Turn the hand lever, fix the upper shaft angle at around 98°, and adjust the encoder as in [Fig.6-19]. Tighten the screws when FIX POS light is turned on. Fasten fixed screw on the lower shaft connecting parts of couple ring.




[Fig.6-19]

6-10) JUMP MOTOR ADJUSTMENT

Adjustment is required for new or malfunctioning jump motor.

1) Adjusting the Standby Position (adjusting motor base)


- ① Unscrew motor base ([Fig.6-20]) and adjust so that the jump crank roller is 0.3mm away from the controller. Fasten the screw.
- ② If the gap is wider than 0.3mm, the needle may not jump well. If the gap is narrower than 0.3mm, the jump will cause noise.



[Fig.6-20]

2) Adjusting Jump Manual Clutch

- ① Jump manual clutch is used to turn the head off mechanically. If the clutch lever doesn't function properly, check the clutch assembly.
- ② First, pull the clutch lever forward and check if the carve on the clutch base is in line with the center of the clutch pin and the center of the motor shaft when in standby (see [Fig.6-21]). If not, unscrew and adjust the clutch body with the jump crank roller attached to the stopper. Fasten the screw back.
- ③ Pull the clutch lever forward and check if the clutch body and the stopper are completely attached. If not, adjust the stopper to be completely attached to the body.



[Fig.6-21]



1. If you will not be using the head with the head ON/OFF switch, make sure to use the jump manual clutch lever.
2. If the A side of the jump manual clutch does not touch the stopper, when you run the electric jump you will hear a noise.

6-11) ADJUSTING DRIVER BELT TENSION

[CAUTION]

- 1. Drive belt tension can be adjusted only by trained SWF engineers.
- 2. Make sure to turn OFF the machine during the adjustment.

6-11-1) Specification of Drive Belt Tension Adjuster


- ① Model: U-305 Series Sound Wave Belt Tension Gauge - Standard
- ② Manufacturer: UNITTA

6-11-2) Y-Axis Timing Belt

- ① Push the X frame plate to the driven pulley ([Fig.6-22]) and check the drive belt tension on the Y-axis. Use the sound wave tension gauge.
- ② Tension on the Y-axis belt should measure as below on the sound wave measurer when you pluck the middle of the belt between the end of the X frame connecting plate and the drive pulley with your finger.
- ③ Input data for the sound wave tension measurer:

Type	SWF/E- UH1504D-45	SWF/E- UH1506D-45	SWF/E- UH1508D-45	SWF/E- UH1512D-45
Weight	3.8 gf/m	3.8 gf/m	3.8 gf/m	3.8 gf/m
Wide	35 mm/#R	35 mm/#R	35 mm/#R	35 mm/#R
Span	510 mm	520 mm	530 mm	530 mm
Tension measurement	18 kgf	18 kgf	18 kgf	18 kgf

- ④ To adjust the tension on the Y-axis timing belt, unfasten the tension base screws. Turn the bolts to adjust the tension. Turn clockwise to increase and counterclockwise to decrease the tension.




[Fig.6-22]

6-11-3) X-Axis Timing Belt

- ① Push the Y-axis frame plate fully to the right ([Fig.6-23]). Check the drive belt tension on X-axis using the sound wave tension gauge.
- ② Tension on the X-axis timing belt should measure as below on the sound wave measurer when you pluck the middle of the belt with your finger.
- ③ Input data for the sound wave tension measurer:

Type	SWF/E-UH1504D-45	SWF/E-UH1506D-45	SWF/E-UH1508D-45	SWF/E-UH1512D-45
Weight	4.0 gf/m	3.8 gf/m	4.0 gf/m	4.0 gf/m
Wide	15 mm/#R	35 mm/#R	15 mm/#R	15 mm/#R
Span	610 mm	445 mm	590 mm	590 mm
Tension measurement	19 kgf	25 kgf	19 kgf	19 kgf

- ④ To adjust the tension on the X-axis timing belt, use the tension bolt. After the adjustment, fasten the bolt. Turn the bolt clockwise to increase the tension and counterclockwise to decrease the tension.




[Fig.6-23]

6-11-4) Timing Belt on Main Shaft Motor

- ① Tension on the timing belt of the main shaft motor should measure as below on the sound wave measurer when you pluck the middle of the belt with your finger.
- ② Input data for the sound wave tension measurer:

Weight	004.0 gf/m
Wide	25 mm/#R
Span	0405 mm
Tension measurement	18 Kgf

- ③ To adjust the tension, unscrew the idler and adjust it right and left to get the right tension. Turn the idler left to increase the tension and right to decrease the tension.




[Fig.6-24]

6-12) LAMP (OPTIONAL)

6-12-1) Adjusting Lamp Socket

Standard lamp for SWF machines measures 580mm in length. If you have to use 590mm lamp for certain purposes, adjust the lamp in the following order.

- ① Unfasten the three screws on the socket.
- ② Push the lamp socket fully to the right of the shell.
- ③ Install a new lamp and adjust the socket according to the length of the lamp. Fasten the socket screws.



[Fig.6-25]

TROUBLE SHOOTING




DANGER

CAUTION


Inspect/repair the machine by the guideline when in machine failures.


Error Type	Cause	Inspection & Repair	Reference
Operation failure	① Loose belt tension / belt damage	Adjust belt tension / change belt	
	② Power failure or short-circuit of fuse	Check fuse in main shaft motor and change fuse	
	③ Failure to sense signals for needle position or 1 rotation	Run manual color change and check if signal lamps (needle set lamp & needle position lamp) blinks at correct needle position. Adjust the half-turn film.	
	④ Red light on X/Y drive box	Address the cause and press RESET. Check if the lamp turns green.	
	⑤ Machine does not start at START	Check connection of START switch	
Incorrect Stop Position	① Loose tension on main driver belt	Adjust belt tension	
	② Incorrect position of encoder or bad encoder	Adjust encoder position or change encoder	

Error Type	Cause	Inspection & Repair	Reference
Bad Color Change	① Incorrect position of needle stop	Refer to user's manual	Set main shaft angle back at 100°, if you manually moved it for cleaning, inspection or repair.
	② Failure to sense signals for needle position or 1 rotation	Run manual color change and check if signal lamps (needle set lamp & needle position lamp) blinks at correct needle position. Adjust the half-turn film.	
	③ Incorrect position of needle bar	Set it to the correct position	
	④ Incorrect position of take-up lever	Adjust so take-up lever is in line with other levers in stop position (upper shaft angle:100°)	<p>▣ Unscrew the lever and adjust so it is in line with the others on the guide rail.</p>  <p>The diagram shows a cross-section of the thread take-up mechanism. A lever is mounted on a shaft, and a screw is used to adjust its position. The lever is labeled 'Thread take-up driving lever fixing screw' and the assembly is labeled 'Thread take-up'.</p>
	⑤ Fuse failure for color change motor Bad connection	Change fuse F3 in joint board or check connection	▣ Check fuse spec.

Error Type	Cause	Inspection & Repair	Reference
Poor detection of upper thread	① Poor connection of take-up spring and thread detector plate ② Poor connection & quality of tension adjusting plate	Clean the spring and the plate, or adjust the spring tension. Check the plate connection and change the circuit board	
Bad jump	① Bad motor and bad motor wiring ② Bad connection ③ Switch failure on tension adjusting board and bad circuit board	Check wiring and change motor Check connection Change switch and circuit board	
Bad stitch quality	① Bad tape ② Inadequate tension on X-Y belt ③ Foreign substance in X-Y rail ④ Failure of X/Y driver board ⑤ Heavy load on frame	Correct tape Adjust tension Clean the rail Change circuit board Reduce speed of main shaft	

Error Type	Cause	Inspection & Repair	Reference
Thread breaks	① Stitch is too small/dense for thread	Re-punch design tape	Check design
	② Frequent thread break in the same spot	<ul style="list-style-type: none"> • Re-punch after checking design • Correct the stitches on operation box 	
	③ Inadequate needle size for thread	Change needle	
	④ Needle damage (bent, dent, worn)	Change needle	
	⑤ Incorrect needle installation (height, direction, etc.)	Re-install needle	
	⑥ Dirty needle (adhesive, etc.)	Clean or change needle and hook	
			Use minimum adhesive for appliqué


Error Type	Cause	Inspection & Repair	Reference
	⑦ Bad thread (weak, uneven thickness, poorly twisted, old)	Change thread	<p>Check the using thread</p> <p>* Selecting thread</p> <ul style="list-style-type: none"> · soft, even thickness · tight, left-twisted
	⑧ Right-twisted thread	Change to left-twisted thread	 <p>· Z-direction: left</p> <p>· S-direction: right</p> <p>(CAUTION) left-twist prevents unraveling in the counterclockwise rotation of the hook</p>
	⑨ Excessive thread tension	Adjust tension	
	⑩ Tension imbalance between upper and lower threads		
	⑪ Excessive tension & stroke on take-up spring	Adjust tension and stroke	

Error Type	Cause	Inspection & Repair	Reference
	<p>⑫ Dent on thread path on hook and bobbin case</p> <p>⑬ Narrow space between hook holder and groove for hook holder (on hook)</p>	<p>Remove dent or change the case</p> <p>Adjust space</p>	<p>□ Set it at 0.5-0.7mm for smooth feeding of upper thread</p> 
	⑭ Insufficient oil in hook	Oil the raceway of hook	
	⑮ Poor timing of needle and hook	Adjust timing	
	⑯ Incorrect lower dead stop	Adjust the lower dead stop	
	⑰ Dent on thread path	<p>• Check</p> <p>① Thread path in presser foot</p> <p>② Around needle hole on needle plate</p> <p>③ Thread guide on the head</p> <p>④ Thread path in tension adjuster</p>	
	⑱ Fabric moves on the frame	Fix the material firmly	
	⑲ Inadequate height of presser foot (does not press the work material)	Adjust height	

Error Type	Cause	Inspection & Repair	Reference
Skipped Stitches	① Bent needle		
	② Inadequate needle size for thread	Change needle	
	③ Incorrect installation of needle	Adjust installation	
	④ Poor timing of needle and hook	Adjust timing	
	⑤ Large gap between needle groove and hook point		
	⑥ Incorrect lower dead stop	Adjust the lower dead stop	
	⑦ Damaged hook point	Use whetstone to adjust hook point or change hook	
	⑧ Thread feeding is interfered	<ul style="list-style-type: none"> · Adjust thread tension · For upper thread, change bobbin or bobbin case 	
	⑨ Inadequate thread (twist, elasticity, and flexibility)	Select right thread for embroidery	
	⑩ Excessive tension or stroke on the take-up lever spring	Adjust stroke or tension	
	⑪ Fabric moves with needle - weak or damaged presser foot (spring)	Change presser foot spring	

Error Type	Cause	Inspection & Repair	Reference
Poor stitch tension	① Weak upper thread tension ② Uneven upper thread tension due to foreign substances ③ Weak lower thread tension ④ Uneven lower thread tension ⑤ Thread thickness ⑥ Poor timing of needle and hook ⑦ Insufficient oil in hook	Adjust tension Clean main and sub tension adjusters in the thread tension adjusting plate Adjust tension Clean bobbin case and check tension on bobbin spring Change to quality thread Adjust timing Oil the raceway of hook	
Needle breaks	① Bent needle ② Bad quality needle ③ Tip of the needle is worn or bent ④ Needle touches the hook point ⑤ Needle touches the hook point ⑥ Incorrect installation of needle ⑦ Needle touches the needle hole on the plate	Change needle Space the needle and the hook point Correct the installation ① Check if needle plate is unscrewed ② Adjust the position of the needle bar	

Error Type	Cause	Inspection & Repair	Reference
Puckering	<p>① Excessive thread tension</p> <p>② Excessive pressure of presser foot</p> <p>③ Needle failure worn out/damaged needle tip needle is too large for thread</p> <p>④ Needle hole is too large for needle</p>	<p>Adjust tension</p> <p>Change presser foot spring</p> <p>Change needle</p> <p>Use adequate size of needle</p>	<p>* SWF/□ needle holes are 2.0mm</p>
Trimming failure	<p>① Poor connection/quality of trimming solenoid</p> <p>② Bad connection</p> <p>③ Trimming driver TR damaged</p>	<p>Check and change solenoid and solenoid connection</p> <p>Check connection</p> <p>Change joint board</p>	

Error Type	Cause	Inspection & Repair	Reference
Trimmer return failure	① Poor connection of sensor ② Bad circuit board ③ Bad sensor or sensor position Dirty area around the sensor	Check connection Change circuit board · change sensor · clean around the sensor · adjust location of the sensor unit	
Short upper thread after trimming due to separation failure	① Movable blade is too fast or too slow to separate the upper thread ② Incorrect position of picker ③ Picker failure	Adjust insert angle of movable blade (295°) Adjust picker position · Check and change fuse F1 · Check/change solenoid and solenoid connection · Check connection and change joint board	· Check fuse spec
Thread break before trimming	① Upper thread is too short · check main and sub tension adjuster · dent or damage to movable blade ② Lower thread is too short · doesn't unwind smoothly · too weak or too elastic	Adjust upper thread tension remove dent using whetstone or sandpaper or change movable blade · adjust or change bobbin case spring · clean/check for dent in thread guide on the bobbin case · Change lower thread	 Check for dent · Too short lower thread cannot make stitches right after trimming

Error Type	Cause	Inspection & Repair	Reference
Short upper thread after trimming	① Upper thread is trimmed too short and comes unthreaded ② Upper thread is trimmed too long and thread tail remains on the embroidery	<ul style="list-style-type: none"> check upper thread tension set LONG or MEDIUM length of trimmed thread in data set-up set MEDIUM or SHORT length of trimmed thread in data set-up if upper thread is held due to narrow velcro space in upper thread holder, clean the velcro 	The default is MEDIUM
Thread is not cut (at specific head)	① Failure of movable and fixed blades ② Loose cross tension of the blades ③ Movable blade damaged ④ Incorrect return position of movable blade	Check screws and crank driver clamp screws of the movable blade Check tension of fixed blade Change movable blade Adjust the position of movable blade	
Failure of upper thread holder solenoid	① Poor connection/quality of solenoid ② Bad connection ③ Poor quality circuit board	Check/change solenoid & connection Check connection Change thread detecting plate in sub controller	
Failure to hold upper thread	① Short strokes of upper thread holder ② Upper thread holder overloaded	Adjust stroke Adjust the workload	
When the fluorescent lamp is not properly operating, one of the following might be the reason:	① Cable fuse short-circuit ② Circuit fuse short-circuit ③ Expired lifespan of the lamp	Replace the cable fuse Replace the con. box lamp ass'y fuse Replace the fluorescent lamp	<ul style="list-style-type: none"> Change fuse spec Change fuse spec Change fuse spec

8 BLOCK DIAGRAM

