


RouterBOARD 600 Series

User's Manual

Rev. A (30-Oct-2007)



Copyright

Copyright © 2003-2007 MikroTikls SIA. This manual contains information protected by copyright law. No part of it may be reproduced or transmitted in any form without prior written permission from the copyright holder.

Trademarks

RouterBOARD, RouterOS, RouterBOOT and MikroTik are trademarks of MikroTikls SIA. All trademarks and registered trademarks appearing in this manual are the property of their respective holders.

Limited Warranty

Hardware. MikroTikls SIA warrants all RouterBOARD 600 series equipment for the term of one year from the shipping date to be free of defects in materials and workmanship under normal use and service. All parts will be repaired or replaced with similar or functionally equivalent parts by MikroTikls SIA during the warranty term, except in case the returned parts have mechanical, electrical or other accidental or intended damages caused by improper use or due to wind, rain, fire or other acts of nature.


Parts (or systems) must be shipped pre-paid to our facility in Riga, Latvia. All items must have a Return Material Authorization (RMA) which you can get by contacting us via email, telephone or fax. RMA must be printed, signed, and enclosed with the shipment, also the RMA number must be written on the package itself. Parts sent without following the proper procedure will be treated as those not to be repaired or replaced due to the above mentioned conditions. Items proved to be free of defects in our lab will be returned to the customer at the customer's expense. Those that do meet the warranty repair requirements will be repaired or replaced, and returned to the customer's location at our expense, extending the warranty term for the time the items are being shipped to and from our facility and replaced or repaired.

Manual. This manual is provided "as is" without a warranty of any kind, expressed or implied, including, but not limited to, the implied warranty of merchantability and fitness for a particular purpose. The manufacturer has made every effort to ensure the accuracy of the contents of this manual, however, it is possible that it may contain technical inaccuracies, typographical or other errors. No liability is assumed for any inaccuracy found in this publication, nor for direct or indirect, incidental, consequential or other damages that may result from such an inaccuracy, including, but not limited to, loss of data or profits.


Table of Contents

Copyright	1
Trademarks	1
Limited Warranty	1
System Board View	3
System Board Layout	3
Specifications	4
Block Diagram	4
Hardware Guide	5
Memory and Storage Devices	5
Onboard Memory	5
Onboard NAND Storage Device	5
CompactFlash Slots	5
Extension Slots	5
MiniPCI Slots	5
Daughterboard Connector	5
Input/Output Ports	5
LAN1 Port with PoE	5
LAN2 Port	5
LAN3 Port	5
DB9 Serial Port	6
Fan Connectors	6
LEDs	6
Power LED	6
User LED	6
User's Guide	6
Assembling the Hardware	6
Powering	6
Booting options	7
Onboard NAND Storage Device	7
Internal Storage Device	7
Booting from network	7
Operating System Support	7
System Architecture	7
MikroTik RouterOS	7
RouterBOOT	7
Boot Loader Configuration	8
Configurable Options	8
Boot Loader Upgrading	9
Primary Boot Loader	9
RouterOS on RouterBOARD 600	9
Health monitor	9
Firmware information	9
Firmware Settings	9
Software Reset	10
Appendix	10
Connector Index	10
Button Index	10
Ethernet Cables	11
Serial Null-modem (Console) Cable with Loopback	11

System Board View




Top view



Bottom view


System Board Layout



Specifications

	RouterBOARD 600
CPU	MPC8343E 266/400MHz network processor
Memory	64MB DDR SDRAM onboard memory
Boot loader	RouterBOOT
Data storage	64MB onboard NAND memory chip
Ethernet	Three 10/100/1000 Mbit/s Gigabit Ethernet ports supporting Auto-MDI/X
MiniPCI slot	Four MiniPCI Type IIIA/IIIB slots
Expansion	Daughterboard support, including RB500 daughterboards
CompactFlash slots	Two independent CompactFlash slots (True IDE Microdrive supported)
Serial port	One DB9 RS232C asynchronous serial port
LEDs	Power and User LED
Beeper	Present
Power	Power over Ethernet: 38..56V DC (supports power over datalines) Power jack: 10..56V DC
Fan control	Two 5V DC fan power output headers with rotation sensor and automatic fan switching (maximum output current - 300mA total)
Dimensions	14 cm x 20 cm (5.51 in x 7.87 in)
Weight	227 g (8 oz)
Temperature	Operational: -20°C to +65°C (-4°F to 149°F)
Humidity	Operational: up to 70% relative humidity (non-condensing)
Power consumption	~9W without extension cards, maximum - 35+ W (25+ W output to extension cards)

Block Diagram



Hardware Guide

Memory and Storage Devices

Onboard Memory

The boards are equipped with 64 MB DDR SDRAM onboard memory.

Onboard NAND Storage Device

The boards are equipped with one 64MB NAND nonvolatile memory chip.

CompactFlash Slots

The board has two independent CompactFlash slots that support Compact Flash Type I or II cards and True IDE Microdrive storage devices. The first one (**J301**) is bootable. **Warning! The RouterBOARD 600 series boards do not support hot insert of CompactFlash/Microdrive devices.**

Extension Slots

MiniPCI Slots

The board has four MiniPCI Type IIIA slots with 3.3V only power signaling. They also accept MiniPCI Type IIIB standard cards. The board has been tested to operate with 5 Ubiquity SR series high power cards if ambient temperature and adequate cooling is ensured.

Supplied power for the extension cards (excluding CPU and onboard Ethernet ports):

+3.3V: 7.5A typical

Daughterboard Connector

Additional Ethernet and/or MiniPCI slots may be connected to the board using the daughterboard connector, which supports the same devices as the RouterBOARD 500 series do.

Input/Output Ports

LAN1 Port with PoE

This Gigabit Ethernet port is recognized as the first LAN interface. It is compatible with most Power over Ethernet injectors. The board accepts voltage input from 38 to 56 V DC. It is suggested to use 48V for power over long cables because of better efficiency (less power is lost in the cable itself and power supply is more efficient).

See **Connector Index** for pinout of the standard cable required for PoE. All cables made to EIA/TIA 568A/B cable specifications will work correctly with PoE. Note that this port supports automatic cross/straight cable correction (Auto MDI/X), so you can use either straight or cross-over cable for connecting to other network devices.

LAN2 Port

This Gigabit Ethernet port is recognized as the second LAN interface. This port does not support Power over Ethernet.

All cables made to EIA/TIA 568A/B cable specifications will work correctly (see **Connector Index** for pinout). Note that this port supports automatic cross/straight cable correction (Auto MDI/X), so you can use either straight or cross-over cable for connecting to other network devices.

LAN3 Port

This Gigabit Ethernet port is recognized as the third LAN interface. This port does not support Power over Ethernet.

All cables made to EIA/TIA 568A/B cable specifications will work correctly (see **Connector Index** for pinout). Note that this port supports automatic cross/straight cable correction (Auto MDI/X), so you can use either straight or cross-over cable for connecting to other network devices.

DB9 Serial Port

The RS232C standard male DB9 asynchronous serial port may be used for initial configuration, or for attaching a modem or any other RS232 serial device. TxD (pin 3) of this port has -5V DC power when idle. Some signals are not connected, so this implementation may not be considered to support full hardware flow-control, so software flow-control (XON/XOFF) or none at all should be used.

Fan Connectors

You can connect up to two fans to the RouterBOARD, but only one of them will work at a time. They will receive 5.5V DC power. The board supports fan speed feedback signaling. RouterOS can be configured to change the active fan, if the current active one is not rotating (note that if a fan does not have rotation sensor, it will be considered failed).

LEDs

Power LED

Power LED is on when the board is powered.

User LED

User LED may be programmed at user's option. It is lit by default when the board starts up, then it is turned off when the bootloader runs kernel.

User's Guide

Assembling the Hardware

First to use the board:

- In most cases you do not need to use any additional boot devices, as you can boot the RouterBOARD from the onboard NAND memory. You can also install one or two CompactFlash modules or Microdrive hard drives, which you can use as an alternative boot device (in **J301** slot only) or additional storage media (in any or both slots);
- Insert MiniPCI cards on the board itself, and on the daughterboard if you have one;
- Install the board in a case, connect and secure the daughterboard and connect antenna wires, if needed;
- Connect other peripherals and cables.

You can also order a pre-assembled system with RouterBOARD and extension cards of your choice already installed in a case.

Powering

Power options:

- **J901** power jack:
10..56V DC
- Power over Ethernet (PoE) on the **J701** LAN1 Ethernet port:
38..56V DC Power over Ethernet

The board has a direct-input power jack **J901** (5.5mm outside and 2mm inside diameter, female, pin positive plug) and can as well be powered with PoE. All power inputs are always active, but only one should be used at the same time.

RouterBOARD 600 series boards are equipped with a reliable 35+ Watt onboard power supply. 10..56 V DC input voltages are accepted through the **J901** power jack. The system is tested with 24V solar/wind/RV systems with 27.6 charge voltage.

RouterBOARD 600 series boards are compatible with most standard and non-standard (passive) Power over Ethernet injectors and accept powering over up to 100m (330 ft) long Ethernet cable connected to the Ethernet port (**J701**). The minimum turn on voltage is about 38V DC and it has undervoltage protection turning the board off when the input voltage drops lower than 32V.

The maximum output of the power supply to the extension cards is normally at about 25W (7.5A at 3.3V), however with appropriate cooling, the onboard power supply is capable to provide higher power output to

the extension cards.

Booting options

First, RouterBOOT loader is started. It displays some useful information on the onboard RS232C asynchronous serial port, which is set to 115200bit/s, 8 data bits, 1 stop bit, no parity by default. The loader may be configured to boot the system from the onboard NAND module or from Ethernet network. See the respective section of this manual for how to configure booting sequence and other boot loader parameters.

Onboard NAND Storage Device

The RouterBOARD may be started from the onboard NAND storage chip. As there is no partition table on the device, the boot loader assumes the first 4MiB form a YAFFS filesystem, and executes the file called "kernel" stored in the root directory on that partition. It is possible to partition the rest of the medium by patching the kernel source.

Internal Storage Device

The RouterBOARD may be started from a CompactFlash module or a Microdrive hard drive installed in the first (**J301**) CompactFlash slot. At least two partitions must exist on the device, first of which being the ELF image the board is to be booted from (normally, it is a Linux kernel, appended with the kernparm ELF section that specifies the root partition name and, optionally, other kernel parameters of your choice).

Booting from network

Network boot works similarly to PXE or EtherBoot protocol, and allows you to boot a RouterBOARD 600 series boards from an executable image stored on a TFTP server. It uses BOOTP or DHCP (configurable in boot loader) protocol to get a valid IP address, and TFTP protocol to download an executable (ELF) kernel image combined with the initial RAM disk (inserted as an ELF section) to boot from (the TFTP server's IP address and the image name must be sent by the BOOTP/DHCP server).

To boot the RouterBOARD computer from Ethernet network you need the following:

- An ELF kernel image for the loader to boot from (you can embed the kernel parameters and initrd image as ELF sections called *kernparm* and *initrd* respectively)
- A TFTP server which to download the image from
- A BOOTP/DHCP server (may be installed on the same machine as the TFTP server) to give an IP address, TFTP server address and boot image name

See the RouterBOOT section on how to configure loader to boot from network.

Note that you must connect the RouterBOARD you want to boot, and the BOOTP/DHCP and TFTP servers to the same broadcast domain (i.e., there must not be any routers between them).

Operating System Support

System Architecture

RouterBOARD 600 series embedded boards are fully compatible with the standard e300 architecture with PCI bus.

CPU. RouterBOARD 600 series has Freescale MPC8343E PowerQUICC II Pro based embedded processor using e300 core. The core does not include Encryption Acceleration.

Ethernet. RouterBOARD 600 series has two onboard Gigabit Ethernet ports (**J701 LAN1** and **J702 LAN2**) controlled by the QUICC Engine and one additional onboard Gigabit Ethernet port (**J401 LAN3**) controlled by VIA Velocity VT6122 Gigabit Ethernet Controller.

MikroTik RouterOS

MikroTik RouterOS, starting from version 3.0rc1 (RouterBOARD 600 series edition), is fully compatible with RouterBOARD 600 series embedded boards.

RouterBOOT

The RouterBOOT firmware (also referred as boot loader here) provides minimal functionality to boot an Operating System. It supports serial console via the onboard serial port at the boot time. The loader supports booting from the onboard NAND device and from a network server (see the respective section for

details on this protocol).

Boot Loader Configuration

Loader parameters may be configured through the onboard RS232C DB9 asynchronous serial interface. To connect to it, use a standard null-modem cable. By default, the port is set to 115200bit/s, 8 data bits, 1 stop bit, no parity. **Note** that the device does not fully implement the hardware (RTS/CTS) flow control, so it is suggested to try to disable hardware flow control in the terminal emulation program in case the serial console does not work as expected, and if it does not help, make a new cable using the pinout given in the Appendix.

To enter the loader configuration screen, press any key (or only [Delete] key (or [Backspace] key – see the note for the respective configurable option), depending on the actual configuration) just after the boot loader is asking for it:

```
RouterBOOT booter 2.11
```

```
RouterBoard 600
```

```
CPU frequency: 400 MHz
```

```
Memory size: 64 MB
```

Press any key within 2 seconds to enter setup

```
RouterBOOT-2.11
```

```
What do you want to configure?
```

```
  d - boot delay
  k - boot key
  s - serial console
  o - boot device
  f - cpu frequency
  r - reset configuration
  e - format nand
  g - upgrade firmware
  i - board info
  p - boot protocol
  t - do memory testing
  x - exit setup
```

```
your choice:
```

To select a menu point, press the key written at the beginning of this line. Pressing [Enter] selects the option marked with '*'.

Configurable Options

boot delay – how much time to wait for a key stroke while booting (1..9 seconds; **2 second** by default).

boot key – which key will cause the loader to enter configuration mode during **boot delay** (any key | <Delete> key only; **any key** by default). Note that in some serial terminal programs, it is impossible to use the [Delete] key to enter the setup – in this case it might be possible to do this with the [Backspace] key.

serial console – to configure initial serial console bitrate (1200 | 2400 | 4800 | 9600 | 19200 | 38400 | 57600 | 115200; **115200** bps by default).

boot device – initial boot device (boot over Ethernet | boot from NAND, if fail then Ethernet | boot from CompactFlash only | boot Ethernet once, then NAND | boot Ethernet first, then CompactFlash | boot from NAND only; **boot from NAND, if fail then Ethernet** by default). You can also select **boot chosen device** option to boot from the device selected immediately, without saving the setting.

cpu-frequency – CPU frequency (266MHz | 400MHz | 533MHz; **266MHz** by default).

reset configuration – whether to reset all the boot loader settings to their respective default values (yes | no; **no** by default).

format nand – perform a low-level NAND format. During this operation, all previously marked bad sectors are retested to find out if they are faulty indeed.

upgrade firmware – receive a new boot loader image using XModem protocol over serial line or using DHCP/BOOTP and TFTP protocols through the Ethernet network (upgrade firmware over ethernet | upgrade firmware over serial port).

board info – prints the serial number, boot loader version, CPU frequency, memory size and MAC addresses of the onboard Ethernet ports

boot protocol – network booting protocol (bootp protocol | dhcp protocol; **bootp protocol** by default).

do memory testing – performs a full memory test.

Boot Loader Upgrading

The boot loader is needed to initialize all the hardware and boot the system up. Newer loader versions might have support for more hardware, so it's generally a good idea to upgrade the loader once a newer version is available. You can upgrade the loader through the onboard serial port using XModem protocol (programs available for all major OSs). For example, you can use HyperTerminal for Windows or Minicom for Linux to upload the boot loader. Alternatively if you have a DHCP/BOOTP and TFTP servers available, you can specify the loader image as a boot image and choose the **bios upgrade over ethernet** option in the boot loader configuration menu. The loader will get the image from the TFTP server and upgrade itself.

The boot loader upgrading is supported also from MikroTik RouterOS. The procedure is described in the MikroTik RouterOS manual.

Primary Boot Loader

There are two boot loaders present on the NOR flash memory chip. Secondary is the main one, that is executed by default. This is the one that can be upgraded. In case something goes wrong in the upgrade process, or you have set some incorrect settings that render it unusable, you can load the Primary boot loader by holding the Software Reset 1 button (**S301**), connecting the power, and then releasing the button/jumper. The Primary boot loader has the default settings, which can not be changed. It is also not possible to upgrade it.

RouterOS on RouterBOARD 600

Health monitor

This menu shows the current fan status.

```
[admin@MikroTik] > system health print
  fan-mode: manual
  use-fan: main
  active-fan: main
[admin@MikroTik] >
```

fan-mode – whether to use automatic fan failover (auto | manual; **manual** by default).

use-fan – which fan to use in manual mode (main | auxiliary; **main** by default).

Firmware information

This menu displays RouterBOARD model number, serial number, the current boot loader version and the version available in the current software packages installed.

```
[admin@MikroTik] > system routerboard print
  routerboard: yes
  model: "rb600"
  serial-number: "154201C1DD3C"
  current-firmware: "2.11"
  upgrade-firmware: "2.11"
[admin@MikroTik] >
```

The firmware version can be upgraded using **"/system routerboard upgrade"** command.

Firmware Settings

Boot loader settings are also accessible through this menu.

```
[admin@MikroTik] > system routerboard settings print
  baud-rate: 115200
  boot-delay: 2s
```

```

boot-device: nand-if-fail-then-ethernet
enter-setup-on: any-key
boot-protocol: bootp
enable-jumper-reset: yes
[admin@MikroTik] >

```

The Software Reset 2 button (**TP31**) button, which resets both boot loader settings and RouterOS setting by default, can be disabled in this menu (it will still reset the boot loader settings).

Software Reset

It is possible to reset all software configuration by holding the Software Reset 2 button (**TP31**) during the power-up. No confirmation or passwords will be asked, so use with caution. This feature can be disabled in the "**system routerboard settings**" menu by switching the "**enable-jumper-reset**" parameter to "**no**".

Appendix

Connector Index

J301	CompactFlash slot 1 (bootable)	
J302	CompactFlash slot 2	
J401	RJ45 Gigabit Ethernet 1000Base-T port LAN3 (no PoE)	
J402	Daughterboard connector	
J501	MiniPCI Type type IIIA/B connector 1	
J502	MiniPCI Type type IIIA/B connector 2	
J503	MiniPCI Type type IIIA/B connector 3	
J504	MiniPCI Type type IIIA/B connector 4	
J601	RS232C male DB9 serial port	
	2	RxD (Receive Data)
	3	TxD (Transmit Data)
	5	GND
	7	RTS (Request to Send)
	8	CTS (Clear to Send)
J701	RJ45 Gigabit Ethernet 1000Base-T port LAN1 with PoE extension	
J702	RJ45 Gigabit Ethernet 1000Base-T port LAN2 (no PoE)	
J901	Power jack (10..56 V DC, positive contact is the central pin)	
JP801	DC Fan 1 connector	
	1	GND
	2	+5.5 V DC
	3	Rotation speed feedback
JP802	DC Fan 2 connector	
	1	GND
	2	+5.5 V DC
	3	Rotation speed feedback

Button Index

S301	Software Reset 1 button. Loads the Primary boot loader
TP31	Software Reset 2 button. Resets boot loader and RouterOS settings




Ethernet Cables

RJ45 Pin	Color	Function (100Mbit)	Function (1Gbit)	RJ45 pin for Straight cable (MDI, EIA/TIA568A)	RJ45 pin for Crossover cable (MDI-X, EIA/TIA568B)
1	Green	TX+ Data	Data A+	1	3
2	Green/White	TX- Data	Data A-	2	6
3	Orange	RX+ Data	Data B+	3	1
4	Blue	-	Data C+	4	4
5	Blue/White	-	Data C-	5	5
6	Orange/White	RX- Data	Data B-	6	2
7	Brown	-	Data D+	7	7
8	Brown/White	-	Data D-	8	8

Serial Null-modem (Console) Cable with Loopback

DB9f	Function	DB9f	DB25f
1 + 4 + 6	CD + DTR + DSR	N/C	N/C
N/C	CD + DTR + DSR	1 + 4 + 6	6 + 8 + 20
2	RxD	3	2
3	TxD	2	3
5	GND	5	7
7 + 8	RTS + CTS	7 + 8	4 + 5

N/C – not connected.



1. Unspecified R ≤ 1
 2. Unspecified tolerances: DIN7168/FINE
 except p.3:

Tolerance		
Nominal	>	\leq
6	30	0.1
30	120	0.3
120	315	0.4
315	1000	0.6
1000	2000	1.0

External: -IT12
 Internal: +IT12
 Others: $\pm IT12/2$

3. Hole coordinates with unspecified tolerances
 Hole pattern $\phi \phi 0,3$ for all coordinative dim-s;
 countersunks - $\phi \phi 0,1$

Do not scale drawing			Finish:	Scale 1:2	Mass:
Date	Name		Material:		
Drawn.	05.06.07	Veiders	Description: RB600 external dimensions		
Check:			Drawing code: RB600 ED		
Approv.			A3		
			Printed: 10.12.07		
			sheet 1 of 1		