

User Manual

Farm Premium Controllers



Farm Premium, Premium-P, Premium XL, P-XL Climate Controllers

Ag/MIS/UmGB-2044-01/13 rev. 1.9
P/N: 110087

Farm Premium, Premium-P, Premium XL, P-XL

User Manual

Revision: N1.9 of 11.06.2014

Product Software: Version 3.06/4.06

This manual for use and maintenance is an integral part of the apparatus together with the attached technical documentation.

This document is destined for the user of the apparatus; it may not be reproduced in whole or in part, committed to computer memory as a file or delivered to third parties without the prior authorization of the assembler of the system.

Munters reserves the right to effect modifications to the apparatus in accordance with technical and legal developments.

Index

<i>Chapter</i>	<i>page</i>
1 INTRODUCTION	7
1.1 Disclaimer	7
1.2 Introduction	7
1.3 Notes	7
2 INTRODUCTION TO FARM PREMIUM	8
2.1 Precision Ventilation - a quick look	8
2.2 Farm Premium units	10
2.3 Front panel	11
2.4 Keypad	11
2.5 Relay switches	12
2.6 Hot screens	13
2.7 Standard display	14
2.8 Main Menu icons	16
2.9 Version history	17
3 CONTROL MENU	18
3.1 Temperature curve	18
3.1.1 Temperature curve help set definitions	19
3.1.2 Radiant heaters help set definitions	20
3.1.3 Variable heater help set definitions	21
3.2 Humidity treatment	22
3.2.1 Humidity treatment help set definitions	23
3.3 CO2 treatment	23
3.3.1 CO2 treatment help set definitions	24
3.4 Min/Max level	24
3.4.1 By Day and By Soft Days curve	25
3.4.2 By Time	25
3.4.3 Day Soft Min	25
3.4.4 By Weight	26
3.5 Static Pressure	29
3.5.1 Disabling the Static Pressure Sensor	30
3.5.2 Static Pressure help set definitions	30
3.6 Control Mode	31

3.7	System Parameters -----	32
4	DEVICE MENU -----	33
4.1	Levels of ventilation-----	34
4.1.1	Levels of Ventilation help set definitions	35
4.2	Speed Fan levels-----	36
4.3	Vent & Curtain levels-----	36
4.3.1	Vent & Curtain levels help set definitions	37
4.4	Stir Fan levels -----	38
4.5	Stir Fan program -----	39
4.5.1	Stir Fan Program help set definitions version 4.05 and above	39
4.5.2	Stir Fan Program help set definitions Version 4.03 and below	41
4.6	Cool pad-----	43
4.6.1	Cool Pad help set definitions	43
4.7	Foggers-----	44
4.7.1	Foggers help set definitions.....	45
4.8	Light-----	46
4.8.1	Light help set definitions	47
4.9	Water & Feed -----	49
4.9.1	Water and Feed help set definitions.....	49
4.10	Extra Systems -----	50
4.11	Emergency Setting-----	51
4.11.1	Emergency Setting help set definitions	52
4.12	Water on Demand -----	53
5	MANAGE MENU -----	54
5.1	Bird Inventory -----	54
5.2	Feed Inventory-----	55
5.2.1	Feed Inventory help set definitions	56
5.3	Time & Date -----	56
5.4	Growth Day & Flock -----	56
5.5	Alarm Setting-----	57
5.5.1	Alarm Setting help set definitions.....	58
5.6	Alarm Reset-----	60
5.7	Fail Safe Setting-----	60
5.8	Password-----	61
5.9	Relay Current -----	61
6	SCALE MENU-----	63
6.1	Scale Layout-----	63
6.2	General Settings -----	64

6.2.1	General Settings Help set definitions.....	64
6.3	Bird Scale Setting	65
6.4	Feed Bin Setting	65
6.5	Bird Curve	66
6.6	History	67
6.7	Feed Conversion	67
6.8	Test.....	68
6.9	Calibration.....	68
6.9.1	Scale calibration	68
6.9.2	Feed Bin calibration.....	69
7	HISTORY MENU	70
7.1	Temperature.....	70
7.2	Humidity.....	70
7.3	CO2.....	71
7.4	Water	71
7.5	Feed	71
7.6	Mortality.....	71
7.7	Heaters	71
7.8	Radiant Heaters	72
7.9	Alarms	72
7.10	Table of Events	72
7.11	History View.....	72
7.12	Power Consumption.....	73
8	TEST MENU	74
8.1	Switches & Relays	74
8.2	Switches & Relays Extension.....	75
8.3	Alarm.....	75
8.4	Analog Sensors	75
8.5	Digital Sensors.....	76
8.6	Analog Output	76
8.7	Static Pressure	76
8.8	Communication.....	77
8.9	Hardware Checklist	77
8.10	Emergency Status.....	77
9	SERVICE MENU	78
9.1	Temperature Calibration.....	78
9.2	Humidity Calibration.....	79
9.3	CO2 Sensor Calibration.....	79

9.4	Static Pressure Calibration -----	80
9.5	Light Sensor Calibration -----	81
9.6	Feed Calibration -----	81
9.7	Water Calibration -----	82
9.8	Vent Calibration -----	82
9.9	Nipple Flushing -----	83
9.9.1	Nipple Flushing help set definitions	84
9.10	Feeders & Drinkers -----	84
9.10.1	Feeders & Drinkers help set definitions	85
9.11	Save Settings to Plug -----	86
9.12	Read from Plug -----	86
9.13	Current Sense Relay calibration -----	87
10	INSTALL MENU -----	89
10.1	Setup -----	89
10.2	Relay Layout -----	90
10.2.1	Output function list	91
10.2.2	Relay Layout – help set definitions	93
10.3	Analog Sensors -----	93
10.4	Digital Sensors -----	94
10.5	Analog Output -----	94
10.6	Curtain Setup -----	95
10.7	Temperature Definition -----	95
10.8	Fan Air Capacity -----	96
10.9	House Dimensions -----	97
10.10	Communication -----	97
11	APPENDIX A -----	98
12	WARRANTY -----	101

1 Introduction

1.1 Disclaimer

Munters reserves the right to make alterations to specifications, quantities, dimensions etc. for production or other reasons, subsequent to publication. The information contained herein has been prepared by qualified experts within Munters. While we believe the information is accurate and complete, we make no warranty or representation for any particular purposes. The information is offered in good faith and with the understanding that any use of the units or accessories in breach of the directions and warnings in this document is at the sole discretion and risk of the user.

1.2 Introduction

Congratulations on your excellent choice of purchasing an Farm Premium!

In order to realize the full benefit from this product it is important that it is installed, commissioned and operated correctly. Before installation or using the fan, this manual should be studied carefully. It is also recommended that it is kept safely for future reference. The manual is intended as a reference for installation, commissioning and day-to-day operation of the Munters Controllers.

1.3 Notes

Date of release: May 2009

Munters cannot guarantee to inform users about the changes or to distribute new manuals to them.

All rights reserved. No part of this manual may be reproduced in any manner whatsoever without the expressed written permission of Munters. The contents of this manual are subject to change without notice.

2 Introduction to Farm Premium

This document describes the **Farm Premium**, **Farm Premium-P**, and **Farm Premium XL** Precision Mode operation. For greater simplicity and ease of use, you can opt to use the Standard Mode; documentation is provided in the Standard Mode manual.

Computerized Electronic Controllers such as the Farm Premium advance the producer's ability to grow high quality poultry by accurately controlling the environment. Instead of struggling with individual thermostats for heat zones and ventilation, Farm Premium brings them all together into one convenient place with great accuracy. In Precision Mode, the Farm Premium optimizes and precisely applies your equipment and energy sources to most benefit from the accuracy of your computer and sensors.

Where ***Simplicity*** and ***Ease of Use*** are important benefits of Standard Mode, ***Features*** and ***Precise Application*** characterize Precision Mode. The Farm Premium coordinates your ventilation equipment in precise levels of ventilation to provide the optimal fresh air balanced with heating costs. The light and feed clocks provide additional channels for greater capability. Besides advanced Cooling Pad methods, you benefit from superior stir fan programs to recover ceiling heat and other features. Precision Mode's additional features enable you to improve your profitability significantly.

Farm Premium provides a variety of management and history utilities. You can choose from simple overviews, or fully detailed by the *minute* records of minimum, maximum and average temperatures for each individual sensor. The unique ***Table of Events*** records the moment of every significant action taken by the Farm Premium and, optionally, its operator.

Communication software is available to customers who wish to access their Farm Premium controllers locally or remotely at the **Munters'** website, www.Munters.com. **Munters** provides technical support on the website, as well as through the large dealer and agent network.

- Precision Ventilation - a quick look, page 8
- Front panel, page 11
- Keypad, page 11
- Relay switches, page 12
- Hot screens, page 13
- Standard display, page 14
- Main Menu icons, page 16
- Version history, page 17

2.1 Precision Ventilation - a quick look

Munters' Precision Ventilation works by giving the Farm Premium many finely spaced levels of ventilation from which to choose. This enables it to find the right ventilation for the conditions present. A typical change in ventilation from one level to the next in Precision Mode is 20%, compared to as much 1,000% in Standard Mode (for example, when the Minimum Ventilation Timer setting is 30 seconds on, 270 seconds off).

Consider the following simplified Ventilation Levels example:

Ventilation Level	Diff °F	On Time Seconds	Off Time Seconds	Cycle Fans	Comments
...	0	Lower Levels ...
5	0	60	240	1 and 2	1 Minute out of 5 on Timer Fans
6	0	75	225	1 and 2	Current Level, 25% more than Level 5
7	0	90	210	1 and 2	1½ Minutes out of 5, 20% more than Level 6
... Higher Levels

The Farm Premium is currently at Level 6, which in this example means two cycle or timer fans run 1¼ minutes out of five. If required, the Farm Premium moves to Level 5 or Level 7 to maintain the Target Temperature.

In this example, the Differential Temperature for each level is **Zero**. This means that all these levels occur at the **same temperature!** In Precision Mode, the Farm Premium finds that level of ventilation that precisely maintains the target temperature.

Besides maintaining more accurate and precise temperatures, Precision Mode has other benefits. A few examples:

- **Increased Reliability:** Can 'rotate' minimum ventilation timer fans so that all of your fans get a turn.
- **Save Fuel while Ventilating More Efficiently:** Can automatically decrease ventilation as fuel use increases, and increase ventilation whenever outside temperatures allow economical use of free air. See the 'Soft Min Vent' section.
- **Recapture Free Heat:** On-board features to reclaim lost heat back to the birds where it benefits them. See the 'Stir Fans' sections.

2.2 Farm Premium units



Figure 1: Farm Premium-XL Unit



Figure 2: Farm Premium-P XL Unit



Figure 3: Farm Premium-Unit



Figure 4: Farm Premium-P Unit

2.3 Front panel

Figure 4 shows the Farm Premium front panel and its elements.




Figure 5: Farm Premium-P XL - Front Panel

The following sections detail the front panel elements.

NOTE: The Farm Premium-P XL has a larger screen, but the functionality of the Farm Premium, Farm Premium-P and P XL are the same.

2.4 Keypad



Enter main menu, also acts as "ESC" or "Back" key



Access help screens and graphs


NOTE: Only Farm Guard Versions 4.X (and higher) support the graphic view of historical data.




Erase typing mistakes



Enter menus, values, open windows





2.5 Relay switches



Figure 6: Standard Relay Switches

Figure 5 illustrates a row of standard relay switches. Set each relay to:

- **On:** Always on
- **Off:** Always off
- **Auto:** The relay operates according to its set parameters.



Figure 7: Emergency Relay Switches




Figure 8: Winch Switches


2.6 Hot screens

Many of the keys serve as shortcuts. Here are the main ones:

-  Software version
-  Return to standard main screen
-  Temperature, Humidity Status, and Wind Chill Temperature
-  Curve Status
-  Curtain Position
-  Bird Scale and Feed Bin Status
-  Light Status
-  Analog Output Status
-  Temperature sensors
-  Lock password protected controller
-  Scan through Hot Screens for five seconds each
-  Air Status (refer to Weight hot screen, page 29 for details on this screen)

NOTE: *Increase/Decrease Offset from Temperature Setting from the Standard display only (hold both keys) – defined in the [TEMPERATURE CURVE HELP | SET](#)*

NOTE: *In Versions 3.06/4.06, if two humidity sensors are installed, Hot Screen 2 displays their average.*

-  Increase/ decrease offset from temperature setting from the standard display only (hold both keys) – defined in the [TEMPERATURE CURVE HELP | SET](#)

 OK



2.7 Standard display

The main screen consists of the following parts.

SENSORS		AV. TEMP.	ACTIVE	
Temp1	37.9°	27.5°	Heat	1
Temp2	16.2°	<div>STATUS</div> <div>08:53:06</div> <div>Day: 5</div> <div>Set: 25.0</div> <div>Level: 3</div> <div>Min. Vent</div> <div>FanOff: 176</div>	Heat. Hi	1
Temp3	28.2°		Tun. Fan	
E. Tmp1	28.8°		Exh. Fan	
E. Tmp2	28.4°		Stir	
Press.	23		Cool P.	
Out T.	23.9°		Fogger	
Hum. In	58.7%		Curt. 1	100%
Hum. Out	61.9%		Curt. 2	100%
Weight	0.000		Curt. 3	0%
Weights	0		Curt. 4	0%
4 MESSAGES			Ext. Sys	
(2) Low Feed At Bin 2			Alarm	

1. Displays individual sensor readings. Temperature sensors marked with dark squares form the current average temperature.

- **Filled square:** Indicates the sensor participates in the average calculation.
- **Empty square:** Indicates the sensor does not participate in the average calculation.

SENSORS	
Temp1	37.9°
Temp2	16.2°
Temp3	28.2°
E. Tmp1	28.8°
E. Tmp2	28.4°
Press.	23
Out T.	23.9°
Hum. In	58.7%
Hum. Out	61.9%
Weight	0.000
Weights	0

NOTE: Go to Table 3: Sensor Readings page 98, to view all the possible sensors.

2. Reports the current average temperature. This example is in Celsius, but yours may be in Fahrenheit.

AV. TEMP.
27.5°

3. Displays the output relay list. The filled black boxes indicate active outputs. Controller also informs the position of inlets and curtains, as well as the number of operating heaters or fans.


ACTIVE	
Heat	1
Heat. Hi	1
Tun. Fan	
Exh. Fan	
Stir	
Cool P.	
Fogger	
Curt. 1	100%
Curt. 2	100%
Curt. 3	0%
Curt. 4	0%

NOTE: Go to Table 4: Output List (Active), page 98 to view all the available readings (ACTIVE).

NOTE: The **ACTIVE** screen shows rectangular markers by the outputs. Filled rectangles indicate operating outputs; empty rectangles indicate outputs that are off.

4. Status Window provides important general information such as the time and ventilation mode.

EXAMPLE




NOTE: Go to Table 3: Sensor Readings, page 98 to view all the available readings.

5. Displays important messages/alarms. The title bar displays the number of important messages, and if there are several messages, they each appear in turn.

4 MESSAGES
(2) Low Feed At Bin 2

2.8 Main Menu icons

1. To enter the Main Menu screen, press **Menu**.
2. To select an option, press **Enter**.



2.9 Version history

The following section details the various versions of the Farm Premium Controllers mentioned in the manual.

Version 3.02 supports:

- CO2 Treatment (refer to CO2 treatment, page 23; CO2, page 71; Analog Sensors, page 93)

Version 3.03 supports:

- Light Sensor Support (refer to Light help | set definitions, page 47; Light Sensor Calibration, page 81;
- Setting the light table based on feed/no feed days (refer to Light, page 46)
- Four water meters (refer to Digital Sensors, page 94)

Version 4.03 supports:

- Based on Version 3.03
- Current Sense Relays (refer to Relay Current, page 61; Power Consumption, page 73; Current Sense Relay calibration, page 87)

Version 4.04 supports:

- Ventilation by Weight (refer to By Weight, page 26)

Version 4.05 supports:

- Four variable speed stir fans (refer to Stir Fan levels, page 38; Auger Empty Alarm, page 58)
- Feed calibration using Current Sense (refer to Feed Calibration, page 81; Feed, page 71)
- Four feed bins (refer to Feed Inventory, 55; Scale Layout, page 63; Feed, page 71; Feed Bin calibration, page 69)
- Four auger and feed lines (refer to Output function list, page 91)
- Four variable speed stir fan outputs (refer to Stir Fan levels, page 38; Analog Output, page 94)
- 3 x Stir fan program controlled by sensor differentials or independent (refer to Stir Fan Program help | set definitions version 4.05, page 39)
- Wind chill hotkey

Version 3.06/4.06 supports:

- Water on Demand (refer to Water on Demand, page 53)
- Variable Heat Control (refer to Variable heater help | set definitions, page 21)
- Two humidity sensors

NOTE: *Version 3.06* refers to Farm Premium Controllers equipped with an XA CPU. *Version 4.06* refers to Farm Premium Controllers equipped with an ARM CPU.

NOTE: *Only Farm Guard Versions 4.X (and higher) support the graphic view of historical data.*

3 Control menu

The following sections detail the following functions:

- Temperature curve, page 18
- Humidity treatment, page 22
- CO2 treatment, page 23
- Min/Max level, page 24
- Static Pressure, page 29
- Control Mode, page 31
- System Parameters, page 32

3.1 Temperature curve

From the Main Menu screen, select 'Control' → 1. TEMPERATURE CURVE.

CONTROL	
1. TEMPERATURE CURVE	
2. HUMIDITY TREATMENT	
3. CO2 TREATMENT	
4. MIN/MAX LEVEL	
5. STATIC PRESSURE	
6. CONTROL MODE	
7. SYSTEM PARAMETERS	

TEMPERATURE CURVE					
Day	Target	Heat	Tunnel	Alarm	
				Low	High
1	89.0	89.0	100.0	84.0	102.0
2	89.0	89.0	99.0	84.0	102.0
3	87.0	87.0	97.0	82.0	95.0
7	84.0	83.0	91.0	80.0	95.0
15	82.0	81.0	89.0	78.0	93.0
21	79.0	78.0	86.0	75.0	90.0
28	76.0	74.0	81.0	71.0	87.0
35	72.0	70.0	77.0	67.0	84.0
42	70.0	68.0	75.0	63.0	83.0
48	68.0	66.0	73.0	60.0	83.0


1. Define the required target temperature curve.

- **Day:** Sets growth day. You can program negative growth days up to -2 for pre-warming. To enter a negative growth day, type the day number followed by the +/- key.
- **Target:** Set the desired temperature.
- **Heat:** Set the temperature to stop heat.
- **Tunnel:** Set the temperature for Tunnel to begin.
Alarm Low & High: Set average temperature alarm limits. See [Manage | Alarm Settings](#) for zone alarm settings.

2. If required set the:

- Temperature curve help | set definitions, page 19
- Radiant heaters help | set definitions, page 20
- Variable heater help | set definitions, page 21

3.1.1 Temperature curve help | set definitions



- **Temperature Curve Offset:** Adjusts all temperature curves by this amount. You can use this to temporarily adjust all temperatures up or down for special circumstances. The curve appears in the [Status Window](#), and you can use the [ENTER and Up](#) or [ENTER and Down](#) hot key combinations to change the offset.
- **Set Temp. Change Reminder (Diff):** Sets the change in set temperature that triggers a reminder for you to set backup thermostats. Often producers forget to set backup thermostats as their birds grow from baby chicks to market age, so the Farm Premium reminds you. When you press Enter to acknowledge the reminder, the Farm Premium logs it in the Table of Events.
- **Target Temp. Band:** The size of the target temperature zone. This "Happy Zone" is between Target Temperature and (Target Temperature + Band).
- **Heater Temp. Band:** Heaters turn on at 'Band' degrees below Heat, and turn off at the Heat Temperature.

NOTE: Heaters operate at minimum level only; however, Radiant Heaters can operate at any temperature or level below Tunnel.

- **Cool Down Factor (%):** Minimum percentage correction towards target during each increase [ventilation level delay](#). If average temperature does not improve by this amount, the Farm Premium increases ventilation by one level.
- **Cool Down Fast Response (Deg.):** Set a limit to the maximum degrees per minute of cooling. If Average Temperature drops more than this in one minute, the Farm Premium decreases ventilation one level to avoid overshooting.

NOTE: Avoid making this parameter too small or the normal temperature variation caused by timer fans reduces the ventilation level.

- **Min Vent Below Heat Temp By:** Tells controller to go directly to Min Level in some cases. Select from the following choices:
 - None: Operate by the normal level decrease time delay rule.
 - Zone: Go directly to minimum level if any active temperature sensor reaches heat temperature.
 - Avg.: Go directly to minimum level if the average temperature reaches heat temperature.
- **Non Brood Area Diff. From Heat:** Set differential temperature for non-brood heaters. You normally use this to set temperatures in unoccupied areas.

NOTE: When set at -99 °F the heaters are effectively disabled, since it will probably never go to 99° F below the heater temperature. Putting this parameter at 0° sets the non-brood areas to the heater temperature.

3.1.2 Radiant heaters help | set definitions

SYSTEM PARAMETERS	
TEMPERATURE CURVE	
Temperature Curve Offset	0.0
Set Temp. Change Reminder (Diff)	3.0
Target Temp. Band	1.5
Heater Temp. Band	1.0
Cool Down Factor (%)	15
Cool Down Fast Response (Deg.)	3.0
Min Vent Below Heat Temp By: ►	ZONE
RADIANT HEATERS	
Rad. Low -Diff from Heat Set	0.0
Rad. High -Diff (Below Low Set)	1.0
Radiant Ignition Time (sec)	30

To configure the radiant heaters:

1. In *Installation > Relay Layout* define at least one relay as a radiant heater (Relay Layout, page 90).
2. Configure the following parameters:
 - **Radiant Low - Differential from Heat Set:** Set degree of difference from Heat for LOW Radiant Heaters to begin working. This differential can be positive or negative. (default: 2.0)
 - **Radiant High - Differential (Below Low Set):** Set number of degrees below Radiant Low Heaters for HIGH Radiant Heaters to begin working (default: 1.0). To ensure proper heater ignition, Radiant High Heaters remain on for the Radiant Ignition Time along with the Radiant Low Heaters.
 - **Radiant Ignition Time (sec):** Set number of seconds to power radiant ignition (default: 30).

NOTE: The Heater Temperature Band applies to radiant heaters as well. For example, if the Heat Temperature is 80° F and the Heater Temperature Band is 1° F, then heaters turn on at 79° F and off at 80° F. If the Radiant Low Differential is at 2.0° F, then radiant heaters turn off at 82° F, and on 1° F below that at 81° F. However, a Radiant High Heater turns on regardless of its temperature setting for the Radiant Ignition Time whenever the corresponding Radiant Low Heater turns on. This feature ensures proper flame ignition.




Figure 9: Radiant Heater Differentials

3.1.3 Variable heater help | set definitions

SYSTEM PARAMETERS	
Target Temp. Band	1.5
Heater Temp. Band	1.0
Cool Down Factor (%)	15
Cool Down Fast Response (Deg.)	3.0
Min Vent Below Heat Temp By:	▶ ZONE
RADIANT HEATERS	
Rad. Low –Diff from Heat Set	0.0
Rad. High –Diff (Below Low Set)	1.0
Radiant Ignition Time (sec)	30
VARIABLE HEATER	
Low Diff Below Heat Tmp.	0.5
High Diff Below Heat Tmp.	4.5

The Farm Premium Controller enables configuring up to eight variable heaters. The output of the heaters changes as the temperature increases or decreases.

To configure the variable heaters:

1. In *Installation > Analog Output* configure:
 - a. up to eight analog outputs as variable heaters
 - b. the minimum and maximum voltage output for each heater

ANALOG OUTPUT			
Out No.	Output Function	Min V.Out	Max V. Out
1	Var. Heater 1	1.0	10.0
2	Var. Heater 2	1.0	10.0
3	Var. Heater 3	1.0	10.0
4	Var. Heater 4	1.0	10.0
5	Var. Heater 5	1.0	10.0
6	Var. Heater 6	1.0	10.0
7	Var. Heater 7	1.0	10.0
8	Var. Heater 8	1.0	10.0

2. In *Control > Temperature Curve > Help*, scroll down to Variable Heater. Configure the
 - **Low Diff Below Heat Tmp**: Temperature at which the variable heater begins to function
 - **High Diff Below Heat Tmp**: Temperature at which the heater begins to operate at maximum output

Figure 9 illustrates how a variable heater functions. The Target Temperature is 89° F. The Low Diff Below Heat Tmp is 0.5°; the High Diff Below Heat Tmp is 4.5°.




Figure 10: Variable Heater Example

3.2 Humidity treatment


Humidity treatment forces an increase in ventilation level when the humidity is too high. It holds the increase for 'Duration Seconds', and checks back after 'Interval Minutes' for another increase. After the duration, the ventilation level comes back down automatically.

CONTROL			
1. TEMPERATURE CURVE			
2. HUMIDITY TREATMENT			
3. CO2 TREATMENT			
4. MIN/MAX LEVEL			
5. STATIC PRESSURE			
6. CONTROL MODE			
7. SYSTEM PARAMETERS			

HUMIDITY TREATMENT			
Day	Humidity	Delay (min.)	Duration Sec.
1	70	10	130
7	75	7	150
14	80	5	180
0	0	0	0
0	0	0	0
0	0	0	0
0	0	0	0
0	0	0	0
0	0	0	0

- **Day:** Growth day. Can set multiple programs for same day (Maximum number of programs: 20)
- **Humidity:** Humidity at which to begin treatment
- **Delay Minute:** Amount of time the controller pauses before ventilating
- **Duration Sec.:** Number of seconds the controller maintains the increased level of ventilation

3.2.1 Humidity treatment help | set definitions



- **Humidity Band (%)**: Hysteresis band for Humidity Treatment.
- **Humidity Treatment below Heat**: Select YES or NO for allowing Humidity Treatment when heaters are operating (set in [Control | Temperature curve](#)).

3.3 CO2 treatment

NOTE: Version 3.02 and higher supports this feature.

CO2 treatment forces an increase in ventilation level when the CO2 level is too high. It holds the increase for 'Delay Seconds', and checks back after 'Interval Minutes' for another increase. After the duration, the ventilation level may come back down automatically.

If during treatment, the CO2 level drops below the **Stop Value** parameter, the ventilation level automatically returns to that level used before CO2 treatment was initiated.


CONTROL	
1. TEMPERATURE CURVE	
2. HUMIDITY TREATMENT	
3. CO2 TREATMENT	
4. MIN/MAX LEVEL	
5. STATIC PRESSURE	
6. CONTROL MODE	
7. SYSTEM PARAMETERS	

CO2 TREATMENT				
Day	Start Value	Stop Value	Delay (Sec)	Duration Sec.
1	3000	2500	120	130
7	2700	2200	120	150
14	2500	2000	90	180
0	0	0	0	0
0	0	0	0	0
0	0	0	0	0
0	0	0	0	0
0	0	0	0	0
0	0	0	0	0
0	0	0	0	0

- **Day**: Growth day. Can set multiple programs for same day (Max. programs 20)
- **Start Value**: CO2 value at which to begin treatment
- **Stop Value**: CO2 value at which to end treatment
- **Delay (Sec)**: Number of seconds the controller pauses before ventilating

- **Duration (Sec):** Number of seconds the controller maintains the increased level of ventilation

3.3.1 CO2 treatment help | set definitions



- **CO2 Treatment below Heat:** Select YES or NO to enable CO2 treatment when heaters are operating (set in [Control | Temperature curve](#)).

SYSTEM PARAMETERS	
CO2 TREATMENT	
CO2 Treatment Below Heat	NO

3.4 Min/Max level

CONTROL
1. TEMPERATURE CURVE
2. HUMIDITY TREATMENT
3. CO2 TREATMENT
4. MIN/MAX LEVEL
5. STATIC PRESSURE
6. CONTROL MODE
7. SYSTEM PARAMETERS

IMPORTANT: Before setting Min/Max levels, go through and set up the Device Settings, especially the [ventilation levels](#). Once you have entered the ventilation levels, use Min/Max to select the range of levels to apply to your situation. Typically, you increase the minimum ventilation level as litter conditions deteriorate and the birds require greater amounts of fresh air. You can also restrict the maximum level to prevent excess airflow on young birds.

Use one of the following methods to set the Min/Max levels:

- By Day and By Soft Days curve
- By Time
- Day Soft Min.
- By Weight

Go to Control Mode, page 31 to select the method used.

3.4.1 By Day and By Soft Days curve

MIN/MAX LEVEL		
Day	Min	Max
1	1	16
3	2	16
6	3	16
10	4	16
14	5	21
21	6	21
35	7	21
0	0	0
0	0	0
0	0	0

- **Day:** Set growth day
- **Min:** Set minimum ventilation level for controller
- **Max:** Set maximum ventilation level for controller

NOTE: *BY DAYS CURVE* generates an incremental increase/decrease between the defined days whereas *BY DAYS* simply operates according to the min/max values of the day until the following day defined is reached.

3.4.2 By Time

MIN/MAX LEVEL		
From	Min	Max
06:00	1	6
10:00	4	8
13:00	6	12
18:00	8	15
21:00	1	3
00:00	0	0
00:00	0	0
00:00	0	0
00:00	0	0
00:00	0	0

- **From:** Set time of day (hh:mm) in 24 hour format
- **Min:** Set minimum ventilation level for controller
- **Max:** Set maximum ventilation level for controller


3.4.3 Day Soft Min.

SOFT MIN/MAX LEVEL			
Day	Min	Min Soft	Max
1	1	11	16
3	2	11	16
6	3	11	16
10	4	11	16
14	5	11	21
21	6	11	21
35	7	11	21
0	0	0	0
0	0	0	0
-	-	0	-

- **Day:** Set growth day
- **Min Soft:** Set minimum ventilation level for when temperature drops below heat temperature

- **Min:** Set minimum ventilation level for when temperature is above heat temperature
- **Max:** Set maximum ventilation level for controller

3.4.3.1 Soft Min/Max level help | set definitions



- **Differential Below Heat for Soft Min:** Set the degree of difference from heat temperature (set in [Control | Temperature curve](#)) to switch minimum level from **Min.** to **Soft Min.**
- **Temp Choice for Soft Min:** Select inside/outside/attic temperature to control Minimum Level changes. The minimum level adjusts towards the Soft Min as this temperature falls. Above the heat temperature, the minimum level is at the Min setting.

As temperature rises, **INSIDE** and **ATTIC** stay at lowest ventilation level reached until average temperature gets to the heat setting, and then changes instantly. With the **OUTSIDE** selection, the minimum ventilation level increases gradually as temperature rises to the heat setting. This means inside and attic soft min vent choices to latch to the lowest level reached as long as the temperature remains below the heat setting.

3.4.4 By Weight

The By Weight option enables controlling the minimum air flow depending on the number of birds, their weight and the current outside temperature. When using the Weight option, Farm Premium takes several parameters and calculates the air speed, level of ventilation and cycle time needed to supply the required volume. As opposed to the other ventilation methods, the Weight option is dynamic, with the ventilation changing according to the current parameters (quantity of air required, weight of birds and number of birds, outside air temperature). In addition, Ventilation By Weight sends out an alarm if the current ventilation is below the minimum required level.

NOTE: This option is available in Version 4.04 and higher.

To set up the Weight Option:

1. In the *Install > Setup* menu (page 89) enable Minimum Vent (Power).
2. In the *Install > Fan Air Capacity* menu, define the air capacity / hour (page 96).

3. In the *Scale > General Setting* menu, select the curve.
4. In the *Scale > Bird Curve* menu, define the growth days and weights as required.
5. In the *Control > Control Mode > Min. Max Level Control* menu, select **Weight**.
6. In the *Control > Min/Max Level* menu, set the parameters as required.

SOFT MIN/MAX LEVEL BY WEIGHT (OUT TEMP)				
Day	Min	Air Per Kg/Lb		Max Level
	Level	Cold	Warm	
1	1	0.5	1.5	16
3	1	0.5	1.5	16
6	1	0.5	1.5	16
10	4	1.1	1.7	16
12	4	1.1	1.7	21
15	7	1.1	1.7	21
17	7	1.1	1.7	21
19	7	1.1	1.7	21
21	7	1.1	1.7	21
35	7	0		22
0	0			22
0	0			0
0	0			0

- **Day:** Set growth day
- **Min Level:** Set the minimum level of ventilation (refer to Levels of ventilation, page 34)
- **Air Per Kg/Lb:** Volume of air per kilogram/pound per hour per bird.
- **Cold:** Volume of air supplied when the outside temperature goes down to the *Cold Temperature* parameter (see the following section).
- **Warm:** Volume of air supplied when the outside temperature reaches *Warm Temp. - Diff Below Heat* (see the following section).

NOTE: As the level rises between days (for example between day 6 and day 10 in the screen above), the air volume rises proportionally each day, once a day. For example, on Day 7, the Cold Air per Kg/Lb. rises to 0.65; on Day 8, 0.8 and so on.


- **Max Level:** Set the maximum level of ventilation (refer to Levels of ventilation, page 34).

7. In the *Management > Bird Inventory* menu, type the number of birds.

8. In the *Help* menu, define the parameters as required.

Ventilation by Weight is configured.

3.4.4.1 Min/Max Level By Weight help | set definitions



- **Warm Temp. – Diff Below Heat:** Differential below the heat temperature (refer to Temperature curve, page 18) that defines outside temperature as Warm in the Soft Min/Max table. For example, if the Heat Temperature is 78° F, Warm Temp. – Diff Below Heat is 2.0, then the outside temperature is defined as warm at 76° F.
- **Cold Temperature:** Outside temperature (or below) at which Air per Kilogram/Pound (Cold) capacity is reached.

When the outside temperature is between the Warm and Cold Temperature, the flow rate is calculated at a proportional rate.

- **Air Change:** As the temperature rises from the Cold Temperature parameter to the Heat Temperature (or drops from the Heat Temperature to the Cold Temperature parameter), the minimal air volume rises/falls proportionally. Air Change defines the minimal change in air temperature that must take place to cause a change in the air supply.
- **Fan Cycle Time:** The total amount of time that the fans operate while operating under Minimum Ventilation. During this time, the fans supply the required volume of air at the minimum ventilation level required. Farm Premium adjusts the minimum ON time and OFF time as needed. If the fans cannot supply the required volume at a particular level of ventilation, Farm Premium automatically adjusts the minimum ventilation level.
 - **Minimum ON Time in Vent Cycle:** The minimum amount of time that the fans operate during a cycle. Farm Premium adjusts the actual fan time as needed.
 - **Minimum OFF Time in Vent Cycle:** The minimum amount of time that the fans do not operate during a cycle. Farm Premium adjusts the actual fan time as needed.

As the temperature rises, the actual Minimum OFF Time decreases until it reaches the minimum time. Only then does the Minimum On Time begin to rise.

NOTE: If the temperature goes about the Band Temperature, Power Ventilation begins and times are adjusted accordingly.

3.4.4.2 Weight hot screen

Selecting the Ventilation by Weight option enables an additional Hot Screen, the Air Status Screen. This screen displays the critical parameters involved in the Ventilation by Weight option.

AIR STATUS				
Inside Temp		24.1		
Outside Temp		21.3		
Humidity		46.7%		
Weight KG		0.468		
		Current	Min	Max
Level		2	1	2
Cycle On		30	30	30
Cycle Off		98	134	66
Total Air	M3/h	8347	6552	11232
M3/h				
Air/WGT	M3h/kg	0.9	0.7	1.20

- **Inside Temperature:** Current temperature inside the house
- **Outside Temperature:** Current temperature outside the house
- **Humidity:** Current relative humidity inside the house (requires a humidity sensor)
- **Weight KG:** Current average weight of the Bird Curve (page 66)
- **Level:** Displays the current, minimum and maximum level of ventilation.

NOTE: If the current level is below the minimum required level, Farm Premium displays an alarm "Below Min Air".

- **Cycle On/Off:** Displays the current, minimum and maximum fan on and off times.
- **Total Air M3/h:** Displays the current, minimum and maximum quantity of ventilation, per hour.
- **Air/WGT:** Displays the current amount of ventilation, per kilo/pound of bird weight.

3.5 Static Pressure

Set target parameters for Static Pressure at High and Low Outside Temperatures, as well as alarms for high and low static pressure.

CONTROL
1. TEMPERATURE CURVE
2. HUMIDITY TREATMENT
3. CO2 TREATMENT
4. MIN/MAX LEVEL
5. STATIC PRESSURE
6. CONTROL MODE
7. SYSTEM PARAMETERS

STATIC PRESSURE	
Minimum Ventilation	
S.Press. At Low Temperature	0.120
S.Press. At High Temperature	0.080
Low Static Pressure Alarm	0.010
High Static Pressure Alarm	0.150
Static Pressure Band	0.040
Tunnel Ventilation	
Target Static Pressure	0.080
Low Static Pressure Alarm	0.010
High Static Pressure Alarm	0.150
Static Pressure Band	0.040
Attic	
Target Static Pressure	0.050

Minimum Ventilation

- **Static Pressure at Low Temp:** Set desired static pressure for low outside temperature conditions. Be sure that there is proper airflow at this setting.

- **Static Pressure at High Temp:** Set desired static pressure for high temperature conditions. Normally this pressure is lower to obtain a larger air inlet opening.

NOTE: *Controller interpolates between the LOW and HIGH Temp. If Static Pressure exists, then it is controlled by the outside temperature sensor, otherwise the average temperature.*

- **Low Static Pressure Alarm:** Set alarm for low static pressure. If you disable it by setting zero, the Farm Premium warns you and enters a record in the Table of Events.
- **High Static Pressure Alarm:** Set alarm for high static pressure.
- **Static Pressure Band:** Set desired band for the target pressure.

Tunnel Ventilation

- **Target Static Pressure:** Set required Static Pressure for Tunnel Ventilation Mode.
- **Low Static Pressure Alarm:** Set alarm for low static pressure.
- **High Static Pressure Alarm:** Set alarm for high static pressure.
- **Static Pressure Band:** Set required band for pressure in tunnel ventilation mode.

Attic

- **Target Static Pressure:** Set required Static Pressure when in attic mode.
- **Static Pressure Band:** Set required band for attic ventilation mode.

3.5.1 Disabling the Static Pressure Sensor

To disable the static pressure sensor:


1. Go to *Installation > Setup*.
2. Set the Static Pressure Unit to **None**.

The main screen stops:

- displaying the pressure
- displaying High Pressure and Pressure Sensor Failure alarms

NOTE: *If either of these alarms were active before disabling the sensor, the main screen continues to display the alarms. Reset the alarms one time to cease the display.*

3.5.2 Static Pressure help | set definitions



SYSTEM PARAMETERS	
STATIC PRESSURE	
Wind Gust Delay Time (sec)	10
S. Pressure During Tunnel ►	YES
Transitional Tunnel ►	NO
Minimum Ventilation Using ►	VENT
LOW Incoming Air (diff to Trg)	-25.0
HIGH Incoming Air (diff to Trg)	-10.0
Emergency S. Press. Delay (sec)	60
Curt. Pos. In Emerg. S. Press. %	100
Low S.P. Alarm Min. Level (MinV)	0
Low S.P. Alarm Min. Level (Tun.)	0
Time To Produce S. Pressure (sec)	10
Attic Advance Opening Time (sec)	0

- **Wind Gust Delay Time (sec):** Set length of time in seconds before starting Static Pressure control after an unexpected change in air pressure.
- **Static Pressure During Tunnel:** Select YES or NO for using Static Pressure control when in Tunnel mode.
- **Transitional Tunnel:** Select YES or NO for using tunnel curtains when static pressure is high and vents are already at 100%.
- **Minimum Ventilation Using (vent/curtain):** Select VENT or CURTAIN for controlling static pressure when in minimum ventilation.
- **LOW Incoming Air (Diff to Trigger):** Define low temperature for static pressure control.
- **HIGH Incoming Air (Diff to Trigger):** Define high temperature for static pressure control.
- **Emergency Static Pressure Delay (sec):** Set length of time in seconds before initiating an emergency opening when pressure exceeds high alarm setting.
- **Curtain Position in Emergency Static Pressure (%):** Set the desired curtain position (in percentage) when an emergency pressure event occurs.
- **Low Static Pressure Alarm Min. Level (MinV):** Below this level, the controller ignores low static pressure alarms.
- **Low Static Pressure Alarm Min. Level (Tun.):** Below this level, the controller ignores low static pressure alarms while in tunnel mode.
- **Time to Produce Static Pressure (sec):** Enter the length of time to reach target pressure when minimum ventilation fan cycle is on.
- **Attic Advance Opening Time (sec):** Define the amount of time for the attic inlets to open before minimum vent cycling fans turn on.

3.6 Control Mode

Select house-operating modes, turn temperature curves on or off and select which type of min/max CO2 level method to use.


CONTROL MODE	
Empty House Mode ►	HOUSE
Temperature Curve ►	NO
Min. Max. Level Control ►	BY DAYS
	BY DAYS
	CURVE

- **House Mode:** Select whether the house is in one of the brood set ups, or in full house.
- **Empty House Mode:** Select YES in order to disable alarms.

- **Temperature Curve:** If you select OFF, temperature settings become fixed values until midnight on the next setting in [Control | Temperature curve](#) (page 18).
- **Min. Max. Level Control:** Set ventilation control method (By Days, By Days Curve, By Time, By Soft Min, and Weight). Refer to Min/Max level, page 24 for more details).

3.7 System Parameters

System Parameters consolidates all of the **HELP | SET** menus into one screen.



System Parameters	Page	System Parameters	Page
Temperature curve help set	19	Cool Pad help set	43
Radiant heaters help set	20	Foggers help set	45
Humidity treatment help set	23	Light help set	47
Day Soft Min.	26	Feed Inventory help set	56
Disabling the Static Pressure Sensor	30	Emergency Setting help set	52
Levels of Ventilation help set	35	Alarm Setting help set	58
Vent & Curtain levels help set	37		

4 Device menu

The Farm Premium can have many closely spaced levels of ventilation enabling it to find the optimum average airflow for the poultry facility. Many of the levels are at exactly the same temperature setting, so there may be a question as to how the Farm Premium chooses the correct level.

The menus in this section apply levels to ventilation, variable speed fans, curtains and so on. The levels in the various menus are consistent with each other so that a level in one menu corresponds with that level in any other menu.

The rules that apply here are:

- **Rule 1:** If the temperature is at target (in the Happy Zone) stay at the current level.
- **Rule 2:** If the temperature moves outside the Happy Zone, have some patience.
- **Rule 3:** After some patience increase or decrease level appropriately.

You can find the 'patience' factors under [HELP | SET](#) in this menu. They are the increase level delay and decrease level delay parameters. The factory default values are 180 seconds for an increase and 60 seconds for a decrease. The factory default values biases the Farm Premium slightly toward warmer temperatures, as would be appropriate for young birds. The level increase delay is longer than the level decrease delay. You may wish to reverse these values by the time you have market age broilers, since they are more sensitive to heat stress than to cold.

Although many of the levels have 0.0 differential temperatures, certain levels should have differentials to account for wind chill on the birds. The first tunnel level accounts for wind chill by switching to the tunnel temperature instead of target temperature. Higher tunnel levels require an additional wind chill because of the increased airflow.

In addition, the last few levels before entering tunnel can form a transitional region. You may want to build differentials from target temperature just before the first tunnel level.

The controller obeys both the time delay rules and the differential temperature rules when changing levels. Tunnel exit has several additional rules, such as outside temperature restriction and the tunnel exit delay described under [HELP | SET](#). In addition, there are Cool Down and change to Min Vent on reaching the Heat temperature features described in [Control | Temperature Curve | HELP | Set](#) parameters.

The following sections detail the menu functions.

- Levels of ventilation, page 34
- Vent & Curtain levels, page 36
- Stir Fan program, page 39
- Foggers, page 44
- Water & Feed, page 49
- Emergency Setting, page 51
- Speed Fan levels, page 36
- Stir Fan levels, page 38
- Cool pad, page 43
- Light, page 46
- Extra Systems, page 50
- Water on Demand, page 53

4.1 Levels of ventilation

The Precision Ventilation table provides up to 30 ventilation levels. To program this table, start with the minimum ventilation used in the first level and increase ventilation gradually. A reasonable rule of thumb is to increase the airflow about 25% at each level. Increases in airflow up to 50% work satisfactorily with factory default settings.

DEVICE SETTING											
1. LEVELS OF VENTILATION											
2. SPEED FAN LEVELS											
3. VENT & CURTAIN LEVELS											
4. STIR FAN LEVELS											
5. STIR FAN PROGRAM											
6. COOL PAD											
7. FOGGERS											
8. LIGHT											
9. WATER & FEED											
10. EXTRA SYSTEMS											
11. EMERGENCY SETTING											
12. WATER ON DEMAND											

LEVELS OF VENTILATION											
No	Diff Deg.	On Sec	Exhaust 1 2 3			Tunnel 1 2 3 4 5 6 7 8 9 0					
1	0.0	30								
2	0.0	40								
3	0.0	50	◀▶	◀▶	◀▶					
4	0.0	65	◀▶	◀▶	◀▶					
5	0.0	80	◀▶	◀▶	◀▶					
6	0.0	100	◀▶	◀▶	◀▶					
7	0.0	125								
Air Capacity: 300			◆	-Continuous							
Chill Range: ---			◀▶	-Cycle							
			△	-Rotate							
						Tunnel Level: 11					

1. Ventilation Level: Read-only

2. Differential Temperature: Triggers next level according to difference from target temperature (time delays remain in effect).

The first several levels normally have differential temperature set to 0.

If the ventilation level is below tunnel, the differential temperature is relative to Target temperature given in [Control | Temperature curve](#).

If the ventilation level is a tunnel level, the differential temperature is relative to the Tunnel temperature given in [Control | Temperature curve](#).

3. Cycle timer ON: Set ON time for fans for that ventilation level.

4. Cycle timer OFF: Set OFF time for fans of that ventilation level. This parameter disappears if cycle time is set in the [HELP | SET](#) Parameters to something other than 0 and the controller calculates the "Cycle timer OFF" automatically.

5. Exhaust: Control exhaust fans according to **Continuous, Cycle, and Rotate**.

6. Tunnel: Control tunnel fans according to Continuous, Cycle, and Rotate.



Continuous: Works constantly without a break




Cycle: Operates according to ON/OFF timer



Rotate: Operates according to ON/OFF timer; in each cycle a different fan operates

4.1.1 Levels of Ventilation help | set definitions



- **Maximum Levels of Ventilation:** Set the maximum number of levels.
- **First Tunnel Level:** Entry point to tunnel mode.
- **Max Fans, Switch to Tunnel:** Maximum number of fans allowed to operate when entering tunnel mode.
- **Tunnel Exit – Differential Below Tunnel:** Set degree of difference below Tunnel temperature (set in [Control | Temperature curve](#)) to Exit Tunnel mode.
- **Tunnel Exit – Outside Differential from Tunnel:** The outside temperature must read below this (Tunnel + Differential) to allow exiting from tunnel mode.
- **Increase Level Delay Time (sec):** Set length of time in seconds before transitioning to next level.
- **Decrease Level Delay Time (sec):** Set length of time in seconds before transitioning to lower level.
- **Fan Cycle Time (sec):** If set to 0, set on and off times for each level manually. If you are using a fixed cycle time, such as 300 seconds, enter it here and enter only the **On** time at each level. Default: 0
- **Tunnel Exit Delay (minutes):** Set length of time in minutes before exiting Tunnel mode. This time begins once all other parameters are satisfied.

4.2 Speed Fan levels

DEVICE SETTING	
1. LEVELS OF VENTILATION	
2. SPEED FAN LEVELS	
3. VENT & CURTAIN LEVELS	
4. STIR FAN LEVELS	
5. STIR FAN PROGRAM	
6. COOL PAD	
7. FOGGERS	
8. LIGHT	
9. WATER & FEED	
10. EXTRA SYSTEMS	
11. EMERGENCY SETTING	
12. WATER ON DEMAND	

VARIABLE SPEED FAN LEVEL				
Level	-1-	-2-	-3-	-4-
1	30	30	30	30
2	45	30	30	30
3	30	30	45	5
4	45	45	45	30
5	45	60	45	60
6	60	60	60	60
7	60	75	60	75
8	75	75	75	75
9	90	90	90	90

In the Variable Speed Fan Level table you can set the speed in percentages for up to four groups of fans by level. Configure them in [Install | Analog Output](#).

This function requires an Analog Output card in the controller. This card sends a low voltage control signal to a Variable Speed controller to run the variable speed fan. Several kinds of speed controllers are available, such as TRIAC Control, and Variable Frequency 3 Phase drives.

4.3 Vent & Curtain levels

Set the curtain levels to correspond with the ventilation levels.

DEVICE SETTING	
1. LEVELS OF VENTILATION	
2. SPEED FAN LEVELS	
3. VENT & CURTAIN LEVELS	
4. STIR FAN LEVELS	
5. STIR FAN PROGRAM	
6. COOL PAD	
7. FOGGERS	
8. LIGHT	
9. WATER & FEED	
10. EXTRA SYSTEMS	
11. EMERGENCY SETTING	
12. WATER ON DEMAND	


VENT & CURTAIN LEVELS		
Level	Tunnel	Vent
1	0	15
2	0	15
3	0	15
4	0	15
5	0	15
6	0	15
7	0	15
8	0	15
9	0	15
10	0	15

1. Ventilation Level: Read-only.

2. Minimum Position (%) Tunnel Ventilation: Set position for the tunnel curtain by level. If you have Static Pressure in Tunnel turned on ([Control | Static Pressure | Help | Set](#)), this becomes the minimum position for the tunnel inlet.

3. Minimum Position (%) Side Vents: This is the minimum opening for the Side Vents level-by-level while in Min Vent mode and while either exhaust or tunnel fans are operating. The Farm Premium ignores this parameter in Tunnel Ventilation.

4.3.1 Vent & Curtain levels help | set definitions



SYSTEM PARAMETERS	
CURTAINS	
Num. Steps For Curtain to Calib	99
Stop Fans, Curt. Move (total %)	30
1st Day for 2nd Vent to Oper.	-2
1st Level for 2nd Vent to Oper	1
Num. Steps for Vent to Calib.	99
Calibrate at Power Up ▶	YES
ATTIC	
Operate Until Day	10
Operate Until Level	10
Operate From Time	0:00
Operate To Time	0:00
Max Temperature to Disable Attic	100.0

Curtains

- **Num. of Steps for Curtain to Calibrate:** Set calibration point for curtain after desired amount of curtain opening/closing (steps). During calibration, if the curtain is open more than 50% it opens to 100%, calibrates, and returns to the previous position. If the curtain is open less than 50% it closes to 0%, calibrates, and returns to the previous position. Default: 99.
- **Stop Fans, Curtain Move (total %):** Commands controller to stop fans during curtain movements when total of all curtains is less than the total percent set in this parameter. For example, 3 curtains at 40% each total 120% for this parameter. Default: 30%
- **1st Day for 2nd Vent to Operate:** Set the day the second vent begins operating. Default: 1.

NOTE: You can set negative days.

- **1st Level for 2nd Vent to Operate:** Set the level the second vent begins operating. Default: 1
- **Num. Steps for Vent to Calibrate:** Set calibration point for vent after desired amount of opening/closing (steps). During calibration, vent opens to 100%. Default: 99.
- **Calibrate at Power Up:** This parameter instructs the Farm Premium to perform automatic calibration of air inlets when recovering from a power outage. In many installations the backup system, such as Munters' RBU-27, may have opened the air sources. When the Farm Premium takes over control again, the air inlets are incorrectly positioned. The calibration at power up feature synchronizes the actual position and the controller.

Attic

- **Minimum Attic Temp. To Operate:** Set the minimum temperature to activate the Attic operation.
- **Operate Until Day:** Set the last day for attic operation.
- **Operate From/To Time:** Set the time frame for attic operation.

NOTE: If one of the above options is relevant, the Attic is enabled.

- **Max Temperature to Disable Attic:** Set the maximum attic temperature to stop using attic ventilation. This setting can prevent the heating effect in the growing space being too high resulting in overheating.

4.4 Stir Fan levels

DEVICE

1. LEVELS OF VENTILATION
2. SPEED FAN LEVELS
3. VENT & CURTAIN LEVELS
- 4. STIR FAN LEVELS**
5. STIR FAN PROGRAM
6. COOL PAD
7. FOGGERS
8. LIGHT
9. WATER & FEED
10. EXTRA SYSTEMS
11. EMERGENCY SETTING
12. WATER ON DEMAND

STIR FAN LEVELS

Level	Var. Fan				Stir Fan No.			
	1	2	3	4	1	2	3	4
1	50	60	50		◄	◊	◄	◊
2	70	80	70	80	◄	◊	◄	◊
3	70	80	70	80	◄	◊	◄	◊
4	70	80	70	80	◄	◊	◄	◊
5	100	100	100	100	◄	◊	◄	◊
6	100	100	100	100	◄	◊	◄	◊
7	100	100	100	100	◄	◊	◄	◊
8	0	0	0	0	◄	◊	◄	◊
9	0	0	0	0	◄	◊	◄	◊

◆-Continuous ◄-Cycle On ◊-Cycle Off

In the Stir Fan Level table set the speed in percentage that you want the variable speed fan to work at (by levels). For each level, program the stir fans' cycle. Configure the actual speed in Analog Output, page 94.

1. **Ventilation Level:** Read only.
2. **Speed Fan-1, 2, 3, 4:** Set variable speed fan operation in percentages.
3. **Stir Fan:** Control stir fans according to Continuous, Cycle On, Cycle Off (ventilation cycles are the same as previously set in [Levels of Ventilation](#)).

- ◆ Continuous: Constantly works without a break.
- ◄ Cycle: Operates according to ON/OFF timer.
- ◊ Rotate: Operates according to ON/OFF timer; in each cycle a different fan operates

NOTE: The Stir Fans operate according to the levels you program in this menu, and according to the programs you select in the Stir Fan Program. The fan turns on if any program or level requests ON; all programs and levels must be OFF for the Stir Fan to be off.

NOTE: Version 4.05 and higher supports four variable speed fans. Previous versions support two fans.

4.5 Stir Fan program

This section contains five different programs that you can assign to each stir fan. Check the programs applying to each fan by using the '+/-' key (further explained in [STIR FAN PROGRAM HELP | SET](#)).


NOTE: If the same variable stir fan is selected for different programs, the program having the highest fan speed operates.

DEVICE SETTING
1. LEVELS OF VENTILATION
2. SPEED FAN LEVELS
3. VENT & CURTAIN LEVELS
4. STIR FAN LEVELS
5. STIR FAN PROGRAM
6. COOL PAD
7. FOGGERS
8. LIGHT
9. WATER & FEED
10. EXTRA SYSTEMS
11. EMERGENCY SETTING
12. WATER ON DEMAND

STIR FAN PROGRAM					
Fan No.	-A-	-B-	-C-	-D-	-E-
1	✓	✓	■	■	■
2	✓	■	✓	■	✓
3	■	✓	✓	✓	■
4	■	■	✓	✓	✓
5	■	■	■	■	■
6	■	■	■	■	■
7	■	■	■	■	■
8	■	■	■	■	■
ACTIVE	■	□	□	□	□

- **A (heaters):** This program corrects temperature variations lengthwise in the building. Insert diff and sensor numbers.
- **B (for min vent):** This program helps mixing minimum ventilation air for buildings having stir fans to mix the air coming in with warm inside air
- **C, D & E (sensors diff temperature):** These options create three stir fan groups which operate according to sensor differentials.

4.5.1 Stir Fan Program help | set definitions version 4.05 and above



SYSTEM PARAMETERS	
PROGRAM A (for min vent)	
Operate After End of Cycle: ►	ON
Delay for Operation (sec) (+/-)	0
Time for Operation (sec)	0
From Level	0
To Level	0
From Time (hh:mm)	00:00
To Time (hh:mm)	00:00
PROGRAM B (sensors diff temp)	
Temp Diff to Operate	2.0
Diff Between Sensor Number	0
Diff Between Sensor Number	0
Cycle On Time (sec)	0

Program A (for Heaters)

- **Diff below Target to Operate:** Set the degree of difference below the target temperature for stir fans to operate.
- **Cycle On time (sec):** Define the length of time in seconds you would like the stir fan to operate during the cycle.
- **Cycle Off time (sec):** Define the length of time in seconds you would like the stir fan to be off during the cycle.
- **From/To Level:** Limit the program to operate between the levels defined.
- **From/To Time:** Define the time frame for the program to operate (24-hour format).
- **Stop During Fan Operation:** Select **YES** run the heaters when the fans are operating.

Program B (for Min Vent)

- **Operate after End of Cycle:** Set when stir fan begins operating. It can be at the end of the ON cycle or the OFF cycle set in the [DEVICE | Levels of Ventilation](#).
- **Delay for Operation (sec) (+/-):** Define length of time in seconds from the end or start of cycle you chose in **Operate after end of cycle** above, for the stir fans to operate.
- **Time for Operation (sec):** Define length of time in seconds for the stir fans to operate.
- **From/To Level:** Limit the program to operate between the levels defined.
- **From/To Time:** Define the time frame for the program to operate (24-hour format).

Program C, D, E (Sensors Diff Temp or Independent)

- **Temp Diff to Operate:** Set the degree of difference between sensors for stir fans to begin operating.

NOTE: If this parameter is set to 0 (zero), the variable stir fan runs independently of the sensors.

- **Diff between Sensor Number:** Select a sensor to define one temperature reading.
- **Diff between Sensor Number:** Select a second sensor to define a temperature reading from a different area.
- **Cycle On time (sec):** Define the length of time in seconds you would like the stir fan to operate during the cycle.
- **Cycle Off time (sec):** Define the length of time in seconds you would like the stir fan to be off during the cycle.
- **From/To Level:** Limit the program to operate between the levels defined.
- **From/To Time:** Define the time frame for the program to operate (24-hour format).
- **Stop During Fan Operation:** Select **YES** run the heaters when the fans are operating.
- **Variable Stir Fan:** Select the stir fan to be used
- **Min/Max Variable Stir Fan Speed:** Enter the minimum and maximum speed (in percentage).

4.5.2 Stir Fan Program help | set definitions Version 4.03 and below


Program A (for Minimum Ventilation)

- **Operate after End of Cycle:** Set when stir fan begins operating. It can be at the end of the ON cycle or the OFF cycle set in the [DEVICE | Levels of Ventilation](#).
- **Delay for Operation (sec) (+/-):** Define length of time in seconds from the end or start of cycle you chose in **Operate after end of cycle** above, for the stir fans to operate.
- **Time for Operation (sec):** Define length of time in seconds for the stir fans to operate.
- **From/To Level:** Limit the program to operate between the levels defined.
- **From/To Time:** Define the time frame for the program to operate (24-hour format).


NOTE: See the examples below. They show how the various delays work with respect to the minimum ventilation fan timers defined in [DEVICE | Levels of Ventilation](#).

Example 1 of Program A

SYSTEM PARAMETERS	
PROGRAM A (for min vent)	
Operate After End of Cycle: ►	ON
Delay for Operation (sec) (+/-)	5
Time for Operation (sec)	20
From Level	0
To Level	0
From Time (hh:mm)	00:00
To Time (hh:mm)	00:00
PROGRAM A (sensors diff temp)	
Temp Diff to Operate	2.0
Diff Between Sensor Number	0
Diff Between Sensor Number	0
Cycle On Time (sec)	0



Example 2 of Program A



Program B (Sensors Different Temperature)

- Temp Diff to Operate: Set the degree of difference between sensors for stir fans to begin operating.
- Diff between Sensor Number: Select a sensor to define one temperature reading.
- Diff between Sensor Number: Select a second sensor to define a temperature reading from a different area.
- Cycle On time (sec): Define the length of time in seconds you would like the stir fan to operate during the cycle.
- Cycle Off time (sec): Define the length of time in seconds you would like the stir fan to be off during the cycle.

NOTE: The other parameters are explained in the program above.

Program C (for Heaters)

- Diff below Target to Operate: Set the degree of difference below the target temperature for stir fans to operate.

NOTE: Additional parameters are the same as in Programs A & B, explained above.

Program D & E (Independent)

Programs D and E enable you to set the desired cycle, level range, and time range for the stir fans to operate. They do not rely on ventilation cycles or temperature readings, thus making them independent.

4.6 Cool pad


This menu sets the operating conditions for Cool Pad.

DEVICE SETTING	
1. LEVELS OF VENTILATION	
2. SPEED FAN LEVELS	
3. VENT & CURTAIN LEVELS	
4. STIR FAN LEVELS	
5. STIR FAN PROGRAM	
6. COOL PAD	
7. FOGGERS	
8. LIGHT	
9. WATER & FEED	
10. EXTRA SYSTEMS	
11. EMERGENCY SETTING	
12. WATER ON DEMAND	

COOL PAD						
Day	Start Time	End Time	Tunnel Diff	To Hum	On sec	Off sec
1	10:00	21:00	3.0	99	15	285
7	10:00	21:00	3.0	99	15	285
7	10:00	21:00	5.0	99	45	255
14	10:00	21:00	2.0	99	15	285
14	10:00	21:00	3.0	99	30	270
14	10:00	21:00	4.0	99	45	255
14	10:00	21:00	5.0	99	60	240
14	10:00	21:00	6.0	99	75	225
14	10:00	21:00	7.0	99	100	200
14	10:00	21:00	8.0	99	200	100

- **Day:** Set growth day.
- **Start Time:** The cool pad begins operating.
- **End Time:** The cool pad ceases to operate.
 - It is possible to set multiple start and stop times for a single day.
 - In the screen above, growth day jumps from day 7 to day 14, the cool pad continues to work according to day 7 settings from growth day 7 through growth day 14.
- **Tunnel Differential:** Set difference from tunnel temperature to use this setting. You can use negative differential temperatures.
 - Note the settings for Day 14. The Farm Premium uses the maximum temperature differential that applies to choose the correct settings.
- **To Humidity:** Set maximum humidity allowed before stopping cool pad. You can enter 100%.
- **On Sec:** Set the maximum on time for each cycle of cool pad operation.
- **Off Sec:** Set the minimum off time for each cycle of cool pad operation.

4.6.1 Cool Pad help | set definitions



SYSTEM PARAMETERS	
COOL PAD	
Temperature Band	2.0
Humidity Band (%)	2.0
Flush Cool Pad At:	00:00
Cool Pad Flush Duration (minute)	0
Diff Between Cool Pads Stage	0.0
Min Level to Enable Operation	1

- **Temperature Band:** Define the on/off hysteresis relative to temperature.
- **Humidity Band (%):** Define the on/off hysteresis relative to humidity.
- **Flush Cool Pad At:** Set time of day (hh:mm) to start a continuous application of water to the cool cells in order clean them of deposits.
- **Cool Pad Flush Duration (minutes):** Set the length of time in minutes for flushing. If parameter is set, flush is applied without regard to ventilation level or operating mode.
- **Diff Between Cool Pads Stage:** If cool pads are defined on the same sensor or average, then the following cool pads begin operating after the previous, but only after the difference set in this parameter.
- **Min Level to Enable Operation:** Select the minimum ventilation level to operate the cool cells. This does not apply to the flush functions.

Example: Cool Pad ON temperature = 80°, Diff set to 2° F:

Cool Pad #	Assigned Sensor	Diff Between Cool Pads Stage	Actual ON temperature
1	Average	0.0	80°
2	Average	2.0	82°
3	Temp Sensor 2	0.0	80°
4	Temp Sensor 2	2.0	82°

4.7 Foggers

This menu sets the operating conditions for the Foggers. The main difference between the Fogger Menu and the Cool Pad Menu is the different temperature reference point. The Fogger Temperature Differentials are relative to the target temperature instead of the tunnel entry temperature.


DEVICE SETTING
1. LEVELS OF VENTILATION
2. SPEED FAN LEVELS
3. VENT & CURTAIN LEVELS
4. STIR FAN LEVELS
5. STIR FAN PROGRAM
6. COOL PAD
7. FOGGERS
8. LIGHT
9. WATER & FEED
10. EXTRA SYSTEMS
11. EMERGENCY SETTING

FOGGERS						
Day	Start Time	End Time	Target Diff	To Hum	On sec	Off sec
47	12:00	21:00	18.0	99	300	600
47	12:00	21:00	20.0	99	300	300
0	00:00	00:00	0.0	0	0	0
0	00:00	00:00	0.0	0	0	0
0	00:00	00:00	0.0	0	0	0
0	00:00	00:00	0.0	0	0	0
0	00:00	00:00	0.0	0	0	0
0	00:00	00:00	0.0	0	0	0
0	00:00	00:00	0.0	0	0	0
0	00:00	00:00	0.0	0	0	0

- **Day:** Set growth day

- **Start Time & End Time:** Time of day you want foggers to start and stop.
 - It is possible to set multiple start and stop times for single day.
 - In the screen above, the first programmed line is at day 47. The foggers do not operate before growth day 47 in this case. Since there are no entries other than day 47, the day 47 program lines apply from then on.
- **Target Differential:** Set difference from target temperature to trigger foggers.
- **To Humidity:** Set maximum humidity allowed before stopping foggers.
- **On Sec:** Set the maximum on time for each cycle of fogger operation.
- **Off Sec:** Set the minimum off time for each cycle of fogger operation.


4.7.1 Foggers help | set definitions



- **Temperature Band:** Define the on/off hysteresis relative to temperature.
- **Humidity Band (%):** Define the on/off hysteresis relative to humidity.
- **Min Level to Enable Operation:** Select the minimum ventilation level to operate the foggers.
- **Max Level to Enable Operation:** Set the maximum ventilation level for fogger operation.

4.8 Light

This menu sets the operating conditions for lights. The controller has a capacity for up to four channels of *On/Off Lights* and up to four channels of *Dimmer Lights*.



Day	Time	LIGHT			Intensity (%)	
		1	2	3	1	2
1	00:00	✓	✓	■	100	0
12	00:00	✓	■	✓	45	45
12	01:00	■	■	■	0	0
12	03:00	✓	■	✓	45	45
12	21:00	■	■	■	0	0
25	00:00	■	■	■	0	0
25	03:00	■	■	■	35	35
25	20:00	■	■	■	0	0
25	23:00	■	■	■	35	35
0	00:00	■	■	■	0	0

NOTE: Version 3.03 and higher support setting the light table based on feed days.

The configuration of this menu is dependent on the Water and Feed help | set definitions (page 49) configuration:

- If you select Daily, the above screen appears when you select Light; configure the Light menu once.
- If you select 2 – 6 Days or Week, the screen below appears.




1. Select Feed and press **Enter**. The Light parameters screen appears. These parameters configure the Light functions on feed days.
2. Configure the parameters.
3. Select No Feed and press **Enter**. The Light parameters screen appears. These parameters configure the Light functions on non-feed days.
4. Configure the parameters.
 - **Day:** Set Growth Day

In the example, the brood lights (channel 1) and bright center lights (channel 2) turn on from day 1, while the grow end lights (channel 3) are off. The example shows two channels of light dimmer, Channel 1 at 100% and Channel 2 at 0% (for baby chicks in the brood zone).

- **Time:** Set event times for the lights.
 - On day 12, the center lights turn off, and the dimmer lights go to 45%. There are two periods of darkness: from 01:00 to 03:00 in the morning, and 09:00 PM to midnight. This program repeats until day 25.
 - From day 25 the on/off lights stay off, and the dimmer lights provide dim light during the on periods, and go out fully for two periods of darkness. The dark periods total 6 hours, being from midnight to 03:00 AM and from 08:00 PM (20:00) to 11:00 PM (23:00).
- **Light:** Check mark the desired light(s) you would like to turn on. Apply dots for lights you would like to turn off. Switch between check marks and dots by pressing the +/- key.
- **Intensity (%):** Set intensity in percentage for light dimmer(s). Dimmer lights start to brighten if the intensity increases, and complete dimming if the intensity decreases at the set time. That is, they start dimming the 'sunset time' in advance of the set time (see **Help | Set** below).

4.8.1 Light help | set definitions



- **Sunrise Time (minutes):** The amount of time required for the light intensity to rise from 0% to the designated level.
- **Sunset Time (minutes):** The amount of time required for the light intensity to decline from the designated level to 0%.
- **Allow Spiking from Day:** The day spiking begins.
- **Spike Cycle (minutes):** The time length that the spike is at its maximum level. Reaching the maximum level and returning to the preset level both take one minute. For example if the spike duration is 10 minutes, the spike cycle is 8 minutes.
- **Spike Durations (minutes):** The total amount of time of the spike cycle, including the rise and fall times.
- **Spike Increase Amount:** Set the increase in intensity for the spike in relation to the current light intensity.
- **Signal Light Is:** Only one light operates during feeding times. Select which light is lit or choose "None".

NOTE: After the feeding period ends, all lights selected in the Light Parameters screen relight.


- **Signal Before Feed (seconds):** Amount of time, before the feeding starts, that all other lights go off.
- **Signal During Feed (seconds):** Amount of time that the selected light remains on after feeding ends.

NOTE: The above two parameters are disabled on no feed days.


- **Light Sensor Active:** The light sensor turns off all lights when sufficient outside lights exists (refer to Light Sensor Calibration, page 81). If a light sensor is installed, enable this option to turn off the light during feeding time when there is sufficient outside light.

NOTE: The above parameter is only available in Version 3.03 and higher.

4.8.1.1 Lighting without spiking



4.8.1.2 Lighting with spiking



NOTE: The initial reference time for the Spike Cycle is the end of Sunrise. The spike begins Spike Duration minutes before the end of the Spike Cycle, and has one minute up and down ramps in intensity. If Sunrise Duration is set to zero, no spiking occurs.

4.9 Water & Feed

This menu sets the operating conditions for water and feed devices.

DEVICE
1. LEVELS OF VENTILATION
2. SPEED FAN LEVELS
3. VENT & CURTAIN LEVELS
4. STIR FAN LEVELS
5. STIR FAN PROGRAM
6. COOL PAD
7. FOGGERS
8. LIGHT
9. WATER & FEED
10. EXTRA SYSTEMS
11. EMERGENCY SETTING
12. WATER ON DEMAND

WATER & FEED					
Day	Time hh:mm	Water		Feeder	
		1	2	1	2
1	00:00	✓	■	✓	■
12	10:00	✓	✓	✓	✓
25	14:00	✓	✓	✓	✓
46	00:00	✓	✓	■	■
48	00:00	■	■	■	■
0	00:00	■	■	■	■
0	00:00	■	■	■	■
0	00:00	■	■	■	■
0	00:00	■	■	■	■
0	00:00	■	■	■	■

- **Day:** Set growth day.
- **Time:** Set event times for water, feeder, or auger. Check marks indicate ON at the event time, and dots indicate OFF. Toggle between check marks and dots with the +/- keys.
- **Water:** Select a check mark to mark water lines to turn on, dot the ones to turn off.
- **Feeder:** Check mark feed lines to turn on, dot the ones to turn off.
- **Auger:** Check mark auger lines to turn on, dot the ones to turn off.

NOTE: You can implement mealtime, clean up meals and other options similarly as shown earlier in the light programs.

4.9.1 Water and Feed help | set definitions

These parameters define the feed and water delivery schedule through the week.

NOTE: The Water and Feed parameters work in conjunction with the Lighting parameters.

- **Daily:** Same schedule for every day of the week.
- **2 - 6 Days:** Select a cycle that lasts the number of days chosen and then repeats itself. For example, 2 Days means that the cycle lasts two days and then repeats itself.

SYSTEM PARAMETERS			
WATER & FEEDS		2 DAYS	
Feed Day Cycle			
DAYS CYCLE			
Day:	1	2	
Feed:	✓		
WATER ON NO FEED DAYS			
Start	Stop	Start	Stop
10:00	10:30	11:30	12:30

- **Week:** Select which days in the week that feed and water are delivered.

SYSTEM PARAMETERS							
WATER & FEEDS							WEEK
Feed Day Cycle							
DAYS CYCLE							
Day:	SUN	MON	TUE	WED	THU	FRI	SAT
Feed:	✓		✓	✓		✓	
WATER ON NO FEED DAYS							
Start	Stop		Start		Stop		
10:00	10:30		11:30		12:30		

NOTE: If you choose *Daily*, the Scale function is always enabled. If you choose *2- 6 Days* or *Week*, the Scale function is **disabled** on non-feeding days.

NOTE: If you want to provide feed every day, select *Daily*. Selecting *Week* and marking each day, causes problems with this function.

If you select the 2 – 6 Day schedule or the Week schedule, configure:

- **Days Cycle (2 – 6 Days):** Select which days in the cycle that feed and water is delivered.
- **Week Cycle:** Select the days that feed and water is delivered.
- **Water on No Feed Days:** Select up to two time periods when water is delivered on non-feed days.

NOTE: On feed days, water is delivered when feed is delivered.

4.10 Extra Systems

This menu is for setting the parameters of the other devices that are not listed in the controller.

DEVICE
1. LEVELS OF VENTILATION
2. SPEED FAN LEVELS
3. VENT & CURTAIN LEVELS
4. STIR FAN LEVELS
5. STIR FAN PROGRAM
6. COOL PAD
7. FOGGERS
8. LIGHT
9. WATER & FEED
10. EXTRA SYSTEMS
11. EMERGENCY SETTING
12. WATER ON DEMAND

EXTRA SYSTEMS				
System	1	2	3	4
Start Time	10:30	06:15	14:20	00:00
End Time	18:45	20:30	03:15	00:00
From Temp	75.5	85.5	60	0.0
To Temp	93.0	95.5	98.0	0.0
From Hum.	55	60	60	0
To Hum.	85	85	85	0
On (sec)	45	45	300	0
Off (sec)	300	300	2000	0

- **Start Time:** Time at which this Extra System starts.
- **End Time:** Time at which this Extra System stops.
- **From Temp:** Temperature above which Extra System operates.
- **To Temp:** Temperature below which Extra System operates.
- **From Humidity:** Humidity above which Extra System operates
- **To Humidity:** Humidity below which Extra System operates.
- **On (sec):** On time for the Extra System. If set to 0, the extra system does not operate.

- **Off (sec):** Off time for Extra System after completion of on time. If you have values in both **ON** and **Off**, the extra system cycles. If you have zero OFF time, and any ON time, the system simply stays on as long as the other parameters are satisfied.

NOTE: All parameters must be satisfied for an Extra System to operate. If the temperature is below the From Temperature or the Humidity below the From Humidity for example, the system is OFF. You can assign specific temperature sensors to an Extra System in [Install | Temp Definition](#). The Extra System uses the Inside Humidity, not the Outside Humidity. If there is no humidity sensor, the Extra Systems ignore the humidity parameters.

4.11 Emergency Setting


This selection applies to optional emergency cards. These cards are battery backed, and operate as standard switch and relay cards during normal operation. If an emergency occurs, the cards continue to operate according to their emergency settings.

DEVICE
1. LEVELS OF VENTILATION
2. SPEED FAN LEVELS
3. VENT & CURTAIN LEVELS
4. STIR FAN LEVELS
5. STIR FAN PROGRAM
6. COOL PAD
7. FOGGERS
8. LIGHT
9. WATER & FEED
10. EXTRA SYSTEMS
11. EMERGENCY SETTING
12. WATER ON DEMAND

EMERGENCY SETTING				
Relay	Function	Diff	Day	Operate
31	Heat 4	-5.0	10	Min
32	Exh. Fan 1	0.0	20	Vent
33	Tun. Fan 6	2.0	30	Temp.
34	Tun. Fan 7	4.0	0	Temp.
35	Tun. Fan 8	6.0		Temp.

- 1. Relay:** The Farm Premium determines the relay numbers automatically from the position in the controller in which the Emergency Switch card is installed.
- 2. Function:** Assign the relay function in [Install | Relay Layout](#). Your selections will likely be different from the example above. The Farm Premium does not allow certain selections for the emergency functions.
- 3. Differential:** The difference from target temperature at which the device operates during emergency operation.
- 4. Day:** After this day, the device operates continuously without regard to temperature setting during emergency operation. In this example:
 - Exhaust Fan 1 operates up to the target temperature using the Min Vent timer calculated in [Help | Set](#) on the next page, and continuously above the target temperature. However, from Growth Day 10 forward, the fan operates continuously without regard to temperature.
 - Tunnel Fan 6 is off below 2.0° + Target, and operates continuously if the temperature is more than 2.0° above Target Temperature. However, if the Growth Day is 20 or greater, Tunnel Fan 6 operates continuously without regard to temperature during emergency conditions.
- 5. Operate:** Choose whether the Min Vent timer applies to this device or only the temperature differential.

4.11.1 Emergency Setting help | set definitions



SYSTEM PARAMETERS	
EMERGENCY SETTING	
Diff Above Target For Emergency	15.0
Diff Below Target For Emergency	-10.0
Min. Vent On Time Day 1 (sec)	30
Min. Vent Off Time Day 1 (sec)	270
Min. Vent On Time Day 21 (sec)	300
Min. Vent Off Time Day 21 (sec)	0
Delay Time to Start Fans (sec)	30

- **Diff Above Target for Emergency:** Set a value above temperature target at which the emergency card enters emergency operation.
- **Diff Below Target for Emergency:** Set a value below temperature target at which the emergency card enters emergency operation.
- **Min. Vent on Time Day 1 (sec):** Set the minimum ventilation on time for 1-day-old birds in this parameter. The card calculates on times between days 1 to 21.
- **Min. Vent off Time Day 1 (sec):** Set the off time for minimum ventilation cycle timer during emergency for growth day 1
- **Min. Vent on Time Day 21 (sec):** Set the on time for minimum ventilation for three-week old birds.
- **Min. Vent off Time Day 21 (sec):** Set the off time for minimum ventilation cycle timer during emergency for growth day 21.
- **Delay Time to Start Fans (sec):** Set a delay time for the card to wait upon entering emergency before starting fans. This delay gives air inlet devices time to pre-position before turn on and build static pressure. Otherwise, the static pressure could cause air inlet curtains to stick to wire mesh barriers.

4.12 Water on Demand

The Water On Demand (WOD) function enables regulating the pressure of all nipple lines in the house from one central point, ensuring uniform pressure in all lines. The function also enables immediate transitioning between different preset pressures of all nipple lines in the house by closing and opening of valves at the central point (manual or solenoid according to the mode installed).

DEVICE
1. LEVELS OF VENTILATION
2. SPEED FAN LEVELS
3. VENT & CURTAIN LEVELS
4. STIR FAN LEVELS
5. STIR FAN PROGRAM
6. COOL PAD
7. FOGGERS
8. LIGHT
9. WATER & FEED
10. EXTRA SYSTEMS
11. EMERGENCY SETTING
12. WATER ON DEMAND

EMERGENCY SETTING			
Day	From Time hh:mm	To Time hh:mm	WOD
1	12:00	14:00	1
2	12:00	14:00	2
3	12:00	14:00	3
5	12:00	14:00	3
7	12:00	14:00	4
9	12:00	14:00	4

1. In *Installation > Relay Layout* designate up to four relays as WOD valves (relays 179 to 182). Refer to *Relay Layout*, page 90 for details.

2. In *Device > Water on Demand*, configure the following parameters:

- **Day:** Specifies the day to activate the selected WOD valve
- **From Time/To Time:** Specifies the time to activate and deactivate the specified WOD valve
- **WOD:** Specifies the WOD valve to be activated

NOTE: You can specify up to 50 time periods.

NOTE: Versions 3.06 and 4.06 and higher support the WOD function.

5 Manage menu

The following sections detail the Management menu.

- Bird Inventory, page 54
- Feed Inventory, page 55
- Time & Date, page 56
- Growth Day & Flock, page 56
- Alarm Setting, page 57
- Alarm Reset, page 60
- Fail Safe Setting, page 60
- Password, page 61
- Relay Current, page 61

5.1 Bird Inventory

Maintain your bird inventory by entering data into the controller.

MANAGEMENT
1. BIRD INVENTORY
2. FEED INVENTORY
3. TIME & DATE
4. GROWTH DAY & FLOCK
5. ALARM SETTING
6. ALARM RESET
7. FAIL SAFE SETTING
8. PASSWORD
9. RELAY CURRENT

BIRD INVENTORY			
	Male	Female	Total
Add Dead Birds	0	0	0
Add Culled	0	0	0
Birds Moved	0	0	0
Birds Placed	10000	5000	15000
Today's Dead Birds	35	33	68
Today's Culled	12	10	22
Total Dead Birds	35	33	68
Total Culled	12	10	22
Total Birds Moved	1020	510	1530
Bird Count	8933	4447	13380

- Maintain bird inventory by entering quantities in the upper half of the screen. There are separate columns for male and female. If you do not wish to keep separate data, simply enter the data into one or the other.
- Initially, enter the number of birds **placed**. Thereafter, enter the quantity found **dead**, **culled** (Add Culled) or **moved** as needed. The Farm Premium shows totals and subtotals in the lower portion of the screen.
- You can correct an error, so long as you correct it on the same day before midnight, by entering a negative quantity (press the +/- key after the number) to subtract the error. After midnight, the information transfers to the [History](#) Menu.

5.2 Feed Inventory

Maintain your feed inventory by entering data into the controller.

MANAGEMENT	
1. BIRD INVENTORY	
2. FEED INVENTORY	
3. TIME & DATE	
4. GROWTH DAY & FLOCK	
5. ALARM SETTING	
6. ALARM RESET	
7. FAIL SAFE SETTING	
8. PASSWORD	
9. RELAY CURRENT	

FEED INVENTORY					
No.	Date	1	2	3	4
1	2-Jan-12	7800	0	0	0
2	5-Jan-12	0	900	15000	10000
3	13-Jan-12	8000	0	0	0
4	- -	0	0	0	0
5	- -	0	0	0	0
6	- -	0	0	0	0
7	- -	0	0	0	0
8	- -	0	0	0	0
Total Feed:		15800	900	150000	10000
ACTIVE		√	0	√	√

To enter feed inventory manually:


1. Type the day of the month and press **ENTER**.
2. Select the month and press **ENTER**.
3. Type the two-digit year and press **ENTER**.
4. Enter the feed quantity under the Feed Bins and press **ENTER**. The cumulative total appears in the **Total Feed** row.
5. To delete an entry, change the quantity to zero for all feed bins and press **ENTER**. Exit the menu and the entry disappears when you enter the menu again.

NOTE: Version 4.05 and higher supports four feed bins. Previous versions support two bins.

If you have installed load cells and connected feed bin scales to your Farm Premium, it automatically maintains feed inventory, including delivery dates and feed consumption data. You can monitor your fill system and maintain approximate feed inventory using the [Digital Inputs](#). In this case, you need to enter your own delivery dates.

This information transfers to the [History | Water & Feed](#) menus daily, and optionally as often as selected (by the minute) in History View.

5.2.1 Feed Inventory help | set definitions



SYSTEM PARAMETERS	
FEED INVENTORY	
Total Feed In Bin-1	0
Total Feed In Bin-2	0
Total Feed In Bin-3	0
Total Feed In Bin-4	0
Active Feed Bin	F.BIN1

- **Total Feed in Bin-1/Bin-2/Bin-3/Bin-4:** Manually change or correct the amount of feed in the bins.
- **Active Feed Bin:** Select the desired feed bin for use. It is possible to select both.

5.3 Time & Date

This menu sets the current time and date for the controller.

TIME & DATE	
Current Time	09:19
Date	10-Mar-08
Day of the Week	SUNDAY

- **Current Time:** Enter the current time in 24 hour format.
- **Date:** Enter the date in day-month-year format.
- **Day of the Week:** Select the day of the week from the drop down menu.

5.4 Growth Day & Flock

This menu defines the number of growth days and flock number.

Growth Day & Group	
Current Growth Day	27
Group No.	1
New Group	NO

- **Current Growth Day:** Enter current growth day, if necessary. It is possible to enter negative growth days up to -2. If you reset the growth day for a new flock using this tool, your old history data does not clear. Use New Flock function to clear out old history in preparation for new birds.
- **Flock No.:** The controller automatically increments the flock number each time you choose New Flock. You can edit the flock number. Since this field accepts six digits, some producers enter a flock number that is made of the day, month and year the birds arrived.
- **New Flock:** Use the new flock function on arrival of a new set of birds to set the growth day back to 1, 0, -1, or -2, and to clear out old history data.

5.5 Alarm Setting

This menu defines the various alarm settings.

MANAGEMENT

1. BIRD INVENTORY
2. FEED INVENTORY
3. TIME & DATE
4. GROWTH DAY & GROUP
5. ALARM SETTING
6. ALARM RESET
7. FAIL SAFE SETTING
8. PASSWORD
9. RELAY CURRENT

ALARM SETTING	
Global Alarm Delay (sec)	1
Alarm Reminder (min., 0-Disable)	30
SENSOR ALARM	
Sensor Low Temp. Range	32.0
Sensor High Temp. Range	122.0
Sensor Alarm-Diff From Lo. Alarm	1.0
Sensor Alarm-Diff From Hi. Alarm	1.0
ALARM	
Alarm Test At Time: (hh:mm)	12:00
Day Of Alarm Test: ▶	DAILY
Alarm Test Duration (sec)	0
AUGER OVERTIME ALARM	
Auger Overtime Delay (minute)	15

NOTE: *See Fail Safe Setting.*

- **Global Alarm Delay (sec):** Alarms without a separate alarm delay, use this global delay before signaling the alarm.
- **Alarm Reminder (min., 0-Disable):** Set a reminder after a period of time in minutes if the situation has not yet been corrected.

Sensor Alarm

- **Sensor Low Temperature Range:** Sets the minimum reading a sensor can have to be considered a valid sensor reading. Sensor readings below this are rejected. This generates a sensor out of range alarm. This does not apply to the special Circuit Breaker Sensor or Outside Temperature Sensor.
- **Sensor High Temperature Range:** Sets the maximum reading a sensor may have to be considered a valid sensor reading. Sensor readings above this reading are rejected. This generates a sensor out of range alarm. This does not apply to the special Circuit Breaker Sensor or Outside Temperature Sensor.
- **Sensor Alarm-Differential from Low Alarm:** Individual sensor (or zone) alarm if any active sensor reads this much or more below the [Control | Temperature Curve | Low Alarm Temperature](#).
- **Sensor Alarm-Differential from High Alarm:** Individual active growth area sensors alarm if they read this much or more above the [Control | Temperature Curve | High Alarm Temperature](#).

Alarm

- **Alarm Test at Time:** Schedule an alarm test at a particular time.
- **Day of Alarm Test:** Choose **Daily** or a particular **day** of the week for the scheduled alarm.
- **Alarm Test Duration (sec):** Choose a specific duration for the Alarm Test.

Auger Overtime Alarm

- **Auger Overtime Delay:** Set the maximum auger run time for your cross fill system. If you have a monitor connected to the digital inputs programmed as Feeder-1 Overtime or Feeder-2 Overtime the Farm Premium sends an alarm after this delay.
- **Feeder Off During Overtime:** Choose whether to shut the feed systems off after a feeder overtime alarm. Options:
 - **No:** All augers and feeders remain on.
 - **All:** All augers and feeders shut down.
 - **Related:** Only the specific auger from which the alarm originated and its feeders shut down.


NOTE: If you choose **All** or **Related**, the feed system turns off and does not resume until you [Reset Alarm](#) in the Management Menu.

Auger Empty Alarm

- **Condition Detection Delay (sec.):** Farm Premium sends an alarm when the current goes to the level set in the following parameter after this delay.
- **Below Nominal Current:** Send an alarm when the nominal current drops to the level set here.

NOTE: Version 4.05 and above supports the Auger Empty Alarm. This alarm is operative only if 1) Current Sense Relays are installed and calibrated 2) augers have been calibrated.

5.5.1 Alarm Setting help | set definitions



- **Advanced Alarms:** When selecting YES, the following additional alarms appear on the ALARM SETTINGS screen (press MENU and then ENTER to reenter the screen):

Feed Alarms

- **Allow Feed Alarm From/To:** Set a starting time from which the controller can send feed shortage alarms.
- **Bin 1/2 Low Feed Alarm Limit:** Alarm if feed in Bin 1/2 is below this limit and time is between From and To limits.

NOTE: Version 4.05 and higher supports up to four feed bins.

Water Overflow Alarms

- **According to Light Table:** Change overflow alarm level when the lights are off.
- **First Day:** Overflow on the FIRST day applies to the first day operation. You can define a first day at which to start increasing the overflow limit automatically. Days prior to the 'First Day' use the First Day overflow limit; days following the first day have an incremental curve toward the LAST DAY OVERFLOW parameter setting.
- **Overflow on First Day:** Number of gallons/liters per minute that generate an overflow alarm on the first day.
- **Last Day:** Set the last day for the Overflow curve.
- **Overflow on Last Day:** Overflow (Gallons/Liters) on the last day sets the maximum overflow limit will be continued after that day.
- **Overflow At Dark:** Select overflow limit. When it is dark, controller checks every minute.
- **Overflow Alarm Delay:** Define delay time before the controller generates an overflow alarm.
- **Extra Delay At Light Start:** When the first light appears, define the amount of minutes before the controller begins to operate according to the set Overflow for that day.
- **Fogger Water Overflow:** Define the water overflow for foggers (per minute).

Water Shortage Alarms

- **Allow Water Shortage Alarm From/To:** Set the period for which the controller generates water shortage alarms.
- **Shortage During Lights Off:** Select whether water shortage alarm should be disabled when all lights are out.
- **Quantity for Shortage:** Minimum flow rate that must be maintained or a water shortage alarm is generated.
- **Shortage Alarm Delay:** Minimum period of time that the shortage must extend through before generating an alarm.

Bird Scales Alarms

- **Allow Bird Scale Alarms From/To:** Set time frame for which the controller begins and ends generating alarms for the bird scale.

Auxiliary Alarms


- Assign auxiliary alarms in the Install menu. Note that digital sensors, auxiliary alarm input with related relay must always match their relay status.
- Related Relay For Aux Alarm 1/2/3/4: Relay for Auxiliary Alarm 1/2/3/4.
- **AUX. Alarm Delay (sec):** Separate from the **Global Alarm Delay**. If there is a dry contact, the alarm is sent after the defined **AUX. Alarm Delay**.

Circuit Breaker Alarm

- **Temperature for Circuit Breaker Alarm:** Set circuit breaker alarm temperature.

5.6 Alarm Reset

This menu functions as an alarm and siren reset.




- Alarm Reset:
 - **NO:** Does not reset alarms
 - **SIREN ONLY:** Resets only the siren, alarms remain
 - **YES:** Resets alarms

Selecting **YES:**

- Clears the alarm relay for all current alarms. The alarms may remain valid, but the unit does not register new alarms. If a new alarm occurs, or an existing alarm clears and reoccurs, the alarm relay signals again (after any appropriate delay).
- Restores normal operation after an emergency pressure or feed overrun incident. If the controller experiences a high-pressure alarm for too long, it enters emergency pressure operation by opening all known air sources. Curtains open to preset amounts as set in Control | Static Pressure. If you select **SIREN ONLY**, the alarm relay returns to the no alarm condition, but the emergency pressure status continues.
- Restores normal operation after a feed overrun situation that calls for turning off the feeding system. If the feed monitor senses the cross auger runs too long, it trips a feed overrun alarm and optionally turns off the feed system. If you select **SIREN ONLY**, the alarm relay returns to the no alarm condition, but the feed overrun status continues.

5.7 Fail Safe Setting

When there is a problem such as extremely high air temperature, the Fail-Safe function immediately activates a backup system (for example the Farm Alarm System) to ensure that adequate ventilation continues.



The Farm Premium has six options besides controller failure or power off to activate the fail-safe relay. Apply the additional settings by using the '+/-' key:

- **High/Low Temperature:** Select to trigger fail-safe when the temperature is exceptionally high/low.
- **Low/High Static Pressure:** Select to trigger fail-safe when the static pressure is exceptionally low/high.
- **Avg. Temperature Fail:** Select to trigger fail-safe when all sensors in house fail.
- **AUX:** Select to trigger fail-safe when auxiliary dry contact occurs.

5.8 Password

PASSWORD	
Owner Password	----
User-1 Password	----
User-2 Password	----
User-3 Password	----
User-4 Password	----
User-5 Password	----
Visitor Password	----

The owner can set new passwords for himself, all users and the Visitor. The owner cannot see user passwords once entered or changed by the users. The users can access the controller and make changes to all controller settings and their own password. A user can only see and change his own password. The visitor can access the controller, but cannot make changes. Each time someone accesses the controller with a password, an event is recorded in the [History | Table of Events](#).

NOTE: *If your controller uses passwords, the controller also requires a password entry to acknowledge switch position changes. If the switch change is not acknowledged the controller signals an alarm.*

5.9 Relay Current

NOTE: *Version 4.03 and higher supports the Relay Current feature. The Relay Current feature supports **single phase electricity** only.*

This menu configures the relay current sense parameters. You can configure:

- the minimum and maximum amperage flowing to the relays
- the relay current alarm
- voltage type

NOTE: *Configuring the amperage is not required. The Farm Premium controller automatically configures default settings.*

MANAGEMENT
1. BIRD INVENTORY
2. FEED INVENTORY
3. TIME & DATE
4. GROWTH DAY & GROUP
5. ALARM SETTING
6. ALARM RESET
7. FAIL SAFE SETTING
8. PASSWORD
9. RELAY CURRENT

RELAY CURRENT SETTING						
Rly.	Function	Min	Nom	Max	Alr	Vlt
31	Heat 6	2.7	3.8	5.0	NO	110
32	Heat 7	2.7	3.8	5.0	NO	110
33	Heat 8	3.0	3.8	5.6	NO	110
34	Exh. Fan 5	2.7	4.3	5.0	NO	110
35	Exh. Fan 6	2.3	3.8	5.0	NO	110
36	Tun. Fan 1	3.0	4.3	5.6	NO	110
37	Tun. Fan 2	0.0	0.0	0.0	NO	110
38	Tun. Fan 3	0.0	0.0	0.0	NO	110

NOTE: Calibrate the relay before configuring these parameters. Refer to Current Sense Relay calibration, page 87. Relays that are not calibrated (or if the relay is not a Current Sense relay) do not display amperage readings (see relays 37 and 38 in the above figure).

To configure the relay current:

1. Using the arrow buttons, select a minimum or maximum amperage setting.
2. Configure the parameter as required.

NOTE: The minimum amperage must be greater than the default minimum and the maximum amperage must be less than the default maximum. For example, relay 35's amperage must be more than 2.3 and less than 5.0 amps.

The Nom amperage is the parameter set when calibrating the relay (refer to page 87).

3. Configure the alarm:

- No: Alarms are not sent in the event of low or high current
- Yes: Alarms are sent in the event of low or high current
- No at zero: The controller sends an alarm if the current is low or high, but not if power is cut off entirely.

4. Configure the voltage: Select 110 or 220 volts.

NOTE: All relays' minimum/maximum current settings per equipment type must be within 30% (\pm) of the nominal value. However, the augers minimum can go down to 0.0 amperes.


6 Scale menu

The following sections detail the weighing functions.

- Scale Layout, page 63
- General Settings, page 64
- Bird Scale Setting, page 65
- Feed Bin Setting, page 65
- Bird Curve, page 66
- History, page 67
- Feed Conversion, page 67
- Test, page 68
- Calibration, page 68

6.1 Scale Layout

Use Scale Layout to define the scales or feed bins connected to the controller.




Define weighing device attached to each channel of the scale option card. It is possible to program either bird scale and/or feed bin (silo) scale.

NOTE: Version 4.05 and higher supports up to four feed bins. Previous versions support up to two bins.


6.2 General Settings

This menu sets general weighing parameters.



- **Bird Scale Mode:** Select the weighing method:
 - **SEXED:** Considers all birds to be the same sex or 'unisex' as in mixed broilers. It computes its own reference weight or acceptable range from the weighed birds.
 - **MIXED:** Considers the flock to be mixed males and females, with the goal of identifying each bird weight as male or female, which is, classifying it according to a pre-programmed pair of expected weight curves.
- **Uniformity Range (5-30%):** Controller classifies bird weights within this percentage of the average as uniform. Default is 10%.
- **Curve Selector (for mixed):** There are three standard pairs of pre-programmed weight curves. If you use the mixed weighing method, edit the curves to match your expected growth profile (**BROILER**, **TURKEY**, or **BREEDER**).


6.2.1 General Settings Help | set definitions



- **Factory Default Curve:** Select **YES** to return bird curves to the factory default settings

6.3 Bird Scale Setting

There are two different weighing options available; the option can be selected in the previous section [Scale | General Settings](#).




- **Start Time:** Set the hour you would like the scale to begin weighing
 - **End Time:** Set the hour you would like the scale to stop weighing
 - **Range - (0-100%):** Band above and below reference weight
 - **Reference Weight 1:** Starting out weight for scale 1
 - **Reference Weight 2:** Starting out weight for scale 2
- **Start Time:** Set the hour you would like the scale to begin weighing
 - **End Time:** Set the hour you would like the scale to stop weighing
 - **Range - (0-100%):** Band above and below reference weight

6.4 Feed Bin Setting

These settings help you monitor your feed bin through weighing. There are two events that take place, emptying (feeding) and filling (loading).

NOTE: Feed Bins must be defined in *Scale Layout* for the following parameters to be functional.



- **Minimum Emptying Weight** (Default: 20 Kg): Define the accumulated emptying weight from the bin during feeding time for it to be recorded as an event. Once it has been recorded, the counter resets.
- **Minimum Filling Weight** (Default: 2000 Kg): Define weight required to be filled during loading to be recorded in **History – Feed**; **History – History View**; **Scale – Feed Conversion**
- **Filling Detection Weight** (Default: 300 Kg): Define the weight you want your controller to detect a filling in order to stop augers.
- **Resume Time (minute)** (Default: 5 min.): Once loading is completed, define the time you want your controller to count down for the augurs to resume normal operation.

The following is a typical scenario that will help in understanding how to define the Feed Bin Settings:

A loading truck will come to fill the bin. Define the **Filling Detection Weight** to stop the augers from operating during a loading event (Default: 300 Kg). Next, a **Minimum Filling Weight** needs to be defined in order to have the filling event recorded in the **Feed Inventory** (Default: 2000 Kg). Once the loading of the feed is finished, the timer begins to count down for the augers to resume normal operation (**Resume Time**, Default: 5 minutes) and for the filling event to be recorded as completed. Define the **Minimum Emptying Weight** for the feeding event to be recorded in the following three locations:

1. **History – Feed**
2. **History – History View**
3. **Scale – Feed Conversion**

6.5 Bird Curve

This screen displays data according to growth day for **BROILERS**, **TURKEYS**, or **BREEDERS**, previously set in [Scale | General Settings](#).

SCALE	
1. SCALE LAYOUT	
2. GENERAL SETTINGS	
3. BIRD SCALE SETTING	
4. FEED BIN SETTING	
5. BIRD CURVE	
6. HISTORY	
7. FEED CONVERSION	
8. TEST	
9. CALIBRATION	

BIRD CURVE		
Day	Female Weight	Male Weight
1	0.11	0.13
7	0.31	0.35
14	0.66	0.70
21	1.26	1.54
28	2.07	2.73
35	3.15	4.27
42	4.45	6.15
49	5.95	8.22
Now	1.87	2.44

Edit the growth days and weights for the bird curves to fit individual preference.

6.6 History

The scale history shows bird weight statistics. You can review daily data for each scale, or separately. The unit records up to two-bird scale data; if you have more than one scale-1 or one scale-2, their data is combined.

SCALE					
1. SCALE LAYOUT					
2. GENERAL SETTINGS					
3. BIRD SCALE SETTING					
4. FEED BIN SETTING					
5. BIRD CURVE					
6. HISTORY					
7. FEED CONVERSION					
8. TEST					
9. CALIBRATION					

HISTORY					
Day	Avg.	NO.	S.D.	Unif.	C.V
17	0.000	0	0.000	0	0
18	0.000	0	0.000	0	0
19	0.000	0	0.000	0	0
20	0.000	0	0.000	0	0
21	0.000	0	0.000	0	0
22	0.000	0	0.000	0	0
23	0.000	0	0.000	0	0
24	0.159	1	0.000	100	0
25	0.000	0	0.000	0	0
26	0.000	0	0.000	0	0

- If you selected **SEXED** weighing, the history includes average data for the combined scales, and on the next screens separate data for each scale.
- If you select **MIXED** weighing, the history includes average data for all birds, and separate male and female data for Scale 1 and for Scale 2.
 - Use the arrow keys to scroll to the separated scale data, or up and down for data that is off screen.
 - The average and the number of weights are the usual definition. The Standard Deviation is the usual biased estimator (see a suitable textbook on statistical measurements). The Uniformity is the industry standard 10% uniformity (number of birds per 100 within 10% of the average weight), and the Coefficient of Variation or C.V. is the normalized standard deviation (standard deviation divided by average times 100 %.)

6.7 Feed Conversion

This screen displays the amount of feed converted into the bird's weight.

SCALE			
1. SCALE LAYOUT			
2. GENERAL SETTINGS			
3. BIRD SCALE SETTING			
4. FEED BIN SETTING			
5. BIRD CURVE			
6. HISTORY			
7. FEED CONVERSION			
8. TEST			
9. CALIBRATION			

FEED CONVERSION			
Day	Bird Weight	Daily Feed	Feed Conversion
17	0.00	0	N/A
18	0.00	0	N/A
19	0.00	0	N/A
20	0.00	0	N/A
21	0.00	0	N/A
22	0.00	0	N/A
23	0.00	0	N/A
24	0.16	0	0.00
25	0.00	0	N/A
26	0.00	0	N/A

6.8 Test

This section is a real time table to show the statuses of all scales connected to the controller.

SCALE				
1. SCALE LAYOUT				
2. GENERAL SETTINGS				
3. BIRD SCALE SETTING				
4. FEED BIN SETTING				
5. BIRD CURVE				
6. HISTORY				
7. FEED CONVERSION				
8. TEST				
9. CALIBRATION				

TEST				
	- 1 -	- 2 -	- 3 -	- 4 -
Type	Scale 1	Scale 2	Scale 3	Scale 4
A/D	2024	2010	1891	1893
Weight	0.222	35.768	0.000	0.000
Status	O.K.	O.K.	O.K.	O.K.

Make sure that all statuses are **O.K.** If any of them show a different status, the scale is not installed properly. Unused positions can also show **O.K.**

6.9 Calibration


This menu calibrates the scales connected to the controller.

SCALE	
1. SCALE LAYOUT	
2. GENERAL SETTINGS	
3. BIRD SCALE SETTING	
4. FEED BIN SETTING	
5. BIRD CURVE	
6. HISTORY	
7. FEED CONVERSION	
8. TEST	
9. CALIBRATION	

CAUTION Do not use scales while calibrating.


6.9.1 Scale calibration

1. Follow instructions on the bottom section of the screen.
2. Wait until the progress bar displayed shows 100%.
3. Place a known weight on the scale and enter its weight.
4. Wait until the calibration progress bar reaches 100%.
5. Ensure **"Good Calibration."**



6.9.2 Feed Bin calibration

1. Follow instructions on the bottom section of the screens.
2. Wait until the progress bar displayed shows 100%.
3. Place a known weight or start filling the feed bin.
4. Wait until the calibration progress bar reaches 100%.
5. Ensure "Good Calibration."



7 History menu

In the History Menu you can view data regarding:

- Temperature
- Humidity
- CO2
- Water
- Feed
- Mortality
- Heaters
- Radiant Heaters
- Alarms
- Table of Events
- History View
- Power Consumption

7.1 Temperature

The temperature history menu stores minimum, average and maximum temperatures by growth day. The average is weighted, so if most of the day has been warm the average is closer to the maximum than the minimum.



7.2 Humidity

The humidity history menu stores minimum, average and maximum inside humidity by growth day. The average is weighted, so if most of the day has been humid the average is closer to the maximum than the minimum.

NOTE: *In Version 3.06/4.06, if two humidity sensors are installed, this screen displays their average. The History View display shows reading of both sensors only if they have been selected for logging.*

7.3 CO2

The CO2 history menu stores minimum, average and maximum inside CO2 levels by growth day. The average is weighed, therefore if most of the day has been high CO2 levels the average is closer to the maximum than the minimum.

NOTE: *Versions 3.02 and higher support this feature.*

7.4 Water

The water menu records daily water consumption and shows the daily differential change from the previous day in percent. You must have the water monitor digital inputs connected. You can monitor up to two drinking water meters, total drinking water, total water, cool pad, fogger and cold pad flush consumption.

7.5 Feed

The feed menu records daily feed consumption and shows the daily differential change from the previous day in percent for two feed bins/fill systems. You must have a feed silo weighing system installed for the feed system, or monitor the auger system.

NOTE: *Versions 4.05 and higher support four feed bins. Previous versions support two bins.*

The feed data can be based on one of the following inputs. If more than one input is installed, priority is according to the order of the bulleted list.

- **Feed Bin:** If feed bins (load cells) are installed, feed consumption data of each bin is based on the feed bin weight.
- **Current Sense:** If Current Sense Relays for Augers are installed and calibrated (refer to Current Sense Relay calibration, page 87), feed consumption data of each auger is based on the current sense, calculation method settings, and actual auger run-time. The run-time is calculated based on the measured current, when the actual current is higher than the nominal value (refer to Relay Current, page 61).
- **Feed Count:** If a feed count sensor is installed feed consumption for each feed count input is based on the feed count method settings (refer to Digital Sensors, page 94).

7.6 Mortality

The mortality history menu maintains daily summaries of mortality, cull and total dead. It also shows the percentage dead and gives an updated count of bird inventory. The history is maintained separately for male, female and total. Use the left and right arrow keys to switch to the next screen.

7.7 Heaters

The Farm Premium maintains daily total run times of each heater. The table fills several screens; to view the off screen data, use the arrow keys to scroll. The data is in hours: minutes format.

7.8 Radiant Heaters

The Farm Premium maintains daily total run times of each radiant heater, including separate data for low level and high-level heaters. The table fills several screens; to view the off screen data, use the arrow keys to scroll. The data is in hours: minutes format.

7.9 Alarms

The alarm history records the growth day and time of each alarm. Alarms that are currently active show up as flashing on the screen. Alarm history is not reset when using *Management, Growth Date & Flock > New Flock*. The last 250 alarms are saved, and as the table is filled, new alarms push out the older alarms.

7.10 Table of Events

The Farm Premium records significant events with growth day and time stamp. The Table of Events is 1000 events long and is not reset when using *Management, Growth Date & Flock > New Flock*. New events push out the older events.

Typical events recorded are switch changes, entry into tunnel mode, natural or minimum ventilation, alarm resets, ventilation mode changes and more. The Table of Events is an excellent tool to determine whether your controller is going in and out of tunnel due to marginal settings as well as finding and identifying problems

NOTE: Go to the Table 6, page 99 to view all the available events.

7.11 History View

The History View menu has detailed history on a variety of sensors and data. Go to *Help > Set* under History View to select the particular data to collect.

Go to *Install > Setup > History Resolution* to set the frequency of your data collection. You can collect data as frequently as by the minute or only on a daily basis. Factory default collects one-hour data on a selection from the choices below.

- Under **Help | Graph** you can select a variety of graphs of the detailed history.
- In the **HISTORY VIEW | HELP | SET** menu, set the desired choice by using the '+/-'.

The options are as follows:

- Target Temp.
- House Temperature
 - Minimum, Average and Maximum
- Temp - 1-9
 - Minimum, Average and Maximum
- Attic Sensor
 - Minimum, Average and Maximum
- Outside Temperature
 - Minimum, Average and Maximum
- Humidity In/Out

- Minimum, Average and Maximum
- Water Consumption
- Feed Consumption
- Level of Ventilation

NOTE: *Altering choices erases old data and starts a fresh data set.*

7.12 Power Consumption

This menu displays the daily power consumption (in kWh) of the heaters, fans, lights and other equipment and the change from the previous day.

NOTE: *Current sense relays are required for this function to be enabled.*

NOTE: *Versions 4.03 and higher support this feature. The Relay Current feature supports **single phase electricity only**.*


8 Test menu

The Test Menu screen shows internal information in order to verify that the Farm Premium is operating correctly. Moreover, it can help find broken wires or any other problems related to it.

- Switches & Relays, page 74
- Switches & Relays Extension, page 75
- Alarm, page 75
- Analog Sensors, page 75
- Digital Sensors, page 76
- Analog Output, page 76
- Static Pressure, page 76
- Communication, page 77
- Hardware Checklist, page 77
- Emergency Status, page 77

8.1 Switches & Relays

This menu displays a screen of identified switches and relays installed in the controller. Use this option to determine faulty hardware.



SWITCHES & RELAYS									
01	02	03	04	05	06	07	08	09	10
Aut	Aut	Aut	Aut	Aut	Aut	Aut	Aut	Aut	Aut
11	12	13	14	15	16	17	18	19	20
Off	Off	Aut	Aut	Aut	Aut	Aut	Aut	Aut	Aut
21	22	23	24	25	26	27	28	29	30
Aut	Aut	Aut	Aut	Aut	Aut	Aut	Aut	Aut	Aut
31	32	33	34	35	36	37	38	39	40
On	Aut	On	Aut	Aut	Aut	Aut	Aut	Aut	Aut

On	When the switch is positioned 'on'
Off	When the switch is positioned 'off'
Aut	The usual state (Automatic)
XX	The relay referred to has a failure
-	No switches

8.2 Switches & Relays Extension

SWITCHES & RELAYS									
41	42	43	44	45	46	47	48	49	50
Aut	Aut	Aut	Aut	Aut	Aut	Aut	Aut	Aut	Aut
51	52	53	54	55	56	57	58	59	60
Off	Off	Aut	Aut	Aut	Aut	Aut	--	--	--
61	62	63	64	65	66	67	68	69	70
--	--	--	--	--	--	--	--	--	-
71	72	73	74	75	76	77	78	79	80
--	--	--	--	--	--	--	--	--	--

Test the operation of the on/off/auto switches and relays in the optional Extension Box. The Farm Premium supports a maximum of 40 switches/relays in the basic controller. You can add an external extension box to obtain up to 80 switches/relays total.

8.3 Alarm

Press **Enter** to toggle the Alarm Relay. ON indicates Alarm, OFF indicates No Alarm. Note that the alarm relay is powered for the 'NO ALARM' condition to provide automatic **Power Fail Alarm** in case of power failure to the Farm Premium. That is, the Normally Open side is closed during NO ALARM.

ALARM TEST

Relay Alarm: ON

Press ENTER For On/Off

8.4 Analog Sensors

ANALOG SENSORS	
Input	Value
1	425
2	421
3	426
4	422
5	426
6	422
7	1023
8	1023
9	364
10	315
11	998

Observe the converter readings for analog sensors with this menu. The readings can vary from 0 to 1023.

The values displayed in the 'Value' column indicate that the analog sensor is either operating or not connected according to the following:

- If a very large value is shown (such as a four digit number) or a small value is shown (such as a one digit number): sensor is **not connected**.
- If the unit displays a 3-digit number, usually beginning with the digit '4': sensor is **operating**.

8.5 Digital Sensors

DIGITAL SENSORS							
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)
0	0	0	0	0	0	0	0

Observe the state of the eight digital sensors. A '1' indication implies a shorted input, a '0' an open input. The digital sensors operate with dry contact inputs such as the Arad Water Meter, or micro-switches.

You can apply a short/open input to each channel; the response is then displayed.

8.6 Analog Output

This selection tests light dimmers, variable speed fans, and variable heaters.

1. Scroll to the required output.
2. Enter the test voltage and verify that the device is operating.

Analog Output	
Output	0-10V
1	0.0
2	0.0
3	0.0


8.7 Static Pressure

Observe the converter readings for the static pressure sensor. The nominal 'zero' pressure reading is 130. Remove the air hoses from the brass connectors on the left side outside of the controller to check this reading.

STATIC PRESSURE	
A/D Counts	126

8.8 Communication

This menu facilitates testing on communication networks. A multiplexer in loop back mode is used to test the communication. The Farm Premium follows its' own communication to check for failed hardware. Follow the instructions displayed on the screen.



8.9 Hardware Checklist

Check the installed hardware that has been identified by the Plug and Play system. The system detects all cards except Communication. The standard optional Communication card provides lightning protection, and does not have local computerized intelligence to identify itself to the system. Note that if a card is missing, turn the power OFF and then ON for a card rescan.

HARDWARE CHECKLISTE		
Description	Found	Relays
Analog Input	✓	
Digital Input	✓	
Analog Output	■	
Scales	✓	
Static Pressure	✓	
Alarm	✓	
N.C. Emergency Card	1	5
N.O. Switch Card	7	35
N.C. Switch Card	0	0
Vent Board/Curtain Card	0	0

8.10 Emergency Status

This option views the status of emergency cards if installed.

EMERGENCY STATUS	
Emergency Card 1 Temp.	28.4
Emergency Card 2 Temp.	27.7
Set Temperature	24.7
Battery 1 Level	GOOD
Battery 2 Level	GOOD
Min. Vent Cycle On (sec)	57
Min. Vent Cycle Off (sec)	243

- Emergency card sensor temperature
- Current set or target temperature
- Backup battery level
- Minimum ventilation cycle timer ON/OFF time


9 Service menu

The Service Menu items calibrate various Farm Premium functions.

- Temperature Calibration, page 78
- Humidity Calibration, page 79
- CO2 Sensor, page 79
- Static Pressure Calibration, page 80
- Light Sensor Calibration, page 81
- Feed Calibration, page 81
- Water Calibration, page 82
- Vent Calibration, page 82
- Nipple Flushing, page 83
- Feeders & Drinkers, page 84
- Save Settings to Plug, page 86
- Read from Plug, page 86
- Current Sense Relay calibration, page 87

9.1 Temperature Calibration

The Farm Premium temperature sensors are typically accurate to approximately 0.5° F within the range of temperatures for poultry production. Calibrate them in this menu by adding/subtracting a constant correction factor to each sensor. Adjust the sensor of your choice with the left/right arrow keys.



TEMPERATURE CALIBRATION		
Sensor	Temp°	Factor
1	78.2	1.6
2	86.4	0.9
3	83.0	-1.5
4	86.2	0.8
5	85.2	-1.6
6	84.2	0.0

Calibrating against infrared or in air temperature sensors generally results in less accuracy than the basic sensors have without calibration.

To calibrate the sensor:

1. Obtain an accurate reference sensors and a pail of water at the approximate temperature desired.
2. Stir the reference sensor together with the Farm Premium sensor vigorously in the bucket of water. Keep hands off the sensor itself, so that it responds accurately to the water temperature. Stirring is necessary to preclude stratification within the bucket of water.
3. Call out the accurate reading to a second person standing at the Farm Premium. Walkie-talkie radios may be a good idea.
4. The individual at the controller should double-check that you are calibrating the correct sensor. You might warm/cool the sensor temporarily to see which sensor changes temperature appropriately.
5. Once you determine the correct temperature and allow approximately one minute for stabilization in the water, adjust the sensor reading at the controller.
6. Offset the factor using the left/right arrow keys.

9.2 Humidity Calibration

To calibrate the humidity level, obtain a suitable humidity test kit, and use the procedures described there. They are commonly available via the Internet.

HUMIDITY CALIBRATION		
Sensor	Humidity°	Factor
In	58.9	2.3
Out	N/A	---

Press Left/Right Arrows to Calibrate

- Adjust the Farm Premium reading as needed using the left/right arrow keys.

9.3 CO2 Sensor Calibration

To calibrate the CO2 level, obtain a suitable test kit and use the procedures described in the kit. Ensure that the house is well ventilated, either naturally or using fans.

CO2 SENSOR CALIBRATION	
	Value
PPM at 4 mA/1 VDC	26
PPM at 20 mA/5 VDC	3000
Factor (PPM)	22

CO2 (ppm):
482

- Ppm at 4 mA / 1 VDC: Parts per million for 4 mA or 1 VDC
- Ppm at 20 mA / 5 VDC: Parts per million for 20 mA or 5 VDC
- Factor (ppm): (-/+) ppm shift from the current reading

- **CO2 (ppm):** Current CO2 readings

Adjust the Farm Premium reading as needed using the left/right arrow keys.



9.4 Static Pressure Calibration

The Static Pressure should be 0 when there is no ventilation and the house is closed. When the controller reads 130 A/D counts, this is zero static pressure. Check for blocked air hoses or wind interference for inaccurate readings.

NOTE: *Run Farm Premium for a few hours so that the temperature in the box stabilizes and only then calibrate.*

There are two ways of calibrating the sensor to 0:

- **Software calibration:** 130 ± 40
- **Hardware calibration:** Adjust trimmer




NOTE: *A/D Counts of 130 ± 40 is considered a good calibration.*

Calibrate the static pressure physically using the calibration screw on the sensor card prior to completing the software calibration.

- **Hardware Calibration:** With air hoses removed, adjust the zero pressure reading to approximately 130 by turning the calibration screw with a small jewelers screwdriver.
- **Software Calibration:** After hardware calibration, follow the procedure given by the controller.

The calibration procedure adjusts the zero pressure reading. The static pressure sensor is located inside the controller in the upper left hand corner to the left of the power supply.



9.5 Light Sensor Calibration

NOTE: This feature is only available in Version 3.03 and higher.

Installing a light sensor enables turning off the lights when there is sufficient outside light.

To calibrate the light sensor:

1. Place the sensor in the required location.
2. Go to *Service > Light Sensor Calibration*.
3. When the outside light is bright enough, press **Enter**.

The Light Sensor is calibrated.

9.6 Feed Calibration

The Farm Premium can use feed bin scales or less expensive digital monitoring devices to keep track of your feed. This menu calibrates the digital monitoring devices.

To calibrate the digital monitoring device:

1. Select the feed counting method. Your digital monitoring device may generate a dry contact pulse for each quantity of feed, or it may simply indicate that the feed is running.
2. Enter the quantity of feed per pulse in case you use a dry contact pulse. Otherwise, enter the amount of feed delivered per minute of auger operation.
3. Select one of the following:
 - **Pulse:** Weight per pulse
 - **Time:** Weight per minute
 - **Current Sense:** Motor run time when the auger contains feed
4. Enter quantity (weight per minute or per pulse).

FEED CALIBRATION				
Feed	1	2	3	4
Method	TIME	TIME	TIME	TIME
Factor	2.203	2.203	2.203	2.203
Method Pulse: Weight per Pulse Method Time: Weight per Minute Method Current: Weight per Minute				

NOTE: Versions 4.05 and higher support feed calibration using Current Sense.

9.7 Water Calibration

The Farm Premium supports up to four dry contact pulse output water meters. Enter the quantity of water per pulse for your water meters.

WATER CALIBRATION			
Water 1	–	Water Per Pulse	Time
Water 2	–	Water Per Pulse	Time
Cool Pad	–	Water Per Pulse	2.203
Fogger	–	Water Per Pulse	2.203

9.8 Vent Calibration

This menu enables calibrating the vent. After pressing ENTER on the desired vent to calibrate, WAIT for the vent to (1) fully close; (2) fully open; and (3) fully close again.

VENT CALIBRATION

	MIN	POS	MAX
1 st Vent	0	351	1000

Stop fans from running to avoid

VENT CALIBRATION

	MIN	POS.	MAX
1 st Vent	0	351	1000

Closing Vent

VENT CALIBRATION

	MIN	POS	MAX
1 st Vent	351	351	1000

Opening Vent

VENT CALIBRATION

	MIN	POS	MAX
1 st Vent	351	544	544

Closing Vent

VENT CALIBRATION

	MIN	POS	MAX
1 st Vent	249	249	520

Calibration Vent: 1

VENT CALIBRATION

	MIN	POS.	MAX
1 st Vent	574	527	574

BAD Calibration Vent: 1
Check the Vent Connections
Press MENU to Menu

✓

ENSURE

Good Calibration

9.9 Nipple Flushing

To use this selection, program the water solenoids using the following relay codes:

- **111 Water Main:** The control's supplementary for the usual water line
- **112 Water Bypass:** The control's supplementary to bypass the water pressure regulator
- **113 Water line 1 through 122 Water line 10:** Individual water line supplementary to select the line to flush


During normal operation, only relay 111 water main is active. During flushing relay, code 112 is active together with each of the individual water line relays in turn.

NOTE: Configure up to 20 flush times.

- Set start time/duration of water flushing (water lines as defined by relay layout)

NIPPLE FLUSHING		
Start Time	On Time (min)	Status
06:00	2	AUTO
15:40	1	AUTO
00:00	0	AUTO
00:00	0	AUTO
00:00	0	AUTO

9.9.1 Nipple Flushing help | set definitions



FLUSH ORDER							
Line:	1	2	3	4	--	--	--
Order:	1	2	3	4	--	--	--

FLUSHING DAYS							
Day:	Sun	Mon	TUE	WED	THU	FRI	SAT
Flush:	▪	√	√	▪	▪	▪	▪

- **Flush Order:** Set flushing according to line/order
- **Flushing Days:** Set flushing per day using '+'/'-' key


9.10 Feeders & Drinkers

This selection enables inserting relevant information regarding feeder and drinker lines.

FEEDERS AND DRINKERS			
Day	Window Pos (%)	Feeder-Line Lift (inch)	Drinker-Line Lif (inch)
15	90	0.0	14.0
20	50	15.0	3.0
0	0	0.0	0.0
0	0	0.0	0.0
0	0	0.0	0.0
^	^	^^	^^

- **Day:** Insert day number.
- **Window Pos (%):** Insert the percentage of window's position.
- **Feeder-Line Lift (Inch):** Define the specific feed line lift, measured in inches.
- **Drinker-Line Lift (Inch):** Define the specific drinker line lift, measured in inches.

9.10.1 Feeders & Drinkers help | set definitions



- **Adjust at Time:** Set the desired time to adjustment.

Feeder Window

- **Stop Feed Before Adjust (min):** Set the amount of time to stop feeding before adjustment begins.
- **Time from Close to Open (sec):** Set the amount of time after stopping the feeding before opening the feeder's window.

Feed Line


- **Movement Time per 10 inch (sec):** Set a number of seconds needed to move the feed line 10 inches.

Drinker Lines


- **Movement time per 10 inch (sec):** Set a number of seconds needed to move the drinker lines in 10 inches.

9.11 Save Settings to Plug

This menu enables the user to save his program settings to the included data plug and transport them to another controller for quick programming.



1. **Insert** data plug as shown.
2. **Save** controller settings.






9.12 Read from Plug

This menu enables reading a saved program from a data plug into the controller quickly and reliably rather than configuring the settings manually.

NOTE: *Make sure that the program data is identical to the relay layout of the controller.*

- Follow the instructions given on the screen.






9.13 Current Sense Relay calibration

NOTE: Versions 4.03 and higher support this feature. The Current Sense relays supports *single phase electricity* only.

This menu calibrates the amount of current that passes through Current Sense relays. Calibration enables configuring the minimum and maximum permissible currents.

To calibrate the current sense relay:

1. Define the relay (refer to Relay Layout, page 90).
2. Select Service > Relay Current Cal. The following screen appears.



3. Select a relay and click **Enter**.

NOTE: The relay must be set to Auto.

4. Repeat for each current sense relay.

RELAY CURRENT CALIBRATION			
Relay	Function	Measure	Current
			ON
31	Heat 6	Done	0.2
32	Heat 7	Done	0.2
33	Heat 8	Done	0.2
34	Exh. Fan 5	Done	3.8
35	Exh. Fan 6	Done	4.3

Warning!!!
The selected equipment will be turned ON
now for current reading adjustment WAIT
till operation completion for 15 sec

5. To set the minimum and maximum voltages, alarms and 110/220 voltage, refer to Relay Current, page 61.

10 Install menu

The Install Menu items are used when installing input and output devices, as well as configuring critical parameters needed to run your controller properly.

- Setup, page 89
- Relay Layout, page 90
- Analog Sensors, page 93
- Digital Sensors, page 94
- Analog Output, page 94
- Curtain Setup, page 95
- Temperature Definition, page 95
- Fan Air Capacity, page 96
- House Dimensions, page 97
- Communication, page 97



10.1 Setup

To set the VENTILATION MODE, perform a Cold Start.

To perform a Cold Restart:

1. Turn controller power off.
2. Press and hold **DELETE** and turn controller power on.
3. Press **Yes** to confirm the Cold Start.

After the Cold Start, select the Ventilation Mode.



Set the following:

- **Temperature Unit** Celsius / Fahrenheit
- **Static Pressure Unit** Milibar / Inches of WC (Water Column) / Pascal / cm of WC / mm of WC / None


- **Fan Air Capacity Unit** Cubic feet per minute (CFM) / Cubic meter per hour (M3/H)
- **Length Unit** Meter / Feet
- **Weight Unit** Pounds (LB) / Kilograms (KG)
- **Growing Zones** 1/2/3/4
- **Minimum Vent (Power)** YES (power) / NO
- **Natural Ventilation** YES / NO
- **Tunnel** YES / NO
- **History Resolution** 1 minute / 5 minute / 10 minute / 15 minute / 30 minute / 1 hour / 2 hours

10.2 Relay Layout

Use this menu to define the devices connected to the controller. There are (up to) 40 available relays.

NOTE: Up to 40 more relays can be added when using the Farm Premium Extension.

1. Select the requested choice from the menu list by using the up/down cursor keys (refer to Output function list, page 91).
2. If the required code is 100 and above, use the '+/-' keys before selecting and then press a two digit number. For example 135 would be +/-35.
3. To duplicate relays use the 'As Relay # X' where 'X' stands for a relay number defined already in the system.



- Enter relays according to equipment installation (I/O list of technician) using up/down arrow keys.
- If you have installed Current Sense relays, Farm Premium defines them automatically. Current sense relays transmit to the user's PC the amount of the current being passed to the relay and send alarms when the current is too low or too high. In addition, you can view the daily electricity consumption in History. Refer to Current Sense Relay calibration, page 87 for calibration instructions.

NOTE: Version 4.03 and higher supports this feature. The Current Sense Relays support *single phase electricity* only.

NOTE: Version 4.05 and higher supports four augers and four feed lines.

10.2.1 Output function list


Table 1: Versions 4.04 and Below

Number	Output Function
1 - 16	Heaters 1 - 16
17 - 64	Radiant Heaters (Lo/Hi/Ign) 1 - 16
65 - 84	Tunnel Fan 1 - 20
85 - 94	Exhaust Fan 1 - 20
95 - 109	Stir Fan 1 - 15
110 - 113	Cool 1 - 4
114 - 117	Cool Pad 1 - 4
118 - 121	Fogger 1 - 4
122 - 129	Curtain 1 - 4 (Open/Close)
130 - 133	Extra System 1 - 4
134 - 135	Tunnel Curtain (Open/Close) 1 - 2
136 - 137	1st Inlet (Open/Close) 1 - 2
138 - 139	2nd Inlet (Open/Close) 1 - 2
140 - 143	Water 1 - 4
144 - 145	Feeder 1 - 2
146 - 149	Light 1 - 4
150 - 151	Auger 1 - 2
152 - 153	Feeder Window (Open/Close) 1 - 2
154 - 155	Feeder Line (Up/Down) 1 - 2
156 - 157	Drink Line (Up/Down) 1 - 2
158	Alarm (N.C.)
159	Water Main
160	Water Bypass
161 - 170	Water Line 1 - 10
171	Vent Speed
172 - 173	Attic Inlet (Open/Close) 1 - 2
174	Fail Safe
175 - 254	As Relay # 1 - 80

Table 2: Versions 4.05 and Above

Number	Output Function
1 - 16	Heaters 1 - 16
17 - 64	Radiant Heaters (Low/High/Ignite) 1 - 16
65 - 84	Tunnel Fan 1 - 20
85 - 94	Exhaust Fan 1 - 20
95 - 109	Stir Fan 1 - 15
110 - 113	Cool 1 - 4
114 - 117	Cool Pad 1 - 4
118 - 121	Fogger 1 - 4
122 - 129	Curtain 1 - 4 (Open/Close)
130 - 133	Extra System 1 - 4
134 - 135	Tunnel Curtain (Open/Close)
136 - 137	1st Inlet (Open/Close)
138 - 139	2nd Inlet (Open/Close)
140 - 143	Water 1 - 4
144 - 147	Feeder 1 - 4
148 - 151	Light 1 - 4
152 - 155	Auger 1 - 4
156 - 157	Feeder Window (Open/Close) 1 - 2
158 - 159	Feeder Line (Up/Down) 1 - 2
160 - 161	Drink Line (Up/Down) 1 - 2
162	Alarm (N.C.)
163	Water Main
164	Water Bypass
165 - 174	Water Line 1 - 10
175	Vent Speed
176 - 177	Attic Inlet (Open/Close) 1 - 2
178	Fail Safe (NC)
179 - 182	WOD 1/2/3/4
183 - 262	As Relay # 1 - 80

10.2.2 Relay Layout – help | set definitions




- Define relay operation mode: DC or AC.

NOTE: AC mode produces less heat in the controller box.

- Define five relays to be inversed by software.

10.3 Analog Sensors

This selection enables the user to install the analog sensors. The Farm Premium regards temperature, humidity, and CO2 sensors and circuit breaker as 'Analog sensors'. These sensors measure a continuous range rather than just on or off.




- Enter temperature / humidity sensors wired to each input (setup according to technician).

NOTE: If sensor numbers duplicate, the sensors average.

NOTE: Version 3.02 and higher support CO2 sensors.

10.4 Digital Sensors

This option enables configuring the installed digital sensors. These sensors monitor both water and feed consumption if the building is equipped accordingly. Digital inputs include on/off and pulsing inputs such as auxiliary alarms, pulsing water meters and feed.



In	Input Function
1	<
2	<
3	<
4	<
5	<
6	<
7	<
8	<


In	Input Function
1	03. Water Meter
2	02. < None >
3	03. < None >
4	04. < None >
5	05. < None >
6	06. < None >
7	07. < None >
8	08. < None >

- Enter sensors wired to each input (setup according to technician)
- Example: Digital sensor installation

NOTE: Version 3.03 supports four water meters.

10.5 Analog Output

This selection controls light dimmers, variable speed fans and variable heaters. Select the required output function from the menu list and insert the approximate output voltages.



Out No.	Output Function	Min V.Out	Max V. Out
1	< None >		
2	< None >		
3	< None >		
4	< None >		
5	< None >		
6	< None >		
7	< None >		
8	< None >		

Out No.	Output Function	Min V.Out	Max V. Out
1	05. Light Dimmer 1	0.0	10.0
2	06. Light Dimmer 2	0.0	10.0
3	07. Light Dimmer 3	0.0	10.0
4	08. Light Dimmer 4	0.0	10.0
5	09. Var. Stir Fan 1	0.0	10.0
6	< None >	0.0	10.0
7	< None >	0.0	10.0
8	< None >	0.0	10.0

- Enter sensors wired to each input (setup according to technician).
- The above is an example of an analog output configuration

NOTE: Version 4.05 and higher supports up to four variable stir fans. Previous versions support up to two fans.

- To configure the light dimmers, refer to Light, page 46.
- To configure the variable speed fans, refer to Stir Fan levels, page 38.
- To configure the variable heaters, refer to Temperature curve help | set definitions, page 19.

NOTE: *Farm Premium-P XL* units equipped with *C-PPJ-VARSPEED* cards: Set output 1 and 2 as variable speed fans to enable the fans.

10.6 Curtain Setup

Enter the number of seconds to open and close from limit to limit for each of the Vents and Curtains in your installation. The Farm Premium then calculates the percentage of open and closed time and adjusts the static pressure methods accordingly.

CURTAIN SETUP		
Curtain	Open (sec)	Close (sec)
Curtain 1	60	60
Curtain 2	60	60
Curtain 3	60	60
Curtain 4	60	60
Tunnel	60	60
1st Vent	60	60
2st Vent	60	60
Attic Vent	60	60

- Set full open/full close time (in seconds) for Curtains, Tunnel, 1st & 2nd Vent, and Attic Vent.

NOTE: Default is set at 60.

10.7 Temperature Definition

This menu assigns specific temperature sensors for various brood setups and for heater zones. Moreover, assigning sensors to particular devices is possible. Note that if the sensors selection remains blank, the default value is assigned.

Choose 1 to 18 temperature sensors for each item listed by using the '+/-' keys. The house, brooding and tunnel sensors cause the current average to apply to devices when no specific sensor is assigned to them. The current average substitutes for either failed or missing sensors.

NOTE: Sensors 10 – 18 require installing a second analog card.

TEMPERATURE DEFINITION	
Function	Temp. Sensor
	1 2 3 4 5 6 7 8 9
FULL HOUSE	✓✓✓
TUNNEL
SETTING
ATTIC	. . . ✓ . . .
OUTSIDE ✓ . .

- Press **+/-** key to add/remove ✓ to assign temperature sensors to corresponding function.

NOTE: If you are using two (2) input analog cards, the screen displays Temp. Sensor(s) 1-18 (refer to above screen capture).

NOTE: When an attic sensor is not installed, the attic vent is disabled.

Assign Temperature Sensors as required in **Install | Temp Definition**. Devices that do not accept temperature sensors, such as Exhaust Fans, Tunnel Fans, Feed and Light do not appear.

Note that Exhaust Fans and Tunnel Fans do not appear because the Ventilation Levels defined in **Device | Levels of Ventilation** control their operation. Stir Fans appear even though the **Device | Stir Fan Levels** apply to them because they simultaneously operate according **Device | Stir Fan Programs** where specific sensor assignments are required in Program B and recommended in Program C.

10.8 Fan Air Capacity

This option enables defining the fans' air capacity. Insert fan air capacity for both the exhaust and tunnel fans. The units are as chosen in **INSTALL | SETUP**.


FAN AIR CAPACITY	
Fan	CFM
Tun. Fan 1	24600
Tun. Fan 2	24600
Tun. Fan 3	29400
Tun. Fan 4	29400
Tun. Fan 5	29400
Tun. Fan 6	29400
Tun. Fan 7	29400
Tun. Fan 8	29400
Tun. Fan 9	29400
Tun. Fan 10	29400

- Define air capacity for exhaust/tunnel fans (default setting shown above).

NOTE: *This information enables the display of air capacity for each level in the Levels of Ventilation table (Precision ONLY).*

10.9 House Dimensions

The selection allows the user to set its' house dimensions. Set it according to actual house size. These dimensions are used for calculating the wind chill factor (the chilling effect of the wind that can significantly lower the temperature).



- Define height, width, and length of house (Controller calculates total area).
- To set the dimensions in metric or non-metric units, go to *Installation > Setup* and scroll down to Length Unit.

NOTE: This information enables the calculation of the Wind Chill factor displayed in Hot Screen Key = 2 (Tunnel mode ONLY).

10.10 Communication

This menu defines the communication parameters.

COMMUNICATION SETUP	
Baud Rate	9600
House Number	1
	1200
	2400
	9600
	19200
	38400

- **Baud rate:** This parameter is a measure of the communication speed for local or remote communications to a PC. The default is 9600 represents a data rate of approximately 1000 characters per second. If the connection fails at this speed, try a lower speed.
- **House number:** Each controller on a network must have a unique number so Munters' communication software can distinguish individual controllers. Note that these numbers are from 1 to 64.

11 Appendix A

Table 3: Sensor Readings

Sensor	Definition
Temp	Displayed with the specific sensor number
Out T.	Outside temperature
Press.	Pressure
Hum. In	Inside humidity
Hum. Out	Outside humidity
Weight	Average weight
Weights	Number of weights
E. Tmp1	Temperature related to emergency card 1
E. Tmp2	Temperature related to emergency card 2
Breaker	Circuit breaker

Table 4: Output List (Active)

Output	Definition
Alarm	Can be either active or not. Note that this always appears last.
Heat	Indicates operating heat number
Heat. Hi	Indicates operating heat high number
Tun. Fan	Indicates operating tunnel fan number
Exh. Fan	Indicates operating exhaust fan number
Stir	Indicates operating stir fan number
Cool P.	Indicates operating cool pad number
Fogger	Indicates operating fogger number
Inlet	
Tunnel	
Curt.	Mentions opening percentage
Ext. Sys	Indicates operating external system number
Light	Note that these mention output percentage
Water	Indicates operating water number
Feed	Indicates operating feed number

Output	Definition
Auger	Indicates operating auger number
Rad. Lo	Indicates operating radiant heat low number
Rad. Hi	Indicates operating radiant heat high number

Table 5: Status Readings

Status	Definition
Time	Specific time
Day	Growth day
Set	Target temperature
Offset	Temperature Curve HELP SET parameter
House mode	Control Mode HELP SET parameter
Level	Level number
Tunnel, Natural, Min. Vent	The controller's state
Fan Off	How long the cycle ends its' operation
Fan On	How long the cycle begins its' operation
Curve off	Occurs when located in low curve temperature or when the Control Mode HELP SET 'Temperature Curve' parameter is set to OFF.
Hum. Treat	Indicates when treatment occurs
Cool flush	Indicates when flush occurs
Nip. Flush	Indicates when flush occurs

Table 6: Table of Events

Event	Event Explanation
Power Off	Appears when power is off
Power On	Appears when power is on
Cold Start	Appears when cold start is done
Change level to vent	Changes according to a specific stage
Backup set reminder	HELP SET: 'Set Temp. Change remainder (diff)' parameter
Alarm on	Appears when the alarm is on
Change in setting	
Change in switches	Relay switch setting changed
New flock	Appears when new flock is updated
Reset alarm	Appears when reset alarm is done
System message #	For Munters' technicians only

Event	Event Explanation
Alarm card fail	Appears when the alarm card fails
Digital card fail	Appears when the digital card fails
Memory restore	Appears when the system does restore cause by noises
Minimum ventilation	Appears when minimum ventilation occurs
Natural ventilation	Appears when entering natural ventilation
Tunnel ventilation	Appears when entering tunnel ventilation
Alarm test	Appears when alarm test completes
Precision Mode	Switch to Precision Mode
Standard Mode	Switch to Standard Mode
Changed growth day	Appears when changing the growth day occurs
MinV L.P Alarm Dis.	Appears when minimum low pressure alarm is disabled
MinV L.P Alarm Ena	Appears when minimum low pressure alarm is enabled
Tun. L.P Alarm Dis.	Appears when tunnel low pressure alarm is disabled
Tun L.P Alarm Ena.	Appears when tunnel low pressure alarm is enabled
Visitor Log in	Appears when the visitor logs in with his password
User #1-5 log in	Appears when the user logs in with his password
Owner log in	Appears when the owner logs in with his password
Change Visitor pass	Appears when the visitor changed his password.
Change User #1-5 pass	Appears when the user changed his password
Change Owner pass	Appears when the owner changed his password
Data read from plug	Appears when data is read from plug
System recover	Appears when the system tries to recover itself, in cases such as noises
System lock	Appears when either using the correct password, or when using hot key '9,' or automatically after 5 minutes
Empty house mode	Appears when setting at a specific time

12 Warranty

Warranty and technical assistance

Munters products are designed and built to provide reliable and satisfactory performance but cannot be guaranteed free of faults; although they are reliable products they can develop unforeseeable defects and the user must take this into account and arrange adequate emergency or alarm systems if failure to operate could cause damage to the articles for which the Munters plant was required: if this is not done, the user is fully responsible for the damage which they could suffer.

Munters extends this limited warranty to the first purchaser and guarantees its products to be free from defects originating in manufacture or materials for one year from the date of delivery, provided that suitable transport, storage, installation and maintenance terms are complied with. The warranty does not apply if the products have been repaired without express authorisation from Munters, or repaired in such a way that, in Munters' judgement, their performance and reliability have been impaired, or incorrectly installed, or subjected to improper use. The user accepts total responsibility for incorrect use of the products.

The warranty on products from outside suppliers fitted to Farm Premium, (for example sensors, analog inputs, cables, etc.) is limited to the conditions stated by the supplier: all claims must be made in writing within eight days of the discovery of the defect and within 12 months of the delivery of the defective product. Munters has thirty days from the date of receipt in which to take action, and has the right to examine the product at the customer's premises or at its own plant (carriage cost to be borne by the customer).

Munters at its sole discretion has the option of replacing or repairing, free of charge, products which it considers defective, and will arrange for their despatch back to the customer carriage paid. In the case of faulty parts of small commercial value which are widely available (such as bolts, etc.) for urgent despatch, where the cost of carriage would exceed the value of the parts, Munters may authorise the customer exclusively to purchase the replacement parts locally; Munters will reimburse the value of the product at its cost price.

Munters will not be liable for costs incurred in demounting the defective part, or the time required to travel to site and the associated travel costs. No agent, employee or dealer is authorised to give any further guarantees or to accept any other liability on Munters' behalf in connection with other Munters products, except in writing with the signature of one of the Company's Managers.

WARNING! *In the interests of improving the quality of its products and services, Munters reserves the right at any time and without prior notice to alter the specifications in this manual.*

The liability of the manufacturer Munters ceases in the event of:

- dismantling the safety devices;
- use of unauthorised materials;
- inadequate maintenance;
- use of non-original spare parts and accessories.

Barring specific contractual terms, the following are directly at the user's expense:

- preparing installation sites;
- providing an electricity supply (including the protective equipotential bonding (PE) conductor, in accordance with CEI EN 60204-1, paragraph 8.2), for correctly connecting the equipment to the mains electricity supply;
- providing ancillary services appropriate to the requirements of the plant on the basis of the information supplied with regard to installation;
- tools and consumables required for fitting and installation;
- lubricants necessary for commissioning and maintenance.

It is mandatory to purchase and use only original spare parts or those recommended by the manufacturer.

Dismantling and assembly must be performed by qualified technicians and according to the manufacturer's instructions.

The use of non-original spare parts or incorrect assembly exonerates the manufacturer from all liability.

Requests for technical assistance and spare parts can be made directly to the nearest Munters office. A full list of contact details can be found on the back page of this manual.



www.munters.com

Australia Munters Pty Limited, Phone +61 2 8843 1594, **Brazil** Munters Brasil Industria e Comercio Ltda, Phone +55 41 3317 5050, **Canada** Munters Corporation Mason, Phone +1 517 676 7070, **China** Munters Air Treatment Equipment (Beijing) Co. Ltd, Phone +86 10 80 481 121, **Denmark** Munters A/S, Phone +45 9862 3311, **India** Munters India, Phone +91 20 3052 2520, **Indonesia** Munters, Phone +62 818 739 235, **Italy** Munters Italy S.p.A., Chiusavecchia, Phone +39 0183 52 11, **Japan** Munters K.K., Phone +81 3 5970 0021, **Korea** Munters Korea Co. Ltd., Phone +82 2 761 8701, **Mexico** Munters Mexico, Phone +52 818 262 54 00, **Russia** Munters AB, Phone +7 812 448 5740, **Singapore** Munters Pte Ltd., Phone +65 744 6828, **South Africa and Sub-Sahara Countries** Munters (Pty) Ltd., Phone +27 11 997 2000, **Spain** Munters Spain S.A., Phone +34 91 640 09 02, **Sweden** Munters AB, Phone +46 8 626 63 00, **Thailand** Munters Co. Ltd., Phone +66 2 642 2670, **Turkey** Munters Form Endüstri Sistemleri A.Ş., Phone +90 322 231 1338, **USA** Munters Corporation Mason, Phone +1 517 676 7070, **Vietnam** Munters Vietnam, Phone +84 8 3825 6838, **Export & Other countries** Munters Italy S.p.A., Chiusavecchia Phone +39 0183 52 11