

The following document contains information on Cypress products. Although the document is marked with the name "Spansion" and "Fujitsu", the company that originally developed the specification, Cypress will continue to offer these products to new and existing customers.

Continuity of Specifications

There is no change to this document as a result of offering the device as a Cypress product. Any changes that have been made are the result of normal document improvements and are noted in the document history page, where supported. Future revisions will occur when appropriate, and changes will be noted in a document history page.

Continuity of Ordering Part Numbers

Cypress continues to support existing part numbers. To order these products, please use only the Ordering Part Numbers listed in this document.

For More Information

Please contact your local sales office for additional information about Cypress products and solutions.

About Cypress

Cypress (NASDAQ: CY) delivers high-performance, high-quality solutions at the heart of today's most advanced embedded systems, from automotive, industrial and networking platforms to highly interactive consumer and mobile devices. With a broad, differentiated product portfolio that includes NOR flash memories, F-RAM™ and SRAM, Traveo™ microcontrollers, the industry's only PSoC® programmable system-on-chip solutions, analog and PMIC Power Management ICs, CapSense® capacitive touch-sensing controllers, and Wireless BLE Bluetooth® Low-Energy and USB connectivity solutions, Cypress is committed to providing its customers worldwide with consistent innovation, best-in-class support and exceptional system value.



Colophon

The products described in this document are designed, developed and manufactured as contemplated for general use, including without limitation, ordinary industrial use, general office use, personal use, and household use, but are not designed, developed and manufactured as contemplated (1) for any use that includes fatal risks or dangers that, unless extremely high safety is secured, could have a serious effect to the public, and could lead directly to death, personal injury, severe physical damage or other loss (i.e., nuclear reaction control in nuclear facility, aircraft flight control, air traffic control, mass transport control, medical life support system, missile launch control in weapon system), or (2) for any use where chance of failure is intolerable (i.e., submersible repeater and artificial satellite). Please note that Spansion will not be liable to you and/or any third party for any claims or damages arising in connection with above-mentioned uses of the products. Any semiconductor devices have an inherent chance of failure. You must protect against injury, damage or loss from such failures by incorporating safety design measures into your facility and equipment such as redundancy, fire protection, and prevention of over-current levels and other abnormal operating conditions. If any products described in this document represent goods or technologies subject to certain restrictions on export under the Foreign Exchange and Foreign Trade Law of Japan, the US Export Administration Regulations or the applicable laws of any other country, the prior authorization by the respective government entity will be required for export of those products.

Trademarks and Notice

The contents of this document are subject to change without notice. This document may contain information on a Spansion product under development by Spansion. Spansion reserves the right to change or discontinue work on any product without notice. The information in this document is provided as is without warranty or guarantee of any kind as to its accuracy, completeness, operability, fitness for particular purpose, merchantability, non-infringement of third-party rights, or any other warranty, express, implied, or statutory. Spansion assumes no liability for any damages of any kind arising out of the use of the information in this document.

Copyright © 2013 Spansion Inc. All rights reserved. Spansion[®], the Spansion logo, MirrorBit[®], MirrorBit[®] EclipseTM, ORNANDTM and combinations thereof, are trademarks and registered trademarks of Spansion LLC in the United States and other countries. Other names used are for informational purposes only and may be trademarks of their respective owners.



PMSM PROTECTION TECHENOLOGY

USER MAMUAL

ARM and Cortex-M3 are the trademarks of ARM Limited in the EU and other countries.





Revision History

Version	Date	Updated by	Approved by	Modifications
1.0.0	2012-1-17	Devin Zhang		First Draft

This manual contains 16 pages.

Specifications are subject to change without notice. For further information please contact each office.

All Rights Reserved.

The contents of this document are subject to change without notice.

Customers are advised to consult with sales representatives before ordering.

The information, such as descriptions of function and application circuit examples, in this document are presented solely for the purpose of reference to show examples of operations and uses of FUJITSU SEMICONDUCTOR device; FUJITSU SEMICONDUCTOR does not warrant proper operation of the device with respect to use based on such information. When you develop equipment incorporating the device based on such information, you must assume any responsibility arising out of such use of the information.

FUJITSU SEMICONDUCTOR assumes no liability for any damages whatsoever arising out of the use of the information. Any information in this document, including descriptions of function and schematic diagrams, shall not be construed as license of the use or exercise of any intellectual property right, such as patent right or copyright, or any other right of FUJITSU SEMICONDUCTOR or any third party or does FUJITSU SEMICONDUCTOR warrant non-infringement of any third-party's intellectual property right or other right by using such information. FUJITSU SEMICONDUCTOR assumes no liability for any infringement of the intellectual property rights or other rights of third parties which would result from the use of information contained herein.

The products described in this document are designed, developed and manufactured as contemplated for general use, including without limitation, ordinary industrial use, general office use, personal use, and household use, but are not designed, developed and manufactured as contemplated (1) for use accompanying fatal risks or dangers that, unless extremely high safety is secured, could have a serious effect to the public, and could lead directly to death, personal injury, severe physical damage or other loss (i.e., nuclear reaction control in nuclear facility, aircraft flight control, air traffic control, mass transport control, medical life support system, missile launch control in weapon system), or (2) for use requiring extremely high reliability (i.e., submersible repeater and artificial satellite).

Please note that FUJITSU SEMICONDUCTOR will not be liable against you and/or any third party for any claims or damages arising in connection with above-mentioned uses of the products.

Any semiconductor devices have an inherent chance of failure. You must protect against injury, damage or loss from such failures by incorporating safety design measures into your facility and equipment such as redundancy, fire protection, and prevention of over-current levels and other abnormal operating conditions.

Exportation/release of any products described in this document may require necessary procedures in accordance with the regulations of the Foreign Exchange and Foreign Trade Control Law of Japan and/or US export control laws.

The company names and brand names herein are the trademarks or registered trademarks of their respective owners.

Copyright © 2011 Fujitsu Semiconductor Design (Chengdu) Co. Ltd. All rights reserved.



Contents

RI	EVISI	ON HISTORY	2		
C	ONTE	NTS	3		
1	INTR	RODUCTION	4		
	1.1	Purpose	4		
	1.2	Document Overview	4		
2	PRIN	NCIPLE OF MOTOR PROTECTION TECHNOLOGY	5		
	2.1	AD Offset Detection	5		
	2.2	Open Phase Detection	6		
	2.3	Motor Locked Detection	7		
	2.4	Over-Low DC Voltage Detection	8		
	2.5	IPM Protection Detection	9		
	2.6	PFC hardware over current Protection Detection	10		
	2.7	PFC software over current Protection Detection	11		
	2.8	PFC software over voltage Protection Detection	11		
3	FLO	W CHART AND FAULT CODE DEFINITION OF PROTECTION FUNCTION	12		
	3.1	Flow Chart of Protection Function	12		
	3.2	Definition of Fault Code	13		
4	ADD	ITIONAL INFORMATION	15		
5	APP	PENDIX			
	5 1	List of Figures and Tables	16		



1 Introduction

1.1 Purpose

This user manual describes the operation of motor driver protection technology based on the FUJITSU FM3 32 bits in MB9AF112L Series.

This user manual describes FUJITSU protection solution for permanent magnet DC motor driver, which includes motor-lock detection, open-phase detection, start-up detection, over-current detection, over voltage detection, low voltage, IPM protection and so on.

1.2 Document Overview

The rest of document is organized as the following:

Chapter 2 explains the principle of motor protection technology.

Chapter 3 explains flow chart and fault code definition of protection function.

Chapter 4 explains additional information.

Chapter 5 explains appendix.



2 Principle of Motor Protection Technology

This chapter describes the item and implementation of motor protection method in details.

2.1 AD Offset Detection

In FUJITSU motor sampling current solution, It has a steady middle level voltage (2.5V), which needs to detect before motor start-up each time. And in the program, the real-time sampling middle voltage has been described as "uphase_midvol", "vphase_midvol" in dual resistance sampling system, or "Ibus_midvol" in single shunt sampling system. Set the range of tolerance AD offset value (+adoffset_tolerance). The current AD sampling value of the OP-Amplifier is detected at the power on stage. If the detected middle voltage is lower than "2.5-adoffset_tolerance", or larger than "2.5+adoffset_tolerance", the program would deal with it as an error, the error flag 'pmsm_error_type' for AD offset would be set to '1'and motor is stopped. Otherwise, the program would take the real-time sampling value as steady middle voltage to operation, and set "pmsm_error_type ==0" and start up motor. The figure of implementation of AD offset detection is as follows:




Figure 2-1 AD offset detection of current sample



2.2 Open Phase Detection

Based on the difference situation, open phase fault can be appeared before motor start-up or motor running.

The first situation, when in start-up motor, at the orientation stage, it would sample the phase current ('pmsm_isalpha'), at the same time, based on the Q-axis reference current ('pmsm_isqref') and the rotor angle ('pmsm_theta'), the α -axis current ('lose_isalpha') can be calculated. If the sampling current value ('pmsm_isalpha') is nearly less than $\frac{3}{4}$ 'lose_isalpha', or 'pmsm_isalpha' is larger than $\frac{5}{4}$ 'lose_isalpha' in continuous 50ms, the error flag 'pmsm_error_type' for open phase would be set to '1' and motor is stopped, otherwise, startup motor as normal.

The second, when in running motor, when the given Q-axis reference current is larger than 1A, If the average of current sample value is nearly less than 0.5A in continuous 200ms, motor is stopped right now, and the error flag 'pmsm_error_type' for open phase would be set to '1'. Otherwise, run motor as normal. (Attention: 1A and 0.5A are manual given, which should be changed in different driver system for getting the best effect.)




Figure 2-2 Sequence diagram of motor open phase detection




Figure 2-3 Motor open phase detection module frame



2.3 Motor Locked Detection

Start-up motor, if the motor runs in the open loop stage, and the given PI target speed is no more less than 800RPM. When the running time is over 1s, but the estimated speed ('omegaMr_avr') in program is also less than 500rpm, motor is stopped right now, and the error flag 'pmsm_error_type' for the locked rotor would be set to '1'. Otherwise, run motor as normal.

The other situation, if the motor runs in the close loop stage, and the given PI target speed is larger than 3000RPM. the estimated speed ('omegaMr_avr') in program is less than 1200rpm lasting out more than 500ms, or the given PI target speed is larger than 2400RPM. the estimated speed ('omegaMr_avr') in program is less than 600rpm lasting out more than 500ms, motor is stopped right now, and the error flag 'pmsm_error_type' for the locked rotor would be set to '1'. Otherwise, run motor as normal.




Figure 2-4 Flow chart of motor locked detection




Figure 2-5 Motor locked detection module frame



2.4 Over-Low DC Voltage Detection

With the influence of electrical net and PFC modul, it would maybe induce the wavy DC voltage. Sample DC voltage, if the sampling DC voltage is larger or less than the given range of the steady DC voltage, it would be deal with as a over or low DC voltage fault. The details are as follows:

Over DC voltage protection: if the real-time sample DC voltage('direct_voltage') is larger than the given max DC voltage('max_dcvoltage') lasting out 1ms, motor is stopped, and the error flag 'pmsm_error_type' for over DC voltage would be set to '1'. Otherwise, run motor as normal.

Low DC voltage protection: if the real-time sample DC voltage('direct_voltage') is less than the given minimal DC voltage('min_dcvoltage') lasting out 1ms, motor is stopped, and the error flag 'pmsm_error_type' for low DC voltage would be set to '1'. Otherwise, run motor as normal.




Figure 2-6 Sequence diagram of motor over-low voltage detection




Figure 2-7 Motor over-low voltage detection module frame



2.5 IPM Protection Detection

When running the motor, if the hardware IPM is over hot, over current or low power(+15v), the pin(FO) of the IPM would put out a low level signal. Then, motor is stopped right now, and set 'pmsm status ==3'.

Attention:

When the IPM is over hot, only the pin (FO) would put out a low level signal just lies on the IPM module has the temperature detection function.

The manual given value of the max current for protection lies on the parameter of the current protection circuit, IPM current trigger value and the ability of the anti-jamming.




Figure 2-8 Sequence diagram of IPM hardware over current detection




Figure 2-9 IPM hardware over current detection module frame



2.6 PFC hardware over current Protection Detection

When running the PFC module, if the current of the PFC circuit is larger than the max permitted current, the PFC hardware circuit would put out a low pulse signal and trigger an interrupt to close the PFC operation. The error flag 'PFC_stop_Flag' for PFC module would be set to '1'. Otherwise, run PFC module as normal.



Figure 2-10 PFC over current detection module frame




Figure 2-11 Sequence diagram of PFC over current detection



2.7 PFC software over current Protection Detection

When running the PFC module, if the current of the AC side is larger than the given max current in program, it should stop the PFC operation and set the error flag "PFC_stop_Flag ==6". Otherwise, run the PFC module as normal.

Attention: the sequence diagram of PFC software over current protection detection is similar as the motor over current detection.

2.8 PFC software over voltage Protection Detection

When running the PFC module, if the DC voltage is larger than the given max voltage in program, it should stop the PFC operation and set the error flag "PFC_stop_Flag ==5". Otherwise, run the PFC module as normal.

Attention: the sequence diagram of PFC software over DC voltage protection detection is similar as the motor over voltage detection.



3 Flow chart and fault code definition of protection function

This chapter describes the flow chart and fault code definition of protection function.

3.1 Flow Chart of Protection Function




Figure 3-1 Flow Chart of Protection Function



3.2 Definition of Fault Code

In fujitsu motor driver system, the definitions of fault code can be described as Table 3-1, it also can be found in the relevant head files.

```
= 0x00.
                                   //Motor initial or normal state
pmsm_error_type
                                   //Motor over DC voltage state
pmsm_error_type
                     = 0x01,
pmsm_error_type
                     = 0x02,
                                   // Motor low DC voltage state
                                   //Motor software over current state
pmsm_error_type
                     = 0x04,
pmsm_error_type
                     = 0x08,
                                   //Motor failed start-up
pmsm_error_type
                     = 0x10,
                                   //Motor open phase state
                                   //No Motor
pmsm_error_type
                     = 0x20,
                     = 0x40,
                                   //Motor AD offset fault state
pmsm_error_type
pmsm_error_type
                     = 0x80
                                   //Motor locked state
                                  //PFC initial or normal state
PFC_stop_Flag = 0;
PFC_stop_Flag = 1;
                                  //PFC hardware over current state
PFC_stop_Flag = 5;
                                  //PFC software over voltage state
                                 //PFC software over current state
PFC_stop_Flag = 6;
```



Table 3-1: Fault Code of Protection Function

Fault Code	Type of Fault	Reason
0x0000	Motor initial or normal state	Motor stop or normal run
0x0001	Motor over DC voltage state	High AC input, DC sample circuit fault, PFC abnormity
0x0002	Motor low DC voltage state	Low AC input, DC sample circuit fault
0x0004	Motor software over current state	Motor run abnormity, current sample fault
0x0008	Motor failed start-up	Improper parameter, hardware driver fault
0x0010	Motor open phase state	Motor connected abnormity
0x0020	No Motor	Motor connected abnormity
0x0040	Motor AD offset fault state	AD current sample abnormity
0x0080	Motor locked state	Motor fault, Improper parameter, hardware circuit fault
0	PFC initial or normal state	PFC no work or normal work
1	PFC hardware over current state	PFC run abnormity or sample fault or hardware fault
5	PFC software over voltage state	PFC run abnormity or sample fault or hardware fault
6	PFC software over current state	PFC run abnormity or sample fault or hardware fault



4 Additional Information

For more Information on FUJITSU semiconductor products, visit the following websites:

English version address:

http://www.fujitsu.com/cn/fsp/services/mcu/32bit/fm3/an.html

Chinese version address:

http://www.fujitsu.com/cn/fss/services/mcu/32bit/fm3/an.html



5 Appendix

5.1 List of Figures and Table	5.1	List	of F	Figures	and	Table
-------------------------------	-----	------	------	---------	-----	--------------

Table 3-1: Fault Code of Protection Function	14
Figure 2-1 AD offset detection of current sample	5
Figure 2-2 Sequence diagram of motor open phase detection	6
Figure 2-3 Motor open phase detection module frame	6
Figure 2-4 Flow chart of motor locked detection	7
Figure 2-5 Motor locked detection module frame	7
Figure 2-6 Sequence diagram of motor over-low voltage detection	8
Figure 2-7 Motor over-low voltage detection module frame	8
Figure 2-8 Sequence diagram of IPM hardware over current detection	9
Figure 2-9 IPM hardware over current detection module frame	9
Figure 2-10 PFC over current detection module frame	10
Figure 2-11 Sequence diagram of PFC over current detection	10
Figure 3-1 Flow Chart of Protection Function	12