



EXOR International

# Industrial Computing Solutions

## Fan-less Computer

### eCC3600E Series

#### User Manual

# CONTENTS

## Preface

Copyright .....	iv
Disclaimer .....	iv
Acknowledgements .....	iv
Regulatory Compliance Statements.....	iv
Declaration of Conformity.....	iv
RoHS Compliance .....	v
Warranty and RMA .....	vi
Safety Information .....	viii
Installation Recommendations.....	viii
Safety Precautions.....	ix
Technical Support and Assistance .....	x
Conventions Used in this Manual.....	x
Global Service Contact Information.....	xi
Package Contents .....	xiii
Ordering Information .....	xiv

## Chapter 1: Product Introduction

Overview .....	1
Key Features .....	1
Hardware Specifications.....	2
Knowing Your eCC3600E .....	4
Front Panel .....	4
Rear Panel .....	5
Mechanical Dimensions.....	6

## Chapter 2: Jumpers and Connectors

Before You Begin .....	8
Precautions .....	8
Jumper Settings .....	9
Locations of the Jumpers and Connectors for NISB 3600.....	10
NISB 3600 .....	10
Jumpers .....	12
CMOS Clear Select .....	12
ME Pin Header.....	12
LVDS Power Pin Header .....	13
Connector Pin Definitions .....	14
External I/O Interfaces - Front Panel .....	14
USB 3.0.....	14
DisplayPort A .....	14
DisplayPort B.....	15
CompactFlash .....	15
SIM Card Connector .....	16
Power Switch.....	16
External I/O Interfaces - Rear Panel.....	17
Remote Power on/off Switch.....	17
DC-in Power Jack .....	17
Serial Interface (COM 1 - COM 4).....	18
COM 5 and COM 6 Ports .....	20
LAN1 and USB 3.0 Ports.....	20
LAN2 and USB 2.0 Ports.....	21

VGA and DVI-D Connectors .....	22	Installing a SATA DOM .....	42
Audio Connectors .....	23	Installing a PCIe/PCI Expansion Card.....	44
Internal Connectors .....	24	Removing the Chassis Top Cover .....	46
SIM Card Line-out Pin Header .....	24	Installing a CPU.....	46
SIM Card Mic-in Pin Header .....	24	Installing a SO DIMM .....	48
DC-in Power Connector .....	25	Installing a Wireless LAN Module (half-size).....	49
LVDS Channel A Connector.....	25	Installing a Wireless LAN Module (full-size).....	50
LVDS Channel B Connector .....	26	Installing a GPS Module .....	51
LVDS Backlight Connector .....	26	Installing Antennas .....	53
Line-in 1 Pin Header .....	27	Installing a SIM Card .....	54
Line-in 2 Pin Header .....	27	Installing a CompactFlash Card .....	55
SATA1 Connector.....	28	Wallmount Brackets.....	56
SATA2 Connector.....	28		
SATA3 Connector.....	29	<b>Chapter 4: BIOS Setup</b>	
SATA1 Power Connector .....	29	About BIOS Setup .....	57
SATA2 Power Connector .....	30	When to Configure the BIOS.....	57
SATA3 Power Connector .....	30	Default Configuration .....	58
GPS JST Connector.....	31	Entering Setup .....	58
USB 2.0 JST Connector.....	31	Legends .....	58
PCIe x8 Slot.....	32	BIOS Setup Utility.....	60
COM4 RI# Pin Header .....	33	Main .....	60
Mini-PCIe Connector.....	34	Advanced .....	61
GPIO Pin Header .....	35	Chipset.....	71
GPIO LED Pin Header.....	35	Boot.....	80
Smart Fan1 Connector .....	36	Security .....	82
Smart Fan2 Connector .....	36	Save & Exit .....	82
Internal LED Pin Header.....	37		
Reset JST Connector.....	37	<b>Appendix A: Power Consumption.....</b>	<b>83</b>
		<b>Appendix B: GPI/O Programming Guide.....</b>	<b>85</b>
<b>Chapter 3: System Setup</b>		<b>Appendix C: Watchdog Timer Setting.....</b>	<b>87</b>
Removing the Chassis Bottom Cover .....	38		
Installing a SATA Hard Drive .....	39		

# PREFACE

## Copyright

This publication, including all photographs, illustrations and software, is protected under international copyright laws, with all rights reserved. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written consent from EXOR International S.p.A.

## Disclaimer

The information in this document is subject to change without prior notice and does not represent commitment from EXOR International S.p.A. However, users may update their knowledge of any product in use by constantly checking its manual posted on our website: <http://www.exorint.net>. EXOR shall not be liable for direct, indirect, special, incidental, or consequential damages arising out of the use of any product, nor for any infringements upon the rights of third parties, which may result from such use. Any implied warranties of merchantability or fitness for any particular purpose is also disclaimed.

## Acknowledgements

eCC3600E Series is a trademark of EXOR International S.p.A. All other product names mentioned herein are registered trademarks of their respective owners.

## Regulatory Compliance Statements

This section describes how to keep the system CE compliant.

## Declaration of Conformity

### CE

The product(s) described in this manual complies with all applicable European Union (CE) directives if it has a CE marking. For computer systems to remain CE compliant, only CE-compliant parts may be used. Maintaining CE compliance also requires proper cable and cabling techniques.

## RoHS Compliance



### EXOR RoHS Environmental Policy and Status Update

This publication, including all photographs, illustrations and software, is protected under international copyright laws, with all rights reserved. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written consent from EXOR International S.p.A.

RoHS restricts the use of Lead (Pb) < 0.1% or 1,000ppm, Mercury (Hg) < 0.1% or 1,000ppm, Cadmium (Cd) < 0.01% or 100ppm, Hexavalent Chromium (Cr6+) < 0.1% or 1,000ppm, Polybrominated biphenyls (PBB) < 0.1% or 1,000ppm, and Polybrominated diphenyl Ethers (PBDE) < 0.1% or 1,000ppm.

In order to meet the RoHS compliant directives, EXOR has established an engineering and manufacturing task force to implement the introduction of green products. The task force will ensure that we follow the standard EXOR development procedure and that all the new RoHS components and new manufacturing processes maintain the highest industry quality levels for which EXOR are renowned.

The model selection criteria will be based on market demand. Vendors and suppliers will ensure that all designed components will be RoHS compliant.

### How to recognize EXOR RoHS Products?

All new product models launched after January 2006 will be RoHS compliant. They will use the usual EXOR naming convention.

# Warranty and RMA

## EXOR Warranty Period

EXOR manufactures products that are new or equivalent to new in accordance with industry standard. EXOR warrants that products will be free from defect in material and workmanship for 2 years, beginning on the date of invoice by EXOR. HCP series products (Blade Server) which are manufactured by EXOR are covered by a three year warranty period.

## NEXCOM Return Merchandise Authorization (RMA)

- Customers shall enclose the “EXOR RMA Service Form” with the returned packages.
- Customers must collect all the information about the problems encountered and note anything abnormal or, print out any on-screen messages, and describe the problems on the “EXOR RMA Service Form” for the RMA number apply process.
- Customers can send back the faulty products with or without accessories (manuals, cable, etc.) and any components from the card, such as CPU and RAM. If the components were suspected as part of the problems, please note clearly which components are included. Otherwise, EXOR is not responsible for the devices/parts.
- Customers are responsible for the safe packaging of defective products, making sure it is durable enough to be resistant against further damage and deterioration during transportation. In case of damages occurred during transportation, the repair is treated as “Out of Warranty.”
- Any products returned by EXOR to other locations besides the customers’ site will bear an extra charge and will be billed to the customer.

## Repair Service Charges for Out-of-Warranty Products

EXOR will charge for out-of-warranty products in two categories, one is basic diagnostic fee and another is component (product) fee.

## Repair Service Charges for Out-of-Warranty Products

EXOR will charge for out-of-warranty products in two categories, one is basic diagnostic fee and another is component (product) fee.

### System Level

- Component fee: EXOR will only charge for main components such as SMD chip, BGA chip, etc. Passive components will be repaired for free, ex: resistor, capacitor.
- Items will be replaced with EXOR products if the original one cannot be repaired. Ex: motherboard, power supply, etc.
- Replace with 3rd party products if needed.
- If RMA goods can not be repaired, EXOR will return it to the customer without any charge.

### Board Level

- Component fee: EXOR will only charge for main components, such as SMD chip, BGA chip, etc. Passive components will be repaired for free, ex: resistors, capacitors.
- If RMA goods can not be repaired, EXOR will return it to the customer without any charge.

## Warnings

Read and adhere to all warnings, cautions, and notices in this guide and the documentation supplied with the chassis, power supply, and accessory modules. If the instructions for the chassis and power supply are inconsistent with these instructions or the instructions for accessory modules, contact the supplier to find out how you can ensure that your computer meets safety and regulatory requirements.

## Cautions

Electrostatic discharge (ESD) can damage system components. Do the described procedures only at an ESD workstation. If no such station is available, you can provide some ESD protection by wearing an antistatic wrist strap and attaching it to a metal part of the computer chassis.

## Safety Information

Before installing and using the device, note the following precautions:

- Read all instructions carefully.
- Do not place the unit on an unstable surface, cart, or stand.
- Follow all warnings and cautions in this manual.
- When replacing parts, ensure that your service technician uses parts specified by the manufacturer.
- Avoid using the system near water, in direct sunlight, or near a heating device.
- The load of the system unit does not solely rely for support from the rackmounts located on the sides. Firm support from the bottom is highly necessary in order to provide balance stability.
- The computer is provided with a battery-powered real-time clock circuit. There is a danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.



Danger of explosion if battery is incorrectly replaced. Replace with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

## Installation Recommendations

Ensure you have a stable, clean working environment. Dust and dirt can get into components and cause a malfunction. Use containers to keep small components separated.

Adequate lighting and proper tools can prevent you from accidentally damaging the internal components. Most of the procedures that follow require only a few simple tools, including the following:

- A Philips screwdriver
- A flat-tipped screwdriver
- A grounding strap
- An anti-static pad

Using your fingers can disconnect most of the connections. It is recommended that you do not use needle-nose pliers to disconnect connections as these can damage the soft metal or plastic parts of the connectors.



## Safety Precautions

1. Read these safety instructions carefully.
2. Keep this User Manual for later reference.
3. Disconnect this equipment from any AC outlet before cleaning. Use a damp cloth. Do not use liquid or spray detergents for cleaning.
4. For plug-in equipment, the power outlet socket must be located near the equipment and must be easily accessible.
5. Keep this equipment away from humidity.
6. Put this equipment on a stable surface during installation. Dropping it or letting it fall may cause damage.
7. The openings on the enclosure are for air convection to protect the equipment from overheating. **DO NOT COVER THE OPENINGS.**
8. Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
9. Place the power cord in a way so that people will not step on it. Do not place anything on top of the power cord. Use a power cord that has been approved for use with the product and that it matches the voltage and current marked on the product's electrical range label. The voltage and current rating of the cord must be greater than the voltage and current rating marked on the product.
10. All cautions and warnings on the equipment should be noted.
11. If the equipment is not used for a long time, disconnect it from the power source to avoid damage by transient overvoltage.
12. Never pour any liquid into an opening. This may cause fire or electrical shock.
13. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel.
14. If one of the following situations arises, get the equipment checked by service personnel:
  - a. The power cord or plug is damaged.
  - b. Liquid has penetrated into the equipment.
  - c. The equipment has been exposed to moisture.
  - d. The equipment does not work well, or you cannot get it to work according to the user's manual.
  - e. The equipment has been dropped and damaged.
  - f. The equipment has obvious signs of breakage.
15. Do not place heavy objects on the equipment.
16. The unit uses a three-wire ground cable which is equipped with a third pin to ground the unit and prevent electric shock. Do not defeat the purpose of this pin. If your outlet does not support this kind of plug, contact your electrician to replace your obsolete outlet.
17. **CAUTION: DANGER OF EXPLOSION IF BATTERY IS INCORRECTLY REPLACED. REPLACE ONLY WITH THE SAME OR EQUIVALENT TYPE RECOMMENDED BY THE MANUFACTURER. DISCARD USED BATTERIES ACCORDING TO THE MANUFACTURER'S INSTRUCTIONS.**

## Technical Support and Assistance

1. For the most updated information of EXOR products, visit EXOR's website at [www.exorint.net](http://www.exorint.net).
2. For technical issues that require contacting our technical support team or sales representative, please have the following information ready before calling:
  - Product name and serial number
  - Detailed information of the peripheral devices
  - Detailed information of the installed software (operating system, version, application software, etc.)
  - A complete description of the problem
  - The exact wordings of the error messages

### Warning!

1. Handling the unit: carry the unit with both hands and handle it with care.
2. Maintenance: to keep the unit clean, use only approved cleaning products or clean with a dry cloth.
3. CompactFlash: Turn off the unit's power before inserting or removing a CompactFlash storage card.

## Conventions Used in this Manual



### Warning:

Information about certain situations, which if not observed, can cause personal injury. This will prevent injury to yourself when performing a task.



### Caution:

Information to avoid damaging components or losing data.



### Note:

Provides additional information to complete a task easily.



**Safety Warning:** This equipment is intended for installation in a Restricted Access Location only.

## Package Contents

Before continuing, verify that the NISE 3600E package that you received is complete. Your package should have all the items listed in the following table.

Item	Description	Qty
1	Terminal Blocks 2P Phoenix Contact:1803578	2
2	Round Head Screw W/Spring+Flat Washer Long FEI:P3x6L	2
3	Flat Head Screw Long FEI:F#6-32x8	1
4	I Head Screw Long FEI:I2x4 NYLOK NIGP	2
5	Round Head Screw Long FEI:P6#32T T10 NYLOK	1
6	Flat Head Screw Long FEI:F3x5 NYLOK NI+Heat Treatment	4
7	Plastic Screw	1
8	Plastic Nut GIN LIAN:M6HW	1
9	Thermal Pad APUS:3A2015001001500	1
10	Cable EDI:231441090251-RS	1
11	DC Cord EDI:281040051051-RS	1

## Ordering Information

The following information below provides ordering information for eCC3600E Series.

- **Barebone**

**eCC3600E (P/N: 70ECC3600E)**

- 3rd Generation Intel® Core™ i5/i3 Fanless System with one PCIe x4 Expansion

**eCC3600P2E (P/N: 70ECC3600P2E)**

- 3rd Generation Intel® Core™ i5/i3 Fanless System with one PCIe x4 Expansion and one PCI Expansion



Optional Power Adapter: Suggest to use an appropriate AC/DC power adapter compliant with CE or UL safety regulations.

# CHAPTER 1: PRODUCT INTRODUCTION

## Overview



## Key Features

- Support 3rd generation Intel® Core™ i5/ i3 rPGA socket type processor
- Mobile Intel® QM77 PCH
- Support 1x 2.5" SATA HDD or 2x SATA DOM
- 1x VGA, 1x DVI-D and 2x Display port with Independent Display support
- Dual Intel® GbE LAN ports
- 4x USB 3.0, 2x USB 2.0, 5x RS232 and 1x RS232/422/485
- 1x internal mini-PCIe with two antenna holes
- 1x PCIe4 Expansion and 1x external CFast socket
- Support 9V~30V DC input
- Support ATX power mode, WoL, LAN teaming and PXE function

# Hardware Specifications

## CPU Support

- Support 3rd generation Intel® Core™ i5/i3 rPGA Socket Type Processor
  - Core™ i5-3610ME, Dual Core, 2.7GHz, 3M Cache
  - Core™ i3-3120ME, Dual Core, 2.4GHz, 3M Cache
  - Support Three Independent Display with above processors
- Support 2nd generation Intel® Core™ i5/i3 rPGA Socket Type Processor
  - Core™ i5-2510E, Dual Core, 2.5GHz, 3M Cache
  - Core™ i3-2330E 2.2GHz, 3M Cache
  - Celeron® B810, Dual Core, 1.6GHz, 2M Cache
  - Support Dual Independent Display with above processors

## Main Memory

- 2x DDR3 SO-DIMM socket, supports up to 8GB DDR3/ DDR3L 1333/ 1600 SDRAM, with un-buffered and non-ECC

## Display Option

- Three Independent Display (only support on 3rd Generation Processor)
  - Two Display Port and 1x VGA
  - Two Display Port and 1x DVI-D
- Dual Independent Display
  - VGA and DVI-D
  - Display Port and VGA
  - Display Port and DVI-D

## I/O Interface-Front

- ATX power on/ off switch
- HDD Access/ Power status LEDs
- 2x USB3.0 ports (Blue Color)
- 2x Display Port (Can be converted to DVI-D or HDMI via cables)
- 2x Antenna holes
- 1x external CFast (optional)
- 1x SIM card socket

## I/O Interface-Rear

- 2x DB9 for COM5 & COM6 (RS232)
- 1x DB44 Serial Port, 4x COM port
  - COM1/COM3/COM4: RS232
  - COM2: RS232/422/485
- 2x Intel® GbE LAN ports (Intel 82574L and 82579LM)
- 2x USB2.0 ports
- 2x USB3.0 ports (Blue Color)
- 1x DB15 VGA port
- 1x DVI-D port
- 1x Line-out and 1x Mic-in
- 2-pin Remote Power on/ off switch
- 9~30V DC input

## Storage Device

- 1x CFast socket
- 1x 2.5" SATA HDD or 2x SATA DOM
- SATA DOM: support 90 degree horizontal type only

## Expansion Slot

- 1x miniPCIe socket (support optional WiFi or 3.5G module)
- eCC3600E: one PCIe x4 Expansion Slot
  - Add-on card length: 169mm max.
  - Power consumption: 10W/slot max.
- eCC3600P2E: one PCIe x4 Expansion and one PCI Expansion
  - Add-on card length: 169mm max./PClex4 expansion and 240mm max./PCI expansion
  - Power consumption: 10W/slot max.

## Power Requirements

- ATX power mode
- On-board DC to DC power support from 9V to 30V DC
- Optional power adapter

## Dimensions

eCC3600E

- 215mm (W) x 272mm (D) x 93mm (H) without wall mount bracket

eCC3600P2E

- 215mm (W) x 272mm (D) x 114mm (H) without wall mount bracket

## Construction

- Aluminum Chassis with fanless design

## Environment


- Operating temperature:  
Ambient with air flow: -5°C ~ 55°C  
(According to IEC60068-2-1, IEC60068-2-2, IEC60068-2-14)
- Storage temperature: -20°C ~ 80°C
- Relative humidity: 95% at 40 degree C
- Shock protection: 20G, half sine, 11ms, IEC60068-2-27
- Vibration protection  
Random: 0.5Grms @5~500 Hz according to IEC60068-2-64  
Sinusoidal: 0.5Grms @5~500 Hz according to IEC60068-2-6

## Certifications

- CE approval

# Knowing Your eCC3600E

## Front Panel



### USB 3.0

Dual USB 3.0 ports to connect the system with USB 3.0/2.0 devices.

### Antenna Hole

Used to install external antennas.

### Display Ports

Dual DisplayPort to connect the system with display devices.

### SIM

Used to insert a SIM card.

### CFast Socket

Used to insert a CompactFlash card.

### Power/HDD/LAN LED


Indicates the power status, hard drive and LAN activity of the system.

### Power Switch

Press to power-on or power-off the system.



## Rear Panel



### Remote Power On/Off

Used to connect a remote to power on/off the system.

### Digital Output

Support S3 Wake on LAN.

### 9-30V DC Input

Used to plug a DC power cord.

### COM5 and COM6

Two DB9 ports used to connect RS232 compatible devices.

### COM1 to COM4

The DB44 port supports three RS232 and one RS232/422/485 compatible serial devices.

### LAN

Used to connect the system to a local area network.

### USB 3.0

Used to connect USB 3.0/2.0 devices.

### USB 2.0

Used to connect USB 2.0/1.1 devices.

### VGA

Used to connect an analog VGA monitor.

### DVI-D

Used to connect a digital LCD panel.

### Line-out


Used to connect a headphone or a speaker.

### Mic-in


Used to connect an external microphone.

# Mechanical Dimensions

## eCC3600E



# eCC3600P2E



# CHAPTER 2: JUMPERS AND CONNECTORS

This chapter describes how to set the jumpers and connectors on the eCC3600E motherboard.

## Before You Begin

- Ensure you have a stable, clean working environment. Dust and dirt can get into components and cause a malfunction. Use containers to keep small components separated.
- Adequate lighting and proper tools can prevent you from accidentally damaging the internal components. Most of the procedures that follow require only a few simple tools, including the following:
  - A Philips screwdriver
  - A flat-tipped screwdriver
  - A set of jewelers screwdrivers
  - A grounding strap
  - An anti-static pad
- Using your fingers can disconnect most of the connections. It is recommended that you do not use needle-nosed pliers to disconnect connections as these can damage the soft metal or plastic parts of the connectors.
- Before working on internal components, make sure that the power is off. Ground yourself before touching any internal components, by touching a metal object. Static electricity can damage many of the electronic components. Humid environments tend to have less static electricity than

dry environments. A grounding strap is warranted whenever danger of static electricity exists.

## Precautions

Computer components and electronic circuit boards can be damaged by discharges of static electricity. Working on computers that are still connected to a power supply can be extremely dangerous.

Follow the guidelines below to avoid damage to your computer or yourself:


- Always disconnect the unit from the power outlet whenever you are working inside the case.
- If possible, wear a grounded wrist strap when you are working inside the computer case. Alternatively, discharge any static electricity by touching the bare metal chassis of the unit case, or the bare metal body of any other grounded appliance.
- Hold electronic circuit boards by the edges only. Do not touch the components on the board unless it is necessary to do so. Don't flex or stress the circuit board.
- Leave all components inside the static-proof packaging that they shipped with until they are ready for installation.
- Use correct screws and do not over tighten screws.

## Jumper Settings


A jumper is the simplest kind of electric switch. It consists of two metal pins and a cap. When setting the jumpers, ensure that the jumper caps are placed on the correct pins. When the jumper cap is placed on both pins, the jumper is short. If you remove the jumper cap, or place the jumper cap on just one pin, the jumper is open.

Refer to the illustrations below for examples of what the 2-pin and 3-pin jumpers look like when they are short (on) and open (off).

Two-Pin Jumpers: Open (Left) and Short (Right)




Three-Pin Jumpers: Pins 1 and 2 are Short




## Locations of the Jumpers and Connectors for NISB 3600

### NISB 3600

The figure below is the top view of the NISB 3600 main board which is the main board used in the eCC3600E system. It shows the locations of the jumpers and connectors.



The figure below is the bottom view of the NISB 3600 main board.



## Jumpers

### CMOS Clear Select

Connector type: 1x3 3-pin header, 2.54mm pitch

Connector location: JP4



Pin	Settings
1-2 On	Normal
2-3 On	Clear BIOS

1-2 On: default

Pin	Definition
1	RTC_RST#_PU
2	RTC_RST#
3	CLR_CMOS

### ME Pin Header

Connector type: 1x3 3-pin header, 2.54mm

Connector location: JP5



Pin	Definition
1	SRTC_RST#_PU
2	SRTC_RST#
3	CLR_ME

1-2 On: default



## LVDS Power Pin Header

Connector type: 1x3 3-pin header, 2.54mm

Connector location: JP6



Pin	Definition
1	VCC3
2	VCCLCDIN
3	VCC5

1-2 On: default


## Connector Pin Definitions

### External I/O Interfaces - Front Panel

#### USB 3.0

Connector type: Dual USB 3.0 ports

Connector location: USB1




Pin	Definition	Pin	Definition
1	VCC5	2	USB2_2N
3	USB2_2P	4	GND
5	USB3_RX2_N	6	USB3_RX2_P
7	GND	8	USB3_TX2_N
9	USB3_TX2_P	10	VCC5
11	USB2_3N	12	USB2_3P
13	GND	14	USB3_RX3_N
15	USB3_RX3_P	16	GND
17	USB3_TX3_N	18	USB3_TX3_P
MH1	GND	MH2	GND
MH3	GND	MH4	GND

#### DisplayPort A

Connector type: DisplayPort

Connector location: J10



Pin	Definition	Pin	Definition
1	DPC_LANE0_P	2	GND
3	DPC_LANE0_N	4	DPC_LANE1_P
5	GND	6	DPC_LANE1_N
7	DPC_LANE2_P	8	GND
9	DPC_LANE2_N	10	DPC_LANE3_P
11	GND	12	DPC_LANE3_N
13	DPC_CONFIG1	14	DPC_CONFIG2
15	DPC_AUX_P	16	GND
17	DPC_AUX_N	18	DPC_HPD
19	GND	20	VCC3
MH1	GND	MH2	GND
MH3	GND	MH4	GND




While using DisplayPort to HDMI cable or DisplayPort to DVI cable, the cable must be active type.

## DisplayPort B

Connector type: DisplayPort

Connector location: J8



Pin	Definition	Pin	Definition
1	DPD_LANE0_P	2	GND
3	DPD_LANE0_N	4	DPD_LANE1_P
5	GND	6	DPD_LANE1_N
7	DPD_LANE2_P	8	GND
9	DPD_LANE2_N	10	DPD_LANE3_P
11	GND	12	DPD_LANE3_N
13	DPD_CONFIG1	14	DPD_CONFIG2
15	DPD_AUX_P	16	GND
17	DPD_AUX_N	18	DPD_HPD
19	GND	20	VCC3
MH1	GND	MH2	GND
MH3	GND	MH4	GND




While using DisplayPort to HDMI cable or DisplayPort to DVI cable, the cable must be active type.

## CompactFlash

Connector type: CompactFlash Type 2


Connector location: CN3



Pin	Definition	Pin	Definition
S1	GND	PC6	NC
S2	SATA_TXP3	PC7	GND
S3	SATA_TXN3	PC8	CFAST_LED1_C
S4	GND	PC9	CFAST_LED2_C
S5	SATA_RXN3	PC10	NC
S6	SATA_RXP3	PC11	NC
S7	GND	PC12	NC
PC1	CFAST_CDI	PC13	VCC3
PC2	GND	PC14	VCC3
PC3	NC	PC15	GND
PC4	NC	PC16	GND
PC5	NC	PC17	CFAST_CDO

## SIM Card Connector

Connector location: IDE1



Pin	Definition	Pin	Definition
C1	UIM_PWR	C2	UIM_RESET
C3	UIM_CLK	C5	GND
C6	UIM_VPP	C7	UIM_DATA
SW	GND		

## Power Switch

Connector location: SW1




Pin	Definition	Pin	Definition
1	GND	2	PBT_PU
3	PBT_PU	4	GND
A1	PWRLED_N	C1	PWRLED_P
MH1	NC	MH2	NC

## External I/O Interfaces - Rear Panel

### Remote Power on/off Switch

Connector type: 4-pin switch

Connector location: J2




Pin	Definition	Pin	Definition
1	GND	2	PBT_PU
3	SLP_S3#	4	GND

### DC-in Power Jack

Connector type: 4-pin DC Jack

Connector location: CN1




Pin	Definition	Pin	Definition
1	VIN	2	VIN
3	GND	4	GND
5	GND	MH1	GND
MH2	GND	MH3	GND
MH4	GND		


## Serial Interface (COM 1 - COM 4)

Connector type: 44-pin D-Sub, 2x22 (12.55mm x 53.04mm)

Connector location: CN2



The 44-pin D-Sub connector is used to connect 4 external serial devices. Use the COM ports on the provided “DB44 to 4x DB9 COM port cable” (included in the package) to connect the devices.



DB44	COM1, COM2, COM3, COM4
COM1	RS232
COM2	RS232, RS422, RS485
COM3	RS232
COM4	RS232

Pin	Definition	Pin	Definition
1	COM1_DCD	2	COM1_RXD
3	COM1_TXD	4	COM1_DTR
5	GND	6	COM1_DSR
7	COM1_RTS	8	COM1_CTS
9	COM1_RI	10	GND
11	COM2_DCD	12	COM2_RXD
13	COM2_TXD	14	COM2_DTR
15	GND	16	COM2_DSR
17	COM2_RTS	18	COM2_CTS
19	COM2_RI	20	GND
21	COM3_DCD	22	COM3_RXD
23	COM3_TXD	24	COM3_DTR
25	GND	26	COM3_DSR
27	COM3_RTS	28	COM3_CTS
29	COM3_RI	30	GND
31	COM4_DCD	32	COM4_RXD
33	COM4_TXD	34	COM4_DTR
35	GND	36	COM4_DSR
37	COM4_RTS	38	COM4_CTS
39	COM4_RI	40	GND
41	NC	42	NC
43	NC	44	NC
MH1	GND	MH2	GND

COM1 (RS232) labeled "A" on DB9 Cable Connector					
DB44 Pin #	DB9 Pin #	Def.	DB44 Pin #	DB9 Pin #	Def.
1	1	DCD1	2	2	RXD1
3	3	TXD1	4	4	DTR1
5	5	GND	6	6	DSR1
7	7	RTS1	8	8	CTS1
9	9	RI1	10		GND

COM4 labeled "D" on DB9 Cable Connector					
DB44 Pin #	DB9 Pin #	Def.	DB44 Pin #	DB9 Pin #	Def.
31	1	DCD4	32	2	RXD1
33	3	TXD4	34	4	DTR1
35	5	GND	36	6	DSR1
37	7	RTS4	38	8	CTS1
39	9	RI4	40		GND

Note: Pin 39 is defined as an external power source, which can be selected for 5V or 12V using JP1.

COM2 (RS232) labeled "B" on DB9 Cable Connector					
DB44 Pin #	DB9 Pin #	Def.	DB44 Pin #	DB9 Pin #	Def.
11	1	DCD2	12	2	RXD2
13	3	TXD2	14	4	DTR2
15	5	GND	16	6	DSR2
17	7	RTS2	18	8	CTS2
19	9	RI2	20		GND

COM2 (RS422) labeled "B" on DB9 Cable Connector					
DB44 Pin #	DB9 Pin #	Def.	DB44 Pin #	DB9 Pin #	Def.
11	1	TXD-	12	2	TXD+
13	3	RXD+	14	4	RXD-
15	5	GND	16	6	RTS-
17	7	RTS#	18	8	CTS+
19	9	CTS-	20		GND

COM3 (RS232) labeled "C" on DB9 Cable Connector					
DB44 Pin #	DB9 Pin #	Def.	DB44 Pin #	DB9 Pin #	Def.
21	1	DCD3	22	2	RXD3
23	3	TXD3	24	4	DTR3
25	5	GND	26	6	DSR3
27	7	RTS3	28	8	CTS3
29	9	RI3	30		GND


COM2 (RS485) labeled "B" on DB9 Cable Connector					
DB44 Pin #	DB9 Pin #	Def.	DB44 Pin #	DB9 Pin #	Def.
11	1	TXD-	12	2	TXD+
		RXD-			RXD+
13	3	Reserved	14	4	Reserved
15	5	Reserved	16	6	Reserved
17	7	Reserved	18	8	Reserved
19	9	Reserved	20		Reserved

## COM 5 and COM 6 Ports

Connector type: DB-9 port, 9-pin D-Sub

2x10 20-pin header, 1.25mm pitch

Connector location: CN16




Pin	Definition	Pin	Definition
1	SP5_DCD	2	SP6_DCD
3	SP5_TXD	4	SP6_TXD
5	SP5_RTS	6	SP6_RTS
7	SP5_RI	8	SP6_RI
9	GND	10	GND
11	SP5_RXD	12	SP6_RXD
13	SP5_DTR	14	SP6_DTR
15	SP5_DSR	16	SP6_DSR
17	SP5_CTS	18	SP6_CTS
19	GND	20	GND
MH1	GND	MH2	GND

## LAN1 and USB 3.0 Ports

Connector type: RJ45 port with LEDs and dual USB 3.0 ports

Connector location: CON2B (LAN1) and CON2A (USB)



Act	Status
Flashing Yellow	Data activity
Off	No activity

Link	Status
Steady Green	1G network link
Steady Orange	100Mbps network link
Off	No link

## LAN1

Pin	Definition	Pin	Definition
19	VCT	20	LAN1_MDI0P
21	LAN1_MDI0N	22	LAN1_MDI1P
23	LAN1_MDI1N	24	LAN1_MDI2P
25	LAN1_MDI2N	26	LAN1_MDI3P
27	LAN1_MDI3N	28	GND
29	V3_3M	30	LAN1_LED_ACT#
31	LAN1_LED100#	32	LAN1_LED1000#
MH5	GND	MH6	GND
MH7	GND	MH8	GND




## USB

Pin	Definition	Pin	Definition
1	VCC5	2	USB2_ON
3	USB2_OP	4	GND
5	USB3_RX0_N	6	USB3_RX0_P
7	GND	8	USB3_TX0_N
9	USB3_TX0_P	10	VCC5
11	USB2_1N	12	USB2_1P
13	GND	14	USB3_RX1_N
15	USB3_RX1_P	16	GND
17	USB3_TX1_N	18	USB3_TX1_P
MH1	GND	MH2	GND
MH3	GND	MH4	GND

## LAN2 and USB 2.0 Ports

Connector type: RJ45 port with LEDs and dual USB 2.0 ports, Type A  
Connector location: CON3B (LAN2) and CON3A (USB)



Act	Status
Flashing Yellow	Data activity
Off	No activity

Link	Status
Steady Green	1G network link
Steady Orange	100Mbps network link
Off	No link

## LAN2

Pin	Definition	Pin	Definition
9	V1_9	10	LAN2_MDI0P
11	LAN2_MDI0N	12	LAN2_MDI1P
13	LAN2_MDI1N	14	LAN2_MDI2P
15	LAN2_MDI2N	16	LAN2_MDI3P
17	LAN2_MDI3N	18	GND
19	LAN2_LINK100#	20	LAN2_LINK1000#
21	LAN2_LED_ACT#	22	3VSB
MH5	GND	MH6	GND
MH7	GND	MH8	GND

## USB



Pin	Definition	Pin	Definition
1	VCC5	2	USB2_8N
3	USB2_8P	4	GND
5	VCC5	6	USB2_9N
7	USB2_9P	8	GND
MH1	GND	MH2	GND
MH3	GND	MH4	GND

## VGA and DVI-D Connectors

Connector type: DB-15 port, 15-pin D-Sub (VGA)

24-pin D-Sub, 2.0mm-M-180 (DVI)

Connector location: CN15B (VGA) and CN15A (DVI-D)



## DVI-D

Pin	Definition	Pin	Definition
1	TX2-	2	TX2+
3	GND	4	NC
5	NC	6	DDC_CLK
7	DDC_DATA	8	NC
9	TX1-	10	TX1+
11	GND	12	NC
13	NC	14	DVI_VCC(+5V)
15	GND	16	HotPlugDet
17	TX0-	18	TX0+
19	GND	20	NC
21	NC	22	NC
23	TXCLK+	24	TXCLK-


## VGA

Pin	Definition	Pin	Definition
25	VGA_RED	26	VGA_GREEN
27	VGA_BLUE	28	GND
29	GND	30	VGA_DET
31	GND	32	GND
33	VCC5	34	GND
35	GND	36	DDC_DATA
37	VGA_HSYNC	38	VGA_VSYNC
39	DDC_CLK	MH3	GND
MH4	GND		

## Audio Connectors

Connector type: 2x 3.5mm TRS

Connector location: CN9A (Mic-in) and CN9B (Line-out)



Pin	Definition	Pin	Definition
1	GND	2	MIC_L
3	GND	4	MIC_JD
5	MIC_R	MH1	GND
MH2	GND	MH3	GND
MH4	GND	22	FRONT_L
23	GND	24	FRONT-JD
25	FRONT_R	MH1	NC

## Internal Connectors

### SIM Card Line-out Pin Header

Connector type: 1x3 3-pin header, 2.0mm

Connector location: JP8



Pin	Definition
1	LOUT_RL
2	LOUT_RR
3	ANGND

### SIM Card Mic-in Pin Header

Connector type: 1x3 3-pin header, 2.0mm

Connector location: JP9




Pin	Definition
1	SRTC_RST#_PU
2	SRTC_RST#
3	CLR_ME

## DC-in Power Connector

Connector type: 2x2 4-pin header

Connector location: CON1




Pin	Definition
1	GND
2	GND
3	VIN
4	VIN

## LVDS Channel A Connector

Connector type: 2x10 20-pin header, 1.25mm pitch

Connector location: CN8




Pin	Definition	Pin	Definition
1	DDC_CLK	2	DDC_DATA
3	VDD	4	LVDSA_DATAP0
5	LVDSA_DATAP3	6	LVDSA_DATANO
7	LVDSA_DATAN3	8	VDD
9	GND	10	LVDSA_DATAP1
11	LVDSA_CLKP	12	LVDSA_DATAN1
13	LVDSA_CLKN	14	GND
15	GND	16	PANEL1_BACKLIGHT
17	LVDSA_DATAP2	18	LVDSA_BACKLIGHT
19	LVDSA_DATAN2	20	GND
MH1	GND	MH2	GND

## LVDS Channel B Connector

Connector type: 2x10 20-pin header, 1.25mm pitch

Connector location: CN14




Pin	Definition	Pin	Definition
1	DDC_CLK	2	DDC_DATA
3	VDD	4	LVDSB_DATAP0
5	LVDSB_DATAP3	6	LVDSB_DATAN0
7	LVDSB_DATAN3	8	VDD
9	GND	10	LVDSB_DATAP1
11	LVDSB_CLKP	12	LVDSB_DATAN1
13	LVDSB_CLKN	14	GND
15	GND	16	PANEL1_BACKLIGHT
17	LVDSB_DATAP2	18	LVDSB_BACKLIGHT
19	LVDSB_DATAN2	20	GND
MH1	GND	MH2	GND

## LVDS Backlight Connector

Connector type: 1x7 JST, 7-pin header, 2.5mm pitch

Connector location: J11



Pin	Definition	Pin	Definition
1	VCC5	2	PANEL1_BACKLIGHT
3	PANEL1_BACKLIGHT	4	L_BKLTCTL
5	GND	6	GND
7	L_BKLTEN		

## Line-in 1 Pin Header

Connector type: 1x4 4-pin header, 2.5mm pitch  
Connector location: JP10



Pin	Definition
1	LINE1-L
2	GND
3	LINE1-JD
4	LINE1-R

## Line-in 2 Pin Header

Connector type: 1x4 4-pin header, 2.5mm pitch  
Connector location: JP11




Pin	Definition
1	LINE2-L
2	GND
3	LINE2-JD
4	LINE2-R

## SATA1 Connector

Connector type: Standard Serial ATAII 7P (1.27mm, SATA-M-180)

Connector location: CN12




Pin	Definition	Pin	Definition
1	GND	2	SATA_TXP0
3	SATA_TXN0	4	GND
5	SATA_RXN0	6	SATA_RXP0
7	GND		

## SATA2 Connector

Connector type: Standard Serial ATAII 7P (1.27mm, SATA-M-180)

Connector location: CN13




Pin	Definition	Pin	Definition
1	GND	2	SATA_TXP1
3	SATA_TXN1	4	GND
5	SATA_RXN1	6	SATA_RXP1
7	GND		



## SATA3 Connector

Connector type: Standard Serial ATAII 7P (1.27mm, SATA-M-180)

Connector location: CN10




Pin	Definition	Pin	Definition
1	GND	2	SATA_TXP2
3	SATA_TXN2	4	GND
5	SATA_RXN2	6	SATA_RXP2
7	GND		

## SATA1 Power Connector

Connector type: 1x2 2-pin header, 2.54mm pitch


Connector location: J12



Pin	Definition
1	VCC5
2	GND

## SATA2 Power Connector


Connector type: 1x2 2-pin header, 2.54mm pitch  
Connector location: J13



Pin	Definition
1	VCC5
2	GND

## SATA3 Power Connector

Connector type: 1x2 4-pin Wafer, 2.54mm pitch  
Connector location: CN11



Pin	Definition
1	+12V
2	GND
3	GND
4	VCC5

## GPS JST Connector

Connector type: 1x6 JST, 6-pin header, 1.00mm pitch  
Connector location: J7



Pin	Definition	Pin	Definition
1	3VSB	2	GPS_LED
3	COM6_TXD	4	COM6_RXD
5	GND	6	VCC3
MH1	GND	MH2	GND

## USB 2.0 JST Connector

Connector type: 1x6 JST, 6-pin header, 2.00mm pitch  
Connector location: J4




Pin	Definition	Pin	Definition
1	VCC5	2	USB2_10N
3	USB2_10P	4	USB2_11N
5	USB2_11P	6	GND

## PCIe x8 Slot

Connector type: PCIe x8 Slot

Connector location: SLOT1



Pin	Definition	Pin	Definition
A1	PCIE_PRSENT1	B1	+12V
A2	+12V	B2	+12V
A3	+12V	B3	+12V
A4	GND	B4	GND
A5	NC	B5	SMB_CLK
A6	NC	B6	SMB_DATA
A7	NC	B7	GND
A8	NC	B8	VCC3
A9	VCC3	B9	NC
A10	VCC3	B10	3VSB
A11	PLT_RST_CPU_PCIE#	B11	PCIE_WAKE#
A12	GND	B12	NC
A13	CLK_PEG_P	B13	GND
A14	CLK_PEG_N	B14	PEG_TXP0
A15	GND	B15	PEG_TXN0
A16	PEG_RXP0	B16	GND
A17	PEG_RXN0	B17	PRSNT2_1
A18	GND	B18	GND
A19	NC	B19	PEG_TXP0
A20	GND	B20	PEG_TXN0
A21	PEG_RXP1	B21	GND

Pin	Definition	Pin	Definition
A22	PEG_RXN1	B22	GND
A23	GND	B23	PEG_TXP0
A24	GND	B24	PEG_TXN0
A25	PEG_RXP2	B25	GND
A26	PEG_RXN2	B26	GND
A27	GND	B27	PEG_TXP0
A28	GND	B28	PEG_TXN0
A29	PEG_RXP3	B29	GND
A30	PEG_RXN3	B30	NC
A31	GND	B31	PRSNT2_2
A32	NC	B32	GND
A33	NC	B33	PEG_TXP0
A34	GND	B34	PEG_TXN0
A35	PEG_RXP4	B35	GND
A36	PEG_RXN4	B36	GND
A37	GND	B37	PEG_TXP0
A38	GND	B38	PEG_TXN0
A39	PEG_RXP5	B39	GND
A40	PEG_RXN5	B40	GND
A41	GND	B41	PEG_TXP0
A42	GND	B42	PEG_TXN0
A43	PEG_RXP6	B43	GND
A44	PEG_RXN6	B44	GND
A45	GND	B45	PEG_TXP0
A46	GND	B46	PEG_TXN0
A47	PEG_RXP7	B47	GND
A48	PEG_RXN7	B48	PRSNT2_3
A49	GND	B49	GND

## COM4 RI# Pin Header

Connector type: 1x5 5-pin header, 2.00mm pitch


Connector location: JP1



Pin	Definition	Pin	Definition
1	VCC5	2	SP4_RI_T
3	+12V	4	SP4_RI_T
5	SP4_RI		

## Mini-PCle Connector

Connector location: CN6




Pin	Definition	Pin	Definition
1	MIC_R	2	3VSB
3	MIC_L	4	GND
5	LOUT_R	6	V1_5
7	LOUT_L	8	3VSB
9	GND	10	UIM_DATA
11	PCIE_MINI_CLK_N	12	UIM_CLK
13	PCIE_MINI_CLK_P	14	UIM_RESET
15	GND	16	UIM_VCCP
17	GND	18	GND
19	GND	20	3VSB
21	GND	22	PLT_RST
23	PCIE_MINI_RXN	24	3VSB
25	PCIE_MINI_RXP	26	GND

Pin	Definition	Pin	Definition
27	GND	28	V1_5
29	GND	30	SMB_CLK
31	PCIE_MINI_TXN	32	SMB_DATA
33	PCIE_MINI_TXP	34	GND
35	GND	36	USB_N
37	GND	38	USB_P
39	3VSB	40	GND
41	3VSB	42	WLAN_ACT
43	GND	44	WLAN_ACT
45	NA	46	WLAN_ACT
47	NA	48	V1_5
49	NA	50	GND
51	NA	52	3VSB

## GPIO Pin Header

Connector type: 2x5 10-pin header, 2.00mm pitch

Connector location: JP3




Pin	Definition	Pin	Definition
1	VCC5	2	GND
3	GPO24	4	GPI20
5	GPO25	6	GPI21
7	GPO26	8	GPI22
9	GPO27	10	GPI23

## GPIO LED Pin Header

Connector type: 2x2 4-pin header, 2.00mm pitch


Connector location: JP2



Pin	Definition
1	GPO24
2	GND
3	GPO25
4	GND

## Smart Fan1 Connector


Connector type: 1x4 4-pin Wafer, 2.54mm pitch  
Connector location: FAN1



Pin	Definition
1	GND
2	+12V
3	FAN_TAC1
4	FAN_CTL1

## Smart Fan2 Connector

Connector type: 1x4 4-pin Wafer, 2.54mm pitch  
Connector location: FAN2




Pin	Definition
1	GND
2	+12V
3	FAN_TAC2
4	FAN_CTL2



## Internal LED Pin Header


Connector type: 2x7 14-pin, 2.54mm pitch  
Connector location: J3



Pin	Definition
1	GND
2	+12V
3	FAN_TAC2
4	FAN_CTL2

## Reset JST Connector

Connector type: 1x2 2-pin header, 2.5mm pitch  
Connector location: J1



Pin	Definition
1	PM_RESET#_J
2	GND


## CHAPTER 3: SYSTEM SETUP

### Removing the Chassis Bottom Cover



Prior to removing the chassis cover, make sure the unit's power is off and disconnected from the power sources to prevent electric shock or system damage.

1. With the bottom side of the chassis facing up, remove the mounting screw of the bottom cover and then put them in a safe place for later use.



2. Lift up the cover and remove it from the chassis.

## Installing a SATA Hard Drive



1. Remove 4 screws around the empty HDD bracket.

2. Use the provided screws to secure the drive in place.




3. Connect the SATA data/power cable and fasten the cable to HDD bracket by provided screw.

4. Insert the HDD bracket onto the panel at a 45 degree angle, and gently slide the HDD bracket in place.



5. Connect the SATA data/power cable to the connector on the SATA drive then secure the HDD bracket to its original place.




SATA drive/bracket

SATA data/power cable

## Installing a SATA DOM


1. Remove the HDD bracket before installing a SATA DOM.
2. Locate the SATA connector on the board and fasten with the copper post included in the accessory package.



SATA Connector

Copper Post


3. Connect one side of power cable to the SATA DOM.



4. Install the SATA DOMM and connect the other side of SATA power cable to the SATA power connector.



The SATA DOMM is locked after installation. Be sure to push the lock when releasing.



**SATA Connector**  
**Power Connector**

**Screw**

5. Fasten the screw on the top of copper post.




## Installing a PCIe/PCI Expansion Card

### Note:

eCC3600E is equipped with one PCIe x4 expansion slot.  
eCC3600P2E is equipped with one PCIe x4 expansion slot and one PCI expansion slot.


1. Remove the chassis bottom cover.
2. Remove screws of the riser bracket.



Note: Example shown is eCC3600P2E



3. Remove screws on the expansion cover.





Note: Example shown is eCC3600P2E

4. Insert PCIe/PCI expansion card and fasten the screw.



5. Secure the riser bracket to its original position.

## Removing the Chassis Top Cover


1. Remove the mounting screw on the top cover and then put them in a safe place for later use.




2. Lift up the cover and remove it from the chassis.

## Installing a CPU


1. With the top cover removed, locate and remove the CPU heatsink on the board by loosening the mounting screws.



2. Locate the CPU socket.




3. Install the CPU and lock it.



**Mounting Screw**

5. Fix the thermal pad in the center of the CPU.



**Thermal pad**

4. Take out the small thermal pad in the accessory bag and remove the release paper on both sides of the thermal pad.



**Thermal pad & Release paper**



**Thermal pad & Release paper**

Warning: Must remove release paper before using.


6. Fasten the CPU heatsink in its original place.



**CPU Heatsink**

## Installing a SO DIMM

1. Locate the SO DIMM socket.



SO DIMM Socket

2. Release the lock on the SO DIMM socket.



Lock

3. Insert the module into the socket at a 90 degree angle. Apply firm even pressure to each end of the module until it slips into the socket.



SO DIMM

4. While pushing the SO DIMM into the position, the lock will close automatically.



## Installing a Wireless LAN Module (half-size)

1. Locate the Mini PCI Express slot on the board.



Mini PCI Express Slot

2. Fasten the Wireless LAN module with the mini PCI express bracket.



Screw

3. Insert the wireless LAN module into the Mini PCI Express slot at a 45 degree angle until the gold-plated connector on the edge of the module completely disappears inside the slot.



4. Push the module down and then secure it with mounting screws.



Screw

## Installing a Wireless LAN Module (full-size)

1. Locate the Mini PCI Express slot on the board.



Mini PCI Express Slot

2. Insert the wireless LAN module into the Mini PCI Express slot at a 45 degree angle until the gold-plated connector on the edge of the module completely disappears inside the slot.




3. Push the module down and then secure it with mounting screws.



Screw


## Installing a GPS Module

1. Locate the GPS module install location and remove the two screws on the board.




Screw

2. Fasten the copper post included in the accessory bag onto the screw holes.




Copper Post

3. Secure the GPS bracket on the copper post.



Screws

4. Secure the GPS module to the bracket.




5. Connect the GPS cable





## Installing Antennas

1. Remove the antenna hole covers located in the front panel.




2. Insert the antenna jack through the antenna hole.



3. Insert the 2 rings (ring 1 and ring2) onto the antenna jack.



4. Attach one end of the RF cable onto the module.



## Installing a SIM Card


1. Locate the SIM card on the front panel.



2. Push the yellow button to release the SIM card holder.



3. Place the SIM card to the SIM card holder and secure it to the original position.



## Installing a CompactFlash Card

1. The CompactFlash socket is located at the front side of the chassis.
4. Fasten CFast cover.



**CompactFlash**

2. Remove the mounting screws and cover of the CompactFlash socket.



**Mounting screw**


3. Insert the CFast.

## Wallmount Brackets

The wallmount brackets provides a convenient and economical way of mounting the system on the wall.

1. The mounting holes are located at the bottom of the system. Secure the brackets on each side of the system using the provided mounting screws.
2. Now mount the system on the wall by fastening screws through the bracket's mounting holes.

**Secure the bracket to the system**



**Fasten screws to mount the system to the wall**



# CHAPTER 4: BIOS SETUP

This chapter describes how to use the BIOS setup program for the eCC3600E series. The BIOS screens provided in this chapter are for reference only and may change if the BIOS is updated in the future.

To check for the latest updates and revisions, visit the EXOR Web site at [www.exorint.net](http://www.exorint.net).

## About BIOS Setup

The BIOS (Basic Input and Output System) Setup program is a menu driven utility that enables you to make changes to the system configuration and tailor your system to suit your individual work needs. It is a ROM-based configuration utility that displays the system's configuration status and provides you with a tool to set system parameters.

These parameters are stored in non-volatile battery-backed-up CMOS RAM that saves this information even when the power is turned off. When the system is turned back on, the system is configured with the values found in CMOS.

With easy-to-use pull down menus, you can configure such items as:

- Hard drives, diskette drives, and peripherals
- Video display type and display options
- Password protection from unauthorized use
- Power management features

The settings made in the setup program affect how the computer performs. It is important, therefore, first to try to understand all the setup options, and second, to make settings appropriate for the way you use the computer.

## When to Configure the BIOS

- This program should be executed under the following conditions:
- When changing the system configuration
- When a configuration error is detected by the system and you are prompted to make changes to the setup program
- When resetting the system clock
- When redefining the communication ports to prevent any conflicts
- When making changes to the Power Management configuration
- When changing the password or making other changes to the security setup

Normally, CMOS setup is needed when the system hardware is not consistent with the information contained in the CMOS RAM, whenever the CMOS RAM has lost power, or the system features need to be changed.

## Default Configuration

Most of the configuration settings are either predefined according to the Load Optimal Defaults settings which are stored in the BIOS or are automatically detected and configured without requiring any actions. There are a few settings that you may need to change depending on your system configuration.


## Entering Setup

When the system is powered on, the BIOS will enter the Power-On Self Test (POST) routines. These routines perform various diagnostic checks; if an error is encountered, the error will be reported in one of two different ways:














- If the error occurs before the display device is initialized, a series of beeps will be transmitted.
- If the error occurs after the display device is initialized, the screen will display the error message.

Powering on the computer and immediately pressing <Del> allows you to enter Setup. Another way to enter Setup is to power on the computer and wait for the following message during the POST:

TO ENTER SETUP BEFORE BOOT PRESS  +  + 

Press the  key to enter Setup:


## Legends

Key	Function
 	Moves the highlight left or right to select a menu.
 	Moves the highlight up or down between sub-menus or fields.
	Exits the BIOS Setup Utility.
	Scrolls forward through the values or options of the highlighted field.
	Scrolls backward through the values or options of the highlighted field.
	Selects a field.
	Displays General Help.
	Load previous values.
	Load optimized default values.
	Saves and exits the Setup program.
	Press <Enter> to enter the highlighted sub-menu


### Scroll Bar

When a scroll bar appears to the right of the setup screen, it indicates that there are more available fields not shown on the screen. Use the up and down arrow keys to scroll through all the available fields.

### Submenu

When “▶” appears on the left of a particular field, it indicates that a submenu which contains additional options are available for that field. To display the submenu, move the highlight to that field and press  .

## BIOS Setup Utility

Once you enter the AMI BIOS Setup Utility, the Main Menu will appear on the screen. The main menu allows you to select from several setup functions and one exit. Use arrow keys to select among the items and press  to accept or enter the submenu.

### Main

The Main menu is the first screen that you will see when you enter the BIOS Setup Utility.



### System Date

The date format is <day>, <month>, <date>, <year>. Day displays a day, from Monday to Sunday. Month displays the month, from January to December. Date displays the date, from 1 to 31. Year displays the year, from 1999 to 2099.

### System Time

The time format is <hour>, <minute>, <second>. The time is based on the 24-hour military-time clock. For example, 1 p.m. is 13:00:00. Hour displays hours from 00 to 23. Minute displays minutes from 00 to 59. Second displays seconds from 00 to 59.




## Advanced

The Advanced menu allows you to configure your system for basic operation. Some entries are defaults required by the system board, while others, if enabled, will improve the performance of your system or let you set some features according to your preference.




Setting incorrect field values may cause the system to malfunction.



## ACPI Settings


This section is used to configure ACPI Settings.



### Enable Hibernation

Enables or disables system ability to hibernate (OS/S4 Sleep State). This option may not be effective with some OS.


## ACPI Sleep State



Select the highest ACPI sleep state the system will enter when the suspend button is pressed. The options are Suspend Disabled, S1 (CPU Stop Clock) and S3 (Suspend to RAM).

## CPU Configuration

This section is used to configure the CPU.



### Hyper Threading

Enables or disables hyper-threading technology.

### Intel® Virtualization Technology

Enables or disables Intel® Virtualization technology.

## SATA Configuration

This section is used to configure the SATA drives.



### SATA Controller(s)

Enables or disables SATA device.

### SATA Mode Selection

Configures the SATA as IDE, AHCI or RAID mode.

- IDE This option configures the Serial ATA drives as Parallel ATA physical storage device.
- RAID This option allows you to create RAID or Intel Matrix Storage configuration on Serial ATA devices.
- AHCI This option configures the Serial ATA drives to use AHCI (Advanced Host Controller Interface). AHCI allows the storage driver to enable the advanced Serial ATA features which will increase storage performance.

### Serial ATA Port 0 to Serial ATA Port 3

Displays information on the SATA devices detected.

## AMT Configuration

This section is used to configure Active Management Technology (AMT) options.



### Intel® AMT

Enables or disables Intel® Active Management Technology.

### BIOS Hotkey Pressed

Enables or disables BIOS hotkey press.

### MEBx Selection Screen

Enables or disables MEBx selection screen.

## USB Configuration

This section is used to configure the USB.



### Legacy USB Support

Enable Enables Legacy USB.

Auto Disables support for Legacy when no USB devices are connected.


Disable Keeps USB devices available only for EFI applications.

### USB3.0 Support

Enables or disables USB 3.0 controller support.

## Super IO Configuration

This section is used to configure the serial ports.



### Super IO Chip

Displays the Super I/O chip used on the board.

## Serial Port 0 Configuration

This section is used to configure serial port 0.



### Serial Port

Enables or disables the serial port.

### Change Settings

Selects an optimal setting for the Super IO device.

### Onboard Serial Port Max Baud Rate

Select this to change the max baud rate of the serial port.

## Serial Port 1 Configuration

This section is used to configure serial port 1.

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.	
Advanced	
<b>Serial Port 1 Configuration</b>	Enable or Disable Serial Port (COM)
Serial Port	[Enabled]
Device Settings	IO=2F8h; IRQ=3;
Change Settings	[IO=2F8h; IRQ=3;]
Onboard Serial Port 1 Mode	[RS232]
Onboard Serial Port Max Baud Rate	[115200 bps]
→←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit	
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.	

### Serial Port

Enables or disables the serial port.

### Change Settings

Selects an optimal setting for the Super IO device.

### Onboard Serial Port 1 Mode

Select this to change the serial port mode to RS232, RS422, RS485 or RS485 Auto.

### Onboard Serial Port Max Baud Rate

Select this to change the max baud rate of the serial port.

## Serial Port 2 Configuration

This section is used to configure serial port 2.

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.	
Advanced	
<b>Serial Port 2 Configuration</b>	Enable or Disable Serial Port (COM)
Serial Port	[Enabled]
Device Settings	IO=3E8h; IRQ=10;
Change Settings	[IO=3E8h; IRQ=10;]
Onboard Serial Port Max Baud Rate	[115200 bps]
→←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit	
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.	

### Serial Port

Enables or disables the serial port.

### Change Settings

Selects an optimal setting for the Super IO device.

### Onboard Serial Port Max Baud Rate

Select this to change the max baud rate of the serial port.

## Serial Port 3 Configuration

This section is used to configure serial port 3.

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.	
Advanced	
<b>Serial Port 3 Configuration</b>	
Serial Port	[Enabled]
Device Settings	IO=2E8h; IRQ=11;
Change Settings	[IO=2E8h; IRQ=11;]
Onboard Serial Port Max Baud Rate	[115200 bps]
Enable or Disable Serial Port (COM)	
→←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit	
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.	

### Serial Port

Enables or disables the serial port.

### Change Settings

Selects an optimal setting for the Super IO device.

### Onboard Serial Port Max Baud Rate

Select this to change the max baud rate of the serial port.

## Serial Port 4 Configuration

This section is used to configure serial port 4.

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.	
Advanced	
<b>Serial Port 4 Configuration</b>	
Serial Port	[Enabled]
Device Settings	IO=2F0h; IRQ=6;
Change Settings	[IO=2F0h; IRQ=6;]
Onboard Serial Port Max Baud Rate	[115200 bps]
Enable or Disable Serial Port (COM)	
→←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit	
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.	

### Serial Port

Enables or disables the serial port.

### Change Settings

Selects an optimal setting for the Super IO device.

### Onboard Serial Port Max Baud Rate

Select this to change the max baud rate of the serial port.

## Serial Port 5 Configuration

This section is used to configure serial port 5.



### Serial Port

Enables or disables the serial port.

### Change Settings

Selects an optimal setting for the Super IO device.

### Onboard Serial Port Max Baud Rate

Select this to change the max baud rate of the serial port.

### Onboard Serial Port 6 Mode

Select this to change the serial port mode to RS232 or GPS.

## Smart Fan Function

This section is used to configure the fan's function.




### Smart Fan Mode

Selects the mode of the fan, the options are Full on Mode, Automatic Mode and Disable Mode.



## H/W Monitor

This section is used to monitor hardware status such as temperature, fan speed and voltages.



## Fan2 Speed

Detects and displays Fan2 speed.

## Vcore

Detects and displays the Vcore CPU voltage.

## 3.3V

Detects and displays 3.3V voltage.

## 5V

Detects and displays 5V voltage.

## 12V

Detects and displays 12V voltage.

## CPU Core Temperature

Detects and displays the current CPU temperature.

## System Temperature


Detects and displays the current system temperature.

## Fan1 Speed

Detects and displays Fan1 speed.

## CPU PPM Configuration

This section is used to configure the Processor Power Management (PPM) configuration.



### EIST

Enables or disables Intel® SpeedStep.

### CPU C3 Report

Enables or disables C3 report to the operating system.

### CPU C6 Report


Enables or disables C6 report to the operating system.

### CPU C7 Report

Enables or disables C7 report to the operating system.

## Chipset

This section gives you functions to configure the system based on the specific features of the chipset. The chipset manages bus speeds and access to system memory resources.



### System Agent (SA) Configuration


System Agent (SA) parameters.

### PCH-IO Configuration

PCH-IO parameters.

## PCH-IO Configuration

This section is used to configure PCH-IO configuration.



### LAN2 Controller

Enables or disables the onboard LAN2 controller.


### PCH LAN Controller

Enables or disables onboard NIC.

### Wake on LAN

Enables or disables integrated LAN to wake the system.

## USB Configuration



### EHCI1 and EHCI2

Enables or disables the Enhanced Host Controller Interface (USB 2.0), one EHCI controller must always be enabled.

## PCH Azalia Configuration



### Azalia

Control Detection of the Azalia device.


Disabled

Azalia will be unconditionally disabled.

Enabled

Azalia will be unconditionally disabled.

## Restore AC Power Loss



Select AC power state when power is re-applied after a power failure.

## System Agent (SA) Configuration

This section is used to configure the System Agent (SA) configuration.



### VT-d

Enables or disables VT-d function on MCH.

### Graphics Configuration

Configures the graphic chip settings.

### NB PCIe Configuration

Configures the NB PCI Express settings.

## Graphics Configuration



### Primary Display

Select which of IGFX/PEG/PCI graphics device should be primary display or select SG for switchable Gfx.


### Internal Graphics

Keep IGD enabled based on the setup options.


### DVMT Total Gfx Mem

Select DVMT5.0 Total Graphic Memory size used by the Internal Graphics Device.

## LCD Control




## Primary IGFX Boot Display




Select the video device which will be activated during POST. Has no effect if external graphics is present. Secondary boot display selection will appear based on your selection. VGA modes will be supported only on primary display.

## Secondary IGFX Boot Display




Select the secondary display device.

### LCD Panel Type



Select the LCD panel used by the internal graphics device by selecting the appropriate setup item.

### Active LFP




Select the Active LFP configuration.

No LVDS  
 Int-LVDS

VBIOS does not enable LVDS.  
 VBIOS enables LVDS driver by Integrated encoder.




### Panel Color Depth




Select the LFP Panel Color Depth.

### NB PCIe Configuration

This section is used to configure Northbridge PCI Express settings.




### PEG0 - Gen X



Configure PEG0 B0:D1:F0 Gen1-Gen3, IVB maximum Gen3, SNB maximum Gen2.

### PEG1 - Gen X



Configure PEG1 B0:D1:F1 Gen1-Gen3.


## Enable PEG

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.		
Chipset		
<b>NB PCIe Configuration</b>		To enable or disable the PEG.
<b>PEG0</b>	<b>Not Present</b>	
PEGO - Gen X	[Auto]	
<b>PEG1</b>	<b>Not Present</b>	
PEG1 - Gen X	[Auto]	
Enable PEG	[Enabled]	
		→←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.		

Enables or disables the PEG slot.

## Boot

This section is used to configure the boot features.



### Quiet Boot

Enabled            Displays OEM logo instead of the POST messages.  
 Disabled          Displays normal POST messages.

### Launch PXE OpROM Policy


Controls the execution of UEFI and legacy PXE OpROM.

### Boot Option Priorities

Adjust the boot sequence of the system. Boot Option #1 is the first boot device that the system will boot from, next will be #2 and so forth.


## Hard Drive BBS Priorities

### Boot Option #1




Sets the first legacy device to boot from.

## Boot Option #2



Sets the second legacy device to boot from.

## Boot Option #3



Sets the third legacy device to boot from.

## Security

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.					
Main	Advanced	Chipset	Boot	Security	Save & Exit
<p><b>Password Description</b></p> <p>If <b>ONLY</b> the Administrator's password is set, then this only limits access to Setup and is only asked for when entering Setup.</p> <p>If <b>ONLY</b> the User's password is set, then this is a power on password and must be entered to boot or enter Setup. In Setup the User Will have Administrator rights.</p> <p>The password length must be in the following range:</p> <p>Minimum length                    <b>3</b></p> <p>Maximum                               <b>20</b></p> <p>Administrator Password</p> <p>User Password</p>		<p>Set Administrator Password</p>			
		<p>→←: Select Screen</p> <p>↑↓: Select Item</p> <p>Enter: Select</p> <p>+/-: Change Opt.</p> <p>F1: General Help</p> <p>F2: Previous Values</p> <p>F3: Optimized Defaults</p> <p>F4: Save &amp; Exit</p> <p>ESC: Exit</p>			
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.					

### Administrator Password

Select this to reconfigure the administrator's password.

### User Password

Select this to reconfigure the user's password.

## Save & Exit

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.					
Main	Advanced	Chipset	Boot	Security	Save & Exit
<p>Save Changes and Reset</p> <p>Discard Changes and Reset</p> <p>Load Optimized Defaults</p>		<p>Reset the system after saving the changes.</p>			
		<p>→←: Select Screen</p> <p>↑↓: Select Item</p> <p>Enter: Select</p> <p>+/-: Change Opt.</p> <p>F1: General Help</p> <p>F2: Previous Values</p> <p>F3: Optimized Defaults</p> <p>F4: Save &amp; Exit</p> <p>ESC: Exit</p>			
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.					

### Save Changes and Reset

To save the changes and reset, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes.

### Discard Changes and Reset

To exit the Setup utility without saving the changes, select this field then press <Enter>. You may be prompted to confirm again before exiting.

### Load Optimized Defaults

To restore the BIOS to default settings, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes.

# APPENDIX A: POWER CONSUMPTION

## Test Configuration

System Configuration	Sys#1
Chassis	CHASSIS eCC3600 VER:A
CPU	Intel® Core™ i5 Ivy Bridge Processor 3M Cache, 2.30 GHz (ES)
Memory	ADATA 2GB DDR3 1600MHz SODIMM x2
CPU board	N/A
Mother board	NISB3600 REV:A
HDD	SATA2 HDD 2.5 250GB 7200RPM HTE725025A9A364
FDD	N/A
CD-ROM	N/A
CFast	Apacer CFast 8GB (81.3L040,DB30B)
Power Supply	POWER ADAPTER FSP180-AAAN1
Add-on Card	N/A
CPU Cooler	eCC3600E CPU HEATSINK SHYUNG SHUHN
System FAN	N/A
Keyboard	LEMEL B-5201-P
Mouse	GENIVS EASY MOUSE USB

## Power Consumption Management

### Purpose

The purpose of the power consumption test is to verify the power dissipation of system, and the loading of power supply.

### Test Equipment

PROVA CM-07 AC/DC CLAMP METER

### Device Under Test

DUT: sys#1/

### Test Procedure

1. Power up the DUT, boot into Windows XP SP3
2. Entering standby mode (HDD power down)
3. Measure the power consumption and record it.
4. Run Burn-in test program to apply 100% full loading
5. Measure the power consumption and record it.

### Test Data

	Sys #1
	+19V
Full-Loading Mode	2.78A
Total	52.82W
Standby S3Mode	0.13A
Total	2.47W



## APPENDIX B: GPIO PROGRAMMING GUIDE

GPIO (General Purpose Input/Output) pins are provided for custom system design. This appendix provides definitions and its default setting for the ten GPIO pins in the eCC3600 series. The pin definition is shown in the following table:

Pin	GPIO mode	PowerOn Default	Address	Pin	GPIO mode	PowerOn Default	Address
1	VCC	-	-	2	GND	-	-
3	GPO0	Low	A04h (Bit4)	4	GPI0	High	A04h (Bit0)
5	GPO1	Low	A04h (Bit5)	6	GPI1	High	A04h (Bit1)
7	GPO2	Low	A04h (Bit6)	8	GPI2	High	A04h (Bit2)
9	GPO3	Low	A04h (Bit7)	10	GPI3	High	A04h (Bit3)

Control the GPO pin (3/5/7/9) level from I/O port A04h bit (4/5/6/7).  
The bit is Set/Clear indicated output High/Low.

### GPIO programming sample code

```
#define GPIO_PORT      0xA04
#define GPO0          (0x01 << 4)
#define GPO1          (0x01 << 5)
#define GPO2          (0x01 << 6)
#define GPO3          (0x01 << 7)

#define GPO0_HI       outportb(GPIO_PORT, GPO0)
#define GPO0_LO       outportb(GPIO_PORT, 0x00)
#define GPO1_HI       outportb(GPIO_PORT, GPO1)
#define GPO1_LO       outportb(GPIO_PORT, 0x00)
#define GPO2_HI       outportb(GPIO_PORT, GPO2)
#define GPO2_LO       outportb(GPIO_PORT, 0x00)
#define GPO3_HI       outportb(GPIO_PORT, GPO3)
#define GPO3_LO       outportb(GPIO_PORT, 0x00)
void main(void)
{
    GPO0_HI;
    GPO1_LO;
    GPO2_HI;
    GPO3_LO;
}
```

# APPENDIX C: WATCHDOG TIMER SETTING

## ITE8783 WatchDog Programming Guide

```
#define SUPERIO_PORT    0x2E
#define WDT_SET        0x72
#define WDT_VALUE 0x73

void main(void)
{
    #Enter SuperIO Configuration
    outportb(SUPERIO_PORT, 0x87);
    outportb(SUPERIO_PORT, 0x01);
    outportb(SUPERIO_PORT, 0x55);
    outportb(SUPERIO_PORT, 0x55);

    # Set LDN
    outportb(SUPERIO_PORT, 0x07);
    outportb(SUPERIO_PORT+1 ,0x07);

    # Set WDT setting
    outportb(SUPERIO_PORT, WDT_SET);
    outportb(SUPERIO_PORT+1, 0xC0);           # Use the second
                                           # Use the minute, change value to 0x40

    # Set WDT sec/min
    outportb(SUPERIO_PORT, WDT_VALUE);
    outportb(SUPERIO_PORT+1, 0x05);         #Set 5 seconds
}
```