



# Emulex Driver Version 10.6 for FreeBSD

## User Manual

Copyright © 2012–2015 Emulex. All rights reserved worldwide. No part of this document may be reproduced by any means or translated to any electronic medium without the prior written consent of Emulex.

Information furnished by Emulex is believed to be accurate and reliable. However, no responsibility is assumed by Emulex for its use; or for any infringements of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under any patent, copyright or related rights of Emulex.

Emulex, the Emulex logo, Emulex BladeEngine, Emulex InSpeed, Emulex LightPulse, Emulex OneCommand, Emulex OneConnect, and Emulex SLI are registered trademarks, and Emulex Advanced-8, Emulex Connect, Emulex CrossLink, Emulex Engine, Emulex Edge, Emulex ExpressLane, Emulex GreenState, Emulex OneCore, Emulex Pilot, Emulex SURF, Emulex Universal Multi-Channel, Emulex vEngine, Emulex Virtual Fabric, Emulex Virtual Network Exceleration, Emulex vPath, and Emulex vScale, are trademarks, of Emulex. All other brand or product names referenced herein are trademarks or registered trademarks of their respective companies or organizations.

Emulex provides this manual "as is" without any warranty of any kind, either expressed or implied, including but not limited to the implied warranties of merchantability or fitness for a particular purpose. Emulex may make improvements and changes to the product described in this manual at any time and without any notice. Emulex assumes no responsibility for its use, nor for any infringements of patents or other rights of third parties that may result. Periodic changes are made to information contained herein; although these changes will be incorporated into new editions of this manual, Emulex disclaims any undertaking to give notice of such changes.

Emulex, 3333 Susan Street  
Costa Mesa, CA 92626

# Table of Contents

List of Tables .....	4
1. Introduction .....	5
Supported Versions and Adapters.....	5
Abbreviations .....	6
2. Installing and Uninstalling .....	7
General Installation Requirements .....	7
Installing the FreeBSD Driver Kit.....	7
Uninstalling the FreeBSD Driver Kit .....	7
Updating the FreeBSD Driver Kit .....	8
Checking the FreeBSD Driver Version.....	8
Loading and Unloading the Driver .....	8
3. Configuration .....	9
NIC Driver Configuration.....	9
Kernel Module Parameters .....	9
Configuring TSO .....	9
Configuring LSO .....	9
Configuring Jumbo Frame Transmit.....	10
Configuring AIC.....	10
Configuring CARP .....	10
Viewing Device Driver Statistics.....	11
Updating the Firmware .....	11
Extracting an SFP Module's VPD Information .....	12

# List of Tables

Table 3-1 Kernel Module Parameters..... 9

# 1. Introduction

This document provides installing, uninstalling, updating, and configuring procedures for an Emulex<sup>®</sup>-supported FreeBSD network interface card (NIC) driver release.

## Supported Versions and Adapters

This manual is applicable to several versions of FreeBSD NIC drivers, operating systems, firmware, and adapters.

For a list of supported FreeBSD operating systems and their associated Emulex firmware and drivers, see the Emulex website for the specific adapter.

The FreeBSD operating system supports the Emulex OneConnect<sup>®</sup> OCe11102 universal converged network adapter (UCNA), the LightPulse<sup>®</sup> LPe16202 converged fabric adapter (CFA), and the OneConnect OCe14000-series converged network adapter (CNA). The driver and adapters support:

- Peripheral Component Interconnect Express (PCIe) bus standard (Generation 2 or later)
- Statistics – Ethernet statistics provided for the number of packets received and sent, and errors encountered
- Jumbo packets (greater than 1500 bytes)
- Virtual local area network (VLAN)
- Multicast – packets sent from a source to a group of destinations
- Receive side scaling (RSS) – load balancing on Rx traffic across multiple Rx queues
- TSO/LSO (TCP segmentation offload/large segment offload) – offloads Tx traffic to hardware to improve performance
- CSO (Checksum Offload) to hardware
- Bonding – Ethernet bonding across multiple ports for load balancing and fail-over
- PXE – Preboot eXecution Environment for network boot
- MSI-x – Message signal interrupts–extended
- Promiscuous mode – configuring an Ethernet interface to accept traffic from any destination
- Debugging capability

## Abbreviations

AIC	adaptive interrupt coalescing
CARP	Common Address Redundancy Protocol
CFA	converged fabric adapter
CSO	Checksum Offload
LSO	large segment offload
MSI-X	message signaled interrupts-extended
NIC	network interface card (or controller)
PCIe	Peripheral Component Interconnect Express
PXE	Preboot eXecution Environment
RSS	receive side scaling
SFP	small form-factor pluggable
TCP	Transmission Control Protocol
TSO	TCP segmentation offload
UCNA	universal converged network adapter
VHID	virtual host ID
VLAN	virtual local area network
VPD	vital product data

## 2. Installing and Uninstalling

This section provides installation and removal instructions for the FreeBSD driver kit.

### General Installation Requirements

Prior to driver installation, you must:

- Install a supported adapter in the system. Refer to the adapter's installation manual for specific hardware installation instructions.
- Install the FreeBSD NIC driver on a dual-core (or better) server with Intel x86 or AMD64 architecture and MSI-X support.
- Use a supported operating system. See the Emulex website for a list of supported FreeBSD operating systems.

### Installing the FreeBSD Driver Kit

To install the FreeBSD driver kit:

1. Download the appropriate driver kit from the Emulex website.
2. Log on as "root" and type

```
pkg_add oce-<VERSION>-<ARCH>.tbz
```

For example:

```
pkg_add oce-4.1.86.0-amd64.tbz
```

3. Type

```
echo 'oce_load="YES"' >> /boot/loader.conf
```
4. Extract the tbz driver package and copy the oce.ko file to the /boot/kernel/ directory.
5. Reboot the system.

### Uninstalling the FreeBSD Driver Kit

To uninstall the FreeBSD driver kit:

1. Log on as "root" and type

```
pkg_delete oce-<VERSION>-<ARCH>
```

For example:

```
pkg_delete oce-4.1.86.0-amd64
```

2. Remove the 'oce\_load="YES"' entry from the /boot/loader.conf file.
3. Reboot the system.

## Updating the FreeBSD Driver Kit

To update the FreeBSD driver:

1. Type

```
pkg_update oce-<VERSION>-<ARCH>.tbz
```

For example:

```
pkg_update oce-4.1.86.0-amd64.tbz
```

2. Reboot the system.

## Checking the FreeBSD Driver Version

To check the currently installed FreeBSD driver version:

1. Log on as “root”.

2. Type

```
pkg_info | grep -i 'oce driver'
```

For example:

```
pkg_info | grep -i 'oce driver'
```

Output:

```
oce-4.4.130.0          oce driver for freebsd
```

## Loading and Unloading the Driver

To load the kernel module, type

```
kldload oce.ko
```

To unload the kernel module, type

```
kldunload oce.ko
```

To verify that the driver loaded properly, type

```
kldstat | grep oce
```



## 3. Configuration

This section provides information on configuring the FreeBSD NIC driver, updating the firmware, and extracting an SFP module's VPD information.

### NIC Driver Configuration

This section lists the kernel module parameters and how to configure the FreeBSD NIC driver.

#### Kernel Module Parameters

Table 3-1 Kernel Module Parameters

Parameter	Description
max_rsp_handled	Default: 64 Allowed values: 1-1024 kenv name: hw.oce.max_rsp_handled sysctl name: dev.oceX.max_rsp_handled max_rsp_handled indicates the maximum number of received frames that are processed during a single receive frame interrupt.

#### Configuring TSO

TSO can be configured globally (affects all controllers in the system) or individually for Emulex adapters.

To enable TSO globally, type

```
sysctl net.inet.tcp.tso=1
```

To disable TSO globally, type

```
sysctl net.inet.tcp.tso=0
```

To enable TSO for NIC interfaces only, type

```
ifconfig oce<if_id> tso
```

To disable TSO for NIC interfaces only, type

```
ifconfig oce<if_id> -tso
```

**Note:** <if\_id> is the interface identification number.

#### Configuring LSO

To enable LSO, type

```
ifconfig oce<if_id> lso
```

To disable LSO, type

```
ifconfig oce<if_id> -lso
```

**Note:** <if\_id> is the interface identification number.

## Configuring Jumbo Frame Transmit

To enable Jumbo frames transmission, type

```
ifconfig oce<if_id> mtu <mtu>
```

**Note:** <if\_id> is the interface identification number and <mtu> should be less than or equal to 9000.

## Configuring AIC

**Note:** AIC configuration is available on OneConnect OCe11102 and OCe14000-series adapters only.

To enable AIC, type

```
sysctl dev.oce.<if_id>.aic_enable = 1
```

To disable AIC, type

```
sysctl dev.oce.<if_id>.aic_enable = 0
```

## Configuring CARP

**Note:** CARP is supported in FreeBSD 10.0 and later only.

CARP enables multiple hosts to share the same IP address and VHID in order to provide high availability for one or more services. If one or more host servers fail, the other host servers will transparently continue operations so a service failure is not observed.

In addition to the shared IP address, each host server has its own IP address for management and configuration. All of the systems that share an IP address have the same VHID. The VHID for each virtual IP address must be unique across the broadcast domain of the network interface.

To enable boot-time support for CARP, you must add an entry for the carp.ko kernel module in /boot/loader.conf by typing:

```
carp_load="YES"
```

To immediately load the module without rebooting, type:

```
# kldload carp
```

The host name, management IP address and subnet mask, shared IP address, and VHID are all set by adding entries to /etc/rc.conf. This example is for hosta.example.org:

```
hostname="hosta.example.org"  
ifconfig_em0="inet 192.168.1.3 netmask 255.255.255.0"  
ifconfig_em0_alias0="vhid 1 pass testpass alias 192.168.1.50/32"
```

The next set of entries are for `hostb.example.org`. Since it represents a second main host server, it uses a different shared IP address and VHID. However, the passwords specified with “pass” must be identical, as CARP only responds to systems with the correct password.

```
hostname="hostb.example.org"
ifconfig_em0="inet 192.168.1.4 netmask 255.255.255.0"
ifconfig_em0_alias0="vhid 2 pass testpass alias 192.168.1.51/32"
```

The third system, `hostc.example.org`, is configured to handle failover from either main host server. This system is configured with two CARP VHIDs – one to handle the virtual IP address for each of the main host servers. The CARP advertising skew, “advskew”, is set to ensure that the backup host advertises later than the main host server, since “advskew” controls the order of precedence when there are multiple backup servers.

```
hostname="hostc.example.org"
ifconfig_em0="inet 192.168.1.5 netmask 255.255.255.0"
ifconfig_em0_alias0="vhid 1 advskew 100 pass testpass alias
192.168.1.50/32"
ifconfig_em0_alias1="vhid 2 advskew 100 pass testpass alias
192.168.1.51/32"
```

Having two CARP VHIDs configured enables `hostc.example.org` to recognize if either of the main host servers becomes unavailable. If a main host server fails to respond before the backup server, the backup server will pick up the shared IP address until the main host server becomes available again.

## Viewing Device Driver Statistics

To view device driver statistics, type

```
sysctl -a | grep oce
```

To view statistics for a single interface, type

```
sysctl dev.oce.<if_id>
```

**Note:** `if_id` can be any of the interface values that correspond to the Emulex interfaces in the `ifconfig` output.

## Updating the Firmware

**Note:** For information on using the `Elxflash` management utility to update firmware, see the *Elxflash and LpCfg Management Utilities User Manual*.

To update the firmware:

1. Copy the code below to the makefile.

```
KMOD=elxflash
FIRMWS=imagenamename.ufi:elxflash
.include <bsd.kmod.mk>
```

2. Replace "imagename" in the copied code with the actual firmware file name. The format is <filename>.ufi.
3. Copy this makefile and the firmware file to a temporary directory.
4. Run a "make" command in the directory. This generates an elxflash.ko file.
5. Copy the elxflash.ko file to /boot/modules.
6. Run the command:

```
sysctl dev.oce.<if_id>.fw_upgrade=elxflash
```

**Note:** <if\_id> can be any of the interface values that correspond to the Emulex interfaces in the ifconfig output. If multiple Emulex NIC adapters exist in the same system, the firmware download procedure must be repeated on one <if\_id> for each adapter.

7. Check if the sysctl command execution for the firmware update was successful.

If it was successful, reboot the system. Otherwise, you should see one of the following errors codes:

- "Invalid BE3 firmware image"
- "Invalid Cookie. Firmware image corrupted?"
- "cmd to write to flash rom failed."

If one of the messages above appears, verify that you have the latest firmware update by checking the Emulex website and then attempt to update the firmware again. If you continue to have issues, contact your Emulex Technical Support representative.

## Extracting an SFP Module's VPD Information

To dump an SFP module's VPD:

1. Trigger the dump by typing

```
sysctl dev.oce.<if_id>.sfp_vpd_dump=0
```

2. Choose one of the following dump options:

- For a hexadecimal dump, type

```
sysctl -x dev.oce.<if_id>.sfp_vpd_dump_buffer
```

- For a binary dump, type

```
sysctl -b dev.oce.<if_id>.sfp_vpd_dump_buffer > <filename>
```

where filename is the file into which the output should be redirected.

For example:

```
sysctl -b dev.oce.<if_id>.sfp_vpd_dump_buffer > sfp.bin
```