



Imaging Wheel Aligner

Installation Guide

&

User Manual

Version 10.02

Copyright © 2010 All rights reserved

No part of this publication may be translated, stored in an electronic retrieval system, reproduced, or partially or totally adapted by any means (including microfilm and Photostats) without prior written permission.

Information and specifications contained herein may be subject to modification and change without prior notice.

READ THIS ENTIRE MANUAL BEFORE ASSEMBLING AND OPERATING THE ALIGNER

IMPORTANT !

RECORD THE FOLLOWING INFORMATION LOCATED ON THE SERIAL NUMBER DATA PLATE AT THE BACK OF THE CABINET:

Model Number: _____

Serial Number: _____

USB Security Key Number: _____

Date of Manufacturing: _____

HP, Philips, Dell, Microsoft, Windows Vista, MS and MS-DOS are registered trademarks. Windows and the Windows logo are trademarks of Microsoft Corporation. IBM is a registered trademark of IBM Corporation.

SAFETY REGULATIONS

WARNING:

Failure to observe all instructions and all danger warnings can cause serious injury to the operator and/or other persons.

Do not use the aligner until you have read and completely understand all the danger, warning and attention notices in this manual.

ProtoStar multi-dimensional digital wheel aligner must only be used by authorized and qualified operators who are capable of understanding all written instructions provided by the manufacturer. They must be suitably trained and conversant with all safety regulations. Operators are expressly forbidden to use the aligner under the influence of alcohol or drugs capable of affecting physical and mental capacity.

The following conditions are essential:

Read and understand all operating and safety instructions before using the aligner;

Have a thorough knowledge of the capacities and characteristics of the aligner;

Keep unauthorized persons well clear of the area of operation;

Insure the aligner has been installed in compliance with established legislation and standards;

Before using the ProtoStar multi-dimensional digital wheel aligner, the operator must be knowledgeable of automobile systems and other safety regulations including all tools and equipment that will operate together with the aligner (such as a lift, rolling jack and repair tools). Improper use may cause serious injury.

SAVE THIS INSTRUCTION MANUAL — DO NOT DISCARD!!

IMPORTANT!!

Risk of electrical shock:

Do not operate equipment with a damaged power cord or if the equipment has been dropped or damaged. Consult a qualified service person and confirm it is safe to operate.

If an extension cord is necessary, use a cord with an electrical current rating equal to or greater than that of the aligner. Using an improper extension cord is a serious danger to both the operator and the aligner. Personal Injury and non warranty aligner damage can result.

Unplug the aligner from electrical outlet when not in use. Never use the cord to pull the plug from the outlet. Grasp plug firmly and pull gently to disconnect.

Do not expose the aligner to any form of water. Do not use on wet surfaces.

Plug unit into correct power supply. Connecting the aligner to an incorrect power supply will void the aligner warranty and can cause serious injury or death.

Do not remove or bypass grounding pin.

High voltages are present within the console unit. Contact with high voltages can cause death or serious injury.

Service:

There are no operator serviceable items inside the console except the keyboard and printer.

Service on the aligner must only be performed by qualified personnel. Do not open any part of the console unless it is clearly identified as being acceptable to do so. Turn power switch off and disconnect the aligner from all power sources before servicing.

Risk of eye injury:

Wear approved safety goggles when operating the aligner or servicing a vehicle. Dirt, fluids, or other debris may drop from a vehicle or lift. These can cause serious eye injury. Take care that nothing will fall on the operator or the aligner.

Risk of crushing:

Vehicles may roll off alignment lift if not secured. Use wheel chocks whenever vehicle is positioned on the lift
Leave automatic transmission in park or manual transmission in gear with the brake applied unless aligner operation steps require vehicle in neutral.
Apply parking brake unless aligner operation steps require wheel movement.
Follow vehicle and lift manufacturer's safety recommendations when lifting a vehicle.
Vehicles rolling off lifts can cause death or serious injury.
When using a rolling jack to raise a vehicle, insure the vehicle is properly secured on the jack.

Risk of entanglement or crushing:

There are moving parts on vehicle lifts during operation. Keep all persons clear of lifts.
Read lift manufacturer's operation instructions carefully.
Follow lift manufacturer's safety recommendations.
Contact with moving parts can cause injury.

Risk of burns:

Do not touch hot exhaust system, manifolds, engines, radiators, etc.
Wear gloves whenever performing a service near hot components.
Hot components can cause burns.

Risk of injury:

Tools may break or slip if improperly used or maintained. Use the correct tool for the task.
Frequently inspect, clean, and lubricate (If recommended) all tools
Follow recommended tool procedures when performing vehicle services.
Tools that break or slip can cause injury.

DEFINITIONS OF HAZARD LEVELS

Identify hazard levels used in this manual with the following definitions and symbols:

DANGER! Watch for this symbol: It Means: Immediate hazards which will result in severe personal injury or death.

WARNING! Watch for this symbol: It Means: Hazards or unsafe practices which could result in severe personal injury or death.

CAUTION! Watch for this symbol: It Means: Hazards or unsafe practices which may result in minor personal injury or product or property damage.

**Watch for all Hazard Symbols! They mean: "BE ALERT!"
Your safety, and the safety of others, is involved!**



WARNING

The Aligner is designed for INDOOR USE ONLY. Exposure to damp or wet locations will cause damage to the aligner's components or injury to the user and will void warranty.



CAUTION

The computer may have the ability to connect to the internet, intranet, a local or wide area network. DO NOT connect the computer to any network or the internet unless instructed to by a manufacture or authorized technician.

DO NOT install any 3rd party software or hardware into or onto the aligner as it may cause conflicts with Aligner software or drivers. Failure to comply will void aligner warranty



WARNING

Do not plug the cabinet power cord in until all connections have been verified. Damage or injury can result.



WARNING

Insure all installations on this aligner are legal in your country.

Table of Contents

PART I: INTRODUCTION	11
PART II: GETTING STARTED	12
Transport, Storage and Handling	12
Uncrating Instructions	12
Installation Instructions.....	13
Requirement for already installed lift/ service bay	13
Post Position and Installation (For installation with Post)	14
Cabinet Assembly	15
Testing the installation position	20
Lift Calibration / Initial Calibration	21
Positioning the Aligner	23
Aligner Components:.....	24
Console	24
Chessboard Targets	24
Wheel Clamps	24
Settings.....	25
Opening and Closing SureAlign™ 3.0 Alignment Software	25
Common shortcut keys	26
Software Settings.....	27
Shop Owner's Information	31
Part III Operating Guide	31
Alignment Procedures.....	31
Attach Wheel Clamps and Targets	32
Start Wheel Alignment Software.....	32
Vehicle Specifications	33
Pre-Alignment.....	34

Pre-Alignment Inspection.....	34
Run out Compensation	34
Measuring Caster.....	37
Rear Axle Reading.....	40
Front Axle Reading	40
Software Functions.....	41
Live Caster	41
Super Toe	41
Display and Print Measuring Result.....	44
Customer Data	45
New Customer Information.....	46
Part IV Aligner Maintenance	46
Database Manager	47
Add New Vehicle Data	47
Update Vehicle Database.....	49
Internet Update.....	49
Customer Information Manager	49
Appendix 1: Basic Shortcuts	51
Appendix 2: Troubleshooting	52
Appendix 3: Technical Specifications	53
Appendix 4: ProtoStar Aligner Components and Parts Lists	54
Appendix 4: Aligner Components and Parts Lists (continued)	55
Appendix 4: Aligner Components and Parts Lists (continued)	56

Table of Figures

Figure 1 Aligner Crate	12
Figure 2 Leveled and parallel lift illustration	14
Figure 3 Illustration of geometric center line of the lift	14
Figure 4 Illustration of the distance from the center of the camera to the center of the turn table	14
Figure 5 Illustration of Camera Beam perpendicular to the post.....	15
Figure 6 Illustration of height between camera to the lift	15
Figure 7 Swivel and Rigid Caster installation	16
Figure 8 Power Box Wiring	16
Figure 9 Wheel clamp bracket.....	17
Figure 10 Mouse Holder (Socket Head Cap Screws)	17
Figure 11 Monitor Wiring	18
Figure 12 Cabinet Backdoor	18
Figure 13 Printer Location	18
Figure 14 Keyboard Wiring	19
Figure 15 Computer Wiring	19
Figure 16 Installation Requirements	20
Figure 17 illustration of installation methods	20
Figure 18 Illustration of Vehicle Position on the lift.....	21
Figure 19 Rear Target Calibration.....	21
Figure 20 Front target calibration	22
Figure 21 Console	24
Figure 22 Illustration of Target	24
Figure 23 Wheel Clamp	24
Figure 24 System Connection Diagram	25
Figure 25 Alignment Software	26

Figure 26 Exit SureAlign™ Alignment Software	26
Figure 27 Aligner Management Screen	27
Figure 28 Aligner Setup	27
Figure 29 Standard Axis Setting.....	28
Figure 30 Selection of Toe measurement unit	28
Figure 31 Rim measurement	29
Figure 32 Measurement units	29
Figure 33 Value Display Precision.....	29
Figure 34 Value Display Style.....	30
Figure 35 Language Selection	30
Figure 36 Workshop Information	31
Figure 37 Vehicle Manufacturer's Selection.....	32
Figure 38 Vehicle manufacturer and Year Selection	33
Figure 39 Vehicle model selection.....	33
Figure 40 Alignment Preliminaries	34
Figure 41 Run out Compensation 1	35
Figure 42 Run out Compensation 2	35
Figure 43 Run out Compensation 3	36
Figure 44 Run out Compensation 4	36
Figure 45 Run out Compensation 5	36
Figure 46 Run out Compensation 6	37
Figure 47 Caster Swing Screen at 10 degree	37
Figure 48 Straight Steering Wheel at 10 degree	37
Figure 49 Caster Measurement Screen	38
Figure 50 Instruction to turn steering wheel left	38
Figure 51 Instruction to turn steering wheel right	38
Figure 52 Instruction to return steering wheel to straight ahead position.....	39

Figure 53 Warning Screen	39
Figure 54 All Data Screen.....	39
Figure 55 Rear Axle Readings	40
Figure 56 Zoom Function.....	40
Figure 57 Front Reading Screen.....	41
Figure 58 Live Caster Screen.....	41
Figure 59 Super Toe Screen	42
Figure 60 Super Toe Screen	42
Figure 61 Left Front Toe Reading Screen.....	42
Figure 62 Left Front Toe	43
Figure 63 Right Front Toe	43
Figure 64 Right Front Toe	43
Figure 65 Front Toe	44
Figure 66 Result Screen	44
Figure 67 Select Customer Screen	45
Figure 68 Existing Vehicle Plate Number.....	45
Figure 69 New Vehicle	45
Figure 70 New Customer Screen	46
Figure 71 Aligner Maintenance Screen	46
Figure 72 Data Bank Manager	47
Figure 73 Add New Vehicle Data Manager.....	47
Figure 74 Add Vehicle Manufacturer Data	48
Figure 75 Add Vehicle Specification Data.....	48
Figure 76 Add Vehicle Specification Data.....	49

PART I: INTRODUCTION

The purpose of this manual is to provide the owner and operator of the ProtoStar 9000 Multi Dimensional Multi dimensional digital wheel aligner with safe and practical instructions for its use and maintenance.

Following all instructions carefully will assist you in your work and give long term and efficient service. The following paragraphs define the levels of danger associated with warning captions in this manual.



The 9000 ProtoStar Aligner is intended for use by properly trained, skilled automotive technicians. The safety messages presented in this section and throughout the manual are reminders to the operator to exercise extreme care when performing wheel alignments with this product.

There are many variations in procedures, techniques, tools, and parts for servicing vehicles, as well as the skill of the individual doing the work. Because of the vast number of vehicle applications and potential uses of the aligner, the manufacturer cannot possibly anticipate or provide advice or safety messages to cover every situation. It is the automotive technician's responsibility to be knowledgeable of the vehicle to be aligned. It is essential to use proper servicing methods and perform wheel alignments in an appropriate and acceptable manner that does not endanger operator safety, the safety of others in the work area, the equipment or vehicle being serviced.

Read this manual carefully before powering up the equipment. Conserve this manual and all illustrative material supplied with the equipment in a folder near the equipment where it is readily accessible for consultation by the operator.

The technical documentation supplied is considered an integral part of the equipment; in the event of sale all relative documentation must remain with the system.

This manual is only being considered valid for the equipment of the model and with the serial number indicated on the nameplate applied to it. The nameplate is attached to the back of the cabinet.

Without prior knowledge to the manufacture or manufacture authorized dealers, any alterations to this aligner may cause serious injury. The manufacture is not responsible for any injury caused by improper use, abuse, or unauthorized repair.

PART II: GETTING STARTED

Transport, Storage and Handling

Equipment transport conditions

The aligner must be shipped in its original packing and stowed in the position indicated on the outside.



To avoid damage, never place other items on top of the packaging.




Figure 1 Aligner Crate

Handling of the aligner must be performed only with an appropriate lifting device such as a forklift or pallet jack.

Only personnel who are experienced and qualified on material handling procedures should handle any transportation or moving of the aligner.

Inspect for any damage to the crate and notify local distributor (and/or transport company) immediately if any damage is observed.

Uncrating Instructions:

Carefully remove the crating and packing materials and all skid and pallet fasteners.

Be careful when cutting banding material as items may become loose and fall causing personal harm or injury. Always wear gloves when uncrating the machine to prevent scratches, abrasions, or cuts due to the contact with packing materials.

Retain all packaging in the event you need to return any parts for warranty or servicing.

Carefully unpack and inventory all items.

Familiarize yourself with all components before beginning set up and assembly.

Check List

Your aligner should include the following items

- 1 Camera beam
- 1 Post or wall mount bracket
- 4 Chessboard Target
- 4 Wheel clamps
- 1 Cabinet
- 1 Computer
- 1 USB Security Key
- 1 Monitor
- 1 Printer
- 2 Swivel casters
- 2 Rigid casters
- 1 Power bar
- 1 Plastic Top
- 1 Steering wheel lock
- 1 Brake depressor

Installation Instructions

NOTE: Check the voltage, phase and proper amperage requirements for the alignment machine and components. Wiring should only be performed by a certified technician. Overheating, short circuits and fire damage will result from inadequate wiring. Wiring must be installed in accordance with National and Local Electric Codes and Standards covering electrical apparatus and wiring.

Be certain that adequate wire sizes are used, and that:

- Service is of adequate amp rating.
- The supply line wire is the proper size and has the same electrical characteristics (voltage, cycles and phase) as the alignment machine and components.
- No other equipment is to be operated from the same line.

Requirement for already installed lift/ service bay

To obtain accurate result, first check if the lift is leveled and parallel on both sides. If not, have the authorized technician to adjust.





Figure 2 Leveled and parallel lift illustration

Post Position and Installation (For installation with Post)

Use tape measure to find the center line of the lift.



Put the Post of the aligner in front of the lift, make sure the distance between the camera and center of turn table is approximately 2200 mm. Install the camera beam on to the post, adjust the post position so the center of the beam is on the same axes as center of the lift.

Figure 3 Illustration of geometric center line of the lift

Use the tape measure to find if the distance from the camera to the center of turn table is the same for both side. Once the post is moved, make sure the camera beam is leveled and is on the center line of the lift.




Figure 4 Illustration of the distance from the center of the camera to the center of the turn table

Level the camera beam and make sure the beam is perpendicular to the post.




Figure 5 Illustration of Camera Beam perpendicular to the post




Figure 6 Illustration of height between camera to the lift

Raise the lift to the alignment position. Make sure the distance between the camera beams is about 700 mm higher than the alignment position.

Cabinet Assembly

1. Open the Cabinet and remove all items packed inside.
2. Use the shipping carton or other protective material for protection. Lay the cabinet down on its side.
3. Install the two Swivel Casters with brake and two Rigid Casters to the bottom of the Cabinet using the 16 Hex Head Bolts, Nuts and Washers.

NOTE: Install the Swivel Casters with Brake in the front and the Rigid Casters in the rear.
(see next page for illustration)



Figure 7 Swivel and Rigid Caster installation

4. Raise cabinet up onto the Casters.

5. Connect Power Strip to Power Box Wiring as shown below




Figure 8 Power Box Wiring

6. Install four wheel clamp brackets to the sides of the cabinet using the two Clip Nuts, Socket Head Screws, and Washers as shown



Figure 9 Wheel clamp bracket

7. Install Mouse Holder on right side of Cabinet using two Nuts and Socket Head Screws.

Figure 10 Mouse Holder (Socket Head Cap



Screws)




CAUTION

Do not move the cabinet until you have tightened down the Monitor. Hold Down Clamps or the monitor may fall off the cabinet while moving.

11. Place the Monitor on top of the Cabinet. Tighten the Monitor hold down clamps.

Connect the Power Cable and Monitor Cable to the Monitor.
Route the Monitor Cable and Monitor Power Cable through the Hole.

Figure 11 Monitor Wiring



12. Remove lower rear panel of cabinet for better access to computer and power cables.

Figure 12 Cabinet Backdoor



18. Place the Computer in the drawer

19 Read the Printer Manual for instructions on installation. Load printer paper and printing cartridges into the printer. Plug the USB Printer Cable into Printer.

Figure 13 Printer Location



20. Place the Mouse Pad and Mouse on the Mouse Shelf. Place the Keyboard on top of the Cabinet and run the Keyboard and Mouse Cable through the hole in the center of the Cabinet top.

Figure 14 Keyboard Wiring



21. Plug the Printer USB Cable into the back of the Computer using one of the available USB Ports on the rear of the computer.

Plug the USB Mouse Cable into an empty USB Port on the rear of the computer.

Plug the Keyboard USB cable into an empty USB Port on the rear of the computer.

Plug the Bluetooth Receiver Serial Cable into the serial port on the rear of the Computer.

Tighten Screws.

Plug the Monitor Cable into the Monitor Port on rear of the Computer and tighten screws.

Plug the USB Security Key into one of the available USB ports on the rear of the Computer.



Figure 15 Computer Wiring

- A. Monitor
- B. Keyboard
- C. Camera 1
- D. Camera 2
- E. Printer Cable
- F. Mouse

Please note, some computers may come with more USB ports. Plug the software key into the extra USB port. Otherwise, plug the software key onto the USB port in the front of the computer. If only 4 USB port are available on the computer, purchase a USB splitter from local computer store.

22. Plug the Power Cable into the Computer

Plug the Computer Power Cable into the Power Strip

Plug the Monitor Power Cable into the Power Strip

Plug the Printer Power Cable into the Power Strip

Plug the Power Supply for the Blue Tooth Receiver Box into the Power Strip

Installation of the Post

Follow the dimensions below and choose appropriate mounting.




Figure 16 Installation Requirements

Please note the standard and adjustable post has to be mounted / fixed on the floor or else it may tilt and affect accuracy of the measurement. The wall mount has to be attached to permanent wall not dry wall.




Figure 17 illustration of installation methods

Testing the installation position

Drive a standard sized vehicle (eg Ford Taurus, Volkswagen Passat, Honda Accord etc.) onto the lift; install the wheel clamp and target, from the home screen. Press F11-F2-F1 to Lift

Calibration. The software will draw color lines on the target if it recognizes the pattern. Push the vehicle backward and check if the camera can recognize the pattern for the entire distance of the lift. Adjust the angle of the camera beam if necessary until the camera can see the entire route.




Figure 18 Illustration of Vehicle Position on the lift

Drive the vehicle off the lift.

Lift Calibration / Initial Calibration

Put the calibration fixture on the rear of the lift, installed both rear targets on to the shaft. Make sure the calibration fixture is leveled. From the alignment software main screen, press F11-F2-F2 to lift calibration screen and following the procedure below.




Figure 19 Rear Target Calibration

1. Level the rear target by checking the bubble on the target
2. Make sure the number on one side of the calibration fixture is at 0 then click "Set to Target Vertical Angle Position"
3. The number will floating, once it becomes stable, click "Set to Target Vertical Angle Position"
4. Rotate the calibration bar 45 degree, then click "Set to Target Vertical Angle Position"
5. Rotate the calibration bar back to 0 degree, Click "Set to Target Vertical Angle Position"
6. The number will floating, once it becomes stable, click "Set to Target Vertical Angle"

Position”

7. Rotate the calibration bar 45 degree, then click “Set to Target Vertical Angle Position”
8. Rotate the calibration bar back to 0 degree, Click “Set to Target Vertical Angle Position”
9. The number will floating, once it becomes stable, click “Set to Target Vertical Angle Position”
10. Rotate the calibration bar 45 degree, then click “Set to Target Vertical Angle Position”

Once the above procedure is done, the program will enter the 2nd step. This step will be the same as last step; the purpose of this step is to verify the calibration in the 1st step.

1. Level the target by checking the bubble on the target
2. Make sure the number on one side of the calibration fixture is at 0 then click “Set to Target Vertical Angle Position”
3. The number will floating, once it becomes stable, click “Set to Target Vertical Angle Position”
4. Rotate the calibration bar 45 degree, then click “Set to Target Vertical Angle Position”
5. Rotate the calibration bar back to 0 degree, Click “Set to Target Vertical Angle Position”
6. The number will floating, once it becomes stable, click “Set to Target Vertical Angle Position”
7. Rotate the calibration bar 45 degree, then click “Set to Target Vertical Angle Position”
8. Rotate the calibration bar back to 0 degree, Click “Set to Target Vertical Angle Position”
9. The number will floating, once it becomes stable, click “Set to Target Vertical Angle Position”
10. Rotate the calibration bar 45 degree, then click “Set to Target Vertical Angle Position”

At this time, the rear target calibration is done.

Continue to the front target calibration by putting the calibration fixture on the front of the lift. Make sure the calibration bar is leveled using the bubble.




Figure 20 Front target calibration

1. Level the front target by checking the bubble on the target
2. Make sure the number on one side of the calibration fixture is at 0 then click “Set to

Target Vertical Angle Position”

3. The number will floating, once it becomes stable, click “Set to Target Vertical Angle Position”
4. Rotate the calibration bar 45 degree, then click “Set to Target Vertical Angle Position”
5. Rotate the calibration bar back to 0 degree, Click “Set to Target Vertical Angle Position”
6. The number will floating, once it becomes stable, click “Set to Target Vertical Angle Position”
7. Rotate the calibration bar 45 degree, then click “Set to Target Vertical Angle Position”
8. Rotate the calibration bar back to 0 degree, Click “Set to Target Vertical Angle Position”
9. The number will floating, once it becomes stable, click “Set to Target Vertical Angle Position”
10. Rotate the calibration bar 45 degree, then click “Set to Target Vertical Angle Position”

Once this step is done, click ok to save the calibration data then follow the next section to verify the data.

1. Level the front target by checking the bubble on the target
2. Make sure the number on one side of the calibration fixture is at 0 then click “Set to Target Vertical Angle Position”
3. The number will floating, once it becomes stable, click “Set to Target Vertical Angle Position”
4. Rotate the calibration bar 45 degree, then click “Set to Target Vertical Angle Position”
5. Rotate the calibration bar back to 0 degree, Click “Set to Target Vertical Angle Position”
6. The number will floating, once it becomes stable, click “Set to Target Vertical Angle Position”
7. Rotate the calibration bar 45 degree, then click “Set to Target Vertical Angle Position”
8. Rotate the calibration bar back to 0 degree, Click “Set to Target Vertical Angle Position”
9. The number will floating, once it becomes stable, click “Set to Target Vertical Angle Position”
10. Rotate the calibration bar 45 degree, then click “Set to Target Vertical Angle Position”

Click “OK” to finish the calibration procedure.

To check if the calibration is completed correctly, Test it with vehicle on and do a run out compensation.

Positioning the Aligner

Place the aligner in a convenient location where the monitor can be seen from every position during the measuring process. Take care to protect the aligner from any potential damage.

Caution: Insure there are no permanent magnets, electromagnets or sources of heat or water in the vicinity of the machine as these could cause irreparable damage to the computer and other components. Keep the aligner dry all the time.

Aligner Components:

Console

Most aligner components are kept in the console, including power supply, computer, monitor, keyboard, mouse, printer as well as targets and wheel clamps.



Figure 21 Console

Chessboard Targets




Figure 22 Illustration of Target

Wheel Clamps




Figure 23 Wheel Clamp

The ProtoStar 9000 multi dimensional digital wheel aligner uses 2 industrial camera connected with computer to dynamically monitor the real time geometric change at four targets.




Figure 24 System Connection Diagram

Settings

Opening and Closing SureAlign™ 3.0 Alignment Software

ProtoStar 9000 multi dimensional wheel aligner is equipped with SureAlign™ 3.0 wheel alignment software.

Switch on power supply and push the power button to start the computer. The computer should start the alignment software automatically. In case the alignment software does not start, click on the Minster icon to start the alignment software.

To enable automatic software start-up, copy the alignment software shortcut from the desktop to

C:\Documents and Settings\All Users\Start Menu\Programs\Startup under Windows XP

Or

C:\Users*User Name*\AppData\Roaming\Microsoft\Windows\Start Menu\Programs\Startup under Windows Vista or Windows 7

If you do not see a shortcut for the alignment software, please make sure your alignment software is properly installed; contact your local service center if necessary.



Figure 25 Alignment Software

Following a 9000 ProtoStar welcome animation, the monitor will display SureAlign™ 3.0 alignment software main menu screen as shown in figure above. For easy operation, the SureAlign™ 3.0 alignment software uses function keys. Users can access a required function by pressing the appropriate function key.

As the 9000 ProtoStar aligner uses an IBM standard keyboard, there are 12 function keys from F1 to F12 located on the top of keyboard. There are also specific function keys located on the right side of keyboard, such as “Page Up”, “Page Down”, “Enter” “Home” and arrow direction keys. Instructions for these function keys will be mentioned in following sections and you will find their use very convenient.

Common shortcut keys

Home - from any screen in the software, once home key is pressed, it will return to main menu

F6 – Caster sweep menu

F7 – Front Axle

F8 – Rear Axle F9 – Result Screen

F6 – F2 or F7-F5 Direct Caster

F10 – Help

ESC – double press escape turns off the computer

Press HOME key under any screen to go back to SureAlign™ software main menu screen

Press ESC function key located at the top left corner of keyboard will display the following window:





Figure 26 Exit SureAlign™ Alignment Software

Following the instructions, press ESC again to close SureAlign™ Alignment software. Press any other key to close the dialog window and go back main screen. After exiting SureAlign™ Alignment S software, the computer will turn off automatically within 10 seconds.



Please do NOT switch off power supply directly to shut down the computer. Switching off power directly may affect proper operation of the Microsoft Windows system.



Press ESC under SureAlign™ Alignment Software main menu screen to close software.



Press F10 under any window to get Help of software

Software Settings



Figure 27 Aligner Management Screen

SureAlign™ Aligner Alignment Settings

Press F11 under main menu screen to enter T SureAlign™ Aligner Manager Screen. In this window, you can choose from aligner setting, aligner maintenance, manage aligner, customer database and upgrade database as well as personalize the aligner on the printout. The following section provides detailed instructions regarding these settings.

Aligner Setup



Figure 28 Aligner Setup

Press F11 to enter Aligner Setup



Caution: Only qualified technicians are allowed to access and perform settings. Inaccurate settings will deliver inaccurate results.

Make sure the “F9 Demo Mode” icon is grayed out. If it is highlighted, the aligner will NOT take any measurement and is running in demonstration mode.

Insure the following instructions are carefully read and understood before operation:

Standard Axis

Press F1 to display the following window




Figure 29 Standard Axis Setting

Press “Up” or “Down” arrow key to select. The selected item will be marked with black dot on the left side. Press “Page Down” to confirm selection and goes back to Setup screen. Press “Page Up” to cancel selection and go back to Setup screen. Settings remain unchanged.

Toe Measurement Units


Press F2 to display the following window

Three units may be selected for Toe measurement i.e. degree, mm and inch.

If you select the degree setting, the screen displays measurements in degrees.

If you select mm or inch as measurement units, the software requires you to input the diameter of tire before the aligner begins the measuring process.

Figure 30 Selection of Toe measurement unit



Rim Diameter Measurement Units

Press F3 to display the following window

Select “mm” or “inch” as the measurement unit for rim diameter

Figure 31 Rim measurement




Measurement Units

Press F4 to display the window below.

You can select 1/60 minute fraction or 1/100 decimal fraction mode for angle value display.


Figure 32 Measurement units



Value Display Precision

Press F5 to display the following window

Figure 33 Value Display Precision



The three values of display precision are 0.1, 0.05 and 0.01 respectively.

Select the value of required accuracy by inserting a dot in the circle on the left side of the heading you choose. The recommended setting is High (0.01)

If 0.01 is selected, the number will be shown in increments of 0.01: for example 0.01, 0.02, 0.03 etc.

if 0.05 is selected, the number will be shown in increments of 0.05 : for example 0.05, 0.10, 0.15 etc

if 0.1 is selected, the number will be shown in increments of 0.1: for example, 0.1, 0.2, 0.3 etc.

Value Display Style

Press F6 to display the following window

The default setting from the factory is for an actual measurement value. The operator can select a different measurement display value if required.




Figure 34 Value Display Style

Relative value is how much off from the manufacturer data, it displays the difference between the actual values to the manufacturer data. By formula, Relative Value= Manufacturer data – Actual Value.

Please note that the result screen will always displayed in actual reading value.

Language Selection

You can select different languages in the alignment software, Press "PageDn" key or use mouse to click "Confirm" icon to save your selection. (Language availability may differ by location)



Figure 35 Language Selection

Shop Owner's Information

Press “Page Up” or “Home-F11” to go back to aligner manager screen.
Press F4 to display Workshop information setup screen.

Completing the information on this screen personalizes your aligner. The information will then be displayed on the aligner's main menu screen and will print out on the information sheets detailing alignment results. Fill in your information in the column highlighted in yellow. Use the Up or Down arrow keys to select the column you want to edit. For Multilanguage input method please refers to Microsoft Windows user menu.




Figure 36 Workshop Information

Part III Operating Guide

Alignment Procedures

Diagnosing vehicle problems is very important before starting and during the alignment process. The following steps are important minimum guidelines:

Question the vehicle owner to discover all vehicle problems (check for collision damage or change of parts).

Perform a test drive — try to find and confirm the customer's problem.

Check tires for wear patterns.

Check frame and steering system.

Carefully drive vehicle onto the lift.

Install wheel clamps and sensors. Perform Run Out Compensation. If measuring error is out of range, first check the wheel clamp.

Complete Caster Swing

Measure Camber and Toe. Follow instructions on screen.

Angle adjustments must be done in sequence:

Rear Camber

Rear Toe

Front Caster

Front Camber

Front Toe

If Caster is adjusted, re-measure to insure accuracy

If necessary, re-center steering wheel and readjust front Toe

Print alignment results.

Perform test-drive to confirm you have solved all customer problems.


Attach Wheel Clamps and Targets

Pay attention to sensor position. Incorrect position may lead to alignment problems.

Start Wheel Alignment Software

Search for correct vehicle manufacturer's data.

Figure 37 Vehicle Manufacturer's Selection



Press Page Down or select Start on the Home Screen to access Vehicle Manufacturers Screen. This screen shows the vehicle manufacturers in the alignment database. Move selection bar up or down with arrow direction keys to select manufacturer and press "Page Down" or double click Manufacturer icon to select. For easy searching, the software sorts each manufacturer by "country", "name" and "frequency" respectively. You can use the function keys listed below to complete your own personalized search.



When not under alignment software main screen, press HOME to enter main menu screen. This operation means the start of new search and all previous data measured will be deleted.

F1: sort manufacturer by country.

F2: sort manufacturer by name.

F3: sort manufacturer by frequency.

>> Page Down: enter selection.

<< Page Up: exit selection and return to last page.

Home: exit selection and go back to main menu screen.

If you cannot get the vehicle manufacturer's data you need, please contact the Wheel Aligner manufacture and ask how to update your database. If you have access to standard data not contained in the database, you can add it by using the alignment database manager. For details, refer to Management (Part IV) of this menu.

Vehicle Year Selection

After confirming vehicle manufacturer press >> Page Down or double click the to select vehicle year.

Figure 38 Vehicle manufacturer and Year Selection





Figure 39 Vehicle model selection



Once the year is selected, the software will show vehicle models made in selected year. Double click the model or use up down arrow to select.

Move selection bar up or down with arrow direction keys to select. You can also use the following function keys to search: F1 - models sorted by year. F2 - models sorted by frequency. >>Page Down - enter vehicle data display. <<Page Up - Exit selection and back to last page. Home - Exit selection and back to main menu screen.

Vehicle Specifications

When selecting a vehicle model, press >> Page Down to enter specifications. Press F1 or Enter to play selected alignment adjustment diagrams. Press Enter or Page Dn to exit adjustment diagrams. Press F2 to print out data. Press F3 to enter vehicle weight specification screen and display manufacturer's special requirement data. (F3 key is only available for certain vehicles models.)

Pre-Alignment

After check back all data, press Page Down to enter Pre-Alignment screen.

Pre-Alignment Inspection

Press F1 under pre-alignment screen to enter visual inspection screen.

Figure 40 Alignment Preliminaries



Visual inspection has four screens. Press Up or Down arrow direction keys to select inspection item. Press Left and Right arrow direction keys to edit.

Under any inspection screen, press F1 to print out a blank inspection form. Technician could fill the form during inspection, and enter result in computer later.

Press F3 to set all item to normal.

After finish one page, press Page Down to enter next page. Press F2 under page four to print out inspection result.

These inspection results are important tools, but also may not be relevant. Under many circumstances, damage of vehicle parts would affect quality of alignment.

After finish pre-alignment inspection settings, press page down to back to pre-alignment screen.



Press F1 to print out blank inspection form.

Press F2 to print out inspection result.

Run out Compensation

Compensating for the amount of Run out of vehicle wheel assemblies is an important factor in the alignment process. If not correctly determined, there will be errors in the displayed camber and toe angles.

Make sure to lock turn table and rear slip plate before continue to next step.

To begin run out compensation, first put one of the rubber vehicle stop in front of rear driver side tire. This will mark the stop position once run out is done.




Figure 41 Run out Compensation 1

Follow the instruction indicated on the software

Install and level all targets
Install steering wheel
Release hand brake.

Once all three instructions are done, press “Next” icon on the screen or “PgDn” key to continue.

Once hit the “Next icon” or “PgDn” key, please keep vehicle still. The software will take the first measurement.

Attention: Please note the “STOP” sign on the top left corner. Once this sign is shown, please keep vehicle still. Any movement during this period will result in inaccurate result.




Figure 42 Run out Compensation 2

Once the measurement is done, follow the on screen instruction to push the vehicle backward.

Hint: You can move the vehicle by pushing one of the wheel clamps backward 45 degree.
Put the other rubber wheel stop at the back of the same wheel that has the rubber wheel stop in the front to avoid rolling off the lift.




Figure 43 Run out Compensation 3

When the wheel is close to 45 degree, a clock tick will be shown. It will enter a short red zone then long green zone. After the clock turns blue, a stop sign will come up to the screen. The software will measure the second position.




Figure 44 Run out Compensation 4

Once the 2nd position is taken, the software will instruct to push vehicle forward. The same clock will appear once the vehicle is back at 0 degree.

Note: Since you have the rubber wheel stop in the front of one tire, the vehicle should stop very close to 0 degree.




Figure 45 Run out Compensation 5

After the vehicle is rolled back to 0 degree or original position, click “Next” icon on the screen or “PgDn” key on the keyboard to continue to next step.




Figure 46 Run out Compensation 6

Measuring Caster

When Run out Compensation is finished press Page Down to go to Caster swing screen.



Figure 47 Caster Swing Screen at 10 degree

There are three different angles you can use to measure caster. The angle you choose is selected by pressing F3 or F4 or F5. The software is able to calculate caster by measuring at 7, 10 or 20 degree. Once an angle is selected, it will show a red circle with white text indicating the angle you have chosen.

Enter the "Measure Caster" menu. The aligner will begin by completing a self-check and initialization. Following this the screen will direct you to the Straight Steering Wheel screen.

Following the instructions on screen, move the front wheels to the straight ahead position.



Figure 48 Straight Steering Wheel at 10 degree

When you have completed this, the screen will confirm that you are ready to start measuring caster. Start to measure caster.



Figure 49 Caster Measurement Screen

Follow the instructions on the screen to measure the caster angle. Begin by turning the front wheels to the left until the screen tells you to stop. Insure the front wheels maintain a steady position as the computer will take a measurement at this point. When the measurement is completed the screen will advise "OK" (see figure 50).



Figure 50 Instruction to turn steering wheel left

The screen will then ask you to turn the front wheels to the right and when you reach the correct point it will tell you to stop. Insure the front wheels maintain a steady position as the computer will take a measurement at this point. When the measurement is completed the screen will advise "OK".



Figure 51 Instruction to turn steering wheel right

The caster measurement is now complete and the screen will ask you to return the front wheels to the straight ahead position. Watching the on screen meter turn the wheels until it tells you to stop and the meter reaches zero.



Warning Screen

Note: If any target has a problem, the screen will display following warning screen:



DO NOT block sightline of camera to target during measuring process.

The aligner screen displays all measurement results. Any measurement with a RED text is not in manufacturer specs tolerance (adjustments are required). Measurements with a GREEN text are in manufacturer specs tolerance. The data with white text means the item cannot be adjusted or no manufacturer data has been provided.



Rear Axle Reading

Press “PgDn” under Measuring Caster Menu to enter rear-axle reading screen.

Press F8 under other screens to enter rear-reading screen.

A colored background indicates the relationship between dynamic and prescribed values. A RED background indicates the angle value is out of range and has been disqualified by the computer. A GREEN background indicates the measurement is within range. A light blue background indicates it is close to range. When the angle value is out of prescribed range, the wheel illustration in the center on the side turns red and to inclined position



Figure 55 Rear Axle Readings



A picture of a wrench under the diagram suggests the item is adjustable.

ZOOM IN—select item need to be zoomed in by arrow direction key and press Enter.





Figure 56 Zoom Function

Press F1 to see zoomed angle display. Press Page Dn or Page Up to close zoom in. Use the Arrow direction key to select a meter. Press Enter to zoom in.

Front Axle Reading

Press Page Down to enter front reading screen. Press F7 under other screen to enter front reading screen.

Figure 57 Front Reading Screen



When working with front readings, the steering wheel must be kept in the straight ahead position and all sensors must be tightened. Front reading screen functions are similar to the rear reading screen.



A picture of a wrench under the diagram indicates the item is adjustable.
ZOOM IN—select the item you want to zoom in on using the arrow direction key



Use arrow direction key to select a meter and Press Enter.
Press Page UP to enter front reading.

Front wheel adjusting sequence:

1. Caster
2. Camber
3. Toe

If a caster measurement is out of range of manufacturers' data, adjust caster first.

Software Functions

Live Caster

Press F6 to enter measuring caster screen. Press F2 to enter adjusting caster screen. Live caster will only be available after completing the caster swing procedure. Caster swing must be redone if any adjustment has been made to the vehicle.

Press F6-F2 or F5 under Front Axle reading to go back to live caster screen.



Figure 58 Live Caster Screen

Super Toe


Press F7 to enter front reading screen. Then press

Figure 59 Super Toe Screen



The computer will measure the toe condition of the front left wheel first and display the reading. Turn the wheel left to calculate value.

Figure 62 Left Front Toe



After finishing left wheel adjusting, press Page Dn. Screen instructs to turn right wheel to repair required position. Then press PgDn to start measuring again.

Figure 63 Right Front Toe





Figure 64 Right Front Toe



Turn right wheel to calculate value.

Figure 65 Front Toe



Press PageDn to display adjusted front toe.

Display and Print Measuring Result

Press F9 from any screen to enter the all measurements screen or Page Dn from Front Axle reading.



Figure 66 Result Screen

This screen displays all measuring results. A RED background indicates the angle value is out of range and has been disqualified by the computer (further adjustments are required). A GREEN background indicates the measurement is within range. A light background indicates the manufacturer's set parameter or that it cannot be adjusted.

Press F2 for vehicle factory data reference screen.

Press F3 to enter vehicle inspection screen if inspection is not done.

Press F1 to print out measuring result.

Customer Data




Figure 67 Select Customer Screen

Select an existing customer name by using Up or Down arrow direction keys. Press Page Dn to enter customer vehicle plate number screen. Select plate number by using arrow direction keys and press Page Dn. Enter vehicle odometer reading in following window and press PgDn to print out result.




Figure 68 Existing Vehicle Plate Number

If customer vehicle plate number is not listed, press F1 and enter plate number in the window




Figure 69 New Vehicle

Press Page Dn when finished editing and follow the steps above.
Press F2 to delete selected vehicle plate number and press Page Down to confirm.

New Customer Information

Figure 70 New Customer Screen

Press F1 under customer menu to enter new customer information screen. Add new customer information. Select item by using Up or Down arrow direction keys. When finished, press Page Dn to display next window. Enter customer vehicle plate number in this window and press Page Dn. Enter customer's vehicle odometer in this window and press Page Dn. Printer starts to print out result. Screen displays printing process page.

Part IV Aligner Maintenance

Press F11 under main menu screen to enter Manager Screen.


Figure 71 Aligner Maintenance

Screen

Lift Level Calibration (Follow initial setup procedure on page 20)

Database Manager

Figure 72 Data Bank Manager



Database manager includes Vehicle Data Manager and Customer Data Manager. Press F11 under main menu screen to enter manager screen. Press F3 to enter data manager screen. The manufacture provides vehicle data upgrades regularly, however, the Operator can add new vehicle data at any time by this function.

Add New Vehicle Data

Press F1 to display new vehicle data screen. Operator can add new vehicle data by using this screen. First select vehicle manufacturer by using up or down arrow direction keys. If the vehicle manufacturer is not listed, press F1 to add new vehicle manufacturer.

Figure 73 Add New Vehicle Data Manager



Press F1 to enter vehicle manufacturer country.

Select manufacturer country by using Up or Down arrow direction key.
 If the country is not listed, press F1 to add country, and press Page Down when finished.
 After inputting the country name, press Page Dn to add vehicle manufacturer.
 Press Page Dn when finished to enter vehicle data screen.
 Select item column by up or down arrow direction key. Input data in selected column.

Figure 74 Add Vehicle Manufacturer Data

Press Page Dn when finished to enter next page-front wheel.
 Press arrow direction key to skip item.
 Press Page Dn when finished to enter next page-rear wheel.

Figure 75 Add Vehicle Specification Data

	Value (Deg.)	Positive	Tolerance	Negative
Total Toe	0.06	0.25		0.25
Camber	0.50	0.75		0.75
Max. Tolerance	0.00			
Caster	4.50	2.40		2.40
Max. Tolerance	-0.40			
Included Angle	0.00	0.00		0.00
Max. Tolerance	0.00			
Full Steering Angle	0.00	0.00		0.00
Steering Diff. at 20 deg.	0.00	0.00		0.00

Press Page Down when finished to enter next page-leaving factory data.
 Screen displays all data input. Check back and edit data by using Page Up to go back to previous page. Press Page Down to enter leaving factory data screen when finished editing.
 When all finished, press Page Down to save data. Go back to databank manager screen when finished.

Vehicle manufacturer's Data Rear Axle KJC-9000

	Value (Deg.)	Positive	Tolerance	Negative
Total Toe	0.00	0.00		0.00
Camber	0.00	0.00		0.00
Max. Tolerance	0.00			

Vehicle Weight (kg)

CS Previous Help Next

Figure 76 Add Vehicle Specification Data

Update Vehicle Database

Warning: Only authorized technician should perform database update. Improper operation may cause database corrupted.

Exit SureAlign alignment software by press ESC key once, then press F8 , enter service password.

Get database update file from the manufacture or authorized local distributor

Copy supply.xpd or replace.xpd in root of C drive >> ie. C:/

Note: Supply.xpd will add new data to the existing database, thus may duplicate data. Replace.xpd will check and compare existing database then add only newer data to the database.

Attention: If customized data is entered and have the same vehicle name, year and model, the customized data may erased.

Once either the supply.xpd or replace.xpd is under C:/ root drive, click "Minster" icon on the desktop to run alignment software. From the home screen, press F11-F3, enter service password, then F3. The alignment program will automatically upate vehicle data. The middle of screen displays processing window. When upgrade is finished, this window disappears.

Internet Update

Make sure your computer is connected to the internet.

Press F4 to update. The software will download the database from the manufacture server and update the software automatically.

Customer Information Manager

Press F11- F3 to enter customer information manager screen.

Customers' names are listed on the left side of screen. Select customer name by Up or Down arrow direction key. Right side of screen displays information of selected customers.

Press F9 or F10 or F11 to sort customers' name by required sequence.

Press F1 to add a new customer. Operator can input new customer data under new customer

screen.

Press F2 to edit customer's information.

















Press F3 to delete selected customer. Press Page Down to confirm.

Press Page Down to exit customer information manager screen. Press HOME to go back to main menu screen.

Please refer to this manual when performing alignments.

For more information, please contact your local agent.

Appendix 1: Basic Shortcuts

Keystroke	Screen	Function
	Rear Reading Screen; Front Reading Screen; Measuring Caster Menu; Easy Toe Screen.	Enter Runout Compensation screen
	Front Reading Screen	Enter Measuring Caster Menu
	Measuring Caster Menu	Enter easy toe screen.
	Measuring Caster Menu	High Precision selection
	Measuring Caster Menu	Enter Difference of 20 Degree Steering Turn screen
		Enter Measuring Caster Menu
		Enter Front Reading screen
		Enter Rear Reading screen
		Enter measuring result screen
	All screens	Help
		Enter next function screen
		Enter next function screen
	All screens	Back to main menu screen
		To select item
		To Edit
	Rear Reading screen; Front Reading Screen	Zoom In
	main menu screen	Finish alignment and exit

Appendix 2: Troubleshooting

Symptom	Possible Cause	Suggested Repair
Aligner No screen display	Power	Check power supply Check cable connection
	Power cable	Check and change cable Check fuse
	Fuse	Check voltage, change fuse Contact manufacture Change fuse
	Monitor power not on	Check monitor power
	Monitor or video card failure	Contact local computer service
Windows does not start	Windows problem	Contact local computer service
	Bad computer components	Contact manufacture
Windows starts but does not load alignment Menu	Corrupted system files	Contact local computer service
	Software damaged	If reinstallation of alignment software is required, please contact the manufacture
Program slow or stops	Voltage interference	Press CTRL ALT and DEL keys at the same time to restart computer. Otherwise, switch off console and restart computer again. Contact the manufacture.

Appendix 3: Technical Specifications

Features:

Measuring range
and accuracy


Parameter	Accuracy	range
Total Toe	$\pm 2'$	$\pm 50^\circ$
Separate Toe	$\pm 2'$	$\pm 25^\circ$
Camber	$\pm 1'$	$\pm 15^\circ$
Set back	$\pm 2'$	$\pm 9^\circ$
Trust Angle	$\pm 2'$	$\pm 9^\circ$
Caster	$\pm 2'$	$\pm 22^\circ$
King Pin	$\pm 2'$	$\pm 22^\circ$

Console Size



Power Voltage: 110/220V 50/60Hz



Appendix 4: ProtoStar Aligner Components and Parts Lists



1	80330101	Front Camera Cover (Right)
2	80330401	M16*12 Screw
3	80330201	Camera Assembly Support
4	80330310	Camera Assembly(Right)
5	80330102	Rear Camera Cover(Right)
6	80330402	M4*20 Screw
7	80330403	M5*16 Socket head cap screw
8	80330404	M6*12 Socket head cap screw
9	80330204	Steel Rod
10	80330205	Bracket for Steel Rod
11	80330405	M6*10 Screw
12	80330406	M5*8 Screw
13	80330103	Center Cover(ProtoStar logo)
14	80330407	M4*10 Screw
15	80330104	Rear Camera Cover(Left)
16	80330320	Camera Assembly(Left)
17	80330105	Front Camera Cover (Left)
18	80330410	M3*16 Screw
19	80330206	Power Board for Assistant LED
20	80330411	Ø4*8 Washer
21	80330203	Aluminium Camera Bar

Appendix 4: Aligner Components and Parts Lists (continued)


1	Post main frame	80340001
2	Track Rod Lower Holder	80340002
3	MX screw	80340003
4	MX screw	80340004
5	Track Rod	80340005
6	MX screw	80340006
7	MX screw	80340007
8	Counter weight back cover	80340008
9	Counter weight back cover	80340009
10	MX nuts	80340010
11	MX screw	80340011



12	Bearing	80340012
13	Screw of bearing (MX)	80340013
14	MX screw	80340014
15	Moveable Handle	80340015
16	Adjustment Knob	80340016
17	MX screw	80340017
18	Track Frame	80340018
19	O ring	80340019
20	Camera beam support bracket	80340020
21	MX screw	80340021
22	MX screw	80340022
23	Steel rod	80340023
24	Spring holding screw	80340024
25	spring	80340025
26	washer	80340026
27	MX nuts	80340027

Appendix 4: Aligner Components and Parts Lists (continued)

Wheel Clamp (25 Inch)



No.	Parts No.	Description
	80130100	Wheel Clamp
1	80130101	Wheel Clamp End Nut
2	80130102	Wheel Clamp End Plate
3	80130103	Wheel Clamp Plastic Plug
4	80130104	Wheel Clamp Standard Finger
5	80130105	Wheel Clamp Standard Finger Holding Stud
6	80130106	Wheel Clamp Lower Casting
7	80130107	Wheel Clamp Slider Rod
8	80130108	Wheel Clamp Main Treaded Shaft
9	80130109	Wheel Clamp Spindle Lock Nut
10	80130110	Wheel Clamp Center Spindle Casting
11	80130111	Wheel Clamp Spindle
12	80130112	Wheel Clamp Spindle Locking Bolt Spring
13	80130113	Wheel Clamp Spindle Locking Bolt Bushing
14	80130114	Wheel Clamp Spindle Locking Bolt
15	80130115	Wheel Clamp Threaded Brass Bushing Upper
16	80130116	Wheel Clamp Adjustment Knob
17	80130117	Wheel Clamp Slider Rod Lock Thumb Screw
18	80130118	Wheel Clamp Washer
19	80130119	Wheel Clamp Stud Acorn Nut
20	80130120	Wheel Clamp Stud Washer
21	80130121	Wheel Clamp Locking Screw and Sleeve
22	80130122	Wheel Clamp Washer
23	80130123	Wheel Clamp Threaded Brass Bushing Lower
24	80130124	Wheel Clamp End Nut Locking Set Screw
	80130130	Wheel Clamp Meg Finger
	80130131	Wheel Clamp Hubcap Finger

Optional Wheel Clamps

80130300



80130400

