

# User's Manual

## Model UP350 Program Controller

### User's Manual

#### Installation

IM 05E01D02-01E

**YOKOGAWA**  
Yokogawa M&C Corporation



2nd Edition: Jul 1, 2001

This manual describes installation, wiring, and other tasks required to make the controller ready for operation.

## Contents

1. Safety Precautions
2. Model and Suffix Codes
3. How to Install
4. How to Connect Wires
5. Hardware Specifications
6. Terminal Wiring Diagrams

## Introduction

Thank you for purchasing the UP350 program controller. The controller is shipped from the factory with 4 hardcopy user's manuals (A2 size) and 1 user's manual on CD-ROM. The 4 user's manuals in hardcopy format describe the operating procedures required for basic use. It is recommended that you refer to these user's manuals to understand [1] installation, [2] initial settings, [3] program settings, and [4] operating procedures of the controller. The CD-ROM contains an User's Manual (Reference) with descriptions of various functions and setting ranges that can be set as necessary. Moreover, the use of an optional parameter setting tool (model: LL100-E10) allows you to easily perform settings and adjustments with a PC.

## How to Use the Manuals

Purpose	Manual Title	Description	Media
Setup	Installation	Describes the tasks (installation, wiring, and others) required to make the controller ready for operations.	A2-size paper, front
Basic operation	Initial Settings	Describes examples of setting PV input types, and control output types. Making settings described herein and program creation in Programming User's Manual allow you to carry out basic control.	A2-size paper, front
Program creation	Programming	Describes examples of creating basic programs. See Program Pattern Setup Charts on the back of Installation User's Manual, and program functions.	A2-size paper, back and front
Operating procedures and troubleshooting	Operations	Describes key operation sequences. For operation control through external contact inputs, see the back of Installation User's Manual.	A2-size paper, back
Brief operation and setpoint recording	Parameters	Contains the parameter map used as a guideline for setting parameters and lists of parameters for recording User Settings.	A2-size paper, back and front
Detailed description of functions	User's Manual (Reference)	Explains more advanced applications than those found in the 4 hardcopy user's manuals (A2 size).	CD-ROM

## 1. Safety Precautions

The following symbol is indicated on the controller to ensure safe use.

### CAUTION

This symbol on the controller indicates that the operator must refer to an explanation in the user's manual in order to avoid the risk of injury or death of personnel or damage to the instrument. The manual describes how the operator should exercise special care to avoid electric shock or other dangers that may result in injury or loss of life.

The following symbols are used in the hardcopy user's manuals and in the user's manual supplied on the CD-ROM.

### NOTE

Indicates that operating the hardware or software in a particular manner may damage it or result in a system failure.

### IMPORTANT

Draws attention to information that is essential for understanding the operation and/or features of the controller.

## 2. Model and Suffix Codes

Before using the controller, check that the model and suffix codes match your order.

Model	Suffix Code	Description
UP350		Program controller (provided with retransmission output and 15V DC loop power supply as standard)
Type	-0	Standard type
Optional functions	0 1	None With communication


Check that the following items are provided:

- Program controller (of ordered model): 1
- Brackets (mounting hardware): 1 pair
- Unit label: 1
- User's Manuals: 4 (A2 size)
- User's Manual (Reference) (CD-ROM version): 1

## 3. How to Install


### Installation Position

Install the controller at an angle within 30° from horizontal with the front panel facing upward. Do not install it facing downward. The position of right and left sides should be horizontal.



## NOTE

- To install the controller, select a location where:
- (1) no one may accidentally touch the terminals,
  - (2) mechanical vibrations are minimal,
  - (3) corrosive gas is minimal,
  - (4) temperature can be maintained at about 23°C and the fluctuation is minimal,
  - (5) no direct radiant heat is present,
  - (6) no magnetic disturbances are caused,
  - (7) no wind blows against the terminal board (reference junction compensation element),
  - (8) no water is splashed,
  - (9) no flammable materials are around.




Never place the controller directly on flammable items or equipment. If the controller has to be installed close to flammable items or equipment, be sure to provide shielding panels all around the controller, at least 150mm away from every side; the panels should be made of either 1.43mm-thick metal-plated steel plates or 1.6mm-thick uncoated steel plates.

## NOTE

Never touch the opening at the bottom of the case. It is to be used in the factory at shipping.


## External Dimensions and Panel Cutout Dimensions



## How to Install

### CAUTION

Turn off the power to the controller before installing it on the panel because there is a possibility of electric shock.



## 4. How to Connect Wires


### CAUTION

- 1) Before carrying out wiring, turn off the power to the controller and check that the cables to be connected are not alive with a tester or the like because there is a possibility of electric shock.
- 2) Wiring must be carried out by personnel who have basic electrical knowledge and practical experience.


### NOTE

- 1) Provide power from a single-phase instrument power supply. If there is a lot of noise in the power line, insert an insulating transformer into the primary side of the line and use a line filter (recommended part: ZAC2205-00U from TDK) on the secondary side. As a countermeasure against noise, do not place the primary and secondary power cables close to each other.
- 2) For thermocouple input, use shielded compensating lead wires for wiring. For RTD input, use shielded wires that have low conductor resistance and cause no significant differences in resistance between the three wires. The cables to be used for wiring, terminal specifications, and recommended parts are as shown below.
- 3) Control output relays may be replaced. However, because they have a life of 100,000 times that of the resistance load, use auxiliary relays to turn on/off a load.
- 4) The use of inductance (L) loads such as auxiliary relays, motors and solenoid valves causes malfunction or relay failure; always insert a CR filter for use with alternating current or a diode for use with direct current, as a spark-removal surge suppression circuit, into the line in parallel with the load.
- 5) When there is possibility of being struck by external lightning surge, use the arrester to protect the instrument.

### For DC Relay Wiring



### For AC Relay Wiring



## Cable Specifications and Recommended Cables

Purpose	Name and Manufacturer
Power supply, grounding, relay contact outputs	600 V PVC insulated wires, JIS C 3307, 0.9 to 2.0 mm <sup>2</sup>
Thermocouple	Shielded compensating lead wires, JIS C 1610, □□□□□□□□ (See Yokogawa Electric's GS 6B1U1-E.)
RTD	Shielded wires (three conductors), UL2482 (Hitachi Cable)
Other signals	Shielded wires

## Recommended Terminal Lugs

Applicable wire size	Tightening torque
0.3 to 1.65 mm <sup>2</sup>	0.8 N·m or less



## Terminal Covers (Optional parts)

Target Model	Part Number	Sales Unit
UP350	T9115YD	1

## 5. Hardware Specifications

### PV Input Signals

- Number of inputs: 1 (terminals ①-③)
- Input type: Universal input system. The input type can be selected with the software.
- Sampling period: 250 ms
- Burnout detection: Functions at TC, RTD, standard signal (0.4 to 2 V or 1 to 5 V)
  - For standard signal, burnout is determined to have occurred if it is 0.1 V or less.
- Input bias current: 0.05 μA (for TC or RTD b-terminal)
- Measurement current (RTD): About 0.13 mA
- Input resistance: 1 MΩ or more for thermocouple or mV input
  - About 1 MΩ for DC voltage input
- Allowable signal source resistance: 250 Ω or less for thermocouple or mV input
  - Effects of signal source resistance: 0.1 μV/Ω or less 2 kΩ or less for DC voltage input
  - Effects of signal source resistance: About 0.01%/100 Ω
- Allowable wiring resistance: For RTD input
  - Maximum 150 Ω/wire: Conductor resistance between three wires should be equal
  - However, 10 Ω/wire for a maximum range of -150.0 to 150.0°C.
  - Wire resistance effect: ±0.1°C/10 Ω
- Allowable input voltage: ±10 V DC for thermocouple, mV, or RTD input
  - ±20 V DC for DC voltage input
- Noise rejection ratio: 40 dB (50/60 Hz) or more in normal mode 120 dB (50/60 Hz) or more in common mode
- Reference junction compensation error: ±1.0°C (15 to 35°C) ±1.5°C (0 to 15°C, 35 to 50°C)
- Applicable standards: JIS, IEC, DIN (ITS-90) for thermocouples and RTD

### Retransmission Output

- Either PV, program setpoint, or control output is output. Either the retransmission output or the loop power supply can be used with terminals ⑭-⑰.
- Number of outputs: 1 (terminals ⑭-⑰)
  - Output signal: 4-20 mA DC
  - Load resistance: 600 Ω or less
  - Output accuracy: ±0.3% of span under standard operating conditions (23 ±2°C, 55 ±10% RH, power frequency of 50/60 Hz)

### Control Output

Universal output system. The output type can be selected with the software.

Number of outputs	1 (switched between a voltage pulse output and current output)
Output signal	4-20 mA DC
Load resistance	600 Ω or less
Output accuracy	±0.3% of span under standard operating conditions (23 ± 2°C, 55 ± 10% RH, power frequency of 50/60 Hz)

Number of outputs	1 (switched between a voltage pulse output and current output)
Output signal	On-voltage = 12 V or more (load resistance: 600 Ω or more) Off-voltage = 0.1 V DC or less
Resolution	10 ms

Number of outputs	1
Output signal	Three terminals (NC, NO, and common)
Contact rating	250 V AC or 30 V DC, 3 A (resistance load)
Resolution	10 ms

### Loop Power Supply


Power is supplied to a two-wire transmitter. (15 V DC: terminals ⑱-⑳) A resistor (10 to 250 Ω) connected between the controller and transmitter converts a current signal into a voltage signal, which is then read via the PV input terminal. Supply voltage: 14.5 to 18.0 V DC, max. 21 mA (provided with a protection circuit against a field short-circuit)

## 6. Terminal Wiring Diagrams

### NOTE

Do not use unassigned terminals as relay terminals.

## UP350 Standard Type (Model UP350-0□)



## Contact Inputs

- Purpose: Run/Reset switching
- Number of inputs: 2 points
- Input type: Non-voltage contact or transistor open collector input
- Input contact rating: 12 V DC, 10 mA or more
- On/off determination: For non-voltage contact input, contact resistance of 1 kΩ or less is determined as "on" and contact resistance of 20 kΩ or more as "off". For transistor open collector input, input voltage of 2 V or less is determined as "on" and leakage current must not exceed 100 μA when "off".
- Minimum status detection hold time: About 1 second

## Contact Outputs

- Purpose: PV event outputs (2) and time event output (1)
- Number of outputs: 3 points
- Relay contact rating: 240 V AC, 1 A, or 30 V DC, 1 A

## Display Specifications

- PV display: 4-digit, 7-segment red LED display, character height of 20 mm
- Setpoint display: 4-digit, 7-segment red LED display character height of 9.3 mm
- Status indicating lamps: LEDs

## Safety and EMC Standards

- Safety: Compliant with IEC1010-1: 1990 and EN61010-1: 1992 Approved by CSA1010 CSA1010 installation category (overvoltage category): CATH (IEC1010-1) Approved by UL508
- EMC standards: Complies with EN61326. The instrument continues to operate at a measuring accuracy of within ±20% of the range during tests.

## Construction, Installation, and Wiring

- Construction: Only the front panel is dust-proof and drip-proof (protection class IP55) For side-by-side close installation the controller loses its dust-proof and drip-proof protection.
- Material: ABS resin and polycarbonate
- Case color: Black
- Weight: About 1 kg or less
- Dimensions: 96 (W) × 96 (H) × 100 (depth from panel face) mm
- Installation: Panel-mounting type. With top and bottom mounting hardware (1 each)
- Panel cutout dimensions: 92<sup>+0.8</sup> (W) × 92<sup>+0.8</sup> (H) mm (not designed for facing downward)
- Installation position: Up to 30° upward facing
- Wiring: M3.5 screw terminals (for signal wiring and power/ground wiring as well)

## Power Supply Specifications

- Power supply: Rated voltage of 100 to 240 V AC (±10%), 50/60 Hz
- Power consumption: Max. 20 VA (8.0 W max.)
- Internal fuse rating: 250 V AC, 1.6A time-lag fuse
- Data backup: Non-volatile memory (can be written to up to 100,000 times)
  - Between primary terminals\* and secondary terminals\*\*:
  - At least 1500 V AC for 1 minute (Note)
  - Between primary terminals\* and grounding terminal: At least 1500 V AC for 1 minute (Note)
  - Between grounding terminal and secondary terminals\*\*:
  - At least 1500 V AC for 1 minute
  - Between secondary terminals\*\*:
  - At least 500 V AC for 1 minute
- \* Primary terminals indicate power terminals and relay output terminals
- \*\* Secondary terminals indicate analog I/O signal, voltage pulse output, and contact input terminals
- Note: The withstanding voltage is specified as 2300 VAC per minute to provide a margin of safety.
- Insulation resistance: 20 MΩ or more at 500 V DC between power terminals and grounding terminal
- Grounding resistance: Class 3 grounding (grounding resistance of 100 Ω or less)

## Signal Isolations

- PV input terminals: Isolated from other input/output terminals. Not isolated from the internal circuit.
- 15 V DC loop power supply terminals: Not isolated from 4-20 mA analog output and voltage pulse control output. Isolated from other input/output terminals and internal circuit.
- 4-20 mA analog output terminals (for control output and retransmission): Not isolated between 4-20 mA outputs and from 15 V DC loop power supply and voltage pulse control output. Isolated from other input/output terminals and internal circuit.
- Voltage pulse control output terminals: Not isolated from 4-20 mA outputs and 15 V DC loop power supply. Isolated from other input/output terminals and internal circuit.
- Relay contact control output terminals: Isolated between contact input terminals and from other input/output terminals and internal circuit.
- Contact input terminals: Not isolated between contact input terminals and from communication terminals. Isolated from other input/output terminals and internal circuit.
- Relay contact event output terminal: Not isolated from each other; isolated from other input/output terminals and the internal circuit.
- RS-485 communication terminals: Not isolated from contact input terminals. Isolated from other input/output terminals and internal circuit.
- Power terminals: Isolated from other input/output terminals and internal circuit.
- Grounding terminals: Isolated from other input/output terminals and internal circuit.

## Environmental Conditions

- Normal operating conditions:
  - Ambient temperature: 0 to 50°C (40°C or less for side-by-side close installation)
  - Temperature change rate: 10°C/h or less
  - Ambient humidity: 20 to 90% RH (no condensation allowed)
  - Magnetic field: 400 A/m or less
  - Continuous vibration at 5 to 14 Hz: Full amplitude of 1.2 mm or less
  - Continuous vibration at 14 to 150 Hz: 4.9 m/s<sup>2</sup> or less
  - Short-period vibration: 14.7 m/s<sup>2</sup>, 15 seconds or less
  - Shock: 147 m/s<sup>2</sup> or less, 11 ms
  - Installation height: Height above sea level of 2000 m or less
  - Warm-up time: 30 minutes or more after power on
- Transportation and storage conditions:
  - Temperature: -25 to 70°C
  - Temperature change rate: 20°C/h or less
  - Humidity: 5 to 95% RH (no condensation allowed)
  - Effects of changes in operating conditions
    - Effects from changes in ambient temperature:
      - On voltage or thermocouple input: ±1 μV/°C or ±0.01% of F.S./°C, whichever is larger
      - On RTD input, ±0.05°C/°C (ambient temperature) or less
      - On analog output, ±0.05% of F.S./°C or less
    - Effects from power supply fluctuation (within rated voltage range)
      - On analog input, ±1 μV/10 V or ±0.01% of F.S./10 V, whichever is larger
      - On analog output, ±0.05% of F.S./10 V or less

**Program Pattern Setup Charts**


See "1. Overview of Program Patterns" and "2. Example of Program Pattern Setup Charts" in the **Programming User's Manual** for details on how to use the setting charts.

There are two identical charts shown below because two programs can be registered with the UP350.

Fill in the fields with bold-face borders in the order of steps 1 to 10, as shown below. Then, input these setup data items to the UP350.


1. Maximum value of PV input range: Setpoint of the setup parameter "Maximum Value of PV Input Range (RH)"
2. Minimum value of PV input range: Setpoint of the setup parameter "Minimum Value of PV Input Range (RL)"
3. PV input unit: Setpoint of the setup parameter "PV Input Unit (UNIT)"
4. Program time unit: Setpoint of the setup parameter "Program Time Unit (TMU)"
5. Segment setting method: Setpoint of the setup parameter "Segment Setting Method (SEG.T)"
6. Starting target setpoint: Setpoint of the program parameter "Starting Target Setpoint (SSP)"
7. Start code: Setpoint of the program parameter "Start Code (STC)"
8. Junction code: Setpoint of the program parameter "Junction Code (JC)"
9. Target setpoint, Segment time, PV events 1 and 2, and Time event: Setpoint of each program parameter
10. Draw the program pattern.

System name		Program time unit (TMU)	4	Starting target setpoint (SSP)	6
Program No.		Segment setting method (SEG.T)	5	Start code (STC)	7
Program name				Junction code (JC)	8
Model	UP350 -				
Serial No.					



Segment No.		1	2	3	4	5	6	7	8	9	10
Target setpoint (SP)											
Segment time (TM)											
PV event 1	Event type (AL1)										
	Event setpoint (A1)										
PV event 2	Event type (AL2)										
	Event setpoint (A2)										
Time event	On time of time event (EON)										
	Off time of time event (EOF)										

System name		Program time unit (TMU)	4	Starting target setpoint (SSP)	6
Program No.		Segment setting method (SEG.T)	5	Start code (STC)	7
Program name				Junction code (JC)	8
Model	UP350 -				
Serial No.					




Segment No.		1	2	3	4	5	6	7	8	9	10
Target setpoint (SP)											
Segment time (TM)											
PV event 1	Event type (AL1)										
	Event setpoint (A1)										
PV event 2	Event type (AL2)										
	Event setpoint (A2)										
Time event	On time of time event(EON)										
	Off time of time event(EOF)										

This manual describes examples of setting PV input types, control output types, and alarm types. Carrying out settings described herein allows you to perform basic control. Refer to examples of various settings to understand how to set parameters required. Refer to "1. Parameter Map" in **Parameters User's Manual** for an easy to understand explanation of setting various parameters. If you cannot remember how to carry out an operation during setting, press the  $\square$  key for more than 3 seconds. This brings you to the display (operating display) that appears at power-on.

Contents

- Names and Functions of Front Panel Parts
- Setting PV Input Type (Setting First at Power-on)
- Changing PV Input Type
- Setting Control Output Type
- Changing Alarm Type
- Description of Multiple Setpoints and PID

1. Names and Functions of Front Panel Parts



Name of Part	Function
1. Process variable (PV) display	Displays PV. Displays a parameter symbol when you set a parameter. Displays an error code (in red) if an error occurs.
2. Setpoint display	Displays the setpoint (SP) or the output value (OUT) during operation. Displays the set value of parameters on the parameter setting display.
3. Target setpoint (SP) number indicator lamps	When the SP number currently used for operation is 2, 3 or 4, the respective SP No. indicator lamp lights. When the SP number is 1, the lamp does not light.
4. Status indicator lamp	Is lit in green during manual operation. MAN: Is lit when in manual mode. Blinks during auto-tuning.
5. Alarm indicator lamps	If any of alarms 1 to 3 occurs, the respective alarm indicator lamp (AL1 to AL3) is lit (in orange).
6. Light-loader interface	Interface for an adapter cable used when setting and storing parameters from a PC. This requires an optional parameter setting tool.
7. A/M key	Used to switch between the AUTO and MAN modes. Each time you press the key, it switches to the AUTO or MAN mode alternately.
8. SET/ENT key	Used to switch or register a parameter. Pressing the key for more than 3 seconds allows you to switch between the operating display and the menu for operating parameter setting display alternately.
9. $\nabla$ and $\Delta$ keys	Used to change numerical values. On setting displays for various parameters, you can change target setpoints, parameters, and output values (in manual operation). Pressing the $\nabla$ key decreases a numerical value, while pressing the $\Delta$ key causes it to increase. You can hold down a key to gradually increase the speed of change.

IMPORTANT

The controller automatically returns to the display at the time of power-on (i.e., operating display) if no key is operated for at least one minute.

Although only figures of the UT350 front panel are cited in "2. Setting PV Input Type (Setting First at Power-on)," and thereafter, the UT320 is identical to the UT350 in terms of front panel operation.



Setting of Main Parameters at the Factory before Shipment

Item	Factory-set defaults for standard type controllers	Factory-set defaults for heating/cooling type controllers
Control output	Time proportional PID relay output (variable)	Heating side: Time proportional PID relay output (variable) Cooling side: Time proportional PID relay output (variable)
Control action	Reverse action (variable)	Not specified
PID parameter	P = 5.0%, I = 240 seconds, D = 60 seconds.	
Alarm output	Alarm-1: PV high limit, Alarm-2: PV low limit, Alarm-3: PV high limit	

2. Setting PV Input Type (Setting First at Power-on)

NOTE

- The controller displays the operating display when the power is turned on. However, if PV input type has not been set, "IN" appears. In this case, first use the  $\square$  key to display the input range code to use, then press the  $\square$  key to register it. Then, set the maximum value (RH) and minimum value (RL) of the PV input range (for voltage input, set the maximum value (SH) and minimum value (SL) of the PV input scale).
- The controller is configured to the initial value of each parameter at the factory before shipment. First check the initial values shown in "2. Lists of Parameters," in **Parameters User's Manual** and change parameter values as necessary.



The following operating procedure describes an example of setting the controller to a K-type thermocouple (-199.9°C to 500.0°C) and the measurement range of 0.0°C to 200.0°C.

- Display screen at power-on. The parameter "IN" for setting the PV input type appears.
- Press the  $\square$  or  $\square$  key to display the required setpoint. The figure below is an example of the controller set to a K-type thermocouple (-199.9°C to 500.0°C). See "Instrument Input Range Codes."
- Press the  $\square$  key once to register the required setpoint.
- Press the  $\square$  or  $\square$  key to display the parameter "RL" (minimum value of PV input range).
- Press the  $\square$  key once to register the required setpoint.
- Press the  $\square$  or  $\square$  key to display the required setpoint. The figure below shows an example of setting the minimum value of PV input range to 0.0°C.
- Press the  $\square$  key once to display the parameter "UNIT" (PV Input Unit).
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the parameter "RH" (maximum value of PV input range).
- To set the type of control output, see steps 7 and later in "4. Setting Control Output Type." To finish settings, press the  $\square$  key for more than 3 seconds. This returns you to the display shown at power-on (figure below).
- Press the  $\square$  or  $\square$  key to display the required setpoint. The figure below shows an example of setting the maximum value of PV input range to 200.0°C.

Instrument Input Range Codes

Input	Type	Instrument Input Range Code	Instrument Input Range	Measurement Accuracy
Unspecified		OFF	Set the data item PV Input Type 'IN' to the OFF option to leave the PV input type undefined.	
K		1	-200 to 1370°C -300 to 2500°F	±0.1% of instrument range ±1 digit for temperatures equal to or higher than 0°C ±0.2% of instrument range ±1 digit for temperatures below 0°C
		2	-199.9 to 999.9°C 0 to 2300°F	
		3	-199.9 to 500.0°C -199.9 to 999.9°F	
		4	-199.9 to 999.9°C -300 to 2300°F	
		5	-199.9 to 400.0°C -300 to 750°F	
		6	0.0 to 400.0°C -199.9 to 750.0°F	
J		7	0 to 1800°C 32 to 3300°F	±0.15% of instrument range ±1 digit for temperatures equal to or higher than 400°C ±5% of instrument range ±1 digit for temperatures below 400°C
		8	0 to 1700°C 32 to 3100°F	
		9	0 to 1700°C 32 to 3100°F	
		10	-200 to 1300°C -300 to 2400°F	
		11	-199.9 to 999.9°C -300 to 1800°F	
		12	-199.9 to 900.0°C -300 to 1300°F	
T		13	-199.9 to 400.0°C -300 to 750°F	±0.1% of instrument range ±1 digit for temperatures equal to or higher than 0°C ±0.2% of instrument range ±1 digit for temperatures below 0°C
		14	0.0 to 400.0°C -199.9 to 750.0°F	
		15	0 to 2300°C 32 to 4200°F	
		16	0 to 1390°C 32 to 2500°F	
		17	0 to 1900°C 32 to 3400°F	
		18	0 to 2000°C 32 to 3600°F	
RTD		19	-150.0 to 150.0°C -199.9 to 300.0°F	±0.1% of instrument range ±1 digit (Note1) (Note2)
		20	-199.9 to 850.0°C -300 to 1560°F	
		21	-199.9 to 500.0°C -199.9 to 999.9°F	
		22	-150.0 to 150.0°C -199.9 to 300.0°F	
		23	-199.9 to 300.0°C -199.9 to 500.0°F	
		24	-150.0 to 150.0°C -199.9 to 300.0°F	
Standard signal		25	0.4 to 2 V 1 to 5 V	±0.1% of instrument range ±1 digit The read-out range can be scaled between -1999 and 9999.
		26	0 to 2 V 0 to 10 V	
		27	0 to 10 V 0 to 100 mV	
		28	0 to 10 V 0 to 100 mV	
		29	0 to 2 V 1 to 5 V	
		30	0 to 2 V 1 to 5 V	
DC voltage		31	1.000 to 5.000 V 0.000 to 2.000 V	±0.1% of instrument range ±1 digit (Note1) (Note2)
		32	0.000 to 2.000 V 0.000 to 10.00 V	
		33	-10.0 to 20.0 mV 0 to 100.0 mV	
		34	-10.0 to 20.0 mV 0 to 100.0 mV	
		35	-10.0 to 20.0 mV 0 to 100.0 mV	
		36	-10.0 to 20.0 mV 0 to 100.0 mV	

\* Performance in the standard operating condition (at 23±2°C, 55±10%RH, and 50/60Hz power frequency)  
Note1: The accuracy is ±0.3% of instrument range ±1 digit for a temperature range from 0°C to 100°C.  
Note2: The accuracy is ±0.5% of instrument range ±1 digit for a temperature range from -100°C to 200°C.  
\* To receive a 4-20 mA DC signal, select a standard signal of 1 to 5 V DC and connect it to a 250Ω resistor. This resistor is optional.  
Model: X010-250-2 (resistor with M3.5 crimp-on terminal lugs)

NOTE

The controller may automatically initialize the registered operating parameter setpoints if any change is made to the data item PV Input Type (IN), Maximum Value of PV Input Range (RH), Minimum Value of PV Input Range (RL), PV Input Decimal Point Position (SDP), Maximum Value of PV Input Scale (SH) or Minimum Value of PV Input Scale (SL). After a change has been made to any of these data items, be sure to verify the registered operating parameter setpoints to ensure that they are correct. If any data item has been changed to its default, set it to a required value.

3. Changing PV Input Type

The following operating procedure describes an example of changing the K-type thermocouple (-199.9°C to 500.0°C) to a Pt100 resistance temperature detector (-199.9°C to 500.0°C) and setting the measurement range of 0.0°C to 200.0°C.

- Bring the operating display into view (display appears at power on).
- Press the  $\square$  key for more than 3 seconds to call up the menu "OP.PA".
- Press the  $\square$  key once to display the menu "STUP".
- Press the  $\square$  key once to display the parameter "UNIT" (PV input unit).
- Press the  $\square$  key once to display the menu "FUNC".
- Press the  $\square$  or  $\square$  key to display the required setpoint. The figure below shows an example of setting the maximum value of PV input range to 200.0°C.
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the parameter "RH" (maximum value of PV input range).
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "I/O".
- Press the  $\square$  or  $\square$  key to display the required setpoint. The figure below shows an example of setting the minimum value of PV input range to 0.0°C.
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  key once to display the menu "FUNC".
- Press the  $\square$  or  $\square$  key to display the parameter "RL" (minimum value of PV input range).
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "I/O".
- Press the  $\square$  or  $\square$  key to display the required setpoint. The figure below shows an example of setting the minimum value of PV input range to 0.0°C.
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  key once to display the menu "I/O".
- Press the  $\square$  or  $\square$  key to display the parameter "RH" (maximum value of PV input range).
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "FUNC".
- Press the  $\square$  or  $\square$  key to display the parameter "RL" (minimum value of PV input range).
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "I/O".
- Press the  $\square$  or  $\square$  key to display the required setpoint. The figure below shows an example of setting the minimum value of PV input range to 0.0°C.
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "FUNC".
- Press the  $\square$  or  $\square$  key to display the parameter "RL" (minimum value of PV input range).
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "I/O".
- Press the  $\square$  or  $\square$  key to display the required setpoint. The figure below shows an example of setting the minimum value of PV input range to 0.0°C.
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "FUNC".
- Press the  $\square$  or  $\square$  key to display the parameter "RL" (minimum value of PV input range).
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "I/O".
- Press the  $\square$  or  $\square$  key to display the required setpoint. The figure below shows an example of setting the minimum value of PV input range to 0.0°C.
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "FUNC".
- Press the  $\square$  or  $\square$  key to display the parameter "RL" (minimum value of PV input range).
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "FUNC".
- Press the  $\square$  or  $\square$  key to display the parameter "RL" (minimum value of PV input range).
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "I/O".
- Press the  $\square$  or  $\square$  key to display the required setpoint. The figure below shows an example of setting the minimum value of PV input range to 0.0°C.
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "FUNC".
- Press the  $\square$  or  $\square$  key to display the parameter "RL" (minimum value of PV input range).
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "I/O".
- Press the  $\square$  or  $\square$  key to display the required setpoint. The figure below shows an example of setting the minimum value of PV input range to 0.0°C.
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "FUNC".
- Press the  $\square$  or  $\square$  key to display the parameter "RL" (minimum value of PV input range).
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "I/O".
- Press the  $\square$  or  $\square$  key to display the required setpoint. The figure below shows an example of setting the minimum value of PV input range to 0.0°C.
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "FUNC".
- Press the  $\square$  or  $\square$  key to display the parameter "RL" (minimum value of PV input range).
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "I/O".
- Press the  $\square$  or  $\square$  key to display the required setpoint. The figure below shows an example of setting the minimum value of PV input range to 0.0°C.
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "FUNC".
- Press the  $\square$  or  $\square$  key to display the parameter "RL" (minimum value of PV input range).
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "I/O".
- Press the  $\square$  or  $\square$  key to display the required setpoint. The figure below shows an example of setting the minimum value of PV input range to 0.0°C.
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "FUNC".
- Press the  $\square$  or  $\square$  key to display the parameter "RL" (minimum value of PV input range).
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "I/O".
- Press the  $\square$  or  $\square$  key to display the required setpoint. The figure below shows an example of setting the minimum value of PV input range to 0.0°C.
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "FUNC".
- Press the  $\square$  or  $\square$  key to display the parameter "RL" (minimum value of PV input range).
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "I/O".
- Press the  $\square$  or  $\square$  key to display the required setpoint. The figure below shows an example of setting the minimum value of PV input range to 0.0°C.
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "FUNC".
- Press the  $\square$  or  $\square$  key to display the parameter "RL" (minimum value of PV input range).
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "I/O".
- Press the  $\square$  or  $\square$  key to display the required setpoint. The figure below shows an example of setting the minimum value of PV input range to 0.0°C.
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "FUNC".
- Press the  $\square$  or  $\square$  key to display the parameter "RL" (minimum value of PV input range).
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "I/O".
- Press the  $\square$  or  $\square$  key to display the required setpoint. The figure below shows an example of setting the minimum value of PV input range to 0.0°C.
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "FUNC".
- Press the  $\square$  or  $\square$  key to display the parameter "RL" (minimum value of PV input range).
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "I/O".
- Press the  $\square$  or  $\square$  key to display the required setpoint. The figure below shows an example of setting the minimum value of PV input range to 0.0°C.
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "FUNC".
- Press the  $\square$  or  $\square$  key to display the parameter "RL" (minimum value of PV input range).
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "I/O".
- Press the  $\square$  or  $\square$  key to display the required setpoint. The figure below shows an example of setting the minimum value of PV input range to 0.0°C.
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "FUNC".
- Press the  $\square$  or  $\square$  key to display the parameter "RL" (minimum value of PV input range).
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "I/O".
- Press the  $\square$  or  $\square$  key to display the required setpoint. The figure below shows an example of setting the minimum value of PV input range to 0.0°C.
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "FUNC".
- Press the  $\square$  or  $\square$  key to display the parameter "RL" (minimum value of PV input range).
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "I/O".
- Press the  $\square$  or  $\square$  key to display the required setpoint. The figure below shows an example of setting the minimum value of PV input range to 0.0°C.
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "FUNC".
- Press the  $\square$  or  $\square$  key to display the parameter "RL" (minimum value of PV input range).
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "I/O".
- Press the  $\square$  or  $\square$  key to display the required setpoint. The figure below shows an example of setting the minimum value of PV input range to 0.0°C.
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "FUNC".
- Press the  $\square$  or  $\square$  key to display the parameter "RL" (minimum value of PV input range).
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "I/O".
- Press the  $\square$  or  $\square$  key to display the required setpoint. The figure below shows an example of setting the minimum value of PV input range to 0.0°C.
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "FUNC".
- Press the  $\square$  or  $\square$  key to display the parameter "RL" (minimum value of PV input range).
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "I/O".
- Press the  $\square$  or  $\square$  key to display the required setpoint. The figure below shows an example of setting the minimum value of PV input range to 0.0°C.
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "FUNC".
- Press the  $\square$  or  $\square$  key to display the parameter "RL" (minimum value of PV input range).
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "I/O".
- Press the  $\square$  or  $\square$  key to display the required setpoint. The figure below shows an example of setting the minimum value of PV input range to 0.0°C.
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "FUNC".
- Press the  $\square$  or  $\square$  key to display the parameter "RL" (minimum value of PV input range).
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "I/O".
- Press the  $\square$  or  $\square$  key to display the required setpoint. The figure below shows an example of setting the minimum value of PV input range to 0.0°C.
- Press the  $\square$  key once to register the setpoint.
- Press the  $\square$  or  $\square$  key to display the menu "FUNC".
- Press the  $\square$  or  $\square$  key to display the parameter "RL" (minimum value of PV input range).
- Press the  $\square$

This manual describes key entries for operating the controller. For operations using external contact inputs, see "6. Terminal Wiring Diagrams" in **Installation User's Manual**. If you cannot remember how to carry out an operation during setting, press the **[F]** key for more than 3 seconds. This brings you to the display (operating display) that appears at power-on.

**Contents**


- Setting Target Setpoint (SP)
- Performing/Canceling Auto-tuning
- Setting PID Manually
- Setting Alarm Setpoints
- Selecting Target Setpoint Numbers (SP.NO)
- Switching between Run and Stop
- Switching between AUTO and MAN
- Manipulating the Control Output in Manual Operation
- Troubleshooting

**NOTE**  
 Do not use the instrument generating strong magnetic field such as radio equipment and the like near the controller. This may cause the fluctuation of the PV value.

**1. Setting Target Setpoint (SP)**

The following operating procedure describes an example of setting 120.0 to a target setpoint. In automatic operation, the controller starts control using set target setpoints.


**NOTE**  
 When the target setpoint is set through communication, the target setpoint cannot be changed by keystroke.



**2. Performing/Canceling Auto-tuning**



Auto-tuning should be carried out after setting a target setpoint (SP). Make sure the controller is in automatic operation mode (AUTO) and in running state (RUN) before carrying out auto-tuning. See "7. Switching between AUTO and MAN," to change to AUTO and "6. Switching between RUN and STOP," to change to RUN.

**NOTE**  
 When on-off control is being used, auto-tuning cannot be carried out. Moreover, do not perform auto-tuning when controlling any of following processes:  
 • Control processes with quick response such as flow control or pressure control  
 • Processes where even temporary output on/off results in inconvenience  
 • Processes where a large output change at control element results in inconvenience  
 • Processes where variations in PV may exceed an allowable range, adversely affecting product quality




**3. Setting PID Manually**

If you know the values to be set or if suitable PID constants cannot be obtained by auto-tuning, follow the procedure below to set values.



**4. Setting Alarm Setpoints**


The following operating procedure describes an example of setting 160.0 to alarm-1 setpoint. Check alarm type before setting the alarm setpoint. To change the type of alarm, see "5. Changing Alarm Type" in **Initial Setting User's Manual**.



**5. Selecting Target Setpoint Numbers (SP.NO)**

The following operating procedure describes an example of changing a target setpoint number (SP.NO) from 1 to 2.


**NOTE**  
 If a target setpoint number has been switched using contact input, when the contact input is on, that number cannot be selected by keystroke. When using target setpoint ramp setting function, PV tracking works if the target setpoint number is switched.



**6. Switching between Run and Stop**


Switching between the RUN and STOP states can be performed only using external contact input.

**NOTE**  
 When the controller is shipped from the factory, it is configured so that switching between the RUN and STOP states cannot be performed. To make the switching possible, configure the DIS setup parameter as "DIS = 4".




**7. Switching between AUTO and MAN**

**NOTE**  
 If AUTO and MAN have been switched using contact input, when the contact input is ON, switching between AUTO and MAN cannot be achieved by keystroke.




**8. Manipulating the Control Output in Manual Operation**


**NOTE**  
 Control output cannot be changed if the controller is stopped. In this case, the preset output value (setup parameter PO) will be output.



**Manipulating the Control Output during Heating/Cooling Control**




**Controller behavior and control output manipulation when the dead band is positive**  
 The following is an example when the DB parameter is set at 12.4%. If you hold down the [M] key with the heating-side output under manipulation (i.e., cooling-side output C = 0.0%), the heating-side output (H) decreases. Consequently, both the heating-side and cooling-side outputs change to 0.0%. If you keep the [M] key held down longer, you enter the state of manipulating the cooling-side output, and its value begins to increase. Inversely, if you hold down the [M] key with the cooling-side output under manipulation (i.e., heating-side output H = 0.0%), the cooling-side output (C) decreases. Consequently, both the heating-side and cooling-side outputs go to 0.0%. If you keep the [M] key held down longer, you enter the state of manipulating the heating-side output, and its value begins to increase.



**9. Troubleshooting**

**Troubleshooting Flow**

If the operating display does not appear after turning on the controller's power, follow the measures in the procedure below. If a problem appears complicated, contact our sales representative.



**IMPORTANT**

Take note of the parameter settings when asking the vendor for repair.

**Errors at Power On**

The following table shows errors that may be detected by the fault diagnosis function when the power is turned on.

Error indication (on PV display unit)	Description of error	PV	Control output	Alarm output	Retransmission output	Communication	Remedy
E000 (E000)	Faulty RAM	None	0% or less or OFF	OFF	0% or less	Stopped	Faulty Contact us for repair.
E001 (E001)	Faulty ROM	None	0% or less or OFF	OFF	0% or less	Stopped	
E002 (E002)	System data error	0%	Normal action (out of accuracy)				
PV decimal point blinks.	Faulty calibration value	Normal action (out of accuracy)	Normal action	Check and set the parameters, as they have been set to the limited values.			
E400 (E400)	Parameter error	0%	Preset value output	OFF	0%	0%	

**Possible Errors during Operation**

The following shows possible errors occurring during operations.

Error indication (on PV display unit)	Description of error	PV	Control output	Alarm output	Retransmission output	Communication	Remedy
Displays "RJC" and PV alternately	RJC error	Measured with RJC=OFF	Normal action	Normal action	Normal action	Normal action	Faulty Contact us for repair.
PV value blinks.	EEPROM error	Normal action	Normal action	Normal action	Normal action	Normal action	Faulty Contact us for repair.
E300 (E300)	A/DC error	105%	Preset value output	Normal action	Normal action	Normal action	Normal action
boUt (B.OUT)	PV burnout error	Dependent on the BSL parameter Up-scale: 105% Down-scale: -5%	Preset value output	Normal action	Normal action	Normal action	Check wires and sensor.
oBr (OVER) or -oBr (-OVER)	Excessive PV Out of -5 to 105%	-5% or 105%	Normal action	Normal action	Normal action	Normal action	Check process.
E200 (E200)	Auto-tuning failure (Time-out)	Normal action	Normal action	Normal action	Normal action	Normal action	Check process. Press any key to erase error indication.
SP decimal point blinks. (on setpoint display unit)	Faulty communication line	Normal action	Normal action	Normal action	Normal action	Normal action	Check wires and communication parameters, and make resetting. Recovery at normal receipt
All indications off	Runaway (due to defective power or noise)	None	0% or less or OFF	OFF	0% or less	Stopped	Faulty if power off/on does not reset start the unit. Contact us for repair.
All indications off	Power off	None	0%	OFF	0%	Stopped	Check for abnormal power.

**If a Power Failure Occurs during Operation**

**Momentary power failures shorter than 20 ms**  
 The controller is not affected at all and continues normal operation.

**Power failures of 20 ms or longer**  
 • The alarm function of the controller continues to work normally. (Alarms with the stand-by feature temporarily return to their stand-by state, however.)  
 • Setting parameters that have already been configured retain their settings.  
 • Auto-tuning is cancelled.  
 • After recovery from a power failure, control action resumes in the same mode as the one before the occurrence of the power failure. The control output begins with the preset output value.

**Troubleshooting When the Controller Fails to Operate Correctly**

If your control tasks are not successful, check the preset parameters and controller wiring before concluding the controller to be defective. The following show some examples of troubleshooting you should refer to in order to avoid the possibility of other problems.

**The controller does not show the correct measured input (PV).**  
 • The UT350/UT320 controllers have a universal input.  
 The type of PV input can be set/changed using the parameter "IN". At this point, the controller must be wired correctly according to the selected type of PV input. Check the wiring first if the controller fails to show the correct PV. To do this, refer to **Initial Settings User's Manual**.  
 With the parameters "RH", "RL", "SDP", "SH" and "SL", it is possible to scale the input signal and change its number of decimal places. Also check that these parameters are configured correctly.

**The controller does not provide any control output or the control output does not change at all.**  
 • The UT350/UT320 controllers have a universal output.  
 The type of control output can be set/changed using the parameter "OT". At this point, the controller must be wired correctly according to the selected type of control output. Check the wiring first if the controller provides no control output. To do this, refer to "6. Terminal Wiring Diagrams," in **Installation User's Manual**.  
 With the parameters "OH" and "OL", it is possible to set/change the high and low limits of control output. The control output may not change at all, however, because of restrictions on these parameters. Also check the restrictions on these parameters.  
 • The control output can only be changed when the controller is in the MAN mode.  
 If the MAN lamp is off (i.e., the controller is in the AUTO mode), you cannot change the control output using key operation.

**The control output does not change soon after the target setpoint SP has been changed.**  
 • If this happens, check the setpoint of the parameter "C.MD". In cases where fixed-point control is selected as the PID control mode (C.MD = 1), tracking based on the I-term works to prevent the control output from changing suddenly even if the target setpoint SP is varied.  
 The control output therefore may appear to be working incorrectly at first; however it gradually adapts itself to the new target setpoint.




This manual contains a parameter map as a guideline for setting parameters, and lists of parameters for recording User Settings.

**Contents**

1. Basic Key Operation Sequence and Parameter Map
2. Lists of Parameters

**1. Basic Key Operation Sequence and Parameter Map**

- Basic Key Operation Sequence**
- Setting display can be switched (moved) using the **Menu** key.
  - A numerical value is changed by:
    - Using the **Up** or **Down** key to change a displayed value (decimal point blinking) and
    - Pressing the **Enter** key to register it.
  - Pressing the **Menu** key on an operating display (for more than 3 seconds) brings you to the operating parameter setting display.
  - Pressing the **Menu** key on the operating parameter setting display (for more than 3 seconds) returns you to the operating display.
  - Pressing the **Menu** key on the setup parameter setting display (for more than 3 seconds) returns you to the operating parameter setting display. You cannot return to the operating parameter setting display from the setup parameter setting display.



**NOTE**

Changing the registered value of a setup parameter may cause the registered value of an operating parameter to be initialized automatically. Thus, when you have changed a setup parameter, always check that the registered value of the operating parameter is appropriate. If it is initialized to default, reset it to the required value.

**Operating Parameter Setting Display**

oPPA	Menu	oPPA	Menu
LL	LL communication interface selection	IP	Proportional band / heating-side proportional band
A1	Alarm-1 setpoint	2P	Integral time / heating-side integral time
A2	Alarm-2 setpoint	3P	Derivative time / heating-side derivative time
A3	Alarm-3 setpoint	4P	Manual reset
AL	Auto-tuning	2nr	Cooling-side proportional band
SC	SUPER function	3nr	Cooling-side integral time
SPno	Target setpoint number selection	4nr	Cooling-side derivative time
PI d	PID parameter display number	2dc	Dead band
FL	PV input filter	3db	Zone PID reference point-1
b5	PV input bias	4db	
UPr	Setpoint ramp-up rate	rP	
dnr	Setpoint ramp-down rate		
oH	Output high limit/heating-side output high limit		
oL	Output low limit/cooling-side output high limit		
H	ON/OFF control hysteresis/heating-side/cooling-side ON/OFF control hysteresis		
dr	Direct/reverse action switching		
Hb1	Heater burnout current setpoint 1		
Hb2	Heater burnout current setpoint 2		
Hc1	Heater burnout current measurement 1		
Hc2	Heater burnout current measurement 2		
orb	ON/OFF rate detection band		
orH	ON/OFF rate high limit		
orL	ON/OFF rate low limit		
or	ON/OFF rate		
ISP	Target setpoint-1		
2SP	Target setpoint-2		
3SP	Target setpoint-3		
4SP	Target setpoint-4		

The setpoints of the ORB, ORH and ORL parameters are only effective when a sensor grounding alarm is used. The OR parameter represents the moving average (for 5 cycle times) of the control output and is not a setpoint.


**Setup Parameter Setting Display**

SPH	Target setpoint limiter upper limit	Func	Control function related
SPL	Target setpoint limiter lower limit	IO	Input/output related
AL1	Alarm-1 type	lin	PV input type (PV INPUT terminals)
AL2	Alarm-2 type	Unit	PV input unit
AL3	Alarm-3 type	rH	Maximum value of PV input range
HY1	Alarm-1 hysteresis	rL	Minimum value of PV input range
HY2	Alarm-2 hysteresis	SdP	PV input decimal point position (displayed at voltage input)
HY3	Alarm-3 hysteresis	SH	Maximum value of PV input scale (displayed at voltage input)
dY1	Alarm-1 delay timer	SL	Minimum value of PV input scale (displayed at voltage input)
dY2	Alarm-2 delay timer	rJc	Presence/absence of PV input reference junction compensation
dY3	Alarm-3 delay timer	b5L	Selection of PV input burnout action
Ct	Control output cycle time / heating-side control output cycle time	oE	Control output type
Ctc	Cooling-side control output cycle time	rEt	Retransmission output type
Po	Preset output / heating-side preset output	rEtH	Maximum value of retransmission output scale
Poc	Cooling-side preset output	rEtL	Minimum value of retransmission output scale
Cnd	PID control mode	dI5	DI function selection
Zon	Zone PID selection	CS1	SELECT display-1 registration
Rr	Anti-reset windup	CS2	SELECT display-2 registration
tNU	Ramp-rate time unit	CS3	SELECT display-3 registration
PSL	Protocol selection	CS4	SELECT display-4 registration
bPS	Baud rate	LoCK	Key lock
PrI	Parity	Pd	Password setting
StP	Stop bit		
dLn	Data length		
Rdr	Address		
rPt	Minimum response time		
EESt			

**List of Alarm Types**

The table below shows the alarm types and alarm actions. In the table, codes 1 to 10 are not provided with stand-by actions, while codes 11 to 20 are provided with stand-by actions.

Alarm type	Alarm action	Alarm type code	Alarm type	Alarm action	Alarm type code
No alarm		OFF			
PV high limit	Hysteresis Open (unlit) / Closed (lit)	1 11	De-energized on deviation low limit alarm	Hysteresis Open (lit) / Closed (unlit)	6 16
PV low limit	Hysteresis Closed (lit) / Open (unlit)	2 12	Deviation high and low limits	Hysteresis Closed (lit) / Open (unlit)	7 17
Deviation high limit	Hysteresis Open (unlit) / Closed (lit)	3 13	Deviation within high and low limits	Hysteresis Open (unlit) / Closed (lit)	8 18
Deviation low limit	Hysteresis Closed (lit) / Open (unlit)	4 14	De-energized on PV high limit	Hysteresis Closed (lit) / Open (unlit)	9 19
De-energized on deviation high limit alarm	Hysteresis Closed (unlit) / Open (lit)	5 15	De-energized on PV low limit	Hysteresis Open (lit) / Closed (unlit)	10 20
Fault diagnosis output (Note 1)	Fault diagnosis output	21	Heater burnout alarm 1		24
FAIL output (Note 2)	The controller stops when in a FAIL state. The control output is set to "OFF" or "0%" and alarm output is set to "OFF".	22	Heater burnout alarm 2		25
Sensor grounding alarm	Sensor grounding alarm	23			
SP high limit	Hysteresis Open (unlit) / Closed (lit)	28	Output high limit	Hysteresis Open (unlit) / Closed (lit)	30
SP low limit	Hysteresis Closed (lit) / Open (unlit)	29	Output low limit	Hysteresis Closed (lit) / Open (unlit)	31



**Instrument Input Range Codes**

Input	Type	Instrument Input Range Code	Instrument Input Range		
Unspecified	OFF	1	Set the data item PV Input type "IN" to the OFF option to leave the PV input type undefined.		
		2	-199.9 to 999.9°C		
		3	-199.9 to 500.0°C		
		4	-199.9 to 999.9°C		
		5	-199.9 to 400.0°C		
		6	0.0 to 400.0°C		
		7	0 to 1800°C		
		8	0 to 1700°C		
		9	0 to 1700°C		
		10	-200 to 1300°C		
Thermocouple	K	11	-199.9 to 999.9°C		
		12	-199.9 to 900.0°C		
		13	-199.9 to 400.0°C		
		14	0.0 to 400.0°C		
		15	0 to 2300°C		
		16	0 to 1390°C		
		17	0 to 1900°C		
		RTD	Pt100	30	-199.9 to 500.0°C
				31	-150.0 to 150.0°C
				35	-199.9 to 640.0°C
36	-199.9 to 500.0°C				
Standard signal	0.4 to 2 V	40	0.400 to 2.000V		
		41	1.000 to 5.000V		
		50	0.000 to 2.000V		
		51	0.00 to 10.00V		
DC voltage	0 to 20 mV	55	-10.00 to 20.00mV		
		56	0.0 to 100.0mV		

## 2. Lists of Parameters

\* Parameters relating to PV or setpoints should all be set in real numbers. For example, use temperature values to define target setpoints and alarm setpoints for temperature input.

### Operating Parameters

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
LL (LL)	LL communication interface selection	OFF: Communication is carried out via the RS485 communication terminals. ON: Communication is carried out via the light-leader adapter.	with communication : OFF without communication : ON	—	—
AL1 (A1)	Alarm 1-setpoint	PV alarm / SP alarm: -100.0 to 100.0% of PV input range Deviation alarm: -100.0 to 100.0% of PV input range span Output alarm: -5.0 to 105.0% An alarm common to the 1.SP to 4.SP parameters.	PV high limit/SP high limit alarm: 100.0% of PV input range Deviation alarm: 0.0% of PV input range span Other PV/SP low limit alarm: 0.0% of PV input range Output high limit alarm: 100.0% Output low limit alarm: 0.0%	—	—
AL2 (A2)	Alarm 2-setpoint			—	—
AL3 (A3)	Alarm 3-setpoint			—	—
At (AT)	Auto-tuning	OFF: No auto-tuning 1: Auto-tuning for 1.SP 2: Auto-tuning for 2.SP 3: Auto-tuning for 3.SP 4: Auto-tuning for 4.SP AUTO: Performs auto-tuning to all groups 1 to 4.	OFF	—	—
SC (SC)	"Super" function	OFF: Disable 1: Overheat suppressing function Suppresses overshoots generated by abrupt changes in the target setpoint or by disturbances. 2: Hunting suppressing function (Stable mode) Stabilizes the state of control when the load varies greatly, or the target setpoint is changed. Enables to answer the wider characteristic changes compared with Response mode. 3: Hunting suppressing function (Response mode) Enables quick follow-up and short converging time of PV for the changed target setpoint. Note: Use "SUPER" function (SC) 2 or 3 in PID control or PI control. "SUPER" function 2 or 3 is not available in the following control: 1) ON/OFF control 2) P control (control for proportional band only) 3) PD control (control for proportional band and derivative item only) 4) Heating/cooling control Do not use hunting suppressing function when control processes with response such as flow or pressure control. 0: Uses target setpoint via communication 1: Selects target setpoint 1 (1.SP). 2: Selects target setpoint 2 (2.SP). 3: Selects target setpoint 3 (3.SP). 4: Selects target setpoint 4 (4.SP).	OFF	—	Ref.2.1(5) Ref.2.1(6)
SPno (SPNO)	Target setpoint number selection	0: Uses target setpoint via communication 1: Selects target setpoint 1 (1.SP). 2: Selects target setpoint 2 (2.SP). 3: Selects target setpoint 3 (3.SP). 4: Selects target setpoint 4 (4.SP).	1	—	Ref.4.1(1)
PI d (PID)	PID parameter display number	MENU: Move to FL parameter display 1Gr to 4Gr: Display of each PID parameter	MENU	—	—
FL (FL)	PV input filter	OFF, 1 to 120 second. Used when the PV input fluctuates.	OFF	—	Ref.1.1(1)
bS (BS)	PV input bias	-100.0% to 100.0% of PV input range span Used to correct the PV input range.	0.0% of PV input range span	—	Ref.1.1(1)
UPr (UPR)	Setpoint ramp-up-rate	OFF 0.0% + 1 digit of PV input range span to 100.0% of PV input range span Set ramp-up-rate or ramp-down-rate per hour or minute.	OFF	—	Ref.4.1(4)
dNr (DNR)	Setpoint ramp-down-rate	OFF Sets unit in ramp-rate-time unit (TMU).	OFF	—	Ref.4.1(4)
OH (OH)	Output high limit Heating-side output high limit (in heating/cooling control)	-5.0 to 105.0% Heating-side limiter in heating/cooling control: 0.0 to 105.0% (OL < OH)	100% Heating/cooling control: 100.0%	—	Ref.2.1(3)
OL (OL)	Output low limit Cooling-side output high limit (in heating/cooling control)	-5.0 to 105.0% Cooling-side limiter in heating/cooling control: 0.0 to 105.0% (OL < OH)	0.0% Heating/cooling control: 100.0%	—	Ref.2.1(3)
H (H)	ON/OFF control hysteresis Heating-side/cooling-side ON/OFF control hysteresis (in heating/cooling control)	In ON/OFF control: 0.0 to 100.0% of PV input range span In heating/cooling control: 0.0 to 10.0%	ON/OFF control: 0.5% of PV input range span Heating/cooling control: 0.5%	—	—
dr (DR)	Direct/reverse action switching	0: reverse action, 1: direct action Control output 100% Reverse Direct 0% Deviation (PV-SP)	0	—	Ref.2.1(1)
Hb1 (HB1)	Heater burnout current setpoint 1	OFF, or 1 to 50 A	OFF	—	Ref.3.3(5)
Hb2 (HB2)	Heater burnout current setpoint 2	OFF, or 1 to 50 A	OFF	—	Ref.3.3(5)
HC1 (HC1)	Heater burnout current measurement 1	These are not setpoints.	The current value of the heater burnout detector is shown on the display of the HC1 or HC2 parameter.	—	Ref.3.3(5)
HC2 (HC2)	Heater burnout current measurement 2	These are not setpoints.	The current value of the heater burnout detector is shown on the display of the HC1 or HC2 parameter.	—	Ref.3.3(5)
ORb (ORB)	ON/OFF rate detection band	0.0 to 100.0% of PV input range span	1.0% of PV input range span	—	Ref.3.3(4)
ORH (ORH)	ON/OFF rate high limit	ORL + 1 digit to 105.0%	100.0%	—	Ref.3.3(4)
ORL (ORL)	ON/OFF rate low limit	-5.0% to ORH - 1 digit	0.0%	—	Ref.3.3(4)
OR (OR)	ON/OFF rate	This is not a setpoint.	The moving average (for 5 cycle times) of the control output is shown.	—	Ref.3.3(4)
1SP (1.SP)	Target setpoint-1	0.0 to 100.0% of PV input range However, between target setpoint limiter lower limit (SPL) and upper limit (SPH).	0.0% of PV input range	—	Ref.4.1(1)
2SP (2.SP)	Target setpoint-2			—	Ref.4.1(1)
3SP (3.SP)	Target setpoint-3			—	Ref.4.1(1)
4SP (4.SP)	Target setpoint-4			—	Ref.4.1(1)

### PID-related Parameters

The following parameters are displayed when "1Gr" is set to PID parameter display number (PID). In this case, the corresponding target setpoint is 1.SP (target setpoint-1).  
To set PID corresponding to target setpoint 2 to 4, set "2Gr", "3Gr", or "4Gr" to PID. The relevant parameters will then be displayed.

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
IP (1.P)	Proportional band/Heating-side proportional band (in heating/cooling control)	0.1 to 999.9% In heating/cooling control: 0.0 to 999.9% (heating-side ON/OFF control applies when 0.0)	5.0%	—	—
I (1.I)	Integral time Heating-side integral time (in heating/cooling control)	OFF, 1 to 6000 second	240 second	—	—
Id (1.D)	Derivative time Heating-side derivative time (in heating/cooling control)	OFF, 1 to 6000 second	60 second	—	—
Inr (1.MR)	Manual reset (enabled when integral time "1.I" is OFF) The manual reset value equals the output value when PV = SP is true. For example, if the manual reset value is 50%, the output value is 50% when PV = SP becomes true.	-5.0 to 105.0% (enabled when integral time "1.I" is OFF) The manual reset value equals the output value when PV = SP is true. For example, if the manual reset value is 50%, the output value is 50% when PV = SP becomes true.	50.0%	—	Ref.4.1(1)
IPc (1.Pc)	Cooling-side proportional band	0.0 to 999.9% (Cooling-side ON/OFF control applies when 0.0)	5.0%	—	—
Ic (1.Ic)	Cooling-side integral time	OFF, 1 to 6000 second	240 second	—	—

\* The "User Setting" column in the table below is provided for the customer to record setpoints.

\* The "Target Item in CD-ROM" column in the table below provides references from User's Manual (Reference) (CD-ROM Version) which describes items in more detail and items that are not contained in this manual.

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
Idc (1.Dc)	Cooling-side derivative time	OFF, 1 to 6000 second	60 second	—	—
Idb (1.Db)	Deadband	-100.0 to 50.0% In heating/cooling control, a region where both of the heating- and cooling-side outputs are presented, or none of them is presented, can be set.	3.0%	—	Ref.4.1(1)
lrP (1.RP)	Zone PID reference point-1	0.0 to 100.0% of PV input range. Note that 1.RP ≥ 2.RP.	100% value of PV input range	—	—


Refer to the table below for recording setpoints when two sets or more of PID parameters are used.

Parameter	n=2	n=3	n=4
n.P			
n.I			
n.D			
n.MR			
n.Pc			
n.Ic			
n.Dc			
n.DB			
n.RP	None	None	None

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
rDb (RDV)	Reference deviation	OFF, 0.0 to 100.0% of PV input range span Used to select PID constants according to a deviation from the setpoint. The 4th group of PID constants is used when the controller fails to keep track of the deviation.	OFF	—	Ref.4.1(1)

### Auto-tuning

Auto-tuning is a function which the controller automatically measures the process characteristics to automatically set the optimum PID constants. This function does not work when the controller is performing on-off control. The UT350/UT320 employ the "Limit Cycle Method." As shown in the figure on the right, the controller temporarily changes its control output in a step-waveform manner. Then, it calculates the optimum proportional band (P), integral time (I) and derivative time (D) from the resulting response to set them in their respective parameters. If the Output High Limit (OH) and Output Low Limit (OL) parameters are already configured, the control output turns on and off only between the output's high and low limits during auto-tuning.



### Auto-tuning Using Zone PID (see "PID Switching (Zone PID)" later in this manual)


Setting of AT Parameter	Auto-tuned Setpoint	Remarks
OFF	-	Auto-tuning is turned off (disabled).
1	Median value of each zone width	Determines the values of 1.P, 1.I and 1.D parameters by auto-tuning.
2	Median value of each zone width	Determines the values of 2.P, 2.I and 2.D parameters by auto-tuning.
3	Median value of each zone width	Determines the values of 3.P, 3.I and 3.D parameters by auto-tuning.
4	Median value of each zone width	Determines the values of 4.P, 4.I and 4.D parameters by auto-tuning.
AUTO	Median value of each zone width	Determines the values of all PID parameters in use by auto-tuning.

The AT parameter settings numbered 1 to 4 in the table above are dependent on how many zones have been set. For example, if you have set two zones, you can use AT parameter settings 1 and 2. Likewise, if you have set three zones, you can use AT parameter settings 1, 2 and 3.

### Hysteresis (for Target Setpoints (On-Off Control) and Alarm Setpoints)

Hysteresis can be set in on-off control setpoints and alarm setpoints as well. With the hysteresis settings, it is possible to prevent relays from chattering.


- When hysteresis is set in a target setpoint
- When hysteresis is set in an alarm setpoint



### Target Setpoint Ramp Setting Function

Use this function to prevent the target setpoint from changing suddenly. The ramp setting function works when:

- the target setpoint is changed (example: change in "1.SP" from 100°C to 150°C);
- the target setpoint number is switched (example: switch from "1.SP" to "3.SP");
- the power is turned on or the controller is recovered from power failure;
- a change is made from manual operation to automatic operation; or
- a change is made from the STOP state to the RUN state.




### PID Switching (Zone PID)

Using a zone PID, you can automatically switch between groups of PID constants according to the temperature zone. You can set a maximum of three temperature zones.

Setting Method:

- Set the Zone PID Selection (ZON) parameter to "ON".
- Define a reference point.  
When using two zones, define only reference point 1 (1.RP) between the minimum and maximum values of the PV input range.  
When using three zones, define reference points 1 and 2 (1.RP and 2.RP) in the same way as noted above.



Note: Set the maximum and minimum values, as close as possible to those of the actual range to be controlled, in the Maximum Value of PV Input Range (RH) and Minimum Value of PV Input Range (RL) parameters. Otherwise, the controller may fail to determine the optimum values when auto-tuning is carried out.

## Setup Parameters

### Control Function-related Parameters

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
SPH (SPH)	Target setpoint limiter upper limit	0.0 to 100.0% of PV input range where, SPL < SPH Places a limit on the range within which the target setpoint is changed.	100.0% of PV input range	—	—
SPL (SPL)	Target setpoint limiter lower limit	0.0 to 100.0% of PV input range	0.0% of PV input range	—	—
AL1 (AL1)	Alarm-1 type	OFF, 1 to 25, 28 to 31 1: PV high limit (energized, no stand-by action) 2: PV low limit (energized, no stand-by action) 3: Deviation high limit (energized, no stand-by action) 4: Deviation low limit (energized, no stand-by action) 5: Deviation high limit (de-energized, no stand-by action) 6: Deviation low limit (de-energized, no stand-by action)	1	—	Ref.3.3(4)
AL2 (AL2)	Alarm-2 type		2	—	Ref.3.3(4)
AL3 (AL3)	Alarm-3 type		1	—	Ref.3.3(4)
HY1 (HY1)	Alarm-1 hysteresis	0.0 to 100.0% of PV input range span Output alarm: 0.0 to 100.0% Hysteresis for PV high limit alarm (Alarm setpoint)	0.5% of PV input range span Output alarm: 0.5%	—	Ref.3.3(2)
HY2 (HY2)	Alarm-2 hysteresis		0.5%	—	Ref.3.3(2)
HY3 (HY3)	Alarm-3 hysteresis		0.5%	—	Ref.3.3(2)
dY1 (DY1)	Alarm-1 delay timer	An alarm is output when the delay timer expires after the alarm setpoint is reached. 0.00 to 99.59 (min, sec.) (enabled when alarm-1 type "AL1" is 1 to 20 or 28 to 31)	0.00	—	—
dY2 (DY2)	Alarm-2 delay timer	0.00 to 99.59 (min, sec.) (enabled when alarm-2 type "AL2" is 1 to 20 or 28 to 31)	0.00	—	—
dY3 (DY3)	Alarm-3 delay timer	0.00 to 99.59 (min, sec.) (enabled when alarm-3 type "AL3" is 1 to 20 or 28 to 31)	0.00	—	—
Ct (CT)	Heating-side output cycle time (in heating/cooling control)	1 to 1000 second	30 second	—	Ref.3.3(4)
CtC (CTC)	Cooling-side output cycle time	1 to 1000 second	30 second	—	—
PO (PO)	Preset output/Heating-side preset output (in heating/cooling control)	-5.0 to 105.0% In heating/cooling control: Heating side 0.0 to 105.0%. In Stop mode, fixed control output can be generated.	0.0%	—	Ref.2.1(8)
Poc (Poc)	Cooling-side preset output	0.0 to 105.0% In Stop mode, cooling-side fixed control output can be generated.	0.0%	—	Ref.2.1(8)
Cnd (C.MD)	PID control mode	0: Standard PID control (with output bump at SP change) 1: Fixed point control (without output bump at SP change) Choose "fixed point control" when controlling pressure or flow rate.	0	—	Ref.2.1(2)
ZON (ZON)	Zone PID selection	OFF: SP selection ON: Zone PID	ON	—	Ref.4.1(2)
AR (AR)	Anti-reset windup (Excess integration prevention)	AUTO (0), 50.0 to 200.0% Used when the control output travels up to 100% or down to 0% and stays at this point. The larger SP, the sooner PID computation (integral computation) stops.	AUTO	—	Ref.2.1(4)
TMU (TMU)	Ramp-rate time unit setting	0: hour, 1: minute Time unit of setpoint ramp-up (UPR) and setpoint ramp-down (DNR)	0	—	Ref.4.1(4)
P.SL (P.SL)	Protocol selection	0: PC link communication 1: PC link communication (with sum check) 2: Ladder communication 3: Coordinated master station 4: Coordinated slave station 7: MODBUS (ASCII) 8: MODBUS (RTU) 10: Coordinated slave station (loop-1 mode) 11: Coordinated slave station (loop-2 mode)	0	—	Ref.4.1(4)
bPS (BPS)	Baud rate	0: 600, 1: 1200, 2: 2400, 3: 4800, 4: 9600 (bps)	4	—	Ref.4.1(4)
Pri (PRI)	Parity	0: None 1: Even 2: Odd	1	—	Ref.4.1(4)
StP (STP)	Stop bit	1, 2	1	—	Ref.4.1(4)
dLn (DLn)	Data length	7, 8: Fixed at 7, when the P.SL parameter is set to MODBUS (ASCII) or Ladder Communication. Fixed at 8, when the P.SL parameter is set to MODBUS (RTU) or Ladder Communication.	8	—	Ref.4.1(4)
Adr (ADR)	Address	1 to 99 However, the maximum number of stations connectable is 31.	1	—	Ref.4.1(4)
rPt (RP-T)	Minimum response time	0 to 10 (× 10 ms)	0	—	Ref.4.1(4)
tEst (TEST)	If this parameter symbol appears, press the SET/ENT key to return to the FUNC menu. Caution: Do not change the setpoint of the TEST parameter, otherwise the controller will be disabled.			—	Ref.4.1(4)

### Input-/Output-related Parameters

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
In (IN)	PV input type (PV INPUT terminals) (① - ② - ③ terminals)	OFF, 1 to 18, 30, 31, 35 to 37, 40, 41, 50, 51, 55, 56 See Instrument Input Range Codes in <b>Initial Settings</b> / <b>User's Manual</b>	OFF	—	—
Unit (UNIT)	PV input unit	'C': degree Celsius 'F': Fahrenheit (This parameter is not shown for voltage input.)	'C'	—	—
RH (RH)	Max. value of PV input range	Set the PV input range, however RL < RH -Temperature input Set the range of temperature that is actually controlled.	Max. value of instrument input range	—	—
RL (RL)	Min. value of PV input range	-Voltage input Set the range of a voltage signal that is applied. The scale across which the voltage signal is actually controlled should be set using the parameters Maximum Value of PV Input Scale (SH) and Minimum Value of PV Input Scale (SL).	Min. value of instrument input range	—	—
SDP (SDP)	PV input decimal point position (displayed at voltage input)	0 to 3 Set the position of the decimal point of voltage-mode PV input. 0: No decimal place 1: One decimal place 2, 3: Two, three decimal places	1	—	—
SH (SH)	Max. value of PV input scale (displayed at voltage input)	-1999 to 9999, however SL < SH Set the read-out scale of voltage-mode PV input.	100.0	—	—
SL (SL)	Min. value of PV input scale (displayed at voltage input)		0.0	—	—
rJc (RJc)	Presence/absence of PV input reference junction compensation	OFF, ON	ON	—	—
bSL (BSL)	Selection of PV input burnout action	OFF 1: Up scale 2: Down scale	OFF	—	—
ot (OT)	Control output type	0: Time proportional PID relay contact output (terminals ①-②-③) 1: Time proportional PID voltage pulse output (terminals ④-⑤) 2: Current output (terminals ⑥-⑦) 3: ON/OFF relay contact output (terminals ①-②-③)	0	—	—

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
RET (RET)	Retransmission output type	OFF: Does not work. 1: PV, 2: SP, 3: OUT, 4: Loop power supply for sensor (15 V) In position proportional control, a valve opening signal (0 to 100%) is transmitted if setpoint "3" is selected. In heating/cooling control, an output value before allocation to heating and cooling control (0 to 100%) is transmitted if setpoint "3" is selected (0 to 50% Cooling-side output, 50 to 100% Heating-side output).	1	—	Ref.2.2(1)
rEtH (RTH)	Max. value of retransmission output scale	RET=1, 2: RTL + 1 digit to 100.0% of PV input range RET=3: RTL + 1 digit to 100.0%	100.0% of PV input range	—	Ref.2.2(1)
rEtL (RTL)	Min. value of retransmission output scale	RET=1, 2: 0.0% of PV input range to RTH - 1 digit RET=3: 0.0% to RTH - 1 digit	0.0% of PV input range	—	Ref.2.2(1)
DIS (DIS)	DI function selection	OFF: Disables the external control input. 1: DI1: 2.SP (on)/1.SP (off), DI2: AUTO (on)/MAN (off) 2: DI1: Hides (on)/shows (off) the LOCK setup parameter. DI2: Unused. 3: See the table below. 4: DI1: 2.SP (on)/1.SP (off), DI2: STOP (on)/RUN (off)	1	—	Ref.3.1(1)

○ SP Selection when DIS = 3 is set

	DI1	DI2
1.SP	OFF	OFF
2.SP	ON	OFF
3.SP	OFF	ON
4.SP	ON	ON

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
C.S1 (C.S1)	SELECT display-1 registration	OFF, 201 to 1015 Select the desired parameter from among the operating and setup parameters, then register the number (D register No.) accompanying that parameter. For example, registering "231" for C.S1 allows you to change alarm-1 setpoint in operating display.	OFF	—	Ref.6.1(1)
C.S2 (C.S2)	SELECT display-2 registration		—	—	Ref.6.1(1)
C.S3 (C.S3)	SELECT display-3				