

LDAT-Series Integrated Linear Thrusters

Catalog Numbers

LDAT Frame 30	LDAT Frame 50	LDAT Frame 75	LDAT Frame 100	LDAT Frame 150
LDAT-S03xxxx-DB	LDAT-S05xxxx-DB	LDAT-S07xxxx-DB	LDAT-S10xxxx-DB	LDAT-S15xxxx-DB
LDAT-S03xxxx-DBS	LDAT-S05xxxx-DBS	LDAT-S07xxxx-DBS	LDAT-S10xxxx-DBS	LDAT-S15xxxx-DBS
LDAT-S03xxxx-EB	LDAT-S05xxxx-EB	LDAT-S07xxxx-EB	LDAT-S10xxxx-EB	LDAT-S15xxxx-EB
LDAT-S03xxxx-EBS	LDAT-S05xxxx-EBS	LDAT-S07xxxx-EBS	LDAT-S10xxxx-EBS	LDAT-S15xxxx-EBS
LDAT-S03xxxx-DD	LDAT-S05xxxx-DD	LDAT-S07xxxx-DD	LDAT-S10xxxx-DD	LDAT-S15xxxx-DD
LDAT-S03xxxx-DDS	LDAT-S05xxxx-DDS	LDAT-S07xxxx-DDS	LDAT-S10xxxx-DDS	LDAT-S15xxxx-DDS
LDAT-S03xxxx-ED	LDAT-S05xxxx-ED	LDAT-S07xxxx-ED	LDAT-S10xxxx-ED	LDAT-S15xxxx-ED
LDAT-S03xxxx-EDS	LDAT-S05xxxx-EDS	LDAT-S07xxxx-EDS	LDAT-S10xxxx-EDS	LDAT-S15xxxx-EDS

Topic	Page
Important User Information	2
Safety Considerations	3
Catalog Number Explanation	7
About the LDAT-Series Integrated Linear Thruster	8
Before You Begin	9
Install the Linear Thruster	12
Dimensions	20
Connector Data	32
Commissioning	33
Maintenance	52
Troubleshooting	55
Accessories	57
Replacement Parts	59
Install Replacement Parts	60
Interconnect Diagrams	71
Specifications	75
Additional Resources	78

Important User Information

Solid state equipment has operational characteristics differing from those of electromechanical equipment. Safety Guidelines for the Application, Installation and Maintenance of Solid State Controls, publication [SGL-1.1](#), available from your local Rockwell Automation® sales office or online at <http://www.rockwellautomation.com/literature> describes some important differences between solid state equipment and hard-wired electromechanical devices. Because of this difference, and also because of the wide variety of uses for solid state equipment, all persons responsible for applying this equipment must satisfy themselves that each intended application of this equipment is acceptable.





In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc., is prohibited.

Throughout this manual, when necessary, we use notes to make you aware of safety considerations.

	WARNING: Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.
	ATTENTION: Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you identify a hazard, avoid a hazard and recognize the consequences.
	SHOCK HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that dangerous voltage may be present.
	BURN HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that surfaces may reach dangerous temperatures.
IMPORTANT	Identifies information that is critical for successful application and understanding of the product.


Safety Considerations

This section describes the safety issues encountered while using a linear thruster and the precautions you can take to minimize risk. Potential hazards discussed here are identified by labels affixed to the device.






Labels

Here you will find the safety and identification labels affixed to your linear thruster. To prevent injury and damage to the linear thruster, review the safety label and its details and location before using the actuator.

Labels on the Linear Thruster



Safety Labels

Title	Location	Label	Details
Strong Magnets	A		<p>The linear thruster slide uses strong magnets over its entire length. The magnetic field generated can disrupt the functionality of automatic implantable cardioverter defibrillators (AICD). People with cardiac pacemakers should not work near the linear thruster.</p> <p>The strong magnets of the linear thruster slider will attract metal objects that are in its proximity. During handling and installation maintain distance between the linear thruster slider and metal mounting surfaces or structures. Refer to Remove the Linear Thruster from the Shipping Container on page 11</p> <p>Maintenance personnel should avoid the use of metallic tools and secure items such as badge clips other personnel effect that could be attracted to the strong magnetic field.</p> <p>Strong magnets can erase magnetic media. Never let credit cards or electronic media contact or come near the linear thruster.</p>
Pitch Point/ Motion Hazard	B		<p>The linear thruster is capable of sudden and fast motion. Never stand in the axis of motion when under power. Do not put fingers inside the slider. Lock out - tag out if access to the linear thruster is required during maintenance while the connectors are installed.</p>
Hot Surface	C		<p>Indicates that the surface can be hot enough to burn if touched.</p>
High Voltage	D		<p>Do not open linear thruster covers or right angle connectors while the cables are connected. Lock out-tag out if access to the linear thruster is required during maintenance while the connectors are installed.</p>
Shipping/handling Set Screw	E		<p>When handling the linear thruster during maintenance or installation the set screw must be tightened to 2.3 N·m (20 lb·in) to prevent unexpected movement of the slide and weight shift of the linear thruster.</p> <p>After installation, loosen the set screw so that the slider is free to move for normal operation. The set screw is loose when the head of the screw is flush with the surface of the stator housing.</p>

High Energy Magnets

Linear thruster magnet tracks contain high energy magnets that attract ferrous metals from a considerable distance. Precautions must be taken while unpacking, handling, and shipping by air.

Unpacking and Handling

Leave protective wrapping, cardboard and flux containment plates in place until linear thruster is installed. Clear the inspection and repacking area of any ferrous metals that will be attracted to or attract the linear thruster. If you are working multiple linear thrusters, maintain a distance of 1.5 m (5 ft) between each linear thruster.

Air Freight Restrictions

When air freighting linear thruster special preparations and precautions must be taken. The following information outlines the basic requirements at the publication date of this document. However, regulations are subject to change and additional area or carrier restrictions may be imposed. Always check with your carrier or logistics specialist regarding current local, regional, and national transportation requirements when shipping this product.

Linear thruster magnet track contain magnetized material, as classified by International Air Transport Association (IATA) Dangerous Goods Regulations. An IATA trained individual must be involved when shipping this product via domestic or international air freight. Packing Instruction 902 provides information regarding the preparation of this product for air transportation. Follow these regulations for general marking and labeling requirements, the application of specific Magnetized Material Handling Labels, and instructions for preparing the Shipper's Declaration for Dangerous Goods.

As a minimum, refer to the following IATA Dangerous Goods Regulations:

- Subsection 1.5: Training
- Subsection 3.9.2.2: Classification as Magnetized Material
- Subsection 4.2: Identification as UN 2807, Magnetized Material, Class 9, Packing Instruction 902
- Subsection 7.1.5: Marking
- Subsection 7.2: Labeling
- Subsection 7.4.1: Magnetized Material Label
- Section 8: Shipper's Declaration for Dangerous Goods

When shipped via ground in the United States, these products are **not** considered a U.S. D.O.T. Hazardous Material and standard shipping procedures apply.

Vertical or Incline Installation

A linear thruster driven system mounted vertically or on an incline will not maintain position when the power is removed. Under the influence of gravity the motion platform and its payload will fall to the low end of travel. Design engineers should allow for this by designing in controlled power down circuits or mechanical controls to prevent the linear thruster driven system and its payload from being damaged when the power fails.

IMPORTANT

Any person that teaches, operates, maintains, or repairs these linear thruster must be trained and demonstrate the competence to safely perform the assigned task.



ATTENTION: Linear thrusters are capable of high accelerations, sudden and fast motion. Rockwell Automation is not responsible for misuse, or improper implementation of this equipment.



ATTENTION: Linear thrusters driven systems must have the payload must be secured to the system such that it will not sheer off in the event of an impact in excess of the bumper ratings.



ATTENTION: The Hall effect module and motor feedback encoder contain an electrostatic discharge (ESD) sensitive devices. Follow static-control precautions when you install, test, service, or repair this assembly. If you do not follow ESD control precautions, components can be damaged. If you are not familiar with static control precautions, refer to Guarding Against Electrostatic Damage, publication [8000-4.5.2](#), or any other applicable ESD awareness handbook.




BURN HAZARD: When the linear thruster are running at their maximum rating the temperature of attached heat sink can reach 100 °C (212 °F).



SHOCK HAZARD: An assembled linear thruster will generate power if the coil or magnet track is moved. Un-terminated power cables present an electrical shock hazard. Never handle flying leads or touch power pins while moving the motor.

Catalog Number Explanation

This is the catalog explanation for the LDAT-Series integrated linear thruster.




- (1) Magnetic strip has 1 mm pole pitch. Final resolution when used with a Kinetix® 300 servo drive is 0.488 µm. Absolute encoder is only compatible with Kinetix 300 single-axis drives.

See [Accessories on page 57](#) for accessory catalog numbers.

About the LDAT-Series Integrated Linear Thruster

LDAT-Series integrated linear thrusters feature high resolution encoders. The linear motor extends or retracts the slider within the linear thruster housing. The linear thrusters have been designed for exact positioning at high speeds.

Top View of
LDAT-Series Integrated Linear Thruster
(LDAT-S73010xx is shown)



Item	Description
1	Power connector
2	Feedback connector
3	Encoder access panel
4	Encoder alignment access
5	Magnetic Encoder scale
6	Payload mounting surface
7	Grease access (not applicable on frame 30)
8	Stator body

Item	Description
9	Slider
10	Clevis accessory threaded mounting holes
11	Side surface threaded direct-mount holes
12	Shipping and handling set screw
13	Accessory feet bottom-mount threaded holes
14	Accessory feet side -mount threaded holes
15	Bottom surface threaded direct-mount holes




ATTENTION: Magnetized tools can cause damage if they come too close to surface magnetic encoder scale tape.

Before You Begin



ATTENTION: To avoid personal injury and structural damage to the linear thruster, never attempt lift or move the linear thruster by any means other than those listed in this publication.

Keep the packaging material on the linear thruster to minimize the possibility of it tipping. Do not remove any of the corrugated or foam inserts until the linear thruster is at the installation area. Leave corrugated cardboard tube on slider until the linear thruster has been installed in its final location. If necessary for accessory installation cut the cardboard sleeve to gain access to the slider ends.



ATTENTION: High force magnets are located inside the corrugated cardboard tubes that cover the sliders. The corrugated tubes reduce, but does not eliminate magnetic attraction forces.

Overhead lifting is the recommended method for removing the linear thruster from its container. Eye bolts are supplied with linear thrusters of frame 50 and larger and are taped to one of the slider protective tubes.



ATTENTION: Be sure that the load ratings of the lifting device, slings, hooks and shackles have a lifting capacity rated equal to or greater than the load. Failure to do so may result in personal injury and/or equipment damage. For your system's specific weight, refer to the system nameplate label or shipping weights on the packing slip.

Planning Your Installation

Refer to the Kinetix Linear Motion Specifications [GMC-TD002](#), for the specifications and additional products referenced in this section:

- Include unobstructed access to the linear thrusters shipping and handling setscrew in your application design.
- This product can be operated in compliance with the relevant safety regulations, only if the maximum loading limits are observed.
- If you are mounting your linear thruster in a vertical or sloping position, include safety measures that will control the work load, should the power fail.



ATTENTION: Uncontrolled moving masses can cause injury or damage to property. If there is a power failure, the working mass will drop down.

Check whether additional external safety measures are required to prevent damage in the event of a power failure.

- Corrosive environments reduce the service life of linear thrusters.
- Factory-manufactured feedback and power cables are available in standard cable lengths. They provide environmental sealing and shield termination. Contact your Allen-Bradley® sales office or refer to the Kinetix Motion Accessories Specifications, publication [GMC-TD004](#), for additional information.

General safety standards and requirements include, but are not limited to, the following:

- UL 1740 Safety of Robots and Robotic Equipment
- ANSI/RIA R15.06, Industrial Robots and Robot Systems Safety Requirements - Teaching Multiple Robots
- ANSI/NFPA 79, Electrical Standard for Industrial Machinery
- CSA/CAN Z434, Industrial Robots and Robot Systems- General Safety Requirements
- EN60204-1, Safety of Machinery. Electrical Equipment of Machines

Remove the Linear Thruster from the Shipping Container


1. Consider the weight of the linear thruster.

Depending on the design, the linear thruster can weigh up to 106.7 kg (235.2 lb).



ATTENTION: Linear thrusters that exceed 22.7 kg (50.0 lb) require a two man lift. Do not lift the linear thruster by the slider. Use supplied eye bolts when ever possible.

2. Attach two eye bolts to connector side of the linear thruster.



3. Select or adjust the rigging lengths to compensate for the weight distribution.



ATTENTION: Do not pass ropes or cables through the eye bolts. Use hooks or shackles with load-rated slings.

The angle between the lifting cables must not exceed 45° angle from vertical as shown. Maintain the linear thruster in a balanced position.

4. Test lift the linear thruster a minimal amount.

Verify that it is properly secured and balanced before moving it further. The lift points may not be equidistant from the center of gravity.



ATTENTION: Do not loosen the shipping and handling set screw until the linear thruster is installed in your application. The slider is free to move once the shipping set screw is loosened. Use additional care when working with the linear thruster after the set screw is loosened. Unexpected slider movement can cause personal injury.

5. Lift the linear thruster.
6. Visually inspect the linear thruster for damage.
Closely examine the mounting surface, frame, and slider for defects.
7. Notify the carrier of shipping damage immediately.

Prolonging Linear Thruster Life

Thoughtful design and proper maintenance can increase the life of a linear thruster. Follow these guidelines to maximize the life of a linear thruster especially within a food processing environment:

- Always provide a drip loop in each cable to carry liquids away from the connection to the motor.
- If design requirements permit, provide shields that protect the motor housing, slider, and their junctions from contamination by foreign matter or fluids.
- Inspect the bearings and strip cover, if equipped, for damage or wear on a regular basis. If damage or excessive wear is observed, replace the item.

Preventing Electrical Noise

Electromagnetic interference (EMI), commonly called electrical noise, can reduce linear thruster performance. Effective techniques to counter EMI include filtering the AC power by using shielded cables, separating signal cables from power wiring, and practicing good grounding techniques.

Follow these guidelines to avoid the effects of EMI:

- Isolate the power transformers or install line filters on all AC input power lines.
- Separate signal cables from motor cabling and power wiring. Do not route signal cables with motor and power wires, or over the vent openings of servo drives.
- Ground all equipment by using a single-point parallel ground system that employs ground bus bars or large straps. If necessary, use additional electrical noise reduction techniques to reduce EMI in noisy environments.

Refer to System Design for Control of Electrical Noise Reference Manual, publication [GMC-RM001](#), for additional information on reducing the effects of EMI.

Install the Linear Thruster

The installation must comply with all local and national safety and electrical codes and use of equipment and installation practices that promote electromagnetic compatibility and safety. Only qualified service personnel may install or service a linear thruster.



ATTENTION: Do not loosen the shipping and handling set screw until the linear thruster is installed in its application.



ATTENTION: Install linear thruster to avoid interference with buildings, structures, utilities other machines and equipment may create a trapping hazard or pinch points.



ATTENTION: Unmounted linear thrusters, disconnected mechanical couplings, and disconnected cables are dangerous if power is applied.
 Appropriately identify (tag-out) disassembled equipment, and restrict (lock-out) access to electrical power.
 Failure to observe these safety precautions could result in personal injury.

Follow these steps to prepare the linear thruster for installation on the machine.

1. Provide sufficient clearances in the area of the linear thruster for it to stay within its specified operating temperature range.

Refer to [Specifications](#) on [page 75](#) for the operating temperature range. Do not enclose the linear thruster unless forced air is blown across the linear thruster for cooling. Keep other heat producing devices away from the linear thruster.

2. Make sure the mounting surface supports the linear thruster evenly so that it is free of mechanical stress and distortion. Evenness of the mounting surface must be within 0.127 mm (0.005 in.).
3. Attach mounting accessories, shown on [page 57](#), to the linear thruster.

If you are installing with this accessory	Refer to this table or procedure
Clevis mount	Install with Clevis Mount Accessory on page 16
Foot mount	Install with Foot Mount Accessory on page 16
None	Direct Mount the Linear Thruster on page 17

4. Attach slider-end accessories, see on [page 58](#), to the work load as outlined below.

Be sure the work load center of gravity is centric to the slider.



ATTENTION: Damage may occur to the linear thruster bearings and the feedback device if sharp impact to the slider is applied during installation. Do not strike the slider with tools during installation or removal.
 Failure to observe these safety precautions could result in damage to the linear thruster and its components.

Use these torque values to attach a rod eye, rod clevis or payload bracket to the slider.

Cat. No.	Torque, max ⁽¹⁾
LDAT-S03	6.8 N·m (5 lb·ft)
LDAT-S05	
LDAT-S07	
LDAT-S10	14.7 N·m (10.83 lb·ft)
LDAT-S15	

(1) Unless otherwise noted, torque specifications have a $\pm 20\%$ tolerance.


If installing a counterbalance kit, install counter balance end bracket between slider end cap and slider-end accessory. Complete counter balance kit installation by following steps in [Install Counterbalance Kit on page 14](#).

Install Counterbalance Kit


Follow these steps to install the counter balance kit.

Unless otherwise noted, torque specifications have a $\pm 20\%$ tolerance.

1. Remove M8 set screws from stator body.




2. Install stator bracket with two M8 x 1.25 x 16 socket head cap screws (SHCS).
Torque screw to 19.2 N•m (14.2 lb•ft).
3. Screw one 3/8 in. hex nut onto a spring anchor.
4. Install hex nut and spring anchor assembly in one of the three threaded mount locations.
Torque nut to 33.9 N•m (25.0 lb•ft).



5. Remove three screws that secure the slider-end cap and discard.

6. Install the counter balance and slider-end cap the screws that came with the kit.



7. Torque to values shown in table.

LDAT Frame Size	S1	S1 Torque N•m (lb•in)	S2	S2 Torque N•m (lb•in)
30	M8 x1.25 x 40	13.5 (10.0)	M6 x1.0 x 30	9.0 (6.6)
50	M10 x1.5 x 50	33.9 (25.0)	M10 x1.5 x 30	33.9 (25.0)
75				
100				
150	M14 x2.05 x 60	84.7 (62.5)		

8. Screw one 3/8 in. hex nut onto a spring anchor.
9. Install hex nut and spring anchor assemble in the counter balance bracket.
Torque nut to 33.9 N•m (25.0 lb•ft).
Attach your counter balance spring between the two spring anchor pins.

Install with Clevis Mount Accessory

Install the clevis mount accessory with screws included in the kit and torque to the values shown.

Cat. No.	Clevis Kit	Torque, max
LDAT-S03	LDAT-03-CLVSM or LDAT-03-CLVSF	6.8 N·m (5.00 lb·ft)
LDAT-S05	LDAT-0507-CLVSM or LDAT-0507-CLVSF	
LDAT-S07		
LDAT-S10	LDAT-1015-CLVSM or LDAT-1015-CLVSF	14.7 N·m (10.83 lb·ft)
LDAT-S15		

Install with Foot Mount Accessory

Follow these steps to mount the linear thruster on your application with the foot mount accessory.

1. Verify the mounting surface flatness.

The mounting surface must be flat or shimmed flat to the mounting surface of the linear thruster within 0.127 mm (0.005 in.) to avoid distortion and damage to the actuator housing.

2. Loosely install the all of the foot mounts on to your application with your fasteners.
3. Loosely install linear thruster to foot mounts by using two of the supplied screws per foot mount.
4. Tighten mounting fasteners to your application.
5. Torque the foot mount screw to linear thruster to the following values.

Cat. No.	Foot Mount	Torque, max ⁽¹⁾
LDAT-S03	LDAT-MID-FTMOUNT	4.5 N•m (3.33 lb•in)
LDAT-S05		
LDAT-S07		
LDAT-S10	LDAT-LARGE-FTMOUNT	6.8 N•m (5.00 lb•in)
LDAT-S15		

(1) Unless otherwise noted, torque specifications have a $\pm 20\%$ tolerance.

Direct Mount the Linear Thruster

Follow these steps to mount the linear thruster on directly on your machine.

1. Verify the mounting surface flatness.

The mounting surface must be flat or shimmed flat to the mounting surface of the linear thruster within 0.127 mm (0.005 in.) to avoid distortion and damage to the actuator housing.

2. Install and evenly tighten the steel fasteners so the linear thruster.

Torque the steel fasteners evenly to following values.

Cat. No.	Torque, max
LDAT-S03	4.5 N•m (3.33 lb•in)
LDAT-S05	
LDAT-S07	
LDAT-S10	6.8 N•m (5.00 lb•in)
LDAT-S15	



ATTENTION: When installed, pinch points with high forces are created that have the potential for causing physical damage. The risk area surrounding the linear thruster must be enclosed or clearly marked, including signage in accordance with national and international requirements.

The risk area must be protected by a safety system that stops the equipment if anyone enters the risk area. Personnel who enter the risk area must be authorized, trained, and qualified for any task performed inside the risk area.

Build and Route Cables

Knowledgeable cable routing and careful cable construction improves system electromagnetic compatibility (EMC).

To build and install cables, perform these steps.

1. Keep wire lengths as short as possible.
2. Route signal cables (encoder or serial) away from motor and power wiring.
3. Separate cables by 0.3 m (1 ft) minimum for every 9 m (30 ft) of parallel run.
4. Ground both ends of the encoder cable shield and twist the signal wire pairs to prevent electromagnetic interference (EMI) from other equipment.



ATTENTION: High voltage can be present on the shield of a power cable, if the shield is not grounded.

Make sure there is a connection to ground for any power cable shield.

Failure to observe these safety precautions could result in personal injury or damage to equipment.

The cable length from the linear thruster to the drive should be limited to 10 m (32.8 ft). If longer cables are necessary, a 1321-3Rx-x series line reactor is required. Refer to the 1321 Power Conditioning Products Technical Data, publication [1321-TD001](#), to choose a line reactor for applications requiring cable longer than 10 m (32.8 ft).

Attach Motor Cables

Use this procedure to attach the power and feedback cables after the linear thruster is mounted.

1. Carefully align each cable connector with the respective linear thruster connector as shown in the diagram.



ATTENTION: Keyed connectors must be properly aligned and hand-tightened the recommended number of turns.

Improper connector alignment is indicated by the need for excessive force to seat connectors. For example, the need to use tools to fully seat connectors.

Failure to observe these safety precautions could result in damage to equipment.




ATTENTION: When installing a threaded DIN cable with a M4 designation, an O-ring must be installed in the groove immediately adjacent to the body of the linear thruster connector. This O-ring dampens the effects of vibration at the cable-to-linear thruster connection.

Cables requiring O-rings include 2090-XXNFMF-Sxx (standard, non-flex) feedback cables.



ATTENTION: When installing cables with a SpeedTec DIN connector with M7 designation, remove the O-ring.

2. Fully seat the feedback connector and the power/brake connector.
 - Hand tighten the collar of a threaded DIN (M4) connector six turns.
 - Hand tighten the collar of a SpeedTec (M7) connector one-quarter turn.





ATTENTION: Make sure cables are installed and restrained to prevent uneven tension or flexing at the cable connectors. Excessive and uneven lateral force at the cable connectors may result in the connector's environmental seal opening and closing as the cable flexes.


Failure to observe these safety precautions could result in damage to the linear thruster motor and its components.

3. Form a drip loop in the cable to keep liquids away from the connectors.
4. Verify the continuity and functionality of the thermal switch signals, TS+ and TS-.

These signals are transmitted through the feedback cable that connects the motor to its controlling drive.

Change Connector Orientation

You can rotate the circular DIN connector housings up to 180°.



Follow these steps to rotate the DIN connectors.

1. Mount and fully seat a mating cable on the connector.
2. Grasp the connector and the cable plug by their housings and slowly rotate them to the outside of the motor.

If necessary, repeat these steps for the other connector (feedback or power/brake).




ATTENTION: Only apply force to the connectors; do not apply force to the cable. Do not use tools (for example, pliers and vise-grips) to assist with the rotation of the connector.

Failure to observe these safety precautions could result in personal injury or damage to equipment.


Dimensions

Linear Thruster Dimensions (frame 30)


Bottom View of Side Mounting




Bottom View of Bottom Mounting



End View of Bottom Mounting



Dimensions are in mm (in.)



Detail A
Slider and mounting
typical both ends


(1) Up to approximately 5 mm (0.2 in.) overtravel at each end. An additional 12.7 mm (0.5 in.) overtravel each end when stop is fully compressed in a crash condition.

Dimensions (frame 30)


Linear Thruster (frame 30) Cat. No.	Motor size (reference)	Stroke mm (in.)	L mm (in.)	M mm (in.)	A mm (in.)	B mm (in.)	C mm (in.)	N
LDAT-S031010-xxx	100	100 (3.9)	425.4 (16.75)	232.70 (9.161)	—	51.35 (2.022)	38.85 (1.530)	4
LDAT-S031020-xxx		200 (7.9)	525.4 (20.69)					
LDAT-S031030-xxx		300 (11.8)	625.4 (24.62)					
LDAT-S031040-xxx		400 (15.7)	725.4 (28.56)					
LDAT-S032010-xxx	200	100 (3.9)	525.4 (20.69)	332.70 (13.098)	—	66.35 (2.612)	53.85 (2.120)	6
LDAT-S032020-xxx		200 (7.9)	625.4 (24.62)					
LDAT-S032030-xxx		300 (11.8)	725.4 (28.56)					
LDAT-S032040-xxx		400 (15.7)	825.4 (32.50)					
LDAT-S033010-xxx	300	100 (3.9)	625.4 (24.62)	432.70 (17.035)	216.35 (8.518)	—	—	—
LDAT-S033020-xxx		200 (7.9)	725.4 (28.56)					
LDAT-S033030-xxx		300 (11.8)	825.4 (32.50)					
LDAT-S033040-xxx		400 (15.7)	925.4 (36.43)					

Linear Thruster Dimensions (frame 50 and 75)

Bottom View of Side Mounting





Bottom View of Bottom Mounting



(1) Up to approximately 5 mm (0.2 in.) overtravel at each end. An additional 12.7 mm (0.5 in.) overtravel each end when stoo is fully compressed in a crash condition.

End View of Bottom Mounting



Detail A
Slider end mounting
typical both ends

Dimensions (frame 50)

Linear Thruster (frame 50) Cat. No.	Motor size (reference)	Stroke mm (in.)	L mm (in.)	M mm (in.)	A mm (in.)	B mm (in.)	C mm (in.)	N
LDAT-S051010-xxx	100	100 (3.9)	431.8 (16.998)	232.70 (9.161)	—	51.35 (2.022)	38.85 (1.530)	4
LDAT-S051020-xxx		200 (7.9)	531.8 (20.935)					
LDAT-S051030-xxx		300 (11.8)	631.8 (24.872)					
LDAT-S051040-xxx		400 (15.7)	731.8 (28.809)					
LDAT-S051050-xxx		500 (19.7)	831.8 (32.746)					
LDAT-S052010-xxx	200	100 (3.9)	531.8 (20.935)	332.70 (13.098)	216.35 (8.518)	66.35 (2.612)	53.85 (2.120)	5
LDAT-S052020-xxx		200 (7.9)	631.8 (24.872)					
LDAT-S052030-xxx		300 (11.8)	731.8 (28.809)					
LDAT-S052040-xxx		400 (15.7)	831.8 (32.746)					
LDAT-S052050-xxx		500 (19.7)	931.8 (36.683)					
LDAT-S053010-xxx	300	100 (3.9)	631.8 (24.872)	432.70 (17.035)	266.35 (10.486)	66.35 (2.612)	53.85 (2.120)	5
LDAT-S053020-xxx		200 (7.9)	731.8 (28.809)					
LDAT-S053030-xxx		300 (11.8)	831.8 (32.746)					
LDAT-S053040-xxx		400 (15.7)	931.8 (36.683)					
LDAT-S053050-xxx		500 (19.7)	1031.8 (40.620)					
LDAT-S054010-xxx	400	100 (3.9)	731.8 (28.809)	532.70 (20.972)	266.35 (10.486)	66.35 (2.612)	53.85 (2.120)	5
LDAT-S054020-xxx		200 (7.9)	831.8 (32.746)					
LDAT-S054030-xxx		300 (11.8)	931.8 (36.683)					
LDAT-S054040-xxx		400 (15.7)	1031.8 (40.620)					
LDAT-S054050-xxx		500 (19.7)	1131.8 (44.557)					


Dimensions (frame 75)									
Linear Thruster (frame 75) Cat. No.	Motor size (reference)	Stroke mm (in.)	L mm (in.)	M mm (in.)	A mm (in.)	B mm (in.)	C mm (in.)	N	
LDAT-5072010-xxx	200	100 (3.9)	531.8 (20.94)	332.70 (13.098)	—	66.35 (2.612)	53.850 (2.120)	4	
LDAT-5072020-xxx		200 (7.9)	631.8 (24.87)						
LDAT-5072030-xxx		300 (11.8)	731.8 (28.81)						
LDAT-5072040-xxx		400 (15.7)	831.8 (32.75)						
LDAT-5072050-xxx		500 (19.7)	931.8 (36.68)						
LDAT-5072060-xxx		600 (23.6)	1031.8 (40.62)						
LDAT-5072070-xxx		700 (27.6)	1131.8 (44.56)						
LDAT-5073010-xxx	300	100 (3.9)	631.8 (24.87)	432.70 (17.035)	216.35 (8.52)			5	
LDAT-5073020-xxx		200 (7.9)	731.8 (28.81)						
LDAT-5073030-xxx		300 (11.8)	831.8 (32.75)						
LDAT-5073040-xxx		400 (15.7)	931.8 (36.68)						
LDAT-5073050-xxx		500 (19.7)	1031.8 (40.62)						
LDAT-5073060-xxx		600 (23.6)	1131.8 (44.56)						
LDAT-5073070-xxx		700 (27.6)	1231.8 (48.49)						

Dimensions (frame 75) (continued)


Linear Thruster (frame 75) Cat. No.	Motor size (reference)	Stroke mm (in.)	L mm (in.)	M mm (in.)	A mm (in.)	B mm (in.)	C mm (in.)	N
LDAT-S074010-xxx	400	100 (3.9)	731.8 (28.81)	532.70 (20.97)	266.350 (10.49)	66.35 (2.612)	53.850 (2.120)	5
LDAT-S074020-xxx		200 (7.9)	831.8 (32.75)					
LDAT-S074030-xxx		300 (11.8)	931.8 (36.68)					
LDAT-S074040-xxx		400 (15.7)	1031.8 (40.62)					
LDAT-S074050-xxx		500 (19.7)	1131.8 (44.56)					
LDAT-S074060-xxx		600 (23.6)	1231.8 (48.49)					
LDAT-S074070-xxx		700 (27.6)	1331.8 (52.43)					
LDAT-S076010-xxx	600	100 (3.9)	931.8 (36.68)	732.70 (28.85)	366.350 (14.42)	66.35 (2.612)	53.850 (2.120)	5
LDAT-S076020-xxx		200 (7.9)	1031.8 (40.62)					
LDAT-S076030-xxx		300 (11.8)	1131.8 (44.56)					
LDAT-S076040-xxx		400 (15.7)	1231.8 (48.49)					
LDAT-S076050-xxx		500 (19.7)	1331.8 (52.43)					
LDAT-S076060-xxx		600 (23.6)	1431.8 (56.37)					
LDAT-S076070-xxx		700 (27.6)	1531.8 (60.31)					

Linear Thruster Dimensions (frame 100)

Bottom View of Side Mounting





Bottom View of Bottom Mounting



(1) Up to approximately 5 mm (0.2 in.) overtravel at each end. An additional 12.7 mm (0.5 in.) overtravel each end when stop is fully compressed in a crash condition.

End View of Bottom Mounting



Dimensions (frame 100)


Linear Thruster (frame 100) Cat. No.	Motor size (reference)	Stroke mm (in.)	L mm (in.)	M mm (in.)	A mm (in.)	N	S
LDAT-S102010-xx	200	100 (3.9)	538.1 (21.18)	332.70 (13.098)	—	4	
LDAT-S102020-xx		200 (7.9)	638.1 (25.12)				
LDAT-S102030-xx		300 (11.8)	738.1 (29.06)				
LDAT-S102040-xx		400 (15.7)	838.1 (33.00)				
LDAT-S102050-xx		500 (19.7)	938.1 (36.93)				
LDAT-S102060-xx		600 (23.6)	1038.1 (40.87)				
LDAT-S102070-xx		700 (27.6)	1138.1 (44.81)				
LDAT-S102080-xx		800 (31.5)	1238.1 (48.74)				
LDAT-S102090-xx	300	900 (35.4)	1338.1 (52.68)	432.70 (17.035)	216.35 (8.518)	6	4
LDAT-S103010-xx		100 (3.9)	638.1 (25.12)				
LDAT-S103020-xx		200 (7.9)	738.1 (29.06)				
LDAT-S103030-xx		300 (11.8)	838.1 (33.00)				
LDAT-S103040-xx		400 (15.7)	938.1 (36.93)				
LDAT-S103050-xx		500 (19.7)	1038.1 (40.87)				
LDAT-S103060-xx		600 (23.6)	1138.1 (44.81)				
LDAT-S103070-xx		700 (27.6)	1238.1 (48.74)				
LDAT-S102080-xx		800 (31.5)	1338.1 (52.68)				
LDAT-S102090-xx		900 (35.4)	1438.1 (56.62)				

Dimensions (frame 100) (continued)


Linear Thruster (frame 100) Cat. No.	Motor size (reference)	Stroke mm (in.)	L mm (in.)	M mm (in.)	A mm (in.)	N	S
LDAT-S104010-xx	400	100 (3.9)	738.1 (29.06)	532.70 (20.972)	266.35 (10.486)	6	6
LDAT-S104020-xx		200 (7.9)	838.1 (33.00)				
LDAT-S104030-xx		300 (11.8)	938.1 (36.93)				
LDAT-S104040-xx		400 (15.7)	1038.1 (40.87)				
LDAT-S104050-xx		500 (19.7)	1138.1 (44.81)				
LDAT-S104060-xx		600 (23.6)	1238.1 (48.74)				
LDAT-S104070-xx		700 (27.6)	1338.1 (52.68)				
LDAT-S104080-xx		800 (31.5)	1438.1 (56.62)				
LDAT-S104090-xx	600	900 (35.4)	1538.1 (60.55)	732.70 (28.846)	366.35 (14.423)	6	6
LDAT-S106010-xx		100 (3.9)	938.1 (36.93)				
LDAT-S106020-xx		200 (7.9)	1038.1 (40.87)				
LDAT-S106030-xx		300 (11.8)	1138.1 (44.81)				
LDAT-S106040-xx		400 (15.7)	1238.1 (48.74)				
LDAT-S106050-xx		500 (19.7)	1338.1 (52.68)				
LDAT-S106060-xx		600 (23.6)	1438.1 (56.62)				
LDAT-S106070-xx		700 (27.6)	1538.1 (60.55)				
LDAT-S106080-xx		800 (31.5)	1638.1 (64.49)				
LDAT-S106090-xx		900 (35.4)	1738.1 (68.43)				

Linear Thruster Dimensions (frame 150)


Bottom View of Side Mounting



End View of Bottom Mounting



Bottom View of Bottom Mounting



(1) Up to approximately 5 mm (0.2 in.) overtravel at each end. An additional 1.27 mm (0.05 in.) overtravel each end when stop is fully compressed in a crash condition.

Dimensions (frame 150)

Linear Thruster (frame 150) Cat. No.	Motor size (reference)	Stroke mm (in.)	L mm (in.)	M mm (in.)	A mm (in.)	N	S
LDAT-5152010-xxx	200	100 (3.9)	538.1 (21.18)	332.70 (13.098)	—	4	4
LDAT-5152020-xxx		200 (7.9)	638.1 (25.12)				
LDAT-5152030-xxx		300 (11.8)	738.1 (29.06)				
LDAT-5152040-xxx		400 (15.7)	838.1 (33.00)				
LDAT-5152050-xxx		500 (19.7)	938.1 (36.93)				
LDAT-5152060-xxx		600 (23.6)	1038.1 (40.87)				
LDAT-5152070-xxx		700 (27.6)	1138.1 (44.81)				
LDAT-5152080-xxx		800 (31.5)	1238.1 (48.74)				
LDAT-5152090-xxx		900 (35.4)	1338.1 (52.68)				
LDAT-5153010-xxx	300	100 (3.9)	638.1 (25.12)	432.70 (17.035)	216.35 (8.518)	6	4
LDAT-5153020-xxx		200 (7.9)	738.1 (29.06)				
LDAT-5153030-xxx		300 (11.8)	838.1 (33.00)				
LDAT-5153040-xxx		400 (15.7)	938.1 (36.93)				
LDAT-5153050-xxx		500 (19.7)	1038.1 (40.87)				
LDAT-5153060-xxx		600 (23.6)	1138.1 (44.81)				
LDAT-5153070-xxx		700 (27.6)	1238.1 (48.74)				
LDAT-5153080-xxx		800 (31.5)	1338.1 (52.68)				
LDAT-5153090-xxx		900 (35.4)	1438.1 (56.62)				


Dimensions (frame 150) (continued)

Linear Thruster (frame 150) Cat. No.	Motor size (reference)	Stroke mm (in.)	L mm (in.)	M mm (in.)	A mm (in.)	N	S
LDAT-S154010-xxx	400	100 (3.9)	738.1 (29.06)	532.70 (20.972)	266.35 (10.486)	6	6
LDAT-S154020-xxx		200 (7.9)	838.1 (33.00)				
LDAT-S154030-xxx		300 (11.8)	938.1 (36.93)				
LDAT-S154040-xxx		400 (15.7)	1038.1 (40.87)				
LDAT-S154050-xxx		500 (19.7)	1138.1 (44.81)				
LDAT-S154060-xxx		600 (23.6)	1238.1 (48.74)				
LDAT-S154070-xxx		700 (27.6)	1338.1 (52.68)				
LDAT-S154080-xxx		800 (31.5)	1438.1 (56.62)				
LDAT-S154090-xxx	600	900 (35.4)	1538.1 (60.55)	732.7 (28.846)	366.35 (14.423)	6	6
LDAT-S156010-xxx		100 (3.9)	938.1 (36.93)				
LDAT-S156020-xxx		200 (7.9)	1038.1 (40.87)				
LDAT-S156030-xxx		300 (11.8)	1138.1 (44.81)				
LDAT-S156040-xxx		400 (15.7)	1238.1 (48.74)				
LDAT-S156050-xxx		500 (19.7)	1338.1 (52.68)				
LDAT-S156060-xxx		600 (23.6)	1438.1 (56.62)				
LDAT-S156070-xxx		700 (27.6)	1538.1 (60.55)				
LDAT-S156080-xxx		800 (31.5)	1638.1 (64.49)				
LDAT-S156090-xxx		900 (35.4)	1738.1 (68.43)				


Connector Data

This table lists the signal descriptions for connector pins on the linear thruster.

Feedback			Power and Brake	
Pin	Signal Name LDAT-xxxxxxx-xBx (incremental encoder)	Signal Name LDAT-xxxxxxx-xDx (absolute encoder) ⁽²⁾	Pin ⁽³⁾	Signal Name
1	A+	Sin+	A	Phase U
2	A-	Sin-	B	Phase V
3	B+	Cos+	C	Phase W
4	B-	Cos-	D	Ground
5	Index+	Data+	E	Reserved
6	Index-	Data-	F	
7	Reserved	Reserved	G	
8			H	
9			L	
10	Common	Common	Case	Cable Shield and GND
11	Reserved	+9V DC		
12		Reserved		
13	TS+ ⁽¹⁾	TS+ ⁽¹⁾		
14	TS- ⁽¹⁾	TS- ⁽¹⁾		
15	S1	Reserved		
16	S2			
17	S3			
Case	Shield	Shield		



Intercontec P/N
BEDC0911NN00000202000



Intercontec P/N
AEDC113NN00000202000

- (1) The normally closed thermal switch opens at 100 °C (212 °F).
- (2) Absolute encoder is only compatible with Kinetix 300 single-axis drives.
- (3) Power pins A, B, C, and D may be labeled as U, V, W, and GND respectively. Reserved pins E and H may be numbered 1 or 2.



ATTENTION: Be sure that cables are installed and restrained to prevent uneven tension or flexing at the cable connectors. Excessive and uneven lateral force at the cable connector may result in damage to the housing and contacts as the cable flexes. Failure to observe these safety precautions could result in damage to the motor and its components.

Commissioning

This section provides guidelines for using RSLogix™ 5000 and MotionView software to configure your linear thruster servo drive system.

Required Files

Firmware revisions and software versions required to support the linear thrusters include the following.

Drive	Firmware Version min	Software	Software Version min	Supplemental File min
Kinetix 2000 with SERCOS	1.199	RSLogix	16.xx	LDAT_7_6_12.cmf
Kinetix 6000 with SERCOS	1.120			
Ultra™ 3000 with SERCOS	1.52			
Kinetix 6200	1.040		18.xx	
Kinetix 6500	2.006		19.xx	
Kinetix 300	1.067	MotionView	n/a	RSLogix software, version 17.xx with Add-on profiles ⁽¹⁾
Ultra3000	1.52	Ultraware	1.84	Motion Database (.mdb) June 2012
Kinetix 3	2.10			

(1) See Kinetix 300 EtherNet/IP Indexing Servo Drives User Manual, publication [2097-UM001](#).

You can use Motion Analyzer software, version 6.0 or later as required.

Download these files from <http://www.rockwellautomation.com/support>. Contact Rockwell Automation Technical Support at (440) 646-5800 for assistance.

Configure Your Linear Thruster

Configure the linear thruster by using the basic parameter settings described in this section. Use the procedure appropriate for your motion axis.

LDAT-Sxxxxxx-xB linear thrusters with incremental encoders, are compatible with all Kinetix drives and have a default resolution of 5 µm. LDAT-Sxxxxxx-xD linear thrusters with absolute encoders are only compatible with Kinetix 300 drives.

The type of Allen-Bradley drive connected to the linear thruster determines the configuration procedure. The following table shows you the configuration procedures to follow.

Drive	Refer to:
Kinetix 2000 Kinetix 6000 Kinetix 6200 Ultra3000 with SERCOS	Configure and Commission Your SERCOS Servo Drive with RSLogix 5000 Software on page 35
Kinetix 6500	Configure Your Kinetix 6500 EtherNet/IP Servo Drive with RSLogix 5000 Software on page 40 .
Kinetix 300	Configure Your Kinetix 300 EtherNet/IP Servo Drive with MotionView Software on page 42
Ultra3000 and Kinetix 3	Configure Your Servo Drive with Ultraware Software on page 45 .




ATTENTION: Moving parts can cause injuries. Before running the linear thruster, make sure all components are secure and safe guards are in place to prevent access to the path of moving machinery. Safeguards should prevent access to the linear thruster until all motion has stopped. Check that the linear thruster is clear of foreign matter and tools. Objects hit by the moving thrust rod can become projectiles that can cause personal injury or damage to the equipment.

IMPORTANT You must verify that the servo control system safely controls the linear thruster with regard to maximum force, acceleration, and speed.

Positive Motion Direction

Positive motion is defined as the slider extending from the stator body opposite the power and feedback connectors.



Configure and Commission Your SERCOS Servo Drive with RSLogix 5000 Software

For each linear thruster that is powered by a Kinetix 2000, Kinetix 6000, Kinetix 6200, or an Ultra3000 servo drive, use the next four sections to configure, hookup test, tune, fine tune and set up homing for the linear thruster.

These procedure assumes the linear thruster and a Kinetix 2000, Kinetix 6000, Kinetix 6200, or an Ultra3000 servo drive has been installed and wired as one axis of the motion system.

For help using RSLogix 5000 software as it applies to setting up your linear thruster, refer to [Additional Resources](#) on [page 78](#). This procedure assumes you are familiar with RSLogix 5000 software.

Configure

Follow these steps to configure your drive for the linear thruster.

1. Loosen shipping and handling set screw till it is just flush with the stator body surface.
2. Run the RSLogix 5000 software.
3. Complete the basic system configuration to create an axis.
4. Right-click on your axis and select Properties.
5. Set these values in the appropriate Axis Properties tab of RSLogix 5000 software.



ATTENTION: Incorrect parameter settings may result in uncontrolled motion, with the potential for damage to the linear thruster. Setting the Positioning Mode to Rotary can cause damage to the linear thruster or the machine due to incorrect positioning.

Axis Properties Tab	Parameter	Entry/Selection
Drive/Motor	Motor Catalog Number	Select your linear thruster catalog number
	Drive Resolution	200,000 drive counts /motor millimeter
	Attribute 1	Position Error (recommended)
	Attribute 2	TorqueFeedback (recommended)
Units	Position Units	mm
Conversion	Positioning Mode	Linear
	Conversion Constant	200,000.0 drive counts /1.0 mm

The LDAT linear thrusters display a different suffix depending on the servo drive you are using. Systems using a 230V drive show linear thruster with a _A suffix and those using a 460V drive will show _B suffix.

EXAMPLE LDAT -S031020-Bx_A catalog numbers are shown when 230V drive is selected.
LDAT -S031020-Bx_B catalog numbers are shown when 460V drive is selected.

Hookup Test

Run the hookup test before the linear thruster loads or fixtures are installed. Vertical loads or external forces of more than 10% of the rated load may prevent the hookup test from passing, even though the unit is wired correctly.

Follow these steps to do the hookup test for the linear thruster.

1. From the Hookup Axis Properties tab enter the following

Parameter	Entry/Selection
Test Increment	60 mm
Drive Polarity	Positive

2. Click Test Command & Feedback.

Tune

The linear thruster is a direct drive actuator. Tuning the linear thruster establishes a stable axis.



ATTENTION: Before you tune your linear thruster read and understand [Preventing Undetected and Repetitive High Energy Impacts](#) and [Preventing Reduced Dynamic Control Performance on page 39](#)

Follow these steps to tune the linear thruster.

1. Attach your application load to the linear thruster.
2. From the Tune tab enter the following recommended tuning parameters.

Parameter	Entry/Selection
Travel Limit	100 mm
Speed	500 mm/s
Torque/Force	100%
Direction	Forward/Bi-directional
Damping Factor	0.8 (default)
For preliminary Autotune do not check tune parameter boxes.	

3. Click Start Tuning.

You can fine tune the linear thruster for your specific application requirements by using the suggestions made in the next section.

Fine Tune

Use the Gains tab to fine tune your linear thruster. The following bullets show you how to get the best results.

- For precise positioning applications, add position integral gain and increase the position proportional gain as necessary.
- For stiffer and more precise tracking of motion profiles, increase the velocity gain.
- For stable operation increase the velocity gain until you hear the axis oscillate, and then reduce the velocity gain by one half.
- For applications with very high acceleration, > 30 m/s/s (1.2 in/s/s), add acceleration feed forward.
- For linear thrusters with long travel, > 500 mm (20 in.) or with large mass attached to the slider, you may notice the axis is vibrating or resonating after AutoTune. If it does, use the Output screen to add a low pass filter or a notch filter to remove the resonance.

Set up Homing

Enter these parameters to set up homing for the linear thruster.

Parameter	Entry/Selection
Mode	Active
Position	0, typical
Offset	10 mm ⁽¹⁾
Sequence	Torque Level-Marker
Direction	Reverse Bi-directional
Torque Level	20%, min Greater if the system friction, force, or weight exceeds 30% of the Continuous Force Rating at any point in the range of motion
Speed	5 mm/s
Return Speed	10 mm/s

(1) The 10mm offset sets the home position to an axis location clear of the spring stops.



ATTENTION: Avoid excessive force while homing the linear thruster. Do not exceed 100 mm/s (4.0 in/s) during a home routine. Speeds greater than 100 mm/s (4.0 in/s) may damage the linear thruster when the slider reaches the end of travel.

Preventing Undetected and Repetitive High Energy Impacts

To prevent high energy impacts, take normal motion system precautions and make sure the Position Error Tolerance is suitable for your application.

Normal motion system precautions include the following:

- Interlocks for access
- Range of motion hardware and software limits

In addition you should complete these tasks:

- Determine limit positions based on maximum speed and load, and stopping distance at peak capability of motor or drive. You can use Motion Analyzer to determine these positions
- Program the position error fault action to Disable Drive (default) or Stop.
- Program the Limits tab in Axis Properties to reduce the Position Error Tolerance. Typically, a value less than 10 mm (0.39 in.) is achievable without causing nuisance Position Error (E19) faults.
- In higher speed applications, implement 100% Velocity Feed-forward on the Axis Properties Gains tab. This value reduces the Position Error during normal axis motion.
- After performing an Auto-Tune, always set the Position Error Tolerance back to the established reduced values.



ATTENTION: Motor capacity may be exceeded by load changes, obstructions or equipment dynamic responses.

When a closed-loop servo system is operating, changes in loads, obstructions, or equipment dynamic response can cause motor capacity to be exceeded. Under these conditions, the Kinetix 6000 and Kinetix 2000 drives fold back the current to the motor to prevent thermal damage.

Typically, the fold back causes a closed-loop servo system to operate with reduced dynamic control performance, particularly when accelerating and decelerating. If the reduced dynamic control results in undesirable Position Error and the Position Error Tolerance is set to a relatively large value, such as, the default value, the increase in Position Error may go undetected. If proper precautions are not in place, this could lead to equipment damage and/or serious injury.

Preventing Reduced Dynamic Control Performance

To prevent reduced dynamic control, you should take normal motion system precautions and monitor the drive's motor capacity.

Normal motion system precautions include:

- Interlocks for access.
- Range of motion hardware and software limits.
- Use Motion Analyzer to size your Motor/Drive combination with sufficient margin. We recommend that you monitor motor capacity when commissioning the axis.

Additionally, you should monitor the drive's motor capacity in case of unexpected obstruction or axis mechanical failures. Take the following steps to monitor the motor capacity:

- Make sure the Position Error Tolerance is set appropriately for your axis.
- Turn on Motor Capacity Real Time Attribute on the Axis Properties Drive/Motor tab.
- Determine your worst case expected axis.MotorCapacity during normal axis operation.
- In your application run-time code, monitor the axis.MotorCapacity real time attribute. Drive Foldback occurs when axis.MotorCapacity reaches 108% of rated continuous torque.
- Implement a program that brings your axis to a controlled stop before axis.MotorCapacity reaches 100%.

Configure Your Kinetix 6500 EtherNet/IP Servo Drive with RSLogix 5000 Software

For each linear thruster that is powered by a Kinetix 6500 servo drive use the next four sections to configure, hookup test, tune, fine tune and set up homing for the linear thruster.

This procedure assumes the linear thruster and a Kinetix 6500 servo drive has been installed and wired as one axis of the motion system.

For help using RSLogix 5000 software as it applies to setting up your linear thruster, refer to [Additional Resources](#) on [page 78](#). This procedure assumes you are familiar with RSLogix 5000 software.

Configure

Follow these steps to configure your drive for the linear thruster.

1. Loosen the shipping and handling set screw till it is just flush with the stator body surface.
2. Run the RSLogix 5000 software.
3. Complete the basic system configuration to create an axis.
4. From the Motor category click Change Catalog.
5. Select your linear thruster from the Change Catalog Number dialog box.
6. From the Scaling category set the Units to mm.

Hookup Test

If possible, run hookup test before the linear thruster loads or fixtures are installed. Vertical loads or external forces of more than 10% of the rated load may prevent hookup test from passing, even though the unit is wired correctly.

Follow steps to do a hookup test for the linear thruster.

1. Set the Test Distance to 60 mm.
2. Click Start.
3. Verify that the Motor Polarity, Feedback Polarity and Motion Polarity are normal.

Tune

The linear thruster is a direct drive actuator. Tuning the linear thruster establishes a stable axis.



ATTENTION: Before you tune your linear thruster read and understand [Preventing Undetected and Repetitive High Energy Impacts](#) and [Preventing Reduced Dynamic Control Performance on page 39](#)

Follow these steps to tune the linear thruster.

1. Attach your application load to the linear thruster.
2. From the Autotune category enter the following recommended tuning parameters.

Parameter	Entry/Selection
Application Type	Basic
Loop Response	Medium
Load Coupling	Compliant

3. Click Start.

Fine Tune

Use the facilities in the Tune, Velocity, Position and Accelerations Loop categories to meet your specific application requirements.

Home

The Kinetix 6500 drive does not support Home-to-Torque homing. Use this link to the Sample Code Library to download the AOI file called CIP Home to Torque.

http://samplecode.rockwellautomation.com/idc/groups/public/documents/webassets/sc_legal_info.hcst?dID=75636

Configure Your Kinetix 300 EtherNet/IP Servo Drive with MotionView Software

For each linear thruster that is powered by a Kinetix 300 servo drive use the next four sections to configure, hookup test, tune, fine tune and set up homing for the linear thruster.

These procedure assumes the linear thruster and a Kinetix 300 servo drive has been installed and wired as one axis of the motion system. Linear thrusters with the absolute encoder option require the use of the supplied feedback connector LDAT-CONKIT-ABS.

For help using MotionView software as it applies to setting up your linear thruster, refer to [Additional Resources](#) on [page 78](#). This procedure assumes you are familiar with MotionView software.

Configure

Follow these steps to configure your drive for linear thrusters.

1. Loosen the shipping and handling set screw till it is just flush with the stator body surface.
2. Run the MotionView software.
3. From the Motor category, click Change Motor.
For linear thruster with absolute encoders skip to step 6.
4. From the Vendor pull-down menu, select Allen-Bradley Linear.
5. From the Motor Model pull-down menu, select your linear thruster catalog number.
6. Click Update Drive.
7. Click Yes.

Hook up Test

Follow these steps to do a hookup test for the linear thruster with an incremental encoder.



ATTENTION: This procedure causes the linear thruster to move in the negative direction.

1. Position the slider in the center of travel.

- From the Motor category, set the Feedback>Encoder parameters to the following.

Parameter	Value
Resolution (x1)	20 μm
Resolution (x4)	5 μm
Halls order	3
Inverted	Checked
B lead A for forward	Unchecked

- From the Motor category, click Check Phasing.

Tune with Absolute Encoder

The linear thruster is a direct drive actuator. Tuning the linear thruster establishes a stable axis.



ATTENTION: Before you tune your linear thruster read and understand [Preventing Undetected and Repetitive High Energy Impacts](#) and [Preventing Reduced Dynamic Control Performance on page 39](#)

Follow these steps to tune the linear thruster with an absolute encoder.

- Attach your application load to the linear thruster.
- From the General category, set the Drive Mode to Auto Tune.
- From the Dynamics category, set the Feedback Filter to On.
- Enable drive.
- Click Autotuning.
- We recommend you check Position Tuning and Velocity Tuning.
- Set the Travel Limit to 50.0 User Units.
- Click Start.
The linear thruster will oscillate.
- To accept the autotune parameters, click Yes.
- Adjust the Gain Scaling by adding -1.
- Set the Feed back Filter to Off

Tune with Incremental Encoder

The linear thruster is a direct drive actuator. Tuning the linear thruster establishes a stable axis.



ATTENTION: Before you tune your linear thruster read and understand [Preventing Undetected and Repetitive High Energy Impacts](#) and [Preventing Reduced Dynamic Control Performance on page 39](#)

Follow these steps to tune the linear thruster with an incremental encoder.

1. Attach your application load to the linear thruster.
2. From the General category, set the Drive Mode to Auto Tune.
3. From the Dynamics category, set the Feedback Filter to On.
4. Set the Feedback Filter Time Constant to 1 ms.
5. Enable the drive.
6. Click Autotuning.
7. We recommend you check Position Tuning and Velocity Tuning.
8. Set the Travel Limit to 50.0 User Units.
9. Click Start.

The linear thruster will oscillate.

10. To accept the autotune parameters, click Yes

Fine Tune

To increase the precision of the positioning of your linear thruster use the Position I-Gain and increase the Position I-Limit to a value > 1.

Home

To home your linear thruster with an incremental encoder you must have a home switch installed. We recommend you wire a home switch to Input B1.

Follow these steps to home the linear thruster.

1. Disable the axis.
2. From the General category set Drive Mode to Indexing.

- From the Homing category enter the following.

Parameter	Value
Home Accel/Decel	1000 mm/s/s
Home Offset	10 mm
Home Velocity Fast	25 mm/s
Home Velocity Slow	5 mm/s
Home Method	Switch - Marker (chose one appropriate for your application)

Configure Your Servo Drive with Ultraware Software

These steps assume that a linear thruster and a Ultra3000 or Kinetix 3 drive are installed and wired as one axis of a motion system.

For help using Ultraware software as it applies to setting up your linear thruster, refer to [Additional Resources](#) on [page 78](#). This procedure assumes you are familiar with Ultraware software.

Configure

Follow these steps to configure your drive for linear thrusters.

- Connect a serial cable to your drive.
- Apply AC input power to the drive.
When communication with the drive is established, the motor database dialog box opens.
- Click Cancel.
Ultraware software begins scanning for online drives. When a drive is found, an Online Drive icon opens in the Workspace.
- Double-click the Online Drive icon to view the main Drive setup dialog box.
- From the Workspace, select Motor category.
- Change the parameter Auto Motor Iden to Disabled.
- From the Motor Model pull-down menu, select your linear thruster catalog number.

Hookup Test

Run the hookup test before the linear thruster loads or fixtures are installed. Vertical loads or external forces of more than 10% of the rated load may prevent the hookup test from passing, even though the unit is wired correctly.

Follow these steps to do the hookup test for the linear thruster.

1. From the Motor category, click Commutation Diagnostics.
2. Set the parameter Test Current to 25%.
3. Click Start Test.
The slider will move approximately 60 mm (2.4 in.).
4. Verify that the Test Status displays Test Success.
5. Verify that the Recommended Changes displays No Change Required.

Tune

The linear thruster is a direct drive actuator. Tuning the linear thruster establishes a stable axis.



ATTENTION: Before you tune your linear thruster read and understand [Preventing Undetected and Repetitive High Energy Impacts](#) and [Preventing Reduced Dynamic Control Performance on page 39](#)

Follow these steps to tune the linear thruster.

1. From the Workspace, select Tuning.
2. Click Autotuning.
3. Set the parameters to the following values.

Parameter	Value
Motor Direction	Bi-Directional
Maximum Distance	10000 counts
Step Current	10%

4. Click Start Autotune.
The Velocity Regulator Gains changes to reflect autotune values.
The Autotune Complete status indicator turns yellow.

Home

Follow these steps to home the linear thruster.

1. From the Workspace, select Mode Configuration>Homing.
2. Set the parameters to the following values.

Parameter	Value
Home Type	Home to Current Value/Back to Marker
Auto Start Homing on Enable	Inactive
Home Sensor Back-off	Inactive
Homing Velocity	-0.0100 m/s
Homing Accel/Decel	1.0000 m/s/s
Offset Move Distance	2000.0000 counts
Stop Home Decel	1.0000 m/s/s
Home Sensor Polarity	Active Going Transition
Home Position	0.000 counts
Creep Velocity	0.0100 m/s
Home Current Value	2.0000 Amps

If linear thruster does not move to negative spring stop during homing it may be necessary to increase the Home Current Value.

3. From the Workspace, select Indexing.
4. Set the parameter Auto Start Index to Off.
5. Click Indexing Control Panel.
6. Click Enable Drive.
7. Click Start Homing.

The linear thruster moves to the negative spring stop and returns to the home position.

The In Position and At Home display indicators turn yellow.

Setting Travel Limits

Linear thrusters are designed to use the software overtravel limits available in RSLogix 5000 and Ultraware software.

Overtravel limits should be set according to the maximum speed of the servo drive system and the payload of the application. The Deceleration Distance before the slide contacts the end-of-travel bumpers can be determined based on the Deceleration Rate of the load, and the available peak force from the stage-drive combination. Then use Motion Analyzer software to calculate the minimum deceleration distance at the maximum speed of your application. ⁽¹⁾

Software overtravel limits are preferred for these reasons.

- Hard-wired overtravel limit switches are typically located in a position that does not allow the linear stage to decelerate before mechanical damage occurs.
- Software overtravel limit switches can be precisely set, based on maximum speed and load inertia. The stage will come to a complete stop before physical damage occurs.

In addition to software overtravel limits, the end of travel bumpers for the linear stage will stop the carriage up to the ratings listed in the table.

Bumper Stop Energy Limits for Linear Thruster End of Travel

Cat. No.	Energy Limit J (in-lb)
LDAT-S03xxxx	2.5 (22.48)
LDAT-S05xxxx	
LDAT-S07xxxx	

Cat. No.	Energy Limit J (in-lb)
LDAT-S10xxxx	8.19 (72.50)
LDAT-S15xxxx	19.2 (170.00)



ATTENTION: If energy greater than the bumper capacity is anticipated in the application, you must provide additional mechanical means for safely stopping the slider.

To calculate kinetic energy of the carriage with your payload use the formula:

$$\left(J = \frac{1}{2} \times M \times V^2 \right)$$

J = energy in Joules

M = moving mass (linear carriage + payload) [kg]

V = maximum velocity of stage in your application [m/s] ⁽¹⁾

(1) Velocity and kinetic energy can be much higher due to uncontrolled, worst-case motion that is only constrained by the length of stroke and the power capacity of the motor-drive pairing.

Slider Moving Mass

Frame 30

LDAT Cat. No.	Slider Moving Mass kg (lb)
LDAT-S031010-xxx	2.8 (6.23)
LDAT-S031020-xxx	3.4 (7.56)
LDAT-S031030-xxx	4.0 (8.90)
LDAT-S031040-xxx	4.6 (10.23)
LDAT-S032010-xxx	3.4 (7.56)
LDAT-S032020-xxx	4.0 (8.90)

Frame 50

LDAT Cat. No.	Slider Moving Mass kg (lb)
LDAT-S051010-xxx	4.5 (9.89)
LDAT-S051020-xxx	5.4 (11.99)
LDAT-S051030-xxx	6.4 (14.10)
LDAT-S051040-xxx	7.4 (16.21)
LDAT-S051050-xxx	8.3 (18.32)
LDAT-S052010-xxx	5.4 (11.99)
LDAT-S052020-xxx	6.4 (14.10)
LDAT-S052030-xxx	7.4 (16.21)
LDAT-S052040-xxx	8.3 (18.32)
LDAT-S052050-xxx	9.3 (20.42)

Frame 75

LDAT Cat. No.	Slider Moving Mass kg (lb)
LDAT-S072010-xxx	7.1 (15.62)
LDAT-S072020-xxx	8.3 (18.30)
LDAT-S072030-xxx	9.5 (20.99)
LDAT-S072040-xxx	10.7 (23.67)
LDAT-S072050-xxx	12.0 (26.35)
LDAT-S072060-xxx	13.2 (29.03)
LDAT-S072070-xxx	14.4 (31.72)
LDAT-S073010-xxx	8.3 (18.30)
LDAT-S073020-xxx	9.5 (20.99)
LDAT-S073030-xxx	10.7 (23.67)
LDAT-S073040-xxx	12.0 (26.35)
LDAT-S073050-xxx	13.2 (29.03)
LDAT-S073060-xxx	14.4 (31.72)

LDAT Cat. No.	Slider Moving Mass kg (lb)
LDAT-S032030-xxx	4.6 (10.23)
LDAT-S032040-xxx	5.2 (11.57)
LDAT-S033010-xxx	4.0 (8.90)
LDAT-S033020-xxx	4.6 (10.23)
LDAT-S033030-xxx	5.2 (11.57)
LDAT-S033040-xxx	5.9 (12.91)

LDAT Cat. No.	Slider Moving Mass kg (lb)
LDAT-S053010-xxx	6.4 (14.10)
LDAT-S053020-xxx	7.4 (16.21)
LDAT-S053030-xxx	8.3 (18.32)
LDAT-S053040-xxx	9.3 (20.42)
LDAT-S053050-xxx	10.2 (22.53)
LDAT-S054010-xxx	7.4 (16.21)
LDAT-S054020-xxx	8.3 (18.32)
LDAT-S054030-xxx	9.3 (20.42)
LDAT-S054040-xxx	10.2 (22.53)
LDAT-S054050-xxx	11.2 (24.64)

LDAT Cat. No.	Slider Moving Mass kg (lb)
LDAT-S073070-xxx	15.6 (34.40)
LDAT-S074010-xxx	9.5 (20.99)
LDAT-S074020-xxx	10.7 (23.67)
LDAT-S074030-xxx	12.0 (26.35)
LDAT-S074040-xxx	13.2 (29.03)
LDAT-S074050-xxx	14.4 (31.72)
LDAT-S074060-xxx	15.6 (34.40)
LDAT-S074070-xxx	16.8 (37.08)
LDAT-S076010-xxx	12.0 (26.35)
LDAT-S076020-xxx	13.2 (29.03)
LDAT-S076030-xxx	14.4 (31.72)
LDAT-S076040-xxx	15.6 (34.40)
LDAT-S076050-xxx	16.8 (37.08)

Frame 100

LDAT Cat. No.	Slider Moving Mass kg (lb)
LDAT-S102010-xxx	11.3 (24.84)
LDAT-S102020-xxx	13.3 (29.21)
LDAT-S102030-xxx	15.2 (33.59)
LDAT-S102040-xxx	17.2 (37.96)
LDAT-S102050-xxx	19.2 (42.34)
LDAT-S102060-xxx	21.2 (46.72)
LDAT-S102070-xxx	23.2 (51.09)
LDAT-S102080-xxx	25.2 (55.47)
LDAT-S102090-xxx	27.1 (59.84)
LDAT-S103010-xxx	13.3 (29.21)
LDAT-S103020-xxx	15.2 (33.59)
LDAT-S103030-xxx	17.2 (37.96)
LDAT-S103040-xxx	19.2 (42.34)
LDAT-S103050-xxx	21.2 (46.72)
LDAT-S103060-xxx	23.2 (51.09)
LDAT-S103070-xxx	25.2 (55.47)
LDAT-S103080-xxx	27.1 (59.84)
LDAT-S103090-xxx	29.1 (64.22)

LDAT Cat. No.	Slider Moving Mass kg (lb)
LDAT-S104010-xxx	15.2 (33.59)
LDAT-S104020-xxx	17.2 (37.96)
LDAT-S104030-xxx	19.2 (42.34)
LDAT-S104040-xxx	21.2 (46.72)
LDAT-S104050-xxx	23.2 (51.09)
LDAT-S104060-xxx	25.2 (55.47)
LDAT-S104070-xxx	27.1 (59.84)
LDAT-S104080-xxx	29.1 (64.22)
LDAT-S104090-xxx	31.1 (68.60)
LDAT-S106010-xxx	19.2 (42.34)
LDAT-S106020-xxx	21.2 (46.72)
LDAT-S106030-xxx	23.2 (51.09)
LDAT-S106040-xxx	25.2 (55.47)
LDAT-S106050-xxx	27.1 (59.84)
LDAT-S106060-xxx	29.1 (64.22)
LDAT-S106070-xxx	31.1 (68.60)
LDAT-S106080-xxx	33.1 (72.97)
LDAT-S106090-xxx	35.1 (77.35)

Frame 150

LDAT Cat. No.	Slider Moving Mass kg (lb)
LDAT-S152010-xxx	17.2 (37.85)
LDAT-S152020-xxx	20.2 (44.54)
LDAT-S152030-xxx	23.2 (51.23)
LDAT-S152040-xxx	26.3 (57.92)
LDAT-S152050-xxx	29.3 (64.61)
LDAT-S152060-xxx	32.3 (71.30)
LDAT-S152070-xxx	35.4 (77.99)
LDAT-S152080-xxx	38.4 (84.68)
LDAT-S152090-xxx	41.4 (91.36)
LDAT-S153010-xxx	20.2 (44.54)
LDAT-S153020-xxx	23.2 (51.23)
LDAT-S153030-xxx	26.3 (57.92)
LDAT-S153040-xxx	29.3 (64.61)
LDAT-S153050-xxx	32.3 (71.30)
LDAT-S153060-xxx	35.4 (77.99)
LDAT-S153070-xxx	38.4 (84.68)
LDAT-S153080-xxx	41.4 (91.36)
LDAT-S153090-xxx	44.5 (98.05)

LDAT Cat. No.	Slider Moving Mass kg (lb)
LDAT-S154010-xxx	23.2 (51.23)
LDAT-S154020-xxx	26.3 (57.92)
LDAT-S154030-xxx	29.3 (64.61)
LDAT-S154040-xxx	32.3 (71.30)
LDAT-S154050-xxx	35.4 (77.99)
LDAT-S154060-xxx	38.4 (84.68)
LDAT-S154070-xxx	41.4 (91.36)
LDAT-S154080-xxx	44.5 (98.05)
LDAT-S154090-xxx	47.5 (104.74)
LDAT-S156010-xxx	29.3 (64.61)
LDAT-S156020-xxx	32.3 (71.30)
LDAT-S156030-xxx	35.4 (77.99)
LDAT-S156040-xxx	38.4 (84.68)
LDAT-S156050-xxx	41.4 (91.36)
LDAT-S156060-xxx	44.5 (98.05)
LDAT-S156070-xxx	47.5 (104.74)
LDAT-S156080-xxx	50.5 (111.43)
LDAT-S156090-xxx	53.6 (118.12)

Maintenance

In this section, you will find information on lubrication, cleaning, and storing your linear thruster.

Lubrication

Your linear thruster has been lubricated at the factory and is ready for installation. Use the appropriate lubrication interval shown below for schedule estimates or use Motion Analyzer software to calculate the recommended re-grease schedule for the linear thruster.

Before You Begin

You will need the following tools to clean and lubricate your linear stage.



ATTENTION: Lockout and tagout input power before servicing.

- Grease pump kit (catalog number MPAS-GPUMP) with tip type installed and primed
- Grease cartridge (catalog number MPAS-CART), included in grease pump kit.
- Lint free cloth
- Isopropyl alcohol, as necessary for cleaning

TIP A grease gun typically delivers one gram of lubricant for one pump of the gun.


Recommended Maintenance Interval

Recommended maintenance and lubrication interval for frame 50, 75, 100, and 150 linear thrusters is every 6 months or 5000 km of travel, whichever comes first. Frame 30 linear thrusters are lubricated for life.

Bearing Lubrication

Lubricate the linear thruster bearings as shown and described below.

Use the MP-Series™ Integrated Linear Stage grease pump kit, (catalog number MPAS-GPUMP), and additional grease cartridges as necessary.



1. If your linear thruster has the strip cover option, remove it by following the procedure on page [67](#)
2. Clean grease from the bearing by using clean lint free cloth and isopropyl alcohol.
3. Place the grease pump on the grease fitting just inside the stator housing, pushing in until firm contact with the grease fitting is made.
4. Pump the handle until back pressure is felt, or a maximum of two strokes is made.
5. Repeat steps 1 and 3 on all grease fittings.

If your linear thruster has a strip cover install it by following the next steps.

6. Carefully slide the slider cover the through the plastic end-caps centering it on the linear thruster.



ATTENTION: The slider cover has sharp edges. Use care when handling.

7. Clean all screws and apply fresh Loctite 242 to them.
8. Install the end clamps with the M3 x 0.5 x 6 mm button head cap screws.
9. Install the stator cover with the M3 x 0.5 x 6 mm flat head cap screws.
10. Torque all screws to 1.1 N•m (10 lb•in).

Strip Cover Cleaning

Clean the strip cover, if installed, using a lint free cloth lightly saturated with isopropyl alcohol.

IMPORTANT

Replace the strip cover if it cannot be cleaned, or if an uneven or scored surface is detected during cleaning.

A buildup of foreign material on the strip cover degrades the performance of the linear thruster. This buildup coupled with rapid movement of the slider and the resulting friction will score the surface and create a burnished appearance on the strip cover.

Elements contributing to a typical buildup on the strip covers are dust, grease, and other contaminants normally encountered in any operating environment that is not strictly controlled.

Storage

Store your linear thruster for a minimal amount of time in a clean and dry location within the Environmental Specifications on [page 77](#).

Observe these conditions when storing the linear thruster:

- Be sure the equipment is in good working order before storing. Perform repairs, maintenance, and inspections before storing equipment.
- Store the equipment in a suitable storage position (horizontal) that will prevent damage to the connectors and electronics.
- After six months of storage, cycle the linear thruster two complete strokes to redistribute the internal lubricants.
- After storage for a period longer than two years without use, lubricant replacement is recommended, contact Rockwell Automation Technical Support.

Troubleshooting

Use this table to troubleshoot your linear thruster.

Troubleshooting Linear Thrusters


Description	Possible Cause	Corrective Action
Noises or vibrations	Linear thruster mounting is not fastened properly.	Verify correct mounting and torques
	Load or mounting accessory fixture is not fastened properly.	
	Linear thruster not tuned	Tune linear thruster
	Bearing wear	Replace bearings
Excess slider friction or rubbing	Linear thruster is not mounted to a flat rigid surface per mounting guidelines.	Review mounting guidelines
	Improper fastening of mounting feet accessories.	Review mounting instructions.
	Metal debris or hardware on magnet surface of slider.	Remove debris.
	Debris on strip cover	Clean strip cover
	Debris or loose hardware on slider bearings	Remove debris from using masking tape
	Bearing wear	Replace bearings
No response from linear thruster	Controller or drive not enabled	Enable controller and drive
	Controller or drive faulted	Reset the controller or drive
	Improper or failed wiring	Verify correct wiring
Linear thruster is enabled but operating erratically or not at all.	Motor Feedback Cable connection may be faulty or intermittent	Run Hookup Test, verify wiring
	Encoder magnetic strip is damaged	Verify function of linear encoder over full range of travel. If a particular location is malfunctioning, replace incremental encoder magnetic scale. If using an absolute encoder, return for repair.

Troubleshooting Linear Thrusters (continued)

Description	Possible Cause	Corrective Action
Linear thruster is operating but is not up to rated force. Actuator is overheating.	Unexpectedly high moving mass or acceleration	Verify moving load mass and acceleration are within specification and adjust as necessary.
	Unexpectedly high force	Verify mechanical alignment with external guidance.
	Incorrect drive	Verify that the drive can support linear thruster continuous and peak current requirements.
	Incorrect motor catalog Number in RSLogix Software configuration	Verify motor catalog number in software matches linear thruster nameplate
	Motor wiring	Check motor power cable for short circuit.
Linear thruster is operating but is not up to rated speed.	Incorrect motor catalog number in RSLogix software configuration	Verify motor catalog number in software matches linear thruster nameplate
	Drive bus voltage is too low.	Check drive has rated bus voltage.
Linear thruster cannot move load	Force is too large for the capacity of the linear thruster and drive	Verify force requirements
		Verify that the drive can support linear thruster continuous and peak current requirements.
	Incorrect motor catalog Number in RSLogix Software configuration	Verify motor catalog number in software matches linear thruster nameplate
Kinetix 300 drive displays E07 while using linear thruster with absolute feedback option	Not using correct feedback connector accessory	Install un-terminated motor feedback cable with LDAT-CONKIT-ABS connector kit

Accessories

This diagram depicts the accessories available for the linear thrusters. Tables list the catalog number and weight for each accessory. Refer to the Kinetix Linear Motion Technical Data, publication [GMC-TD002](#), for dimensions.



(1) Size and purchase spring according to your application needs. Guidance provided in Kinetix Linear Motion Technical Data, publication [GMC-TD002](#).

Mounting Accessories

Accessory Item	Frame	Cat. No.	Weight, approx g (oz)
1 Foot Mount	30	LDAT-SMID-FTMOUNT	30 (1.06)
	50		
	75		
	100	LDAT-SLARGE-FTMOUNT	40 (1.41)
	150		
2 Clevis, Male	30	LDAT-S03-CLVSM	100 (3.53)
	50	LDAT-S0507-CLVSM	150 (5.29)
	75		
	100	LDAT-S1015-CLVSM	370 (13.05)
	150		

Mounting Accessories (continued)

Accessory Item		Frame	Cat. No.	Weight, approx g (oz)
3	Clevis, Female	30	LDAT-S03-CLVSF	75 (2.65)
		50	LDAT-S0507-CLVSF	100 (3.53)
		75		
		100	LDAT-S1015-CLVSF	250 (8.82)
		150		

Slider-end Accessories


Accessory Item		Frame	Cat. No.	Weight, approx g (oz)
4	Rod Clevis Kit	30	LDAT-S03-RODCLV	190 (6.70)
		50	LDAT-S0507-RODCLV	320 (11.29)
		75		
		100	LDAT-S1015-RODCLV	770 (27.16)
		150		
5	Rod Eye Kit	30	LDAT-S03-RODEYE	150 (5.29)
		50	LDAT-S0507-RODEYE	260 (9.17)
		75		
		100	LDAT-S1015-RODEYE	590 (20.81)
		150		
6	Rod Coupler Kit	30	LDAT-S03-RODCPLR	290 (10.05)
		50	LDAT-S0507-RODCPLR	370 (13.05)
		75		
		100	LDAT-S1015-RODCPLR	1030 (36.33)
		150		
7	Horizontal Payload Mounting Bracket	30	LDAT-S03-HPBRKT	260 (9.17)
		50	LDAT-S0507-HPBRKT	430 (15.17)
		75		
		100	LDAT-S10-HPBRKT	910 (32.10)
		150	LDAT-S15-HPBRKT	1300 (54.86)
8	Counterbalance Kit	30	LDAT-S03-CBRKT	380 (13.4)
		50	LDAT-S0507-CBRKT	600 (21.2)
		75		
		100	LDAT-S10-CBRKT	950 (33.5)
		150	LDAT-S15-CBRKT	1160 (40.9)

Replacement Parts

This is the catalog explanation for the LDAT-Series linear thruster bearing and strip cover replacement parts.

Bearing and Strip Cover Replacement Parts

LDAT - S xx x xxx -xxx



Encoder Replacement Components

Cat. No.	Description
LDAT-TTL-ENC	TTL Incremental encoder
LDAT-TTL-SCALE	Encoder scale tape, 170 cm (67 in.)

Cat. No.	Description
MPAS-GPUMP	Grease pump kit
MPAS-CART	Grease cartridge

Install Replacement Parts

Be sure to have all replacement parts and tools available before starting this procedure. Read and understand procedures before attempting repair any part of the linear thruster.

You will require a set of hex wrenches to preform most tasks. You will require a T10 Torx driver to replace the encoder.

Replace the Bearing

1. Disassemble the linear thruster by following procedure on page [60](#).
2. Remove the bearing by following procedure on page [65](#).
3. Install the bearing by following procedure on page [65](#).
4. Assemble the linear thruster by following procedure on page [63](#).

Replace the Encoder

1. Remove the encoder by following procedure on page [68](#).
2. Install the encoder by following procedure on page [68](#).
3. Check the encoder by following procedure on page [69](#).
4. Run the Hookup test by following procedure on page [70](#).

Replace the Encoder Scale


1. Disassemble the linear thruster by following procedure on page [60](#).
2. Remove the encoder scale by following procedure on page [70](#).
3. Mount the encoder scale by following procedure on page [68](#).
4. Assemble the linear thruster by following procedure on page [63](#).
5. Check the encoder by following procedure on page [69](#).
6. Do the Hookup test by following procedure on page [70](#).

Disassemble the Linear Thruster


Follow this procedure to disassemble your linear thruster.

TIP Use non-magnetic tools and hardware made of beryllium copper, 300 series stainless steel. If these tools are not available, proceed carefully as the magnet track attracts magnetic and ferrous items.

1. If your linear thruster has the strip cover, option follow Remove Strip Cover procedure on page [67](#).
2. Loosen the shipping and handling set screw.
3. Remove the coil screws.




4. Remove the bearing screws.
There are four screws per bearing.




5. Remove the connector side stator end cap.

There are five screws on the perimeter of the end cap.




6. Remove the slider end cap opposite the connector side.



7. Remove the end stop bracket.

8. Remove screws that mount the power and feedback connectors to the stator body.



9. Slide the connectors out of the stator body.


10. Slide the slider and coil assembly from the stator body until the internal encoder connector is exposed.

Complete this step without affecting the position of the coil on the slider.



ATTENTION: The coil is held to the magnet track on the slider by the magnetic forces. Do not allow it to move or attempt to move it while attempting repairs. Moving the coil will make reassembly difficult.

11. Disconnect the internal encoder connector.



12. Remove the slider assembly and coil completely from the stator body.

Assemble the Linear Thruster

Follow this procedure to assemble your linear thruster. Use the figures from the disassemble procedure as a reference.

1. Slide the slider and coil assembly into the stator body.
2. Connect the encoder connectors when they are close enough.
3. Carefully stuff the feedback then power cables into the stator body.



ATTENTION: The coil is held to the magnet track on the slider by the magnetic forces. Do not allow it to move or attempt to move it while attempting repairs. Moving the coil will make reassembly difficult.

Be sure the cables are not touching the slide assembly.



ATTENTION: Be sure the cables do not come in contact with the slider assembly when completing the assembly. Contact with moving parts will cause damage to the cables and premature failure of the linear thruster.

4. Loosely attach the coil to the stator body.


5. Align the first bearing puck to the first set of bearing mounting holes on the connector side of the stator body.
6. Loosely install the bearing puck screws.
7. Slide another bearing puck on to the bearing rail.
8. Align with set mounting holes next to the previous bearing puck.
9. Loosely attach the bearing puck.
10. Repeat step [7...9](#) until all the bearing pucks are installed.
11. Torque the bearing puck screws to values shown.

Mounting Screw Size	Torque N•m (lb•in)
M3	1.1 (10)
M4	2.8 (25)
M5	4.5 (40)
M6	9.5 (84)
M8	24 (212)

12. Torque the bearing rail screws to value shown in previous step.
13. Attach the connectors to the stator body.
14. Attach the end stop bracket to the slider assembly.
15. Check the cable clearance in stator body.
Slide the slider assembly and verify the cables do not come in contact with it.
16. Attach the stator end cap.
17. If your linear thruster has the strip cover option, install the cover by following the Remove Strip Cover procedure on page [67](#) in reverse.

Remove Bearing


1. Remove the screws securing the bearing rail to the slider assembly.
Position the bearing pucks out of your way as necessary.




2. Remove the bearing rail.

Install Bearing

1. Clean the bearing mounting and banking surface with isopropyl alcohol and a soft clean cloth.
2. Loosely install the new bearing rail.



3. Bank the bearing rail against the bearing alignment surface.



4. Torque to values shown in the table starting from the center screws alternating each side.

Bearing Screw Size	Torque N·m (lb·ft)
M3	0.9 (0.67)
M4	1.7 (1.25)
M5	4.5 (3.33)
M6	6.8 (5.00)
M7	14.7 (10.83)

5. Slide one bearing puck on to the bearing rail.


IMPORTANT

Bearing pucks for the frame 30 linear thruster do not have retained ball bearings. Leave the plastic bearing retainer in place until you are ready to assemble the puck to the rail. To assemble the frame 30 bearing pucks, do the following.

- a. Butt the plastic retainer against end of the rail.
- b. Slide the bearing from the retainer to the rail.

Remove Strip Cover

Refer to this figure when removing the strip cover.



Item	Description
1	Stator cover
2	Stator cover low friction tape
3	Stator body low friction tape

Item	Description
4	End clamp
5	Slider cover

1. Remove the M3 x 0.5 x 6 mm flat-head cap screws and the stator cover.
2. Remove the M3 x 0.5 x 6 mm button-head cap screws and the end clamps.
3. Carefully slide the slider cover from the assembly.




ATTENTION: The slider cover has sharp edges. Use care when handling.

4. If you are removing the strip cover to lubricate the linear thruster, you are finished.
5. If you are replacing the strip cover, do the following.
Peel off the low-friction tape from the stator body and the stator cove and discard.

Remove Encoder

1. Remove the Allen-Bradley decal from the encoder bracket.



2. Remove the six screws that secure the encoder bracket to the stator body by using a Torx T10 driver.

IMPORTANT


Use only the proper size and type of driver to remove the encoder bracket screws or you will damage the screw heads.

3. Remove the encoder bracket assembly.
This exposes the encoder connector.
4. Disconnect the encoder.
5. Remove the encoder from encoder bracket.

Install the Encoder

1. Remove the two M8 set screws furthestmost from the connectors on top of stator body.
This allows access to the encoder screws while encoder is installed.
2. Loosely install the new encoder on encoder bracket.
Orient the encoder on the encoder bracket such that the cables exit towards the feedback connector.
3. Connect the encoder cable.
4. Install the encoder bracket assembly.

5. Slide the provided shim along the encoder scale, under the plastic seal into the linear thruster from the connector end.



6. Insert a tool through the encoder access hole and press the encoder against the shim.
7. Tighten the encoder screws with a 2.5 mm hex driver.
8. Remove the shim.
It should be difficult to return the shim beneath the encoder once removed.
9. Move the slider from spring stop to spring stop to verify that the encoder does not rub the scale.
10. Replace the two M8 set screws.

Check Encoder

1. Run RSlogix 5000 software.
2. Click Controller test category.
3. Click Controller tags.
4. Click [+] to expand the axis for you linear thruster.
5. Click Monitor Tags tab.
6. Locate the axis tag ActualPosition.
You will monitor this tag while doing the next step.
7. Move the linear thruster through its entire range of motion.
Verify the position readout does not miscount.

Hookup Test

1. Run RSlogix 5000 software.
2. Double-click on the axis to show the Axis Properties for your linear thruster.
3. Click Hookup tab.
4. Set Test Increment to 60 mm.
5. Click Test Feedback.

Follow prompts to complete the test.

Remove Encoder Scale

1. Remove the scale and stainless steel backer.
2. Clean the scale alignment groove with isopropyl alcohol to remove all of the adhesive residue.
3. Dry thoroughly.

Install Encoder Scale

1. Place the paper-backed scale into the groove.
2. Mark off a length that is 0.8 mm (0.03 in.) shorter than the encoder scale groove length.
3. Repeat step 2 with the stainless steel backer.
4. Remove the paper backing from the stainless steel backer and place the backer in the groove.

IMPORTANT

Lay the stainless steel backer flat to the slider. If the scale is not flat, the encoder scale will rub on the encoder.


5. Remove the paper backing from the encoder scale tape and place the scale tape on the stainless steel backer.

Interconnect Diagrams



These wiring examples are for a linear thruster, specifically Allen-Bradley servo drives.

Note	Description								
1	<p>The preferred power cables are shown on illustration. These are alternate power cables that can be used with LDAT-Series linear thrusters:</p> <table> <tr> <td>2090-CPWM4DF-xxAFxx</td><td>Continuous flex, threaded DIN, with power only</td></tr> <tr> <td>2090-XXNPMF-16Sxx</td><td>Non-flex, threaded DIN, with power and brake</td></tr> <tr> <td>2090-CPBM7DF-16AAxx</td><td>Non-flex, SpeedTek, with power and brake</td></tr> <tr> <td>2090-CPBM7DF-16AFxx</td><td>Continuous flex, SpeedTek, with power and brake</td></tr> </table>	2090-CPWM4DF-xxAFxx	Continuous flex, threaded DIN, with power only	2090-XXNPMF-16Sxx	Non-flex, threaded DIN, with power and brake	2090-CPBM7DF-16AAxx	Non-flex, SpeedTek, with power and brake	2090-CPBM7DF-16AFxx	Continuous flex, SpeedTek, with power and brake
2090-CPWM4DF-xxAFxx	Continuous flex, threaded DIN, with power only								
2090-XXNPMF-16Sxx	Non-flex, threaded DIN, with power and brake								
2090-CPBM7DF-16AAxx	Non-flex, SpeedTek, with power and brake								
2090-CPBM7DF-16AFxx	Continuous flex, SpeedTek, with power and brake								
2	The preferred incremental feedback cables are shown on illustration. 2090-CFBM4DF-CDAFxx continuous flex, threaded DIN for an absolute or incremental encoder is an alternate incremental feedback cables that can be used with LDAT-Series linear thrusters.								
3	<p>The preferred absolute feedback cables are shown on illustration. These are alternate absolute feedback cables that can be used with LDAT-Series linear thrusters:</p> <table> <tr> <td>2090-CFBM7DF-CDAFxx</td><td>Continuous flex, SpeedTek for an absolute or incremental encoder</td></tr> <tr> <td>2090-XXNFMF-Sxx</td><td>Non-flex, threaded DIN, for an absolute or incremental encoder</td></tr> <tr> <td>2090-CFBM4DF-CDAFxx</td><td>Continuous flex, threaded DIN for an absolute or incremental encoder</td></tr> </table>	2090-CFBM7DF-CDAFxx	Continuous flex, SpeedTek for an absolute or incremental encoder	2090-XXNFMF-Sxx	Non-flex, threaded DIN, for an absolute or incremental encoder	2090-CFBM4DF-CDAFxx	Continuous flex, threaded DIN for an absolute or incremental encoder		
2090-CFBM7DF-CDAFxx	Continuous flex, SpeedTek for an absolute or incremental encoder								
2090-XXNFMF-Sxx	Non-flex, threaded DIN, for an absolute or incremental encoder								
2090-CFBM4DF-CDAFxx	Continuous flex, threaded DIN for an absolute or incremental encoder								
4	<p>Use motor power cables with 14 AWG conductors for these linear thruster catalog numbers:</p> <p>LDAT-S076xxx-Dxx LDAT-S106xxx-Dxx LDAT-S156xxx-Dxx</p> <p>All other linear thruster use power cables with 16 AWG conductors.</p>								


Wiring Example of a Linear Thrusters to a Kinetix 3 Drive




Wiring Example of a Linear Thrusters to a Kinetix 300 Drive



Wiring Examples for a Linear Thruster to an Ultra3000 Drive




Grounding Techniques for Feedback Cable Shield



Use 2090-K2CK-D15M connector with these drives:
Kinetix 2000
Kinetix 300 and linear thruster with incremental encoder

Use LDAT-CONNKIT-ABS connector with the Kinetix 300 drive and a linear thruster with an absolute encoder.

Use 2090-K6CK-D15M connector with the Kinetix 6000 drive.



Use 2090-UXBB-DM15 connector with Ultra3000 drives.

Specifications

Linear Thruster Weights

Linear Thruster (frame 30) Cat. No.	Weight, approx kg (lb)
LDAT-S031010-xx	6.9 (15.2)
LDAT-S031020-xx	7.5 (16.6)
LDAT-S031030-xx	8.1 (17.9)
LDAT-S031040-xx	8.7 (19.2)

Linear Thruster (frame 50) Cat. No.	Weight, approx kg (lb)
LDAT-S051010-xx	10.3 (22.7)
LDAT-S051020-xx	11.3 (24.8)
LDAT-S051030-xx	12.2 (26.9)
LDAT-S051040-xx	13.2 (29.0)
LDAT-S051050-xx	14.1 (31.7)
LDAT-S052010-xx	14.6 (32.2)
LDAT-S052020-xx	15.6 (34.3)

Linear Thruster (frame 75) Cat. No.	Weight, approx kg (lb)
LDAT-S072010-xx	17.7 (39.1)
LDAT-S072020-xx	18.9 (41.8)
LDAT-S072030-xx	20.2 (44.4)
LDAT-S072040-xx	21.4 (47.1)
LDAT-S072050-xx	22.6 (49.8)
LDAT-S072060-xx	23.8 (52.2)
LDAT-S072070-xx	25.0 (55.2)
LDAT-S073010-xx	23.0 (50.7)
LDAT-S073020-xx	24.2 (53.3)
LDAT-S073030-xx	25.4 (56.0)

Linear Thruster (frame 30) Cat. No.	Weight, approx kg (lb)
LDAT-S032010-xx	9.7 (21.5)
LDAT-S032020-xx	10.3 (22.8)
LDAT-S032030-xx	10.9 (24.1)
LDAT-S032040-xx	11.6 (25.5)

Linear Thruster (frame 50) Cat. No.	Weight, approx kg (lb)
LDAT-S052030-xx	16.5 (36.4)
LDAT-S052040-xx	17.5 (38.5)
LDAT-S052050-xx	18.4 (40.6)
LDAT-S053010-xx	18.9 (41.6)
LDAT-S053020-xx	19.8 (43.7)
LDAT-S053030-xx	20.8 (45.8)
LDAT-S053040-xx	21.8 (48.0)

Linear Thruster (frame 75) Cat. No.	Weight approx kg (lb)
LDAT-S073040-xx	26.6 (58.7)
LDAT-S073050-xx	27.8 (61.4)
LDAT-S073060-xx	29.1 (64.1)
LDAT-S073070-xx	28.2 (62.1)
LDAT-S074010-xx	30.3 (66.8)
LDAT-S074020-xx	29.4 (64.8)
LDAT-S074030-xx	30.6 (67.5)
LDAT-S074040-xx	31.8 (70.2)
LDAT-S074050-xx	33.1 (72.9)
LDAT-S074060-xx	34.3 (75.6)

Linear Thruster (frame 30) Cat. No.	Weight, approx kg (lb)
LDAT-S033010-xx	12.6 (26.9)
LDAT-S033020-xx	13.2 (30.4)
LDAT-S033030-xx	13.8 (31.7)
LDAT-S033040-xx	14.4 (31.7)

Linear Thruster (frame 50) Cat. No.	Weight, approx kg (lb)
LDAT-S053050-xx	22.7 (50.1)
LDAT-S054010-xx	23.3 (51.3)
LDAT-S054020-xx	24.2 (53.4)
LDAT-S054030-xx	25.2 (55.5)
LDAT-S054040-xx	26.1 (57.6)
LDAT-S054050-xx	27.1 (59.7)

Linear Thruster (frame 75) Cat. No.	Weight approx kg (lb)
LDAT-S074070-xx	35.5 (78.2)
LDAT-S076010-xx	38.6 (85.1)
LDAT-S076020-xx	39.8 (87.7)
LDAT-S076030-xx	41.0 (90.4)
LDAT-S076040-xx	42.2 (93.1)
LDAT-S076050-xx	43.5 (95.8)
LDAT-S076060-xx	44.7 (98.5)
LDAT-S076070-xx	45.9 (101.2)

Linear Thruster (frame 100) Cat. No.	Weight, approx kg (lb)	Linear Thruster (frame 100) Cat. No.	Weight approx kg (lb)	Linear Thruster (frame 100) Cat. No.	Weight approx kg (lb)
LDAT-S102010-xx	27.9 (61.5)	LDAT-S103040-xx	42.0 (92.1)	LDAT-S104070-xx	56.0 (123.3)
LDAT-S102020-xx	29.9 (65.8)	LDAT-S103050-xx	44.0 (96.9)	LDAT-S104080-xx	58.0 (127.9)
LDAT-S102030-xx	31.9 (70.2)	LDAT-S103060-xx	45.9 (101.3)	LDAT-S104090-xx	60.0 (132.3)
LDAT-S102040-xx	33.8 (74.6)	LDAT-S103070-xx	47.9 (105.6)	LDAT-S106010-xx	60.2 (132.7)
LDAT-S102050-xx	35.8 (79.0)	LDAT-S102080-xx	49.9 (110.0)	LDAT-S106020-xx	62.2 (137.1)
LDAT-S102060-xx	37.8 (83.4)	LDAT-S102090-xx	51.9 (114.4)	LDAT-S106030-xx	64.2 (141.5)
LDAT-S102070-xx	39.8 (87.7)	LDAT-S104010-xx	44.1 (97.3)	LDAT-S106040-xx	66.1 (145.8)
LDAT-S102080-xx	41.8 (92.1)	LDAT-S104020-xx	46.1 (101.7)	LDAT-S106050-xx	68.1 (150.2)
LDAT-S102090-xx	43.8 (96.9)	LDAT-S104030-xx	48.1 (106.1)	LDAT-S106060-xx	70.1 (154.6)
LDAT-S103010-xx	36.0 (79.4)	LDAT-S104040-xx	50.1 (110.4)	LDAT-S106070-xx	72.1 (159.0)
LDAT-S103020-xx	38.0 (83.8)	LDAT-S104050-xx	52.1 (114.8)	LDAT-S106080-xx	74.1 (163.3)
LDAT-S103030-xx	40.0 (88.1)	LDAT-S104060-xx	54.1 (119.2)	LDAT-S106090-xx	76.1 (167.7)

Linear Thruster (frame 150) Cat. No.	Weight, approx kg (lb)	Linear Thruster (frame 150) Cat. No.	Weight approx kg (lb)	Linear Thruster (frame 150) Cat. No.	Weight approx kg (lb)
LDAT-S152010-xx	38.6 (85.1)	LDAT-S153040-xx	58.6 (129.2)	LDAT-S154070-xx	78.6 (173.3)
LDAT-S152020-xx	41.6 (91.7)	LDAT-S153050-xx	61.7 (135.9)	LDAT-S154080-xx	81.7 (180.0)
LDAT-S152030-xx	44.6 (98.4)	LDAT-S153060-xx	64.7 (142.6)	LDAT-S154090-xx	84.7 (186.7)
LDAT-S152040-xx	47.7 (105.1)	LDAT-S153070-xx	67.7 (149.3)	LDAT-S156010-xx	82.4 (181.7)
LDAT-S152050-xx	50.7 (111.8)	LDAT-S152080-xx	70.8 (156.0)	LDAT-S156020-xx	85.5 (188.4)
LDAT-S152060-xx	53.7 (118.5)	LDAT-S152090-xx	73.8 (162.7)	LDAT-S156030-xx	88.5 (195.1)
LDAT-S152070-xx	56.8 (125.2)	LDAT-S154010-xx	60.4 (133.2)	LDAT-S156040-xx	91.5 (201.8)
LDAT-S152080-xx	59.8 (131.9)	LDAT-S154020-xx	63.4 (139.9)	LDAT-S156050-xx	94.6 (208.5)
LDAT-S152090-xx	62.9 (138.6)	LDAT-S154030-xx	66.5 (146.6)	LDAT-S156060-xx	97.6 (215.1)
LDAT-S153010-xx	49.5 (109.2)	LDAT-S154040-xx	69.5 (153.3)	LDAT-S156070-xx	100.6 (221.8)
LDAT-S153020-xx	52.6 (115.9)	LDAT-S154050-xx	72.5 (159.9)	LDAT-S156080-xx	103.7 (228.5)
LDAT-S153030-xx	55.6 (122.6)	LDAT-S154060-xx	75.6 (166.6)	LDAT-S156090-xx	106.7 (235.2)

Environmental Specifications

Attribute	LDAT-Series Linear Thrusters
Temperature, operating ambient	0...40 °C (32...104 °F)
Temperature, storage ambient	-30...70 °C (-22...158 °F)
Humidity, relative (noncondensing)	5...95%
Liquid/dust protection	IP30 (strip cover option only)
Shock, max	20 g peak, 6 ms duration
Vibration, max ⁽¹⁾	2.5 g peak @ 30...2000 Hz

(1) Tested for one hour per Rockwell Automation specification 10000056670. Contact your distributor for a copy of this specification.

Additional Resources

These documents contain additional information concerning related products from Rockwell Automation.

Resource	Description
Kinetix Linear Motion Specifications, publication GMC-TD002	Specifications, motor/servo-drive system combinations, and accessories for Kinetix Motion Control products.
Kinetix 3 Component Servo Drives, publication 2071-UM001	How to install, set up, and troubleshoot a servo-drive system.
Kinetix 300 EtherNet/IP Indexing Servo Drives User Manual, publication 2097-UM001	
Kinetix 2000 Multi-axis Servo Drives User Manual, publication 2093-UM001	
Kinetix 6000 Multi-axis Servo Drives User Manual, publication 2094-UM001	
Kinetix 6200 and Kinetix 6500 Modular Multi-axis Servo Drives User Manual, publication 2094-UM002	
Ultra3000 Digital Servo Drives Installation Manual, publication 2098-IN003	
Ultra3000 Digital Servo Drives Integration Manual, publication 2098-IN005	
Motion Analyzer software, download at http://www.rockwellautomation.com/en/e-tools	Drive and motor sizing with application analysis software.
SERCOS and Analog Motion Configuration User Manual, publication MOTION-UM001	Information on configuring and troubleshooting your ControlLogix® and CompactLogix™ SERCOS interface modules, and using the home to torque-level sequence.
System Design for Control of Electrical Noise Reference Manual, publication GMC-RM001	Information, examples, and techniques designed to minimize system failures caused by electrical noise.

You can view or download publications at <http://www.rockwellautomation.com/literature>. To order paper copies of technical documentation, contact your local Allen-Bradley distributor or Rockwell Automation sales representative.

Notes:

Rockwell Automation Support

Rockwell Automation provides technical information on the Web to assist you in using its products. At <http://www.rockwellautomation.com/support>, you can find technical manuals, technical and application notes, sample code and links to software service packs, and a MySupport feature that you can customize to make the best use of these tools. You can also visit our Knowledgebase at <http://www.rockwellautomation.com/knowledgebase> for FAQs, technical information, support chat and forums, software updates, and to sign up for product notification updates.

For an additional level of technical phone support for installation, configuration and troubleshooting, we offer TechConnectSM support programs. For more information, contact your local distributor or Rockwell Automation representative, or visit <http://www.rockwellautomation.com/support/>.

Installation Assistance

If you experience a problem within the first 24 hours of installation, please review the information that's contained in this manual. You can also contact a special Customer Support number for initial help in getting your product up and running.

United States or Canada	1.440.646.3434
Outside United States or Canada	Use the Worldwide Locator at http://www.rockwellautomation.com/support/americas/phone_en.html , or contact your local Rockwell Automation representative.

New Product Satisfaction Return

Rockwell Automation tests all of its products to ensure that they are fully operational when shipped from the manufacturing facility. However, if your product is not functioning and needs to be returned, follow these procedures.

United States	Contact your distributor. You must provide a Customer Support case number (call the phone number above to obtain one) to your distributor to complete the return process.
Outside United States	Please contact your local Rockwell Automation representative for the return procedure.

Documentation Feedback

Your comments will help us serve your documentation needs better. If you have any suggestions on how to improve this document, complete this form, publication [RA-DU002](#), available at <http://www.rockwellautomation.com/literature/>.

Allen-Bradley, ControlLogix, CompactLogix, Kinetix, MP-Series, Rockwell Software, RSLogix, Rockwell Automation, TechConnect, and Ultra are trademarks of Rockwell Automation, Inc.

Rockwell Otomasyon Ticaret A.Ş., Kar Plaza İş Merkezi E Blok Kat:6 34752 İçerenköy, İstanbul, Tel: +90 (216) 5698400

www.rockwellautomation.com

Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444
Europe/Middle East/Africa: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640
Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846