

How to configure an Anybus Modbus-TCP slave module with Unity Pro L



Document history

Revision	Date	Description	Author
1.00	2007-06-20	Created	Thorbjörn Palm
1.01	2007-07-18	Minor revision	Thorbjörn Palm
1.02	2007-07-20	Minor correction	Thorbjörn Palm
1.03	2008-03-05	Updated layout	Thorbjörn Palm

More information about the network and products

The latest manuals and EDS-files can be found on the HMS homepage, www.anybus.com

The Modbus user organisation has a homepage on the Internet, <http://www.modbus.org/>. Several technical guides are available in or via this page.

Contents

1.	Applicable Anybus products	4
2.	Requirements.....	4
3.	Solution overview	5
4.	Modbus TCP configuration	6
4.1.	The PLC configuration	6
4.2.	The Modbus-TCP network configuration	8
4.3.	The PLC program	12
5.	Anybus configuration.....	16
5.1.	IP settings.....	16
5.2.	I/O configuration.....	17
5.3.	Communicator configuration	18
5.4.	X-gateway configuration	20
6.	Testing	22
	Appendix	24
	Modbus-TCP addresses	24

1. Applicable Anybus products

Description	Name / Type
Anybus X-gateway	Modbus-TCP
Anybus Communicator	Modbus-TCP
Anybus-Slave	Modbus-TCP
Anybus-PCI	Modbus-TCP
Anybus-CompactCom	Modbus-TCP
Anybus-IC	EtherNet/IP (supporting Modbus-TCP)

Note: The configuration of the X-gateway and the Anybus Communicator is described in this document. In the case with the remaining Anybus products this document is applicable, but the configuration is depending on the type of application.

2. Requirements

Description	Name / Type	Version
Schneider Premium PLC	TSX P571634 with ETY Port master Modbus-TCP card	n.a.
PLC software	Unity Pro L	2.1
Anybus IPconfig tool	Anybus IPconfig	1.3.1.1
X-gateway Network Interface Addendum	Anybus X-gateway Ethernet Slave Interface, Network Interface Addendum	1.02
X-gateway User Manual	X-gateway Generic User Manual	1.02
Communicator User Manual	Anybus Communicator for Ethernet, User Manual	2.01
Slave Field bus Appendix	Anybus-S Ethernet, Field bus Appendix	1.42
IC Field bus Appendix	Anybus-IC Ethernet/IP, Field bus Appendix	1.52
PCI Interface Design Guide	Anybus-S Slave & Master, Parallel Interface Design Guide	2.0
CompactCom Network Interface Appendix	CompactCom Modbus-TCP, Network Interface Appendix	2.02
Power supply 24VDC	n.a.	n.a.
Configuration cables	n.a.	n.a.
Null modem cable (Supplied with the Anybus X-gateway)	n.a.	n.a.

3. Solution overview

This application note describes how to configure an Anybus Modbus-TCP Slave product with a Schneider PLC. Below you can find an overview of the system described in this document. Other nodes may be attached to the network, but are not necessary.

Note: This document is valid for all Anybus Modbus TCP products, however sections written in *italics* describe the configuration of a specific product.

The contents describe step by step how a configuration is done. This document assumes the reader is familiar with industrial communication, Modbus-TCP networks and HMS Communicator and X-gateway.




Figure 1 Hardware connection overview.

4. Modbus TCP configuration

To configure the PLC and the Modbus network the tool Unity Pro L is used. Firstly the PLC needs to be configured and secondly the Modbus network. Start the program and follow the steps below.

4.1. The PLC configuration

Start the Unity Pro L program and open the file menu and select new. In the window seen below, select the relevant PLC from the list, in this case the TSX P571634 model.




Figure 2 Configuring the type of PLC.

Press OK and the PLC with predefined modules is configured. Double click on the X-bus in the navigation list to the left and the window seen below will appear in a new window.




Figure 3 Configuring the PLC modules.

Double click on the modules 2, 3 etcetera for configuring additional modules. In this case two discrete I/O modules are used, one for input and one for output data. After double clicking on one of the extra modules the list seen below will be shown.




Figure 4 Configuring the I/O modules.

Select the desired module and click OK. In this case the I/O modules TSX DEY16D2 AND TSX DSY16T2 are added to the configuration. To configure additional modules repeat the previous steps.

To configure the IP settings of the PLC, open the PLC menu and select Set Address. The IP address is the address to which the configuration is to be downloaded to if using TCP/IP for the project transfer. The following window will be visible.



Figure 5 Configuring the IP settings of the PLC.

Enter the desired IP address and select TCPIP and press OK. The IP address for the PLC is now configured.

4.2. The Modbus-TCP network configuration

The next step is to configure the Ethernet module. Right click on Networks in the navigation list to the left and select add network.




Figure 6 Adding a network.

Select Ethernet and choose a name. In this case the network is named Modbus.




Figure 7 Configuring the network.

Under Communication in the navigation list to the left double click on the network named Modbus as seen below. Enter the desired settings. By using the alternative “From a server” the IP settings are retrieved by BOOTP.




Figure 8 The IP configuration.

Enable the I/O scanning tab by selecting YES in the module utilities. The I/O scanning function uses the Modbus function 0x17, 23_{dec}, Read/Write Multiple Registers to access the data from the nodes. Using this function the user can configure data and transfer it between network nodes without specific programming. To be able to scan both Input and Output data the Anybus module needs to be configured for Anybus mode. The registers and coils can also be accessed in other ways, by commands. In each case the mapping is depending on what mode is selected. For a more detailed description see the note below.

Note:

Anybus mode: When the Anybus product is configured for Anybus mode both the Input and Output data can be accessed by the I/O scanning function. In Anybus mode it is also possible to access coils with the same memory location as of a register. In other words it is possible to access individual bits of a register. See the table below showing the Modbus addresses in Modbus and Anybus mode. For a more detailed description see the Appendix Modbus addresses.

Modbus mode: If the Modbus mode is used only the Output data can be accessed by the I/O scanning function.

Data	Anybus mode, Register	Register type	Modbus mode, Register	Register type
Input data	1-1024	Input/Holding	1-1024	Input
Output data	1025-2048	Input/Holding	1-1024	Holding
Data	Anybus mode, Coil	Coil type	Modbus mode, Coil	Coil type
Input coil	1-16384	Input/Output	1-16384	Input
Output coil	16385-32768	Input/Output	1-16384	Output

Figure 9 Table showing the Modbus addresses used in Anybus and Modbus mode.

Note for the Anybus Communicator: In the Communicator the registers 257 to 1024 are reserved. For a more detailed description see the Communicator User Manual.

Note for the Anybus CompactCom: Also note the Anybus and Modbus mode is not supported by the Anybus CompactCom. The module has a complete different I/O configuration and the maximum data exchange is 256 bytes in each direction refer to the CompactCom Software Design Guide.

Then open the I/O scanning tile as shown below.




Figure 10 Configuring the I/O scanning.

In this case the PLC is reading the Slave index 0 and writing to the index 1024 using the “zero notation”. In the PLC the words with address 0 and 10 are used. The repetitive rate can be set to less than 500 ms as used in this example.

The next step is to double click on the Ethernet module and configure the network the PLC module is to be connected to. In this case the network named Modbus previously configured is selected. Open the configuration in the left navigation list and double click on the Ethernet module as seen below. Select the desired network and close the tile.




Figure 11 Configuring the PLC Ethernet module.

4.3. The PLC program

To test the communication between the slave and the master PLC a simple PLC program is used. The first step is to define the variables. Open the elementary variables and add the variables as seen below.




Figure 12 Defining the variables.

The second step is to put together a PLC program. The program is depending on the application; in this case a test program is used. Insert a new task of the FAST type and add a new section to the section folder. This is done by right clicking the Tasks folder under the Program folder and select add new task. Then right click on sections to add the program.




Figure 13 Adding a new program.

The program is built in the ladder language and named test in this case.

An ADD-function, ADD_INT, is used in this case. The easiest way to insert the function is to use the Function Input Assistant.




Figure 14 Adding the ADD function.

Click on the Function Input Assistant button and then on the browse button to the right in the row called FFB type.




Figure 15 Browsing the Function library.

Double click on the Libset as seen below to expand the library. Select the ADD_INT function and press OK. Then click with the mouse on the working space to the right.




Figure 16 Inserting the ADD function.

The start condition is controlled by the Boolean named Start. To insert the start condition mark the EN connector and click on the normally open contact button, the button is found in the top left corner. See the window below.

The next step is to connect the defined variables to the ADD function. Double click on the respective connector and select the variables as seen in the picture below. The Out variable is connected to the IN1 connector and the constant to the IN2 connector. The Out variable is also connected to the OUT connector.




Figure 17 Configuring the ADD function.

The next step is to insert a new animation table to monitor the variables. Right click on the Animation Tables in the navigation list to the left and select add a new Animation Table. Double click in the name column and add the desired variables.




Figure 18 The animation table.

To be able to monitor the variables the program needs to be transferred to the PLC. Firstly the project needs to be compiled and saved. Press the rebuild all button and then save the project. After that open the PLC menu and select Transfer project to the PLC. Press the transfer button.




Figure 19 Downloading the program.

5. Anybus configuration

5.1. IP settings

Make sure each node on the network has a unique IP address. The IP settings of the Anybus Modbus-TCP modules can be configured in various ways. It is recommended to use the Anybus IPconfig tool for configuring the IP-settings. The Anybus IPconfig tool can be used to configure the IP settings of all Anybus Modbus-TCP modules. The program can be downloaded at HMS¹ website. Start the program and the main window will be opened.




Figure 20 The Anybus IPconfig tool.

The program scans the network for Anybus Ethernet modules. By double clicking on the desired module the IP-settings can be entered. The settings can be configured manually or the DHCP function can be used. DHCP is activated by default.




Figure 21 Configuring the IP settings.

¹ www.anybus.com

As mentioned before there are other ways to configure the IP settings. See the notes below for more information.

Note for the Anybus-S Slave, and Communicator:

DIP switches 1-8 set the last part of the IP address, 192.168.0.xxx. The switches will be found next to the indication LEDs on the Communicator and the Slave Interface. The modules can also be configured by mailbox commands or by the ethcfg.cfg configuration file.

Note for the X-gateway:

The X-gateway can be configured by the DIP switches as described above or by the ethcfg.cfg configuration file.

Note for the Anybus PCI card:

The module can be configured by mailbox commands or by the ethcfg.cfg configuration file.

Note for the Anybus-IC:

For the Anybus-IC for Modbus-TCP the configuration is depending on the application. The IP address is set by the IP configuration parameters if the NA-bit is 1 or, if mounted, by switches if the NA-bit is 0. The IP address can also be configured by the network via EtherNet/IP via the TCP/IP Interface Object.

Note for the Anybus CompactCom:

The Anybus CompactCom can be configured by the network configuration object

For further instructions see the respective manual or appendix.

5.2. I/O configuration

The Anybus product has to be configured for the same I/O sizes as set up in the Modbus scanner configuration. The configuration procedure is depending on the type of module. See the notes below.

Note: The I/O sizes are depending on the application, the configured I/O sizes in this chapter are just examples.

Note for the Anybus-S Slave Interface and the Anybus PCI card:

The Anybus Slave Interface and the Anybus PCI card are configured by mailbox commands. Refer to the respective Fieldbus Appendix for details.

Note for the Anybus CompactCom and the Anybus-IC:

The Anybus CompactCom and the Anybus-IC are configured by messages send by the application. Refer to the respective Design Appendix for details.

Note for the Anybus Communicator and the Anybus X-gateway:

The configuration of the Anybus Communicator and the Anybus X-gateway is described in separate sections below.

5.3. Communicator configuration

To configure the Communicator start the ABC Config Tool and start a new project. Select the field bus Modbus-TCP and the desired I/O data size.




Figure 22 Configuring the Field bus.

In this case 8 bytes are configured and the Modbus addressing mode is disabled. This means that the Anybus mode is enabled, see the chapter 4.2 and the Communicator User Manual.

In this case a loop back dongle at the serial connection of the Communicator is connected. To loop data the generic data mode is selected; all other values are left at their defaults.




Figure 23 Configuring the Communicator.

The next step is to configure the sub-network.




Figure 24 Configuring the sub network.

Right click on new node and add a consume and a produce transaction as shown above. Change the Offline timeout time to 200 ms and leave the settings for the produce transaction at the defaults. Right click on the produce and consume transaction respectively and select add data. In this case 8 bytes of data is used.

Note: The update time for the produce transaction is to be set to less than the offline timeout time for the consume transaction; in this case the update time is set to 100 ms.

For a more detailed description see the Communicator user manual.

5.4. X-gateway configuration

Use the HyperTerminal on a PC and configure the X-gateway. Connect a serial cable between the PC and the config port on the X-gateway. Open the "File" menu and click on new, choose the desired COM port and then click on OK. The following window will appear.




Figure 25 Configuring the connection in the HyperTerminal.

Make sure the settings are identical to those shown in the window above. Alternatively download a HyperTerminal session file from the HMS website², double click on it and select COM port.

Connect and press ESC and the following menu will appear.




Figure 26 Anybus X-gateway Main menu.

Press 6 and enter the desired configuration. The figure below shows an example; in this case an Ethernet Modbus-TCP/Modbus Plus X-gateway is used and 8 bytes of I/O data is configured. The Modbus addressing mode is disabled. This means that the Anybus mode is enabled. See the chapter 4.2 and also the X-gateway Ethernet Slave Interface Adapter Interface, Network Interface Addendum for a more detailed description.

² www.anybus.com




Figure 27 The X-gateway configuration.

6. Testing

After the configuration the testing of the network can be done.

Open the PLC menu again and select the command connect. Then press the run button in the top navigation list. In the animation window the variables can now be monitored. Open the animation table and press the modification button and modify the variables.




Figure 28 Modifying the variables.

The constant used is set to five, in other words the variable OUT is increased by five for each program scan cycle. To start the program set the value of the Boolean Start to one. The In variable will then obtain a new value as seen above.

To see the data being transmitted on the Modbus network the tool Modscan32 is used. Open the connection menu and select connect as seen below.




Figure 29 Configuring the connection.

Select Remote TCP/IP Server and enter the IP address for the slave, in this case 10.10.12.140. After pressing OK, select 03 Holding Register and enter 401 in the address field as seen below.




Figure 30 Scanning the Holding register.

The Register 401 Hex is 1025 in decimal format, in other words the register corresponds to the one written by the PLC. The value seen is the same as of variable Out.

Note: In ModScan32 the starting address is 1 and not 0 as in the PLC.

In the same way the variable In can be monitored by scanning the register numbered 1. Change the Modbus Point Type to 04 Input Register and enter 1 in the address field as seen below.




Figure 31 Scanning the Input register.

Appendix

Modbus-TCP addresses

The two tables below describe the Modbus-TCP addresses when using respectively Modbus mode and Anybus mode. HMS mode is analogue to Anybus mode as mentioned in the table below. The tables shows the Register and Coil addresses, register type but also the offset address in the area and the DPRAM address in the Anybus module.

Modbus/TCP addresses when Modbus-mode is used

Description	Offset address inside the area	Input register	Holding register	Input coil (MSB to LSB)	Output coil (MSB to LSB)
Cyclic/acyclic data in the IN area	0	-	-	1 to 8	-
	1	-	-	9 to 16	-
	...	-	-	...	-
	...	-	-	...	-
	...	-	-	...	-
	...	-	-	...	-
	...	-	-	...	-
	...	-	-	...	-
	y-1	-	-	8(y-1) to 8(y-1)+8	-
	y	-	-	8y to 8y+8	-
(Note: Input coils will only be available if requested with the MB_SET_COIL_AREA_SIZE mailbox command. If not defined, the first Input register will be mapped to the beginning of the IN area.)	0	1 (high byte)	-	-	-
	1	1 (low byte)	-	-	-
	2	2 (high byte)	-	-	-
	3	2 (low byte)	-	-	-
	-	-	-
(Note: Output coils will only be available if requested with the MB_SET_COIL_AREA_SIZE mailbox command. If not defined, the first Holding register will be mapped to the beginning of the OUT area.)	x-3	x/2 (high byte)	-	-	-
	x-2	x/2 (low byte)	-	-	-
	x-1	(x+1)/2 (high byte)	-	-	-
	x	(x+1)/2 (low byte)	-	-	-
	y	-	-	-	-
Cyclic/acyclic data in the OUT area	0	-	-	-	1 to 8
	1	-	-	-	9 to 16
	2	-	-	...	-
	3	-	-	...	-
	...	-	-	...	-
	...	-	-	...	-
	x-3	-	-	...	-
	x-2	-	-	...	-
	x-1	-	-	8(y-1) to 8(y-1)+8	-
	x	-	-	8y to 8y+8	-
0	1 (high byte)	-	-	-	
1	1 (low byte)	-	-	-	
...	2 (high byte)	-	-	-	
...	2 (low byte)	-	-	-	
...	..	-	-	-	
...	..	-	-	-	
...	x/2 (high byte)	-	-	-	
...	x/2 (low byte)	-	-	-	
y-1	(x+1)/2 (high byte)	-	-	-	
y	(x+1)/2 (low byte)	-	-	-	