



WP-S1 User Guide



Free local and international calls from your mobile with Skype

Many people know Skype as a brilliant way to make free calls from one PC to another. Now you can make those same calls as well as chat from your mobile. So you can call more than 170 million Skype users all over the world including other Skype users on 3.

Making Skype-to-Skype calls is easy. Your phone has its own Skype dedicated key.

Not only that but your mobile also comes with a 2 megapixel camera, MP3 player and a memory card with loads of storage space. You can access the internet by pressing the Launcher or **Planet 3**.

And that's just scratching the surface of what the WP-S1 phone offers you.



Get set up

1

Your mobile explained

2

Set up Skype

3

Planet 3 and the mobile internet

4

Calls

5

Text, multimedia and email messages, and Skype chat

6

Contacts

7

Media and Game Centre

8

Extra features and security

9

Connectivity settings

10

Troubleshooting, handset safety and maintenance, and index

11

Please see section 11 for AMOI'S health and safety information related to your mobile

Contents

1. Get set up

- 1.1 Insert your USIM, battery and memory card, and charge your mobile
- 1.2 Turn your phone on and off
- 1.2 Set the date and time and choose a wallpaper and ringtone
- 1.2 Set up voicemail and videomail
- 1.3 Choose a text entry method
- 1.4 Phone maintenance

2. Your mobile explained

- 2.1 Get to know your mobile
- 2.3 Your mobile's screen
- 2.5 The multitask menu
- 2.6 The handset's menu options

3. Set up Skype

- 3.1 Sign into Skype
- 3.2 Skype settings
- 3.2 Skype status icons

4. Planet 3 and the mobile internet

- 4.1 Find out what you can do on **Planet 3**
- 4.2 The mobile internet

5. Calls

- 5.1 Make voice and video calls
- 5.1 Make a call from contacts
- 5.1 Make Skype-to-Skype calls
- 5.1 Make emergency calls
- 5.1 Receive calls
- 5.1 Conference calls
- 5.2 Make a call from Call log
- 5.2 Call divert
- 5.2 Call features
- 5.2 Withhold your mobile number
- 5.2 Video call settings
- 5.3 Call log

6. Text, multimedia and email messages, and Skype chat

- 6.1 Text messages
- 6.1 Skype chat
- 6.1 Multimedia messages
- 6.2 Set up your email
- 6.2 Write an email message
- 6.2 Retrieve an email
- 6.2 Reply to an email
- 6.2 Browse into mail

7. Contacts

- 7.1 Add a contact
- 7.1 Access contacts
- 7.1 Edit a contact
- 7.1 Add a Skype contact
- 7.1 Import your Skype contacts
- 7.2 Delete a contact
- 7.2 Add a photo to your contact
- 7.2 Copy a contact between USIM and mobile
- 7.2 Copy contacts between USIM and mobile

8. Media and Game Centre

- 8.1 Play music
- 8.2 Take photos or make video clips
- 8.2 View your photos or video clips
- 8.2 Update your media files
- 8.3 Access games and apps

9. Extra features and security

- 9.1 Set an alarm
- 9.1 Calendar
- 9.1 Calculator
- 9.2 Activate and change your USIM PIN
- 9.2 Change your USIM PIN
- 9.3 Network settings
- 9.3 Master reset
- 9.3 Language




10. Connectivity settings

- 10.1 Connect with a Bluetooth headset
- 10.1 Transfer files from your mobile using Bluetooth
- 10.2 Transfer files between your mobile and PC
- 10.2 Update your media files
- 10.2 PC synchronisation

11. Troubleshooting, handset safety and maintenance, and index

- 11.1 Troubleshooting
- 11.3 Safety precautions
- 11.8 Index





1 Get set up

First things first.

There are a few simple things to do before you can use your new mobile. This section shows you how to install your USIM and battery and how to charge it up.

- 1.1 Insert your USIM, battery and memory card, and charge your mobile
- 1.2 Turn your phone on and off
- 1.2 Set the date and time and choose a wallpaper and ringtone
- 1.2 Set up voicemail and videomail
- 1.3 Choose a text entry method
- 1.4 Phone maintenance

1

Get set up







Insert your USIM, battery and memory card, and charge your mobile

Your 3 USIM can only be used in mobiles which are enabled for 3 services.

If you try to use the USIM in other mobiles you could seriously damage the mobile and may be unable to use it, including making emergency calls. If you do that, we are not responsible for any such damage or usage problems.

Illustrations

- 1 Remove battery cover and battery
- 2 Insert your USIM
- 3 Insert memory card
- 4 5 Insert your battery and battery cover
- 6 Charge your battery



Fully charge the battery before using it for the first time.

General set up

This section shows you how you can adjust various settings to make your mobile perform exactly as you like. It explains how to set the time and date, sounds and wallpapers, as well as showing the various ways of entering text available.



Power on

- › Press and hold  to switch on your phone.



Power off

- › Press and hold  to switch off the phone.


Set time and date

- › Press  from the Start Screen and select **Settings**  › **Phone settings** › **Time and date**.
- › Enter the date and time.
- › Select **Save**.

Set the wallpaper



- › Press  from the Start Screen and select **Settings**  › **Phone settings** › **Display** › **Main screen**.
- › Select **Show wallpaper** › your preferred image › **OK**.

Set your ringtone

- › Press  (left) from the Start Screen and select **Normal** or other profiles.
- › Select **Options** › **Edit** › **OK**.
- › Select **Change** › select your preferred tune from **Tracks** › **OK**.

Voicemail and videomail

To set up voicemail and videomail:

- › Set up voicemail: press and hold .
Follow the voice prompts to choose a PIN and record your greeting.
- › Set up videomail: press and hold  for a video call. Then follow the voice prompts to record your video greeting.

1

Get set up

Choose a text entry method

While writing a message, entering contact details etc, you will need to select an appropriate text entry method.

Text entry status icons

- Abc T9** Predictive text mode, initial
- ABC T9** Predictive text mode, caps lock
- abc T9** Predictive text mode, lowercase
- Abc** Multipress text input mode, initial
- ABC** Multipress text input mode, caps lock
- abc** Multipress text input mode, lowercase
- 123** Numeric input mode

Changing input modes

The multitap, T9 and numeric input modes can be changed by pressing **↵** within a text box.

- › **ABC Input:** use the keypad to enter letters, numbers, symbols, and other characters. Press the same key repeatedly to cycle through available characters. If you do not press a key for two seconds, the character in the block cursor is accepted, and the cursor moves to the next position.
- › **T9 Text Input:** you press each key only once, even if the character you want is not the first character on the key. It tries to predict the word.
- › **123 Input:** if you want to input a series of numbers, you need to change to 123 mode or press and hold the particular key for three secs.
- › **Symbol Input:** for text message, select **Options** › **Insert other** › **Symbol**. Select the corresponding symbols on your keypad.




Phone maintenance

Mobile phones are complex electronic devices and must be looked after carefully. The following advice can help you to look after your phone and prolong its life.

- › The phone and its spare parts should be kept out of the reach of children.
- › Keep the phone dry. Rain, moisture or water will corrupt its electronic circuitry. If your phone does get wet, remove the battery immediately.
- › Don't put the phone in dusty places or this will affect the everyday use of the phone.
- › Don't touch the screen with a sharp object.
- › Don't expose the phone to high temperatures. High temperatures will shorten the life of electronic devices, destroy the battery and destroy or melt a phone's plastic shell.
- › Don't expose the phone to low temperatures. Otherwise, when the temperature rises, moisture will condense in the phone and could damage the phone's electronic circuitry.
- › Don't throw, knock or shake the phone intensely as this could damage the electronic circuitry and structure of the phone.
- › Please use a clean, soft cloth to clean the camera lens and other delicate surfaces.

1

Get set up



2 Your mobile explained


Your mobile can do a lot of things.


This section explains what all the icons and symbols mean, and shows you how to find your way around your mobile.

- 2.1 Get to know your mobile
- 2.3 Your mobile's screen
- 2.5 Multitask menu
- 2.6 The handset's menu options

Get to know your mobile

Familiarise yourself with its features.





Your mobile's screen

Your mobile's screen is divided into three basic screens: the Status bar, the Main Screen and the Prompt box.



Status bar













Shows what operations are taking place, Skype status (see page 3.2), and the battery and signal strength. See the next page for status icon details.





Main Screen

When not on Start Screen, the screen will show main menu or the sub menu related to the particular feature.

The Prompt box

Displays various prompts in the soft key boxes. These are activated by pressing the appropriate left and right soft key under each one.


Icon	Description
	Signal strength - shows the strength of your mobile's connection with the network  indicates you are outside video service area
	Battery - shows the level of battery.  shows little battery power left
	Profile - Normal - notifies you of an incoming call or message.  Silent .  Vibrate only .  Loud
	Skype - signed in. Available to receive calls and chats. See page 3.2 for other Skype status icons
	New messages - appears when there are new unread text and multimedia messages
	Alarm clock - appears when the alarm clock is set
	Roaming - appears when you are out of your home area and have registered on a different network

Icon	Description
	PDP - PDP always on
	Bluetooth activated - Bluetooth is active
	Memory full - appears when the phone memory is limited. In this case it may be necessary to clear some memory on your phone
	Calendar - appears on the day when a calendar event exists

Multitask menu

The Multitask menu displays icons of applications which are open - there should only be a maximum of six items in the list. If all six spaces are taken, and a seventh item is added, the application that has not been used for the longest period of time will not be displayed and the position will be occupied by the new application icon.

The most recently opened application is placed at the beginning of the list. The image above shows the Multitask menu:



Switch key
for multitask

- › To close a current application select **Options** › **Close** or highlight the chosen application and press **□**.
- › To close all applications select **Options** › **Close all**.
- › To access an open application highlight the preferred application and select **Go to**.

The handset's menu options

Take a look below to see all of your handset's menu options and what they include. Press **MENU** ...



Web

- Enter address
- Search
- My bookmarks
- History
- Saved pages
- Planet 3**



Call log



Games and apps

- Downloaded apps
- Application shop
- My applications



Multimedia

- Media player
- Camera
- Video camera
- Voice recorder



Messages

- New
- Inbox
- Skype chat
- Email
- Outbox
- Drafts
- Sent
- Template
- Settings



My stuff

- Music
- Pictures
- Movies
- Others



Tools

- Alarm
- Calculator
- Calendar
- Notepad
- PC Sync
- World time
- Stopwatch
- Memory card






Contacts



Settings

- Profiles
- Phone settings
- Connectivity
- Calls
- Network settings
- Security settings
- Java settings
- Master reset



3 Set up Skype

With Skype on 3, you can make Skype-to-Skype calls from your mobile. This means you can call people all over the world who use Skype, including other Skype on 3 users.


- 3.1 Sign into Skype
- 3.2 Skype settings
- 3.2 Skype status icons

3

Set up Skype



Sign into Skype

If you have a Skype account

- › Press  from the Start screen.
- › Select **Sign in for existing users**, then enter your username and password.
- › Scroll to **Sign me in** and set it as **Automatically** or **Manually**.
- › If you select **Automatically**, you'll automatically sign into Skype each time you turn on your mobile.

To create a new account

If you don't have a Skype account


- › Press  from the Start screen.
- › Scroll to **Create account for new users** and press .
- › Read the Skype End User Licence, Terms of Service and Privacy Policy available at www.skype.com/eula, www.skype.com/tos, www.skype.com/privacy or on the CD version of this user guide, select **Accept** and enter a username and password on the Create account screen.
- › Select **OK** to save the settings.

You can:


- › Import your Skype contacts to your mobile phone when you activate your Skype account for the first time.
- › Otherwise import your Skype contacts - see page 7.1
- › For Skype calls - see page 5.1
- › For Skype chat - see page 6.1
- › Add a Skype contact - see page 7.1

Skype settings


Change Skype status

- › Press  from the Start screen.
- › Select **Options > Change status.**

Sign out of Skype






- › Press  from the Start screen.
- › Select **Options > Sign out.**


Change Skype sign in setting

- › Press  from the Start screen.
- › Select **Options > Settings > Sign me in > Automatically / Manually.**

The Skype status icon you select will appear on your mobile's status bar. This can be seen by your Skype buddies.




You can choose to set your own status to:

-  **Online** - others will see you as online (default settings when you sign in)
-  **Away** - others will see you as away
-  **Not Available** - others will see you as not available
-  **Do Not Disturb** - others will see you as do not disturb
-  **Invisible** - others will see you as offline



3

Set up Skype



4 Planet 3 and the mobile internet

With so many sites designed to work on mobiles, you can now get the best of the web on your phone. And with Planet 3 you can download music, the latest goals and games plus much more.

- 4.1 Find out what you can do on Planet 3
- 4.2 The mobile internet

Find out what you can do on Planet 3

From  you can...

Watch music videos and goals, play games and much more.
It's free to browse and we'll tell you how much things cost
before you download them.



3MusicStore

Download full length music videos and tracks.



Tunes

Personalise your mobile so it sounds unlike anyone else's.



Games

Buy a game and keep it forever or rent one and pay less.



Meet & Share

Flirt and chat, share videos, message your friends and meet new people. Also be a show off on **SeeMe TV**.



Mobile TV

View live clips from the biggest TV shows.

All this plus news, showbiz, movie trailers, comedy and more through .




The mobile internet

Go to mobile websites




- › Press **MENU** > **Web**  > **Google / Yahoo** to enter the website URL and select **Go to**.

Search the internet

- › Press **MENU** > **Web**  and select then scroll to **Google / Yahoo** to enter the search word(s) and select **Go to**.



- › Press **Launcher**.
- › Select your preferred internet application eg. Yahoo!, Search or Google Search.



5 Calls

Right. Let's get some basic functions sorted out.

Making and receiving calls is as easy as you'd expect. But there's also a number of useful 3 services that will make it easier for you to manage your calls. Conference calls, Caller ID, Call Divert... take a look at the list below for the complete picture.


- 5.1 Make voice and video calls
- 5.1 Make a call from contacts
- 5.1 Make Skype-to-Skype calls
- 5.1 Make emergency calls
- 5.1 Receive calls
- 5.1 Conference calls
- 5.2 Make a call from Call log
- 5.2 Call divert
- 5.2 Call features
- 5.2 Withhold your mobile number
- 5.2 Video call settings
- 5.3 Call log

Make voice and video calls



Making and receiving calls is as easy as you'd expect. But there's also a number of useful services that will make it easier for you to manage your calls. Conference Call, Call Divert, Call Barring, Call Waiting... take a look at the list below for the complete picture.

Make voice and video calls





To make a call from the Start screen:

- › Enter the phone number.
- › Press  to make a voice call.
- › Select **Options** › **Video call** › **OK** for a video call.

Make a call from Contacts

- › Press  (down).
- › Scroll to your preferred contact and press  for voice call.
- › Scroll to your preferred contact and select **Options** › **Video call** › **OK** for a video call.

Make Skype-to-Skype calls

- › Press  and scroll to your preferred contact.
 - › Press  for Skype-to-Skype calls.
See page 7.1 to import Skype contacts.
- or
- › Press  (down).
 - › Scroll to your preferred Skype contact and press  for Skype-to-Skype calls.

Make emergency calls

Enter the appropriate emergency numbers for your location (such as 999) then press .

Receive calls

- › To answer a call press .

Reject calls


- › Press .

End a call




- › Press  to end a call.

Conference calls

While on a call, you can make another call or receive a second call and talk with up to three people at the same time. This option is not available in Skype.

- › Enter the second number and press  to make another call.
- › Press **Options** › **Conference**.

Make a call from Call Log

- › Press  from the Start screen and scroll to your preferred contact.
- › Press  for a voice call and press  for a Skype call.

Call divert

Lets you transfer incoming voice and video calls to a specified number. For video calls, it must be to another video mobile number.

- › Press **MENU**.
- › Select  **Settings** > **Calls** > **Call divert**.


Call features

During a call, press **Options** to access the following features:

- › **Hold**: select to place the caller you are talking to on hold. Select **Retrieve** to remove the call from hold.
- › **Mute**: select to turn off the microphone so that you can hear the caller but the caller cannot hear you. Select **Mute off** to switch on the microphone again.
- › **Call log**: select to view your call log list.
- › **Contacts**: select to view your Contacts List.
- › **Messages**: select to access the Messages menu.


Withhold your mobile number

Enables you to choose whether your phone number will be hidden or not during a call.

- › Press **MENU**.
- › Select  **Settings** > **Calls** > **Call settings** > **Withhold number**.

Video call settings

Enables you to change settings for video calls.

- › Press **MENU** and select  **Settings** > **Calls** > **Video call settings**.
- › **My video size**: allows you to set the size for your own video. You can choose either large or small.
- › **My video position**: allows you to set the position of your image on the display. You can choose either left or right.
- › **Hide my video**: allows you to choose whether to display your own video on the screen.
- › **Block my video**: enables you to allow or stop the sending of your own video to the other party.



Make voice and video calls

Call log

To view call log:

- › From the Start screen, press .

Caution:

Press  or  to switch between **Dialled calls / Answered calls / Missed calls / All calls** list.

From the call log you have a number of options available. See below for the full list. Choose your preferred contact, and select **Options** to access any of the following:

Options

View detail

Functions

Displays the status, time, name, number and picture (the picture will be displayed only when the number has been saved in the contacts and assigned the picture to the number) of this call.

Voice call

Makes a voice call to the selected number.

Video call

Makes a video call to the selected number.

Send message

Sends text, picture message, a Skype chat or an email to the selected number.

Create contact

Creates a new contact, and the contact will be added to the Contact List automatically.

Add to contact

Adds the number to the contact which has been saved in Contact List.

Delete

Deletes the selected contact from the list.

Delete all

Deletes all contacts in current list.

6 Text, multimedia and email messages, and Skype chat


Go text crazy! send videos, pictures and emails to your friends - and chat to other Skype users.

- 6.1 Text messages
- 6.1 Skype chat
- 6.1 Multimedia messages
- 6.2 Set up your email
- 6.2 Write an email message
- 6.2 Retrieve an email
- 6.2 Reply to an email
- 6.2 Browse into mail



Text, multimedia and email messages

You can send and receive text, picture, video and voice messages, plus email on your mobile.

Text messages

- › Press  (right) from the Start screen and select **New > Text message**.
- › Enter the phone number at **To(1)** or press **Contacts** to select preferred contact.
- › Scroll to **Message** and write the message. Press **Send** to send the message.


Skype chat

- › Press  from the Start screen.
- › Scroll to select the preferred Skype contact, select **Options > Start chat**.
- › Write your message and press .



Skype chat is a network dependent feature.

Multimedia messages


To create a new multimedia message

- › Press  (right) from the Start screen and select **New > Picture message**.
- › Enter the phone number or email address at **To(1)**. Scroll to **Message** and press **Options** and select **Insert picture / video / sound** and select a file. Press **Send** to send the message.


Take a picture or video and send it

- › From Start screen press  on the right of your mobile.
- › Select **Options > Capture mode** to switch between camera and video mode.
- › Select **Back** and press  to take photo or to start video recording and press **Stop** (left soft key) to stop video recording.
- › Select **Send** to send the message. Follow the menu.


Setting up your email

- › Press  (right) from the Start screen and select **Settings** › **Email**.
- › Select **Options** › **Edit** › **Account details** › **OK**.
- › At **Account name** enter your name. Then scroll to **username** and enter your mobile number starting with 447xxxxxxx but without plus +. Then scroll to **Password**, enter the 4-digit PIN selected for voicemail and press **Save**.


Write an email message

- › Press  (right) from the Start screen and select **New** › **Email**.
- › Enter the email address at **To(1)**. Scroll to **Message** and write the message. Press **Send** to send the message.

Retrieve an email

- › Press  (right) from the Start screen and select **Email**.
- › Select **OK** › **Retrieve** to select your preferred email.




Reply to an email

- › Press  (right) from the Start screen and select **Email**.
- › Scroll to the email, and select **Retrieve** › **View** › **Reply**.

Browse into mail

- › Press  **Windows**.
- › Select  **Services** ›  **Mail**.

From the browser you can send emails and view and manage emails, voicemails and contacts.



7 Contacts

The place to find all your numbers in one place.



- 7.1 Add a contact
- 7.1 Access contacts
- 7.1 Edit a contact
- 7.1 Add a Skype contact
- 7.1 Import your Skype contacts
- 7.2 Delete a contact
- 7.2 Add a photo to your contact
- 7.2 Copy a contact between USIM and mobile
- 7.2 Copy contacts between USIM and mobile

Contacts


Add a contact

- › Enter a contact number from the Start screen and select **Options** › **Create contact**.
- › Enter name and other details and select **Save**.


Access contacts

- › Press  (down) from the Start screen.
- › When there is more than one number for a contact, press  (left or right) to view numbers or select **Options** › **View & Edit**.

Edit a contact


- › Press  (down) from the Start screen.
- › Select **Options** › **View & Edit** › **Edit** to edit your contact and then press **Save**.

Add a Skype contact



- › Press  from the Start screen.
- › Select **Options** › **Add a contact** enter the contact's Skype name and select **Save**. You'll also have the option to save the Skype contact in your phone book.

Import your Skype contacts

You can save your Skype contacts onto your mobile along with your other contacts.


- › Press  (down) from the Start screen.
- › Select **Options** › **Skype options** › **Update Skype contacts**.

Delete a contact


- › Press  (down) from the start screen.
- › Scroll to the contact and press  › **Yes** to delete the contact.

Add a photo to your contact


You can add a photo to a contact stored on the mobile (not on your USIM card).




- › Press  (down) from the Start screen.
- › Scroll to highlight the desired contact, select **Options** › **View & Edit** › **Edit**.
- › Scroll to **Picture** › **Add** and select your preferred image. Press **OK** to save the setting.

Copy a contact between USIM and mobile

- › Press  (down) from the Start screen.
- › Scroll to the desired contact and select **Options** › **Manager** › **Copy to USIM** / **Copy to phone**.

Copy contacts between USIM and mobile

- › Press  (down) from the Start screen.
- › Select **Options** › **Mark** › **Mark** › **Mark**.
- › Scroll to select the desired contact(s) › **Options** › **Copy to USIM** / **Copy to phone**.



8 Media and Game Centre

Play music, take pictures, record videos or play games. The media centre is where you'll find all the fun stuff your mobile can do for you.

- 8.1 Play music
- 8.2 Take photos or make video clips
- 8.2 View your photos or video clips
- 8.2 Update your media files
- 8.3 Access games and apps


Multimedia

The media centre on your mobile lets you take photos and videos and play music.

Play music

- › Press **MENU** from the Start screen.
- › Select **Multimedia** > **Media Player** > **Artist, Album, Track, Recently added**, etc.

See the Now Playing screen as below:



Play/Pause

Volume status

Repeat play

Fast reverse

Play the next file

Play the previous file

Playing time

Play list indication

Fast forward

The icons in the interface are:

Icon

Functions




The icon indicates the current volume status, press Side Up key to increase the volume and press Side Down key to decrease the volume.




Repeat play.



Press  (up) to play the previous file.




Press  (down) to play the next file.




Press  to switch between Play and Pause.






Press  (left) to fast reverse.




Press  (right) to fast Forward.

Take photos or make video clips

- › From Start screen, press  on the right of your mobile.
- › Select **Options** > **Capture mode** to switch between camera and video mode.
- › Select **Back** and press  to take a photo or to start video recording, and select **Stop** (left soft key) or Camera key  to stop video recording.
- › For additional camera features, select **Options** by pressing Left Soft Key.

View your photos or video clips

- › Press **MENU**.
- › Select **My stuff**  > **Pictures / Movies** > **OK**.
- › Select your preferred picture or video clips and select **OK**.

Update your media files

Each time you transfer music, picture or video files from your PC to the mobile including the memory card, you need to do this:

- › Press **MENU**.
- › Scroll to select **My Stuff**  > **Update**.

Games and applications

Your mobile supports Java so you can download games from **Today on 3** and from the Application Shop, and play them on your mobile.

Access games and apps

- › Press **MENU**.
- › Select  **Games and apps**.

Downloaded apps

You'll find your games and downloaded from **Planet 3**.

Application shop

Access and download new applications and games for your mobile.

My Applications

You'll find your new applications and games downloaded from the **Application Shop**.

9 Extra features and security


Your mobile has a bunch of useful extra features, including a Calendar with alarms to remind you of specific appointments, alarms clock and a way to lock your mobile.

- 9.1 Set an alarm
- 9.1 Calendar
- 9.1 Calculator
- 9.2 Activate and change your USIM PIN
- 9.2 Change your USIM PIN
- 9.3 Network settings
- 9.3 Master reset
- 9.3 Language

Alarm

The alarm can be set to ring at a specific time within 24 hours. The alarm signal rings even if the phone is set to silent or turned off.


Set an alarm

- › Press **MENU**.
- › Scroll to select **Tools**  › **Alarm** › **Alarm1**. Press **OK** to set your alarm.
- › After setting, select **Save**.

Calendar






You can use the calendar to keep track of important meetings.

To create a new event/task:

- › Press **MENU**.
- › Scroll to select **Tools**  › **Calendar**.
- › Scroll to your preferred date. Press **View** and select **Yes** to create a new calendar.
- › Select **New event / New to do**.
- › Enter the details and select **Save**.

Calculator

To use the calculator:

- › Press **MENU**.
- › Scroll to select **Tools**  › **Calculator**.
- › Use  to Add, Multiply, Divide or Subtract and  to select calculator. Press  to delete a number and  for decimal point.


Set up your PIN number

Make sure you protect your mobile number so that only you can use it.

Activate and change your USIM PIN


Your PIN (Personal Identification Number) code protects the information stored on your USIM.

To activate your USIM PIN:

- › Press **MENU**.
- › Scroll to select **Settings**  › **Security settings** › **Activate PIN** › **Enable**.
- › Enter the default PIN **0000**, and press **OK**.

Change your USIM PIN

Once you have activated your PIN, each time your turn on your mobile, you'll need to enter your PIN.

- › Press **MENU**.
- › Scroll to select **Settings**  › **Security settings** › **Change PIN**.
- › Enter your default PIN (0000), press **OK** and enter your new PIN (4-8 digit) twice.
- › Select **OK** to save the setting.

Caution


- › If you enter an incorrect PIN code three times in succession, your USIM and phone functions will be locked. For more details, please refer to **Safety precautions** on page 11.3.
- › If you do not know the correct PIN code and PUK code, please contact your operator or network service provider.

Network settings

Your mobile is automatically set to connect to your network. When travelling abroad it will automatically select an available network.

Network settings

You can also manually select the network you wish to be on when travelling abroad.

- › Press **MENU**.
- › Scroll to select **Settings**  › **Network settings** › **Search** › **Manual**.
- › Select your preferred network and press **Select**.

Master reset

The Master reset function enables you to reset your mobile back to the factory settings.




- › Press **MENU** from the Start screen.
- › Scroll to select **Settings** › **Master reset**.
- › Enter the default handset code **0000** and press **OK**.




You can change this code by:

- › Press **MENU** › **Settings** › **Security settings** › **Lock phone** › **Change code**.

Language

This function allows you to choose the language for the display of your phone. Several options are available.

- › Press **MENU**.
- › Scroll to select **Settings**  › **Phone settings** › **Language**.
- › Press  (up) or  (down) to select the preferred language and select **OK**.



10 Connectivity settings

Keep track of your appointments and updates of your contacts by copying them to your PC and connect to your friends' mobiles with Bluetooth.


- 10.1 Connect with a Bluetooth headset
- 10.1 Transfer files from your mobile using Bluetooth
- 10.2 Transfer files between your mobile and PC
- 10.2 Update your media files
- 10.2 PC synchronisation

Bluetooth synchronisation

Connect with a Bluetooth headset

Before making calls with a Bluetooth headset, you must first set up the headset to work with your mobile. Once you've done this, your mobile remembers the headset's ID. You can find more details in your Bluetooth headset user guide.


To connect with a Bluetooth headset:

- › Press **MENU**.
- › Scroll to select **Settings**  › **Connectivity** › **Bluetooth** › **Switch on** › **OK** to switch on the Bluetooth function.
- › Scroll to **Search new devices** › **OK**.

Make sure that your headset's Bluetooth is switched on. See your Bluetooth headset user guide for details to connect your mobile and headset.

Transfer files from your mobile using Bluetooth

You can transfer files from your mobile to PC or mobiles Bluetooth.

- › Press **MENU**.
- › Scroll to select **My stuff**  and select your preferred file.
- › Select **Options** › **Send as** › **Bluetooth**.
- › Select **Search** and select the device you want to transfer, then follow the instructions.

Transfer files between your mobile and PC

Connect your mobile and PC using the USB cable. You don't need to install any drivers on your PC. You'll need to make sure that your mobile's memory card is inserted.

- › First insert the USB cable into your handset and your PC.
- › Select **USB Mass Storage**.
- › Open your media folder on your PC. Then drag and drop your preferred tracks between your PC and mobile.

Update your media files




Each time you transfer music, picture or video files from your PC to the mobile including the memory card, you need to do this:

- › Press **MENU**.
- › Scroll to select **My Stuff** > **Update**.

PC synchronisation

You can set up your mobile and PC so that the Contacts, Calendar, SMS and files are up to date and match each other.

For more information, please refer to the PC sync software made for your phone.



11 Troubleshooting, handset safety and maintenance, and index

Any problems, questions or queries?
You'll find the answers here!

- 11.1 Troubleshooting
- 11.3 Safety precautions
- 11.8 Index

Troubleshooting

Having problems with your mobile? See below for a list of common questions. If we can't answer your questions here, then just call us on **333** from your mobile or **0870 7330 333** from another phone.

The phone can't be switched on

Possible reason	Solution
You are not holding the phone down for long enough.	Press and hold.
The battery power is used up.	Charge the battery.
Incorrect battery insertion.	Check and insert the battery correctly.

The phone is switched off automatically

Possible reason	Solution
Low battery power.	Charge the battery.

The call volume is too low

Possible reason	Solution
The call volume has been set too low.	Increase the call volume.

The person you are calling cannot hear your voice

Possible reason	Solution
Call status has been set to mute.	Turn off the mute function on the call menu.
The microphone is too far from the sound source.	Put the phone's microphone closer to your mouth.

The incoming call doesn't ring

Possible reason	Solution
The phone selects silent mode.	Reset the ring type in Profiles to Normal or Loud .
The ring volume has been set too low.	Increase the volume in Profiles.
The call diverting option has been set.	Cancel call diverting in Settings.

The battery can't be charged

Possible reason	Solution
The battery is worn out and the charging time takes too long.	Charge when the phone prompts low battery.
The battery doesn't connect well to the phone.	Ensure the battery has been inserted correctly.

Can't display network

Possible reason	Solution
The USIM card has been incorrectly inserted.	Refer to the USIM card insertion method.

The phone does not recognise the memory card

Possible reason	Solution
The memory card has been incorrectly inserted.	Insert the memory card correctly according to instructions in the user manual.
The memory card has been damaged.	Replace the memory card.

Safety precautions

Usage environment

Please remember to obey the relevant rules and regulations whenever use your phone. This will help keep you and others around you safe.

- Switch off your phone when close to petrol stations, bunkers, chemical factories or explosive areas and follow any safety signs and instructions there. Breaking any rules could cause explosion or injury.
- Using the phone in a plane can cause interference and danger to an aircraft navigation system and network. You must switch off your phone before boarding and make sure your phone is switched off during the whole flight.
- Please place the phone somewhere safe and don't put it on a seat or in places where it could fall and break. To keep safe on the road, please don't use the phone when you're driving. If you must use it, please use the phone on hands-free kit with a fixed cradle (and make sure you still exercise proper control of the vehicle) or stop at a safe location by the roadside before making or answering a call.

Medical devices

Please switch off your phone near electronic medical equipment (such as heart pacemakers, hearing aids etc). Most medical devices can shield the phone's RF signal,

but some can't. If you have any questions or need to find out more, please consult your doctor or medical device manufacturer.

Pacemaker

Pacemaker manufacturers advise keeping a distance between your phone and heart pacemaker of at least 6 inches (15.3cm), or the phone could interfere with the pacemaker.

Anyone wearing a pacemaker should do the following:

- Always keep a distance between the phone and pacemaker of more than 6 inches (15.3cm) when the phone is switched on.
- Avoid carrying the phone in a breast pocket.
- Listen to the phone using the ear on the opposite side of the body to the pacemaker.

Caution

If you are unsure as to the level of interference, please switch off the phone at once and consult a doctor immediately.

Safety precautions

Hearing aids

Phones may cause interference to some hearing aids. If there is any interference, please get in touch with the manufacturers of the hearing aid immediately.


Emergency calls

It is impossible to ensure your phone can be connected successfully in every situation, so please don't rely purely on your phone as the only means of communication in an emergency (such as medical first aid).

Make an emergency call

If your phone is switched off, please turn on your phone and check whether the network signal is strong enough.

You can't use Skype to make emergency calls.

1. Input the local emergency number correctly (such as 999). Different areas have different emergency numbers.
2. Press  to call.

Caution

While making an emergency call, you should try to provide all important information correctly. Don't end the call without being told to do so by the emergency services.

Password access

Your phone and USIM card can be protected by a password to stop others using it without your permission.

Phone password

This protects your handset from unauthorised use by other people. The preset password is 0000. Please modify your handset password as soon as possible and keep it secret.

PIN code

This is a personal identification code which is used to protect the USIM card from unauthorised use by other people. Generally, the PIN code and USIM card are provided together. After activating the PIN code, you can use the handset normally by correctly inputting your password each time.

Caution

If you input your PIN code incorrectly three times in succession, the USIM card will be locked. You will need to input the PUK code to unlock it. (If you don't have a PUK code, please contact your operator and USIM card provider for this information. Please input all characters.)

Safety precautions

PIN2 code

This is the password which activates the special USIM card functions. Usually, the PIN2 code and the USIM card will be provided together. If you incorrectly input the PIN2 code three times in succession, it will be locked and you will need to input PUK2 to unlock it again.

PUK code

This is used to unlock the PIN code. If you incorrectly input the PUK code ten times in a row, then the USIM card cannot be used again. Usually the PUK code and USIM card are provided together. If you lose PUK code or it isn't supplied with USIM card, please contact your network operator or USIM card provider.

PUK2 code

This is used to unlock the PIN2 code. Usually the PUK2 code and the USIM card are provided together. PUK2 can modify the locked PIN2 code. If you incorrectly input the PUK2 code ten times in a row, you will not be able to access some of the functions. Please apply to your operator for a new card. The PUK2 code cannot be changed. If you lose it, please contact your service provider.

Note about charging the battery

The handset provides power by using a lithium battery. How long a charged battery lasts will be influenced by the system's environment and phone settings.

- Please use the battery and charger provided by the AMOI Company. AMOI will take no responsibility for damage caused by using the wrong battery or charger.

Caution

Generally, the charging time is 2-5 hours according to the current status of the phone (whether switched on, making a call, etc).

- Don't touch the handset, battery or charger with wet hands while it's charging.

Caution

To charge a new battery as fully as possible, please charge and discharge the phone twice or three times.

Safety precautions

Battery information and care

- Never use any battery that has been damaged.
 - When you use the handset near a network station, the power consumption is very low, which means that how long you can use your phone before charging the battery depends greatly on the signal strength of the network and other factors.
 - The battery charging time will depend on the amount of electricity remaining and the type of battery and charger used. When the operation time is noticeably shorter than normal, it is time to buy a new battery.
 - Only use batteries that are compatible with your handset and only recharge your battery with a compatible charger. If a charger is not in use, disconnect it from the power source. Do not leave the battery connected to a charger for more than a week, as overcharging may shorten its life.
 - Do not connect the anode and cathode of a battery the wrong way round.
 - Do not leave the battery in places with too high or too low temperature (such as in a car during summer or winter), or the battery capacity will be reduced and battery life will be shortened. Always try to keep the battery at room temperature.
 - Do not short-circuit the battery. This may damage the electronic core or the protected circuit inside the battery. Accidental short-circuiting can take place when a metal object (coin, clip or pen) causes a direct connection between the anode and cathode of the battery, for example when you carry a spare battery in a pocket or bag. Short-circuiting the terminals may damage the battery or the object causing the short-circuiting. So please store the battery carefully and on its own.
 - Don't burn your handset battery or treat it as common rubbish. Please follow the local environmental policy in order to avoid endangering life and causing environmental damage, and recycle your batteries.
 - If your handset, battery or other charging device leaks due to carelessness, you must not put it inside any piece of equipment that heats up (such as drier, microwave etc). The handset or other products may go wrong, and you could even cause the handset, battery or other charging device to burn, expand and explode.
- AMOI will take no responsibility for any direct or indirect damage caused by user error.

Safety precautions

Note about using spare parts

- Please put all spare parts (such as USIM card, storage card, battery, etc) out of reach of children.
- Please switch off the handset and disconnect the handset and charger before removing the battery from the phone.
- As the phone's spare parts are not waterproof, please keep all spare parts dry.
- You should pull out the plug of any spare part correctly when you switch off the power; don't pull strongly on the power line.

If the handset, battery, and charger don't operate normally, please contact one of our maintenance centres with a qualified repair service as soon as possible.

Other safety information

- When you are not using your handset, it is a good idea to switch it off. You can remove the battery to save energy.
- If you use earphones to listen to music or watch a film, please don't turn the volume up too high as this could damage your hearing.
- Don't dismantle the terminal and battery of the phone - this should be left to qualified staff.

Index

B

Battery	
- Charging	1.1
- Power display	2.4

C

Call	
- Conference	5.1
- Features	5.2
- Making	5.1
- Receiving	5.1
- Video call settings	5.2

Contacts

- Accessing	7.1
- Adding	7.1
- Adding Skype	7.1
- Copying	7.2
- Deleting	7.2
- Editing	7.1
- Importing Skype	7.1

E

Extra feature & security	
- Activate and change your USIM PIN	9.2
- Alarm	9.1
- Calculator	9.1
- Calendar	9.1
- Master reset	9.3
- Network settings	9.3

G

Games and apps	8.3
General set up	
- Choosing a text entry method	1.3
- Ringtone	1.2
- Time and date	1.2
- Voicemail and videomail	1.2
- Wallpaper	1.2

I

Inserting	
- Memory card	1.1
- USIM card and battery	1.1
Internet	4.2

M

Menu tree	2.6
Messages	
- Email messages	6.2
- Multimedia messages	6.1
- Setting up your email	6.2
- Text messages	6.1
Multimedia	
- Playing music	8.1
- Taking a photo or video	8.2
- Viewing photos and video clips	8.2
Multitask menu	2.5

P

Phone maintenance	1.4
Power on/ off	1.2

S

Safety notice	11.3
Safety precautions	11.3
Skype	
- Call	5.1
- Chat	6.1
- Sign in	3.1
- Sign out	3.2
- Status	3.2

T

Transfer	10.2
Troubleshooting	11.1

Y

Your phone	
- Back view	2.2
- Front view	2.1
- Keys and navigation	2.1
- Side view	2.2
- Start screen	2.3

Published by Hutchison 3G UK Limited. All rights in this publication are reserved and no part may be reproduced without the prior written permission of the publisher.

© 2007 Hutchison 3G UK Limited. A Hutchison Whampoa company.

Hutchison 3G UK Limited trading as 3 is a service provider. "AMOI" and "AMOI" is the manufacturer of the WP-S1 phone. AMOI has provided the information on its features and use set out in this user guide. © 2007 AMOI.

The contents are believed to be correct at the time of going to press, but any information, products or services mentioned may be modified, supplemented or withdrawn. The provision of any products and services by Hutchison 3G UK Limited is subject to 3's customer terms (available at three.co.uk). The customer terms will take precedence if there is any discrepancy with this publication.

3 and related images, logos and names referred to in this publication are trademarks of the Hutchison Whampoa group of companies.

Designed by Duttons, Bristol. This publication is printed on fully recyclable paper.

DM40198 Sep07



WP-S1 phone user guide

Helpful information

Find out more about 3's services

- › Visit three.co.uk
- › For more information on My3 visit three.co.uk/my3
- › Email customer.services@3mail.com or call customer services on **333 (0870 7330 333)** from another phone).

Useful numbers

	Mobile	Other phones
3 customer services	333	0870 7330 333
Mail (voicemail and email)	123	07782 333 123
Videomail	123	(Select video call option)
Pay As You Go top-up	444	0870 7330 444
Directory enquiries	118 333	118 333
International directory enquiries	118 313	118 313
Disabled and elderly enquiries	195	
Emergency calls	999	999

