

# Concept User Manual

## Volume 3

840 USE 493 00 eng Version 2.5 - SR2

---

---

## Table of Contents



---

**The chapters marked gray are not included in this volume.**

	<b>About the book</b> . . . . .	<b>IX</b>
Chapter 1	General description of Concept . . . . .	1
Chapter 2	New Performance Attributes of Concept 2.5 in Comparison with Concept 2.2 . . . . .	19
Chapter 3	Project structure . . . . .	29
Chapter 4	Creating a Project . . . . .	43
Chapter 5	PLC configuration . . . . .	63
Chapter 6	Main structure of PLC Memory and optimization of memory . . . . .	107
Chapter 7	Function Block language FBD . . . . .	165
Chapter 8	Ladder Diagram LD . . . . .	187
Chapter 9	Sequence language SFC . . . . .	217
Chapter 10	Instruction list IL . . . . .	261
Chapter 11	Structured text ST . . . . .	321
Chapter 12	Ladder Logic 984 . . . . .	363
Chapter 13	DFBs (Derived Function Blocks) . . . . .	389
Chapter 14	Macros . . . . .	425
Chapter 15	Variables editor . . . . .	447
Chapter 16	Project Browser . . . . .	459

---

Chapter 17	Derived data types .....	465
Chapter 18	Reference data editor .....	487
Chapter 19	ASCII Message Editor .....	499
Chapter 20	Online functions .....	515
Chapter 21	Import/Export .....	561
Chapter 22	Documentation and Archiving .....	599
Chapter 23	Simulating a PLC .....	613
Chapter 24	Concept Security .....	625
<b>Appendices</b>	.....	<b>637</b>
	At a Glance .....	637
<b>Appendix A</b>	<b>Tables of PLC-dependent Performance Attributes .....</b>	<b>639</b>
	Introduction .....	639
	Performance of Quantum .....	640
	Performance Attributes of Compact .....	645
	Performance Attributes of Momentum .....	649
	Performance Attributes of Atrium .....	653
<b>Appendix B</b>	<b>Windows interface .....</b>	<b>659</b>
	At a Glance .....	659
B.1	Window .....	661
	At a Glance .....	661
	Window Types .....	662
	Elements of a window .....	663
B.2	Menu commands .....	666
B.3	Dialog boxes .....	668
B.4	Generating a project symbol .....	671
B.5	Online help .....	673
	At a Glance .....	673
	How the Online Help is set out .....	675
<b>Appendix C</b>	<b>List of symbols and short cut keys .....</b>	<b>679</b>
	At a Glance .....	679
C.1	Icon bar .....	681
	At a Glance .....	681
	General icon bar .....	682
	Icon bar in the FBD editor .....	683
	Icon bar in the SFC-Editor .....	684
	Icon bar in the LD editor .....	686
	List of Symbols in the IL and ST Editor .....	687

---

---

	List of Symbols in the LL984-Editor . . . . .	688
	Icons in PLC Configuration . . . . .	689
	Toolbar in the RDE Editor . . . . .	690
C.2	Short cut keys . . . . .	691
	At a Glance . . . . .	691
	General Short Cut Keys . . . . .	692
	Short Cut Keys in the IL, ST and Data Type Editor . . . . .	693
	Short Cut Keys in the FBD and SFC Editor . . . . .	695
	Shortcut keys in the LD-Editor . . . . .	699
	Short Cut Keys in the LL984-Editor . . . . .	705
<b>Appendix D</b>	<b>IEC conformity . . . . .</b>	<b>707</b>
	At a Glance . . . . .	707
D.1	What is the IEC 1131-3 standard? . . . . .	709
	At a Glance . . . . .	709
	General information about IEC conformity . . . . .	710
	IEC Conformity Test . . . . .	711
D.2	IEC standards tables . . . . .	712
	At a Glance . . . . .	712
	Common elements . . . . .	712
	IL (AWL) language elements . . . . .	719
	ST language elements . . . . .	721
	Common graphic elements . . . . .	722
	LD (KOP) language elements . . . . .	723
	Implementation-dependent parameters . . . . .	725
	Error causes . . . . .	728
D.3	Expansions of IEC 1131-3 . . . . .	730
D.4	Text language syntax . . . . .	731
<b>Appendix E</b>	<b>Configuration examples . . . . .</b>	<b>733</b>
	At a Glance . . . . .	733
E.1	Quantum Example - Remote Control with RIO . . . . .	735
	Introduction . . . . .	735
	Editing local drop . . . . .	736
	Editing Remote Drop . . . . .	740
E.2	Quantum Example - Remote control with RIO (series 800) . . . . .	743
	Introduction . . . . .	743
	Editing Local Drop . . . . .	744
	Editing Remote Drop . . . . .	748
E.3	Quantum Example - Remote Control with DIO . . . . .	754
	Introduction . . . . .	754
	Editing Local Drop . . . . .	755
E.4	Quantum Example – INTERBUS Control . . . . .	763
	Introduction . . . . .	763
	General Information . . . . .	764
	Editing Local Drop . . . . .	765

---

---

E.5	Quantum Example - SY/MAX Controller . . . . .	769
	Introduction . . . . .	769
	Editing Local Drop . . . . .	770
	Editing Remote Drop . . . . .	774
E.6	Quantum Example - Profibus DP Controller . . . . .	777
	Introduction . . . . .	777
	General Information . . . . .	778
	Example 7 - Profibus DP Export Settings in SyCon. . . . .	778
	Editing Local Drop . . . . .	780
	Importing Profibus DP Configuration . . . . .	784
E.7	Quantum-Example - Peer Cop. . . . .	791
	At a glance. . . . .	791
	Generals to Peer Cop . . . . .	792
	Configuration of Peer Cop . . . . .	793
	Global data transfer . . . . .	795
	Specific data transfer . . . . .	797
E.8	Compact Example . . . . .	799
	Editing Local Drop . . . . .	799
E.9	Atrium Example – INTERBUS Controller. . . . .	804
	Introduction . . . . .	804
	General Information . . . . .	805
	INTERBUS Export Settings in CMD . . . . .	805
	Editing Local Drop . . . . .	806
	Editing Remote Drop (Importing INTERBUS Configuration) . . . . .	810
E.10	Momentum Example - Remote I/O Bus . . . . .	813
	Introduction . . . . .	813
	General Information . . . . .	814
	Editing local drop . . . . .	814
	Example 10 – Editing Remote Drops (I/O Bus) . . . . .	818
E.11	Momentum Example - Ethernet Bus System. . . . .	821
	Introduction . . . . .	821
	Configure Ethernet. . . . .	822
	Network Configuration in Different Operating Systems . . . . .	823
	Editing local drop . . . . .	833
	Online-Verbindung herstellen . . . . .	836
	<b>Appendix F Convert Projects/DFBs/Macros . . . . .</b>	<b>837</b>
	Converting projects/DFBs . . . . .	837
	<b>Appendix G Concept ModConnect . . . . .</b>	<b>841</b>
	At a Glance . . . . .	841
G.1	Introduction . . . . .	843
G.2	Integration of Third Party Modules. . . . .	844
	At a Glance . . . . .	844
	Integrating new Modules . . . . .	845
	Removing Modules . . . . .	846

---

---

G.3	Use of third party module in Concept . . . . .	847
<b>Appendix H</b>	<b>Conversion of Modsoft Programs . . . . .</b>	<b>849</b>
	At a Glance . . . . .	849
	Introduction . . . . .	850
	How to Convert a Modsoft Program . . . . .	852
	Exceptions. . . . .	853
<b>Appendix I</b>	<b>Modsoft and 984 References . . . . .</b>	<b>855</b>
	At a Glance . . . . .	855
	Modsoft Keys with Concept Equivalents. . . . .	856
	Modsoft Function Compatibility . . . . .	858
<b>Appendix J</b>	<b>Presettings when using Modbus Plus for startup . . . . .</b>	<b>859</b>
	Introduction . . . . .	859
	Installing the SA85 in Windows 98/2000 . . . . .	860
	Installing the SA85 in Windows NT . . . . .	863
	Installing the Modbus Plus Driver in Windows 98/2000/NT. . . . .	865
	Virtual MBX Driver for 16 bit application capability with Windows 98/2000/NT . . . . .	866
	MBX Driver for connection between ModConnect Host interface adapters and 32 bit applications with Windows 98/2000/NT. . . . .	867
	Remote MBX - Driver for Remote Operation. . . . .	868
	Ethernet MBX - Driver for Modbus Plus Function via TCP/IP. . . . .	869
	Establishing the hardware connection. . . . .	871
<b>Appendix K</b>	<b>Presettings when using Modbus for startup . . . . .</b>	<b>873</b>
	Introduction . . . . .	873
	Interface settings in Windows 98/2000 . . . . .	874
	Interface Settings in Windows NT . . . . .	876
	Setting up the hardware connection . . . . .	876
	Transfer problems. . . . .	877
<b>Appendix L</b>	<b>Startup when using Modbus with the EXECLoader . . . . .</b>	<b>879</b>
	Introduction . . . . .	879
	Quantum first startup with EXECLoader . . . . .	880
	Compact first startup with EXECLoader . . . . .	884
	Momentum first startup for IEC with EXECLoader . . . . .	888
	Momentum first startup for LL984 with EXECLoader . . . . .	893
<b>Appendix M</b>	<b>Startup when using Modbus with DOS Loader . . . . .</b>	<b>899</b>
	Introduction . . . . .	899
	Quantum first startup with DOS Loader . . . . .	900
	Compact first startup with DOS Loader. . . . .	903
	Momentum first startup for IEC with DOS Loader. . . . .	906
	Momentum first startup for LL984 with DOS Loader. . . . .	909

---


---

<b>Appendix N</b>	<b>Startup when using Modbus Plus with the EXECLoader . . .</b>	<b>913</b>
	Introduction . . . . .	913
	Quantum first startup with EXECLoader . . . . .	914
	Compact first startup with EXECLoader . . . . .	918
	Atrium first startup with EXECLoader . . . . .	922
	Momentum first startup for IEC with EXECLoader. . . . .	925
	Momentum first startup for LL984 with EXECLoader. . . . .	929
<b>Appendix O</b>	<b>Startup when using Modbus Plus with DOS Loader . . . . .</b>	<b>933</b>
	Introduction . . . . .	933
	Quantum first startup with DOS Loader. . . . .	934
	Compact first startup with DOS Loader . . . . .	937
	Atrium first startup with DOS Loader . . . . .	940
	Momentum first startup for IEC with DOS Loader . . . . .	943
	Momentum first startup for LL984 with DOS Loader . . . . .	946
<b>Appendix P</b>	<b>EXEC files . . . . .</b>	<b>949</b>
	Loading Firmware . . . . .	949
<b>Appendix Q</b>	<b>Settings in the CONCEPT.INI . . . . .</b>	<b>953</b>
	Introduction . . . . .	953
	General information on the Concept INI file. . . . .	954
	INI Print Settings . . . . .	955
	INI Settings for the Register Address Format, for Variable Storage and for Defining the Project Name . . . . .	956
	INI Settings for Global DFBs [Path] [Upload]. . . . .	957
	Representation of Internal Data in the INI File. . . . .	959
	INI Settings for the LD Section. . . . .	959
	INI-Settings for Online Animation [Colors]. . . . .	960
<b>Glossary</b>	<b>. . . . .</b>	<b>961</b>
<b>Index</b>	<b>. . . . .</b>	<b>i</b>



---

## About the book



---

### At a Glance

**Document Scope** This user manual is intended to help you create a user program with Concept. It provides authoritative information on the individual program languages and on hardware configuration.

**Validity Note** The documentation applies to Concept 2.5 for Microsoft Windows 98, Microsoft Windows 2000 and Microsoft Windows NT 4.x.

**Note:** Additional up-to-date tips can be found in the Concept README file.

---

### Related Documents

Title of Documentation	Reference Number
Concept Installation Instructions	840 USE 492 00
Concept IEC Block Library	840 USE 494 00
Concept EFB User Manual	840 USE 495 00
Concept LL984 Block Library	840 USE 496 00

**User Comments** We welcome your comments about this document. You can reach us by e-mail at [TECHCOMM@modicon.com](mailto:TECHCOMM@modicon.com)


---

About the book

---

---

## Appendices



---

### At a Glance

#### Overview

Additional information that is not necessarily required for an understanding of the documentation.

#### What's in this appendix?

The appendix contains the following chapters:

Chapter	Chaptername	Page
A	Tables of PLC-dependent Performance Attributes	639
B	Windows interface	659
C	List of symbols and short cut keys	679
D	IEC conformity	707
E	Configuration examples	733
F	Convert Projects/DFBs/Macros	837
G	Concept ModConnect	841
H	Conversion of Modsoft Programs	849
I	Modsoft and 984 References	855
J	Presettings when using Modbus Plus for startup	859
K	Presettings when using Modbus for startup	873
L	Startup when using Modbus with the EXECLoader	879
M	Startup when using Modbus with DOS Loader	899
N	Startup when using Modbus Plus with the EXECLoader	913
O	Startup when using Modbus Plus with DOS Loader	933
P	EXEC files	949
Q	Settings in the CONCEPT.INI	953


---

Appendices

---

---

## Tables of PLC-dependent Performance Attributes



---

### Introduction

#### Overview

The performance attributes of the different hardware platforms (Quantum, Compact, Momentum and Atrium) can be found in the following tables.

#### What's in this chapter?

This chapter contains the following topics:

Topic	Page
Performance of Quantum	640
Performance Attributes of Compact	645
Performance Attributes of Momentum	649
Performance Attributes of Atrium	653

---

## Performance of Quantum

---

### IEC and LL984 Support

Availability of IEC and LL984 support:

Performance	CPU type					
	113 02	113 03	213 04	424 0x	434 12	534 14
LL984 only	x	-	-	-	-	-
IEC only (Stripped Exec)	x	x	x	-	-	-
IEC and LL984	-	x	x	x	x	x
x = available - = not available						

---

**Special  
Performance  
Attributes**

Availability of special performance attributes:

Performance	CPU type					
	113 02	113 03	213 04	424 0x	434 12	534 14
LL984 Hot Standby	x	x	x	x	x	x
IEC Hot Standby	-	-	-	-	x	x
Interrupt processing with HLI (LL984 only)	x	x	x	x	x	x
Split memory (LL984 only with separate software)	-	-	-	-	-	-
Support for XMIT loadable (LL984 only)	x	x	x	x	x	x
Support for XMIT EFB (IEC only)	-	-	-	-	-	-
Support for XXMIT EFB (IEC only)	x	x	x	x	x	x
Upload of the user program	x	x	x	x	x	x
Support of the Modbus function codes 42 (IEC only)	x	x	x	x	x	x
Password protection of connection structure with PLC	-	-	-	-	-	-
PCMCIA support	-	-	-	-	-	-
Flash memory for program and configuration	-	-	-	-	x	x
Remote Terminal Unit (RTU) configuration extension	-	-	-	-	-	-
Profibus DP configuration extension	x	x	x	x	x	x
Cyclical data exchange for configuration extension	x	x	x	x	x	x
Code generation options: Include diagnosis information	x	x	x	x	x	x

Performance

Performance	CPU type					
	113 02	113 03	213 04	424 0x	434 12	534 14
Code generation options: Fastest code	-	-	x	x	x	x
MMS Ethernet configuration extension	x	x	x	x	x	x
ASCII Messages	x	x	x	x	x	x
Peer Cop	x	x	x	x	x	x
RIO (Remote I/O)	x	x	x	x	x	x
DIO (Distributed I/O)	x	x	x	x	x	x
SYMAX I/O	x	x	x	x	x	x
800 I/O	x	x	x	x	x	x
LonWorks	x	x	x	x	x	x
A120 I/O	-	-	-	-	-	-
x = available - = not available						

Buses

Availability of the buses:

Performance	CPU type					
	113 02	113 03	213 04	424 0x	434 12	534 14
Modbus	x	x	x	x	x	x
Modbus Plus	x	x	x	x	x	x
Ethernet (TCP/IP)	x	x	x	x	x	x
Ethernet (SY/MAX)	x	x	x	x	x	x
Interbus	x	x	x	x	x	x
Interbus: PCP loadable (LL984 only)	x	x	x	x	x	x
Interbus: PCP-EFB (IEC only)	x	x	x	x	-	-
LonWorks (Echelon)	using NOA 611 xx and LL984	using NOA 611 xx and LL984	using NOA 611 xx and LL984	using NOA611 xx and LL984	using NOA 611 xx and LL984	using NOA 611 xx and LL984
MVB (MultiVehicleBus)	-	-	-	-	-	-
x = available - = not available						



**Block Libraries** Availability of the block libraries:

Performance	CPU type					
	113 02	113 03	213 04	424 0x	434 12	534 14
AKFEFB (IEC only)	x	x	x	x	x	x
ANA_IO (IEC only)	x	x	x	x	x	x
COMM (IEC only)	x	x	x	x	x	x
CONT_CTL (IEC only)	x	x	x	x	x	x
DIAGNO (IEC only)	x	x	x	x	x	x
EXPERTS (IEC only)	x	x	x	x	x	x
EXTENDED (IEC only)	x	x	x	x	x	x
FUZZY (IEC only)	x	x	x	x	x	x
HANDTABLEAU (IEC only)	x	x	x	x	x	x
IEC (IEC only)	x	x	x	x	x	x
LIB984 (IEC only)	x	x	x	x	x	x
SYSTEM (IEC only)	x	x	x	x	x	x
LL984 (LL984 only)	x	x	x	x	x	x
x = available - = not available						

**Utilities**

## Availability of utilities:

Performance	CPU type					
	113 02	113 03	213 04	424 0x	434 12	534 14
Concept DFB	x	x	x	x	x	x
Concept EFB	x	x	x	x	x	x
Concept SIM	x	x	x	x	x	x
Concept PLCSIM32	x	x	x	x	x	x
Concept security	x	x	x	x	x	x
Concept EXECLoader	x	x	x	x	x	x
Concept-Converter	x	x	x	x	x	x
Modsoft converter	x	x	x	x	x	x
ModConnect tool	x	x	x	x	x	x
x = available - = not available						

**Runtime System**    Runtime System

Performance	CPU type					
	113 02	113 03	213 04	424 0x	434 12	534 14
16 bit CPU	x	x	x	x	-	-
32 bit CPU	-	-	-	-	x	x
x = available - = not available						

**Available Memory for User Program**

Available memory for user program

Performance	CPU type					
	113 02	113 03	213 04	424 0x	434 12	534 14
IEC only runtime system	125k	375k	612k	-	-	-
IEC and LL984 runtime system	-	160k	330k	460k	800k	2500k
LL984 only runtime system	-	-	-	-	-	-
x = available - = not available						

**Different Performance Attributes**

Availability of different performance attributes:

Performance	CPU type					
	113 02	113 03	213 04	424 0x	534 14	534 14
Battery adapter required for backing up IEC programs	-	-	-	-	-	-
Floating point processor	-	-	x	x	x	x
Floating point emulation (IEC)	x	x	-	-	-	-
x = available - = not available						

## Performance Attributes of Compact

### IEC and LL984 Support

Availability of IEC and LL984 support:

Performance	CPU type			
	258 (512k)	265 (512k)	275 (512k)	285 (1M)
LL984 only	-	-	-	-
IEC only (Stripped Exec)	-	-	-	-
IEC and LL984	x	x	x	x
x = available - = not available				

### Special Performance Attributes

Availability of special performance attributes:

Performance	CPU type			
	258 (512k)	265 (512k)	275 (512k)	285 (1M)
LL984 Hot Standby	-	-	-	-
IEC Hot Standby	-	-	-	-
Interrupt processing with HLI (LL984 only)	-	-	-	-
Split memory (LL984 only with separate software)	x	x	x	x
Support for XMIT loadable (LL984 only)	x	x	x	x
Support for XMIT EFB (IEC only)	-	-	-	-
Support for XXMIT EFB (IEC only)	x	x	x	x
Upload of the user program	x	x	x	x
Support of Modbus function code 42 (IEC only)	x	x	x	x
Password protection of connection structure with PLC	x	x	x	x
PCMCIA support	-	-	x	x
Flash memory for program and configuration	x	x	x	x
Remote Terminal Unit (RTU) configuration extension	x	x	x	x

Performance

Performance	CPU type			
	258 (512k)	265 (512k)	275 (512k)	285 (1M)
Profibus DP configuration extension	-	-	-	-
Cyclical data exchange for configuration extension	-	-	-	-
Code generation options: Include diagnosis information	x	x	x	x
Code generation options: Fastest code	x	x	x	x
MMS Ethernet configuration extension	-	-	-	-
ASCII Messages	-	-	-	-
Peer Cop	-	x	x	x
RIO (Remote I/O)	-	-	-	-
DIO (Distributed I/O)	-	-	-	-
SYMAX I/O	-	-	-	-
800 I/O	-	-	-	-
LonWorks	-	-	-	-
A120 I/O	x	x	x	x
x = available - = not available				

Buses

Availability of the buses:

Performance	CPU type			
	258 (512k)	265 (512k)	275 (512k)	285 (1M)
Modbus	x	x	x	x
Modbus Plus	using BridgeModule	x	x	x
Ethernet (TCP/IP)	using BridgeModule	using BridgeModule	using BridgeModule	using BridgeModule
Ethernet (SY/MAX)	-	-	-	-
Interbus	using BKF xxx	using BKF xxx	using BKF xxx	using BKF xxx

Performance	CPU type			
	258 (512k)	265 (512k)	275 (512k)	285 (1M)
Interbus: PCP loadable (LL984 only)	-	-	-	-
Interbus: PCP-EFB (IEC only)	-	-	-	-
LonWorks (Echelon)	-	-	-	-
MVB (MultiVehicleBus)	x	x	x	x
x = available - = not available				

**Block Libraries**

Availability of block libraries:

Performance	CPU type			
	258 (512k)	265 (512k)	275 (512k)	285 (1M)
AKFEFB (IEC only)	x	x	x	x
ANA_IO (IEC only)	x	x	x	x
COMM (IEC only)	-	x	x	x
CONT_CTL (IEC only)	x	x	x	x
DIAGNO (IEC only)	x	x	x	x
EXPERTS (IEC only)	x	x	x	x
EXTENDED (IEC only)	x	x	x	x
FUZZY (IEC only)	x	x	x	x
HANDTABLEAU (IEC only)	x	x	x	x
IEC (IEC only)	x	x	x	x
LIB984 (IEC only)	x	x	x	x
SYSTEM (IEC only)	x	x	x	x
LL984 (LL984 only)	x	x	x	x
x = available - = not available				

**Utilities**

Availability of utilities:

Performance	CPU type			
	258 (512k)	265 (512k)	275 (512k)	285 (1M)
Concept DFB	x	x	x	x
Concept EFB	x	x	x	x
Concept SIM	x	x	x	x

Performance

Performance	CPU type			
	258 (512k)	265 (512k)	275 (512k)	285 (1M)
Concept PLCSIM32	x	x	x	x
Concept Security	x	x	x	x
Concept EXECLoader	x	x	x	x
Concept-Converter	x	x	x	x
Modsoft converter	x	x	x	x
Concept-ModConnect	-	-	-	-
x = available - = not available				

**Runtime System** Runtime system

Performance	CPU type			
	258 (512k)	265 (512k)	275 (512k)	285 (1M)
16 bit CPU	-	-	-	-
32 bit CPU	x	x	x	x
x = available - = not available				

**Different Performance Attributes**

Availability of different performance attributes:

Performance	CPU type			
	258 (512k)	265 (512k)	275 (512k)	285 (1M)
Battery adapter required for backing up IEC programs	-	-	-	-
Floating point processing	-	-	-	-
Floating point emulation	x	x	x	x
x = available - = not available				

## Performance Attributes of Momentum

### IEC and LL984 Support

Availability of IEC and LL984 support:

Performance	CPU type				
	700 00 700 10 780 00	760 00	760 10 780 10	960 20 980 20	960 30 980 30
LL984 only	x	x	x	x	x
IEC only	-	x	x	-	x
IEC and LL984	-	-	-	-	-
x = available - = not available					

### Special Performance Attributes

Availability of special performance attributes:

Performance	CPU type				
	700 00 700 10 780 00	760 00	760 10 780 10	960 20 980 20	960 30 980 30
LL984 Hot Standby	-	-	-	-	-
IEC Hot Standby	-	-	-	-	-
Interrupt processing with HLI (LL984 only)	-	-	-	-	-
Split memory (LL984 only with separate software)	-	-	-	-	-
Support for the XMIT blocks (LL984 only)	x	x	x	x	x
Support for XMIT EFB (IEC only)	-	-	-	-	-
Support for XXMIT EFB (IEC only)	x	x	x	x	x
Upload of the user program	x	x	x	x	x
Support of Modbus function code 42 (IEC only)	-	x	x	-	x
Password protection of connection structure with PLC	-	-	-	x	x
PCMCIA support	-	-	-	-	-

Performance	CPU type				
	700 00 700 10 780 00	760 00	760 10 780 10	960 20 980 20	960 30 980 30
Flash memory for program and configuration (LL984)	x	x	x	x	x
Flash memory for program and configuration (IEC)	-	-	x	-	x
Remote Terminal Unit (RTU) configuration extension	-	-	-	-	-
Profibus DP configuration extension	-	-	-	-	-
Cyclical data exchange for configuration extension	-	-	-	-	-
Code generation options: Include diagnosis information	-	-	-	-	-
Code generation options: Fastest code	-	-	-	-	-
MMS Ethernet configuration extension	-	-	-	-	-
ASCII Messages	-	-	-	-	-
Peer Cop	x	x	x	x	x
RIO (Remote I/O)	-	-	-	-	-
DIO (Distributed I/O)	-	-	-	-	-
TIO (Terminal I/O)	x	x	x	x	x
SYMAX I/O	-	-	-	-	-
800 I/O	-	-	-	-	-
LonWorks	-	-	-	-	-
A120 I/O	-	-	-	-	-
x = available - = not available					



**Buses**

Availability of the buses:

Performance	CPU type				
	700 00 700 10 780 00	760 00	760 10 780 10	960 20 980 20	960 30 980 30
Modbus (with ring card)	x	x	x	x	x
Modbus Plus (with ring card)	x	x	x	x	x
Ethernet (TCP/IP)	-	-	-	x (LL984 only)	x
Ethernet (SY/MAX)	-	-	-	-	-
Interbus	x	x	x	x	x
Interbus: PCP loadable (LL984 only)	-	-	-	-	-
Interbus: PCP-EFB (IEC only)	-	-	-	-	-
LonWorks (Echelon)	-	-	-	-	-
MVB (MultiVehicleBus)	-	-	-	-	-
x = available - = not available					

**Block Libraries**

Availability of the block libraries:

Performance	CPU type				
	700 00 700 10 780 00	760 00	760 10 780 10	960 20 980 20	960 30 980 30
AKFEFB (IEC only)	-	x	x	-	x
ANA_IO (IEC only)	-	x	x	-	x
COMM (IEC only)	-	-	-	-	x
CONT_CTL (IEC only)	-	x	x	-	x
DIAGNO (IEC only)	-	x	x	-	x
EXPERTS (IEC only)	-	-	-	-	x
EXTENDED (IEC only)	-	x	x	-	x
FUZZY (IEC only)	-	x	x	-	x
HANDTABLEAU (IEC only)	-	-	-	-	x
IEC (IEC only)	-	x	x	-	x
LIB984 (IEC only)	-	x	x	-	x
SYSTEM (IEC only)	-	x	x	-	x

Performance

Performance	CPU type				
	700 00	760 00	760 10	960 20	960 30
	700 10		780 10	980 20	980 30
	780 00				
LL984 (LL984 only)	x	x	x	x	x
x = available - = not available					

Utilities

Availability of utilities:

Performance	CPU type				
	700 00	760 00	760 10	960 20	960 30
	700 10		780 10	980 20	980 30
	780 00				
Concept DFB	-	x	x	-	x
Concept EFB	-	x	x	-	x
Concept SIM	-	x	x	-	x
Concept PLCSIM32	-	x	x	-	x
Concept security	-	x	x	-	x
Concept EXECLoader	x	x	x	x	x
Concept-Converter	x	x	x	x	x
Modsoft converter	x	x	x	x	x
Concept-ModConnect	x	x	x	x	x
x = available - = not available					

Runtime System

Runtime System

Performance	CPU type				
	700 00	760 00	760 10	960 20	960 30
	700 10		780 10	980 20	980 30
	780 00				
16 bit CPU	x	x	x	x	x
32 bit CPU	-	-	-	-	-
x = available - = not available					

**Different Performance Attributes**

Availability of different performance attributes:

Performance	CPU type				
	700 00 700 10 780 00	760 00	760 10 780 10	960 20 980 20	960 30 980 30
Battery adapter required for backing up IEC programs	-	x	-	-	-
Floating point processor	-	-	-	-	-
Floating point emulation (IEC)	-	x	x	-	x
x = available - = not available					

**Performance Attributes of Atrium****IEC and LL984 Support**

Availability of IEC and LL984 support:

Performance	CPU type
	121 01 (2M) 241 01 (4M) 241 01-S908 (4M)
LL984 only	-
IEC only (Stripped Exec)	-
IEC and LL984	x
x = available - = not available	

**Special  
Performance  
Attributes**

Availability of special performance attributes:

Performance	CPU type
	121 01 (2M) 241 01 (4M) 241 01-S908 (4M)
LL984 Hot Standby	-
IEC Hot Standby	-
Interrupt processing with HLI (LL984 only)	-
Split memory (LL984 only with separate software)	-
Support for XMIT loadable (LL984 only)	-
Support for XMIT EFB (IEC only)	-
Support for XXMIT EFB (IEC only)	121 01 (2M): - 241 01 (4M): x 241 01-S908 (4M): -
Upload of the user program	x
Support of Modbus function code 42 (IEC only)	x
Password protection of connection structure with PLC	-
PCMCIA support	-
Flash memory for program and configuration	-
Remote Terminal Unit (RTU) configuration extension	-
Profibus DP configuration extension	-
Cyclical data exchange for configuration extension	-
Code generation options: Include diagnosis information	-
Code generation options: Fastest code	-
MMS Ethernet configuration extension	-
ASCII Messages	-
Peer Cop	x
RIO (Remote I/O)	-
DIO (Distributed I/O)	x
SYMAX I/O	-
800 I/O	-
LonWorks	-
A120 I/O	-
x = available - = not available	

**Buses**

Availability of the buses:

Performance	CPU type
	121 01 (2M) 241 01 (2M) 241 01-S908 (4M)
Modbus	-
Modbus Plus	x
Ethernet (TCP/IP)	-
Ethernet (SY/MAX)	-
Interbus	x x -
Interbus: PCP loadable (LL984 only)	-
Interbus: PCP-EFB (IEC only)	-
S908 I/O Bus	- - x
LonWorks (Echelon)	-
MVB (MultiVehicleBus)	-
x = available - = not available	

**Block Libraries**

Availability of block libraries:

Performance	CPU type
	121 01 (2M) 241 01 (2M) 241 01-S908 (4M)
AKFEFB (IEC only)	x
ANA_IO (IEC only)	x
COMM (IEC only)	-
CONT_CTL (IEC only)	x
DIAGNO (IEC only)	x
EXPERTS (IEC only)	x
EXTENDED (IEC only)	x
FUZZY (IEC only)	x
HANDTABLEAU (IEC only)	x
IEC (IEC only)	x

Performance

Performance	CPU type
LIB984 (IEC only)	x
SYSTEM (IEC only)	x
LL984 (LL984 only)	x
x = available - = not available	

Utilities

Availability of utilities:

Performance	CPU type
Concept DFB	x
Concept EFB	x
Concept SIM	x
Concept PLCSIM32	x
Concept Security	x
Concept EXECLoader	x
Concept-Converter	x
Modsoft converter	x
Concept-ModConnect	-
x = available - = not available	

Runtime System

Runtime system

Performance	CPU type
16 bit CPU	-
32 bit CPU	x
x = available - = not available	

**Different  
Performance  
Attributes**

Availability of different performance attributes:

Performance	CPU type
	121 01 (2M) 241 01 (2M) 241 01-S908 (4M)
Battery adapter required for backing up IEC programs	-
Floating point processor	- x x
Floating point emulation	x - -
x = available - = not available	





---

## Windows interface



# B

---

### At a Glance

#### Overview

The chapter describes the most important properties of Concept's Windows interface. Further information can be found in the Microsoft Windows manuals.

#### What's in this chapter?

This chapter contains the following Sections:

Section	Topic	Page
B.1	Window	661
B.2	Menu commands	666
B.3	Dialog boxes	668
B.4	Generating a project symbol	671
B.5	Online help	673

---

Windows interface

---

---

## B.1 Window

---

### At a Glance

---

#### Overview

This section describes the types of windows and window elements in Windows.

---

#### What's in this section?

This section contains the following topics:

Topic	Page
Window Types	662
Elements of a window	663

---

## Window Types


### Introduction

In Windows there are two types of windows:

- Application Window
- Document Window

Types of window:

Application window (project)



Document window (PLC configuration, section)

### Application Window

When Concept is started the application window is opened on your desktop. The application window can be moved to any position on the desktop. Alternatively it can be minimized to a button on the task bar.

A project can be opened or created in this application window. The name of the project then appears in the title bar of the application window.

**Document Window**

After opening or creating a project you can open different document windows. Document windows are, for example, sections in which a user program is created or the document window of the PLC configuration.


Several document windows can be open simultaneously, but only one of these can be active. An active document window can be recognized by the color of the title bar.

Depending on the active document window the menu commands change in the pull down menus and the tool bar of the application window.

**Elements of a window**

**At a Glance**

This section describes the Concept specific elements of a window. Elements of a window:



**Title bar** A project's title bar shows the name of the active application (i.e. Concept) and the name of the project. When coupled with a PLC the node address of the PLC is indicated in angled brackets (<>). If this PLC is on another network the routing path is also indicated.

If a document window (e.g. a section) is enlarged to full screen, i.e. the section takes up the entire application window, the name of the document window (e.g. the section name) appears in the title bar.

Document windows which are not enlarged to full screen have their own title bar in which the name of the document window is indicated.

---

**Menu Bar** The menu bar of the application window contains various main menus. The contents of the menu bar depend on the active document window.

---

**Toolbar** The toolbar consists of buttons which correspond to a menu command on the pull-down menus. The range and content of the toolbar depend on which window is active.

There are three different ways a button can be represented:

- grayed  
The command is currently unavailable. One or more other commands must be executed before the desired button can be used.
  - unpressed  
The command can be selected.
  - pressed  
The command is active.
- 

**Status bar** The appearance of the status bar depends on whether the project is open and the programming language used in the section.

In the first part of the status bar various information is displayed depending on the selected object.

- If a dialog box is open or a menu command or button has been selected some help will be given about it. To display the help select a menu command or a button with the left mouse button and hold it down. A short description of the menu command or button appears in the status bar. To execute the menu command/button release the mouse button. If execution of the menu command/button is not required, move the pointer away from the active area (the description in the status bar disappears) and then release the mouse button.
- If an FFB, a parameter to an input/output, a step or a transition has been selected, a comment about the selected object is displayed. With parameters and transitions the assigned direct address (only in case of located variables) is also displayed.

The second part of the status bar (status of the active section) indicates whether the section is in animation mode or the section is disabled.

- ANIMATED  
The section is animated.
- INHIBITED  
The section is inhibited and will not be processed.

The third part of the status bar indicates the status of the PLC.

- NOT CONNECTED.  
The programming device is not coupled with a PLC.
- STOPPED  
The program on the PLC is suspended.
- RUNNING: CHANGE CONFIG  
The program on the PLC is running and was connected with the access **Change Configuration**.

In the fourth part of the status bar the program status between the PLC and programming device is displayed. This display only appears if a project is open and the programming device with PLC is online.

- EQUAL  
The program on the programming device and the PLC is consistent.
- UNEQUAL  
The program on the programming device and the PLC is not consistent. To establish consistency use the menu command **Online** → **Download...**
- MODIFIED  
The program on the programming device was modified. The modifications can be made online in the PLC with the menu command **Online** → **Download changes**.

Status bar:

T1 AT %1:00001 Transition T1	ANIMATED	RUNNING:CHANGE CONFIG	EQUAL
------------------------------	----------	-----------------------	-------

## B.2 Menu commands

### Menu commands

#### At a Glance

The titles of the individual menus are displayed in the menu bar. The menu commands are listed in the pull-down menus. As in Windows, each Concept window and dialog box has a system menu. This menu is opened using the small box in the top left-hand corner of the window.

A pull-down menu is opened by left-clicking on the title of the menu. To go directly to a menu command, drag the mouse pointer down the menu and then release the mouse button.

The menu can be closed by clicking on the title of the menu or anywhere outside of the menu.

Typical pull-down menu:

Project	Online	Options	Window	Help
Properties...				
PLC Configuration				
Project <u>B</u> rowser				
Execution sequence...				
Variable declaration...			F8	
ASCII reports...				
Search...			F3	
Trance			SHIFT+F3	
Find Next			F6	
Search results...			F5	
References used...				
Analyze section			ALT+F9	
Analyze program				
Options for code generation...				

#### Underlined letter

A main menu (menu title) and subsequently a menu command can be selected by holding down **Alt** and simultaneously entering the underlined letter in the menu title and then that of the menu command. If, for instance, from the menu **Project** you want to execute the menu command **Search...** press **Alt+P** to open the menu and then **Alt+S** to execute the menu command.



---

<b>Grayed out menu command</b>	The command is currently unavailable. One or more other commands must be executed before the desired menu command can be executed.
<b>Suspension points (...) after the menu command</b>	On execution of this menu command a dialog box appears with options, which must be selected before execution.
<b>Check mark (√) before the menu command</b>	The menu command is active. If the menu command is selected the check mark disappears and the menu command is inactive. The check mark is mostly used to identify active modes (e.g. normal display, dial in mode etc.).
<b>Shortcut keys</b>	The key combinations (e.g. <b>F8</b> , <b>Alt+F9</b> , <b>Ctrl+R</b> ) after the menu command are shortcut keys for executing this menu command. Using this key or key combination the menu command can be selected, without having to open the menu.

---

## B.3 Dialog boxes

### Dialog boxes


#### At a Glance

In Concept dialog boxes are displayed if additional information is required from you in order to perform a particular task. Potentially necessary information is also communicated in this way.

Most dialog boxes contain options which can be selected, textboxes, in which text can be entered, and buttons which can be pressed.

Grayed out options are currently not available. One or more other commands must be executed, or options selected or deselected, before the desired option can be activated.

Concept specific basics of a window:



---

**Command buttons**

Command buttons are used to initiate actions immediately, e.g. executing or aborting a command. Command buttons include e.g. **OK**, **Abort** and **Help**.

Command buttons followed by suspension points (...), open a further dialog box. A command button with a "greater than" sign (>>) extends the active dialog box.

The standard setting is identified by a dark margin. This command button can be selected by pressing **Enter**.

To close a dialog box without executing a command select the command button **Cancel**.

---

**Text boxes**

Information (text) is entered into a text box.

If you enter an empty text box an insertion point appears in the far left of the box. The entered text begins at this insertion point. If text is already present within the respective box, it will be selected and replaced by the new text automatically. The text can, however, also be deleted by pressing **Delete** or **Backspace**.

---

**Lists**

In a list the available selection possibilities are listed. If more possibilities are available than fit into the list, the scrollbar or the arrow keys can be used to move within the list.

As a rule only a single entry can be chosen from the list. There are, however, some cases in which several entries can be chosen, e.g. when opening sections.

---

**One line lists**

A single line list box initially appears as a rectangular box, in which the current selection (the default value) is selected. If the arrow in the right of the box is selected, a list of the available selection possibilities opens. If more possibilities are available than fit into the list, then the scrollbar or arrow keys can be used to move around the list.

---

**Option buttons**

Option buttons represent mutually exclusive options. In each case only one option can be chosen.

The selected option button is identified by a black dot.

If the option name contains an underlined letter, the option button can be activated from any position in the dialog box by holding down **Alt** and entering the underlined letter.

---

**Check box**

A check box next to an option means that the option can be activated or deactivated. Any number of check box options can be activated.

Activated options are identified by an X or a check mark (✓).

If the option name contains an underlined letter, the check box can be activated or deactivated from any position in the dialog box by holding down **Alt** and entering the underlined letter.

---

## B.4 Generating a project symbol

### Generating a project symbol

#### At a Glance

Once a project symbol has been generated, a project can be immediately loaded on opening Concept. In this way one or more program groups can be created, which e.g. contain all the projects in a system, allowing them to be started immediately.

**Note:** A symbol can only be generated for an existing project. Otherwise an error message appears on starting.

#### Generating a symbol for projects

The procedure for generating a project symbol is as follows:

Step	Action
1	Via <b>Start</b> → <b>Settings</b> → <b>Taskbar...</b> open the dialog <b>Taskbar Properties</b> .
2	In the register <b>Start Menu Programs</b> select the command button <b>Add...</b>
3	In the dialog <b>Create Shortcut</b> select the command button <b>Browse...</b>
4	In the dialog <b>Browse</b> move into the Concept installation path and double-click on the file <b>CONCEPT.EXE</b> .  <b>Reaction:</b> The dialog <b>Browse</b> is closed and the file <b>CONCEPT.EXE</b> , with its path, is entered in the text box <b>Command line:</b> e.g. <b>C:\CONCEPT\CONCEPT.EXE.</b>
5	Now add the project path and project name to the command line, e.g. <b>C:\CONCEPT\CONCEPT.EXE C:\PROJECTS\PLANT1.PRJ</b> and confirm the details using <b>Next &gt;</b> .
6	In the dialog <b>Program group</b> select an existing program group for the symbol or create a new one using <b>New folder...</b> Confirm the change using the command button <b>Next&gt;</b> .
7	In the dialog <b>Select program designation</b> select the project name and confirm using the command button <b>Finish</b> .
8	Close the dialog <b>Taskbar Properties</b> using <b>OK</b> . <b>Reaction:</b> The properties dialog is closed and the project symbol is available in the selected folder.
9	Start the project by clicking on the project symbol.

**Generating a  
symbol for DFBs**

In this way symbols can likewise be generated for DFBs. To do this select the file **CCEPTDFB.EXE** in step 4 and add the DFB name and path instead of the project name and path to the command line in step 5.

---

---

## B.5 Online help

---

### At a Glance

---

**Overview** This section describes use of online help.

---

**What's in this section?** This section contains the following topics:

Topic	Page
At a Glance	674
How the Online Help is set out	675

---

## At a Glance

---

### General information

The online help is used to quickly and easily obtain information about the task being performed, the use of an unfamiliar command or the functions, Function Blocks and modules.

The online help is available throughout Concept.

**Note:** The option **Use polygon acceleration** may not be used if the graphics card has hardware acceleration functions. Use of these may still lead to the graphics in the online help being incomplete. A detailed description of how to switch off the acceleration function will be found in the graphics card's user manual.

### Starting the online help

There are several methods of calling up the online help:

- Invoking the contents)
  - There are two methods of invoking the online help contents:
    - To invoke the online help contents, select the menu command **Help** → **Contents**.
    - In the program group Concept open the help symbol.
  - Help with the execution of a menu command
    - There are two methods of invoking help with a menu command:
      - using the mouse)
        - To obtain an explanation select the menu command with the left mouse button, hold down the mouse button, press **F1**, and then release the mouse button.
      - using the keyboard)
        - To obtain an explanation of a menu command, select it and then press **F1**.
  - Help with a dialog
    - There are two methods of invoking help with a dialog:
      - To obtain an explanation of a dialog, click on the command button **Help** in the dialog itself.
      - To obtain an explanation of a dialog, press **F1** in the dialog itself.
  - Help with operating an EFB
    - To obtain an explanation of the operation of the EFB, click on the command button **Help with type** within the dialog with the EFB properties.
  - Help with the operation of a module
    - In the dialog **I/O module selection** click on the command button **Help with module**, to obtain an explanation of the operation of a module.



## How the Online Help is set out


### Introduction

If you start the online help, the Windows Help system opens, containing either

- a table of contents (if you started with **Help** → **Contents** or the icon),
- or containing a description of the dialog (if you started with the **Help** command button),
- or containing a description of an EFB (if you started with the **Help on Type** command button),
- or containing a description of a module (if you started with the **Module Help** command button),

This section describes the Concept specific basics of the online help window.

Online help window:



### Title Bar

The title bar contains the active help file names, or in other words the help project.

### Menu Bar

A description of the standard menu bar can be found in the respective Microsoft Windows manual.

<b>Toolbar</b>	<p>The following buttons are available in Concept:</p> <ul style="list-style-type: none"><li>● <b>Contents</b> This button is used to invoke the online help contents directory. Details about this function can be found in the corresponding Windows Manual. <b>Note:</b> If you jump (See <i>Jump</i>, p. 676) between different help projects and click the <b>Contents</b> button, the contents of the invoked help project (rather than the current one) is displayed. This is a Microsoft error. The Navigator is available to allow you to navigate within the current help project (related topics <i>Navigator</i>, p. 676).</li><li>● <b>Index</b> This button is used to invoke an index for finding help texts. Details about this function can be found in the corresponding Windows Manual. <b>Note:</b> If you want to carry out a search of the whole text, press the <b>Index</b> command button, select the <b>Search</b> index card, choose the desired search function and type in the term you're looking for.</li><li>● <b>Back</b> This button is used to invoke the previously read help text.</li><li>● <b>Print</b> This button is used to print out the current topic (the current help topic).</li><li>● <b>&lt;&lt;</b> This button is used to "browse" the previous help text. This button is used to read the online help like a book. When you have reached the first "page" of the online help (contents directory), the button is hidden.</li><li>● <b>&gt;&gt;</b> This button is used to "browse" to the next help text. This button is used to read the online help like a book. When you have reached the last "page" of the online help, the button is hidden.</li><li>● <b>History</b> When you use this button a window opens which displays all of the help topics that are already open.</li></ul>
<b>Title of Topic</b>	<p>The topic title refers to the title of a chapter from paper documentation. This topic title always remains visible, even if, in the case of long documents, the text is moved in the window.</p>
<b>Navigator</b>	<p>The Navigator is in the topic title. It serves as a navigator inside the help projects.</p>
<b>Jump</b>	<p>A jump can be recognized by the fact it is written in green and is underlined. When you click on a jump, the help text corresponding to this key word/ topic appears. Jumps correspond to "related topics" entries in paper documents, the pages are however removed for your convenience. The invoked help text is then replaced by a new help text.</p>

**Popup**

A popup can be recognized by the fact it is written in green and has a dotted line under it. When you click on a popup, the help text corresponding to this key word appears. Poppers correspond to glossary entries in paper documents, however, the pages here are removed for your convenience. To display the text, a popup window is opened. This popup window may contain further popups. The popup window is cleared by re-clicking on it or pressing any key. This does not replace the present help text.


---

Windows interface

---

---

## List of symbols and short cut keys



---

### At a Glance

#### Description

Each editor and the PLC configuration have their own list of symbols available. This facilitates access to frequently used functions. It is also possible to call up many functions with short cut keys instead of menu commands.

#### What's in this chapter?

This chapter contains the following Sections:

Section	Topic	Page
C.1	Icon bar	681
C.2	Short cut keys	691



---

## C.1 Icon bar

---

### At a Glance

---

**Description** This section describes the icon bar icons. In the icon bars there are editor independent and editor dependent icons.

---

**What's in this section?** This section contains the following topics:

Topic	Page
General icon bar	682
Icon bar in the FBD editor	683
Icon bar in the SFC-Editor	684
Icon bar in the LD editor	686
List of Symbols in the IL and ST Editor	687
List of Symbols in the LL984-Editor	688
Icons in PLC Configuration	689
Toolbar in the RDE Editor	690













---

## General icon bar

---

### Symbols

The table below shows the available symbols and their corresponding menu entry commands:

Symbol	Menu entry command executed
	File → Open...
	File → New section... / New DFB section...
	File → Section open...
	File → Save
	Project → Variable declaration...
	Project → Search...
	Online → Online control...
	Online → Download changes...
	Edit → Reverse: Delete
	Edit → Cut
	Edit → Copy
	Edit → Insert











---



## Icon bar in the FBD editor

### Symbols

















The table shows the additional icons available in the FBD editor and the corresponding menu entry commands (see also *General icon bar*, p. 682):

Symbol	Menu entry command executed
	View → Enlarge
	View → Reduce
	Objects → Select mode
	Objects → Link
	Objects → FFB: Last Type
	Objects → Invert Input/Output
	Objects → Text
	Objects → Select FFB...
	Online → Animate selection
	Online → Animate binary values





## Icon bar in the SFC-Editor

### Symbols

The table shows the additional icons available in the SFC editor and the corresponding menu entry commands (see also *General icon bar*, p. 682):

Symbol	Menu entry command executed
	View → Enlarge
	View → Reduce
	Objects → Selection mode
	Objects → Select column structure
	Objects → Select row structure
	Objects → Step
	Objects → Transition
	Objects → Parallel branch
	Objects → Parallel merge
	Objects → Alternative branch
	Objects → Alternative merge
	Objects → Jump
	Objects → Link
	Objects → Step transition sequence
	Objects → Structured parallel chain
	Objects → Structured alternative chain

---

















Symbol	Menu entry command executed
	Objects → Transition step sequence
	Objects → Text
	Online → Animation
	Online → Animation control command

---

## Icon bar in the LD editor

### Symbols

The table shows the additional symbols available in the LD editor and the corresponding menu entry commands (please also refer to the *General icon bar*, p. 682):

Symbol	Menu entry command executed
	View → Enlarge
	View → Reduce
	Objects → Select Mode
	Objects → Link
	Objects → Direct Link
	Objects → Vertical Link
	Objects → FFB: Last Type
	Objects → Invert Input/Output
	Objects → Text
	Objects → Select FFB...
	Objects → Coil
	Objects → Coil Negative
	Objects → Contact - on
	Objects → Contact - off
	Online → Animate selection
	Online → Animate binary values




---

## List of Symbols in the IL and ST Editor

---

### Symbols

The table shows the additional symbols available in the IL and ST editor and the corresponding menu entry commands (see also *General icon bar*, p. 682):

Symbol	Menu Entry Command Executed
	<b>Objects → Add FFB</b>
	<b>Online → View Selections</b>
	<b>Online → Animate binary values</b>












---

## List of Symbols in the LL984-Editor

---

### Symbols

The table shows the additional symbols available in the LL984 editor and the corresponding menu entry commands (see also *General icon bar*, p. 682):















Symbol	Menu Entry Command Executed
	Objects → Select Mode
	Objects → Coil
	Objects → Coil - buffered
	Objects → Horizontal Link
	Objects → Vertical Link
	Objects → Contact – N.O.
	Objects → Contact – Open.
	Objects → Contact – Positive Edge.
	Objects → Contact – Negative Edge.
	Objects → Instruction: Last Type
	Objects → Select instruction...

---

## Icons in PLC Configuration

### Icons

The table shows the icons also available in PLC configuration and their allocated menu commands (related topics: *General icon bar*, p. 682):







Icon	Executed menu command
	PLC configuration → PLC Type...
	PLC configuration → Memory Partitions...
	PLC configuration → ASCII Setup...
	PLC configuration → Loadables...
	PLC configuration → Config. Extension...
	PLC configuration → Segment scheduler...
	PLC configuration → I/O Map...
	PLC configuration → Data Access Protection...
	PLC configuration → Peer Cop...
	PLC configuration → Ethernet / I/O Scanner...
	PLC configuration → Hot Standby...
	PLC configuration → ASCII Port Settings...
	PLC configuration → Modbus Port Settings...
	PLC configuration → Specials...

## Toolbar in the RDE Editor

---

### Icons

The table shows the icons also available in the RDE Editor and their allocated menu commands (see also *General icon bar*, p. 682):

Icon	Executed menu command
	Template → New Template...
	Template → Open Template...
	Template → Save Template
	Online → Animate
	Online → Download Reference Data
	Online → Get CSL
	Online → Delete CSL

---



---

## C.2 Short cut keys

---

### At a Glance

---

**Description** This section describes the available short cut keys. There are editor independent and editor dependent short cut keys.

---

**What's in this section?** This section contains the following topics:

Topic	Page
General Short Cut Keys	692
Short Cut Keys in the IL, ST and Data Type Editor	693
Short Cut Keys in the FBD and SFC Editor	695
Shortcut keys in the LD-Editor	699
Short Cut Keys in the LL984-Editor	705

---

## General Short Cut Keys

### Short Cut Keys

The table shows the short cut keys available and the corresponding menu entry command:

Short Cut Keys	Menu Entry Command Executed
<b>F1</b>	Calls the context-sensitive online help. Use this key to call up an explanation of the menu entry command or dialog chosen. In dialogs, this key corresponds to the menu entry command <b>Help</b> .
<b>Ctrl+F4</b>	<b>System menu (for the document window) → Close document window</b>
<b>Ctrl+F6</b>	<b>System menu (for the document window) → Next</b>
<b>Ctrl+S</b>	<b>Data file → Save project/save DFB</b>
<b>Alt+F4</b>	<b>Data file → Quit the application window (Concept-Application)</b>
<b>F8</b>	<b>Project → Address Declaration...</b>
<b>F3</b>	<b>Project → Search</b>
<b>Shift+F3</b>	<b>Project → Trace</b>
<b>F5</b>	<b>Project → Search results</b>
<b>F6</b>	<b>Project → Advanced search</b>
<b>Alt+F9</b>	<b>Project → Analyze section</b>
<b>Ctrl+P</b>	<b>Online → Online-Control...</b>
<b>F9</b>	<b>Online → Trigger single cycle</b>
<b>Ctrl+R</b>	<b>Online → Reference Data Editor</b>
<b>Shift+F5</b>	<b>Window → Overlapping</b>
<b>Shift+F4</b>	<b>Window → Adjacent</b>

## Short Cut Keys in the IL, ST and Data Type Editor

### Calling up menu command entries

The table shows the short cut keys available in the IL, ST and Data Type Editor and the corresponding menu entry commands (see also *General Short Cut Keys*, p. 692):

Key	Menu Entry Command Executed
Ctrl+Z	Edit → Reverse: Delete
Ctrl+X	Edit → Cut
Ctrl+C	Edit → Copy
Ctrl+V	Edit → Add
Del	Edit → Delete
Ctrl+G	Edit → Go to line...
Ctrl+J	Edit → Go to opposite part...
Ctrl+E	Edit → Expand instruction
Alt+F8	Edit → Search for variables
Ctrl+F	Edit → Advanced search
Ctrl+H	Edit → Replace...
Ctrl+Y	Online → Animate binary values
Ctrl+I	Online → Check Selections
Ctrl+W	Online → View Selections

### Moving insertion marks in the text

Moving insertion marks in the text:

Key	Moving
Down	Onto the next line
Up	Onto the previous line
Ctrl+G	Onto a specific line
End	To the end of the line
Home	To the beginning of the line
Picture up	Into the next window
Picture up	Into the previous window
Ctrl+Right	To the next word
Ctrl+Left	To the previous word
Ctrl+End	To the end of the document
Ctrl+Home	To the beginning of the document

**Deleting text**

Deleting text:

Key	Function
<b>Backspace Key</b> (Delete backwards)	Deleting a mark (or deleting marked text) to the left of the insertion mark.
<b>Del</b>	Deleting a character (or deleting marked text) to the right of the insertion mark.
<b>Ctrl+Backspace key</b> (Delete backwards)	Deleting a line

---

**Marking text**

Marking text:

Key	Extending the marking
<b>Shift+Right</b>	to the next character
<b>Shift+Left</b>	to the previous character
<b>Ctrl+Shift+Right</b>	to the next word
<b>Ctrl+Shift+Left</b>	to the previous word
<b>Shift+Down</b>	to the next line
<b>Shift+Up</b>	to the previous line
<b>Shift+End</b>	to the end of the line
<b>Shift+Home</b>	to the beginning of the line
<b>Shift+Picture down</b>	to a window underneath
<b>Shift+Picture up</b>	to a window above
<b>Ctrl+Shift+Picture down</b>	to the end of the current window
<b>Ctrl+Shift+Picture up</b>	to the beginning of the current window
<b>Ctrl+Shift+End</b>	to the end of the document
<b>Ctrl+Shift+Home</b>	to the beginning of the document

---

**Editing text**

Editing text:

Key	Function
<b>Ctrl+X</b>	Deleting marked text and saving in the clipboard
<b>Ctrl+C</b>	Copying marked text and saving in the clipboard
Entering the new text	Replacing marked text
<b>Del</b>	Deleting marked text without saving in the clipboard
<b>Ctrl+V</b>	Replacing marked text with text from the clipboard.
<b>Ctrl+F</b>	Searching for text
<b>Ctrl+R</b>	Replacing text

**Short Cut Keys in the FBD and SFC Editor****At a Glance**

Concept supports the work with the keyboard in the graphic editors. Although the mouse is a more appropriate input tool, it is nevertheless possible to operate Concept with the keyboard alone – especially in machine environments. The editors behave in the same way regardless of whether they are operated with the mouse or with the keyboard.

**Rules**

The following general rules need to be observed:

- The space bar corresponds to the left mouse button, i.e. the space bar is used for selecting and moving.
- The enter key corresponds to the double click with the left mouse button – for example, the input key is used to call up the properties dialog of objects.
- The shift key is used in conjunction with the keyboard exactly as it is with the mouse – for example, the shift key is used to extend an object selection or to reselect a few objects from a number which have already been selected.

**Calling up menu command entries**

The table shows the short cut keys available in the FBD and SFC editor and the corresponding menu entry commands (see also *General Short Cut Keys, p. 692*):

Key	Menu Entry Command Executed
Ctrl+A	Edit → Select All
Ctrl+Z	Edit → Reverse: Delete
Ctrl+X	Edit → Cut
Ctrl+C	Edit → Copy
Ctrl+V	Edit → Add
Del	Edit → Delete
Ctrl+O	Display → Overview
Ctrl+N	Display → Normal
Ctrl+E	Display → Expanded (only in SFC)
Ctrl++	Display → Enlarge
Ctrl+-	Display → Reduce
Ctrl+Y	In the FBD Editor: Online → Animate binary values In SFC-Editor: Online → Animation
Ctrl+W	Online → Selection animate (in FBD)

**Moving the cursor**

Moving the cursor:

Key	Function
<b>Cursor keys</b>	The <b>cursor keys</b> move the cursor inside the document window. The cursor is moved further around a Pixel. If the cursor is at the edge of the document window, pressing the cursor keys again will page the document window in the corresponding direction.
<b>Ctrl+Cursor Keys</b>	When the <b>Strg</b> key is pressed, the <b>cursor keys</b> move the cursor inside the document window. The cursor is moved further around a logical unit (depending on the active editor). If the cursor is at the edge of the document window, pressing the <b>cursor keys</b> again will page the document window in the corresponding direction
<b>Home</b>	The <b>Pos1</b> key moves the cursor to the left-hand edge of the document window.
<b>End</b>	The <b>End</b> key moves the cursor to the right-hand edge of the document window.

**Scrolling**

## Scrolling:

Key	Function
<b>Ctrl+Home</b>	When the <b>Ctrl</b> key is pressed, the <b>Pos1</b> key moves the document window to the upper left-hand corner of the section.
<b>Ctrl+End</b>	When the <b>Ctrl</b> key is pressed, the <b>End</b> key moves the document window to the lower right-hand corner of the section.
<b>Picture up</b>	The <b>picture up</b> key scrolls the document window one screen page upwards, while the cursor remains in the same position in the document window.
<b>Picture down</b>	The <b>picture down</b> key scrolls the document window one screen page downwards, while the cursor remains in the same position in the document window.
<b>Ctrl+Picture up</b>	When the <b>Ctrl</b> key is pressed, the <b>Picture up</b> key scrolls the document window one page to the left while the cursor remains in the same place in the document window.
<b>Ctrl+Picture down</b>	When the <b>Ctrl</b> key is pressed, the <b>Picture down</b> key scrolls the document window one page to the right while the cursor remains in the same place in the document window.

**Edit**

## Edit

Key	Function
<b>Space bar</b>	In select mode, the object at the cursor position is selected and all other objects are deselected. In placing mode the corresponding object is placed where the cursor is.
<b>Shift key+Space bar</b>	In selection mode, when the <b>Shift</b> key is pressed, objects which have not previously been selected in the cursor position are selected, or vice versa. The selection of all other objects is not affected. In placing mode the corresponding object is placed where the cursor is.
<b>Space bar+Cursor Keys</b>	In selection mode – if there is no selected object where the cursor is – the cursor moves and a selection rectangle is displayed. If a selected object is in the cursor position, all objects will be shifted according to how the cursor is moved. The number of inputs of an FFB with a variable input number can be changed in the FB Editor's Selection Mode by placing the cursor on the rectangle in the middle of the lower edge of the selection frame, which holds down the <b>Space bar</b> and presses the <b>Up</b> or <b>Down</b> keys. The width of the branches or connections can be changed in the SFC Editor's Selection Mode by placing the cursor on the rectangle of the selection frame, which holds down the <b>Space bar</b> and presses the <b>Right</b> or <b>Left</b> keys. In Link Mode, a link is produced by dragging the mouse.

Key	Function
<b>Shift key+Space bar+Cursor keys</b>	In Selection Mode, this key combination creates a selection frame as described above, and the selection of all other objects is retained.

---

**Allocating variables onto an FFB**

To allocate variables onto an FFB, do the following:

Step	Action
1	Use the <b>cursor keys</b> or <b>Shift+cursor keys</b> to move the cursor to the input/output of the FFB.
2	Press <b>Enter</b> .  <b>Reaction:</b> The link FFB <b>dialog</b> for the selected input/output opens.

---

**Changing variables onto an FFB**

To change variables onto an FFB, do the following:

Step	Action
1	Use the <b>cursor keys</b> or <b>Shift+cursor keys</b> to move the cursor to the FFB variables to be changed.
2	Press <b>Enter</b> .  <b>Reaction:</b> The link FFB <b>dialog</b> for the selected input/output opens.

---

**Changing the number of inputs/outputs**

To change the number of inputs/outputs with extendable FFBs, do the following:

Step	Action
1	Use the <b>cursor keys</b> or <b>Shift+cursor keys</b> to move the cursor to the centre of the lower edge of the FFB's block frame.
2	Press <b>Space bar+Down cursor key</b> to generate further inputs/outputs. Press <b>Space bar+Up cursor key</b> to hide further inputs/outputs.  <b>Reaction:</b> The number of inputs/outputs is changed.

---



## Shortcut keys in the LD-Editor

---

### At a Glance

Concept supports the work with the keyboard in the graphic editors. Although the mouse is a more appropriate input tool, it is nevertheless possible to operate Concept with the keyboard alone – especially in machine environments. The Editors behave in the same way regardless of whether they are operated with the mouse or with the keyboard.

---

### Rules

The following general rules need to be observed:

- The space bar corresponds to the left mouse button, i.e. the space bar is used for selecting and moving.
  - The Enter key corresponds to the double click with the left mouse button – for example, the input key is used to call up the properties dialog of objects.
  - The Shift key is used in conjunction with the keyboard exactly as it is with the mouse – for example, the Shift key is used to extend an object selection or to reselect a few objects from a number which have already been selected.
  - Pressing a key only once only affects the element in the center of the current cell.
  - Pressing a key together with **Ctrl** affects the right side of the current cell..
  - Striking a key together with **Shift** affects the left side of the current cell
-

**Calling up menu command**

The table shows the additional shortcut keys and their corresponding menu commands available in LD Editor (see also *General Short Cut Keys, p. 692*):

Key	Menu Entry Command Executed
Ctrl+A	Edit → Select All
Ctrl+Z	Edit → Reverse: Delete
Ctrl+X	Edit → Cut
Ctrl+C	Edit → Copy
Ctrl+V	Edit → Add
Del	Edit → Delete
Ctrl+O	Display → Overview
Ctrl+N	Display → Normal
Ctrl++	Display → Enlarge
Ctrl+-	Display → Reduce
Esc	Objects → Select Mode
Shift+H	Objekts → Link
H	Objects → Direct Link
V	Objects → Vertical Link
F	Objects → FFB: Last Type
I	Objects → Invert Input/Output
T	Objects → Text
Shift+F	Objects → select FFB...
C	Objects → Contact N.O.
L	Objects → Contact – Open.
P	Objects → Contact Positive Flank
N	Objects → Contact Negative Flank
Shift+C	Objects → Coil
Shift+L	Objects → Coil Negative
Shift+S	Objects → Coil Set
Shift+R	Objects → Coil Reset
Shift+P	Objects → Coil Positive Flank
Shift+N	Objects → Coil Negative Flank
Ctrl+Y	Online → Animate binary values
Ctrl+W	Online → Animate selection

---

**Placing objects**

In order to place objects in the LD Editor by using the keyboard, please carry out the following steps:

Step	Action
1	Move the field with a gray background onto the field where the object is to be placed (move gray field (selecting a field)).
2	Strike the key assigned to the object (see <i>Creating objects, p. 704</i> ).  <b>Reaction:</b> Adjoining boolean objects are automatically connected.
3	Links between non-adjoining objects and non-boolean in/outputs have to be made with the mouse pointer (see <i>Moving the mouse pointer, p. 703</i> ).
4	The mouse pointer must also be used to invert in/outputs (see <i>Moving the mouse pointer, p. 703</i> ).

**Moving the gray field (selecting a field)**

Moving the gray field (selecting a field)

Key	Function
<b>Up</b>	Moves the gray field up by one field
<b>Down</b>	Moves the gray field down by one field
<b>To the right</b>	Moves the gray fields to the right by one field
<b>To the left</b>	Moves the gray fields to the left by one field
<b>Home</b>	Moves the gray field to the left margin
<b>Shift+Home</b>	Moves the gray field to the left margin
<b>End</b>	Moves the gray field to the right margin
<b>Shift+End</b>	Moves the gray field to the right margin
<b>Ctrl+Home</b>	Moves the gray field to the top left-hand corner
<b>Ctrl+End</b>	Moves the gray field to the top right-hand corner

**Selecting objects**    Selecting objects

Key	Function
<b>Space character</b>	Selects object in the middle of the gray field
<b>Ctrl+Space character</b>	Selects object on the right-hand side of the gray field
<b>Shift+Space character</b>	Selects object on the left-hand side of the gray field
<b>Enter</b>	In select mode: Selects object in the middle of the gray field and opens its Select dialog (if available)
<b>Ctrl+Enter</b>	In select mode: Selects object from the right-hand side of the gray field and opens its Select dialog (if available)
<b>Shift+Enter</b>	In select mode: Selects object from the left-hand side of the gray field and opens its Select dialog (if available)

---

**Moving a selected object**

Moving a selected object

Key	Function
<b>Shift+Up</b>	Moves the selected object up by one field
<b>Shift+Down</b>	Moves the selected object down by one field
<b>Shift+Right</b>	Moves the selected object to the right by one field
<b>Shift+Left</b>	Moves the selected object to the left by one field

---

**Allocating variables onto an FFB**

To allocate variables onto an FFB, do the following:

Step	Action
1	Move the gray field onto the cell containing the in/output.
2	To allocate variables to inputs, press <b>Ctrl+Enter</b> . To allocate variables to outputs press <b>Ctrl+Enter</b> .  <b>Reaction:</b> The Dialog <b>connect FFB</b> of the selected in/output is opened.

---

**Changing variables onto an FFB**

To change variables onto an FFB, do the following:

Step	Action
1	Move the gray field onto the cell containing the variable to be changed.
2	To select the variable press <b>Shift+Enter</b> .  <b>Reaction:</b> The Dialog <b>connect FFB</b> of the selected in/output is opened.

**Deleting vertical links**

To delete vertical variables, carry out the following step:

Step	Action
1	Move the gray field onto the cell running through the vertical link.
2	Press <b>Ctrl+Delete</b> .  <b>Reaction:</b> The vertical link is deleted.

**Moving the mouse pointer**

Moving the mouse pointer

Key	Function
<b>Ctrl+Up</b>	Moving the mouse pointer up by one step
<b>Ctrl+Down</b>	Moving the mouse pointer down by one step
<b>Ctrl+Right</b>	Moving the mouse pointer to the right by one step
<b>Ctrl+Left</b>	Moving the mouse pointer to the left by one step

**Scrolling**

Scrolling:

Key	Function
<b>Picture up</b>	Scrolls the display sector one page up
<b>Shift+Picture up</b>	Scrolls the display sector one page up
<b>Picture down</b>	Scrolls the display sector one page down
<b>Shift+Picture down</b>	Scrolls the display sector one page down
<b>Ctrl+Picture up</b>	Scrolls the display sector one page to the right
<b>Ctrl+Picture down</b>	Scrolls the display sector one page to the right

**Creating objects**      Creating objects

Key	Function
<b>C</b>	Creates a N.O. in the gray field
<b>L</b>	Creates an opener in the gray field
<b>P</b>	Creates a contract for the recognition of positive flanks in the gray field
<b>N</b>	Creates a contract for the recognition of negative flanks in the gray field
<b>Shift+C</b>	Creates a coil in the gray field
<b>Shift+L</b>	Creates a negated coil in the gray field
<b>Shift+S</b>	Creates a coil set in the gray field
<b>Shift+R</b>	Creates a reset coil in the gray field
<b>Shift+P</b>	Creates a coil for the recognition of positive flanks in the gray field
<b>Shift+N</b>	Creates a coil for the recognition of negative flanks in the gray field
<b>Shift+F</b>	Opens FFB selection dialog
<b>F</b>	Creates current FFB in the gray field

---

**Creating links**      Creating links

Key	Function
<b>H</b>	Activates the link mode
<b>V</b>	Creates a vertical link in the right-hand bottom corner of the gray field (and then moves the gray field to the right by one field)
<b>Shift+V</b>	Creates a vertical link in the bottom left-hand corner of the gray field.

---

**Activating the different modes**      Activating the different modes

Key	Function
<b>Space character</b>	Activates the selection mode
<b>Esc</b>	Activates the selection mode
<b>H</b>	Activates the link mode
<b>I</b>	Activates the mode for inverting in/outputs
<b>T</b>	Activates the text mode

## Short Cut Keys in the LL984-Editor

### Short Cut Keys

The table shows the additional short cut keys available in the LL984 editor and the corresponding menu entry commands (see also *General Short Cut Keys, p. 692*):

Short Cut Keys	Menu Entry Command Executed
Ctrl+Z	Edit → Reverse: Delete
Ctrl+X	Edit → Cut
Ctrl+C	Edit → Copy
Ctrl+V	Edit → Add
Del	Edit → Delete
Ctrl+D	Edit → DX Zoom...
Ctrl+H	Edit → Offset References...
Ctrl+O	Display → Overview
Ctrl+N	Display → Normal
Ctrl+E	Display → Expand
Ctrl++	Display → Enlarge
Ctrl+-	Display → Reduce
(	Objects → Coil
Ctrl+L	Objects → Coil - buffered
"	Objects → Contact – N.O.
/	Objects → Contact – Open.
P	Objects → Contact – Positive Edge.
N	Objects → Contact – Negative Edge.
=	Objects → Horizontal Link
I	Objects → Vertical Link
Ctrl+F	Objects → Instruction by name...
Ctrl+G	Network → Go to...
Ctrl+I	Networks → Add
Ctrl+Q	Networks → Add formula
Ctrl+A	Networks → Attach
Ctrl+U	Networks → Attach formula
Ctrl+K	Networks → Delete
Picture up	Networks → Next
Picture up	Networks → Previous
Ctrl+M	Networks → Commentary

List of symbols and short cut keys

---

<b>Short Cut Keys</b>	<b>Menu Entry Command Executed</b>
<b>Ctrl+T</b>	<b>Online → Trace</b>
<b>Ctrl+B</b>	<b>Online → Retrace</b>

---



---

## IEC conformity



D

---

### At a Glance

#### Overview

This Chapter contains the standards tables required by IEC 1131-1.

#### What's in this chapter?

This chapter contains the following Sections:

Section	Topic	Page
D.1	What is the IEC 1131-3 standard?	709
D.2	IEC standards tables	712
D.3	Expansions of IEC 1131-3	730
D.4	Text language syntax	731

IEC conformity

---

---

## D.1 What is the IEC 1131-3 standard?

---

### At a Glance

---

**Overview** This section contains general information about IEC 1131-3 and the implemented IEC conformity test.

---

**What's in this section?** This section contains the following topics:

Topic	Page
General information about IEC conformity	710
IEC Conformity Test	711

---

## General information about IEC conformity

---

### At a Glance

The IEC standard 1131-3 (compare chapter 1.4) specifies the syntax and semantics of a standardized series of programming languages for Programmable Logic Controls (PLC). These include the two text languages IL (Instruction List) and ST (Structured Text) and the two graphical languages LD (Ladder Diagram) and FBD (Function Block Diagram).

It also defines the elements of the sequential function chart (SFC) language for structuring the internal organization of PLC programs and Function Blocks. Configuration elements, used for installing PLC programs onto PLC systems, are also defined.

**Note:** Concept uses the English acronyms for the programming languages.

Furthermore, it defines methods to enable communication between the PLC and other automated system components.

---

### Concept standard accordance

In accordance with the standard, the present version of the programming system Concept supports a subset of language elements, which are defined in the standard.

In this context, accordance with the standard means the following:

- The standard allows the individual implementing an IEC program system to select or deselect certain language properties or even complete languages from the selection tables, which represent an integrated part of the standard specifications. A system, which itself accords with the standard, may only implement the selected properties exactly as they are given in the standard.
  - In addition, the standard enables the individual implementing to introduce defined language elements into an interactive programming environment. As the standard expressly emphasizes that the specification of such environments lies outside of its area of application, the person implementing has a certain degree of freedom to offer optimized forms of display and implementation mechanisms for the benefit of the user.
  - Concept uses these degrees of freedom e.g. when introducing the term "Project" to implement the IEC language elements "Configuration", "Resource" and "Program" all together (Concept only supports one single cyclically running program within a single resource within the configuration). Apart from this, it uses them, for example, with implementation mechanisms made available for declaring variables and authorizing Function Blocks.
-

---

**IEC standards tables**

Information on which properties are supported and other implementation specific details can be found in the following statements on standard fulfilment and the associated standards tables.

---

**IEC Conformity Test**

---

**Testing the Import/Export Interface**

An interface for importing standard IEC programs and DFBs from ASCII files (menu **File** → **Import**) and exporting these programs into graphical languages in ASCII format (menu **File** → **Export**) is available in Concept. The conformity of this interface can be tested using files which can be obtained from IFAK (Institut für Automation und Kommunikation e.V. Magdeburg).

IEC conformity test scripts:

(c) 1994, IFAK Institut für Automation und Kommunikation e.V.  
Magdeburg  
Steinfeldstraße 3  
D-39179 Barleben

---

**Notes**

The following points must be considered with regard to the conformity of the import interface:

- In Concept, IL operators are permitted as identifiers.  
R, S, LD, S1 and R1 are possible parameter names. Therefore, there will be no changes made to the standard functions/function blocks. Concept requires no change in the IEC table 54 with S to SET, R to RESET, S1 to SET1, R1 to RESET1.
  - All IL operators not in conflict with functions are permitted as variable names in Concept (N, S, R, S1, R1, CLK, CU, CD, PV, IN, PT) – contrary to IEC table 54.
  - Counter EFBs must be typified in Concept, e.g. CTU must become CTU\_INT.
  - Function block instances cannot be called up more than once; a restriction that is self-evident if IEC table 53, property 3 is required.
  - An overflow of time span variables (e.g. t#100s) is not detected. The system calculates the time correctly, so that detection of an overflow is not necessary.
  - IEC IL comments are only permitted as the last element in a line. Concept allows comments to be made everywhere.
-

## D.2 IEC standards tables

### At a Glance

**Overview** This system fulfils the requirements of the IEC 1131-3 in the following properties of the language.

**What's in this section?** This section contains the following topics:

Topic	Page
Common elements	712
IL (AWL) language elements	719
ST language elements	721
Common graphic elements	722
LD (KOP) language elements	723
Implementation-dependent parameters	725
Error causes	728

### Common elements

**IEC standards table** IEC standards table for common elements:

Table number	Property number	Property description
1	1	For required character set – see <i>Chapter 2.1.1</i> of 1131-3
1	2	Lower case characters
1	3a	Hash key (#)
1	4a	Dollar sign (\$)
1	5a	Vertical line ( )
1	6a	Left and right square brackets "[ ]"
2	1	Upper case character and numbers
2	2	Upper and lower case characters, numbers, embedded underscore
2	3	Upper and lower case characters, numbers, leading and embedded underscore
3	1	Comments

Table number	Property number	Property description
4	1	Integer (whole number) literals
4	2	Real literals
4	3	Real literals with exponents
4	4	Base 2 literals
4	5	Base 8 literals
4	6	Base 16 literals
4	7	Boolean zero and one
4	8	Boolean FALSE and TRUE
7	1a	Time span without underscores: short prefix
7	1b	Time span without underscores: long prefix
7	2a	Time span with underscores short prefix
7	2b	Time span with underscores long prefix
10	1	BOOL: Boolean
10	3	INT: Integer
10	4	DINT: Double integer
10	7	UINT: Signed integer
10	8	UDINT: Signed double integer
10	10	REAL: Floating point number
10	12	TIME: Time span
10	17	BYTE: Bit sequence 8
10	18	WORD: Bit sequence 16
12	4	Data types for fields
12	5	Data types for structures
15	1	I: Input ( <i>Note 1, p. 717</i> )
15	2	Q: Output ( <i>Note 2, p. 717</i> )
15	4	X: Bit size ( <i>Note 2, p. 717, Note 1, p. 717</i> )
15	5	no prefix: Bit size ( <i>Note 2, p. 717, Note 1, p. 717</i> )
15	6	B: Byte size ( <i>Note 2, p. 717, Note 1, p. 717</i> )
15	7	W: Word size ( <i>Note 2, p. 717, Note 1, p. 717</i> )
15	8	D: Double word size ( <i>Note 2, p. 717, Note 1, p. 717</i> )
17	2	Declaration of directly displayed buffered variables ( <i>Note 5, p. 718, Note 9, p. 718</i> )
17	3	Declaration of storage locations with symbolic variables ( <i>Note 5, p. 718</i> )

Table number	Property number	Property description
17	4	Assignment of storage locations with fields ( <i>Note 5, p. 718, Note 11, p. 718</i> )
17	5	Automatic storage allocation for symbolic variables ( <i>Note 5, p. 718</i> )
17	7	Declaration for buffered fields ( <i>Note 5, p. 718, Note 11, p. 718</i> )
17	8	Declaration for structured variables ( <i>Note 5, p. 718</i> )
18	2	Initialization of directly displayed buffered variables ( <i>Note 5, p. 718, Note 9, p. 718, Note 10, p. 718</i> )
18	3	Assignment of storage locations and start values for fields ( <i>Note 5, p. 718</i> )
18	4	Assignment of storage locations and start values for fields ( <i>Note 5, p. 718, Note 11, p. 718</i> )
18	5	Initialization of symbolic variables ( <i>Note 5, p. 718</i> )
18	7	Declaration and initialization of buffered variables ( <i>Note 5, p. 718, Note 11, p. 718</i> )
18	8	Initialization of structured variables ( <i>Note 5, p. 718</i> )
18	9	Initialization of constants
19	1	Negated input
19	2	Negated output
20	1	Use of "EN" and "ENO" - REQUIRED for LD ( <i>Note 6, p. 718</i> )
20	2	Use of "EN" and "ENO" – OPTIONAL for FBD
20	3	FBD without "EN" and "ENO"
21	2	Standardized functions ( <i>Note 3, p. 717</i> )
22	1	(*TO**) Type conversion functions ( <i>Note 4, p. 718</i> )
22	2	Truncation towards zero: TRUNC ( <i>Note 3, p. 717</i> )
23	1	ABS: Absolute value
23	2	SQRT: Square root
23	3	LN: Natural logarithm
23	4	LOG: Base 10 logarithm
23	5	EXP: Exponential function
23	6	SIN: Sine, input in radians
23	7	COS: Cosine, input in radians
23	8	TAN: Tangent, input in radians
23	9	ASIN: Arc sine, principal value



Table number	Property number	Property description
23	10	ACOS: Arc cosine, principal value
23	11	ATAN: Arc tangent, principal value
24	12	ADD: Add
24	13	MUL: Multiply
24	14	SUB: Subtract
24	15	DIV: Divide
24	16	MOD: Modulo
24	17	EXPT: Exponentiation
24	18	MOVE: Assignment
25	1	SHL: move to the left
25	2	SHR: Move to the right
25	3	ROR: Rotate to the right
25	4	ROL: Rotate to the left
26	5	AND: LLogical And
26	6	OR: Logical Or
26	7	XOR Logical exclusive Or
26	8	NOT: Negation
27	1	SEL: Binary selection
27	2a	MAX: Extendable maximum
27	2b	MIN: Extendable minimum
27	3	LIMIT: Limit
27	4	MUX: Extendable multiplexer
28	5	GT: Falling sequence
28	6	GE: Monotonic sequence (decreasing)
28	7	EQ: Equality
28	8	LE: Monotonic sequence (increasing)
28	9	LT: Rising sequence
28	10	NE: Inequality
30	1	ADD: Adding TIME to TIME
30	4	SUB: Subtracting TIME from TIME
30	10	MUL: Multiplying TIME by ANY_NUM
30	11	DIV: Dividing TIME by ANY_NUM
33	1	RETAIN identifier for internal variables ( <i>Note 5, p. 718</i> )
33	2	RETAIN identifier for output variables ( <i>Note 5, p. 718</i> )

Table number	Property number	Property description
33	3	RETAIN identifier for internal Function Blocks ( <i>Note 5, p. 718</i> )
34	1	Bistable Function Block (set priority)
34	2	Bistable Function Block (reset priority)
35	1	Detecting the rising edge
35	2	Detecting the falling edge
36	1	Up counter
36	2	Down counter
36	3	Up/Down counter
37	1	TP: Pulse (timer)
37	2a	TON: Switch-on delay
37	3a	TOF: Switch-off delay
39	1	RETAIN identifier for internal variables ( <i>Note 5, p. 718</i> )
39	2	RETAIN identifier for output variables ( <i>Note 5, p. 718</i> )
39	3	RETAIN identifier for internal Function Blocks ( <i>Note 5, p. 718</i> )
39	14	Assignment of storage locations with fields ( <i>Note 5, p. 718</i> )
39	18	Assignment of storage locations and start values for fields( <i>Note 5, p. 718</i> )
39	19	Use of directly displayed variables ( <i>Note 2, p. 717, Note 1, p. 717</i> )
40	1	Step/Start step – graphical form with directional links
40	2	Step/Start step – text form without directional links ( <i>Note 8</i> )
40	3a	Step marker – general form
40	4	Step time elapsed – general form
41	1	Transition condition in ST language within the graphic ( <i>Note 8, p. 718</i> )
41	5	Transition condition in ST language – textual reference ( <i>Note 9, p. 718</i> )
41	6	Transition condition in IL language – textual reference ( <i>Note 9, p. 718</i> )
41	7	Use of the transition name
41	7b	Transition condition in FBD language
41	7c	Transition condition in IL language
41	7d	Transition condition in ST language
42	1	Each Boolean variable can be an action
43	1	Action block

Table number	Property number	Property description
43	2	Concatenated action blocks
43	3	Step body in text form ( <i>Note 8, p. 718</i> )
44	1	Identifier
44	2	Action name
45	1	Not saved (no identifier)
45	2	N: not saved
45	3	R: Overriding reset
45	4	S: Set (saved)
45	5	L: Time limited
45	6	D: Delayed
45	7	P: Pulse
45	9	DS: Delayed and saved
46	1	Simple string
46	2a	Branching in string selection (priority from left to right)
46	3	Merging a string selection
46	4	Parallel strings - branch and merge
46	5a	String jump (priority from left to right)
46	6a	String loop (priority from left to right)

**Note 1** Modicon TSX Quantum Präfix 3 is used in the prefix IB, ID position in all graphical languages.

**Note 2** Modicon TSX Quantum Präfix 4 is used in the prefix QB, QD position in all graphical languages.

**Note 3** The following functions are overloaded with reference to the data which is selected, multiplexed or assigned; the type statement refers to the selection parameters.

List of overloaded functions:

- SEL
- MUX
- MOVE

All other functions are standardized, e.g. REAL\_TRUNC\_INT.

---

<b>Note 4</b>	<p>List of type conversion functions:</p> <ul style="list-style-type: none"><li>• BOOL_TO_BYTE, BOOL_TO_DINT, BOOL_TO_INT, BOOL_TO_REAL, BOOL_TO_TIME, BOOL_TO_UDINT, BOOL_TO_UINT, BOOL_TO_WORD,</li><li>• BYTE_TO_BOOL, BYTE_TO_DINT, BYTE_TO_INT, BYTE_TO_REAL, BYTE_TO_TIME, BYTE_TO_UDINT, BYTE_TO_UINT, BYTE_TO_WORD,</li><li>• DINT_TO_BOOL, DINT_TO_BYTE, DINT_TO_INT, DINT_TO_REAL, DINT_TO_TIME, DINT_TO_UDINT, DINT_TO_UINT, DINT_TO_WORD,</li><li>• INT_TO_BOOL, INT_TO_BYTE, INT_TO_DINT, INT_TO_REAL, INT_TO_TIME, INT_TO_UDINT, INT_TO_UINT, INT_TO_WORD,</li><li>• REAL_TO_BOOL, REAL_TO_BYTE, REAL_TO_DINT, REAL_TO_INT, REAL_TO_TIME, REAL_TO_UDINT, REAL_TO_UINT, REAL_TO_WORD,</li><li>• TIME_TO_BOOL, TIME_TO_BYTE, TIME_TO_DINT, TIME_TO_INT, TIME_TO_REAL, TIME_TO_UDINT, TIME_TO_UINT, TIME_TO_WORD,</li><li>• UDINT_TO_BOOL, UDINT_TO_BYTE, UDINT_TO_DINT, UDINT_TO_INT, UDINT_TO_REAL, UDINT_TO_TIME, UDINT_TO_UINT, UDINT_TO_WORD,</li><li>• UINT_TO_BOOL, UINT_TO_BYTE, UINT_TO_DINT, UINT_TO_INT, UINT_TO_REAL, UINT_TO_TIME, UINT_TO_UDINT, UINT_TO_WORD,</li><li>• WORD_TO_BOOL, WORD_TO_BYTE, WORD_TO_DINT, WORD_TO_INT, WORD_TO_REAL, WORD_TO_TIME, WORD_TO_UDINT, WORD_TO_UINT</li></ul> <p>The consequences of each conversion are described in the block library and the help texts, which are available for the library of IEC standard functions.</p>
<b>Note 5</b>	<p>The RETAIN identifier is implicitly required; no language elements displayed in non-buffered memory areas are supported.</p>
<b>Note 6</b>	<p>"EN" and "ENO" are offered as standard; they can, however, be hidden and any other input or output of data type BOOL can be used for links.</p>
<b>Note 7</b>	<p>Expressions are restricted to individual simple Boolean variables.</p>
<b>Note 8</b>	<p>Only available on import of IEC text form in graphical SFC representation.</p>
<b>Note 9</b>	<p>Only available in textual declaration in IL or ST sections.</p>
<b>Note 10</b>	<p>Initialization only possible for non Boolean outputs.</p>
<b>Note 11</b>	<p>Declaration of field variables only possible when using previously defined field data type names.</p>

---

## IL (AWL) language elements

### IEC standards table

IEC standards table for IL (AWL) language elements:

Table number	Property number	Property description
52	1	LD operator: sets the current result to that of the operand
52	2	ST operator: saves the current result to the operand address
52	3	S operator: sets Boolean operands to "1" R operator: sets Boolean operands to "0"
52	4	AND operator
52	6	OR operator
52	7	XOR operator
52	8	ADD operator
52	9	SUB operator
52	10	MUL operator
52	11	DIV operator
52	12	GT operator: Comparison >
52	13	GE operator: Comparison >=
52	14	EQ operator: Comparison =
52	15	NE operator: Comparison <>
52	16	LE operator: Comparison <=
52	17	LT operator: Comparison <
52	18	JMP operator: Jump to tag ( <i>Note 1, p. 719</i> )
52	19	CAL operator: Calls Function Block
52	21	Closing bracket ")": Editing deferred operations
53	1	CAL operator with list of input parameters
53	2	CAL operator with loading/saving of input parameters

### Note 1

Jumps are only allowed within sections, not across section boundaries.

**Note 2**

The following keywords are not available:

- TYPE...END\_TYP
  - VAR\_INPUT...END\_VAR
  - VAR\_OUTPUT...END\_VAR
  - VAR\_IN\_OUT...END\_VAR
  - VAR\_EXTERNAL...END\_VAR
  - FUNCTION...END\_FUNCTION
  - FUNCTION\_BLOCK...END\_FUNCTION\_BLOCK
  - PROGRAM...END\_PROGRAM
  - STEP...END\_STEP
  - TRANSITION...END\_TRANSITION
  - ACTION...END\_ACTION
  - SEGMENT\_SCHEDULER
  - RET
  - &
-

## ST language elements

### IEC standards table

IEC standards table for ST language elements:

Table number	Property number	Property description
55	1	Placing in brackets: ( Expression )
55	2	Function calls: Function name ( list of arguments )
55	3	Exponentiation: **
55	4	Negation: -
55	5	Complement: NOT
55	6	Multiplication: *
55	7	Division: /
55	8	Modulo: MOD
55	9	Addition: +
55	10	Subtraction: -
55	11	Comparison: <, >, <=, >=
55	12	Equality: =
55	13	Inequality: <>
55	14	Boolean AND: &
55	15	Boolean AND: AND
55	16	Boolean exclusive OR: XOR
55	17	Boolean OR: OR
56	1	Assignment
56	2	Function Block calls and use of FB outputs
56	4	IF instruction
56	5	CASE instruction
56	6	FOR instruction
56	7	WHILE instruction
56	8	REPEAT instruction
56	9	EXIT instruction
56	10	Empty instruction

**Note 1**

The following keywords are not available:

- TYPE...END\_TYP
- VAR\_INPUT...END\_VAR
- VAR\_OUTPUT...END\_VAR
- VAR\_IN\_OUT...END\_VAR
- VAR\_EXTERNAL...END\_VAR
- FUNCTION...END\_FUNCTION
- FUNCTION\_BLOCK...END\_FUNCTION\_BLOCK
- PROGRAM...END\_PROGRAM
- STEP...END\_STEP
- TRANSITION...END\_TRANSITION
- ACTION...END\_ACTION
- SEGMENT\_SCHEDULER
- RETURN

**Common graphic elements****IEC standards table**

IEC standards table for common graphic elements:

Table number	Property number	Property description
57	2	Horizontal lines: Graphic or semi-graphic
57	4	Vertical lines: Graphic or semi-graphic
57	6	Horizontal/vertical connection: Graphic or semi-graphic
57	8	Line intersection without connection: Graphic or semi-graphic
57	10	Connected and unconnected corners: Graphic or semi-graphic
57	12	Blocks with connecting lines: Graphic or semi-graphic



## LD (KOP) language elements

### IEC standards table

IEC standards table for LD (KOP) language elements:

Table number	Property number	Property description
59	1	Left power rail (with linked horizontal connection)
60	1	Horizontal connection
60	2	Vertical connection (with linked horizontal connections)
61	1	Closer
61	3	Opener
61	5	Contact for detection of positive transition
61	7	Contact for detection of negative transition
62	1	Coil ( <i>Note 1, p. 724</i> )
62	2	Negative coil ( <i>Note 1, p. 724</i> )-{-
62	3	SET coil ( <i>Note 1, p. 724</i> )
62	4	RESET coil ( <i>Note 1, p. 724</i> )
62	8	Coil for detection of positive transition
62	9	Coil for detection of negative transition

**Note 1**

In start behavior of PLCs there is a distinction between cold starts and warm starts:

- **Cold start**  
Following a cold start (loading the program with **Online** → **Load**) all variables (irrespective of type) are set to "0" or, if available, their initial value.
- **Warm start**  
In a warm start (stopping and starting the program or **Online** → **Load changes**) different start behaviors are valid for located variables/direct addresses and unlocated variables:
  - **Located variables/direct addresses**  
In a warm start all 0x, 1x and 3x registers are set to "0" or, if available, their initial value.  
4x registers retain their current value (storage behavior).
  - **Unlocated variables**  
In a warm start all unlocated variables retain their current value (storing behavior).

This varying behavior in a warm start leads to peculiarities in the warm start behavior of set and reset functions.

- **Set and Reset in LD and IL**  
Warm start behavior is dependent on the variable type used (storage behavior in use of unlocated variables; non storage behavior in use of located variables/direct addresses)
  - **SR and RS Function Blocks in FBD, LD, IL and ST**  
These Function Blocks work with internal unlocated variables and therefore always have a storage behavior.
-

## Implementation-dependent parameters

### IEC standards table

IEC standards table for implementation-dependent parameters:

Parameters	Threshold values/behavior
Error-handling procedure	See <i>Error causes</i> , p. 728 & EFB help
National characters used	All characters in the Windows ANSI character set are supported.
Maximum length of identifiers	Program name: 8 Formal parameter names: 8 DFB type names: 8 EFB type names: 17 Data type names: 24 all others: 32
Maximum comment length:	Limited only by Windows resources
Range of values for time span literals	0s to 49d_17h_2m_47.295s
Range of values for variables of type TIME	0s to 49d_17h_2m_47.295s
Accuracy of the seconds display with types TIME_OF_DAY and DATE_AND_TIME	not applicable
Maximum number of field indices	Practically no limit
Maximum field size	64 kB
Maximum number of structure elements	Only limited by Windows or PLC resources
Maximum structure size	64 kB
Maximum number of variables per declaration	Only limited by Windows or PLC resources
Maximum number of enumerated values	not applicable
Default maximum length of STRING variables	not applicable
Maximum authorized length of STRING variables	not applicable
Maximum number of hierarchy tiers	1
Configured or physical illustration	Configured illustration, physical illustration through separate I/O projection
Parameters	Threshold values/behavior
Maximum number of indices	Practically no limit

<b>Parameters</b>	<b>Threshold values/behavior</b>
Maximum range of index values	Range of data type INT
Maximum number of structure levels	Only limited by Windows or PLC resources
Initialization of system inputs	System zero; no user-definable start values
Maximum number of variables per declaration	Only limited by Windows or PLC resources
Information for the determination of execution times of program organization units	In preparation
Methods of function display (names or symbols)	Names
Maximum number of function specifications	not applicable
Maximum number of inputs for extendable functions	32
Type conversion accuracy	See EFB help
Accuracy of functions of a variable	INTEL floating point processor or emulator
Arithmetic function implementation	INTEL floating point processor or emulator
Maximum number of Function Block specifications	Only limited by Windows or PLC resources
Maximum number of Function Block authorizations	512 per section; number of sections per program organization unit is only limited by Windows or PLC resources
Pvmin, Pvmax of counters	Limited by rangess of the INT or DINT data types
Effect of a change in the value of a PT input during a time measurement operation	Directly affects the timer's default time
Program size limits	Only limited by available PLC memory
Time behavior and porting effects of the execution control elements	The execution of SFC networks in different sections occurs sequentially, in the order given in these sections.
Accuracy of elapsed step time	10 ms
Maximum number of steps per SFC	Limited by the available area for entering characters within the section; number of sections per program organization unit only limited by Windows or PLC resources; the upper limit for the total number of objects per SFC is 2000
Parameters	Threshold values/behavior

Parameters	Threshold values/behavior
Maximum number of transitions per SFC and per step	Limited by the available area for entering characters within the section; number of sections per program organization unit only limited by Windows or PLC resources; the upper limit for the total number of objects per SFC is 2000
Action control mechanism	Functionally equivalent to the specification in the standard
Maximum number of actions per step	Only limited by Windows or PLC resources
Graphical display of the step situation	Green = active Red = inactive
Transition switch time	Of the magnitude of 10 ms
Maximum width of branches/connections	Limited by the available area for entering characters 32
Contents of the RESOURCE libraries	See EFB libraries & help
Maximum number of tasks	1
Task interval resolution	not applicable
Pre-justified and non pre-justified schedules	not applicable
Maximum length of expressions	Practically no limit
Partial evaluation of Boolean expressions	no partial evaluation
Maximum length of instructions	Practically no limit
Maximum number of CASE selections	Practically no limit
Value of the control variables on completion of FOR loops	undefined
Graphic/semi-graphic display	Graphic
Network topology restrictions	no restrictions
Evaluation sequence of feedback loops	Within a network, the starting point of the FFB execution sequence is determined by the "single" available feedback variable
Means of specifying the network execution sequence	1: Execution sequence of program organization unit sections 2: The network execution sequence can be changed within sections; this is done by using a menu command to switch between the execution sequences of two selected FFB items

## Error causes

### IEC standards table

IEC standards table for error causes:

Error cause	Handling (see Note 1, p. 729)
Variable value exceeds the specified range	not applicable
Initialization list length and number of field elements do not agree	2) Error message during programming
Incorrect use of directly displayed or external variables in functions	not applicable
Type conversion error	4) Error message during execution
Numerical result exceeds the range for data type	4) Error message during execution
Division by zero	4) Error message during execution
Mixed input data types in a selection function	2) Error message during programming
Selector (K) outside MUX function range	4) Error message during execution
Invalid character position	not applicable
Result exceeds maximum sequence length	not applicable
Numerical result exceeds the range for data type	4) Error message during execution
Zero or more than one starting step in SFC network	3) Error message during analysis/loading/connection
User program attempting to change step situation or step time	2) Error message during programming
Simultaneously completed transitions without priority in a selection branch	not applicable
Side effects of evaluation of a transition condition	3) Error message during analysis/loading/connection
Action control error	1) Error not reported
Unsafe or unreachable SFCs	3) Error message during analysis/loading/connection
Data type conflict in VAR_ACCESS	not applicable
Tasks demanding too many processor resources	3) Error message during analysis/loading/connect
Scan time overrun	4) Error message during execution
Error cause	Handling (see note 1)
Further task schedule conflicts	not applicable

<b>Error cause</b>	<b>Handling (see Note 1, p. 729)</b>
Numerical result exceeds the range for data type	4) Error message during execution
Division by zero	4) Error message during execution
Invalid data type for operation	3) Error message during analysis/loading/binding
Return from function without assigned value	not applicable
Occurrence arrives at no outcome	4) Error message during execution
The same identifier as connector tag and element name use	not applicable
Non-initialized feedback variable (initialized with system zero)	1) Error not reported

**Note 1**

Identification for the handling of error causes according to IEC 1131-3, chapter 1.5.1, d):

- 1) Error not reported
- 2) Error message during programming
- 3) Error message during analysis/loading/binding
- 4) Error message during execution

---

## D.3 Expansions of IEC 1131-3

---

### Expansions of IEC 1131-3

---

#### At a Glance

The Concept programming environment makes the construct of the so-called section available in all programming languages permitting the subdivision of a program organization unit. This construct provides the opportunity to mix several languages in the body of a POU (e.g. FBD sections, SFC sections), a property, which, if used for this purpose, represents an expansion of the IEC syntax. Sections do not generate their own name space; the name space for all language elements is the POU.

Sections appearing in the body of a POU written only in the FBD language are not to be viewed as an expansion, rather as a permitted means of specifying the execution sequences of several FBD networks furnished with tags, as specified in the corrigendum to 1131-3.

---

#### Purpose of sections

Sections serve various purposes

- Sections permit the functional division of an expansive POU body: The body of a POU can be divided into sensible functional parts. The section list represents a kind of functional table of contents for a large, otherwise unstructured POU body.
  - Sections permit the graphical division of an expansive POU body: in accordance with an intentionally graphic form of representation, sub-structures of an expansive body can be established. Smaller or larger partial structures may be chosen.
  - The division of an expansive POU body enables faster online changes: the section serves as the unit for online changes in Concept. If the POU body is changed in various places during the program runtime, all sections affected by the changes are taken into account if explicitly initiated reloading occurs.
  - Sections permit the execution sequence to influence particular marked parts of the POU body: the section name serves as a marking for the part of the body contained in the section, and the execution sequence of the sections can be changed by ranking the sections (see also the last part of the "implementation-dependent parameters" table for information on the execution sequence of networks in the FBD language).
  - Sections permit the parallel use of different languages in the same POU: this property is a considerable expansion of the syntax of the IEC 1131-3 standard, which only permits the use of a single IEC language for a POU body. Only the SFC language also provides the opportunity to formulate parts of the body in different languages, because transitions and actions can be expressed in any language, in as far as the corresponding properties are supported by the programming system.
-



## D.4 Text language syntax

### Text Language Syntax

#### Description

The programming system Concept supports the complete language syntax, as specified in appendix B of the IEC language standard 1131-3, with the following exceptions:

- Syntax productions in appendix B of 1131-3, belonging to properties, which according to the IEC standards tables in *IEC standards tables, p. 712* in this document are not supported by Concept, are not implemented.
- The use of some Concept supported properties is, according to the associated remarks in the IEC standards table, only possible in a restricted or modified form. The associated syntax productions are therefore only occasionally or somewhat differently implemented.
- Concept supports the NOT Operator for inverting Boolean battery content in IL.
- The implementation of some faulty syntax productions in appendix B of 1131-3, improved upon either in the corrigendum to 1131-3 or in the planned amendment to 1131-3, uses the suggestions in these documents for orientation.

The improved productions are implemented in Concept as follows (chapter numbers refer to appendix B of 1131-3):

- **B.1.3.3:**

```
array_initialization ::= '[' array_initial_elements {','  
array_initial_elements} ']'
```

```
initialized_structure ::= structure_type_name [':='  
structure_initialization]
```

- **B.2.1:**

```
il_operand_list ::= il_operand [',' [EOL] il_operand]
```

```
il_fb_call ::= ('CAL' | 'CALC' | 'CALCN') fb_name '('  
il_operand_list ')'
```

- **B.2.2:**

```
il_operator ::= 'LD' | 'LDN' | 'ST' | 'STN' | 'S' | 'R'  
| ('AND' | 'ANDN' | 'OR' | 'ORN' | 'XOR' | 'XORN') ['(']  
| ('ADD' | 'SUB' | 'MUL' | 'DIV') ['(']  
| ('GT' | 'GE' | 'EQ' | 'NE' | 'LT' | 'LE') ['(']  
| 'JMP' | 'JMPC' | 'JMPCN' | ')') | function_name
```

IEC conformity

---

---

## Configuration examples



---

### At a Glance

#### Overview

This section contains various configuration examples, given as step-by-step instructions.

#### What's in this chapter?

This chapter contains the following Sections:

Section	Topic	Page
E.1	Quantum Example - Remote Control with RIO	735
E.2	Quantum Example - Remote control with RIO (series 800)	743
E.3	Quantum Example - Remote Control with DIO	754
E.4	Quantum Example – INTERBUS Control	763
E.5	Quantum Example - SY/MAX Controller	769
E.6	Quantum Example - Profibus DP Controller	777
E.7	Quantum-Example - Peer Cop	791
E.8	Compact Example	799
E.9	Atrium Example – INTERBUS Controller	804
E.10	Momentum Example - Remote I/O Bus	813
E.11	Momentum Example - Ethernet Bus System	821

---



---

## E.1 Quantum Example - Remote Control with RIO

---

### Introduction

---

**Overview** This Chapter contains the step-by-step process for the configuration of remote control with RIO (Remote I/O).

---

**What's in this section?** This section contains the following topics:

Topic	Page
Editing local drop	736
Editing Remote Drop	740


---

## Editing local drop

---

### Introduction


This section describes the configuration of the first (local) drop. The processing sequence begins first of all with the definition of all drops. When editing the first (local) drop the modules must be set with their I/O references before the individual modules can be parameterized. Quantum – remote controller with RIO



- 1 Local Quantum drop 1
  - 2 RIO master module
  - 3 RIO slave module
  - 4 RIO drop 2
-

**Defining Drops**

To define drops proceed as follows in the **PLC Configuration** window:

Step	Action
1	Select <b>PLC Selection</b> . <b>Response:</b> The <b>PLC selection</b> dialog is opened.
2	Select the <b>Quantum PLC</b> family and a <b>CPU x113 xx</b> . Using <b>OK</b> return to the <b>PLC Configuration</b> window.
3	Select <b>I/O Map</b> . <b>Response:</b> The <b>I/O Map</b> dialog is opened and the first drop is automatically entered in the table.
4	Select the <b>Head Setup</b> command button. <b>Response:</b> The <b>Head Setup</b> dialog is opened.
5	Enter a 7 in <b>RIO Slot</b> and quit the dialog using <b>OK</b> . <b>Response:</b> The CRP-93x-00 module is automatically inserted in the component list (in slot 7) of the selected drop. In the <b>Go To</b> list box, the <b>Local/RIO (Slot 7)</b> network link is displayed.
6	Select the last line in the table. Select the <b>Insert</b> command button. <b>Response:</b> The second drop is entered in the <b>Type</b> column. <b>Note:</b> The number of drops to be inserted is defined in the <b>segment scheduler</b> dialog. The default predetermines a maximum number of 32. Dialog display
	
7	Select the drop from the <b>Drop</b> column. Select the <b>Edit...</b> command button. <b>Response:</b> You reach the module map.

**Mapping Modules and Specifying I/O References**

To map the modules and specify the address ranges proceed as follows in the **Local Quantum Drop** dialog:


Step	Action
1	Select the <b>Module</b> → ... column. <b>Response:</b> The <b>I/O Module Selection</b> dialog is opened.
2	From the <b>Category</b> column, select the <b>&lt;all&gt;</b> option. <b>Response:</b> All modules are listed in the <b>Modules</b> column.
3	In the <b>Modules</b> column, select the <b>CPS-214-00</b> module. Exit the dialog with <b>OK</b> . <b>Response:</b> The module is inserted in the I/O map.
4	Repeat steps 1 to 3 for all the modules in the example (see <b>Local Quantum Drop</b> dialog representation).
5	In the <b>In Ref</b> and <b>Out Ref</b> columns, set the start references for the input and output modules. <b>Note:</b> Discrete Input References have the prefix 1 (e.g. 100001), Coil References have the prefix 0 (e.g. 000001), Input Register References have the prefix 3 (e.g. 300001) and Output Register References have the prefix 4 (e.g. 400001). <b>Response:</b> The end reference (column <b>In.End.</b> or <b>Out.End.</b> ) of the available address range is automatically entered.

---



**Dialog display**

Following module mapping and I/O reference specification the dialog looks like this:



**Set module parameters**

To set parameters for the individual modules, proceed as follows in the **Local Quantum Drop** dialog:

Step	Action
1	From the <b>Rack Slot</b> column select the <b>1-3</b> line. <b>Response:</b> The <b>1-3</b> text box has a dark background, i.e. the <b>DDI-353-00</b> module has been selected for editing. <b>Note:</b> Parameters are not set for the <b>CPS-214-00</b> and <b>CPU-x13-0x</b> modules.
2	Select the <b>Params</b> command button. <b>Response:</b> The <b>140-DDI-353-00</b> dialog is opened.
3	Select the <b>Discrete</b> option button. <b>Response:</b> You return to the I/O map.
4	Repeat steps 1 to 3 for all the modules in the example. <b>Note:</b> The modules are sometimes set with different parameters. Help with this can be obtained from the corresponding help texts in the parameter dialog.

**Editing Remote Drop**

Editing of the I/O st. (Drop) defined second takes place in the dialog **RIO (Slot 7) - Quantum I/O-St. 2.**

This dialog can be reached in two ways:

- In the **I/O Map** dialog, using the **Edit...** command button, or
  - in the **Local Quantum Drop** dialog, using the **Next** command button.
- 


**Editing Remote Drop**

---

**Introduction**

This section describes the configuration of the second (remote) drop. The drop has already been defined in Editing the First (local) Drop (See *Editing local drop*, p. 736). To edit the second (remote) drop, the modules must be specified with their I/O references before parameters for the individual modules can be set.

Quantum – remote controller with RIO



- 1 Local Quantum drop 1
  - 2 RIO master module
  - 3 RIO slave module
  - 4 RIO drop 2
-

### Mapping Modules and Specifying I/O References

To allocate the modules and specify the address ranges use the dialog **RIO (slot 7) - Quantum I/O-St. 2** and proceed as follows:

Step	Action
1	Select the <b>Module</b> → ... column. <b>Response:</b> The <b>I/O Module Selection</b> dialog is opened.
2	From the <b>Category</b> column, select the <b>&lt;all&gt;</b> option. <b>Response:</b> All modules are listed in the <b>Modules</b> column.
3	In the <b>Modules</b> column select the <b>CRA-93x-00</b> module. Exit the dialog with <b>OK</b> . <b>Response:</b> The module is inserted in the I/O map.
4	Repeat steps 1 to 3 for all the modules in the example (see dialog representation <b>RIO (Slot 7) Quantum Drop 2</b> ).
5	In the <b>In Ref</b> and <b>Out Ref</b> columns, set the start references for the input and output modules. <b>Note:</b> Discrete Input References have the prefix 1 (e.g. 100001), Coil References have the prefix 0 (e.g. 000001), Input Register References have the prefix 3 (e.g. 300001) and Output Register References have the prefix 4 (e.g. 400001). <b>Response:</b> The end reference (column <b>In.End.</b> or <b>Out.End</b> ) of the available address range is automatically entered.

**Dialog display**

Following module mapping and I/O reference specification the dialog looks like this:

**RIO (slot 7) - Quantum Drop 2**

Drop  
 Modules: 5    ASCII Port No.: None  
 Input bits: 176  
 Output bits: 96  
 Status table:

Module  
 Input bits: 0  
 Output bits: 0    Params

Previous    Next    Delete    Delete    Cut    Copy    Paste

Rack-Slot	Module	Detected	In Ref	In End	Out Ref	Out End	Description
1-1	CRA-93x-00						RIO DROP S908
1-2	DDI-353-00		100033	100064			DC IN 24V 4x8
1-3	DDO-353-00				000033	000064	DC OUT 24V 4x8
1-4	AVI-030-00		300033	300041			AN IN 8CH BIPOLAR
1-5	AVO-020-00				400033	400036	AN OUT 4CH VOLT
1-6	...						
1-7	...						
1-8	...						
1-9	...						
1-10	...						
1-11	...						
1-12	...						
1-13	...						
1-14	...						

OK    Cancel    Help     Poll

**Set module parameters**

To set parameters for individual modules use the dialog **RIO (slot 7) - Quantum I/O-St. 2** and proceed as follows:

Step	Action
1	From the <b>Rack Slot</b> column select the <b>1-2</b> line. <b>Response:</b> The <b>1-2</b> text box has a dark background, i.e. the <b>DDI-353-00</b> module has been selected for editing.
2	Select the <b>Params</b> command button. <b>Response:</b> The <b>140-DDI-353-00</b> dialog is opened.
3	Select the <b>Discrete</b> option button. <b>Response:</b> You return to the I/O map.
4	Repeat steps 1 to 3 for all the modules in the example. <b>Note:</b> The modules are sometimes set with different parameters. Help with this can be obtained from the corresponding help texts in the parameter dialog.

---

## E.2 Quantum Example - Remote control with RIO (series 800)

---

### Introduction

---

#### Overview

This Chapter contains the step-by-step process for the configuration of remote control with RIO (**R**emote **I/O**) and series 800 modules.

---

#### What's in this section?

This section contains the following topics:

Topic	Page
Editing Local Drop	744
Editing Remote Drop	748
Editing Remote Drop	751

---


## Editing Local Drop

---

### Introduction

This section describes the configuration of the first (local) drop. The processing sequence begins first of all with the definition of all drops. When editing the first (local) drop the modules must be set with their I/O references before parameters can be set for individual modules.

Quantum – remote controller with RIO (Series 800)



- 1 Local Quantum drop 1
  - 2 RIO master module
  - 3 RIO slave module
  - 4 RIO drop 2
  - 5 Adapter module
  - 6 RIO drop 3 with series 800 modules
-

**Defining Drops**

To define drops proceed as follows in the **PLC Configuration** window:

Step	Action
1	Select <b>PLC Selection</b> . <b>Response:</b> The <b>PLC selection</b> dialog is opened.
2	Select the <b>Quantum PLC</b> family and a <b>CPU x113 xx</b> . Using <b>OK</b> return to the <b>PLC Configuration</b> window.
3	Select <b>I/O Map</b> . <b>Response:</b> The <b>I/O Map</b> dialog is opened and the first drop is automatically entered in the table.
4	Select the <b>Head Setup</b> command button. <b>Response:</b> The <b>Head Setup</b> dialog is opened.
5	Enter a 7 in <b>RIO Slot</b> and quit the dialog using <b>OK</b> . <b>Response:</b> The CRP-93x-00 module is automatically inserted in the I/O map (in slot 7) of the selected drop. In the <b>Go To</b> list box, the <b>Local/RIO (Slot 7)</b> network link is displayed.
6	Select the last free row in the table, and insert the second drop with the command button <b>Insert</b> . <b>Response:</b> The second drop is entered in the <b>Type</b> column of the table. <b>Note:</b> The number of drops to be inserted is defined in the <b>segment scheduler</b> dialog. The default predetermines the maximum number of 32, so that settings are not necessary.
7	Select the last free row in the table again, and insert the third drop with the <b>Insert</b> command button. <b>Response:</b> The second drop is entered in the <b>Type</b> column of the table.
8	Select the third drop and open the list box in the <b>Type</b> column. Select the <b>800 I/O</b> option. Dialog display

**I/O Map** [X]

Reserve for expansion:  [Left Arrow] [Right Arrow]

Go To:  [Down Arrow]

Drop	Type	Supervision Time	In bits	Out bits	Status	Edit
1	Quantum I/O	3	0	0		Edit...
2	Quantum I/O	3	0	0		Edit...
3	800 I/O	3	0	0		Edit...
To insert at the end of the list, select this line						

[Up Arrow] [Down Arrow]

Step	Action
9	Select the first drop from the <b>Drop</b> column. Select the <b>Edit...</b> command button. <b>Response:</b> You reach the module map.

**Mapping  
Modules and  
Specifying I/O  
References**

To map the modules and specify the address ranges proceed as follows in the **Local Quantum Drop** dialog:

Step	Action
1	Select the <b>Module → ...</b> column. <b>Response:</b> The <b>I/O Module Selection</b> dialog is opened.
2	From the <b>Category</b> column, select the <b>&lt;all&gt;</b> option. <b>Response:</b> All modules are listed in the <b>Modules</b> column.
3	In the <b>Modules</b> column, select the <b>CPS-214-00</b> module. Exit the dialog with <b>OK</b> . <b>Response:</b> The module is inserted in the I/O map.
4	Repeat steps 1 to 3 for all the modules in the example (see <b>Local Quantum Drop</b> dialog representation).
5	In the <b>In Ref</b> and <b>Out Ref</b> columns, set the start references for the input and output modules. <b>Note:</b> Discrete Input References have the prefix 1 (e.g. 100001), Coil References have the prefix 0 (e.g. 000001), Input Register References have the prefix 3 (e.g. 300001) and Output Register References have the prefix 4 (e.g. 400001). <b>Response:</b> The end reference (column <b>In.End.</b> or <b>Out.End.</b> ) of the available address range is automatically entered.



**Dialog display**

Following module mapping and I/O reference specification the dialog looks like this:

Rack-Slot	Module	Detected	In Ref	In End	Out Ref	Out End	Description
1-1	CPS-214-00						DC SUMMABLE PS 2
1-2	CPU-x13-0x						CPU 1xMB+
1-3	DDI-353-00		100001	100032			DC IN 24V 4x8
1-4	DDO-353-00				000001	000032	DC OUT 24V 4x8
1-5	AVI-030-00		300001	300009			AN IN 8CH BIPOLAR
1-6	AVO-020-00				400001	400004	AN OUT 4CH VOLT
1-7	CPR-93x-00						RIO Head S908
1-8	...						
1-9	...						
1-10	...						
1-11	...						
1-12	...						
1-13	...						
1-14	...						

**Set module parameters**

To set parameters for the individual modules, proceed as follows in the **Local Quantum Drop** dialog:

Step	Action
1	From the <b>Rack Slot</b> column select the <b>1-3</b> line. <b>Response:</b> The <b>1-3</b> text box has a dark background, i.e. the <b>DDI-353-00</b> module has been selected for editing. <b>Note:</b> Parameters are not set for the <b>CPS-214-00</b> and <b>CPU-x13-0x</b> modules.
2	Select the <b>Params</b> command button. <b>Response:</b> The <b>140-DDI-353-00</b> dialog is opened.
3	Select the <b>Discrete</b> option button. <b>Response:</b> You return to the I/O map.
4	Repeat steps 1 to 3 for all the modules in the example. <b>Note:</b> The modules are sometimes set with different parameters. Help with this can be obtained from the corresponding help texts in the parameter dialog.

**Editing Remote Drop**

Editing of the I/O st. (Drop) defined second takes place in the dialog **RIO (Slot 7) - Quantum I/O-St. 2**.

This dialog can be reached in two ways:

- In the **I/O Map** dialog, using the **Edit...** command button, or
- in the **Local Quantum Drop** dialog, using the **Next** command button.


**Editing Remote Drop**

**Introduction**

This section describes the configuration of the second (remote) drop. The drop has already been defined in Editing the First (local) Drop (See *Editing Local Drop*, p. 744).

To edit the second (remote) drop, the modules must be specified with their I/O references before parameters for the individual modules can be set.

Quantum – remote controller with RIO (Series 800)



- 1 Local Quantum drop 1
- 2 RIO master module
- 3 RIO slave module
- 4 RIO drop 2
- 5 Adapter module
- 6 RIO drop 3 with series 800 modules

### Mapping Modules and Specifying I/O References

To allocate the modules and specify the address ranges use the dialog **RIO (slot 7) - Quantum I/O-St. 2** and proceed as follows:

Step	Action
1	Select the <b>Module</b> → ... column. <b>Response:</b> The <b>I/O Module Selection</b> dialog is opened.
2	From the <b>Category</b> column, select the <b>&lt;all&gt;</b> option. <b>Response:</b> All modules are listed in the <b>Modules</b> column.
3	In the <b>Modules</b> column select the <b>CRA-93x-00</b> module. Exit the dialog with <b>OK</b> . <b>Response:</b> The module is inserted in the I/O map.
4	Repeat steps 1 to 3 for all the modules in the example (see dialog representation <b>RIO (Slot 7) Quantum Drop 2</b> ).
5	In the <b>In Ref</b> and <b>Out Ref</b> columns, set the start references for the input and output modules. <b>Note:</b> Discrete Input References have the prefix 1 (e.g. 100001), Coil References have the prefix 0 (e.g. 000001), Input Register References have the prefix 3 (e.g. 300001) and Output Register References have the prefix 4 (e.g. 400001). <b>Response:</b> The end reference (column <b>In.End.</b> or <b>Out.End</b> ) of the available address range is automatically entered.

**Dialog display**

Following module mapping and I/O reference specification the dialog looks like this:

The dialog box 'RIO (slot 7) - Quantum Drop 2' contains the following information:

**Drop**

Modules: 5    ASCII Port No.: None

Input bits: 176

Output bits: 96

Status table:

**Module**

Input bits: 0

Output bits: 0

Buttons: Previous, Next, Delete, Delete, Cut, Copy, Paste, Params

Rack-Slot	Module	Detected	In Ref	In End	Out Ref	Out End	Description
1-1	CRA-93x-00						RIO DROP S908
1-2	DDI-353-00		100033	100064			DC IN 24V 4x8
1-3	DDO-353-00				000033	000064	DC OUT 24V 4x8
1-4	AVI-030-00		300033	300041			AN IN 8CH BIPOLAR
1-5	AVO-020-00				400033	400036	AN OUT 4CH VOLT
1-6	...						
1-7	...						
1-8	...						
1-9	...						
1-10	...						
1-11	...						
1-12	...						
1-13	...						
1-14	...						

Buttons: OK, Cancel, Help,  Poll

**Set module parameters**

To set parameters for individual modules use the dialog **RIO (slot 7) - Quantum I/O-St. 2** and proceed as follows:

Step	Action
1	From the <b>Rack Slot</b> column select the <b>1-2</b> line. <b>Response:</b> The <b>1-2</b> text box has a dark background, i.e. the <b>DDI-353-00</b> module has been selected for editing.
2	Select the <b>Params</b> command button. <b>Response:</b> The <b>140-DDI-353-00</b> dialog is opened.
3	Select the <b>Discrete</b> option button. <b>Response:</b> You return to the I/O map.
4	Repeat steps 1 to 3 for all the modules in the example. <b>Note:</b> The modules are sometimes set with different parameters. Help with this can be obtained from the corresponding help texts in the parameter dialog.

**Editing Remote 800 Drops**

The third defined drop is edited in the **RIO (Slot 7) - 800 Drop 3** dialog. This dialog can be reached in two ways:

- In the **I/O Map** dialog, using the **Edit....** command button, or
- in the **RIO (Slot 7) - Quantum Drop 2** dialog using the **Next** command button.

**Editing Remote Drop**


**Introduction**

This Section describes the configuration of the third (remote) drop. The drop has already been defined in Editing the First (local) Drop (See *Editing Local Drop*, p. 744).

To edit the third (remote) drop, the modules must be specified with their I/O references before the individual modules can be parameterized.

**Note:** The J890 adapter module must be mounted in the rack of the third drop. However, this module is not visible either in the software or in the dialogs.

Quantum – remote controller with RIO (Series 800)



- 1 Local Quantum drop 1
- 2 RIO master module
- 3 RIO slave module
- 4 RIO drop 2
- 5 Adapter module
- 6 RIO drop 3 with series 800 modules

**Mapping Modules and Specifying I/O References**

To map the modules and specify the address ranges go to the **RIO (slot 7) - 800 drop 3** dialog and proceed as follows:

Step	Action
1	Select the <b>Module</b> → ... column. <b>Response:</b> The <b>I/O Module Selection</b> dialog is opened.
2	From the <b>Category</b> column, select the <b>&lt;all&gt;</b> option. <b>Response:</b> All modules are listed in the <b>Modules</b> column.
3	In the <b>Modules</b> column select the <b>B810</b> module. Exit the dialog with <b>OK</b> . <b>Response:</b> The module is inserted in the I/O map.
4	Repeat steps 1 to 3 for all the modules in the example (see dialog representation <b>RIO (slot 7) 800 drop 3</b> ).
5	In the <b>Out Ref.</b> column, enter the start references for the output modules. <b>Note:</b> Discrete Input References have the prefix 1 (e.g. 100001), Coil References have the prefix 0 (e.g. 000001), Input Register References have the prefix 3 (e.g. 300001) and Output Register References have the prefix 4 (e.g. 400001). <b>Response:</b> The end reference of the available address range ( <b>Out End</b> column) is entered automatically.

---

**Dialog display**

Following module mapping and I/O reference specification the dialog looks like this:

**Set module parameters**

To set parameters for individual modules go to the **RIO (slot 7) - 800 drop 3** dialog and proceed as follows:

Step	Action
1	From the <b>Rack Slot</b> column select the <b>1-1</b> line. <b>Response:</b> The <b>1-1</b> text box has a dark background, i.e. the <b>B810</b> module has been selected for editing.
2	Select the <b>Params</b> command button. <b>Response:</b> The <b>B810</b> dialog is opened.
3	Select the option button <b>Discrete</b> <b>Response:</b> You return to the I/O map.
4	Repeat steps 1 to 3 for all the modules in the example. <b>Note:</b> The modules are sometimes set with different parameters. Help with this can be obtained from the corresponding help texts in the parameter dialog.

## E.3 Quantum Example - Remote Control with DIO

---

### Introduction

---

**Overview** This Chapter contains the step-by-step process for the configuration of remote control with DIO (**D**istributed **I/O**).

---

**What's in this section?** This section contains the following topics:

Topic	Page
Editing Local Drop	755
Editing Local Drop	759


---



## Editing Local Drop

### Introduction

This section describes the configuration of the first (local) drop. The processing sequence begins first of all with the definition of the drop. When editing the first (local) drop the modules must be set with their I/O references before parameters can be set for individual modules. Quantum – remote controller with DIO



- 1 Local Quantum drop 1
- 2 DIO master module
- 3 DIO slave module
- 4 DIO drop 2

**Defining the Drop**

To define the drop use **Configure** from the main menu and proceed as follows:

Step	Action
1	Select <b>PLC Selection</b> . <b>Response:</b> The <b>PLC selection</b> dialog is opened.
2	Select the <b>Quantum PLC</b> family and a <b>CPU x113 xx</b> . Using <b>OK</b> return to the <b>PLC Configuration</b> window.
3	Select <b>I/O Map</b> . <b>Response:</b> The <b>I/O Map</b> dialog is opened and the first drop is automatically entered in the table.
4	Select the <b>Head Setup</b> command button. <b>Response:</b> The <b>Head Setup</b> dialog is opened.
5	Enter a 7 in <b>NOM Slot 1</b> and quit the dialog using <b>OK</b> . <b>Response:</b> The NOM module NOM-2xx-00 is automatically inserted in the I/O map (in slot 7) of the selected drop. In the <b>Go to</b> list box, the network link <b>Local/RIO (Slot ?)</b> is displayed. Dialog display
6	Select the drop from the <b>Drop</b> column. Select the <b>Edit...</b> command button. <b>Response:</b> You reach the module map.

### Mapping Modules and Specifying I/O References

To map the modules and specify the address ranges proceed as follows in the **Local Quantum Drop** dialog:

Step	Action
1	Select the <b>Module</b> → ... column. <b>Response:</b> The <b>I/O Module Selection</b> dialog is opened.
2	From the <b>Category</b> column, select the <all> option. <b>Response:</b> All modules are listed in the <b>Modules</b> column.
3	In the <b>Modules</b> column, select the <b>CPS-214-00</b> module. Exit the dialog with <b>OK</b> . <b>Response:</b> The module is inserted in the I/O map.
4	Repeat steps 1 to 3 for all the modules in the example (see <b>Local Quantum Drop</b> dialog representation).
5	In the <b>In Ref</b> and <b>Out Ref</b> columns, set the start references for the input and output modules. <b>Note:</b> Discrete Input References have the prefix 1 (e.g. 100001), Coil References have the prefix 0 (e.g. 000001), Input Register References have the prefix 3 (e.g. 300001) and Output Register References have the prefix 4 (e.g. 400001). <b>Response:</b> The end reference (column <b>In.End.</b> or <b>Out.End</b> ) of the available address range is automatically entered.

**Dialog display**

Following module mapping and I/O reference specification the dialog looks like this:

Rack-Slot	Module	Detected	In Ref	In End	Out Ref	Out End	Description
1-1	CPS-214-00						DC SUMMABLE PS 2
1-2	CPU-x13-0x						CPU 1xMB+
1-3	DDI-353-00		100001	100032			DC IN 24V 4x8
1-4	DDO-353-00				000001	000032	DC OUT 24V 4x8
1-5	AVI-030-00		300001	300009			AN IN 8CH BIPOLAR
1-6	AVO-020-00				400001	400004	AN OUT 4CH VOLT
1-7	NOM-2xx-00						MN1 MB+
1-8	...						
1-9	...						
1-10	...						
1-11	...						
1-12	...						
1-13	...						
1-14	...						

**Set module parameters**

To set parameters for the individual modules, proceed as follows in the **Local Quantum Drop** dialog:

Step	Action
1	From the <b>Rack Slot</b> column select the <b>1-3</b> line. <b>Response:</b> The <b>1-3</b> text box has a dark background, i.e. the <b>DDI-353-00</b> module has been selected for editing. <b>Note:</b> Parameters are not set for the <b>CPS-214-00</b> and <b>CPU-x13-0x</b> modules.
2	Select the <b>Params</b> command button. <b>Response:</b> The <b>140-DDI-353-00</b> dialog is opened.
3	Select the <b>Discrete</b> option button. <b>Response:</b> You return to the I/O map.
4	Repeat steps 1 to 3 for all the modules in the example. <b>Note:</b> The modules are sometimes set with different parameters. Help with this can be obtained from the corresponding help texts in the parameter dialog.

**Editing Remote Drop**

To edit the remote drop with DIO, you must return to the **I/O Map** dialog and define the drop.


## Editing Local Drop

### Introduction

This section describes the configuration of the second (remote) drop. The processing sequence begins first of all with the definition of the drop. To edit the second (remote) drop, the modules must be specified with their I/O references before parameters for the individual modules can be set.

**Note:** To link to the remote network, the coupling module CRA-21x-x0 must be entered during module mapping.


### Quantum – remote controller with DIO



- 1 Local Quantum drop 1
- 2 DIO master module
- 3 DIO slave module
- 4 DIO drop 2

**Defining the Drop**

To define the drop go to the **I/O map** dialog and proceed as follows:

Step	Action
1	From the <b>Go to</b> list box, select the <b>DIO 1 (Slot 7)</b> network link. <b>Response:</b> The drop entered in the table is no longer displayed.
2	Select the <b>Insert</b> command button. <b>Response:</b> In the <b>Type</b> column, the <b>Read/Write</b> type is entered. Dialog display 
3	Select the drop from the <b>Drop</b> column. Select the <b>Edit...</b> command button. <b>Response:</b> You reach the module map.

### Mapping Modules and Specifying I/O References

To map the modules and specify the address ranges use the **DIO 1 (slot 7) - Drop 1** dialog and proceed as follows:

Step	Action
1	Select the <b>Module</b> → ... column. <b>Response:</b> The <b>I/O Module Selection</b> dialog is opened.
2	From the <b>Category</b> column, select the <b>&lt;all&gt;</b> option. <b>Response:</b> All modules are listed in the <b>Modules</b> column.
3	In the <b>Modules</b> column select the <b>CRA-21x-x0</b> module. Exit the dialog with <b>OK</b> . <b>Response:</b> The module is inserted in the I/O map.
4	Repeat steps 1 to 3 for all the modules in the example (see dialog representation <b>DIO (slot 7) Quantum drop 1</b> ).
5	In the <b>In Ref</b> and <b>Out Ref</b> columns, set the start references for the input and output modules. <b>Note:</b> Discrete Input References have the prefix 1 (e.g. 100001), Coil References have the prefix 0 (e.g. 000001), Input Register References have the prefix 3 (e.g. 300001) and Output Register References have the prefix 4 (e.g. 400001). <b>Response:</b> The end reference (column <b>In.End.</b> or <b>Out.End</b> ) of the available address range is automatically entered.

**Dialog display**

Following module mapping and I/O reference specification the dialog looks like this:

Rack-Slot	Module	Detected	In Ref	In End	Out Ref	Out End	Description
1-1	CRA-21x-x0						DIO DROP MB+
1-2	DDI-353-00		100033	100064			DC IN 24V 4x8
1-3	DDO-353-00				000033	000064	DC OUT 24V 4x8
1-4	AVI-030-00		300033	300041			AN IN 8CH BIPOLAR
1-5	AVO-020-00				400033	400036	AN OUT 4CH VOLT
1-6	...						
1-7	...						
1-8	...						
1-9	...						
1-10	...						
1-11	...						
1-12	...						
1-13	...						
1-14	...						

**Set module parameters**

To set parameters for individual modules use the **DIO 1 (slot 7) - Drop 1** dialog and proceed as follows:

Step	Action
1	From the <b>Rack Slot</b> column select the <b>1-2</b> line. <b>Response:</b> The <b>1-2</b> text box has a dark background, i.e. the <b>DDI-353-00</b> module has been selected for editing.
2	Select the <b>Params</b> command button. <b>Response:</b> The <b>140-DDI-353-00</b> dialog is opened.
3	Select the <b>Discrete</b> option button. <b>Response:</b> You return to the I/O map.
4	Repeat steps 1 to 3 for all the modules in the example. <b>Note:</b> The modules are sometimes set with different parameters. Help with this can be obtained from the corresponding help texts in the parameter dialog.



---

## E.4 Quantum Example – INTERBUS Control

---

### Introduction

---

**Overview** This Chapter contains the step-by-step process for the configuration of INTERBUS control with the Quantum.

---

**What's in this section?** This section contains the following topics:

Topic	Page
General Information	764
Editing Local Drop	765

---

## General Information

---

### Introduction

INTERBUS control using Quantum occurs via module NOA-611-10. During this process the module collects the words of all remote bus nodes and creates a telegram with status information and I/O words. The telegram is then transferred to the CPU, so that the NOA behaves like an I/O module.

**Note:** Using branch interfaces in the remote bus, remote bus branches with further remote bus nodes (TIOs) can be constructed. However, the branch interfaces can only be inserted in the remote bus, not in the remote bus branch.

### Parameterization

Command sequence parameterization (restart procedure) occurs in the CMD Tool, produced by the PHÖNIX firm (see also "NOA 611 1 restart procedure" with an example for parameterizing the command sequence in CMD Tool).

---


## Editing Local Drop

### Introduction

This section describes the configuration of the first (local) drop. The processing sequence begins first of all with the definition of the drop. When editing the first (local) drop the modules must be set with their I/O references before parameters can be set for individual modules.

**Note:** When the NOA-611-00 module is entered in the I/O map, the loadable ULEX is automatically installed.

### Quantum - INTERBUS controller



- 1 Local Quantum Drop
- 2 INTERBUS master module
- 3 Remote bus without branch interface

**Note:** The configuration of remote bus nodes does not take place in Concept and is therefore not apparent in the I/O map. To edit the remote bus nodes, you must use the CMD tool produced by the PHÖNIX firm (Configuration Monitoring and Diagnostic Software).

**Defining Drops**

To define drops proceed as follows in the **PLC Configuration** window:

Step	Action
1	Select <b>PLC Selection</b> . <b>Response:</b> The <b>PLC selection</b> dialog is opened.
2	Select the <b>Quantum PLC</b> family and a <b>CPU x113 xx</b> . Use <b>OK</b> return to the <b>PLC Configuration</b> window.
3	Select <b>I/O Map</b> . <b>Response:</b> The <b>I/O Map</b> dialog is opened and the first drop is automatically entered in the table. Dialog display
4	Select the drop from the <b>Drop</b> column. Select the <b>Edit...</b> command button. <b>Response:</b> You reach the module map.

### Mapping Modules and Specifying I/O References

To map the modules and specify the address ranges proceed as follows in the **Local Quantum Drop** dialog:

Step	Action
1	Select the <b>Module</b> → ... column. <b>Response:</b> The <b>I/O Module Selection</b> dialog is opened.
2	From the <b>Category</b> column, select the <all> option. <b>Response:</b> All modules are listed in the <b>Modules</b> column.
3	In the <b>Modules</b> column, select the <b>CPS-214-00</b> module. Exit the dialog with <b>OK</b> . <b>Response:</b> The module is inserted in the I/O map.
4	Repeat steps 1 to 3 for all the modules in the example (see <b>Local Quantum Drop</b> dialog representation).
5	In the <b>In Ref</b> and <b>Out Ref</b> columns, set the start references for the input and output modules. <b>Note:</b> Discrete Input References have the prefix 1 (e.g. 100001), Coil References have the prefix 0 (e.g. 000001), Input Register References have the prefix 3 (e.g. 300001) and Output Register References have the prefix 4 (e.g. 400001). <b>Response:</b> The end reference (column <b>In.End.</b> or <b>Out.End</b> ) of the available address range is automatically entered.

**Dialog display**

Following module mapping and I/O reference specification the dialog looks like this:

Rack-Slot	Module	Detected	In Ref	In End	Out Ref	Out End	Description
1-1	CPS-214-00						DC SUMMABLE PS 2
1-2	CPU-x13-0x						CPU 1xMB+
1-3	DDI-353-00		100001	100032			DC IN 24V 4x8
1-4	DDO-353-00				000001	000032	DC OUT 24V 4x8
1-5	AVI-030-00		300001	300009			AN IN 8CH BIPOLAR
1-6	AVO-020-00				400001	400004	AN OUT 4CH VOLT
1-7	NOA-611-00		300010	300276	400005	400268	IBS-Head (Mode2)
1-8	...						
1-9	...						
1-10	...						
1-11	...						
1-12	...						
1-13	...						
1-14	...						

**Set module parameters**

To set parameters for the individual modules, proceed as follows in the **Local Quantum Drop** dialog:

Step	Action
1	From the <b>Rack Slot</b> column select the 1-3 line. <b>Response:</b> The 1-3 text box has a dark background, i.e. the <b>DDI-353-00</b> module has been selected for editing. <b>Note:</b> Parameters are not set for the <b>CPS-214-00</b> and <b>CPU-x13-0x</b> modules.
2	Select the <b>Params</b> command button. <b>Response:</b> The <b>140-DDI-353-00</b> dialog is opened.
3	Select the <b>Discrete</b> option button. <b>Response:</b> You return to the I/O map.
4	Repeat steps 1 to 3 for all the modules in the example. <b>Note:</b> The modules are sometimes set with different parameters. Help with this can be obtained from the corresponding help texts in the parameter dialog.

---

## E.5 Quantum Example - SY/MAX Controller

---

### Introduction

---

#### Overview

This Chapter contains the step-by-step process for the configuration of a SY/MAX controller.

---

#### What's in this section?

This section contains the following topics:

Topic	Page
Editing Local Drop	770
Editing Remote Drop	774


---

## Editing Local Drop

---

### Introduction

This section describes the configuration of the first (local) drop. The processing sequence begins first of all with the definition of all drops. When editing the first (local) drop the modules must be set with their I/O references before parameters can be set for individual modules.  
Quantum – SY/MAX controller




- 1 Local Quantum drop 1
  - 2 RIO master module
  - 3 SY/MAX drop 2
-



**Defining Drops**

To define drops proceed as follows in the **PLC Configuration** window:

Step	Action
1	Select <b>PLC Selection</b> . <b>Response:</b> The <b>PLC selection</b> dialog is opened.
2	Select the <b>Quantum</b> PLC family and a <b>CPU x113 xx</b> . Using <b>OK</b> return to the <b>PLC Configuration</b> window.
3	Select <b>I/O Map</b> . <b>Response:</b> The <b>I/O Map</b> dialog is opened and the first drop is automatically entered in the table.
4	Select the <b>Head Setup</b> command button. <b>Response:</b> The <b>Head Setup</b> dialog is opened.
5	Enter a 7 in <b>RIO Slot</b> and quit the dialog using <b>OK</b> . <b>Response:</b> The CRP-93x-00 module is automatically inserted in the I/O map (in slot 7) of the selected drop. In the <b>Go To</b> list box, the <b>Local/RIO (Slot 7)</b> network link is displayed.
6	Select the last line in the table. Select the <b>Insert</b> command button. <b>Response:</b> The second drop is entered in the <b>Type</b> column. <b>Note:</b> The number of drops to be inserted is defined in the <b>segment scheduler</b> dialog. The default defines a maximum number of 32.
7	Select the second drop and in the <b>Type</b> column, open the list box. Select the <b>SY/MAX</b> option. Dialog display
	
8	Select the first drop from the <b>Drop</b> column. Select the <b>Edit...</b> command button. <b>Response:</b> You reach the module map.

**Mapping Modules and Specifying I/O References**


To map the modules and specify the address ranges proceed as follows in the **Local Quantum Drop** dialog:

Step	Action
1	Select the <b>Module</b> → ... column. <b>Response:</b> The <b>I/O Module Selection</b> dialog is opened.
2	From the <b>Category</b> column, select the <b>&lt;all&gt;</b> option. <b>Response:</b> All modules are listed in the <b>Modules</b> column.
3	In the <b>Modules</b> column, select the <b>CPS-214-00</b> module. Exit the dialog with <b>OK</b> . <b>Response:</b> The module is inserted in the I/O map.
4	Repeat steps 1 to 3 for all the modules in the example (see <b>Local Quantum Drop</b> dialog representation).
5	In the <b>In Ref</b> and <b>Out Ref</b> columns, set the start references for the input and output modules. <b>Note:</b> Discrete Input References have the prefix 1 (e.g. 100001), Coil References have the prefix 0 (e.g. 000001), Input Register References have the prefix 3 (e.g. 300001) and Output Register References have the prefix 4 (e.g. 400001). <b>Response:</b> The end reference (column <b>In.End.</b> or <b>Out.End.</b> ) of the available address range is automatically entered.

---

**Dialog display**

Following module mapping and I/O reference specification the dialog looks like this:



**Set module parameters**

To set parameters for the individual modules, proceed as follows in the **Local Quantum Drop** dialog:

Step	Action
1	From the <b>Rack Slot</b> column select the <b>1-3</b> line. <b>Response:</b> The <b>1-3</b> text box has a dark background, i.e. the <b>DDI-353-00</b> module has been selected for editing. <b>Note:</b> Parameters are not set for the <b>CPS-214-00</b> and <b>CPU-x13-0x</b> modules.
2	Select the <b>Params</b> command button. <b>Response:</b> The <b>140-DDI-353-00</b> dialog is opened.
3	Select the <b>Discrete</b> option button. <b>Response:</b> You return to the I/O map.
4	Repeat steps 1 to 3 for all the modules in the example. <b>Note:</b> The modules are sometimes set with different parameters. Help with this can be obtained from the corresponding help texts in the parameter dialog.

**Editing Remote Drop**

Editing the drop defined second takes place in the dialog **RIO (slot 7) – SY/MAX I/O-St. 2**.

This dialog can be reached in two ways:

- In the **I/O Map** dialog, using the **Edit...** command button, or
- in the **Local Quantum Drop** dialog, using the **Next** command button.

**Editing Remote Drop**


**Introduction**

This section describes the configuration of the second (remote) drop. The drop has already been defined in Editing the First (local) Drop (See *Editing Local Drop*, p. 770).

To edit the second (remote) drop, the modules must be specified with their I/O references before parameters for the individual modules can be set.

**Note:** To link to the remote network, the coupling module CRM-931-RG must be entered during module mapping.

Quantum – SY/MAX controller



- 1 Local Quantum drop 1
- 2 RIO master module
- 3 SY/MAX drop 2

### Mapping Modules and Specifying I/O References

To map the modules and specify the address ranges proceed as follows in the **RIO (slot 7) – SY/MAX I/O-St. 2** dialog:

Step	Action
1	Select the <b>Module</b> → ... column. <b>Response:</b> The <b>I/O Module Selection</b> dialog is opened.
2	From the <b>Category</b> column, select the <b>&lt;all&gt;</b> option. <b>Response:</b> All modules are listed in the <b>Modules</b> column.
3	In the <b>Modules</b> column select the <b>CRM-931-RG</b> module. Exit the dialog with <b>OK</b> . <b>Response:</b> The module is inserted in the I/O map.
4	Repeat steps 1 to 3 for all the modules in the example (see dialog representation <b>RIO (Slot 7) SY/MAX Drop 2</b> ).
5	In the <b>In Ref</b> and <b>Out Ref</b> columns, set the start references for the input and output modules. <b>Note:</b> Discrete Input References have the prefix 1 (e.g. 100001), Coil References have the prefix 0 (e.g. 000001), Input Register References have the prefix 3 (e.g. 300001) and Output Register References have the prefix 4 (e.g. 400001). <b>Response:</b> The end reference (column <b>In.End.</b> or <b>Out.End</b> ) of the available address range is automatically entered.

**Dialog display**

Following module mapping and I/O reference specification the dialog looks like this:

Rack-Slot	Module	Detected	In Ref	In End	Out Ref	Out End	Description
1	CRM-931-RG						REG RMT IF
2	RIM-101/361		100033	100048			16 IN AC/DC
3	ROM-121				400005	400008	4 OUT ANLG
4	SIM-116		100049	100064			16 IN SIM
5	...						
6	...						
7	...						
8	...						
9	...						
10	...						
11	...						
12	...						
13	...						
14	...						

**Set module parameters**

To parameter the individual modules use the dialog **RIO (slot 7) – SY/MAX I/O-St. 2** and proceed as follows:

Step	Action
1	In the <b>Slot</b> column, select line <b>2</b> . <b>Response:</b> The <b>2</b> text box has a dark background, i.e. the <b>RIM-101/361</b> module has been selected for editing.
2	Select the <b>Params</b> command button. <b>Response:</b> The <b>8030-RIM-101/361</b> dialog is opened.
3	Select the <b>Discrete</b> option button. <b>Response:</b> You return to the I/O map.
4	Repeat steps 1 to 3 for all the modules in the example. <b>Note:</b> The modules are sometimes set with different parameters. Help with this can be obtained from the corresponding help texts in the parameter dialog.

---

## E.6 Quantum Example - Profibus DP Controller

---

### Introduction

---

**Overview** This Chapter contains the step-by-step process for the configuration of a Profibus DP controller with the Quantum.

---

**What's in this section?** This section contains the following topics:

Topic	Page
General Information	778
Example 7 - Profibus DP Export Settings in SyCon	778
Editing Local Drop	780
Importing Profibus DP Configuration	784

---

## General Information

---

**Introduction** Configuring Profibus DP is done using the SyCon (System Configurator) software produced by Hilscher GmbH. It is initially stored there as a file (\*.CNF). This generated file is loaded into Concept and is visible in the I/O map of the configurator. Before the Profibus DP nodes (max. 32) can be imported, a bus controller (CRP 811 00) must be mapped in the drop (Quantum I/O). Depending on the CPU selection in the **Select Extensions** dialog box, a maximum of two to six bus controllers can be inserted.

---

## Example - Profibus DP Export Settings in SyCon

---

**Introduction** SyCon is used to configure Profibus DP. The procedure for this is to be found in the user manual provided by the manufacturer. The settings for the export of the \*.CNF file are explained in the following step-by-step instructions.

---

**Preconditions** For CRP-811-00 diagnostics the serial interface of the host computer and the diagnostic interface of the bus controller must be linked with a V24 cable. To display this diagnostic data, terminal emulation software must be started (e.g. PROCOMM using the settings: 19.2 kBd, 8 data bits, 1 stop bit, no parity).

---

### Defining the Destination Directory

Firstly, specify the destination directory in which all files are to be saved:

Step	Action
1	Select in the main menu <b>Settings</b> → <b>Search Path...</b> <b>Response:</b> The <b>Search Path</b> dialog is opened and is pre-set with the SyCon directory path as the project directory (e.g. C:\HILSCHER GMBH\SYCON\FIELDBUS\PROFIBUS).
2	Enter the path of the Concept directory (e.g. C:\CONCEPT\PROFIBUS) in the <b>Project Directory</b> text box. <b>Note:</b> You can also accept the default. <b>Response:</b> Execution of the <b>Save</b> and <b>Export</b> menu commands (in the <b>File</b> main menu) saves all files in the entered Concept directory.

---



**Generating an Export File**

To generate an export file (\*.CNF) proceed as follows:

Step	Action
1	Select in the main menu <b>File</b> → <b>Save</b> → <b>*.PB</b> . <b>Response:</b> The configuration is stored as a database file *.PB in the specified directory.
2	Select in the main menu <b>File</b> → <b>Export</b> → <b>ASCII</b> . <b>Response:</b> The configuration is stored as an ASCII file *.CNF in the specified directory.
3	Exit SyCon and start Concept.

**Note about Saving**

The configuration must always be saved as a database file \*.PB first, only then can an ASCII file be generated from the saved \*.PB file. Every change must therefore also be saved as a \*.PB file first, before an ASCII file can be generated for export. The files \*.PB and \*.CNF should always be saved in the same project directory.

**Profibus DP Configuration in Concept**

After the Profibus DP nodes have been configured in SyCon, the Profibus DP configuration is imported into the Concept I/O map. An example of configuration and import is described in the chapter "Editing a Local Drop (See *Editing Local Drop*, p. 780)".

## Editing Local Drop

---


### Introduction

This section describes the configuration of the first (local) drop.  
For Profibus DP configuration the CRP-811-00 coupling module must be registered in the I/O map. The configuration defined in SyCon is loaded into Concept as the generated \*.CNF file is imported into the parameter dialog of the CRP-811-00 coupling module.

**Note:** For an error free transfer of the Profibus DP configuration, it should be ensured that sufficient memory is available. To optimize storage occupancy open the dialog **PLC Memory Partition (PLC Configuration → PLC Memory Partition)**.

When editing the first (local) drop the modules must be set with their I/O references before the individual modules can be parameterized.


Quantum – Profibus DP controller



- 1 Device data base for CRP-811-00 (load onto SyCon)
  - 2 Host computer for Concept and SyCon
  - 3 V24 cable
  - 4 Local Quantum drop 1
  - 5 RIO master module
  - 6 Profibus DP configuration (External modules)
-

**Defining Drops**

To define drops proceed as follows in the **PLC Configuration** window:

Step	Action
1	Select <b>PLC Selection</b> . <b>Response:</b> The <b>PLC Selection</b> dialog is opened.
2	Select the <b>Quantum PLC</b> family and a <b>CPU x113 xx</b> . Using <b>OK</b> return to the <b>PLC Configuration</b> window.
3	Select <b>Config. Extensions</b> → <b>Select Extensions</b> list. Response: The <b>Select Extensions</b> dialog is opened.
4	In the <b>Profibus DP</b> list box select the <b>1</b> option. <b>Response:</b> The coupling module then appears in the <b>I/O Module Selection</b> dialog and can be used in the I/O map.
5	Select <b>I/O Map</b> . <b>Response:</b> The <b>I/O Map</b> dialog is opened and the first drop is automatically entered in the table. Dialog Representation 
6	Select the drop from the <b>Drop</b> column. Select the <b>Edit...</b> command button. <b>Response:</b> You reach the module map.

**Mapping Modules and Specifying I/O References**

To map the modules and specify the address ranges proceed as follows in the **Local Quantum Drop** dialog:

Step	Action
1	Select the <b>Module</b> → ... column. <b>Response:</b> The <b>I/O Module Selection</b> dialog is opened.
2	From the <b>Category</b> column, select the <b>&lt;all&gt;</b> option. <b>Response:</b> All modules are listed in the <b>Modules</b> column.
3	In the <b>Modules</b> column, select the <b>CPS-214-00</b> module. Exit the dialog with <b>OK</b> . <b>Response:</b> The module is inserted in the I/O map.
4	Repeat steps 1 to 3 for all the modules in the example (see <b>Local Quantum Drop</b> dialog representation).
5	In the <b>In Ref</b> and <b>Out Ref</b> columns, set the start references for the input and output modules. <b>Note:</b> Discrete Input References have the prefix 1 (e.g. 100001), Coil References have the prefix 0 (e.g. 000001), Input Register References have the prefix 3 (e.g. 300001) and Output Register References have the prefix 4 (e.g. 400001). <b>Response:</b> The end reference of the available address range ( <b>In End</b> or <b>Out End</b> column) is entered automatically.

---

**Dialog Representation**

Following module mapping and I/O reference specification, the dialog looks like this:

Rack-Slot	Module	Detected	In Ref	In End	Out Ref	Out End	Description
1-1	CPS-214-00						DC SUMMABLE PS 2
1-2	CPU-x13-0x						CPU 1xMB+
1-3	DDI-353-00		100001	100032			DC IN 24V 4x8
1-4	DDO-353-00				000001	000032	DC OUT 24V 4x8
1-5	AVI-030-00		300001	300009			AN IN 8CH BIPOLAR
1-6	AVO-020-00				400001	400004	AN OUT 4CH VOLT
1-7	CRP -811 -00						PROFIBUS DP
1-8	...						
1-9	...						
1-10	...						
1-11	...						
1-12	...						
1-13	...						
1-14	...						

**Parameterization of Modules**

To parameterize the individual modules, proceed as follows in the **Local Quantum Drop** dialog:

Step	Action
1	From the <b>Rack Slot</b> column, select line 1-3. <b>Response:</b> The 1-3 text box has a dark background, i.e. the <b>DDI-353-00</b> module has been selected for editing. <b>Note:</b> The <b>CPS-214-00</b> and <b>CPU-x13-0x</b> modules are not parameterized.
2	Select the <b>Params</b> command button. <b>Response:</b> The <b>140-DDI-353-00</b> dialog is opened.
3	Select the <b>Discrete</b> option button. <b>Response:</b> You return to the I/O map.
4	Repeat steps 1 to 3 for all the modules in the example. <b>Note:</b> The modules are sometimes parameterized differently. Help with this can be obtained from the corresponding help texts in the parameter dialog.

**Importing a Profibus DP Configuration**

Importing configured Profibus DP nodes occurs in the parameter dialog of the CRP-811-00 coupling module. This dialog opens when you select the CRP-811-00 row from the I/O map and press the **Params** command button.

---

## Importing Profibus DP Configuration

---

**Introduction**

This section describes the import of the Profibus DP configuration. After that, further parameter settings for the master take place and the I/O map can be established.

---

**Downloading a Profibus DP Configuration to Concept**

To import, proceed as follows:

Step	Action
1	Select the <b>Import...</b> command button. <b>Response:</b> The <b>Select Import File</b> standard window is opened.
2	Enter the path of the previously generated *.CNF file and exit the dialog with <b>OK</b> . <b>Response:</b> The transfer of the *.CNF file is displayed in the <b>Import Status</b> dialog.
3	Close the dialog after the transfer (100%). <b>Response:</b> The imported configuration is displayed in the <b>CRP-811-00 (Profibus DP)</b> dialog.

---

**Dialog Representation**

Following the import of the configuration, the dialog looks like this (view scrolled all the way to the left):

**CRP-811-00 (Profibus DP)**

**Master**  
Bus address: 1 Slot: 7  
Delete Import... Presettings Parameters...

**Slave**  
Delete Parameters...  
Cut Copy Paste

Bus-Adr.	Module	Module	In Type	In Ref	In End	Out Type	Out Ref	Out End
11	170 DNT 110 10							
		1	BOOL	100081	100160	BOOL	000081	000160
12	170 BDM 344 00/01		BOOL	100161	100176	BOOL	000161	000176
13	170 DNT 110 10							
		1	BOOL	100177	100192			
14	170 DNT 110 10							
		1	BOOL	100193	100208	BOOL	000177	000192
15	170 DNT 110 10							
		1	BOOL	100209	100464	BOOL	000193	000448
16	170 DNT 110 10							
		1	BOOL	100465	100480			

OK Cancel Help  Poll

Following the import of the configuration, the dialog looks like this (view scrolled all the way to the right):

CRP-811-00 (Profibus DP) ✖

**Master**

Bus address: 1      Slot: 7

**Slave**

End	Out Type	Out Ref	Out End	Diag Type	Diag Length	Diag Ref	Diag End	Description
				UINT8 ▼	6	300013	300018	
160	BOOL ▼	000081	000160					170 AMM 090 00 4AI+2AO 4 DI
176	BOOL ▼	000161	000176	UINT8 ▼	6	300019	300024	
				UINT8 ▼	6	300025	300030	
192								170 ADI 740 50 16DI 230V AC
				UINT8 ▼	6	300031	300036	
208	BOOL ▼	000177	000192					170 ARM 370 30 10DI+8DO 12
				UINT8 ▼	6	300037	300042	
464	BOOL ▼	000193	000448					170 ADM 540 80 Modbus Gate
				UINT8 ▼	6	300043	300048	
480								170 ADI 340 00 16DI 24 V DC


Poll

**Note:** In the **Slave** range, the **Parameters...** command button is used for displaying slave parameters. The slave modules are, however, parameterized in SyCon (see SyCon software user manual).




**Parameterizing the Master**

To parameterize the master, proceed as follows:

Step	Action
1	<p>In the <b>Master</b> range, select the <b>Parameters...</b> command button.  <b>Response:</b> The <b>DP Master Parameters</b> dialog is opened.                      Dialog Representation</p> 
2	Accept the defaults, as shown in the figure above, or redefine them.
3	Close the dialog using <b>OK</b> . <b>Response:</b> You return to the <b>CRP-811-00 (Profibus DP)</b> dialog.

**Setting I/O References**

To set the I/O references proceed as follows:

Step	Action
1	<p>Select the command button <b>Preset. ....</b>                      The <b>Preset</b> dialog is opened.                      Dialog Representation</p> 
2	<p>Accept the defaults, as shown in the figure above, or redefine them.</p>
3	<p>Close the dialog using <b>OK</b>.  <b>Response:</b> You return to the <b>CRP-811-00 (Profibus DP)</b> dialog, in which the defined reference ranges have automatically been entered.</p>

**Dialog Representation**

After the I/O references have been set the dialog looks like this (view scrolled all the way to the left):

Bus-Adr.	Module	Module	In Type	In Ref	In End	Out Type	Out Ref	Out End
11	170 DNT 110 10							
		1	BOOL	100081	100160	BOOL	000081	000160
12	170 BDM 344 00/01		BOOL	100161	100176	BOOL	000161	000176
13	170 DNT 110 10							
		1	BOOL	100177	100192			
14	170 DNT 110 10							
		1	BOOL	100193	100208	BOOL	000177	000192
15	170 DNT 110 10							
		1	BOOL	100209	100464	BOOL	000193	000448
16	170 DNT 110 10							
		1	BOOL	100465	100480			

After the I/O references have been set the dialog looks like this (view scrolled all the way to the right):

CRP-811-00 (Profibus DP) ✖

**Master**

Bus address: 1      Slot: 7

**Slave**

End	Out Type	Out Ref	Out End	Diag Type	Diag Length	Diag Ref	Diag End	Description
				UINT8 ▼	6	300013	300018	
160	BOOL ▼	000081	000160					170 AMM 090 00 4AI+2AO 4 DI
176	BOOL ▼	000161	000176	UINT8 ▼	6	300019	300024	
				UINT8 ▼	6	300025	300030	
192								170 ADI 740 50 16DI 230V AC
				UINT8 ▼	6	300031	300036	
208	BOOL ▼	000177	000192					170 ARM 370 30 10DI+8DO 12
				UINT8 ▼	6	300037	300042	
464	BOOL ▼	000193	000448					170 ADM 540 80 Modbus Gate
				UINT8 ▼	6	300043	300048	
480								170 ADI 340 00 16DI 24 V DC

Poll

---

## E.7 Quantum-Example - Peer Cop

---

### At a glance

---

**Introduction** In this chapter the configuration of Peer Cop is described step by step.

---

**What's in this section?** This section contains the following topics:

Topic	Page
Generals to Peer Cop	792
Configuration of Peer Cop	793
Global data transfer	795
Specific data transfer	797

---

## Generals to Peer Cop

---

### Introduction

Peer Cop is a data exchange service provided by the Modbus Plus network. As an overview, imagine that every Modbus Plus network segment (max. 64 nodes) has a global memory, i.e. a certain number of global variables can be read by every node connected to the same segment. The total amount of global variables depends on the number of connected (and active) nodes, every node can provide up to 32 words (16 bit) to the global memory. Only the 32 words provided by a node can be written by the same node, all other nodes have read only access to these variables. So by definition, there is a maximum of  $64 * 32$  words of global memory available to a Modbus Plus network segment. Nodes connected to different (through bridges or gateways) segment cannot share global memory.

When a PLC provides 32 words of global memory it does so by assigning holding registers for broadcast, and when the PLC wants to read global variables provided by another Peer Cop node, assigning holding registers to receive them. These registers are called Global Input (from other nodes) and Global Output (what this node provides) get updated cyclically (in case of a PLC after every scan).

---

### To pass Routing Paths

Actually every Modbus Plus node has its own communication processor (the so called Peer processor), in addition to the processor that controls the node specific work (in case of a PLC: solving user logic).

This leads to some routing paths the global data has to pass to traverse from one node to the other:

- From the data provider (e.g. user logic) to the local (most times embedded peer processor).
- From the local peer processor to the other peer processors (this takes the token cycle time of the Modbus Plus network segment, that depends directly on the number of connected nodes).
- From the peer processor of the data receiver to the data receiver itself, (that is usually the user logic in the receiver PLC).

The actual update time depends on the speed of the Modbus Plus network segment and (that's the big time consumer) the scan times of the data provider and the data receiver.

---

**Send directly**

But the sharing of global memory is just the first part of the full Peer Cop service. Since the global memory architecture requires a setup (or configuration) for both communication partners, there is another subservice to communicate directly with rather than Configure nodes. This service is somewhat like a master to slave communication, where the master knows what data to send and the slave expects data in a fixed layout and uses this data in a fixed manner (like Terminal I/O). The limit of data that can be sent from the master to the slave is also 32 words. This mode is not global data, since it is sent from one node directly and explicitly to one other node. The sender specifies this as specific output and the receiver as specific input (this specification is hardwired on nonintelligent modules like Terminal I/O). The specific output and input words are also assigned to holding registers when a PLC makes use of this Peer Cop service.

Since both, global and specific data transfer, depend on scan time of the PLC's which provide and use this data in their logic, there is no big performance difference with the transfer from one holding register to the other registers.

---

**Configuration of Peer Cop**

---

**Define Peer Cop functionality**

Before configure a Peer Cop you must activate the check box **Peer Cop** in the dialog box **Select Extensions**.


**Note:** Since every PLC can be connected to up to 3 different Modbus Plus network segments, you can setup Peer Cop for every connection separately (remember Peer Cop is reduced to one segment, it doesn't work through bridges).

---

**Peer Cop settings**

To configure a Peer Cop, proceed with the following steps:

Step	Action
1	In the window <b>PLC Configuration</b> with the menu command <b>Config. Extensions</b> → <b>Peer Cop</b> open the dialog box <b>Peer Cop</b> .
2	Assume the default value 100 in the text field <b>Expansion Size</b> . <b>Note:</b> This text field is just a space of memory (in words) that gets reserved for future changes (in offline mode) that shall not cause the necessity for a complete download (this is especially important for direct application setup at a plant).
3	Select the option button <b>Link 0 (CPU)</b> in the area <b>Go To</b> .
4	Assume the default value 500 in the text field <b>Health timeout (msec.)</b> . <b>Note:</b> The Health timeout value has the same meaning as it has in the I/O map for local and remote I/O.
5	Select the option button <b>Hold on timeout</b> in the area <b>Last value</b> . Representation of the dialog:






## Global data transfer


### Global Input

For Global Input proceed as follows:

Step	Action
1	For global data transfer open the dialog box <b>Global Input</b> by clicking the command button <b>Input...</b> in the area <b>Global</b> .
2	Select node <b>10</b> in the list box of the left side of the dialog box.
3	<p>Enter the Destination register, the index, the length and the Bin/BCD Code in the text field of the dialog box, as shown in the figure.</p> <p>Representation of the dialog box:</p>  <p><b>Result:</b> The holding register 400040 gets the first word of global output data of node 10, therefore this is global input data for this PLC. If the length value is higher, lets say 2, register 400041 would get the second word of global output data of node 10. The index value declares with what word the assignment shall start, in this case with the first word. The BIN/BCD column gives you the choice of getting the global data formatted either into the usual binary format or into binary coded decimals.</p> <p>The index value may not be higher than 32, since every node can provide a maximum of 32 word only for global output data. The length value may also not be higher than 32 for the same reason.</p>
4	Close the dialog box <b>Global Input</b> with the command button <b>OK</b> .

**Global Output**

For Global Output proceed as follows:


Step	Action
1	Open the dialog box <b>Gobal Output</b> by clicking the command button <b>Output...</b> in the area <b>Global</b> .
2	<p>Enter the Source register, the length and the Bin/BCD Code in the text field of the dialog box, as shown in the figure. Representation of the dialog box:</p> 
3	Close the dialog box <b>Global Output</b> with the command button <b>OK</b> .

---


**Specific data transfer**

**Specific Input**

For Specific Input proceed as follows:

Step	Action
1	For specific data transfer open the dialog box <b>Specific Input</b> by clicking the command button <b>Input...</b> in the area <b>Specific</b> .
2	<p>Enter the Destination register, the length and the Bin/BCD Code in the text field of the dialog box, as shown in the figure. Representation of the dialog box:</p>  <p><b>Result:</b> If node 10 has declared some specific output, which gets delivered with every token cycle on the Modbus Plus network segment (which is usually faster than the updating by the controller's user logic), that gets sent to holding register 400040. And if it is more than one word, it gets stored in the following holding register, up to 400019 in this example. The formatting can also be either binary or binary coded decimals.</p>
3	Close the dialog box with the command button <b>OK</b> .

**Specific Output** For Specific Output proceed as follows:


Step	Action
1	Open the dialog box <b>Specific Output</b> by clicking the command button <b>Output...</b> in the area <b>Specific</b> .
2	<p>Enter the Destination Reference register, the length and the Bin/BCD Code option in the text field of the dialog box, as shown in the figure. Representation of the dialog box:</p>  <p><b>Result:</b> The values or registers 300030 to 300032 will be sent to node 20 (Target Source) in binary format.</p>
3	Close the dialog box with the command button <b>OK</b> .

## E.8 Compact Example

### Editing Local Drop


**Introduction** This section describes the configuration of the first (local) drop. When editing the first (local) drop the modules must be set with their I/O references before the individual modules can be parameterized.

**Note:** The communication module MVB258A is parameterized in the TCN tool (Train Communication Network). A parameterization file (binary file) is generated and imported into the Concept parameter dialog.



**Defining Drops**

To define drops proceed as follows in the **PLC Configuration** window:

Step	Action
1	Select <b>PLC Selection</b> . <b>Response:</b> The <b>PLC Selection</b> dialog is opened.
2	Select the <b>Compact</b> PLC family and a <b>PC-E984-258</b> . Using <b>OK</b> return to the <b>PLC Configuration</b> window.
3	Select <b>I/O Map</b> . <b>Response:</b> The <b>I/O Map</b> dialog is opened and the first drop is automatically entered in the table. Dialog Representation 
4	Select the drop from the <b>Drop</b> column. Select the <b>Edit...</b> command button. <b>Response:</b> You reach the module map.

### Mapping Modules and Specifying I/O References

To map the modules and specify the address ranges proceed as follows in the **Local TSX Compact Drop** dialog:

Step	Action
1	Select the <b>Module</b> → ... column. <b>Response:</b> The <b>I/O Module Selection</b> dialog is opened.
2	From the <b>Category</b> column, select the <all> option. <b>Response:</b> All modules are listed in the <b>Modules</b> column.
3	In the <b>Modules</b> column, select the <b>MVB258A</b> module. Exit the dialog with <b>OK</b> . <b>Response:</b> The module is inserted in the I/O map.
4	Repeat steps 1 to 3 for all the modules in the example (see Dialog Representation <b>Local TSX Compact Drop</b> ).
5	In the <b>In Ref</b> and <b>Out Ref</b> columns, set the start references for the input and output modules. <b>Note:</b> Discrete Input References have the prefix 1 (e.g. 100001), Coil References have the prefix 0 (e.g. 000001), Input Register References have the prefix 3 (e.g. 300001) and Output Register References have the prefix 4 (e.g. 400001). <b>Response:</b> The end reference of the available address range ( <b>In End</b> or <b>Out End</b> column) is entered automatically.

**Dialog Representation**

Following module mapping and I/O reference specification, the dialog looks like this:

**Drop**

Modules: 7    ASCII Port No.: None ▾

Input bits: 128

Output bits: 64

Status table:

**Module**

Input bits: 16    Params

Output bits: 16

Previous
Next
Delete
Delete
Cut
Copy
Paste

Rack-Slot	Module	Detected	In Ref	In End	Out Ref	Out End	Description
1-1	CPU						TSX COMPACT
1-2	CPU						TSX COMPACT
1-3	MVB258A		300001	300001	400001	400001	MVB Controller w/RS232
1-4	...						
1-5	...						
2-1	DEP214/254		100001	100016			DC 16-IN 12-60V
2-2	DEP2x6/2x7		100017	100032			DC 16-IN
2-3	DAP210				000001	000008	AC 8-OUT 115/230V
2-4	DAP208/258				000009	000016	8-OUT 24..110VDC/24
2-5	...						
3-1	ADU206/256		300065	300069			Analog 4 In
3-2	DAU2x2				400002	400003	An Out 2 ch Volt or Cu
3-3	...						
3-4	...						

OK
Cancel
Help
 Poll



**Parameter-  
ization of  
Modules**

To parameterize the individual modules proceed as follows in the **Local TSX Compact Drop** dialog:

Step	Action
1	From the <b>Rack Slot</b> column, select line <b>1-3</b> . <b>Response:</b> The <b>1-3</b> text box has a dark background, i.e. the <b>MVB258A</b> module has been selected for editing. <b>Note:</b> The <b>CPU</b> module is not parameterized.
2	Select the <b>Params</b> command button. <b>Response:</b> The <b>AS-BMVB258A</b> dialog is opened.
3	Select the <b>Select</b> command button. <b>Response:</b> The <b>Select MVB Import File</b> dialog is opened.
4	Set the path of the parameterization file generated in the TCN tool, and exit the dialog using <b>OK</b> . <b>Response:</b> The selected parameterization file is displayed in the text box in the <b>AS-BMVB258A</b> dialog.
5	Select the <b>Do Import</b> command button. <b>Response:</b> The project data of the parameterization file is transferred to Concept and displayed in the lower list box. Dialog Representation
6	Exit the dialog using <b>OK</b> .
7	Repeat steps 1 to 2 for all the modules in the example. <b>Note:</b> The modules are sometimes parameterized differently. Help with this can be obtained from the corresponding help texts in the parameter dialog.

## **E.9           Atrium Example – INTERBUS Controller**

---

### **Introduction**

---

**Overview**           This Chapter contains the step-by-step process for the configuration of an INTERBUS controller with Atrium (PC based).

---

**What's in this section?**       This section contains the following topics:

<b>Topic</b>	<b>Page</b>
General Information	805
INTERBUS Export Settings in CMD	805
Editing Local Drop	806
Editing Remote Drop (Importing INTERBUS Configuration)	810

---

## General Information

---

- Introduction** The configuration of the INTERBUS is done using the PHÖNIX software CMD. It is initially stored as a file (\*.SVC). This generated file is loaded into Concept and is visible in the I/O map of the configurator.  
Before the INTERBUS nodes are imported, set up the first drop (Atrium I/O) with the CPU board (180-CCO-121-01 and 180-CCO-241-01) and the INTERBUS master (CRP-660-00). A maximum of two INTERBUS masters may be inserted. The diagnosis of the field bus can take place in the CRP-660-00 register in Concept.
- 

## INTERBUS Export Settings in CMD

---

- Introduction** The CMD tool (Configuration Monitoring and Diagnostic tool) is used to configure the INTERBUS. For information about this, refer to the corresponding chapter in the Phoenix user manual.
- 

- Preconditions** The serial interface of the host computer and the diagnostic interface of a PC104 board must be linked with a V24 cable.
- 

- Implementing Export Settings** Before you import the configuration into Concept, carry out the following settings in the CMD tool:

Step	Action
1	Select <b>Configuration</b> → <b>Controller Board</b> → <b>Data Type...</b>
2	Select <b>IBS PC104 SC-T</b> and confirm the selection using <b>OK</b> .
3	Select <b>File</b> → <b>Operating State...</b> <b>Response:</b> The <b>Operating State</b> dialog is opened.
4	Activate the <b>Configuration (Online)</b> option button and exit the dialog using <b>OK</b> .
5	Under <b>Configuration</b> → <b>Controller Board</b> → <b>Control</b> select the command <b>Activate Configuration Frame</b> . Confirm with <b>Yes</b> . <b>Response:</b> A configuration frame is generated.
6	Select <b>Configuration</b> → <b>Configuration Frame</b> → <b>Read Again</b> . <b>Response:</b> The configuration is read into the frame.
7	Under <b>Configuration</b> → <b>Parameterization Memory</b> → <b>Write ASCII File</b> select the command <b>INTERBUS Data (*.SVC)...</b> <b>Response:</b> The INTERBUS data is stored in a file.
8	Enter the directory and the file name in the open dialog and confirm using <b>OK</b> .
9	Select <b>File</b> → <b>Save As...</b> <b>Response:</b> The INTERBUS project is saved.

## Editing Local Drop

---


### Introduction

This section describes the configuration of the first (local) drop. The processing sequence begins first of all with the definition of all drops.

**Note:** For an error free transfer of the INTERBUS configuration, it should be ensured that sufficient memory is available. To optimise the storage allocation open the **PLC Memory Partition** dialog (**PLC Configuration** → **PLC Memory Partition**).

When editing the first (local) drop the modules must be set with their I/O references before parameters can be set for individual modules.


Atrium –INTERBUS Controller



- 1 Host computer for Concept and CMD
  - 2 V24 cable
  - 3 PC104 board on a standard AT board
  - 4 INTERBUS configuration
-

**Defining Drops**

To define drops proceed as follows in the **PLC Configuration** window:

Step	Action
1	Select <b>PLC Selection</b> . <b>Response:</b> The <b>PLC selection</b> dialog is opened.
2	Select the <b>Atrium</b> PLC family and a <b>180-CCO-121-01</b> . Using <b>OK</b> return to the <b>PLC Configuration</b> window.
3	Select <b>I/O Map</b> . <b>Response:</b> The <b>I/O Map</b> dialog is opened and the first drop is automatically entered in the table.
4	Enter a 7 in <b>RIO Slot</b> and quit the dialog using <b>OK</b> . <b>Response:</b> The CRP-93x-00 module is automatically inserted in the I/O map (in slot 7) of the selected drop. In the <b>Go To</b> list box, the <b>Local/RIO (Slot 7)</b> network link is displayed.
5	Select the last line in the table. Select the <b>Insert</b> command button. <b>Response:</b> The second drop is entered in the <b>Type</b> column. <b>Note:</b> The number of INTERBUS masters to be inserted is limited to two drops. Dialog display
	
6	Select the drop from the <b>Drop</b> column. Select the <b>Edit...</b> command button. <b>Response:</b> You reach the module map.

**Setting I/O References**

In the **Local Atrium Drop** dialog the INTERBUS master CRP-660-00 is automatically entered in the I/O map.  
 For the specification of the I/O references, enter the start references in the **In Ref.** and **Out Ref** columns. After the start reference has been entered, the end reference of the available address range of the module is automatically displayed.

**Note:** Discrete input references have the prefix 1 (e.g. 100001), coil references have the prefix 0 (e.g. 000001), input register references have the prefix 3 (e.g. 300001) and output register references have the prefix 4 (e.g. 400001).

Dialog display

Slot	Module	Detected	In Ref	In End	Out Ref	Out End	
1	CCO-12000						Atrium Board
2	CRP-660-00		300001	300030	400001	400002	
3	...						
4	...						

**Set Module Parameters**

To set parameters for the INTERBUS master proceed in the following way in the **Local Atrium Drop** dialog:

Step	Action
1	In the <b>Slot</b> column, select line <b>2</b> . <b>Response:</b> The <b>2</b> text box has a dark background, i.e. the <b>CRP-660-00</b> module has been selected for editing. <b>Note:</b> Parameters are not set for <b>CCO-12000</b> module.
2	Select the <b>Params</b> command button. <b>Response:</b> The <b>CRP-660-00</b> dialog is opened.
3	Press the option buttons as shown in the following figure and exit the dialog using <b>OK</b> . <b>Note:</b> Help with setting parameters is obtained via the dialog's help text. Dialog display

**CRP 660 00** ✕

**Output timeout status** \_\_\_\_\_

Set to zero       Retain previous value

**Addressing mode** \_\_\_\_\_

MSB left (IBS)       MSB right (984)

**IBS Start behavior** \_\_\_\_\_

Compl. config. necessary       Part. config. allowed

**Editing Remote Drop**

To edit the remote drop open the **INTERBUS Drop 2** dialog. This dialog is reached via the **I/O map** dialog by pressing the **Edit...** command button in the second drop. (INTERBUS).

## Editing Remote Drop (Importing INTERBUS Configuration)


---

### Introduction

This section describes the import of the INTERBUS configuration. The assignment of I/O references takes place in the import dialog before the transfer of the configuration file is performed.

**Note:** The module parameters are set in the CMD tool (see CMD tool user manual), because the imported modules are not recognized in Concept.

### Atrium –INTERBUS Controller




- 1 Host computer for Concept and CMD
  - 2 V24 cable
  - 3 PC104 board on a standard AT board
  - 4 INTERBUS configuration
-



**Setting I/O References**

To specify the address ranges proceed as follows in the **INTERBUS Drop 2** dialog:

Step	Action
1	Select the <b>Import...</b> command button. <b>Response:</b> The <b>Import IBS Configuration</b> dialog is opened.
2	Check the <b>Overwrite IBS Drop</b> box. <b>Response:</b> The <b>Do I/O Mapping</b> check box becomes available.
3	Check the <b>Do I/O Mapping</b> check box. <b>Response:</b> The <b>Digital Module in 3x/4x Range</b> check box and the <b>Input 3x</b> and <b>Output 4x</b> text boxes become available.
4	Uncheck the <b>Digital Module in 3x/4x Range</b> check box. <b>Response:</b> The <b>Input 1x</b> and <b>Output 0x</b> text boxes become available.
5	Enter the value 100 in the <b>Input 3x</b> and <b>Output 4x</b> text boxes. <b>Response:</b> The 3x and 4x address ranges of the imported module begin with the start references 300100 and 400100. <b>Note:</b> The 1x and 0x address ranges retain the default value 1, i.e. these address ranges begin with the start references 100001 and 000001. Dialog display
	
6	Exit the dialog with <b>OK</b> . <b>Response:</b> The <b>Select Import File</b> dialog is opened.
7	Enter the path of the configuration file *.SVC. Select <b>OK</b> . <b>Response:</b> The Dialog <b>Import Status</b> dialog is opened, the file transfer starts, and the import status is displayed.
8	Following the transfer (100%), close the dialog. <b>Response:</b> The imported INTERBUS configuration is displayed in the <b>INTERBUS Drop 2</b> dialog in the I/O map.

**Dialog display**

Following the import of the INTERBUS configuration, the dialog looks like this:

The dialog box 'Interbus 8 I/O St. 2' contains the following configuration details:

- Drop:** Modules: 12, Input bits: 144, Output bits: 206, Status table: (empty)
- Module:** Input bits: 0, Output bits: 16
- ASCII Port No.:** None
- Buttons:** Previous, Next, Delete, Delete, Cut, Copy, Paste
- Table:**

No.	Module	Detected	In Ref	In End	Out Ref	Out End	Description
1	BK-012-00						
2	DIO-003-16		100001	100016	000001	000016	
3	DIO-011-16		100017	100032	000017	000032	
4	DI-130-16		100033	100048			
5	AD-065-64				400100	400103	
6	DO-129-16				000033	000048	
7	BK-052-00						
8	AIO-067-64		300100	300103	400104	400107	
9	PCP-203-00						
10	DI-002-16		100049	100064			
11	DO-001-16				000049	000064	
12	DIO-003-16		100065	100080	000065	000080	
13	...						
14	...						
- Buttons:** OK, Cancel, Help,  Poll

---

## E.10 Momentum Example - Remote I/O Bus

---

### Introduction

---

**Overview** This Chapter contains the step-by-step process for the configuration of a remote I/O bus (Momentum).

---

**What's in this section?** This section contains the following topics:

Topic	Page
General Information	814
Editing local drop	814
Example 10 – Editing Remote Drops (I/O Bus)	818

---

## General Information

---


**Introduction** TSX Momentum is a modular system. Bus adapters (e.g. 170 INT 110 00) and CPU adapters (e.g. 171-CCC-760-10-IEC) work in conjunction with an I/O unit as independent modules. In order to function properly, each I/O unit must be equipped with an adapter.

---

## Editing local drop

---


**Introduction** This section describes the configuration of the first (local) drop. The processing sequence begins first of all with the definition of all drops. When editing the first (local) drop the modules must be set with their I/O references before parameters can be set for individual modules.  
Momentum – remote controller with I/O bus



- 1 Host Computer
  - 2 I/O unit e.g. 170-AAI-030-00
  - 3 Interface adapter
  - 4 CPU adapter e.g. 171-CCC-760-10-IEC
  - 5 I/O bus interface e.g. 172-PNN-210-22
  - 6 Bus adapter e.g. 170-INT-110-00
  - 7 I/O unit e.g. 170-AMM-090-00
-

**Defining Drops**

To define drops proceed as follows in the **PLC Configuration** window:

Step	Action
1	Select <b>PLC Selection</b> . <b>Response:</b> The <b>PLC selection</b> dialog is opened.
2	Select the PLC family <b>Momentum</b> and CPU <b>171-CCC-760-10-IEC</b> . Use <b>OK</b> return to the <b>PLC Configuration</b> window.
3	Select <b>I/O Map</b> . <b>Response:</b> The <b>I/O Map</b> dialog is opened and the first drop is automatically entered in the table.
4	Select the last line in the table. Select the <b>Insert</b> command button. <b>Response:</b> The second drop is entered in the <b>Type</b> column. <b>Note:</b> Only one I/O bus can be configured. Dialog display 
5	Select the drop from the <b>Drop</b> column. Select the <b>Edit...</b> command button. <b>Response:</b> You reach the module map.


**Mapping Modules and Specifying I/O References**

To map the modules and specify the address ranges proceed as follows in the **Local Quantum Drop** dialog:

Step	Action
1	Select the <b>Module</b> → ... column. <b>Response:</b> The <b>I/O Module Selection</b> dialog is opened.
2	From the <b>Category</b> column, select the <b>&lt;all&gt;</b> option. <b>Response:</b> All modules are listed in the <b>Modules</b> column.
3	Select from the column <b>Modules</b> , the module <b>AAI-030-00</b> . Exit the dialog with <b>OK</b> . <b>Response:</b> The module is inserted in the I/O map.
4	Repeat steps 1 to 3 for all the modules in the example (see <b>Local Momentum drop</b> ).
5	In the <b>In Ref</b> and <b>Out Ref</b> columns, set the start references for the input and output modules. <b>Note:</b> Discrete Input References have the prefix 1 (e.g. 100001), Coil References have the prefix 0 (e.g. 000001), Input Register References have the prefix 3 (e.g. 300001) and Output Register References have the prefix 4 (e.g. 400001). <b>Response:</b> The end reference (column <b>In.End.</b> or <b>Out.End</b> ) of the available address range is automatically entered.

**Dialog display**


Following module mapping and I/O reference specification the dialog looks like this:



**Note:** With this addressing the 8 measurements of the AAI-030-00 are to be found in the words 300001-300008. The parameters are in the words 400001 and 400002.

**Set Module Parameters**

To set parameters for the module proceed as follows in the **Local Momentum Drop** dialog:

Step	Action
1	Select the <b>Params</b> command button. <b>Response:</b> The <b>170-DDI-353-00</b> dialog is opened.
2	Select the signal conditions for the input and output channels from the list boxes and exit the dialog using <b>OK</b> . <b>Note:</b> Help with this can be obtained from the corresponding help text in the parameter dialog. <b>Response:</b> The parameter settings are automatically allocated to the addresses 400001 and 400002. Dialog display 
3	Exit the dialog using <b>OK</b> . <b>Response:</b> You return automatically to the <b>I/O Map</b> dialog.

**Editing Remote Drops (I/O bus)**

To edit the remote drop open the **RIO I/O Bus Drop** dialog. This dialog is reached via the **I/O Map** dialog by pressing the **Edit...** command button in the second drop (I/O bus).


## Example – Editing Remote Drops (I/O Bus)

---

### Introduction

This section describes the configuration of the Momentum I/O bus. The drop has already been defined in *Editing the First (local) Drop* (See *Editing local drop*, p. 814). When editing the I/O bus the modules must be specified with their I/O references before the individuals modules can be parameterized.

Momentum – remote controller with I/O bus



- 1 Host Computer
  - 2 I/O unit e.g. 170-AAI-030-00
  - 3 Interface adapter e.g. 172-PNN-210-22
  - 4 CPU adapter e.g. 171-CCC-760-10-984
  - 5 I/O bus interface
  - 6 Bus adapter e.g. 170-INT-110-00
  - 7 I/O unit e.g. 170-AMM-090-00
-




**Mapping Modules and Specifying I/O References**

To map the modules and specify the address ranges proceed as follows in the **Local TSX Compact Drop** dialog:

Step	Action
1	Select the <b>Module</b> → ... column. <b>Response:</b> The <b>I/O Module Selection</b> dialog is opened.
2	From the <b>Category</b> column, select the <b>&lt;all&gt;</b> option. <b>Response:</b> All modules are listed in the <b>Modules</b> column.
3	Select from the column <b>Modules</b> , the module <b>AMM-090-00</b> . Exit the dialog with <b>OK</b> . <b>Response:</b> The module is inserted in the I/O map.
4	Repeat steps 1 to 3 for all the modules in the example (see <b>Local Quantum Drop</b> dialog representation).
5	In the <b>In Ref</b> and <b>Out Ref</b> columns, set the start references for the input and output modules. <b>Note:</b> Discrete Input References have the prefix 1 (e.g. 100001), Coil References have the prefix 0 (e.g. 000001), Input Register References have the prefix 3 (e.g. 300001) and Output Register References have the prefix 4 (e.g. 400001). <b>Response:</b> The end reference (column <b>In.End.</b> or <b>Out.End.</b> ) of the available address range is automatically entered.

**Dialog display**

Following module mapping and I/O reference specification the dialog looks like this:




**Note:** With this addressing, the 4 measurements of the AMM-090-00 are to be found in the words 300009-300013. The parameters are in the words 400009-400013.

**Set Module Parameters**

To set parameters for the module proceed as follows in the **RIO I/O Bus Drop** dialog:

Step	Action
1	Select column <b>No.</b> line <b>1</b> . <b>Response:</b> The <b>1</b> text box has a dark background, i.e. the <b>AMM-090-00</b> module has been selected for editing.
2	Select the <b>Params</b> command button. <b>Response:</b> The <b>170-AMM-090-00</b> dialog is opened.
3	Select the signal states for the input and output channels from the list boxes and exit the dialog using <b>OK</b> . <b>Note:</b> Help with this can be obtained from the help text in the parameter dialog. <b>Response:</b> The parameter settings are automatically allocated to the addresses 400009-400013. Dialog display



---

## E.11 Momentum Example - Ethernet Bus System

---

### Introduction

---

**Overview** This chapter contains step-by-step instructions for the configuration of an Ethernet bus system with Momentum.

---

**What's in this section?** This section contains the following topics:

Topic	Page
Configure Ethernet	822
Network Configuration in Different Operating Systems	823
Editing local drop	833
Online-Verbindung herstellen	836

---

## Configure Ethernet

---

**Preconditions** To configure an Ethernet bus system, the following preconditions must be fulfilled:

- PCI network cards in the host computer
- Installation of the network card driver
- Setting Ethernet interface parameters
- Addressing the M1 Ethernet CPU

---

**Installing the PCI network card** For a link to an Ethernet bus system an Ethernet interface located on a PCI network card must be available in the host computer. This card can be upgraded in PCs, as long as a PCI slot is available. Information about this can be found in the computer manufacturer's user manual.

---

**Network configuration** Network configurations for different operating systems are given in section *Network Configuration in Different Operating Systems, p. 823*.

---

**Installing Drivers** Following the installation of the PCI network card the drivers, which come with the network card, must be installed.  
To proceed further, the IP address of the network card is required (it may be necessary to contact network administrator).

---

**Addressing the M1 Ethernet CPU** The M1 Ethernet CPU does not have an IP address when supplied, and must therefore be determined in the **Ethernet / I/O Scanner** dialog. The address for the gateway and Subnet Mask is also determined in this dialog.  
The IP address can be assigned via the system administrator or the BOOTP server.

**Note:** It is important to ensure that the IP address has not already been assigned to another device. Double addressing causes an unforeseeable function in the network.


After addressing, saving to Flash is recommended (**Online Control Panel** → **Flash Program...**), so that the settings are not lost in case of a power outage.


---

## Network Configuration in Different Operating Systems

### Network configuration in Win 98


Declare this IP address in the operating system as follows:

Step	Action
1	<p>Select <b>Start</b> → <b>Settings</b> → <b>Control Panel</b> → <b>Network</b>.  <b>Response:</b> The <b>Network</b> dialog box is opened.                      Dialog display</p>  <p>The screenshot shows the 'Network' dialog box with the 'Configuration' tab selected. Under 'The following network components are installed:', 'TCP/IP' is highlighted. Below the list are buttons for 'Add...', 'Remove', and 'Properties'. The 'Primary Network Logon:' dropdown menu is set to 'Client for Microsoft networks'. There is also a 'File and printer enabling...' button and a 'Description' field containing text about the Microsoft TCP/IP protocol.</p>
2	<p>Select the register <b>Configuration</b>.                      Select the network connection <b>TCP/IP</b>.</p>

Step	Action
3	<p>Select the <b>Properties</b> command button.  <b>Response:</b> The <b>TCP/IP Properties</b> dialog is opened.                      Dialog display</p> 
4	<p>Select the register <b>IP Address</b> and make the following settings.  <b>Response:</b> The programming device is then registered for network operation with the IP address.</p>


**Computer Identification in Win 98/NT**

The information is used to identify the computer in the network:


Step	Action
1	Select <b>Start</b> → <b>Settings</b> → <b>Control Panel</b> → <b>Network</b> . <b>Response:</b> The <b>Network</b> dialog box is opened.
2	Select the register <b>Identification</b> . Enter the computer name, the name of the workgroup and a short description of the computer. Dialog display 
3	Exit the dialog using <b>OK</b> .


**Network configuration in Win NT**

Declare this IP address in the operating system as follows:

Step	Action
1	<p>Select <b>Start</b> → <b>Settings</b> → <b>Control Panel</b> → <b>Network</b>. <b>Response:</b> The <b>Network</b> dialog box is opened. Dialog display</p> 




Step	Action
2	<p>Select the register <b>Protocols</b>. Dialog display</p>  <p>Select the network connection <b>TCP/IP Protocol</b>.</p>


Step	Action
3	<p>Select the <b>Properties</b> command button.</p> <p><b>Response:</b> The <b>Microsoft TCP/IP Properties</b> dialog box is opened.</p> <p>Dialog display</p>  <p>The screenshot shows the 'Microsoft TCP/IP Properties' dialog box with the 'IP address' tab selected. It contains a text box for IP address, a 'Subnet Mask' field, and a 'Standard Gateway' field. The 'Enter IP Address' radio button is selected. The network card selected is '[1] 3 Com Etherlink III-Adapter'. There are 'OK', 'Cancel', and 'Apply' buttons at the bottom.</p>
4	<p>Select the register <b>IP Address</b> and make the following settings.</p> <p><b>Response:</b> The programming device is then registered for network operation with the IP address.</p>


**Network configuration in Win 2000**

Declare this IP address in the operating system as follows:

Step	Action
1	Select <b>Start</b> → <b>Settings</b> → <b>Network and Dial-Up Connections</b> . <b>Response:</b> The <b>Network and Dial-Up Connections</b> window is opened.
2	Select the <b>LAN Connection</b> icon. <b>Response:</b> The <b>LAN Connection status</b> dialog box is opened. Dialog display




Step	Action
3	<p>Select the <b>Properties</b> command button.</p> <p><b>Response:</b> The <b>LAN Connection Properties</b> dialog box is opened.</p> <p>Dialog display</p>  <p>The screenshot shows the 'LAN Connection Properties' dialog box with the 'General' tab selected. Under 'Establish connection using:', the text '3Com 3C918 integrated Fast Ethernet-Controller [3C905B-' is displayed in a text box, with a 'Configure' button to its right. Below this, under 'Activated components are used by this connection:', there are three checked items: 'Client for Microsoft networks', 'File and printer enabling for Microsoft networks', and 'Internet Protocol (TCP/IP)'. The 'Internet Protocol (TCP/IP)' item is highlighted with a black background. At the bottom of this section are three buttons: 'Install...', 'Uninstall', and 'Properties'. A 'Description' section at the bottom contains the text: 'TCP/IP, the standard protocol for WAN networks which allow data to be exchanged over different, connected networks.' Below the description is a checkbox labeled 'Show icon in the task bar when connected'. At the very bottom of the dialog are 'OK' and 'Cancel' buttons.</p>
4	Select the network connection <b>Internet Protocol (TCP/IP)</b> .

Step	Action
5	<p>Select the <b>Properties</b> command button.</p> <p><b>Response:</b> The <b>Internet Protocol (TCP/IP) Properties</b> dialog box is opened.</p> <p>Dialog display</p> 
6	<p>Make the settings there.</p> <p><b>Response:</b> The programming device is then registered for network operation with the IP address.</p>

**Computer Identification in Win 2000**

The information is used to identify the computer in the network:

Step	Action
1	Select <b>Start</b> → <b>Settings</b> → <b>Control Panel</b> → <b>System</b> . <b>Response:</b> The <b>System Properties</b> window is opened.
2	Select the register <b>Network Identification</b> . Dialog display 
3	Select the <b>Network ID</b> command button. <b>Response:</b> The assistant for creating a user on the network is started. Or select the <b>Properties</b> command button. <b>Response:</b> The <b>Identification Changes</b> dialog box is opened.
4	Exit the dialog using <b>OK</b> .

---

## Editing local drop

---

### Introduction


This section describes the configuration of the local I/O station (Drop). The processing sequence begins first of all with the definition of the drop. When editing the local I/O station (Drop) the I/O unit must be specified with its I/O references before parametering of the individual assemblies can take place.

**Note:** Only particular CPUs can be used for the Ethernet bus configuration.

The following CPUs are available:

- 171 CCC 980 30
- 171 CCC 960 30
- 171 CCC 980 20
- 171 CCC 960 20

### Momentum - Ethernet Bus System



- 1 Host Computer
  - 2 Ethernet network card
  - 3 I/O unit e.g. 170-AMM-090-00
  - 4 CPU adapter e.g. 171-CCC-960-20-IEC
  - 5 Hub or Switch
-

**Defining Drops**

To define drops proceed as follows in the **PLC Configuration** window:

Step	Action
1	Select <b>PLC Selection</b> . <b>Response:</b> The <b>PLC selection</b> dialog is opened.
2	Select the PLC family <b>Momentum</b> and CPU <b>171-CCC-960-20-IEC</b> . Use <b>OK</b> return to the <b>PLC Configuration</b> window.
3	Select <b>I/O Map</b> . <b>Response:</b> The <b>I/O Map</b> dialog is opened and the first drop is automatically entered in the table.
4	Select the drop from the <b>Drop</b> column. Select the <b>Edit...</b> command button. <b>Response:</b> You reach the module map.

**Mapping Modules and Specifying I/O References**


To map the modules and specify the address ranges proceed as follows in the **Local Quantum Drop** dialog:

Step	Action
1	Select the <b>Module → ...</b> column. <b>Response:</b> The <b>I/O Module Selection</b> dialog is opened.
2	From the <b>Category</b> column, select the <b>&lt;all&gt;</b> option. <b>Response:</b> All modules are listed in the <b>Modules</b> column.
3	Select from the column <b>Modules</b> , the module <b>AMM-090-00</b> . Exit the dialog with <b>OK</b> . <b>Response:</b> The module is inserted in the I/O map.
4	In the <b>In Ref</b> and <b>Out Ref</b> columns, set the start references for the input and output modules. <b>Note:</b> Discrete Input References have the prefix 1 (e.g. 100001), Coil References have the prefix 0 (e.g. 000001), Input Register References have the prefix 3 (e.g. 300001) and Output Register References have the prefix 4 (e.g. 400001). <b>Response:</b> The end reference (column <b>In.End.</b> or <b>Out.End.</b> ) of the available address range is automatically entered.



**Dialog display**

Following module mapping and I/O reference specification the dialog looks like this:



**Set module parameters**

To set parameters for the individual modules, proceed as follows in the **Local Momentum Drop** dialog:

Step	Action
1	Select the <b>Params</b> command button. <b>Response:</b> The <b>170-AMM-090-00</b> dialog is opened.
2	Select the signal states for the input and output channels from the list boxes and exit the dialog using <b>OK</b> . <b>Note:</b> Help with this can be obtained from the corresponding help text in the parameter dialog. Dialog display

**170 AMM 090 00**

<p><b>Eingangs-Auswahl</b></p> <p>Kanal 1: 1..5V oder 4..20mA ▼</p> <p>Kanal 2: 1..5V oder 4..20mA ▼</p> <p>Kanal 3: 1..5V oder 4..20mA ▼</p> <p>Kanal 4: 1..5V oder 4..20mA ▼</p>	<p><b>Ausgangs-Auswahl</b></p> <p>Kanal 1 Ausgang: Sperren ▼</p> <p>Kanal 1 Rückfall: +0mA bis +20mA -10 V bis + 10 V</p> <p>Kanal 2 Ausgang: Sperren ▼</p> <p>Kanal 2 Rückfall: Ausgang auf Zero ▼</p>
--	---

**Parameter-Worte**

Wort 1: AAAA    Wort 2: 0044

OK    Abbrechen    Hilfe


## Connect online

### Introduction

This chapter describes how a link is created between the programming device and the Ethernet bus system.

### Creating a link

For the link between the programming device and the Ethernet bus system use the Concept main menu **Online** and proceed as follows.

Step	Action
1	Select menu command <b>Link...</b> <b>Response:</b> The <b>Link to PLC</b> dialog box opens.
2	From the list <b>Protocol type</b> select the link <b>TCP/IP</b> . <b>Response:</b> The zone <b>Protocol settings</b> alters for the TCP/IP settings.
3	In the text box IP address or DNS hostname enter the IP address of the Ethernet network card (PCI card). <b>Note:</b> Make sure that the address in Concept matches the address in Network settings of the operating system (See <i>Network configuration in Win 98, p. 823</i> ). <b>Response:</b> An online link exists between the programming device and the Ethernet bus system, and all bus nodes are displayed in the list. Dialog display 
4	Exit the dialog using <b>OK</b> .

---

## Convert Projects/DFBs/Macros



---

### Converting projects/DFBs


#### At a Glance

The four main steps for converting projects/DFBs are as follows:

Step	Action
1	Exporting projects/DFBs/macros within the earlier version of Concept, see <i>Exporting project/DFB/macro (earlier version of Concept)</i> , p. 838.
2	For information on installing the new version of Concept, see <i>Installing new versions of Concepts</i> , p. 839.
3	For information on importing projects/DFBs/macros, see <i>Importing project/DFB/macro</i> , p. 839.
4	For information on editing projects/DFBs/macros, see <i>Editing the project/DFB/macro</i> , p. 839.


---

### Converting EFBs

	<b>CAUTION</b>
	<b>Risk of losing data</b> If user-defined EFBs are being used in the project (EFBs which have been created manually), the current version of the EFB toolkit must be used to convert them ( <b>File</b> → <b>Concept library...</b> ). The Concept converter is not able to convert user-defined EFBs. <b>Failure to observe this precaution can result in injury or equipment damage.</b>


**Exporting project/DFB/macro (earlier version of Concept)**

The procedure for exporting projects/DFBs/macros is as follows:

	<b>CAUTION</b>
	<p><b>Risk of losing data</b></p> <p>The following steps must be performed in the <b>EARLIER</b> version of Concept. The new version of Concept may only be installed once all existing projects have been exported.</p> <p><b>Failure to observe this precaution can result in injury or equipment damage.</b></p>

Step	Action
1	Start the Concept converter.
2	From <b>File</b> → <b>Export...</b> open the menu to select the export range.
3	<p>Select the required export range:</p> <ul style="list-style-type: none"> <li>● <b>Project with used DFBs:</b> All project information including the DFBs and data structures used within the project (derived data types) will be exported.</li> <li>● <b>Project with all DFBs + macros:</b> All project information including all the DFBs and data structures (derived data types) will be exported.</li> <li>● <b>Project without DFBs:</b> All project information including all data structures (derived data types), but excluding DFBs and macros will be exported.</li> <li>● <b>Single DFB with used DFBs/single macro:</b> Only the selected DFB/macro will be exported.</li> </ul> <p><b>Reaction:</b> The select export data dialog box will be opened.</p>
4	<p>Different file extensions must be selected depending on the element to be exported:</p> <ul style="list-style-type: none"> <li>● <b>Exporting projects:</b> From the Format list select the extension .prj.</li> <li>● <b>Exporting DFBs:</b> From the Format list select the extension .dfb.</li> <li>● <b>Exporting macros:</b> From the Format list select the extension .mac.</li> </ul>
5	<p>Select the project / DFB / macro and confirm with <b>OK</b>.</p> <p><b>Reaction:</b> The project/DFBs/macros/data structures (derived data types) will be contained in the current directory as an ASCII data file (.asc).</p>
6	Quit the Concept converter with <b>File</b> → <b>Quit</b> .

### Installing new versions of Concepts

	<b>CAUTION</b>
	<p><b>Risk of losing data</b> Only install the NEW version of Concept if you have performed the previous steps.</p> <p><b>Failure to observe this precaution can result in injury or equipment damage.</b></p>

Follow the procedure described in the "Installation" chapter of the installation instructions.

### Importing project/DFB/macro

The procedure for importing projects/DFBs/macros is as follows:

Step	Action
1	Start the Concept converter.
2	From <b>File</b> → <b>Import...</b> open the select import projects/DFBs/macros dialog box.
3	Select the project/DFB/macro (data file format .asc) and confirm with <b>OK</b> . <b>Reaction:</b> The project/DFBs/macros/data structures will be contained in the current directory as Concept data files.
4	Quit the Concept converter with <b>File</b> → <b>Quit</b> .

### Editing the project/DFB/macro

Start the Concept/Concept DFB and edit the project/DFBs/macros/data structures in the usual way.



---

## Concept ModConnect



---

### At a Glance

#### Introduction

This chapter describes how to integrate third party modules into the Concept I/O map and how to remove it.

#### What's in this chapter?

This chapter contains the following Sections:

Section	Topic	Page
G.1	Introduction	843
G.2	Integration of Third Party Modules	844
G.3	Use of third party module in Concept	847





## G.1 Introduction

---

### Introduction

---

#### Overview

Information on hardware and I/O modules is stored in the Concept System Information Database (SysInfDb). This database is maintained and updated by Schneider and included with every Concept release. Nevertheless, Concept is able to support new I/O modules without having to wait for a new release. That's where the ModConnect Tool comes in - it takes a textual module description (MDC) and adds this information into the SysInfDb. This means that supplier of a new I/O module, who wants this module to be available in Concept, must also deliver an MDC file which describes the characteristics of this module.

Once installed, the I/O modules have the same functionality as existing Schneider Automation modules. This includes the ability to set module parameters and to display an online help.

For the installation of new modules, the third party module manufacturer has to supply a disk which contains a specific MDC file and the help information.

**Note:** The MDC file is dependent on the version of Concept so if you upgrade your Concept version, make sure you get also an upgraded version of your previously used MDC files. You will have to reinstall them.

---

## G.2 Integration of Third Party Modules

---

### At a Glance

---

**Introduction** This chapter describes the procedures which have to be used in Concept ModConnect in order to integrate third party modules into Concept or to remove it.

---

**What's in this section?** This section contains the following topics:

Topic	Page
Integrating new Modules	845
Removing Modules	846

---

## Integrating new Modules

### Precondition

The specific MDC file for the new module has to be available.

### Integrating new Modules

For integrating new modules, proceed the following steps:

Step	Action
1	For starting the application select <b>ModConnect Tool</b> in the Concept programm group. <b>Reaction:</b> Concept ModConnect displays its main window. If any Modules have been installed, a list of installed modules is shown.
2	Copy the MDC file and the help file supplied with module to the Concept installation path.
3	Select <b>File</b> → <b>Open Installation File...</b> <b>Reaction:</b> A dialog for selection the specific MDC file is opened.
4	Set the correct path to the MDC file and select it (e.g. SAMPLE.MDC). Confirm with <b>OK</b> . <b>Reaction:</b> The path including the name of the MDC file is now displayed in the <b>Select Module</b> dialog along with the defined modules.
5	Select the module you want to add and click <b>Add Module</b> or in the case of multiple entries click on the <b>Add All</b> button. You may additionally click the <b>Browse</b> button to return to the <b>Open file</b> dialog where you can select another .MDC for evaluation.
6	Click on the <b>Close</b> button to return to the main window. <b>Reaction:</b> The main window will now be displayed with the module information appearing in the <b>Imported Modules in Concept Database</b> window. By clicking on the added module (to select it) the module details are shown. With <b>Help</b> → <b>Help on Module</b> the help of the selected module can be displayed.
7	Select <b>File</b> → <b>Save Changes</b> to save the changes data base.
8	Select <b>File</b> → <b>Exit</b> for terminating Concept ModConnect. <b>Reaction:</b> The installed modules are now available in the Concept I/O map (See <i>Use of third party module in Concept, p. 847</i> ).

### Upgrade of Concept

**Note:** The MDC-File is dependent on the version of Concept so if you upgrade your Concept version, make sure you get also an upgraded version of your previously used MDC files. You will have to reinstall them.

## Removing Modules

---

### Removing Modules

For removing modules, proceed the following steps:

Step	Action
1	For starting the application select <b>ModConnect Tool</b> in the Concept programm group. <b>Reaction:</b> Concept ModConnect displays its main window with a list of the installed modules.
2	Select the module you want to remove and select <b>File</b> → <b>Remove selected Module</b> . <b>Reaction:</b> The <b>Confirm IOModule Removal</b> dialog is displayed.
3	Selecting <b>OK</b> , causes the removal of the module from Concept. <b>Reaction:</b> The module is no longer listed in the main window of Concept ModConnect or in the <b>I/O Module Selection</b> list box of Concept. <b>Note:</b> When removing modules. If the module has been used in existing Concept projects, the integrity of these projects will be compromised.
4	Select <b>File</b> → <b>Save Changes</b> to save the changes data base.
5	Select <b>File</b> → <b>Exit</b> for terminating Concept ModConnect. <b>Reaction:</b> The installed modules are now available in the Concept I/O map (See <i>Use of third party module in Concept, p. 847</i> ).

---

## G.3 Use of third party module in Concept

### Use of Third Party Modules in Concept

**Precondition** The modules have to be installed according to the procedure *Integrating new Modules*, p. 845.

**Insert module to I/O Map** To insert a module to the I/O map, proceed the following steps:

Step	Action
1	Start Concept.
2	Open the configurator with <b>Project</b> → <b>Configurator</b> .
3	Open the I/O map with <b>I/O map...</b> → <b>Edit...</b>
4	Open the <b>I/O Module Selection</b> dialog by clicking on ... at the <b>Module</b> column. <b>Reaction:</b> The third party modules appear in the <b>Other</b> column.
5	Select the module by clicking. <b>Reaction:</b> A short description appear at the top of the dialog. You may press the <b>Help on Module</b> button to display the module's help file supplied by the vendor.
6	Click on <b>OK</b> (or doubleclick on the module) to insert the module the the I/O map. <b>Reaction:</b> The <b>I/O Module Selection</b> dialog is closes and the selected module is inserted in the I/O map.
7	For entering the module's parameters (if available), select the <b>Rack-Slot</b> column of the module and click on the <b>Params</b> button. <b>Reaction:</b> The parameter screen for the selected dialog is opened.
8	Set the parameters for the module and confirm with <b>OK</b> .
9	Enter the input and output references for the module.
10	Confirm the I/O map with <b>OK</b> and save the project with <b>File</b> → <b>Save project</b> .



---

## Conversion of Modsoft Programs



---

### At a Glance

#### Introduction

This information provides you with the necessary process required to change previously generated Modsoft derived Ladder Logic programs into the Concept environment.

#### What's in this chapter?

This chapter contains the following topics:

Topic	Page
Introduction	850
How to Convert a Modsoft Program	852
Exceptions	853

## Introduction

---

### Overview

For the conversion of an existing Modsoft program to a valid Concept 984 Ladder Logic project the Modsoft Converter is used. The Modsoft Converter provides current Modsoft users with a migration path to the 984 Ladder Logic for Windows environment. The Modsoft Converter requires no previous knowledge of the Concept programming environment. The term project is synonymous with a Modsoft program.

---

### Starting the Modsoft Converter

Windows 98, Windows 2000 or Windows NT allows you to run the program from the **Start** menu, by selecting **Modsoft Converter** in the Concept program group.

---

### The Modsoft .env File

For the conversion the Modsoft .env file is needed. The .env file contains all the file information pertaining to the Modsoft program.

The Modsoft .env file contains the following files:

- **.CFG** Configuration file
- **.PRG** Ladder Logic file
- **.PCM** Network comments
- **.PCT** Network comments
- **.ASC** ASCII file
- **.USL** User Loadables
- **.RFD** Reference presets set by the user in the Modsoft Reference Data Editor
- **.REF** Reference contents contained in the PLC, from an upload
- **.RSF** Reference symbols

The convert process requires the .CFG file to be present in the .env file. If it does not exist, an error dialog is displayed indicating that the .env file does not reference a .CFG file. All other files are optional.

By forcing you to enter the Modsoft \*.env filename, some of the validation is avoided that would otherwise be required if you were allowed to enter a \*.prg and \*.cfg name separately, i.e. Loadables (DX, User and EXE), state ram and builtin functions.

---

### Incompatibilities

Due to differences in "address calculations in the configuration table" between Modsoft 2.6 and Concept 2.2 or later, the same Modsoft program loaded in a PLC and converted using the Modsoft Converter will cause a configuration miscompare in certain page zero locations. This will not affect the validity of the converted program.

---



---

<b>Invalid PLC Types</b>	If the Modsoft configuration file PLC type, is not legal for Concept, you are warned that the convert process will not continue. You then have to return to Modsoft and change the PLC type to one that is valid.
<b>Handling of SY/MAX</b>	SY/MAX programs converted to Modsoft file format will migrate to the Quantum PLC type. The Modsoft Convert utility can then bring the SY/MAX program into Concept.
<b>Modsoft Version</b>	The Convert utility handles Modsoft file format supported in revision 2.2 or greater.
<b>Handling of SFC and Macros</b>	Modsoft does allow the user to save a Ladder Logic program that consists of undefined elements, and Concept needs to resolve those elements. The Modsoft Ladder Logic program is converted without performing any validity checks against the Configuration. When the Modsoft *.prg file contains either SFC or Macros the convert process is aborted and an Error dialog is displayed informing you to return to Modsoft and use <b>Segment Status</b> → <b>Commands</b> → <b>Convert to File</b> . This process expands the Macros and translates the SFC elements.
<b>Handling of I/O Map</b>	Modsoft sets a default I/O map size of 512. Concept does not, but calculates the size as required. Uploading a Controller that has been downloaded with Modsoft will cause a miscompare. You are allowed to continue.
<b>Handling of References</b>	Modsoft can have two types of reference data or none at all. There exists online reference data information (RAM) if you have uploaded from the PLC. There are also references defined using the offline Reference Data Editor. When both types of data exist in the .env file, the convert utility first imports the online references then overlays the offline reference data.

---

## How to Convert a Modsoft Program

---

**Precondition** For converting a Modsoft program the Modsoft .env file (See *The Modsoft .env File*, p. 850) is necessary. The .env file contains all the file information pertaining to the Modsoft program. Once selected the conversion takes place and you are prompted to a **Save as** dialog.

---

**How to Convert a Modsoft Programm** For converting a Modsoft programm, proceed the following steps:

Step	Action
1	Open the Modsoft Converter.
2	Select <b>File</b> → <b>Convert...</b>
3	Select the drive and the directory, where to find the Modsoft .env file. (The file will be found in the Modsoft program directory, e.g. C:\Modsoft\Programs.)
4	Pick the file from the list.
5	<p>Start the conversion with <b>Convert</b>.</p> <p><b>Reaction:</b> The conversion is started.</p> <ul style="list-style-type: none"> <li>• A convert progress dialog is displayed after the validity checks on the *.env file are performed. The first line of the dialog indicates the section currently being converted and the second line indicates progress as it pertains to the whole convert process.</li> <li>• If any errors, such as <b>Out of memory</b>, <b>Out of disk space</b> or <b>File access errors</b>, occur during the convert process, an error dialog is displayed.</li> <li>• An operation completed error free results in the automatic display of the <b>Save as Concept project</b> dialog). The default name of the project, displayed in the Save project dialog, is the *.env filename prompt.</li> </ul>
6	<p>You can then change the project name and the directory in which Concept project will be saved.</p> <p><b>Reaction:</b> If the project name selected already exists a confirmation dialog is displayed.</p> <p><b>Note:</b> Saving the Modsoft converted program as a Concept project does not have to be done at this time, you can still save using the <b>File</b> → <b>Save project as</b> menu item.</p>

---

## Exceptions

### Description

0x and 1x references in a Modsoft program are converted to a Located Variable with data type BOOL in Concept. This data type is compatible with the use of these references.

However, 3x and 4x are converted to integer.

**Note:** This straight conversion precludes both Modsoft bit definition and floating point types.

### Example

If you have the following defined in **Modsoft**:

REF	BIT	SYMBOL	DESCRIPTOR
000001		located_0x_boolean	located 0x boolean descriptor
100001		located_1x_boolean	located 1x boolean descriptor
300001	/16	bit_16_of_3000001	16th bit of 300001 descriptor
400100		incoming_integer	incoming integer descriptor
400200		outgoing_interger	outgoing flt32 descriptor
400300	/ 1	bit_1_of_400300	bit 1 of 400300 descriptor


A conversion of the above to **Concept** using the Convert program yields:

Variable Name	Data Type	Address	Comment
located_0x_boolean	BOOL	000001	located 0x boolean descriptor
located_1x_boolean	BOOL	100001	located 1x boolean descriptor
bit_16_of_3000001	INT	300001	16th bit of 300001 descriptor
incoming_integer	INT	400100	incoming integer descriptor
outgoing_interger	INT	400200	outgoing flt32 descriptor
bit_1_of_400300	INT	400300	bit 1 of 400300 descriptor



---

## Modsoft and 984 References



---

### At a Glance

#### Introduction

This chapter contains the Modsoft and 984 References.

#### What's in this chapter?

This chapter contains the following topics:

Topic	Page
Modsoft Keys with Concept Equivalents	856
Modsoft Function Compatibility	858

## Modsoft Keys with Concept Equivalents

### Keys

**Note:** When possible, the **Ctrl** key is used in place of the Modsoft **Alt** key.

Table of keys:

Funtion	Modsoft 2.x Key	Concept Key
Normally open contact	' or "	same
Coil	( or [	same
Normally closed contacts	/ or \	same
Horizontal short	=	same
Vertical short		same
Negative transitional contact	<b>Alt+N</b>	<b>N</b>
Positive transitional contact	<b>Alt+P</b>	<b>P</b>
Inserting a function block by name	<b>Alt+F</b>	<b>Ctrl+F</b>
Copy element(s)	<b>Alt+F3</b>	<b>Ctrl+C</b>
Delete element(s)	<b>Alt+F4</b> or <b>Del</b>	<b>Ctrl+X</b> or <b>Del</b>
Paste	<b>Alt+F5</b>	<b>Ctrl+V</b>
Offset references	<b>Alt+F6</b>	<b>Ctrl+H</b>
Search	<b>Alt+F7</b>	<b>F3</b>
Search next	<b>Alt+F8</b>	<b>F6</b> When online in direct mode, Concept uses a nonmodal dialog with accelerators for search previous and search next.
Network comments	<b>Alt+C</b>	<b>Ctrl+M</b>
Goto network	<b>Alt+G</b>	<b>Ctrl+G</b>
Insert network	<b>Alt+I</b>	<b>Ctrl+I</b>
Append network	<b>Alt+A</b>	<b>Ctrl+A</b>
Trace	<b>Alt+T</b>	<b>Ctrl+T</b>
Retrace	<b>Alt+B</b>	<b>Ctrl+B</b> or <b>Ctrl+T</b>
Dx zoom	<b>Alt+Z</b>	<b>Ctrl+D</b>
Goto node (1,1) of active network	<b>Home</b>	same
Goto node (7,11) of active network	<b>End</b>	same
Goto first network in current segment	<b>Ctrl+Home</b>	same

<b>Funtion</b>	<b>Modsoft 2.x Key</b>	<b>Concept Key</b>
Goto last network in current segment	<b>Ctrl+End</b>	same
Insert equation	<b>Ins</b>	<b>Ctrl+Q</b>
Append	-	<b>Ctrl+A</b>
Append equation	-	<b>Ctrl+U</b>
Delete current network	-	<b>Ctrl+K</b>
Copy to the clipboard	-	<b>Ctrl+C</b>
Undo	-	<b>Ctrl+Z</b>
Closing an mdi child window	-	<b>Ctrl+F4</b>
Switching to the next open mdi child window	-	<b>Ctrl+F6</b>

### **Status Line Values**

These Concept keys change the status line display value of the currently selected reference:

- A** ASCII
- H** Hexidecimal
- D** Decimal (signed)
- U** Decimal (unsigned)
- R** Real
- L** Long (32 bit)
- S** Short (16 bit)

## Modsoft Function Compatibility

---

### Not Supported Features

The following Modsoft functions are **not** supported in Concept:

- Macros/macro programming
  - SFC (use IEC SFC instead)
  - Search of comments
- 

### User Interface Difference

Concept is an MS-Windows based application. Modsoft is a DOS based application. Concept uses MS-Windows user interface standards and practices. Functions of Concept with 984 Ladder editor are based on the pre-existing functions of Concept.

There are no exact similarities of specific user actions required to perform Concept tasks as compared to Modsoft tasks.

---

### Constant Sweep

Concept has no off line selection to set the constant sweep mode. This mode is available from the **Online Control Panel**.

Once constant sweep has been set in the controller, you can upload the controller and save the project. The constant sweep settings will be retained in the project. If this project is downloaded, the constant sweep settings will be set.

<p><b>Note:</b> Any changes to the controller configuration cause the constant sweep settings to be reset, i.e, constant sweep is disabled whenever the controller configuration changes. Follow the steps above to reenable constant sweep.</p>
--

---

### How to Start the Constant Sweep

To set constant sweep before starting the controller, follow these steps:

Step	Action
1	Create your configuration and program logic, offline.
2	Download your program to the controller. When the dialog appears asking Do you want to start the controller?"click on the <b>No</b> button.
3	From the <b>Online</b> menu, choose <b>Online Control Panel</b> .
4	Set the constant sweep mode and sweep time.
5	Start the controller.

---



---

## Presettings when using Modbus Plus for startup



---

### Introduction

#### Overview

This chapter provides a brief description of the presettings when using Modbus Plus for first startup.

#### What's in this chapter?

This chapter contains the following topics:

Topic	Page
Installing the SA85 in Windows 98/2000	860
Installing the SA85 in Windows NT	863
Installing the Modbus Plus Driver in Windows 98/2000/NT	865
Virtual MBX Driver for 16 bit application capability with Windows 98/2000/NT	866
MBX Driver for connection between ModConnect Host interface adapters and 32 bit applications with Windows 98/2000/NT	867
Remote MBX - Driver for Remote Operation	868
Ethernet MBX - Driver for Modbus Plus Function via TCP/IP	869
Establishing the hardware connection.	871

---

## Installing the SA85 in Windows 98/2000

---

### Hardware configuration

Carry out the following steps to set the SA85 hardware settings:

Step	Action
1	Set the Modbus node address (Modbus Plus Port Address) and the memory based address on the SA85 (see documentation "IBM Host Based Devices").
2	Install the SA85 as described in the "IBM Host Based Devices" documentation.

---

### Installing Drivers

Install the Virtual MBX driver and then the MBX or Remote MBX driver.

Also see:

- *Virtual MBX Driver for 16 bit application capability with Windows 98/2000/NT, p. 866*
  - *MBX Driver for connection between ModConnect Host interface adapters and 32 bit applications with Windows 98/2000/NT, p. 867*
  - *Remote MBX - Driver for Remote Operation, p. 868*
- 

### SA85 configuration

Carry out the following steps to configure the SA85 after installing the driver:

Step	Action
1	Open the control panel ( <b>Start</b> → <b>Settings</b> → <b>Control Panel</b> ).
2	Select the <b>Hardware</b> symbol. <b>Response:</b> The hardware wizard is called.
3	Select the <b>Next</b> command button.
4	<b>Windows 98:</b> Select the option <b>Yes (recommended)</b> . <b>Windows 2000:</b> Select the option <b>Add/Troubleshoot a device</b> . Select the <b>Next</b> command button. <b>Response:</b> Hardware recognition is started.
5	<b>only Windows 98:</b> Select the command button <b>Next</b> . <b>Response:</b> The status of the hardware recognition is displayed.
6	<b>only Windows 98:</b> Select the command button <b>Next</b> . <b>Response:</b> All hardware types found are listed.
7	Select the hardware type <b>MBX Devices for Modicon Networks</b> , and press <b>Next</b> . <b>Response:</b> The database with driver information is installed.
8	Select the adapter <b>SA85-000</b> and press <b>Next</b> . <b>Response:</b> A memory area is automatically created.
9	Select the <b>Next</b> command button. <b>Response:</b> The device no. and polled mode (20 ms) are automatically displayed.

Step	Action
10	Select the <b>Next</b> command button. <b>Response:</b> The software for the new hardware component is installed.
11	Select the <b>Next</b> command button. <b>Response:</b> You will be asked to shut down the computer.
12	Click <b>No</b> . <b>Response:</b> The adapter is configured with the presettings.

**Win 98: Edit SA85 configuration**

To edit the SA85 configuration with Windows 98, carry out the following steps after the first configuration:

Step	Action
1	Open the control panel ( <b>Start</b> → <b>Settings</b> → <b>Control Panel</b> ).
2	Select the <b>System</b> symbol. <b>Response:</b> The window <b>System Properties</b> is called.
3	Select the register card <b>Device Manager</b> .
4	Select the adapter <b>SA85-000</b> and press <b>Properties</b> . <b>Response:</b> The <b>SA85-000 Adapter Properties</b> window is opened.
5	Select the register <b>Device Settings</b> .
6	Make the following changes. (also see Help file LMBX9X on the driver CD.)
7	Select the register <b>Resources</b> , to change the memory area.
8	Exit the window by clicking <b>OK</b> . <b>Response:</b> The changes are excepted by the system.

**Win 2000: Edit SA85 configuration**

To edit the SA85 configuration with Windows 2000, carry out the following steps after the first configuration:

Step	Action
1	Open the control panel ( <b>Start</b> → <b>Settings</b> → <b>Control Panel</b> ).
2	Select the <b>System</b> symbol. <b>Response:</b> The <b>System Properties</b> window is opened.
3	Select the register <b>Hardware</b> .
4	Select <b>Device Manager...</b> <b>Response:</b> The <b>Device Manager</b> is opened.
5	Select <b>Network Adapter</b> → <b>SA85-000</b> .
6	Select the <b>Properties</b> command button. <b>Response:</b> The <b>SA85-000 Adapter Properties</b> window is opened.
7	Select the register <b>Device Settings</b> .
8	Make the following changes. (also see Help file LMBX9X on the driver CD.)
9	Select the register <b>Resources</b> , to change the memory area.
10	Exit the window by clicking <b>OK</b> . <b>Response:</b> The changes are excepted by the system.

**Peer Cop functionality**

Several parameter settings must be made to enable Peer Cop communication via the SA85 adapter. The Peer Cop function is deactivated as standard, and should only be released if your application requires Peer Cop communication. To release and set parameters for Peer Cop communication, start with the first steps as with "Edit SA85 Configuration". In **SA85-000 Adapter Properties**, select the register **Peer Cop** and make your settings.

---

## Installing the SA85 in Windows NT

### Hardware configuration

Carry out the following steps to set the SA85 hardware settings:

Step	Action
1	Set the Modbus node address (Modbus Plus Port Address) and the memory based address on the SA85 (see documentation "IBM Host Based Devices").
2	Install the SA85 as described in the "IBM Host Based Devices" documentation.

### Installing Drivers

Install the Virtual MBX driver and then the MBX or Remote MBX driver.

Also see:

- *Virtual MBX Driver for 16 bit application capability with Windows 98/2000/NT, p. 866*
- *MBX Driver for connection between ModConnect Host interface adapters and 32 bit applications with Windows 98/2000/NT, p. 867*
- *Remote MBX - Driver for Remote Operation, p. 868*

### SA85 configuration

Carry out the following steps to configure the SA85 after installing the driver:

Step	Action
1	In the start menu, open the folder <b>WinConX/MBXDriver (Start → Programs → WinConX)</b> .
2	Double-click on the symbol <b>MBX Driver Configuration</b> . <b>Response:</b> The dialog box <b>MBX Driver Configuration</b> is opened.
3	In the register <b>Device Configuration</b> , click on the command button <b>New</b> . <b>Response:</b> In the column <b>Device Type</b> , a list box is shown.
4	Select the option <b>SA85</b> from the list box. <b>Response:</b> The dialog box <b>SA85 Configuration</b> is opened.
5	Make the following settings. (also see Help file LMBX9X on the driver CD.)
6	Exit the dialog box by clicking <b>Close</b> . <b>Response:</b> The settings are excepted by the system.

**Edit SA85 configuration**

Carry out the following steps to edit the SA85 configuration if it has already been configured:

Step	Action
1	In the start menu, open the folder <b>WinConX/MBXDriver</b> ( <b>Start</b> → <b>Programs</b> → <b>WinConX</b> ).
2	Double-click on the symbol <b>MBX Driver Configuration</b> . <b>Response:</b> The dialog box <b>MBX Driver Configuration</b> is opened.
3	Select SA85 in the register <b>Device Configuration</b> .
4	Click on the <b>Edit</b> command button. <b>Response:</b> The dialog box <b>SA85 Configuration</b> is opened.
5	Make the following changes. (also see Help file LMBX9X on the driver CD.)
6	Exit the dialog box by clicking <b>Close</b> . <b>Response:</b> The settings are excepted by the system.

**Peer Cop functionality**

Several parameter settings must be made to enable Peer Cop communication via the SA85 adapter. The Peer Cop function is deactivated as standard, and should only be released if your application requires Peer Cop communication. To release and set parameters for Peer Cop communication, start with the first steps as with "Edit SA85 Configuration". In the dialog box **SA85 Configuration**, select the register **Peer Cop** and make your settings.

---

## Installing the Modbus Plus Driver in Windows 98/2000/NT

### Introduction

In order to use the Modbus Plus communication, you must first install the CyberLogic MBX driver for Windows 98/2000/NT version  $\geq 4.20$  (+ Service Release 1 for Windows 2000)

The following drivers are available on the CD "MBX Driver Suite v4.20":

Driver	Operating system
MBX Driver <i>MBX Driver for connection between ModConnect Host interface adapters and 32 bit applications with Windows 98/2000/NT, p. 867</i>	Windows 98/2000/NT
Virtual MBX Driver <i>Virtual MBX Driver for 16 bit application capability with Windows 98/2000/NT, p. 866</i>	Windows 98/2000/NT
Remote MBX Driver <i>Remote MBX - Driver for Remote Operation, p. 868</i>	Windows 98/2000/NT
Ethernet MBX Driver <i>Ethernet MBX - Driver for Modbus Plus Function via TCP/IP, p. 869</i>	Windows NT

### Installation

Carry out the following steps to install the Modbus Plus driver:

Step	Action
1	Start Windows.
2	Insert the CD "MBX Driver Suite ver. 4.20".
3	Select the <b>Start</b> → <b>Execute</b> command.
4	Enter the CD drive and <b>: \SETUP</b> in the command line.
5	Confirm with <b>OK</b> .
6	Follow the onscreen instructions. <b>Response:</b> After installation the WinConX program with all installed drivers is created in the Start Menu.

### Configuration

Configuration occurs automatically after installing the driver. To make changes to the configuration, open the dialog to be edited from the **WinConX** → **xxx MBX Driver** Start Menu, by double clicking on the **xxx MBX Configuration Editor** symbol.

## Virtual MBX Driver for 16 bit application capability with Windows 98/2000/NT

---

### Introduction

Installing the Virtual MBX driver guarantees the run capability of all 16 bit DOS or Windows 3.x NETLIB/NetBIOS compatible applications in their original binary form in Windows 98/2000/NT.

**Note:** A detailed description of this driver can be found in the VMBX9X or VMBXNT Help file on the "MBX Driver Suite ver4.20" CD.

### Preconditions

In order for the Virtual MBX driver to function correctly, additional drivers must be installed.  
The following additional drivers can be installed to enhance the Virtual MBX driver's run capability:

Driver	Operating system	Application
MBX	Windows 98/2000/NT	Driver for Modbus Plus Host interface adapter
Remote MBX	Windows 98/2000/NT	Driver for accessing remote nodes on the Modbus Plus and Ethernet network
Ethernet MBX	Windows NT	Driver for Modbus Plus Emulation via TCP/IP

### Installation

The virtual MBX driver software for Windows 98/2000 and Windows NT is included along with other drivers, on the CD "MBX Driver Suite ver4.20".  
Installation is done by Autorun when the CD is inserted or can be started manually (CD drive:\SETUP.EXE). Select the driver to be installed from the main menu. You will then be taken through the installation step by step. The driver is then configured.

### Configuration

**Note:** To guarantee a connection to Concept (= 16-Bit-Application), in the **Virtual MBX Driver Configuration → 16-bit Windows Applications** dialog, check the **Support 16-bit Windows Applications** checkbox.



---

## MBX Driver for connection between ModConnect Host interface adapters and 32 bit applications with Windows 98/2000/NT

---

**Introduction** The installation of the MBX driver guarantees the connection between the MODConnect Host interface adapter and 32 bit applications with Windows 98/2000/NT. This driver also supports the program interfaces MBXAPI and NETLIB. This means that practically all Modbus Plus compatible software programs can be operated via Modbus, Modbus Plus and Ethernet networks, without having to make changes. This also includes 32 bit Windows 98/2000/NT applications and 16 bit old DOS/Windows applications.

**Note:** A detailed description of the driver is included on the CD "MBX Driver Suite ver4.20" in the Help file LMBX9X or LMBXNT.

---

**Hardware support** The MBX driver operates either in Interrupt or Polled mode. It supports the following ModConnect Host interface adapter:

- ISA
- EISA
- MCA
- PC card (PCMCIA)

---

**Remote connection** The MBX driver includes the MBX Remote Server. This enables remote nodes to access local MBX devices (including the Host interface adapter) via any Windows 98/2000/NT compatible network. Also see *Remote MBX - Driver for Remote Operation*, p. 868.

---

**Installation** The MBX driver software for Windows 98/2000/NT is included along with other drivers, on the CD "MBX Driver Suite ver4.20". The installation is carried out by Autorun when the CD is inserted or can be manually started (CD drive:\SETUP.EXE). Select the driver to be installed from the main menu. You will then be taken through the installation step by step. The driver is then configured.

---

## Remote MBX - Driver for Remote Operation

---

**Introduction** The installation of the remote MBX driver allows remote connection of applications operated on remote station client nodes. Remote station access of the Modbus Plus network takes place using a standard LAN (Local Area Network). This driver also unites applications that support the program interfaces MBXAPI and NETLIB.

**Note:** A detailed description of the driver is included on the CD "MBX Driver Suite ver4.20" in the Help file RMBX9X or RMBXNT.

**Preconditions** This connection is only made if your programming device is a node on the MBX Remote Server. Also install one of these drivers because the MBX and Ethernet MBX drivers include the MBX Remote Server.

**Installation** The remote MBX driver software for Windows 98/2000/NT is included along with other drivers, on the CD "MBX Driver Suite ver4.20". The installation is carried out by Autorun when the CD is inserted or can be manually started (CD drive:\SETUP.EXE). Select the driver to be installed from the main menu. You will then be taken through the installation step by step. The driver is then configured.

**Configuration** The configuration of the remote MBX driver is presently the same as the configuration of the other MBX drivers. The remote MBX driver is operated as a remote client node, which does not require a physical host interface adapter. Therefore the driver configuration also includes the creation of logical devices (MBX Remote Client), which refer to the physical devices found on the server node.

---

## Ethernet MBX - Driver for Modbus Plus Function via TCP/IP

---

### Introduction

The installation can only be carried out in Windows NT. When the Ethernet MBX driver is installed, Modbus Plus function is emulated via TCP/IP. This driver also supports the program interfaces MBXAPI and NETLIB. This means that practically all Modbus Plus compatible software programs immediately have access to TCP/IP based communication without having to make changes. This also includes 32 bit Windows 98/2000/NT applications and 16 bit old DOS/Windows applications.

<p><b>Note:</b> A detailed description of the driver is included on the CD "MBX Driver Suite ver4.20" in the Help file EMBXNT.</p>
--

### Winsock API

When using Winsock API, the Ethernet MBX driver can solve certain critical problems created by the Winsock interface.

**For example:** TCP Port 502 can only receive one process with incoming messages. If several applications attempt to receive unexpected messages, a conflict occurs. The Ethernet MBX driver eliminated this problem by acting as global dispatcher for these messages. When using the slave path, Concept in Modbus Plus determines that several (up to 256) applications refer to these unexpected messages and execute them simultaneously.

---

**Advantage of using the driver**

The most important advantages when using the driver via the Winsock API are:

- Changes are no longer needed for existing NETLIP/NetBIOS/MBXAPI compatible applications. End user and developer software investments are completely secured.
  - Consistent management and dispatching of unexpected messages, which prevents overlaps between various products on the same system.
  - Complete functionality of TCP/IP communication, while protecting existing NETLIP/NetBIOS/MBXAPI standards.  
**For example:** Ethernet TCP/IP communication requires a identifier address in the form of an IP address, and a message contains an identifier index byte. The Ethernet MBX driver protects this functionality.
  - Working with TCP/IP communication is an advantage for software developers not experienced with the complicated Winsock API.
  - A single program model for software developers handles communication in Modbus, Modbus Plus and Ethernet TCP/IP networks.
  - Increased compatibility with various products. Winsock API is more oriented towards developer executed, TCP/IP strategies in a slightly different manner and can create compatibility problems in various products.
  - Compatible with all MBX products. How e.g. the Virtual MBX driver for use of old 16-bit DOS/Windows applications and the MBX driver which dispatches messages between Ethernet, Modbus, Modbus Plus and remote MBX nodes.
- 

**Remote connection**

The Ethernet MBX driver includes the MBX Remote Server. This enables remote nodes to access local MBX devices (including Ethernet MBX devices) via any Windows compatible network. The remote client can be a Windows 98/2000/NT node with the remote MBX driver installed. Also see *Remote MBX - Driver for Remote Operation*, p. 868.

---

**Installation**

The Ethernet MBX driver software for Windows NT is included along with other drivers, on the CD "MBX Driver Suite ver4.20". The installation is carried out by Autorun when the CD is inserted or can be manually started(CD drive:\SETUP.EXE). Select the driver to be installed from the main menu. You will then be taken through the installation step by step. The driver is then configured.

---

## Establishing the hardware connection

---

### Introduction

<p><b>Note:</b> Please refer to the "Modbus Protocol Reference Guide" for a detailed description of the hardware setup.</p>
---

---

### Procedure

To establish the hardware connection, do the following:

Step	Action
1	Set a unique Modbus node address for the CPU using the rotary switch on the back of the module.
2	Note the Modbus node address set on the CPU's sliding cover.
3	Connect the CPU to the SA85 interface with a Modbus Plus cable. <b>Result:</b> The flash interval on the CPU "Modbus +" display changes from 3 flashes per second with a pause to 6 without a pause.

---



---

## Presettings when using Modbus for startup



---

### Introduction

#### Overview

The chapter provides a brief description of the presettings when using Modbus for startup.

#### What's in this chapter?

This chapter contains the following topics:

Topic	Page
Interface settings in Windows 98/2000	874
Interface Settings in Windows NT	876
Setting up the hardware connection	876
Transfer problems	877

## Interface settings in Windows 98/2000

---

### Win 98: Interface setting

Carry out the following steps to set the interface in Windows 98:

Step	Action
1	Select the <b>Desktop</b> symbol. <b>Response:</b> All available objects are displayed.
2	Select the <b>Control Panel</b> symbol. <b>Response:</b> All available objects are displayed.
3	Select the <b>System</b> symbol. <b>Response:</b> The <b>System Properties</b> dialog is opened.
4	Select the register card <b>Device Manager</b> .
5	Select <b>Connections (COM and LPT)</b> . <b>Response:</b> The branch <b>COM connection (COMx)</b> and <b>printer port (LPTx)</b> are displayed.
6	Select <b>COM connection (COMx)</b> . <b>Response:</b> The <b>Properties for COM connection (COMx)</b> dialog is opened.
7	Select the register card <b>Connection settings</b> .
8	Select the <b>Advanced...</b> command button. <b>Response:</b> The <b>Connection settings</b> dialog is opened.
9	Tick the check box <b>Use FIFO buffer</b> . <b>Note:</b> Using the FIFO(First In First Out) buffer requires a serial port with 16550 compatible UART (Universal Asynchronous Receiver Transmitter).
10	Use the slide control to change the receive and send buffer which are both set to maximum size.
11	Close all dialogs with <b>OK</b> .

---



**Win 2000:  
Interface setting**

Carry out the following steps to set the interface in Windows 2000:

Step	Action
1	Select the <b>Desktop</b> symbol. <b>Response:</b> All available objects are displayed.
2	Select the <b>Control Panel</b> symbol. <b>Response:</b> All available objects are displayed.
3	Select the <b>System</b> symbol. <b>Response:</b> The <b>System Properties</b> dialog is opened.
4	Select the register card <b>Hardware</b> .
5	Select <b>Device Manager...</b> <b>Response:</b> The <b>Device Manager</b> is opened.
6	Select <b>Connections (COM and LPT)</b> . <b>Response:</b> The branch <b>ECP Printer port (LPT1)</b> and <b>communication port (COMx)</b> are displayed.
7	Select <b>communication connection (COMx)</b> . <b>Response:</b> The <b>Properties for Communication connection (COMx)</b> dialog is opened.
8	Select the register card <b>Connection settings</b> .
9	Select the <b>Advanced...</b> command button. <b>Response:</b> The <b>Advanced settingsCOMx</b> dialog is opened.
10	Tick the check box <b>Use FIFO buffer</b> . <b>Note:</b> Using the FIFO(First In First Out) buffer requires a serial port with 16550 compatible UART (Universal Asynchronous Receiver Transmitter).
11	Use the slide control to change the receive and send buffer which are both set to maximum size.
12	Close all dialogs with <b>OK</b> .

## Interface Settings in Windows NT

---

**Interface setting** Carry out the following steps to set the interface in Windows NT:

Step	Action
1	Double-click on the <b>My Computer</b> icon. <b>Response:</b> All available objects are displayed.
2	Double-click on the <b>Control Panel</b> icon. <b>Response:</b> All available objects are displayed.
3	Double-click on the <b>Connections</b> icon. <b>Response:</b> The <b>Connections</b> dialog box is opened.
4	Select the connection to be set in the list box and click on the command button <b>Settings...</b> <b>Response:</b> The <b>COMx Settings</b> dialog box is opened.
5	Click on the command button <b>Extended...</b> <b>Response:</b> The <b>Advanced Settings for COMx</b> dialog box is opened.
6	Activate the check box <b>FIFO activated</b> . <b>Note:</b> Using the FIFO(First In First Out) buffer requires a serial port with 16550 compatible UART (Universal Asynchronous Receiver Transmitter).
7	Close all dialogs with <b>OK</b> .

---

## Setting up the hardware connection

---

### Introduction

<b>Note:</b> Please refer to the "Modbus Protocol Reference Guide" for a detailed description of the hardware setup.
--

---

### Procedure

To establish the hardware connection, do the following:

Step	Action
1	Set a unique Modbus node address for the CPU using the rotary switch on the back of the module.
2	Note the Modbus node address set on the CPU's sliding cover.
3	Connect the Modbus interface CPU to the PC serial COM interface with a Modbus cable.

---

---

## Transfer problems

### Introduction

Communication errors can occur when loading the EXEC file. Communication, made via the COM interface with Windows, depends on several factors. These factors include the programming device clock speed, the communication software and the other programs (or applications) that are used in the system.

### Check list for transfer problems

Refer to the following check list if transfer problems occur:

Step	Action
1	Check that no other applications are running in the background. Another application running in the background can mean that the active communication application in the foreground cannot receive information fast enough.
2	Check that the programming device is running at the highest possible clock speed. Some programming devices can prolong the lifetime of the buffer battery with lower speeds. Look in the documentation for you computer.
3	Use a serial connector with a 16550A Universal Asynchronous Receiver Transmitter (UART). Windows uses the buffering capability of these connections so that Windows data transfer applications can reach higher speeds even on slower computers.

### RTU transfer problems


If sporadic errors occur during data transfer, transfer cannot be carried out successfully with RTU mode. If this is the case, select ASCII mode. (See Quantum/Compact/Momentum/Atrium first startup.)

---



---

## Startup when using Modbus with the EXECLoader



---

### Introduction

#### Overview

This chapter describes loading executive data (EXEC) onto the PLC with the EXECLoader program.

#### What's in this chapter?

This chapter contains the following topics:

Topic	Page
Quantum first startup with EXECLoader	880
Compact first startup with EXECLoader	884
Momentum first startup for IEC with EXECLoader	888
Momentum first startup for LL984 with EXECLoader	893

---

## Quantum first startup with EXECLoader

### Introduction

This section describes the first startup of Quantum when used with Modbus. The first startup is subdivided into 5 main sections:

- *Start EXECLoader, p. 880*
- *Define Modbus interface, p. 880*
- *Protocol settings, p. 881*
- *Select EXEC file, p. 882*
- *Load EXEC file, p. 882*

### Start EXECLoader

The procedure for launching EXECLoaders is as follows:

Step	Action
1	Open the Concept start menu. <b>Response:</b> All installed Concept programs are displayed as symbols.
2	Click on the symbol with the identifier <b>EXECLoader</b> . <b>Response:</b> The EXECLoader program is started.
3	Click on the command <b>Next</b> , as soon as you have read the information on the page. <b>Response:</b> The dialog <b>Communication Protocol</b> is opened.

### Define Modbus interface

Carry out the following steps to set the Modbus interface:

Step	Action
1	Select the Option button <b>Modbus RTU (RS232)</b> for the RTU transfer mode. Select the Option button <b>Modbus ASCII (RS232)</b> for the ASCII transfer mode. <b>Note:</b> Data transfer can only take place if you have configured the same transfer mode (RTU or ASCII) on the CPU (using a button on the front of the module).
2	Click on the command button <b>Next</b> . <b>Response:</b> The dialog <b>Modbus Target</b> → <b>RTU/ASCII mode</b> is opened.
3	Use the command button <b>COM Port Settings...</b> to open the dialog <b>COM Properties</b> .
4	Use the list field <b>Connect using:</b> to select the programming cable interface on the PC (default setting is <b>COM1</b> ).
5	Use the list field <b>Bits per second:</b> to select the Baudrate (default is <b>9600</b> ).
6	Use the list field <b>Parity:</b> to select the parity (default is <b>EVEN</b> ).
7	Use the list field <b>Stop Bits</b> to select the Stop bits (default is <b>1</b> ).
8	Click on the command button <b>OK</b> . <b>Response:</b> The dialog is closed and you return to the dialog <b>Modbus Target</b> → <b>RTU/ASCII Mode</b> .

**Protocol settings** Carry out the following steps to set the Modbus protocol:

Step	Action
1	Click on the command button <b>Scan</b> . <b>Response:</b> The nodes on the Modbus network are read and displayed graphically in the left window. A green point in the graphic indicates that the CPU is in RUN mode. To stop the CPU continue as described in step 3.
2	Double-click on the read network node in the graphical display. <b>Response:</b> The Modbus address of the node is automatically entered in the textfield <b>Modbus Address</b> .
3	Click the right mouse button in the left window. <b>Response:</b> A context menu with individual PLC commands is opened.
4	If the "Run" display is lit on the CPU, stop the program using the command <b>Stop PLC</b> . <b>Response:</b> A message window appears where you can click <b>OK</b> to confirm stopping the CPU.
5	Click the command button <b>OK</b> , to confirm stopping the CPU. <b>Response:</b> You return to the dialog <b>Modbus Target</b> → <b>RTU mode</b> , and the green point disappears from the graph.
6	Activate the check box <b>Bridge</b> , if the connection to the Modbus node should be made via a Modbus Plus network using a Modbus bridge.
7	Press the appropriate Option button for your system ( <b>PLC</b> , <b>Direct Device</b> , <b>Local Head</b> , <b>Remote I/O Drop</b> ).
8	Click on the command button <b>Next</b> . <b>Response:</b> The <b>Operation</b> dialog is opened.

**Select EXEC file** Carry out the following steps to select the EXEC file:

Step	Action
1	Press the Option button <b>Transfer EXEC to Device</b> .
2	Click on the command button <b>Browse...</b> <b>Response:</b> The Concept directory is opened in a standard window.
3	Double-click on the DAT directory. <b>Response:</b> All available*.BIN files are displayed.
4	Click on the *.BIN file that corresponds to your CPU and the desired programming language. See the table <i>Loading Firmware for Quantum PLC Types, p. 950</i> . <b>Response:</b> The selected *.BIN file is displayed in <b>File name:</b> text field.
5	Click on the command button <b>Open</b> . <b>Response:</b> You return to the dialog <b>Operation</b> , and the path to the selected *.BIN file is displayed in the <b>Filename</b> text field.
6	Click on the command button <b>Next</b> . <b>Response:</b> The dialog <b>File and Device Info</b> is opened. Information is provided here about the selected *.BIN file and also about the PLC.
7	Click on the command button <b>Next</b> . <b>Response:</b> The <b>Summary</b> dialog is opened. This gives you an overview of the settings made for you to check.

**Load EXEC file** Carry out the following steps to load the EXEC file in the CPU flash RAM:

Step	Action
1	Click on the command button <b>Transfer</b> . <b>Response:</b> A message box appears warning you that all data available on the PLC will be lost, and the configuration and program must be reloaded on the PLC.
2	Click on the command button <b>Yes</b> , to continue the transfer. <b>Response:</b> The <b>Progress</b> dialog is opened. This gives information about the progress of the transfer in a progress bar and text.
3	Click <b>Close</b> once the transfer is complete. <b>Response:</b> The dialog is closed, and you return to the dialog <b>Summary</b> .
4	Click on the command button <b>Close</b> , to close the EXECLoader.



**CPU display during transfer**

During transfer the CPU display is as follows:

LED	Response
Ready	lit
Run	slow flashing
Modbus	lit (with some interruptions)
Modbus +	3x flashes with interruptions

**CPU display after transfer**

After transfer the CPU display is as follows:

LED	Response
Ready	lit
Run	not lit
Modbus	not lit
Modbus +	3x flashes with interruptions

**Note:** The three flash sequence Modbus + display indicates that no communication is present on the bus. This is displayed on Modbus by a non-lit Modbus display. The Modbus display is lit again once connection is made with Concept.

**Creating the software connection**

Carry out the steps given in chapter *Creating a Project*, p. 43.

## Compact first startup with EXECLoader

### Introduction

This section describes the first startup of Compact when used with Modbus. The first startup is subdivided into 5 main sections:

- *Start EXECLoader, p. 884*
- *Define Modbus interface, p. 884*
- *Protocol settings, p. 885*
- *Select EXEC file, p. 886*
- *Load EXEC file, p. 886*

### Start EXECLoader

The procedure for launching EXECLoaders is as follows:

Step	Action
1	Open the Concept start menu. <b>Response:</b> All installed Concept programs are displayed as symbols.
2	Click on the symbol with the identifier <b>EXECLoader</b> . <b>Response:</b> The EXECLoader program is started.
3	Click on the command <b>Next</b> , as soon as you have read the information on the page. <b>Response:</b> The dialog <b>Communication Protocol</b> is opened.

### Define Modbus interface

Carry out the following steps to set the Modbus interface:

Step	Action
1	Select the Option button <b>Modbus RTU (RS232)</b> for the RTU transfer mode. Select the Option button <b>Modbus ASCII (RS232)</b> for the ASCII transfer mode. <b>Note:</b> Data transfer can only take place if you have configured the same transfer mode (RTU or ASCII) on the CPU (using a button on the front of the module).
2	Click on the command button <b>Next</b> . <b>Response:</b> The dialog <b>Modbus Target → RTU/ASCII mode</b> is opened.
3	Use the command button <b>COM Port Settings...</b> to open the dialog <b>COM Properties</b> .
4	Use the list field <b>Connect using:</b> to select the programming cable interface on the PC (default setting is <b>COM1</b> ).
5	Use the list field <b>Bits per second:</b> to select the Baudrate (default is <b>9600</b> ).
6	Use the list field <b>Parity:</b> to select the parity (default is <b>EVEN</b> ).
7	Use the list field <b>Stop Bits</b> to select the Stop bits (default is <b>1</b> ).
8	Click on the command button <b>OK</b> . <b>Response:</b> The dialog is closed and you return to the dialog <b>Modbus Target → RTU/ASCII Mode</b> .

**Protocol settings** Carry out the following steps to set the Modbus protocol:

Step	Action
1	Click on the command button <b>Scan</b> . <b>Response:</b> The nodes on the Modbus network are read and displayed graphically in the left window. A green point in the graphic indicates that the CPU is in RUN mode. To stop the CPU continue as described in step 3.
2	Double-click on the read network node in the graphical display. <b>Response:</b> The Modbus address of the node is automatically entered in the textfield <b>Modbus Address</b> .
3	Click the right mouse button in the left window. <b>Response:</b> A context menu with individual PLC commands is opened.
4	If the "Run" display is lit on the CPU, stop the program using the command <b>Stop PLC</b> . <b>Response:</b> A message window appears where you can click <b>OK</b> to confirm stopping the CPU.
5	Click the command button <b>OK</b> , to confirm stopping the CPU. <b>Response:</b> You return to the dialog <b>Modbus Target</b> → <b>RTU mode</b> , and the green point disappears from the graph.
6	Activate the check box <b>Bridge</b> , if the connection to the Modbus node should be made via a Modbus Plus network using a Modbus bridge.
7	Press the appropriate Option button for your system ( <b>PLC</b> , <b>Direct Device</b> , <b>Local Head</b> , <b>Remote I/O Drop</b> ).
8	Click on the command button <b>Next</b> . <b>Response:</b> The <b>Operation</b> dialog is opened.

**Select EXEC file** Carry out the following steps to select the EXEC file:

Step	Action
1	Press the Option button <b>Transfer EXEC to Device</b> .
2	Click on the command button <b>Browse...</b> <b>Response:</b> The Concept directory is opened in a standard window.
3	Double-click on the DAT directory. <b>Response:</b> All available*.BIN files are displayed.
4	Click on the *.BIN file CTSX201D. <b>Response:</b> The selected *.BIN file is displayed in <b>File name:</b> text field.
5	Click on the command button <b>Open</b> . <b>Response:</b> You return to the dialog <b>Operation</b> , and the path to the selected *.BIN file is displayed in the <b>Filename</b> text field.
6	Click on the command button <b>Next</b> . <b>Response:</b> The dialog <b>File and Device Info</b> is opened. Information is provided here about the selected *.BIN file and also about the PLC.
7	Click on the command button <b>Next</b> . <b>Response:</b> The <b>Summary</b> dialog is opened. This gives you an overview of the settings made for you to check.

---

**Load EXEC file** Carry out the following steps to load the EXEC file in the CPU flash RAM:

Step	Action
1	Click on the command button <b>Transfer</b> . <b>Response:</b> A message box appears warning you that all data available on the PLC will be lost, and the configuration and program must be reloaded on the PLC.
2	Click on the command button <b>Yes</b> , to continue the transfer. <b>Response:</b> The <b>Progress</b> dialog is opened. This gives information about the progress of the transfer in a progress bar and text.
3	Click <b>Close</b> once the transfer is complete. <b>Response:</b> The dialog is closed, and you return to the dialog <b>Summary</b> .
4	Click on the command button <b>Close</b> , to close the EXECLoader.

---

**CPU display during transfer**

During transfer the CPU display is as follows:

LED	Response
Ready	lit
Run	slow flashing
Modbus	lit (with some interruptions)
Modbus +	3x flashes with interruptions

**CPU display after transfer**

After transfer the CPU display is as follows:

LED	Response
Ready	lit
Run	not lit
Modbus	not lit
Modbus +	3x flashes with interruptions

**Note:** The three flash sequence Modbus + display indicates that no communication is present on the bus. This is displayed on Modbus by a non-lit Modbus display. The Modbus display is lit again once connection is made with Concept.

**Creating the software connection**

Carry out the steps given in chapter *Creating a Project*, p. 43.

## Momentum first startup for IEC with EXECLoader

---

### Introduction

This section describes the first startup of Momentum for IEC when used with Modbus.

The first startup is subdivided into 5 main sections:

- *Start EXECLoader, p. 888*
  - *Define Modbus interface, p. 889*
  - *Protocol settings, p. 890*
  - *Select EXEC file, p. 891*
  - *Load EXEC file, p. 891*
- 

### Start EXECLoader

The procedure for launching EXECLoaders is as follows:

Step	Action
1	Open the Concept start menu. <b>Response:</b> All installed Concept programs are displayed as symbols.
2	Click on the symbol with the identifier <b>EXECLoader</b> . <b>Response:</b> The EXECLoader program is started.
3	Click on the command <b>Next</b> , as soon as you have read the information on the page. <b>Response:</b> The dialog <b>Communication Protocol</b> is opened.

---

**Define Modbus interface**

Carry out the following steps to set the Modbus interface:

Step	Action
1	Select the Option button <b>Modbus RTU (RS232)</b> for the RTU transfer mode. Select the Option button <b>Modbus ASCII (RS232)</b> for the ASCII transfer mode. <b>Note:</b> Data transfer can only take place if you have configured the same transfer mode (RTU or ASCII) on the CPU (using a button on the front of the module).
2	Click on the command button <b>Next</b> . <b>Response:</b> The dialog <b>Modbus Target → RTU/ASCII mode</b> is opened.
3	Use the command button <b>COM Port Settings...</b> to open the dialog <b>COM Properties</b> .
4	Use the list field <b>Connect using:</b> to select the programming cable interface on the PC (default setting is <b>COM1</b> ).
5	Use the list field <b>Bits per second:</b> to select the Baudrate (default is <b>9600</b> ).
6	Use the list field <b>Parity:</b> to select the parity (default is <b>EVEN</b> ).
7	Use the list field <b>Stop Bits</b> to select the Stop bits (default is <b>1</b> ).
8	Click on the command button <b>OK</b> . <b>Response:</b> The dialog is closed and you return to the dialog <b>Modbus Target → RTU/ASCII Mode</b> .

**Protocol settings** Carry out the following steps to set the Modbus protocol:

Step	Action
1	Click on the command button <b>Scan</b> . <b>Response:</b> The nodes on the Modbus network are read and displayed graphically in the left window. A green point in the graphic indicates that the CPU is in RUN mode. To stop the CPU continue as described in step 3.
2	Double-click on the read network node in the graphical display. <b>Response:</b> The Modbus address of the node is automatically entered in the textfeld <b>Modbus Address</b> .
3	Click the right mouse button in the left window. <b>Response:</b> A context menu with individual PLC commands is opened.
4	If the "Run" display is lit on the CPU, stop the program using the command <b>Stop PLC</b> . <b>Response:</b> A message window appears where you can click <b>OK</b> to confirm stopping the CPU.
5	Click the command button <b>OK</b> , to confirm stopping the CPU. <b>Response:</b> You return to the dialog <b>Modbus Target</b> → <b>RTU mode</b> , and the green point disappears from the graph.
6	Activate the check box <b>Bridge</b> , if the connection to the Modbus node should be made via a Modbus Plus network using a Modbus bridge.
7	Press the appropriate Option button for your system ( <b>PLC, Direct Device, Local Head, Remote I/O Drop</b> ).
8	Click on the command button <b>Next</b> . <b>Response:</b> The <b>Operation</b> dialog is opened.

---



**Select EXEC file** Carry out the following steps to select the EXEC file:

Step	Action
1	Press the Option button <b>Transfer EXEC to Device</b> .
2	Click on the command button <b>Browse...</b> <b>Response:</b> The Concept directory is opened in a standard window.
3	Double-click on the DAT directory. <b>Response:</b> All available*.BIN files are displayed.
4	Click on the *.BIN file that corresponds to your CPU and the desired programming language. See the table <i>Loading Firmware for Momentum PLC Types, p. 951</i> . <b>Response:</b> The selected *.BIN file is displayed in <b>File name:</b> text field.
5	Click on the command button <b>Open</b> . <b>Response:</b> You return to the dialog <b>Operation</b> , and the path to the selected *.BIN file is displayed in the <b>Filename</b> text field.
6	Click on the command button <b>Next</b> . <b>Response:</b> The dialog <b>File and Device Info</b> is opened. Information is provided here about the selected *.BIN file and also about the PLC.
7	Click on the command button <b>Next</b> . <b>Response:</b> The <b>Summary</b> dialog is opened. This gives you an overview of the settings made for you to check.

**Load EXEC file** Carry out the following steps to load the EXEC file in the CPU flash RAM:

Step	Action
1	Click on the command button <b>Transfer</b> . <b>Response:</b> A message box appears warning you that all data available on the PLC will be lost, and the configuration and program must be reloaded on the PLC.
2	Click on the command button <b>Yes</b> , to continue the transfer. <b>Response:</b> The <b>Progress</b> dialog is opened. This gives information about the progress of the transfer in a progress bar and text.
3	Click <b>Close</b> once the transfer is complete. <b>Response:</b> The dialog is closed, and you return to the dialog <b>Summary</b> .
4	Click on the command button <b>Close</b> , to close the EXECLoader.

**CPU display during transfer**

During transfer the CPU display is as follows:

LED	Response
Run	slow flashing
COM ACT	lit (with some interruptions)
Modbus +	3x flashes with interruptions

**CPU display after transfer**

After transfer the CPU display is as follows:

LED	Response
Run	not lit
COM ACT	not lit
Modbus +	3x flashes with interruptions

**Note:** The three flash sequence Modbus + display indicates that no communication is present on the bus. This is displayed on Modbus by a non-lit COM ACT display. The COM ACT display is lit again once connection is made with Concept.

**Creating the software connection**

Carry out the steps given in chapter *Creating a Project*, p. 43.

---

## Momentum first startup for LL984 with EXECLoader

### Introduction

This section describes the first startup of Momentum for LL984 when used with Modbus.

**Note:** Loading the EXEC file for LL984 is not necessary with a new computer, since it is preloaded in the the CPUs Flash RAM. Loading the EXEC file for LL984 is only necessary if you have already loaded the EXEC file for IEC, and now wish to change.

You should always check to see if a new EXEC version has been released in the meantime. This information and the current EXEC file can be found on our website at [www.schneiderautomation.com](http://www.schneiderautomation.com). You can see the currently loaded version of the EXEC file in Concept using the **Online** → **Online controller...** menu command.

The first startup is subdivided into 5 main sections:

- *Start EXECLoader, p. 893*
- *Define Modbus interface, p. 894*
- *Protocol settings, p. 895*
- *Select EXEC file, p. 896*
- *Load EXEC file, p. 896*

### Start EXECLoader

The procedure for launching EXECLoaders is as follows:

Step	Action
1	Open the Concept start menu. <b>Response:</b> All installed Concept programs are displayed as symbols.
2	Click on the symbol with the identifier <b>EXECLoader</b> . <b>Response:</b> The EXECLoader program is started.
3	Click on the command <b>Next</b> , as soon as you have read the information on the page. <b>Response:</b> The dialog <b>Communication Protocol</b> is opened.

**Define Modbus interface**

Carry out the following steps to set the Modbus interface:

Step	Action
1	Select the Option button <b>Modbus RTU (RS232)</b> for the RTU transfer mode. Select the Option button <b>Modbus ASCII (RS232)</b> for the ASCII transfer mode. <b>Note:</b> Data transfer can only take place if you have configured the same transfer mode (RTU or ASCII) on the CPU (using a button on the front of the module).
2	Click on the command button <b>Next</b> . <b>Response:</b> The dialog <b>Modbus Target</b> → <b>RTU/ASCII mode</b> is opened.
3	Use the command button <b>COM Port Settings...</b> to open the dialog <b>COM Properties</b> .
4	Use the list field <b>Connect using:</b> to select the programming cable interface on the PC (default setting is <b>COM1</b> ).
5	Use the list field <b>Bits per second:</b> to select the Baudrate (default is <b>9600</b> ).
6	Use the list field <b>Parity:</b> to select the parity (default is <b>EVEN</b> ).
7	Use the list field <b>Stop Bits</b> to select the Stop bits (default is <b>1</b> ).
8	Click on the command button <b>OK</b> . <b>Response:</b> The dialog is closed and you return to the dialog <b>Modbus Target</b> → <b>RTU/ASCII Mode</b> .

---

**Protocol settings** Carry out the following steps to set the Modbus protocol:

Step	Action
1	Click on the command button <b>Scan</b> . <b>Response:</b> The nodes on the Modbus network are read and displayed graphically in the left window. A green point in the graphic indicates that the CPU is in RUN mode. To stop the CPU continue as described in step 3.
2	Double-click on the read network node in the graphical display. <b>Response:</b> The Modbus address of the node is automatically entered in the textfield <b>Modbus Address</b> .
3	Click the right mouse button in the left window. <b>Response:</b> A context menu with individual PLC commands is opened.
4	If the "Run" display is lit on the CPU, stop the program using the command <b>Stop PLC</b> . <b>Response:</b> A message window appears where you can click <b>OK</b> to confirm stopping the CPU.
5	Click the command button <b>OK</b> , to confirm stopping the CPU. <b>Response:</b> You return to the dialog <b>Modbus Target</b> → <b>RTU mode</b> , and the green point disappears from the graph.
6	Activate the check box <b>Bridge</b> , if the connection to the Modbus node should be made via a Modbus Plus network using a Modbus bridge.
7	Press the appropriate Option button for your system ( <b>PLC</b> , <b>Direct Device</b> , <b>Local Head</b> , <b>Remote I/O Drop</b> ).
8	Click on the command button <b>Next</b> . <b>Response:</b> The <b>Operation</b> dialog is opened.

**Select EXEC file** Carry out the following steps to select the EXEC file:

Step	Action
1	Press the Option button <b>Transfer EXEC to Device</b> .
2	Click on the command button <b>Browse...</b> <b>Response:</b> The Concept directory is opened in a standard window.
3	Double-click on the DAT directory. <b>Response:</b> All available*.BIN files are displayed.
4	Click on the *.BIN file that corresponds to your CPU and the desired programming language. See the table <i>Loading Firmware for Momentum PLC Types, p. 951</i> . <b>Response:</b> The selected *.BIN file is displayed in <b>File name:</b> text field.
5	Click on the command button <b>Open</b> . <b>Response:</b> You return to the dialog <b>Operation</b> , and the path to the selected *.BIN file is displayed in the <b>Filename</b> text field.
6	Click on the command button <b>Next</b> . <b>Response:</b> The dialog <b>File and Device Info</b> is opened. Information is provided here about the selected *.BIN file and also about the PLC.
7	Click on the command button <b>Next</b> . <b>Response:</b> The <b>Summary</b> dialog is opened. This gives you an overview of the settings made for you to check.

**Load EXEC file** Carry out the following steps to load the EXEC file in the CPU flash RAM:

Step	Action
1	Click on the command button <b>Transfer</b> . <b>Response:</b> A message box appears warning you that all data available on the PLC will be lost, and the configuration and program must be reloaded on the PLC.
2	Click on the command button <b>Yes</b> , to continue the transfer. <b>Response:</b> The <b>Progress</b> dialog is opened. This gives information about the progress of the transfer in a progress bar and text.
3	Click <b>Close</b> once the transfer is complete. <b>Response:</b> The dialog is closed, and you return to the dialog <b>Summary</b> .
4	Click on the command button <b>Close</b> , to close the EXECLoader.

**CPU display during transfer**

During transfer the CPU display is as follows:

LED	Response
Run	slow flashing
COM ACT	lit (with some interruptions)
Modbus +	3x flashes with interruptions

**CPU display after transfer**

After transfer the CPU display is as follows:

LED	Response
Run	not lit
COM ACT	not lit
Modbus +	3x flashes with interruptions

**Note:** The three flash sequence Modbus + display indicates that no communication is present on the bus. This is displayed on Modbus by a non-lit COM ACT display. The COM ACT display is lit again once connection is made with Concept.

**Creating the software connection**

Carry out the steps given in chapter *Creating a Project*, p. 43.





---

## Startup when using Modbus with DOS Loader



---

### Introduction

#### Overview

This chapter describes loading executive data (EXEC) onto the PLC with the DOS Loader program.

#### What's in this chapter?

This chapter contains the following topics:

Topic	Page
Quantum first startup with DOS Loader	900
Compact first startup with DOS Loader	903
Momentum first startup for IEC with DOS Loader	906
Momentum first startup for LL984 with DOS Loader	909

## Quantum first startup with DOS Loader

---

### Introduction

This section describes the first startup of Quantum when used with Modbus.

The first startup is subdivided into 5 main sections:

- *Start DOS Loader, p. 900*
  - *Define Modbus interface, p. 900*
  - *Protocol settings, p. 901*
  - *Select EXEC file, p. 901*
  - *Load EXEC file, p. 901*
- 

### Start DOS Loader

The procedure for launching DOS Loaders is as follows:

Step	Action
1	If the CPU display "Run" is lit, stop the program with Concept (in main menu <b>Online</b> ). <b>Response:</b> The "Run" display is no longer lit; the "Ready" is now lit.
2	Open the directory DAT (CONCEPTDAT).
3	Double-click on the file LOADER.EXE. <b>Response:</b> The installation program for the Executive file (EXEC) is started.
4	Select the option <b>Communication Parameters</b> . <b>Response:</b> The dialog box <b>Communication setup</b> is opened.
5	Select the <b>Modbus</b> option. <b>Response:</b> The <b>Modbus communication setup</b> window is opened.

---

### Define Modbus interface

Carry out the following steps to set the Modbus interface:

Step	Action
1	Select the programming cable interface on the PC (default setting is <b>COM1</b> ).
2	Select the Baudrate (default is <b>9600</b> ).
3	Select the parity (default is <b>EVEN</b> ).
4	Select the Option button <b>RTU - 8 Bits</b> for the RTU transfer mode. Select the option <b>ASCII - 7 Bits</b> for the ASCII transfer mode.
5	Select the Stop bits (default is <b>1</b> ). <b>Note:</b> Data transfer can only take place if you have configured the same transfer mode (ASCII or RTU) on the CPU (using a button on the front of the module).

---

**Protocol settings** Carry out the following steps to set the Modbus protocol:

Step	Action
1	Enter in <b>Enter PLC Address</b> : the node address set on the CPU (using a rotary switch on the back of the module).
2	Select the <b>TARGET PATH 0</b> option.
3	Select the <b>ACCEPT CHANGES</b> option. <b>Response:</b> You return to the main menu.

**Select EXEC file** Carry out the following steps to select the EXEC file:

Step	Action
1	Select the option <b>File Selection</b> . <b>Response:</b> The <b>File Selection</b> window is opened.
2	Click on the *.BIN file that corresponds to your CPU and the desired programming language. See the table <i>Loading Firmware for Quantum PLC Types</i> , p. 950.
3	Confirm your selection with RETURN. <b>Response:</b> You return to the main menu.

**Load EXEC file** Carry out the following steps to load the EXEC file in the CPU flash RAM:

Step	Action
1	Select the option <b>Load File To PLC</b> . <b>Response:</b> The <b>Loading Process</b> window is opened, and the warning "The PROGRAM contents of the device being loaded could be lost after loading a new Executive. The CONTENTS stored in the Micro H H P will always be lost after loading a new Executive. Would you like to continue (Y/N) ? N" is displayed.
2	Acknowledge the warning with Y. <b>Response:</b> The message "Node failed to enter normal mode" appears.
3	The DOWNLOAD PROGRESS window appears which shows the transfer rate. <b>Response:</b> After the transfer is complete, the message "Download Operation Successful" appears.
4	Confirm the message with RETURN. <b>Response:</b> You return to the main menu.
5	Select the <b>Exit Program</b> option. <b>Response:</b> The DOS Loader is exited.

**CPU display during transfer**

During transfer the CPU display is as follows:

LED	Response
Ready	lit
Run	slow flashing
Modbus	lit (with some interruptions)
Modbus +	3x flashes with interruptions

**CPU display after transfer**

After transfer the CPU display is as follows:

LED	Response
Ready	lit
Run	not lit
Modbus	not lit
Modbus +	3x flashes with interruptions

**Note:** The three flash sequence Modbus + display indicates that no communication is present on the bus. This is displayed on Modbus by a non-lit Modbus display. The Modbus display is lit again once connection is made with Concept.

**Creating the software connection**

Carry out the steps given in chapter *Creating a Project*, p. 43.

---

---

## Compact first startup with DOS Loader

---

### Introduction

This section describes the first startup of Compact when used with Modbus. The first startup is subdivided into 5 main sections:

- *Start DOS Loader, p. 903*
  - *Define Modbus interface, p. 903*
  - *Protocol settings, p. 904*
  - *Select EXEC file, p. 904*
  - *Load EXEC file, p. 904*
- 

### Start DOS Loader

The procedure for launching DOS Loaders is as follows:

Step	Action
1	If the CPU display "Run" is lit, stop the program with Concept (in main menu <b>Online</b> ). <b>Response:</b> The "Run" display is no longer lit; the "Ready" is now lit.
2	Open the directory DAT (CONCEPT\DAT).
3	Double-click on the file LOADER.EXE. <b>Response:</b> The installation program for the Executive file (EXEC) is started.
4	Select the option <b>Communication Parameters</b> . <b>Response:</b> The dialog box <b>Communication setup</b> is opened.
5	Select the <b>Modbus</b> option. <b>Response:</b> The <b>Modbus communication setup</b> window is opened.

---

### Define Modbus interface

Carry out the following steps to set the Modbus interface:

Step	Action
1	Select the programming cable interface on the PC (default setting is <b>COM1</b> ).
2	Select the Baudrate (default is <b>9600</b> ).
3	Select the parity (default is <b>EVEN</b> ).
4	Select the Option button <b>RTU - 8 Bits</b> for the RTU transfer mode. Select the option <b>ASCII -7 Bits</b> for the ASCII transfer mode.
5	Select the Stop bits (default is <b>1</b> ). <b>Note:</b> Data transfer can only take place if you have configured the same transfer mode (ASCII or RTU) on the CPU (using a button on the front of the module).

---

**Protocol settings** Carry out the following steps to set the Modbus protocol:

Step	Action
1	Enter in <b>Enter PLC Address:</b> the node address set on the CPU (using a rotary switch on the back of the module).
2	Select the <b>TARGET PATH 0</b> option.
3	Select the <b>ACCEPT CHANGES</b> option. <b>Response:</b> You return to the main menu.

---

**Select EXEC file** Carry out the following steps to select the EXEC file:

Step	Action
1	Select the option <b>File Selection</b> . <b>Response:</b> The <b>File Selection</b> window is opened.
2	Select the *.BIN file CTSX201D.
3	Confirm your selection with RETURN. <b>Response:</b> You return to the main menu.

---

**Load EXEC file** Carry out the following steps to load the EXEC file in the CPU flash RAM:

Step	Action
1	Select the option <b>Load File To PLC</b> . <b>Response:</b> The <b>Loading Process</b> window is opened, and the warning "The PROGRAM contents of the device being loaded could be lost after loading a new Executive. The CONTENTS stored in the Micro H H P will always be lost after loading a new Executive. Would you like to continue (Y/N) ? N" is displayed.
2	Acknowledge the warning with Y. <b>Response:</b> The message "Node failed to enter normal mode" appears.
3	The DOWNLOAD PROGRESS window appears which shows the transfer rate. <b>Response:</b> After the transfer is complete, the message "Download Operation Successful" appears.
4	Confirm the message with RETURN. <b>Response:</b> You return to the main menu.
5	Select the <b>Exit Program</b> option. <b>Response:</b> The DOS Loader is exited.

---

**CPU display during transfer**

During transfer the CPU display is as follows:

LED	Response
Ready	lit
Run	slow flashing
Modbus	not lit
Modbus +	fast flashing

**CPU display after transfer**

After transfer the CPU display is as follows:

LED	Response
Ready	lit
Run	not lit
Modbus	not lit
Modbus +	fast flashing

**Note:** The three flash sequence Modbus + display indicates that no communication is present on the bus. This is displayed on Modbus by a non-lit Modbus display. The Modbus display is lit again once connection is made with Concept.

**Creating the software connection**

Carry out the steps given in chapter *Creating a Project*, p. 43.

## Momentum first startup for IEC with DOS Loader

---

### Introduction

This section describes the first startup of Momentum for IEC when used with Modbus.

The first startup is subdivided into 5 main sections:

- *Start DOS Loader, p. 906*
  - *Define Modbus interface, p. 906*
  - *Protocol settings, p. 907*
  - *Select EXEC file, p. 907*
  - *Load EXEC file, p. 907*
- 

### Start DOS Loader

The procedure for launching DOS Loaders is as follows:

Step	Action
1	If the CPU display "Run" is lit, stop the program with Concept (in main menu <b>Online</b> ). <b>Response:</b> The "Run" display is no longer lit; the "Ready" is now lit.
2	Open the directory DAT (CONCEPTDAT).
3	Double-click on the file LOADER.EXE. <b>Response:</b> The installation program for the Executive file (EXEC) is started.
4	Select the option <b>Communication Parameters</b> . <b>Response:</b> The dialog box <b>Communication setup</b> is opened.
5	Select the <b>Modbus</b> option. <b>Response:</b> The <b>Modbus communication setup</b> window is opened.

---

### Define Modbus interface

Carry out the following steps to set the Modbus interface:

Step	Action
1	Select the programming cable interface on the PC (default setting is <b>COM1</b> ).
2	Select the Baudrate (default is <b>9600</b> ).
3	Select the parity (default is <b>EVEN</b> ).
4	Select the Option button <b>RTU - 8 Bits</b> for the RTU transfer mode. Select the option <b>ASCII -7 Bits</b> for the ASCII transfer mode.
5	Select the Stop bits (default is <b>1</b> ). <b>Note:</b> Data transfer can only take place if you have configured the same transfer mode (ASCII or RTU) on the CPU (using a button on the front of the module).

---



**Protocol settings** Carry out the following steps to set the Modbus protocol:

Step	Action
1	Enter in <b>Enter PLC Address</b> : the node address set on the CPU (using a rotary switch on the back of the module).
2	Select the <b>TARGET PATH 0</b> option.
3	Select the <b>ACCEPT CHANGES</b> option. <b>Response:</b> You return to the main menu.

**Select EXEC file** Carry out the following steps to select the EXEC file:

Step	Action
1	Select the option <b>File Selection</b> . <b>Response:</b> The <b>File Selection</b> window is opened.
2	Click on the *.BIN file that corresponds to your CPU and the desired programming language. See the table <i>Loading Firmware for Momentum PLC Types, p. 951</i> .
3	Confirm your selection with RETURN. <b>Response:</b> You return to the main menu.

**Load EXEC file** Carry out the following steps to load the EXEC file in the CPU flash RAM:

Step	Action
1	Select the option <b>Load File To PLC</b> . <b>Response:</b> The <b>Loading Process</b> window is opened, and the warning "The PROGRAM contents of the device being loaded could be lost after loading a new Executive. The CONTENTS stored in the Micro H H P will always be lost after loading a new Executive. Would you like to continue (Y/N) ? N" is displayed.
2	Acknowledge the warning with Y. <b>Response:</b> The message "Node failed to enter normal mode" appears.
3	The DOWNLOAD PROGRESS window appears which shows the transfer rate. <b>Response:</b> After the transfer is complete, the message "Download Operation Successful" appears.
4	Confirm the message with RETURN. <b>Response:</b> You return to the main menu.
5	Select the <b>Exit Program</b> option. <b>Response:</b> The DOS Loader is exited.

**CPU display during transfer**

During transfer the CPU display is as follows:

LED	Response
Run	slow flashing
COM ACT	lit (with some interruptions)
Modbus +	3x flashes with interruptions

---

**CPU display after transfer**

After transfer the CPU display is as follows:

LED	Response
Run	not lit
COM ACT	not lit
Modbus +	3x flashes with interruptions

**Note:** The three flash sequence Modbus + display indicates that no communication is present on the bus. This is displayed on Modbus by a non-lit COM ACT display. The COM ACT display is lit again once connection is made with Concept.

---

**Creating the software connection**

Carry out the steps given in chapter *Creating a Project*, p. 43.

---

## Momentum first startup for LL984 with DOS Loader

### Introduction

This section describes the first startup of Momentum for LL984 when used with Modbus.

**Note:** Loading the EXEC file for LL984 is not necessary with a new computer, since it is preloaded in the CPU's Flash RAM. Loading the EXEC file for LL984 is only necessary if you have already loaded the EXEC file for IEC, and now wish to change.

You should always check to see if a new EXEC version has been released in the meantime. This information and the current EXEC file can be found on our website at [www.schneiderautomation.com](http://www.schneiderautomation.com). You can see the currently loaded version of the EXEC file in Concept using the **Online** → **Online controller...** menu command.

The first startup is subdivided into 5 main sections:

- *Start DOS Loader, p. 909*
- *Define Modbus interface, p. 910*
- *Protocol settings, p. 910*
- *Select EXEC file, p. 910*
- *Load EXEC file, p. 911*

### Start DOS Loader

The procedure for launching DOS Loaders is as follows:

Step	Action
1	If the CPU display "Run" is lit, stop the program with Concept (in main menu <b>Online</b> ). <b>Response:</b> The "Run" display is no longer lit; the "Ready" is now lit.
2	Open the directory DAT (CONCEPT\DAT).
3	Double-click on the file LOADER.EXE. <b>Response:</b> The installation program for the Executive file (EXEC) is started.
4	Select the option <b>Communication Parameters</b> . <b>Response:</b> The dialog box <b>Communication setup</b> is opened.
5	Select the <b>Modbus</b> option. <b>Response:</b> The <b>Modbus communication setup</b> window is opened.

**Define Modbus interface**

Carry out the following steps to set the Modbus interface:

Step	Action
1	Select the programming cable interface on the PC (default setting is <b>COM1</b> ).
2	Select the Baudrate (default is <b>9600</b> ).
3	Select the parity (default is <b>EVEN</b> ).
4	Select the Option button <b>RTU - 8 Bits</b> for the RTU transfer mode. Select the option <b>ASCII -7 Bits</b> for the ASCII transfer mode.
5	Select the Stop bits (default is <b>1</b> ). <b>Note:</b> Data transfer can only take place if you have configured the same transfer mode (ASCII or RTU) on the CPU (using a button on the front of the module).

---

**Protocol settings**

Carry out the following steps to set the Modbus protocol:

Step	Action
1	Enter in <b>Enter PLC Address:</b> the node address set on the CPU (using a rotary switch on the back of the module).
2	Select the <b>TARGET PATH 0</b> option.
3	Select the <b>ACCEPT CHANGES</b> option. <b>Response:</b> You return to the main menu.

---

**Select EXEC file**

Carry out the following steps to select the EXEC file:

Step	Action
1	Select the option <b>File Selection</b> . <b>Response:</b> The <b>File Selection</b> window is opened.
2	Click on the *.BIN file that corresponds to your CPU and the desired programming language. See the table <i>Loading Firmware for Momentum PLC Types, p. 951</i> .
3	Confirm your selection with RETURN. <b>Response:</b> You return to the main menu.

---

**Load EXEC file**

Carry out the following steps to load the EXEC file in the CPU flash RAM:

Step	Action
1	Select the option <b>Load File To PLC</b> . <b>Response:</b> The <b>Loading Process</b> window is opened, and the warning "The PROGRAM contents of the device being loaded could be lost after loading a new Executive. The CONTENTS stored in the Micro H H P will always be lost after loading a new Executive. Would you like to continue (Y/N) ? N" is displayed.
2	Acknowledge the warning with <b>Y</b> . <b>Response:</b> The message "Node failed to enter normal mode" appears.
3	The <b>DOWNLOAD PROGRESS</b> window appears which shows the transfer rate. <b>Response:</b> After the transfer is complete, the message "Download Operation Successful" appears.
4	Confirm the message with <b>RETURN</b> . <b>Response:</b> You return to the main menu.
5	Select the <b>Exit Program</b> option. <b>Response:</b> The DOS Loader is exited.

**CPU display during transfer**

During transfer the CPU display is as follows:

LED	Response
Run	slow flashing
COM ACT	lit (with some interruptions)
Modbus +	3x flashes with interruptions

**CPU display after transfer**

After transfer the CPU display is as follows:

LED	Response
Run	not lit
COM ACT	not lit
Modbus +	3x flashes with interruptions

**Note:** The three flash sequence Modbus + display indicates that no communication is present on the bus. This is displayed on Modbus by a non-lit COM ACT display. The COM ACT display is lit again once connection is made with Concept.

**Creating the  
software  
connection**

Carry out the steps given in chapter *Creating a Project*, p. 43.

---

---

## Startup when using Modbus Plus with the EXECLoader



N

---

### Introduction

#### Overview

This chapter describes loading executive data (EXEC) onto the PLC with the EXECLoader.

#### What's in this chapter?

This chapter contains the following topics:

Topic	Page
Quantum first startup with EXECLoader	914
Compact first startup with EXECLoader	918
Atrium first startup with EXECLoader	922
Momentum first startup for IEC with EXECLoader	925
Momentum first startup for LL984 with EXECLoader	929

---

## Quantum first startup with EXECLoader

---

### Introduction

This section describes the first startup of Quantum when used with Modbus Plus.

The first startup is subdivided into 5 main sections:

- *Start EXECLoader, p. 914*
  - *Define SA85 adapter, p. 914*
  - *Protocol settings, p. 915*
  - *Select EXEC file, p. 916*
  - *Load EXEC file, p. 916*
- 

### Start EXECLoader

The procedure for launching EXECLoaders is as follows:

Step	Action
1	Open the Concept start menu. <b>Response:</b> All installed Concept programs are displayed as symbols.
2	Click on the symbol with the identifier <b>EXECLoader</b> . <b>Response:</b> The EXECLoader program is started.
3	Click on the command <b>Next</b> , as soon as you have read the information on the page. <b>Response:</b> The dialog <b>Communication Protocol</b> is opened.

---

### Define SA85 adapter

Carry out the following steps to define the LAN address set in the CONFIG.SYS file:

Step	Action
1	Select the option button <b>Modbus Plus</b> .
2	Click on the command button <b>Next</b> . <b>Response:</b> The <b>Modbus Plus Target</b> dialog is opened.
3	Select from the list <b>Devices Online</b> : the adapter address you set when installing the SA85 in the CONFIG.SYS file (Parameter /n).

---



**Protocol settings** Carry out the following steps to set the Modbus Plus protocol settings:

Step	Action
1	Click on the command button <b>Scan</b> . <b>Response:</b> The nodes on the Modbus Plus network are read and displayed graphically in the left window. A green point in the graphic indicates that the CPU is in RUN mode. To stop the CPU continue as described in step 3.
2	Double-click on the read network node in the graphical display. <b>Response:</b> The Modbus address of the node is automatically entered in the textfield In the text field <b>Modbus Plus Address</b> .
3	Click the right mouse button in the left window. <b>Response:</b> A context menu with individual PLC commands is opened.
4	If the "Run" display is lit on the CPU, stop the program using the command <b>Stop PLC</b> . <b>Response:</b> A message window appears where you can click <b>OK</b> to confirm stopping the CPU.
5	Click the command button <b>OK</b> , to confirm stopping the CPU. <b>Response:</b> You return to the <b>Modbus Plus Target</b> dialog, and the green point disappears from the graph.
6	Activate the check box <b>Bridge</b> , if the connection to the Modbus network node should be made via a Modbus network using a Modbus bridge.
7	Press the appropriate Option button for your system ( <b>PLC, Local Head, Remote I/O Drop</b> ).
8	Click on the command button <b>Next</b> . <b>Response:</b> The <b>Operation</b> dialog is opened.

**Select EXEC file** Carry out the following steps to select the EXEC file:

Step	Action
1	Press the Option button <b>Transfer EXEC to Device</b> .
2	Click on the command button <b>Browse...</b> <b>Response:</b> The Concept directory is opened in a standard window.
3	Double-click on the DAT directory. <b>Response:</b> All available*.BIN files are displayed.
4	Click on the *.BIN file that corresponds to your CPU and the desired programming language. See the table <i>Loading Firmware for Quantum PLC Types, p. 950</i> . <b>Response:</b> The selected *.BIN file is displayed in <b>File name:</b> text field.
5	Click on the command button <b>Open</b> . <b>Response:</b> You return to the dialog <b>Operation</b> , and the path to the selected *.BIN file is displayed in the <b>Filename</b> text field.
6	Click on the command button <b>Next</b> . <b>Response:</b> The dialog <b>File and Device Info</b> is opened. Information is provided here about the selected *.BIN file and also about the PLC.
7	Click on the command button <b>Next</b> . <b>Response:</b> The <b>Summary</b> dialog is opened. This gives you an overview of the settings made for you to check.

---

**Load EXEC file** Carry out the following steps to load the EXEC file in the CPU flash RAM:

Step	Action
1	Click on the command button <b>Transfer</b> . <b>Response:</b> A message box appears warning you that all data available on the PLC will be lost, and the configuration and program must be reloaded on the PLC.
2	Click on the command button <b>Yes</b> , to continue the transfer. <b>Response:</b> The <b>Progress</b> dialog is opened. This gives information about the progress of the transfer in a progress bar and text.
3	Click <b>Close</b> once the transfer is complete. <b>Response:</b> The dialog is closed, and you return to the dialog <b>Summary</b> .
4	Click on the command button <b>Close</b> , to close the EXECLoader.

---

**CPU display during transfer**

During transfer the CPU display is as follows:

LED	Response
Ready	lit
Run	slow flashing
Modbus	not lit
Modbus +	fast flashing

**CPU display after transfer**

After transfer the CPU display is as follows:

LED	Response
Ready	lit
Run	not lit
Modbus	not lit
Modbus +	fast flashing

**Creating the software connection**

Carry out the steps given in chapter *Creating a Project*, p. 43.

**Note:** If you receive an error message, close Concept and start the BDRESET.EXE file (in the \Concept directory) to reset the SA85. Then start again from the first step.

## Compact first startup with EXECLoader

---

### Introduction

This section describes the first startup of Compact when used with Modbus Plus. The first startup is subdivided into 5 main sections:

- *Start EXECLoader, p. 918*
  - *Define SA85 adapter, p. 918*
  - *Protocol settings, p. 919*
  - *Select EXEC file, p. 920*
  - *Load EXEC file, p. 920*
- 

### Start EXECLoader

The procedure for launching EXECLoaders is as follows:

Step	Action
1	Open the Concept start menu. <b>Response:</b> All installed Concept programs are displayed as symbols.
2	Click on the symbol with the identifier <b>EXECLoader</b> . <b>Response:</b> The EXECLoader program is started.
3	Click on the command <b>Next</b> , as soon as you have read the information on the page. <b>Response:</b> The dialog <b>Communication Protocol</b> is opened.

---

### Define SA85 adapter

Carry out the following steps to define the LAN address set in the CONFIG.SYS file:

Step	Action
1	Select the option button <b>Modbus Plus</b> .
2	Click on the command button <b>Next</b> . <b>Response:</b> The <b>Modbus Plus Target</b> dialog is opened.
3	Select from the list <b>Devices Online</b> : the adapter address you set when installing the SA85 in the CONFIG.SYS file (Parameter /n).

---

**Protocol settings** Carry out the following steps to set the Modbus Plus protocol settings:

Step	Action
1	Click on the command button <b>Scan</b> . <b>Response:</b> The nodes on the Modbus Plus network are read and displayed graphically in the left window. A green point in the graphic indicates that the CPU is in RUN mode. To stop the CPU continue as described in step 3.
2	Double-click on the read network node in the graphical display. <b>Response:</b> The Modbus address of the node is automatically entered in the textfield In the text field <b>Modbus Plus Address</b> .
3	Click the right mouse button in the left window. <b>Response:</b> A context menu with individual PLC commands is opened.
4	If the "Run" display is lit on the CPU, stop the program using the command <b>Stop PLC</b> . <b>Response:</b> A message window appears where you can click <b>OK</b> to confirm stopping the CPU.
5	Click the command button <b>OK</b> , to confirm stopping the CPU. <b>Response:</b> You return to the <b>Modbus Plus Target</b> dialog, and the green point disappears from the graph.
6	Activate the check box <b>Bridge</b> , if the connection to the Modbus network node should be made via a Modbus network using a Modbus bridge.
7	Press the appropriate Option button for your system ( <b>PLC, Local Head, Remote I/O Drop</b> ).
8	Click on the command button <b>Next</b> . <b>Response:</b> The <b>Operation</b> dialog is opened.

**Select EXEC file** Carry out the following steps to select the EXEC file:

Step	Action
1	Press the Option button <b>Transfer EXEC to Device</b> .
2	Click on the command button <b>Browse...</b> <b>Response:</b> The Concept directory is opened in a standard window.
3	Double-click on the DAT directory. <b>Response:</b> All available*.BIN files are displayed.
4	Click on the *.BIN file CTSX201D. <b>Response:</b> The selected *.BIN file is displayed in <b>File name:</b> text field.
5	Click on the command button <b>Open</b> . <b>Response:</b> You return to the dialog <b>Operation</b> , and the path to the selected *.BIN file is displayed in the <b>Filename</b> text field.
6	Click on the command button <b>Next</b> . <b>Response:</b> The dialog <b>File and Device Info</b> is opened. Information is provided here about the selected *.BIN file and also about the PLC.
7	Click on the command button <b>Next</b> . <b>Response:</b> The <b>Summary</b> dialog is opened. This gives you an overview of the settings made for you to check.

---

**Load EXEC file** Carry out the following steps to load the EXEC file in the CPU flash RAM:

Step	Action
1	Click on the command button <b>Transfer</b> . <b>Response:</b> A message box appears warning you that all data available on the PLC will be lost, and the configuration and program must be reloaded on the PLC.
2	Click on the command button <b>Yes</b> , to continue the transfer. <b>Response:</b> The <b>Progress</b> dialog is opened. This gives information about the progress of the transfer in a progress bar and text.
3	Click <b>Close</b> once the transfer is complete. <b>Response:</b> The dialog is closed, and you return to the dialog <b>Summary</b> .
4	Click on the command button <b>Close</b> , to close the EXECLoader.

---

**CPU display during transfer**

During transfer the CPU display is as follows:

LED	Response
Ready	lit
Run	slow flashing
Modbus	not lit
Modbus +	fast flashing

**CPU display after transfer**

After transfer the CPU display is as follows:

LED	Response
Ready	lit
Run	not lit
Modbus	not lit
Modbus +	fast flashing

**Creating the software connection**

Carry out the steps given in chapter *Creating a Project*, p. 43.

**Note:** If you receive an error message, close Concept and start the BDRESET.EXE file (in the \Concept directory) to reset the SA85. Then start again from the first step.

## Atrium first startup with EXECLoader

---

### Introduction

This section describes the first startup of Atrium when used with Modbus Plus. The hardware requirements for loading EXEC files can be seen in the "Modicon TSX Atrium" manual.

The first startup is subdivided into 5 main sections:

- *Start EXECLoader, p. 922*
  - *Define SA85 adapter, p. 922*
  - *Protocol settings, p. 923*
  - *Select EXEC file, p. 924*
  - *Load EXEC file, p. 924*
- 

### Start EXECLoader

The procedure for launching EXECLoaders is as follows:

Step	Action
1	Open the Concept start menu. <b>Response:</b> All installed Concept programs are displayed as symbols.
2	Click on the symbol with the identifier <b>EXECLoader</b> . <b>Response:</b> The EXECLoader program is started.
3	Click on the command <b>Next</b> , as soon as you have read the information on the page. <b>Response:</b> The dialog <b>Communication Protocol</b> is opened.

---

### Define SA85 adapter

Carry out the following steps to define the LAN address set in the CONFIG.SYS file:

Step	Action
1	Select the option button <b>Modbus Plus</b> .
2	Click on the command button <b>Next</b> . <b>Response:</b> The <b>Modbus Plus Target</b> dialog is opened.
3	Select from the list <b>Devices Online</b> : the adapter address you set when installing the SA85 in the CONFIG.SYS file (Parameter /n).

---



**Protocol settings** Carry out the following steps to set the Modbus Plus protocol settings:

Step	Action
1	Click on the command button <b>Scan</b> . <b>Response:</b> The nodes on the Modbus Plus network are read and displayed graphically in the left window. A green point in the graphic indicates that the CPU is in RUN mode. To stop the CPU continue as described in step 3.
2	Double-click on the read network node in the graphical display. <b>Response:</b> The Modbus address of the node is automatically entered in the textfield In the text field <b>Modbus Plus Address</b> .
3	Click the right mouse button in the left window. <b>Response:</b> A context menu with individual PLC commands is opened.
4	If the "Run" display is lit on the CPU, stop the program using the command <b>Stop PLC</b> . <b>Response:</b> A message window appears where you can click <b>OK</b> to confirm stopping the CPU.
5	Click the command button <b>OK</b> , to confirm stopping the CPU. <b>Response:</b> You return to the <b>Modbus Plus Target</b> dialog, and the green point disappears from the graph.
6	Activate the check box <b>Bridge</b> , if the connection to the Modbus network node should be made via a Modbus network using a Modbus bridge.
7	Press the appropriate Option button for your system ( <b>PLC, Local Head, Remote I/O Drop</b> ).
8	Click on the command button <b>Next</b> . <b>Response:</b> The <b>Operation</b> dialog is opened.

**Select EXEC file** Carry out the following steps to select the EXEC file:

Step	Action
1	Press the Option button <b>Transfer EXEC to Device</b> .
2	Click on the command button <b>Browse...</b> <b>Response:</b> The Concept directory is opened in a standard window.
3	Double-click on the DAT directory. <b>Response:</b> All available*.BIN files are displayed.
4	Click on the *.BIN file that corresponds to your CPU and the desired programming language. See the table <i>Loading Firmware for Atrium PLC Types, p. 952</i> . <b>Response:</b> The selected *.BIN file is displayed in <b>File name:</b> text field.
5	Click on the command button <b>Open</b> . <b>Response:</b> You return to the dialog <b>Operation</b> , and the path to the selected *.BIN file is displayed in the <b>Filename</b> text field.
6	Click on the command button <b>Next</b> . <b>Response:</b> The dialog <b>File and Device Info</b> is opened. Information is provided here about the selected *.BIN file and also about the PLC.
7	Click on the command button <b>Next</b> . <b>Response:</b> The <b>Summary</b> dialog is opened. This gives you an overview of the settings made for you to check.

---

**Load EXEC file** Carry out the following steps to load the EXEC file in the CPU flash RAM:

Step	Action
1	Click on the command button <b>Transfer</b> . <b>Response:</b> A message box appears warning you that all data available on the PLC will be lost, and the configuration + program must be reloaded on the PLC.
2	Click on the command button <b>Yes</b> , to continue the transfer. <b>Response:</b> The <b>Progress</b> dialog is opened. This gives information about the progress of the transfer in a progress bar and text.
3	Click <b>Close</b> once the transfer is complete. <b>Response:</b> The dialog is closed, and you return to the dialog <b>Summary</b> .
4	Click on the command button <b>Close</b> , to close the EXECLoader.

---

**Creating the software connection**

Carry out the steps given in chapter *Creating a Project, p. 43*.

**Note:** If you receive an error message, close Concept and start the BDRESET.EXE file (in the \Concept directory) to reset the SA85. Then start again from the first step.

---

## Momentum first startup for IEC with EXECLoader

---

### Introduction

This section describes the first startup of Momentum for IEC when used with Modbus Plus.

The first startup is subdivided into 5 main sections:

- *Start EXECLoader, p. 925*
  - *Define SA85 adapter, p. 925*
  - *Protocol settings, p. 926*
  - *Select EXEC file, p. 927*
  - *Load EXEC file, p. 927*
- 

### Start EXECLoader

The procedure for launching EXECLoaders is as follows:

Step	Action
1	Open the Concept start menu. <b>Response:</b> All installed Concept programs are displayed as symbols.
2	Click on the symbol with the identifier <b>EXECLoader</b> . <b>Response:</b> The EXECLoader program is started.
3	Click on the command <b>Next</b> , as soon as you have read the information on the page. <b>Response:</b> The dialog <b>Communication Protocol</b> is opened.

---

### Define SA85 adapter

Carry out the following steps to define the LAN address set in the CONFIG.SYS file:

Step	Action
1	Select the option button <b>Modbus Plus</b> .
2	Click on the command button <b>Next</b> . <b>Response:</b> The <b>Modbus Plus Target</b> dialog is opened.
3	Select from the list <b>Devices Online</b> : the adapter address you set when installing the SA85 in the CONFIG.SYS file (Parameter /n).

---

**Protocol settings** Carry out the following steps to set the Modbus Plus protocol settings:

Step	Action
1	Click on the command button <b>Scan</b> . <b>Response:</b> The nodes on the Modbus Plus network are read and displayed graphically in the left window. A green point in the graphic indicates that the CPU is in RUN mode. To stop the CPU continue as described in step 3.
2	Double-click on the read network node in the graphical display. <b>Response:</b> The Modbus address of the node is automatically entered in the textfield In the text field <b>Modbus Plus Address</b> .
3	Click the right mouse button in the left window. <b>Response:</b> A context menu with individual PLC commands is opened.
4	If the "Run" display is lit on the CPU, stop the program using the command <b>Stop PLC</b> . <b>Response:</b> A message window appears where you can click <b>OK</b> to confirm stopping the CPU.
5	Click the command button <b>OK</b> , to confirm stopping the CPU. <b>Response:</b> You return to the <b>Modbus Plus Target</b> dialog, and the green point disappears from the graph.
6	Activate the check box <b>Bridge</b> , if the connection to the Modbus network node should be made via a Modbus network using a Modbus bridge.
7	Press the appropriate Option button for your system ( <b>PLC, Local Head, Remote I/O Drop</b> ).
8	Click on the command button <b>Next</b> . <b>Response:</b> The <b>Operation</b> dialog is opened.

---

**Select EXEC file** Carry out the following steps to select the EXEC file:

Step	Action
1	Press the Option button <b>Transfer EXEC to Device</b> .
2	Click on the command button <b>Browse...</b> <b>Response:</b> The Concept directory is opened in a standard window.
3	Double-click on the DAT directory. <b>Response:</b> All available*.BIN files are displayed.
4	Click on the *.BIN file that corresponds to your CPU and the desired programming language. See the table <i>Loading Firmware for Momentum PLC Types, p. 951</i> . <b>Response:</b> The selected *.BIN file is displayed in <b>File name:</b> text field.
5	Click on the command button <b>Open</b> . <b>Response:</b> You return to the dialog <b>Operation</b> , and the path to the selected *.BIN file is displayed in the <b>Filename</b> text field.
6	Click on the command button <b>Next</b> . <b>Response:</b> The dialog <b>File and Device Info</b> is opened. Information is provided here about the selected *.BIN file and also about the PLC.
7	Click on the command button <b>Next</b> . <b>Response:</b> The <b>Summary</b> dialog is opened. This gives you an overview of the settings made for you to check.

**Load EXEC file** Carry out the following steps to load the EXEC file in the CPU flash RAM:

Step	Action
1	Click on the command button <b>Transfer</b> . <b>Response:</b> A message box appears warning you that all data available on the PLC will be lost, and the configuration and program must be reloaded on the PLC.
2	Click on the command button <b>Yes</b> , to continue the transfer. <b>Response:</b> The <b>Progress</b> dialog is opened. This gives information about the progress of the transfer in a progress bar and text.
3	Click <b>Close</b> once the transfer is complete. <b>Response:</b> The dialog is closed, and you return to the dialog <b>Summary</b> .
4	Click on the command button <b>Close</b> , to close the EXECLoader.

**CPU display during transfer**

During transfer the CPU display is as follows:

LED	Response
Run	slow flashing
COM ACT	not lit
Modbus +	fast flashing

**CPU display after transfer**

After transfer the CPU display is as follows:

LED	Response
Run	not lit
COM ACT	not lit
Modbus +	fast flashing

**Creating the software connection**

Carry out the steps given in chapter *Creating a Project*, p. 43.

<p><b>Note:</b> If you receive an error message, close Concept and start the BDRESET.EXE file (in the \Concept directory) to reset the SA85. Then start again from the first step.</p>
--

## Momentum first startup for LL984 with EXECLoader

### Introduction

This section describes the first startup of Momentum for LL984 when used with Modbus Plus.

**Note:** Loading the EXEC file for LL984 is not necessary with a new computer, since it is preloaded in the the CPUs Flash RAM. Loading the EXEC file for LL984 is only necessary if you have already loaded the EXEC file for IEC, and now wish to change.

You should always check to see if a new EXEC version has been released in the meantime. This information and the current EXEC file can be found on our website at [www.schneiderautomation.com](http://www.schneiderautomation.com). You can see the currently loaded version of the EXEC file in Concept using the **Online** → **Online controller...** menu command.

The first startup is subdivided into 5 main sections:

- *Start EXECLoader, p. 929*
- *Define SA85 adapter, p. 929*
- *Protocol settings, p. 930*
- *Select EXEC file, p. 931*
- *Load EXEC file, p. 931*

### Start EXECLoader

The procedure for launching EXECLoaders is as follows:

Step	Action
1	Open the Concept start menu. <b>Response:</b> All installed Concept programs are displayed as symbols.
2	Click on the symbol with the identifier <b>EXECLoader</b> . <b>Response:</b> The EXECLoader program is started.
3	Click on the command <b>Next</b> , as soon as you have read the information on the page. <b>Response:</b> The dialog <b>Communication Protocol</b> is opened.

### Define SA85 adapter

Carry out the following steps to define the LAN address set in the CONFIG.SYS file:

Step	Action
1	Select the option button <b>Modbus Plus</b> .
2	Click on the command button <b>Next</b> . <b>Response:</b> The <b>Modbus Plus Target</b> dialog is opened.
3	Select from the list <b>Devices Online</b> : the adapter address you set when installing the SA85 in the CONFIG.SYS file (Parameter /n).

**Protocol settings** Carry out the following steps to set the Modbus Plus protocol settings:

Step	Action
1	Click on the command button <b>Scan</b> . <b>Response:</b> The nodes on the Modbus Plus network are read and displayed graphically in the left window. A green point in the graphic indicates that the CPU is in RUN mode. To stop the CPU continue as described in step 3.
2	Double-click on the read network node in the graphical display. <b>Response:</b> The Modbus address of the node is automatically entered in the textfield In the text field <b>Modbus Plus Address</b> .
3	Click the right mouse button in the left window. <b>Response:</b> A context menu with individual PLC commands is opened.
4	If the "Run" display is lit on the CPU, stop the program using the command <b>Stop PLC</b> . <b>Response:</b> A message window appears where you can click <b>OK</b> to confirm stopping the CPU.
5	Click the command button <b>OK</b> , to confirm stopping the CPU. <b>Response:</b> You return to the <b>Modbus Plus Target</b> dialog, and the green point disappears from the graph.
6	Activate the check box <b>Bridge</b> , if the connection to the Modbus network node should be made via a Modbus network using a Modbus bridge.
7	Press the appropriate Option button for your system ( <b>PLC, Local Head, Remote I/O Drop</b> ).
8	Click on the command button <b>Next</b> . <b>Response:</b> The <b>Operation</b> dialog is opened.

---



**Select EXEC file** Carry out the following steps to select the EXEC file:

Step	Action
1	Press the Option button <b>Transfer EXEC to Device</b> .
2	Click on the command button <b>Browse...</b> <b>Response:</b> The Concept directory is opened in a standard window.
3	Double-click on the DAT directory. <b>Response:</b> All available*.BIN files are displayed.
4	Click on the *.BIN file that corresponds to your CPU and the desired programming language. See the table <i>Loading Firmware for Momentum PLC Types, p. 951</i> . <b>Response:</b> The selected *.BIN file is displayed in <b>File name:</b> text field.
5	Click on the command button <b>Open</b> . <b>Response:</b> You return to the dialog <b>Operation</b> , and the path to the selected *.BIN file is displayed in the <b>Filename</b> text field.
6	Click on the command button <b>Next</b> . <b>Response:</b> The dialog <b>File and Device Info</b> is opened. Information is provided here about the selected *.BIN file and also about the PLC.
7	Click on the command button <b>Next</b> . <b>Response:</b> The <b>Summary</b> dialog is opened. This gives you an overview of the settings made for you to check.

**Load EXEC file** Carry out the following steps to load the EXEC file in the CPU flash RAM:

Step	Action
1	Click on the command button <b>Transfer</b> . <b>Response:</b> A message box appears warning you that all data available on the PLC will be lost, and the configuration and program must be reloaded on the PLC.
2	Click on the command button <b>Yes</b> , to continue the transfer. <b>Response:</b> The <b>Progress</b> dialog is opened. This gives information about the progress of the transfer in a progress bar and text.
3	Click <b>Close</b> once the transfer is complete. <b>Response:</b> The dialog is closed, and you return to the dialog <b>Summary</b> .
4	Click on the command button <b>Close</b> , to close the EXECLoader.

**CPU display during transfer**

During transfer the CPU display is as follows:

LED	Response
Run	slow flashing
COM ACT	not lit
Modbus +	fast flashing

**CPU display after transfer**

After transfer the CPU display is as follows:

LED	Response
Run	not lit
COM ACT	not lit
Modbus +	fast flashing


**Creating the software connection**

Carry out the steps given in chapter *Creating a Project*, p. 43.

<p><b>Note:</b> If you receive an error message, close Concept and start the BDRESET.EXE file (in the \Concept directory) to reset the SA85. Then start again from the first step.</p>
--

---

## Startup when using Modbus Plus with DOS Loader



---

### Introduction

#### Overview

This chapter describes loading executive data (EXEC) onto the PLC with the DOS Loader program.

#### What's in this chapter?

This chapter contains the following topics:

Topic	Page
Quantum first startup with DOS Loader	934
Compact first startup with DOS Loader	937
Atrium first startup with DOS Loader	940
Momentum first startup for IEC with DOS Loader	943
Momentum first startup for LL984 with DOS Loader	946

## Quantum first startup with DOS Loader

---

### Introduction

This section describes the first startup of Quantum when used with Modbus Plus. The first startup is subdivided into 5 main sections:

- *Start DOS Loader, p. 934*
  - *Define SA85 adapter, p. 934*
  - *Protocol settings, p. 935*
  - *Select EXEC file, p. 935*
  - *Load EXEC file, p. 936*
- 

### Start DOS Loader

The procedure for launching DOS Loaders is as follows:

Step	Action
1	If the CPU display "Run" is lit, stop the program with Concept (in main menu <b>Online</b> ). <b>Response:</b> The "Run" display is no longer lit; the "Ready" is now lit.
2	Open the directory DAT (CONCEPTDAT).
3	Double-click on the file LOADER.EXE. <b>Response:</b> The installation program for the Executive file (EXEC) is started.
4	Select the option <b>Communication Parameters</b> . <b>Response:</b> The dialog box <b>Communication setup</b> is opened.
5	Select the <b>Modbus Plus</b> option. <b>Response:</b> The <b>Modbus Plus communication setup</b> window is opened.

---

### Define SA85 adapter

Carry out the following steps to define the LAN address set in the CONFIG.SYS file:

Step	Action
1	Select the adapter address you set when installing the SA85 in the CONFIG.SYS file (Parameter /n).
2	Confirm your selection with RETURN.

---

**Protocol settings** Carry out the following steps to set the Modbus Plus protocol settings:

Step	Action
1	Enter in <b>Enter First Routing Path</b> : the node address set on the CPU (using a rotary switch on the back of the module).
2	Confirm the entry with RETURN. <b>Response:</b> The option <b>Enter second Routing Path</b> : appears.
3	Acknowledge the option with RETURN. <b>Response:</b> The window for selecting the TARGET PATH appears.
4	Select the <b>TARGET PATH 1</b> option.
5	Enter in <b>Enter Software Interrupt -&gt;</b> the Interrupt (5c or 5d) selected in the CONFIG.SYS file.
6	Select the <b>ACCEPT CHANGES</b> option. <b>Response:</b> You return to the main menu.

**Select EXEC file** Carry out the following steps to select the EXEC file:

Step	Action
1	Select the option <b>File Selection</b> . <b>Response:</b> The <b>File Selection</b> window is opened.
2	Click on the *.BIN file that corresponds to your CPU and the desired programming language. See the table <i>Loading Firmware for Quantum PLC Types, p. 950</i> .
3	Confirm your selection with RETURN. <b>Response:</b> You return to the main menu.

**Load EXEC file**

Carry out the following steps to load the EXEC file in the CPU flash RAM:

Step	Action
1	Select the option <b>Load File To PLC</b> . <b>Response:</b> The <b>Loading Process</b> window is opened, and the warning "The PROGRAM contents of the device being loaded could be lost after loading a new Executive. The CONTENTS stored in the Micro H H P will always be lost after loading a new Executive. Would you like to continue (Y/N) ? N" is displayed.
2	Acknowledge the warning with <b>Y</b> . <b>Response:</b> The message "Node failed to enter normal mode" appears.
3	The <b>DOWNLOAD PROGRESS</b> window appears which shows the transfer rate. <b>Response:</b> After the transfer is complete, the message "Download Operation Successful" appears.
4	Confirm the message with <b>RETURN</b> . <b>Response:</b> You return to the main menu.
5	Select the <b>Exit Program</b> option. <b>Response:</b> The DOS Loader is exited.

---

**CPU display during transfer**

During transfer the CPU display is as follows:

LED	Response
Ready	lit
Run	slow flashing
Modbus	not lit
Modbus +	fast flashing

---

**CPU display after transfer**

After transfer the CPU display is as follows:

LED	Response
Ready	lit
Run	not lit
Modbus	not lit
Modbus +	fast flashing

---

**Creating the software connection**

Carry out the steps given in chapter *Creating a Project*, p. 43.

**Note:** If you receive an error message, close Concept and start the BDRESET.EXE file (in the \Concept directory) to reset the SA85. Then start again from the first step.

## Compact first startup with DOS Loader

### Introduction

This section describes the first startup of Compact when used with Modbus Plus. The first startup is subdivided into 5 main sections:

- *Start DOS Loader, p. 937*
- *Define SA85 adapter, p. 937*
- *Protocol settings, p. 938*
- *Select EXEC file, p. 938*
- *Load EXEC file, p. 939*

### Start DOS Loader

The procedure for launching DOS Loaders is as follows:

Step	Action
1	If the CPU display "Run" is lit, stop the program with Concept (in main menu <b>Online</b> ). <b>Response:</b> The "Run" display is no longer lit; the "Ready" is now lit.
2	Open the directory DAT (CONCEPT\DAT).
3	Double-click on the file LOADER.EXE. <b>Response:</b> The installation program for the Executive file (EXEC) is started.
4	Select the option <b>Communication Parameters</b> . <b>Response:</b> The dialog box <b>Communication setup</b> is opened.
5	Select the <b>Modbus Plus</b> option. <b>Response:</b> The <b>Modbus Plus communication setup</b> window is opened.

### Define SA85 adapter

Carry out the following steps to define the LAN address set in the CONFIG.SYS file:

Step	Action
1	Select the adapter address you set when installing the SA85 in the CONFIG.SYS file (Parameter /n).
2	Confirm your selection with RETURN.

**Protocol settings** Carry out the following steps to set the Modbus Plus protocol settings:

Step	Action
1	Enter in <b>Enter First Routing Path:</b> the node address set on the CPU (using a rotary switch on the back of the module).
2	Confirm the entry with RETURN. <b>Response:</b> The option <b>Enter second Routing Path:</b> appears.
3	Acknowledge the option with RETURN. <b>Response:</b> The window for selecting the TARGET PATH appears.
4	Select the <b>TARGET PATH 1</b> option.
5	Enter in <b>Enter Software Interrupt -&gt;</b> the Interrupt (5c or 5d) selected in the CONFIG.SYS file.
6	Select the <b>ACCEPT CHANGES</b> option. <b>Response:</b> You return to the main menu.

---

**Select EXEC file** Carry out the following steps to select the EXEC file:

Step	Action
1	Select the option <b>File Selection</b> . <b>Response:</b> The <b>File Selection</b> window is opened.
2	Select the *.BIN file CTSX201D.
3	Confirm your selection with RETURN. <b>Response:</b> You return to the main menu.

---



**Load EXEC file**

Carry out the following steps to load the EXEC file in the CPU flash RAM:

Step	Action
1	Select the option <b>Load File To PLC</b> . <b>Response:</b> The <b>Loading Process</b> window is opened, and the warning "The PROGRAM contents of the device being loaded could be lost after loading a new Executive. The CONTENTS stored in the Micro H H P will always be lost after loading a new Executive. Would you like to continue (Y/N) ? N" is displayed.
2	Acknowledge the warning with <b>Y</b> . <b>Response:</b> The message "Node failed to enter normal mode" appears.
3	The DOWNLOAD PROGRESS window appears which shows the transfer rate. <b>Response:</b> After the transfer is complete, the message "Download Operation Successful" appears.
4	Confirm the message with RETURN. <b>Response:</b> You return to the main menu.
5	Select the <b>Exit Program</b> option. <b>Response:</b> The DOS Loader is exited.

**Creating the software connection**

Carry out the steps given in chapter *Creating a Project*, p. 43.

**Note:** If you receive an error message, close Concept and start the BDRESET.EXE file (in the \Concept directory) to reset the SA85. Then start again from the first step.

## Atrium first startup with DOS Loader

---

### Introduction

This section describes the first startup of Atrium when used with Modbus Plus. The hardware requirements for loading EXEC files can be seen in the "Modicon TSX Atrium" manual.

The first startup is subdivided into 5 main sections:

- *Start DOS Loader, p. 940*
  - *Define SA85 adapter, p. 940*
  - *Protocol settings, p. 941*
  - *Select EXEC file, p. 941*
  - *Load EXEC file, p. 942*
- 

### Start DOS Loader

The procedure for launching DOS Loaders is as follows:

Step	Action
1	If the CPU display "Run" is lit, stop the program with Concept (in main menu <b>Online</b> ). <b>Response:</b> The "Run" display is no longer lit; the "Ready" is now lit.
2	Open the directory DAT (CONCEPT\DAT).
3	Double-click on the file LOADER.EXE. <b>Response:</b> The installation program for the Executive file (EXEC) is started.
4	Select the option <b>Communication Parameters</b> . <b>Response:</b> The dialog box <b>Communication setup</b> is opened.
5	Select the <b>Modbus Plus</b> option. <b>Response:</b> The <b>Modbus Plus communication setup</b> window is opened.

---

### Define SA85 adapter

Carry out the following steps to define the LAN address set in the CONFIG.SYS file:

Step	Action
1	Select the adapter address you set when installing the SA85 in the CONFIG.SYS file (Parameter /n).
2	Confirm your selection with RETURN.

---

**Protocol settings** Carry out the following steps to set the Modbus Plus protocol settings:

Step	Action
1	Enter in <b>Enter First Routing Path</b> : the node address set on the CPU (using a rotary switch on the back of the module).
2	Confirm the entry with RETURN. <b>Response:</b> The option <b>Enter second Routing Path</b> : appears.
3	Acknowledge the option with RETURN. <b>Response:</b> The window for selecting the TARGET PATH appears.
4	Select the <b>TARGET PATH 1</b> option.
5	Enter in <b>Enter Software Interrupt -&gt;</b> the Interrupt (5c or 5d) selected in the CONFIG.SYS file.
6	Select the <b>ACCEPT CHANGES</b> option. <b>Response:</b> You return to the main menu.

**Select EXEC file** Carry out the following steps to select the EXEC file:

Step	Action
1	Select the option <b>File Selection</b> . <b>Response:</b> The <b>File Selection</b> window is opened.
2	Click on the *.BIN file that corresponds to your CPU and the desired programming language. See the table <i>Loading Firmware for Atrium PLC Types</i> , p. 952.
3	Confirm your selection with RETURN. <b>Response:</b> You return to the main menu.

**Load EXEC file**

Carry out the following steps to load the EXEC file in the CPU flash RAM:

Step	Action
1	Select the option <b>Load File To PLC</b> . <b>Response:</b> The <b>Loading Process</b> window is opened, and the warning "The PROGRAM contents of the device being loaded could be lost after loading a new Executive. The CONTENTS stored in the Micro H H P will always be lost after loading a new Executive. Would you like to continue (Y/N) ? N" is displayed.
2	Acknowledge the warning with <b>Y</b> . <b>Response:</b> The message "Node failed to enter normal mode" appears.
3	The DOWNLOAD PROGRESS window appears which shows the transfer rate. <b>Response:</b> After the transfer is complete, the message "Download Operation Successful" appears.
4	Confirm the message with <b>RETURN</b> . <b>Response:</b> You return to the main menu.
5	Select the <b>Exit Program</b> option. <b>Response:</b> The DOS Loader is exited.

**Creating the software connection**

Carry out the steps given in chapter *Creating a Project*, p. 43.

**Note:** If you receive an error message, close Concept and start the BDRESET.EXE file (in the \Concept directory) to reset the SA85. Then start again from the first step.

## Momentum first startup for IEC with DOS Loader

### Introduction

This section describes the first startup of Momentum for IEC when used with Modbus Plus.

The first startup is subdivided into 5 main sections:

- *Start DOS Loader, p. 943*
- *Define SA85 adapter, p. 943*
- *Protocol settings, p. 944*
- *Select EXEC file, p. 944*
- *Load EXEC file, p. 945*

### Start DOS Loader

The procedure for launching DOS Loaders is as follows:

Step	Action
1	If the CPU display "Run" is lit, stop the program with Concept (in main menu <b>Online</b> ). <b>Response:</b> The "Run" display is no longer lit; the "Ready" is now lit.
2	Open the directory DAT (CONCEPT\DAT).
3	Double-click on the file LOADER.EXE. <b>Response:</b> The installation program for the Executive file (EXEC) is started.
4	Select the option <b>Communication Parameters</b> . <b>Response:</b> The dialog box <b>Communication setup</b> is opened.
5	Select the <b>Modbus Plus</b> option. <b>Response:</b> The <b>Modbus Plus communication setup</b> window is opened.

### Define SA85 adapter

Carry out the following steps to define the LAN address set in the CONFIG.SYS file:

Step	Action
1	Select the adapter address you set when installing the SA85 in the CONFIG.SYS file (Parameter /n).
2	Confirm your selection with RETURN.

**Protocol settings** Carry out the following steps to set the Modbus Plus protocol settings:

Step	Action
1	Enter in <b>Enter First Routing Path:</b> the node address set on the CPU (using a rotary switch on the back of the module).
2	Confirm the entry with RETURN. <b>Response:</b> The option <b>Enter second Routing Path:</b> appears.
3	Acknowledge the option with RETURN. <b>Response:</b> The window for selecting the TARGET PATH appears.
4	Select the <b>TARGET PATH 1</b> option.
5	Enter in <b>Enter Software Interrupt -&gt;</b> the Interrupt (5c or 5d) selected in the CONFIG.SYS file.
6	Select the <b>ACCEPT CHANGES</b> option. <b>Response:</b> You return to the main menu.

---

**Select EXEC file** Carry out the following steps to select the EXEC file:

Step	Action
1	Select the option <b>File Selection</b> . <b>Response:</b> The <b>File Selection</b> window is opened.
2	Click on the *.BIN file that corresponds to your CPU and the desired programming language. See the table <i>Loading Firmware for Momentum PLC Types, p. 951</i> .
3	Confirm your selection with RETURN. <b>Response:</b> You return to the main menu.

---

**Load EXEC file**

Carry out the following steps to load the EXEC file in the CPU flash RAM:

Step	Action
1	Select the option <b>Load File To PLC</b> . <b>Response:</b> The <b>Loading Process</b> window is opened, and the warning "The PROGRAM contents of the device being loaded could be lost after loading a new Executive. The CONTENTS stored in the Micro H H P will always be lost after loading a new Executive. Would you like to continue (Y/N) ? N" is displayed.
2	Acknowledge the warning with <b>Y</b> . <b>Response:</b> The message "Node failed to enter normal mode" appears.
3	The <b>DOWNLOAD PROGRESS</b> window appears which shows the transfer rate. <b>Response:</b> After the transfer is complete, the message "Download Operation Successful" appears.
4	Confirm the message with <b>RETURN</b> . <b>Response:</b> You return to the main menu.
5	Select the <b>Exit Program</b> option. <b>Response:</b> The DOS Loader is exited.

**CPU display during transfer**

During transfer the CPU display is as follows:

LED	Response
Run	slow flashing
COM ACT	not lit
Modbus +	fast flashing

**CPU display after transfer**

After transfer the CPU display is as follows:

LED	Response
Run	not lit
COM ACT	not lit
Modbus +	fast flashing

**Creating the software connection**

Carry out the steps given in chapter *Creating a Project*, p. 43.

**Note:** If you receive an error message, close Concept and start the BDRESET.EXE file (in the \Concept directory) to reset the SA85. Then start again from the first step.

## Momentum first startup for LL984 with DOS Loader

---

### Introduction

This section describes the first startup of Momentum for LL984 when used with Modbus Plus.

**Note:** Loading the EXEC file for LL984 is not necessary with a new computer, since it is preloaded in the the CPUs Flash RAM. Loading the EXEC file for LL984 is only necessary if you have already loaded the EXEC file for IEC, and now wish to change.

You should always check to see if a new EXEC version has been released in the meantime. This information and the current EXEC file can be found on our website at [www.schneiderautomation.com](http://www.schneiderautomation.com). You can see the currently loaded version of the EXEC file in Concept using the **Online** → **Online controller...** menu command.

The first startup is subdivided into 5 main sections:

- *Start DOS Loader, p. 946*
- *Define SA85 adapter, p. 947*
- *Protocol settings, p. 947*
- *Select EXEC file, p. 947*
- *Load EXEC file, p. 948*

### Start DOS Loader

The procedure for launching DOS Loaders is as follows:

Step	Action
1	If the CPU display "Run" is lit, stop the program with Concept (in main menu <b>Online</b> ). <b>Response:</b> The "Run" display is no longer lit; the "Ready" is now lit.
2	Open the directory DAT (CONCEPTDAT).
3	Double-click on the file LOADER.EXE. <b>Response:</b> The installation program for the Executive file (EXEC) is started.
4	Select the option <b>Communication Parameters</b> . <b>Response:</b> The dialog box <b>Communication setup</b> is opened.
5	Select the <b>Modbus Plus</b> option. <b>Response:</b> The <b>Modbus Plus communication setup</b> window is opened.

---



**Define SA85 adapter**

Carry out the following steps to define the LAN address set in the CONFIG.SYS file:

Step	Action
1	Select the adapter address you set when installing the SA85 in the CONFIG.SYS file (Parameter /n).
2	Confirm your selection with RETURN.

**Protocol settings**

Carry out the following steps to set the Modbus Plus protocol settings:

Step	Action
1	Enter in <b>Enter First Routing Path</b> : the node address set on the CPU (using a rotary switch on the back of the module).
2	Confirm the entry with RETURN. <b>Response:</b> The option <b>Enter second Routing Path</b> : appears.
3	Acknowledge the option with RETURN. <b>Response:</b> The window for selecting the TARGET PATH appears.
4	Select the <b>TARGET PATH 1</b> option.
5	Enter in <b>Enter Software Interrupt -&gt;</b> the Interrupt (5c or 5d) selected in the CONFIG.SYS file.
6	Select the <b>ACCEPT CHANGES</b> option. <b>Response:</b> You return to the main menu.

**Select EXEC file**

Carry out the following steps to select the EXEC file:

Step	Action
1	Select the option <b>File Selection</b> . <b>Response:</b> The <b>File Selection</b> window is opened.
2	Click on the *.BIN file that corresponds to your CPU and the desired programming language. See the table <i>Loading Firmware for Momentum PLC Types</i> , p. 951.
3	Confirm your selection with RETURN. <b>Response:</b> You return to the main menu.

**Load EXEC file** Carry out the following steps to load the EXEC file in the CPU flash RAM:

Step	Action
1	Select the option <b>Load File To PLC</b> . <b>Response:</b> The <b>Loading Process</b> window is opened, and the warning "The PROGRAM contents of the device being loaded could be lost after loading a new Executive. The CONTENTS stored in the Micro H H P will always be lost after loading a new Executive. Would you like to continue (Y/N) ? N" is displayed.
2	Acknowledge the warning with <b>Y</b> . <b>Response:</b> The message "Node failed to enter normal mode" appears.
3	The <b>DOWNLOAD PROGRESS</b> window appears which shows the transfer rate. <b>Response:</b> After the transfer is complete, the message "Download Operation Successful" appears.
4	Confirm the message with <b>RETURN</b> . <b>Response:</b> You return to the main menu.
5	Select the <b>Exit Program</b> option. <b>Response:</b> The DOS Loader is exited.

---

**CPU display during transfer** During transfer the CPU display is as follows:

LED	Response
Run	slow flashing
COM ACT	not lit
Modbus +	fast flashing

---

**CPU display after transfer** After transfer the CPU display is as follows:

LED	Response
Run	not lit
COM ACT	not lit
Modbus +	fast flashing

---

**Creating the software connection** Carry out the steps given in chapter *Creating a Project*, p. 43.

**Note:** If you receive an error message, close Concept and start the **BDRESET.EXE** file (in the \Concept directory) to reset the SA85. Then start again from the first step.

---

---

## EXEC files



---

### Loading Firmware

#### At a Glance

You obtain the PLC types of the different firmware by loading the EXEC files (\*.BIN).

---

**Loading  
Firmware for  
Quantum PLC  
Types**

Assigning the EXEC files:

140 CPU	Q186Vxxx (IEC+LL984)	Q486Vxxx (IEC+LL984)	Q58VxxxD (IEC+LL984)	Q5RVxxxD (IEC+LL984)	QIECVxxx (IEC only) *	IEC Memory (kByte)
113 02	X (LL984 only)	-	-	-	-	
113 02S	-	-	-	-	X	max. 150
113 02X	X (LL984 only)	-	-	-	-	
113 03	X	-	-	-	-	max. 136
113 03S	-	-	-	-	X	max. 379
113 03X	X	-	-	-	-	max. 136
213 04	X	-	-	-	-	max. 305
213 04S	-	-	-	-	X	max. 610
213 04X	X	-	-	-	-	max. 305
424 0x	-	X	-	-	-	max. 465
424 0xX	-	X	-	-	-	max. 465
434 12	-	-	X	-	-	max. 890
534 14	-	-	X	-	-	max. 2550
434 12A (Redesigned CPU)	-	-	-	X	-	max. 890
534 14A (Redesigned CPU)	-	-	-	X	-	max. 2550

**Note:** \* After the QIECVxxx.BIN EXEC file is loaded the EMUQ.EXE loadable must be loaded in Concept in the **Loadables (PLC Configuration → Loadables...)** dialog box.

**Loading  
Firmware for  
Quantum LL984  
Hot Standby  
Operation**

The Quantum CPUs not ending in X or S can be used for the LL984-Hot Standby operation. A special EXEC file must be downloaded onto the CPU for this. The loadable for LL984 Hot Standby (CHS\_208.DAT) is automatically installed by the system.

**Loading  
Firmware for  
Quantum IEC Hot  
Standby  
Operation**

The CPUs 140 CPU 434 12 and 140 CPU 534 14 can also be used for IEC Hot Standby. A special EXEC file must be downloaded onto the CPU for this. The loadables for IEC Hot Standby (IHSB196.EXE and CHS\_208.DAT) are automatically installed by the system.

**Loading  
Firmware for  
Quantum  
Equation Editor**

The Quantum CPUs not ending in X or S can be used for the LL984- equation editor. A special EXEC file must be downloaded onto the CPU flash for this. This EXEC file is not part of the Concept delivery range but can be obtained via the internet at [www.schneiderautomation.com](http://www.schneiderautomation.com).

**Loading  
Firmware for  
Momentum PLC  
Types**

Assigning the EXEC files for Momentum PLC type (CPU 171 CCC 7x0 x0):

171 CCC	M1Vxxx (LL984 only)	M1IECxxx (IEC only)	IEC Memory (kByte)
760 10-984	X	-	
760 10-IEC	-	X	256
780 10-984	X	-	
780 10-IEC	-	X	256

Assigning the EXEC files for Momentum PLC type (CPU 171 CCC 9x0 x0):

171 CCC	M1EVxxx (LL984 only)	M1EWIxxx (IEC only)	IEC Memory (kByte)
960 20-984	X	-	
960 30-984	X	-	
960 30-IEC	-	X	220
980 20-984	X	-	
980 30-984	X	-	
980 30-IEC	-	X	220

Assigning the EXEC files for Momentum PLC type (CPU 171 CCS 7x0 x0):

171 CCS	M1Vxxx (LL984 only)	M1IECxxx (IEC only)	IEC Memory (kByte)
700 10	X	-	
700/780 00	X	-	
760 00-984	X	-	
760 00-IEC	-	X	160

The stripped EXEC of the M1 supports up to a maximum of 44 I/O modules.

**Loading  
Firmware for  
Compact PLC  
Types**

The **CTSXxxxD.BIN** EXEC file must be downloaded onto the CPU flash for all Compact CPUs.

---

**Loading  
Firmware for  
Atrium PLC  
Types**

A special EXEC file must be downloaded onto the CPU flash for each Atrium CPU (see table below).


<b>180 CCO</b>	<b>EXEC File</b>
121 01	AI38Vxxx.BIN
241 01	AI58Vxxx.BIN

**Note:** No EXEC file needs to be downloaded for the 180 ASP 26x xx (SoftPLC) CPU.

---

---

## Settings in the CONCEPT.INI



---

### Introduction

#### Overview

This chapter contains the settings that can be carried out in the CONCEPT.INI file.

#### What's in this chapter?

This chapter contains the following topics:

Topic	Page
General information on the Concept INI file	954
INI Print Settings	955
INI Settings for the Register Address Format, for Variable Storage and for Defining the Project Name	956
INI Settings for Global DFBs [Path] [Upload]	957
Representation of Internal Data in the INI File	959
INI Settings for the LD Section	959
INI-Settings for Online Animation [Colors]	960

---

## General information on the Concept INI file

---

**Introduction** Software settings can be specified in the Concept INI file. Settings generated by the program are also stored in the INI file. The INI file initially contains defaults that can subsequently be changed.

---

**Where is the CONCEPT.INI file situated?** After the installation of Concept, the CONCEPT.INI file can be found in the Windows directory.

---

**Editing the INI File** Various settings are given (exception: path information) and divided into several keywords. The lines that begin with a semicolon (;) represent comments or explain the subsequent setting.  
To edit the INI file, only change the lines without semicolons (;) or insert a new line after the comment, in which to specify the path. Then save the modified file.

<p><b>Note:</b> Changes in the INI file are only accepted after Concept/DFB Editor/Converter is restarted.</p>
--

---



## INI Print Settings [Print]

---

### Printing FBD Sections

Defining default page break values for FBD sections:

Setting	Description
DX_FBD_PORTRAIT=	Specify portrait width (default value at delivery = 75)
DY_FBD_PORTRAIT=	Specify portrait height (default value at delivery = 100)
DX_FBD_LANDSCAPE=	Specify landscape width (default value at delivery = 100)
DY_FBD_LANDSCAPE=	Specify landscape height (default value at delivery = 50)

---

### Printing LD Sections

Defining default page break values for LD sections:

Setting	Description
DX_LD_PORTRAIT=	Specify portrait width (default value at delivery = 70)
DY_LD_PORTRAIT=	Specify portrait height (default value at delivery = 35)
DX_LD_LANDSCAPE=	Specify landscape width (default value at delivery = 105)
DY_LD_LANDSCAPE=	Specify landscape height (default value at delivery = 18)

---

### Printing SFC Sections

Defining default page break values for SFC sections:

Setting	Description
DX_SFC_PORTRAIT=	Specify portrait width (default value at delivery = 11)
DY_SFC_PORTRAIT=	Specify portrait height (default value at delivery = 20)
DX_SFC_LANDSCAPE=	Specify landscape width (default value at delivery = 15)
DY_SFC_LANDSCAPE=	Specify landscape height (default value at delivery = 11)

---

## INI Settings for the Register Address Format, for Variable Storage and for Defining the Project Name

---

### Defining the Register Address Format [Common]

Specifying the register address format (e.g. 4x reference):

Setting	Description
AddrStyle=0	0 = 400001 (default)
AddrStyle=1	1 = 4:00001 (separator)
AddrStyle=2	2 = 4:1 (compact)
AddrStyle=3	3 = QW00001 (IEC)

---

### Defining Variable Storage [Common]

Store variables in file:

Setting	Description
ExportVariables=1	After a project has been downloaded and saved, all variables are stored in a file. This file is called *.VAR and is found in the " <b>Project directory</b> " → <b>VAR</b> → *.VAR. All variables and their attributes are shown in this file.
ExportVariables=0	Additional storage of variables in a file does not take place.

---

### Determining the Permissibility of Digits in Project Names [Common]

Determining the permissibility of digits in project names:

Setting	Description
ProjectPrefixDigit=1	Project names that begin with a digit are permitted.
ProjectPrefixDigit=0	Project names that begin with a digit are not permitted.

---

## INI Settings for Global DFBs [Path] [Upload]

### Defining the Path for Global DFBs and Help Files [Path]

Defining paths:

Setting	Description
GlobalDFBPath=	Specify path for global DFBs.
HelpPath=	Specify paths for help files.

### Defining the Storage of Global DFBs during Upload

Defining a new directory for global DFBs:

Setting	Description
PreserveGlobalDFBs=1	<p>During the upload process, a GLB directory for the global DFBs is created in the project directory. By doing this, existing global DFBs in the Concept DFB directory will not be overwritten.</p> <p><b>Advantage:</b> No impact on other projects, as the global DFBs in these projects are not overwritten.</p> <p><b>Disadvantage:</b> Multiple copies of global DFBs.</p> <p><b>Note:</b> Also read the sections entitled <i>How are Global DFBs Stored?</i>, p. 958 and <i>How are Global DFBs Read?</i>, p. 958.</p>
PreserveGlobalDFBs=0	<p>During the upload process, global DFBs are downloaded into the Concept DFB directory. Different versions of duplicated DFBs are recognized and overwritten after being queried.</p> <p><b>Advantage:</b> Only one copy of global DFBs for several projects.</p> <p><b>Disadvantage:</b> Existing global DFBs whose versions differ from the uploaded DFBs are overwritten. This can cause other projects to be inconsistent in certain circumstances.</p> <p><b>Note:</b> Also read the sections entitled <i>How are Global DFBs Stored?</i>, p. 958 and <i>How are Global DFBs Read?</i>, p. 958.</p>

**How are Global DFBs Stored?**

Storage of global DFBs depends on the settings in the INI file:

If a project...	then the global DFBs are...
is newly created, and no new DFB path has been defined in the INI file,	stored in the x:\CONCEPT\DFB directory.
is newly created, and a new DFB path has been defined in the INI file,	stored in the DFB directory defined in the path.
is uploaded, and the following settings exist in the INI file: - the [Path] option "GlobalDFBPath=x:\DFB", - the [Upload] option "PreserveGlobalDFBs=0",	stored in the DFB directory defined in the path (x:\DFB).
is uploaded, and the following settings exist in the INI file: - the [Path] option "GlobalDFBPath=x:\DFB", - the [Upload] option "PreserveGlobalDFBs=1",	stored in the project's GLB directory. <b>Note:</b> The GLB directory is always used first, as soon as the "PreserveGlobalDFBs=1" [Upload] option is specified.

**How are Global DFBs Read?**

When a project is opened, the system looks for DFBs in the following order:

Step	Description
1	The project directory is searched for an existing GLB directory.
2	The relevant settings are checked in the INI file. For example: [Path]: GlobalDFBPath=x:\DFB [Upload]: PreserveGlobalDFBs=0 In this example, the DFB directory of the path defined is searched for global DFBs.
3	The DFB directory under x:\CONCEPT\DFB is searched.

Only the global DFBs from one directory are used, i.e. if step 1 is unsuccessful, then step 2 follows, step 3 is only performed if neither of the first two are successful.

---

## Representation of Internal Data in the INI File

---

### Representation of Internal Data

The following keywords appear in the INI file and contain internal data according to specific Concept applications:

- [Debug]
  - [Configurator]
  - [Search]
  - [Registration]
  - [Register]
- 

## INI Settings for the LD Section

---

### Defining the Contact Connection

Defining the contact connection to the power rail:

Setting	Description
ExtendedAutoConnect=0	Only the contacts from the first column in the LD editor are automatically connected to the power rail.
ExtendedAutoConnect=1	The contacts from the first and second columns in the LD editor are automatically connected to the power rail.

---

### Defining the Number of Columns/Fields

Defining the number of columns/fields (only available when editing with keys):

Setting	Description
AutowrapColumn=51	The section contains 51 columns/fields by default. It is possible to set from 2 to 51 columns/fields. When the last column/field is reached, the following objects are automatically placed in the next lines. When this happens, a link with the previous lines is established, i.e. the objects are generated within a common rung. <b>Note:</b> Since with automatic line breaking, the objects that follow are placed in the second column/field, it is recommended that you set the contact connection to the power rail as <code>ExtendedAutoConnect=0</code> .

---

## INI-Settings for Online Animation [Colors]

---

### Line Width


Defining the line width of connections in FBD and LD and for objects in LD:

Setting	Description
AnimationSize=	Setting the width of the lines. The default setting is 1. It can be set from 1 to 10.

---

---

## Glossary



### A

- Active Window** The window, which is currently selected. Only one window can be active at any given time. When a window is active, the color of the title bar changes, so that it is distinguishable from the other windows. Unselected windows are inactive.
- Actual Parameters** Current connected Input / Output Parameters.
- Addresses** (Direct) addresses are memory ranges in the PLC. They are located in the State RAM and can be assigned Input/Output modules.  
The display/entry of direct addresses is possible in the following formats:
- Standard Format (400001)
  - Separator Format (4:00001)
  - Compact format (4:1)
  - IEC Format (QW1)
- ANL\_IN** ANL\_IN stands for the "Analog Input" data type and is used when processing analog values. The 3x-References for the configured analog input module, which were specified in the I/O component list, are automatically assigned data types and should therefore only be occupied with Unlocated Variables.
- ANL\_OUT** ANL\_OUT stands for the "Analog Output" data type and is used when processing analog values. The 3x-References for the configured analog input module, which were specified in the I/O component list, are automatically assigned data types and should therefore only be occupied with Unlocated Variables.
- ANY** In the above version "ANY" covers the BOOL, BYTE, DINT, INT, REAL, UDINT, UINT, TIME and WORD elementary data types and related Derived Data Types.

<b>ANY_BIT</b>	In the above version "ANY_BIT" covers the BOOL, BYTE and WORD data types.
<b>ANY_ELEM</b>	In the above version "ANY_ELEM" covers the BOOL, BYTE, DINT, INT, REAL, UDINT, UINT, TIME and WORD data types.
<b>ANY_INT</b>	In the above version "ANY_INT" covers the DINT, INT, UDINT and UINT data types.
<b>ANY_NUM</b>	In the above version "ANY_NUM" covers the DINT, INT, REAL, UDINT and UINT data types.
<b>ANY_REAL</b>	In the above version "ANY_REAL" covers the REAL data type.
<b>Application Window</b>	The window containing the workspace, menu bar and the tool bar for the application program. The name of the application program appears in the title bar. An application window can contain several Document windows. In Concept the application window corresponds to a Project.
<b>Argument</b>	Synonymous with Actual parameters.
<b>ASCII-Mode</b>	The ASCII (American Standard Code for Information Interchange) mode is used to communicate with various host devices. ASCII works with 7 data bits.
<b>Atrium</b>	The PC based Controller is located on a standard AT board, and can be operated within a host computer in an ISA bus slot. The module has a motherboard (requiring SA85 driver) with two slots for PC104 daughter-boards. In this way, one PC104 daughter-board is used as a CPU and the other as the INTERBUS controller.

---

**B**

<b>Backup file (Concept-EFB)</b>	The backup file is a copy of the last Source coding file. The name of this backup file is "backup???.c" (this is assuming that you never have more than 100 copies of the source coding file). The first backup file has the name "backup00.c". If you have made alterations to the Definitions file, which do not cause any changes to the EFB interface, the generation of a backup file can be stopped by editing the source coding file ( <b>Objects</b> → <b>Source</b> ). If a backup file is created, the source file can be entered as the name.
----------------------------------	--



---

<b>Base 16 literals</b>	<p>Base 16 literals are used to input whole number values into the hexadecimal system. The base must be denoted using the prefix 16#. The values can not have any signs (+/-). Single underscores ( _ ) between numbers are not significant.</p> <p>Example 16#F_F or 16#FF (decimal 255) 16#E_0 or 16#E0 (decimal 224)</p>
<b>Base 2 literals</b>	<p>Base 2 literals are used to input whole number values into the dual system. The base must be denoted using the prefix 2#. The values can not have any signs (+/-). Single underscores ( _ ) between numbers are not significant.</p> <p>Example 2#1111_1111 or 2#11111111 (decimal 255) 2#1110_0000 or 2#11100000 (decimal 224)</p>
<b>Base 8 literals</b>	<p>Base 8 literals are used to input whole number values into the octo system. The base must be denoted using the prefix 8#. The values can not have any signs (+/-). Single underscores ( _ ) between numbers are not significant.</p> <p>Example 8#3_77 or 8#377 (decimal 255) 8#34_0 or 8#340 (decimal 224)</p>
<b>Binary Connections</b>	<p>Connections between FFB outputs and inputs with the data type BOOL.</p>
<b>Bitsequence</b>	<p>A data element, which consists of one or more bits.</p>
<b>BOOL</b>	<p>BOOL stands for the data type "boolean". The length of the data element is 1 bit (occupies 1 byte in the memory). The value range for the variables of this data type is 0 (FALSE) and 1 (TRUE).</p>
<b>Bridge</b>	<p>A bridge is a device, which connects networks. It enables communication between nodes on two networks. Each network has its own token rotation sequence - the token is not transmitted via the bridge.</p>
<b>BYTE</b>	<p>BYTE stands for the data type "bit sequence 8". Entries are made as base 2 literal, base 8 literal or base 16 literal. The length of the data element is 8 bits. A numerical value range can not be assigned to this data type.</p>

---

**C**

<b>Clipboard</b>	The clipboard is a temporary memory for cut or copied objects. These objects can be entered in sections. The contents of the clipboard are overwritten with each new cut or copy.
<b>Coil</b>	A coil is a LD element which transfers the status of the horizontal short on its left side, unchanged, to the horizontal short on its right side. In doing this, the status is saved in the relevant variable/direct address.
<b>Compact format (4:1)</b>	The first digit (the Reference) is separated from the address that follows by a colon (:), where the leading zeros are not specified.
<b>Constants</b>	Constants are Unlocated variables, which are allocated a value that cannot be modified by the logic program (write protected).
<b>Contact</b>	A contact is a LD element, which transfers a status on the horizontal link to its right side. This status comes from the boolean AND link of the status of the horizontal link on the left side, with the status of the relevant variable/direct address. A contact does not change the value of the relevant variable/direct address.

---

**D**

<b>Data transfer settings</b>	Settings which determine how information is transferred from your programming device to the PLC.
<b>Data Types</b>	<p>The overview shows the data type hierarchy, as used for inputs and outputs of functions and function blocks. Generic data types are denoted using the prefix "ANY".</p> <ul style="list-style-type: none"><li>• ANY_ELEM<ul style="list-style-type: none"><li>• ANY_NUM<ul style="list-style-type: none"><li>• ANY_REAL (REAL)</li><li>• ANY_INT (DINT, INT, UDINT, UINT)</li></ul></li><li>• ANY_BIT (BOOL, BYTE, WORD)</li><li>• TIME</li></ul></li><li>• System Data types (IEC Extensions)</li><li>• Derived (from "ANY" data types)</li></ul>

---

<b>DCP I/O drop</b>	A remote network with a super-ordinate PLC can be controlled using a Distributed Control Processor (D908). When using a D908 with remote PLC, the super-ordinate PLC considers the remote PLC as a remote I/O drop. The D908 and the remote PLC communicate via the system bus, whereby a high performance is achieved with minimum effect on the cycle time. The data exchange between the D908 and the super-ordinate PLC takes place via the remote I/O bus at 1.5Mb per second. A super-ordinate PLC can support up to 31 D908 processors (addresses 2-32).
<b>DDE (Dynamic Data Exchange)</b>	The DDE interface enables a dynamic data exchange between two programs in Windows. The user can also use the DDE interface in the extended monitor to invoke their own display applications. With this interface, the user (i.e. the DDE client) can not only read data from the extended monitor (DDE server), but also write data to the PLC via the server. The user can therefore alter data directly in the PLC, while monitoring and analyzing results. When using this interface, the user can create their own "Graphic Tool", "Face Plate" or "Tuning Tool" and integrate into the system. The tools can be written in any language, i.e. Visual Basic, Visual C++, which supports DDE. The tools are invoked, when the user presses one of the buttons in the Extended Monitor dialog field. Concept Graphic Tool: Configuration signals can be displayed as a timing diagram using the DDE connection between Concept and Concept Graphic Tool.
<b>Declaration</b>	Mechanism for specifying the definition of a language element. A declaration usually covers the connection of an identifier to a language element and the assignment of attributes such as data types and algorithms.
<b>Definitions file (Concept-EFB)</b>	The definitions file contains general descriptive information on the selected EFB and its formal parameters.
<b>Derived Data Type</b>	Derived data types are data types, which are derived from Elementary Data Types and/or other derived data types. The definition of derived data types is found in the Concept data type editor. A distinction is made between global data types and local data types.
<b>Derived Function Block (DFB)</b>	A derived function block represents the invocation of a derived function block type. Details of the graphic form of the invocation can be found in the "Functional block (instance)". In contrast to the invocation of EFB types, invocations of DFB types are denoted by double vertical lines on the left and right hand side of the rectangular block symbol. The body of a derived function block type is designed using FBD language, LD language, ST language, IL language, however, this is only the case in the current version of the programming system. Furthermore, derived functions can not yet be defined in the current version. A distinction is made between local and global DFBs.

<b>Device Address</b>	The device address is used to uniquely denote a network device in the routing path. The address is set on the device directly, e.g. using the rotary switch on the back of the modules.
<b>DFB Code</b>	The DFB code is the section's DFB code, which can be executed. The size of the DFB code is mainly dependant upon the number of blocks in the section.
<b>DFB instance data</b>	The DFB instance data is internal data from the derived function block used in the program.
<b>DINT</b>	DINT stands for the data type "double length whole number (double integer)". Entries are made as integer literal, base 2 literal, basis 8 literal or base 16 literal. The length of the data element is 32 bits. The value range for variables of this datatype reaches from $-2 \exp (31)$ to $2 \exp (31) -1$ .
<b>Direct Representation</b>	A method of displaying variables in the PLC program, from which the assignment to the logical memory can be directly - and indirectly to the physical memory - derived.
<b>Document Window</b>	A window within an application window. Several document windows can be open at the same time in an application window. However, only one document window can ever be active. Document windows in Concept are, for example, sections, the message window, the reference data editor and the PLC configuration.
<b>DP (PROFIBUS)</b>	DP = Remote Peripheral
<b>Dummy</b>	An empty file, which consists of a text heading with general file information, such as author, date of creation, EFB designation etc. The user must complete this dummy file with further entries.
<b>DX Zoom</b>	This property enables the user to connect to a programming object, to monitor and, if necessary change, its data value.

---

**E**

<b>EFB code</b>	The EFB code is the section's EFB code, which can be executed. In addition the used EFBs count in DFBs.
<b>Elementary functions/ function blocks (EFB)</b>	Identifier for Functions or Function blocks, whose type definitions are not formulated in one of the IEC languages, i.e. whose body for example can not be modified with the DFB editor (Concept-DFB). EFB types are programmed in "C" and are prepared in a pre-compiled form using libraries.

---

<b>EN/ENO (Enable / Error signal)</b>	If the value of EN is equal to "0" when the FFB is invoked, the algorithms that are defined by the FFB will not be executed and all outputs keep their previous values. The value of ENO is in this case automatically set to "0". If the value of EN is equal to "1", when the FFB is invoked, the algorithms which are defined by the FFB will be executed. After the error-free execution of these algorithms, the value of ENO is automatically set to "1". If an error occurs during the execution of these algorithms, ENO is automatically set to "0". The output behavior of the FFB is independent of whether the FFBs are invoked without EN/ENO or with EN=1. If the EN/ENO display is switched on, it is imperative that the EN input is switched on. Otherwise, the FFB is not executed. The configuration of EN and ENO is switched on or off in the Block Properties dialog box. The dialog box can be invoked with the <b>Objects</b> → <b>Properties...</b> menu command or by double-clicking on the FFB.
<b>Error</b>	If an error is recognized during the processing of a FFB or a step (e.g. unauthorized input values or a time error), an error message appears, which can be seen using the <b>Online</b> → <b>Event Viewer...</b> menu command. For FFBs, the ENO output is now set to "0".
<b>Evaluation</b>	The process, through which a value is transmitted for a Function or for the output of a Function block during Program execution.

---

## F

<b>FFB (Functions/ Function blocks)</b>	Collective term for EFB (elementary functions/function blocks) and DFB (Derived function blocks)
<b>Field variables</b>	A variable, which is allocated a defined derived data type with the key word ARRAY (field). A field is a collection of data elements with the same data type.
<b>FIR Filter</b>	(Finite Impulse Response Filter) a filter with finite impulse answer
<b>Formal parameters</b>	Input / Output parameters, which are used within the logic of a FFB and led out of the FFB as inputs/outputs.
<b>Function (FUNC)</b>	A program organization unit, which supplies an exact data element when processing. a function has no internal status information. Multiple invocations of the same function using the same input parameters always supply the same output values. Details of the graphic form of the function invocation can be found in the "Functional block (instance)". In contrast to the invocation of the function blocks, function invocations only have a single unnamed output, whose name is the same as the function. In FBD each invocation is denoted by a unique number via the graphic block, this number is automatically generated and can not be altered.

**Function block (Instance) (FB)**

A function block is a program organization unit, which correspondingly calculates the functionality values that were defined in the function block type description, for the outputs and internal variable(s), if it is invoked as a certain instance. All internal variable and output values for a certain function block instance remain from one function block invocation to the next. Multiple invocations of the same function block instance with the same arguments (input parameter values) do not therefore necessarily supply the same output value(s).

Each function block instance is displayed graphically using a rectangular block symbol. The name of the function block type is stated in the top center of the rectangle. The name of the function block instance is also stated at the top, but outside of the rectangle. It is automatically generated when creating an instance, but, depending on the user's requirements, it can be altered by the user. Inputs are displayed on the left side of the block and outputs are displayed on the right side. The names of the formal input/output parameters are shown inside the rectangle in the corresponding places.

The above description of the graphic display is especially applicable to the function invocation and to DFB invocations. Differences are outlined in the corresponding definitions.

**Function Block Dialog (FBD)**

One or more sections, which contain graphically displayed networks from Functions, Function blocks and Connections.

**Function block type**

A language element, consisting of: 1. the definition of a data structure, divided into input, output and internal variables; 2. a set of operations, which are performed with elements of the data structure, when a function block type instance is invoked. This set of operations can either be formulated in one of the IEC languages (DFB type) or in "C" (EFB type). A function block type can be instanced (invoked) several times.

**Function Number**

The function number is used to uniquely denote a function in a program or DFB. The function number can not be edited and is automatically assigned. The function number is always formed as follows: .n.m

n = section number (current number)

m = Number of the FFB object in the section (current number)

**G**

<b>Generic Data Type</b>	A data type, which stands in place of several other data types.
<b>Generic literals</b>	If the literal's data type is not relevant, simply specify the value for the literal. If this is the case, Concept automatically assigns the literal a suitable data type.
<b>Global Data</b>	Global data are Unlocated variables.
<b>Global derived data types</b>	Global derived data types are available in each Concept project and are occupied in the DFB directory directly under the Concept directory.
<b>Global DFBs</b>	Global DFBs are available in each Concept project. The storage of the global DFBs is dependant upon the settings in the CONCEPT.INI file.
<b>Global macros</b>	Global macros are available in each Concept project and are occupied in the DFB directory directly under the Concept directory.
<b>Groups (EFBs)</b>	Some EFB libraries (e.g. the IEC library) are divided into groups. This facilitates EFB location especially in expansive libraries.

---

**H**

<b>Host Computer</b>	Hardware and software, which support programming, configuring, testing, operating and error searching in the PLC application as well as in a remote system application, in order to enable source documentation and archiving. The programming device can also be possibly used for the display of the process.
----------------------	---

---

**I**

<b>I/O Map</b>	The I/O and expert modules from the various CPUs are configured in the I/O map.
<b>Icon</b>	Graphical representation of different objects in Windows, e.g. drives, application programs and document windows.
<b>IEC 61131-3</b>	International standard: Programmable Logic Controls - Part 3: Programming languages.
<b>IEC Format (QW1)</b>	<p>There is an IEC type designation in initial position of the address, followed by the five-figure address.</p> <ul style="list-style-type: none"><li>• %0x12345 = %Q12345</li><li>• %1x12345 = %I12345</li><li>• %3x12345 = %IW12345</li><li>• %4x12345 = %QW12345</li></ul>
<b>IEC name conventions (identifier)</b>	<p>An identifier is a sequence of letters, numbers and underscores, which must begin with either a letter or underscore (i.e. the name of a function block type, an instance, a variable or a section). Letters of a national typeface (i.e.: ö, ü, é, ð) can be used, except in project and DFB names.</p> <p>Underscores are significant in identifiers; e.g. "A_BCD" and "AB_CD" are interpreted as two separate identifiers. Several leading and multiple successive underscores are not allowed.</p> <p>Identifiers should not contain any spaces. No differentiation is made between upper and lower case, e.g. "ABCD" and "abcd" are interpreted as the same identifier. Identifiers should not be Keywords.</p>
<b>IEC Program Memory</b>	The IEC memory consists of the program code, EFB code, the section data and the DFB instance data.
<b>IIR Filter</b>	(Infinite Impulse Response Filter) a filter with infinite impulse answer
<b>Initial step</b>	The first step in a sequence. A step must be defined as an initial step for each sequence. The sequence is started with the initial step when first invoked.
<b>Initial value</b>	The value, which is allocated to a variable when the program is started. The values are assigned in the form of literals.



---

**Input bits (1x references)** The 1/0 status of the input bits is controlled via the process data, which reaches from an input device to the CPU.

**Note:** The x, which follows the initial reference type number, represents a five-figure storage location in the user data memory, i.e. the reference 100201 signifies an output or marker bit at the address 201 in the State RAM.

**Input parameter (Input)** Upon invocation of a FFB, this transfers the corresponding argument.

**Input words (3x references)** An input word contains information, which originates from an external source and is represented by a 16 bit number. A 3x register can also contain 16 sequential input bits, which were read into the register in binary or BCD (binary coded decimal) format. Note: The x, which follows the initial reference type number, represents a five-figure storage location in the user data memory, i.e. the reference 300201 signifies an input word at the address 201 in the State RAM.

**Input/output marker bits (0x references)** An input/output marker bit can be used to control real output data using an output unit of the control system, or to define one or more discrete outputs in the state RAM. Note: The x, which follows the initial reference type number, represents a five-figure storage location in the user data memory, i.e. the reference 000201 signifies an output or marker bit at the address 201 in the State RAM.

**Instance Name** An identifier, which belongs to a certain function block instance. The instance name is used to clearly denote a function block within a program organization unit. The instance name is automatically generated, but it can be edited. The instance name must be unique throughout the whole program organization unit, and is not case sensitive. If the name entered already exists, you will be warned and you will have to choose another name. The instance name must comply with the IEC name conventions otherwise an error message appears. The automatically generated instance name is always formed as follows: FBI\_n\_m

FBI = Function Block Instance  
n = section number (current number)  
m = Number of the FFB object in the section (current number)

**Instancing** Generating an Instance.

<b>Instruction (IL)</b>	Instructions are the "commands" of the IL programming language. Each instruction begins on a new line and is performed by an operator with a modifier if necessary, and if required for the current operation, by one or more operands. If several operands are used, they are separated by commas. A character can come before the instruction, which is then followed by a colon. The commentary must, where available, be the last element of the line.
<b>Instruction (LL984)</b>	When programming electrical controls, the user should implement operation-coded instructions in the form of picture objects, which are divided into a recognizable contact form. The designed program objects are, on a user level, converted to computer usable OP codes during the download process. The OP codes are decoded in the CPU and processed by the firmware functions of the controller in a way that the required control is implemented.
<b>Instruction (ST)</b>	Instructions are the "commands" of the ST programming language. Instructions must be concluded by semicolons. Several instructions can be entered in one line (separated by semicolons).
<b>Instruction list (IL)</b>	IL is a text language according to IEC 1131, which is shown in operations, i.e. conditional or unconditional invocations of Functions blocks and Functions, conditional or unconditional jumps etc. through instructions.
<b>INT</b>	INT stands for the data type "whole number (integer)". Entries are made as integer literal, base 2 literal, basis 8 literal or base 16 literal. The length of the data element is 16 bits. The value range for variables of this datatype reaches from $-2 \exp (15) - 1$ .
<b>Integer literals</b>	Integer literals are used to input whole number values into the decimal system. The values can have a preceding sign (+/-). Single underscores ( _ ) between numbers are not significant.  Example -12, 0, 123_456, +986
<b>INTERBUS (PCP)</b>	The new INTERBUS (PCP) I/O drop type is entered into the Concept configurator, to allow use of the INTERBUS PCP channel and the INTERBUS process data pre-processing (PDV). This I/O drop type is assigned the INTERBUS switching module 180-CRP-660-01. The 180-CRP-660-01 differs from the 180-CRP-660-00 only in the fact that it has a clearly larger I/O range in the control state RAM.
<b>Invocation</b>	The process, through which an operation is carried out.

**J**

**Jump** Element of the SFC language. Jumps are used to skip zones in the sequence.

---

**K**

**Keywords** Keywords are unique combinations of characters, which are used as special syntactical components, as defined in Appendix B of the IEC 1131-3. All keywords which are used in the IEC 1131-3 and therefore in Concept, are listed in Appendix C of the IEC 1131-3. These keywords may not be used for any other purpose, i.e. not as variable names, section names, instance names etc.

---

**L**

**Ladder Diagram (LD)** Ladder Diagram is a graphic programming dialog according to IEC1131, which is optically oriented to the "rung" of a relay contact plan.

**Ladder Logic 984 (LL)** The terms Ladder Logic and Ladder Diagram refer to the word Ladder being executed. In contrast to a circuit diagram, a ladder diagram is used by electrotechnicians to display an electrical circuit (using electrical symbols), which should show the course of events and not the existing wires, which connect the parts with each other. A usual user interface for controlling the actions of automation devices permits a Ladder Diagram interface, so that electrotechnicians do not have to learn new programming languages to be able to implement a control program. The structure of the actual Ladder Diagram enables the connection of electric elements in such a way that generates a control output, which is dependant upon a logical power flow through used electrical objects, which displays the previously requested condition of a physical electrical device. In simple form, the user interface is a video display processed by the PLC programming application, which sets up vertical and horizontal grid, in which programming objects are classified. The diagram contains the power grid on the left side, and when connected to activated objects, the power shifts from left to right.

**Landscape** Landscape means that when looking at the printed text, the page is wider than it is high.

<b>Language Element</b>	Every basic element in one of the IEC programming languages, e.g. a step in SFC, a function block instance in FBD or the initial value of a variable.
<b>Library</b>	Collection of software objects, which are intended for re-use when programming new projects, or even building new libraries. Examples are the libraries of the Elementary function block types. EFB libraries can be divided up into Groups.
<b>Link</b>	A control or data flow connection between graphical objects (e.g. steps in the SFC Editor, function blocks in the FBD Editor) within a section, represented graphically as a line.
<b>Literals</b>	Literals are used to provide FFB inputs, and transition conditions etc using direct values. These values can not be overwritten by the program logic (read only). A distinction is made between generic and standardized literals. Literals are also used to allocate a constant, a value or a variable an initial value. Entries are made as base 2 literal, base 8 literal, basis 16 literal, integer literal, real literal or real literal with exponent.
<b>Local derived data types</b>	Local derived data types are only available in a single Concept project and the local DFBs and are placed in the DFB directory under the project directory.
<b>Local DFBs</b>	Local DFBs are only available in a single Concept project and are placed in the DFB directory under the project directory.
<b>Local Link</b>	The local network is the network, which connects the local nodes with other nodes either directly or through bus repeaters.
<b>Local macros</b>	Local macros are only available in a single Concept project and are placed in the DFB directory under the project directory.
<b>Local network nodes</b>	The local node is the one, which is currently being configured.
<b>Located variable</b>	<p>A state RAM address (reference addresses 0x, 1x, 3x,4x) is allocated to located variables. The value of these variables is saved in the state RAM and can be modified online using the reference data editor. These variables can be addresses using their symbolic names or their reference addresses.</p> <p>All inputs and outputs of the PLC are connected to the state RAM. The program can only access peripheral signals attached to the PLC via located variables. External access via Modbus or Modbus Plus interfaces of the PLC, e.g. from visualization systems, is also possible via located variables.</p>

**M**

---

<b>Macro</b>	<p>Macros are created with the help of the Concept DFB software. Macros are used to duplicate frequently used sections and networks (including their logic, variables and variable declaration). A distinction is made between local and global macros.</p> <p>Macros have the following properties:</p> <ul style="list-style-type: none"><li>• Macros can only be created in the FBD and LD programming languages.</li><li>• Macros only contain one section.</li><li>• Macros can contain a section of any complexity.</li><li>• In programming terms, there is no difference between an instanced macro, i.e. a macro inserted into a section and a conventionally created section.</li><li>• DFB invocation in a macro</li><li>• Declaring variables</li><li>• Using macro-specific data structures</li><li>• Automatic transfer of the variables declared in the macro.</li><li>• Initial value for variables</li><li>• Multiple instancing of a macro in the entire program with differing variables</li><li>• The name of the section, variable names and data structure names can contain up to 10 different exchange marks (@0 to @9).</li></ul>
<b>MMI</b>	Man-Machine-Interface
<b>Multi element variables</b>	Variables to which a Derived data type defined with STRUCT or ARRAY is allocated. A distinction is made here between field variables and structured variables.

---

**N**

<b>Network</b>	A network is the collective switching of devices to a common data path, which then communicate with each other using a common protocol.
<b>Network node</b>	A node is a device with an address (1...64) on the Modbus Plus network.
<b>Node</b>	Node is a programming cell in a LL984 network. A cell/node consists of a 7x11 matrix, i.e. 7 rows of 11 elements.

---

**O**

<b>Operand</b>	An operand is a literal, a variable, a function invocation or an expression.
<b>Operator</b>	An operator is a symbol for an arithmetic or boolean operation, which is to be carried out.
<b>Output parameter (outputs):</b>	A parameter, through which the result(s) of the evaluation of a FFB is/are returned.
<b>Output/marker words (4x references)</b>	An output / marker word can be used to save numerical data (binary or decimal) in the state RAM, or to send data from the CPU to an output unit in the control system. Note: The x, which follows the initial reference type number, represents a five-figure storage location in the user data memory, i.e. the reference 400201 signifies a 16 bit output or marker word at the address 201 in the State RAM.

---

**P**

<b>Peer Cop</b>	The Peer Cop processes the token execution and the data flow between the Modbus Plus network and the PLC user logic.
<b>PLC</b>	Memory programmable controller
<b>Portrait</b>	Portrait means that the sides are larger than the width when printed.
<b>Print-out</b>	Expressions consist of operators and operands.
<b>Program</b>	The uppermost program organization unit. A program is closed on a single PLC download.
<b>Program organization unit</b>	A function, a function block, or a Program. This term can refer to either a type or an instance.
<b>Program redundancy system (Hot Standby)</b>	A redundancy system consists of two identically configured PLC machines, which communicate with one another via redundancy processors. In the case of a breakdown of the primary PLC, the secondary PLC takes over the control check. Under normal conditions, the secondary PLC does not take over the control function, but checks the status information, in order to detect errors.

---

---

<b>Project</b>	General description for the highest level of a software tree structure, which specifies the super-ordinate project name of a PLC application. After specifying the project name you can save your system configuration and your control program under this name. All data that is created whilst setting up the configuration and program, belongs to this super-ordinate project for this specific automation task. General description for the complete set of programming and configuration information in the project database, which represents the source code that describes the automation of a system.
<b>Project database</b>	The database in the host computer, which contains the configuration information for a project.
<b>Prototype file (Concept-EFB)</b>	The prototype file contains all the prototypes of the assigned functions. In addition, if one exists, a type definition of the internal status structure is specified.

---

## R

<b>REAL</b>	REAL stands for the data type "floating point number". The entry can be real-literal or real-literal with an exponent. The length of the data element is 32 bits. The value range for variables of this data type extends from 8.43E-37 to 3.36E+38.
-------------	--

<p><b>Note:</b> Dependent on the mathematical processor type of the CPU, different ranges within this permissible value range cannot be represented. This applies to values that are approaching ZERO and for values that approach INFINITY. In these cases NAN (<b>Not A Number</b>) or INF (<b>INFinite</b>) will be displayed in the animation mode instead of a number value.</p>
---

<b>Real literals</b>	Real literals are used to input floating point values into the decimal system. Real literals are denoted by a decimal point. The values can have a preceding sign (+/-). Single underscores ( _ ) between numbers are not significant.
----------------------	--

### Example

-12.0, 0.0, +0.456, 3.14159\_26

<b>Real literals with exponents</b>	Real literals with exponents are used to input floating point values into the decimal system. Real literals with exponents are identifiable by a decimal point. The exponent indicates the power of ten, with which the existing number needs to be multiplied in order to obtain the value to be represented. The base can have a preceding negative sign (-). The exponent can have a preceding positive or negative sign (+/-). Single underscores ( _ ) between numbers are not significant. (Only between numbers, not before or after the decimal point and not before or after "E", "E+" or "E-")
-------------------------------------	--

Example  
-1.34E-12 or -1.34e-12  
1.0E+6 or 1.0e+6  
1.234E6 or 1.234e6

**Reference** Every direct address is a reference that begins with an indicator, which specifies whether it is an input or an output and whether it is a bit or a word. References that begin with the code 6, represent registers in the extended memory of the state RAM.  
0x range = Coils  
1x range = Discrete inputs  
3x range = Input registers  
4x range = Output registers  
6x range = Register in the extended memory

**Note:** The x, which follows each initial reference type number, represents a five-figure storage location in the user data memory, i.e. the reference 400201 signifies a 16 bit output or marker word at the address 201 in the State RAM.

**Register in the extended memory (6x-reference)** 6x references are holding registers in the extended memory of the PLC. They can only be used with LL984 user programs and only with a CPU 213 04 or CPU 424 02.

**Remote Network (DIO)** Remote programming in the Modbus Plus network enables maximum performance when transferring data and dispenses of the need for connections. Programming a remote network is simple. Setting up a network does not require any additional ladder logic to be created. All requirements for data transfer are fulfilled via corresponding entries in the Peer Cop Processor.

**RIO (Remote I/O)** Remote I/O indicates a physical location of the I/O point controlling devices with regard to the CPU controlling them. Remote inp./outputs are connected to the controlling device via a twisted communication cable.

**RTU-Mode** Remote Terminal Unit  
The RTU mode is used for communication between the PLC and an IBM compatible personal computer. RTU works with 8 data bits.

**Runtime error** Errors, which appear during program processing on the PLC, in SFC objects (e.g. Steps) or FFBS. These are, for example, value range overflows with figures or timing errors with steps.



**S**

<b>SA85 module</b>	The SA85 module is a Modbus Plus adapter for IBM-AT or compatible computers.
<b>Scan</b>	A scan consists of reading the inputs, processing the program logic and outputting the outputs.
<b>Section</b>	<p>A section can for example be used to describe the mode of functioning of a technological unit such as a motor.</p> <p>A program or DFB consists of one or more sections. Sections can be programmed with the IEC programming languages FBD and SFC. Only one of the named programming languages may be used within a section at any one time.</p> <p>Each section has its own document window in Concept. For reasons of clarity, it is however useful to divide a very large section into several small ones. The scroll bar is used for scrolling within a section.</p>
<b>Section Code</b>	Section Code is the executable code of a section. The size of the Section Code is mainly dependent upon the number of blocks in the section.
<b>Section Data</b>	Section data is the local data in a section such as e.g. literals, connections between blocks, non-connected block inputs and outputs, internal status memory of EFBs.
	<div style="border: 1px solid black; padding: 5px;"><b>Note:</b> Data which appears in the DFBs of this section is not section data.</div>
<b>Separator Format (4:00001)</b>	The first digit (the reference) is separated from the five figure address that follows by a colon (:).
<b>Sequence language (SFC)</b>	The SFC Language Elements enable a PLC program organization unit to be divided up into a number of Steps and Transitions, which are connected using directional Links. A number of actions belong to each step, and transition conditions are attached to each transition.
<b>Serial Connections</b>	With serial connections (COM) the information is transferred bit by bit.
<b>Source code file (Concept-EFB)</b>	The source code file is a normal C++ source file. After executing the <b>Library</b> → <b>Create files</b> menu command, this file contains an EFB-code frame, in which you have to enter a specific code for the EFB selected. To do this invoke the <b>Objects</b> → <b>Source</b> menu command.
<b>Standard Format (400001)</b>	The five figure address comes directly after the first digit (the reference).

**Standardized literals** If you would like to manually determine a literal's data type, this may be done using the following construction: 'Data type name'#'value of the literal'.

Example

INT#15 (Data type: integer, value: 15),  
BYTE#00001111 (Data type: byte, value: 00001111)  
REAL#23.0 (Data type: real, value: 23.0)

To assign the data type REAL, the value may also be specified in the following manner: 23.0.

Entering a comma will automatically assign the data type REAL.

**State RAM** The state RAM is the memory space for all variables, which are accessed via References (Direct representation) in the user program. For example, discrete inputs, coils, input registers, and output registers are situated in the state RAM.

**Status Bits** For every device with global inputs or specific inp./outputs of Peer Cop data, there is a status bit. If a defined group of data has been successfully transferred within the timeout that has been set, the corresponding status bit is set to 1. If this is not the case, this bit is set to 0 and all the data belonging to this group is deleted (to 0).

**Step** SFC-language element: Situation, in which the behavior of a program occurs, regarding its inputs and outputs of those operations which are defined by the actions belonging to the step.

**Step name** The step name is used to uniquely denote a step in a program organization unit. The step name is generated automatically, but it can be edited. The step name must be unique within the entire program organization unit, otherwise an error message will appear.

The automatically generated step name is always formed as follows: S\_n\_m

S = step

n = section number (current number)

m = Number of the step in the section (current number)

**Structured text (ST)** ST is a text language according to IEC 1131, in which operations, e.g. invocations of Function blocks and Functions, conditional execution of instructions, repetitions of instructions etc. are represented by instructions.

**Structured variables** Variables to which a Derived data type defined with STRUCT (structure) is allocated. A structure is a collection of data elements with generally different data types (elementary data types and/or derived data types).

---

**SY/MAX** In Quantum control devices, Concept includes the providing of I/O-map SY/MAX-I/O modules for remote controlling by the Quantum PLC. The SY/MAX remote backplane has a remote I/O adapter in slot 1, which communicates via a Modicon S908 R I/O System. The SY/MAX-I/O modules are executed for you for labelling and inclusion in the I/O map of the Concept configuration.

---

**T**

**Template file (Concept-EFB)** The template file is an ASCII file with layout information for the Concept FBD Editor, and the parameters for code creation.

**TIME** TIME stands for the data type "time". The entry is time literal. The length of the data element is 32 bits. The value range for variables of this data type extends from 0 to  $2^{\text{exp}(32)}-1$ . The unit for the TIME data type is 1 ms.

**Time literals** Permissible units for times (TIME) are days (D), hours (H), minutes (M), seconds (S) and milliseconds (MS) or combinations of these. The time must be marked with the prefix t#, T#, time# or TIME#. The "overflow" of the unit with the highest value is permissible, e.g. the entry T#25H15M is allowed.

**Example**

t#14MS, T#14.7S, time#18M, TIME#19.9H, t#20.4D, T#25H15M,  
time#5D14H12M18S3.5MS

**Token** The network "token" controls the temporary possession of the transfer right via a single device. The token passes round the devices in a rotating (increasing) address sequence. All devices follow the token rotation and can receive all the possible data that is sent with it.

**Total IEC memory** The total IEC memory consists of the IEC program memory and the global data.

**Traffic Cop** The traffic cop is an IO map, which is generated from the user-IO map. The traffic cop is managed in the PLC and in addition to the user IO map, contains e.g. status information on the I/O stations and modules.

**Transition** The condition, in which the control of one or more predecessor steps passes to one or more successor steps along a directed link.

---

**U**

- UDEFB** User-defined elementary functions/function blocks  
Functions or function blocks, which were created in the C programming language, and which Concept provides in libraries.
- UDINT** UDINT stands for the data type "unsigned double integer". Entries are made as integer literal, base 2 literal, basis 8 literal or base 16 literal. The length of the data element is 32 bits. The value range for variables of this data type extends from 0 to  $2^{\text{exp}(32)}-1$ .
- UINT** UINT stands for the data type "unsigned integer". Entries are made as integer literal, base 2 literal, basis 8 literal or base 16 literal. The length of the data element is 16 bits. The value range for variables of this data type extends from 0 to  $(2^{\text{exp } 16})-1$ .
- Unlocated variable** Unlocated variables are not allocated a state RAM address. They therefore do not occupy any state RAM addresses. The value of these variables is saved in the internal system and can be changed using the reference data editor. These variables are only addressed using their symbolic names.
- Signals requiring no peripheral access, e.g. intermediate results, system tags etc., should be primarily declared as unlocated variables.
- 

**V**

- Variables** Variables are used to exchange data within a section, between several sections and between the program and the PLC.  
Variables consist of at least one variable name and one data type.  
If a variable is assigned a direct address (reference), it is called a located variable.  
If the variable has no direct address assigned to it, it is called an unlocated variable.  
If the variable is assigned with a derived data type, it is called a multi element variable.  
There are also constants and literals.
-

**W**

- Warning** If a critical status is detected during the processing of a FFB or a step (e.g. critical input values or an exceeded time limit), a warning appears, which can be seen using the **Online** → **Event Viewer...** menu command. For FFBs, the ENO remains set to "1".
- WORD** WORD stands for the data type "bit sequence 16". Entries are made as base 2 literal, base 8 literal or base 16 literal. The length of the data element is 16 bits. A numerical value range can not be assigned to this data type.
-



---

## Index



### Symbols

=> Assignment, 306, 354  
•General information about online functions, 517  
'SFCSTEP\_STATE' variable, 223  
'SFCSTEP\_TIMES' variable, 222  
'Step'-variable, 223

### A

Access Rights, 627, 634, 635  
Action, 223  
Action variable, 224  
Actions  
    Process, 241  
Activate dialogs, 86  
Actual parameters  
    FBD, 173  
    LD, 201  
Alias designations  
    step, 248  
    transition, 248  
Alternative branch, 230  
Alternative connection, 232  
Animation, 495, 615, 617  
    General information, 555  
    IEC section, 556  
    IL, 315, 318  
    LL984 section, 557  
    Section, 555  
    FBD, 181  
    LD, 210  
    SFC, 252, 255  
ANY Outputs, 351  
Archive  
    DFB, 610  
    EFB, 610  
    project, 610  
ASCII message editor, 499, 501, 506  
    Combination mode, 514  
    Control code, 505  
    Direct mode, 514  
    Flush (buffer), 507  
    Generals, 502  
    How to continue after getting a warning, 513  
    How to Use, 510  
    Message Number, 511  
    Message text, 512  
    Offline mode, 514  
    Repeat, 508  
    Simulation text, 512  
    Spaces, 505  
    Text, 503  
    User interface, 509, 510  
    Variables, 504  
ASCII messages, 52, 85  
Assign instructions  
    ST, 336  
Atrium - INTERBUS controller, 806, 810  
Atrium configuration example  
    INTERBUS controller, 804

- Atrium first startup
  - DOS Loader, 940
  - EXECLoader, 922
  - Modbus Plus, 922, 940
- Available functions in OFFLINE and ONLINE modes, 69
  
- B**
- Backplane Expander
  - Edit I/O Map, 92
  - Error handling, 93
  - Generals, 92
- Backplane Expander Config
  - Configure, 91
- Block call up
  - IL, 301
  - ST, 350
  
- C**
- Call
  - FFB, 308
  - DFB, 300
  - FFB, 300
- Chain jump, 229
- Chain loop, 229
- Change
  - coil, LD, 206
  - contact, LD, 206
  - FFB, FBD, 177
  - FFB, LD, 206
- Change, set PLC password, 539
- Changing signal states of a Located variable
  - Reference data editor, 491
- Close Column
  - LL984, 372
- Closer
  - LD, 192
- Code generation
  - IL, 312
  - ST, 358
- Code generation
  - FBD, 180
  - LD, 209
- Coil
  - change, LD, 206
  - replace, LD, 206
- Coil - negated
  - LD, 194
- Coil – negative edge
  - LD, 195
- Coil – positive edge
  - LD, 194
- Coil - reset
  - LD, 195
- Coil - set
  - LD, 195
- Coils
  - LD, 193
- Cold start, 35
- Color definition
  - INI file, 960
- Comments
  - Data type editor, 481
  - Derived data type, 481
- Communication, 14
- Compact configuration
  - RTU extension, 99
- Compact configuration example
  - Compact controller, 799
- Compact first startup
  - DOS Loader, 903, 937
  - EXECLoader, 884, 918
  - Modbus, 884, 903
  - Modbus Plus, 918, 937
- Concept DFB, 389, 425
- Concept ModConnect, 841
  - Integrating new Modules, 845
  - Removing modules, 846
  - Use of Third Party Modules in Concept, 847
- Concept PLCSIM32, 617
- Concept Security, 625, 626, 627, 634, 635
- Concept SIM, 615
- CONCEPT.INI, 953
  - general, 954
  - LD section settings, 959
  - path for global DFBs, 957
  - path for help files, 957
  - print settings, 955



- project name definition, 956
  - reading global DFBs, 957
  - register address format settings, 956
  - representation of internal data, 959
  - settings for online animation, 960
  - storage of global DFBs during upload, 957
  - variable storage settings, 956
- Configuration, 63
- General information, 65
  - Optional, 84
  - Unconditional, 71
- Configuration example - Quantum
- remote control with RIO, 735
- Configuration example Atrium
- INTERBUS controller, 804
- Configuration example Compact
- Compact controller, 799
- Configuration example Momentum
- remote I/O bus, 813
- Configuration example Quantum
- INTERBUS control, 763
  - Profibus DP controller, 777
  - Remote control with DIO, 754
  - Remote control with RIO (series 800), 743
  - SY/MAX controller, 769
  - Peer Cop, 791
- Configuration examples, 733
- Configuration extensions, 86
- Configuration in OFFLINE and ONLINE mode, 68
- General information, 69
- Configuration of Peer Cop, 793
- Configuration of various network systems, 94
- Configurator
- Ethernet I/O Scanner, 100
- Configure
- Backplane Expander Config, 91
  - INTERBUS, 95
  - RTU extension, 99
  - SoftPLC, 97
  - Ethernet, 98
  - Profibus DP, 96
- Configure Ethernet, 822, 98
- Configure INTERBUS system, 95
- Configure network systems, 86, 94
- Configure Profibus DP system, 96
- Configure SoftPLC, 97
- Connect PLC
- general information, 519
- Connecting IEC Simulator (32-bit), 530
- Constant scan, 533
- Constants, 34
- Contact
- change, LD, 206
  - replace, LD, 206
  - LD, 192, 193
- Context help, 673
- Controller status, 519
- Convert
- DFBs, 837
  - Macros, 837
  - Projects, 837
- Converting RDE templates, 489
- Conversion
- Modsoft programs, 849
- CPU selection for the PLC type, 73
- Create
- DFB, 405
  - Macro, 435
  - Program, 43
  - Project, 43
  - FFB, FBD, 176
  - FFB, LD, 205
- Creating a program
- IL, 319
- Cyclical setting of variables
- Reference data editor, 492
- ## D
- Data exchange between nodes on the Modbus Plus network, 87
- Data flow, 207
- FBD, 178
- Data Protection, 51
- Data protection in the state RAM, 88

- Data type editor, 465, 467, 468
  - Comments, 481
  - Elements, 474
  - Short Cut Keys, 693
  - Syntax, 473
  - key words, 475
  - separators, 480
  - use of memory, 482
  - Names, 479
- Declaration of variables, 448
- Declare
  - Actions, 241
  - Step properties, 239
  - transition, 246
- Defining the LD contact connection
  - settings in the INI file, 959
- Defining the number of LD columns/fields
  - settings in the INI file, 959
- Delete
  - DFB, 611
  - Macro, 611
  - Project, 611
- Deleting memory zones from the PLC, 535
- Deleting PLC contents, 535
- Derived data type, 465, 467, 468
  - Elements, 474
  - Export, 567
  - Syntax, 473
  - Comments, 481
  - Names, 479
  - global, 471
  - key words, 475
  - local, 471
  - separators, 480
  - use of memory, 482
  - Use, 484
- Derived Function Block, 392
  - LD, 198
  - FBD, 171
- DFB, 389, 392
  - archive, 610
  - call, 300
  - context sensitive help, 403
  - Create, 405
  - Delete, 611
  - Documentation, 601
  - FBD, 171
  - global, 394
  - invocation, 302, 351
  - LD, 198
  - local, 394
  - Protect, 635
  - Convert, 837
- Diagnosis
  - Transition diagnosis, 260
- Diagnostics viewer, 558
- Dialog boxes, 668
- Dialog interaction
  - LL984, 369
- Direct addresses, 34
- Document section options, 605
- Documentation
  - Contents, 602
  - DFB, 601
  - Keywords, 608
  - Macro, 601
  - Project, 601
  - layout, 603
- DOS Loader
  - Atrium first startup, 940
  - Compact first startup, 903, 937
  - Momentum first startup, 906, 909, 943, 946
  - Quantum first startup, 900, 934
  - Startup when using Modbus, 899
  - Startup when using Modbus Plus, 933
- Download changes, 549
- Driver for 16 bit application capability with Windows 98/2000/NT
  - Virtual MBX Driver, 866
- Driver for connection between ModConnect Host interface adapters and 32 bit applications with Windows 98/2000/NT
  - MBX-Treiber, 867
- Driver for Modbus Plus Function via TCP/IP
  - Ethernet MBX Driver, 869
- Driver for Remote Operation
  - Remote MBX Driver, 868
- DTY, 465, 467, 468
- DX Zoom
  - LL984, 374

**E**

- Edit
  - Actions, 241
  - LL984, 368, 371
  - SFC, 236
  - Step properties, 239
  - SFC, 235
  - transition, 246
- Edit I/O Map
  - Backplane Expander, 92
- Editing local drop, 736, 744, 755, 765, 770, 806, 814, 833
- Editing Networks
  - LL984, 373
- Editing remote 800 drop, 751
- Editing remote drop, 740, 748, 759, 774, 810
- Editing remote drops, 818
- Editors, 9
- EFB
  - archive, 610
  - FBD, 169
  - LD, 196
- Elementary Function
  - FBD, 169
  - LD, 196
- Elementary Function Block
  - FBD, 170
  - LD, 197
- Elements
  - Data type editor, 474
  - Derived Data Type, 474
- EN
  - FBD, 172
  - LD, 200
- ENO
  - FBD, 172
  - LD, 200
- EQUAL, 519
- Equation network
  - LL984, 378, 379
- Equation network, Syntax and Semantics
  - LL984, 383
- Error handling
  - Backplane Expander, 93
- Establishing the hardware connection
  - Modbus Plus presettings, 871
  - Modbus presettings, 876
- Ethernet, 530
- Ethernet I/O Scanner
  - Configurator, 100
  - How to use the Ethernet / I/O Scanner, 104
- Ethernet bus system
  - Momentum configuration example, 821
- Ethernet bus system (Momentum), 822
- Ethernet MBX Driver
  - Driver for Modbus Plus Function via TCP/IP, 869
- Ethernet with Atrium, 99
- ethernet with Momentum, 99
- Ethernet with Quantum, 98
- Example
  - Profibus DP controller, 778
  - INTERBUS Controller with Atrium, 805
- Example of hardware configuration
  - Remote control with RIO (Series 800), 743
  - Compact controller, 799
  - Ethernet bus system, 821
  - INTERBUS control, 763
  - INTERBUS controller, 804
  - Profibus DP controller, 777
  - remote control with DIO, 754
  - remote control with RIO, 735
  - remote I/O bus, 813
  - SY/MAX controller, 769
- Example to Peer Cop, 791
- Examples of hardware configuration, 733
- Exchange Marking
  - Macro, 430
- EXEC file
  - CPU 424 02, 117
  - CPU X13 0X, 117
  - Momentum, 152
- EXEC files, 949

- EXECLoader
    - Atrium first startup, 922
    - Compact first startup, 884, 918
    - Momentum first startup, 888, 893, 925, 929
    - Quantum first startup, 880, 914
    - Startup when using Modbus, 879
    - Startup when using Modbus Plus, 913
  - Execution order
    - FBD, 177
  - Execution sequence
    - LD, 207
    - Section, 38
  - Export, 561
    - Derived Data Type, 567
    - PLC Configuration, 597
    - Section, 564
    - Variable, 567
    - general information, 563
    - PLC configuration, 596
  - Exporting located variables, 457
  - Expressions
    - ST, 324
  - Extended memory, 121
- F**
- Factory Link, 594
  - FBD, 165
    - Actual parameters, 173
    - animation, 181
    - Calling a macro, 444
    - code generation, 180
    - data flow, 177, 178
    - Derived Function Blocks, 171
    - DFB, 171
    - EFB, 169
    - Elementary Function, 169
    - Elementary Function Block, 170
    - EN, 172
    - ENO, 172
    - execution order, 177
    - FFB, 169
    - Function, 169
    - Function Block, 170
    - Icon bar, 683
    - link, 172
    - loop, 178
    - online functions, 181
    - program creation, 184
    - Short Cut Keys, 695
    - Text Object, 174
    - UDEFB, 172
    - User-defined Elementary Function, 172
    - User-defined Elementary Function Block, 172
  - FFB
    - Call, 308
    - call, 300
    - change, FBD, 177
    - change, LD, 206
    - create, FBD, 176
    - create, LD, 205
    - FBD, 169
    - insert, FBD, 176
    - insert, LD, 205
    - invocation, 302, 351, 354
    - LD, 196
    - position, 176, 205
    - replace, FBD, 177
    - replace, LD, 206
  - Function
    - FBD, 169
    - LD, 196
  - Function Block
    - FBD, 170
    - LD, 197
  - Function Block language, 165
- G**
- General, 1
  - General information, 814
    - Loading a project, 547
    - Online functions, 517
    - Select process information, 543
    - connect PLC, 519
    - INTERBUS Controller, 764
    - INTERBUS Controller with Atrium, 805
    - Profibus DP Controller, 778

- General information about configuration in OFFLINE and ONLINE mode, 69
  - General information about hardware configuration, 65
  - General information about the online control panel, 533
  - General information about the PLC configuration, 66
  - General information about the reference data editor, 488
  - General to the variables editor, 448
  - Generals
    - Backplane Expander, 92
  - Generals to Peer Cop, 792
  - Generate
    - Project symbol, 671
  - Global data transfer, 795
  - Global derived data type, 471
  - Global DFB, 394
  - Global DFBs
    - defining the path, 957
    - INI file, 957
    - reading, 958
    - storing, 958
  - Global macro, 429
- ## H
- Hardware
    - performance, 639
  - Head setup, 49
  - Help, 673
  - Help files
    - defining the path, 957
  - How to use the Ethernet / I/O Scanner
    - Ethernet / I/O Scanner, 104
- ## I
- I/O map, 48, 81
  - Icon bar, 681, 682, 683, 684, 686
  - Icons, 679, 681, 682, 683, 684, 686, 687, 688, 689, 690
  - Identifier, 244
  - IEC
    - Momentum first startup, 888, 925, 943
    - IEC conformity, 707
    - IEC Hot Standby data, 77
    - IEC section
      - Animation, 556
  - IL, 261
    - Animation, 315, 318
    - Block call up, 301
    - Code generation, 312
    - Creating a program, 319
    - Instruction, 264, 265
    - List of Symbols, 687
    - Modifier, 267
    - Online functionen, 318
    - Online functions, 314, 315
    - Operands, 266
    - Operators, 269, 276
    - Short Cut Keys, 693
    - syntax check, 311
    - Tag, 272
  - IL command
    - Comments, 275
    - Compare, 293, 294, 296
    - Declaration, 273
      - call function block, 302
    - Compare, 291, 292, 295
    - DFB invocation, 302
    - Function call, 308
    - invert, 285
    - Reset, 280
    - Set, 278
    - VAR...END\_VAR, 273
  - IL operation
    - addition, 286
    - Boolean AND, 281
    - Boolean exclusive OR, 284
    - Boolean OR, 282
    - call DFB, 300
    - call function block, 300
    - download, 277
    - jump to label, 297
    - multiplication, 288
    - save, 277
    - subtraction, 287
    - division, 289

- 
- Import, 561
    - PLC Configuration, 597
    - Section, 568, 572, 583, 584, 585
    - Structured variables, 590
    - Variables, 587, 590, 594
    - general information, 563
    - PLC configuration, 596
    - section, 569, 580
    - variables, 588
  - Importing INTERBUS configuration, 810
  - Importing Profibus DP configuration, 784
  - INI file, 953
    - general, 954
    - LD section settings, 959
    - path for global DFBs, 957
    - path for help files, 957
    - print settings, 955
    - project name definition, 956
    - reading global DFBs, 957
    - register address format settings, 956
    - representation of internal data, 959
    - settings for online animation, 960
    - storage of global DFBs during upload, 957
    - variable storage settings, 956
  - Initial step, 221
  - Insert
    - FFB, FBD, 176
    - FFB, LD, 205
  - Install loadables, 48
  - Installing the EXEC file, 949
  - Installing the Modbus Plus driver
    - Windows 98/2000/NT, 865
  - Installing the SA85
    - Modbus Plus Presettings, 860, 863
    - Windows 98/2000, 860
    - Windows NT, 863
  - Instruction
    - IL, 264, 265
    - ST, 337
  - Instruction list, 261
  - INTERBUS control
    - Quantum-configuration example, 763
  - INTERBUS control with Atrium, 805
  - INTERBUS controller, 764
    - Atrium configuration example, 804
  - INTERBUS export settings in CMD, 805
  - Interface settings in Windows 95/98/2000
    - Modbus Presettings, 874
  - Interface settings in Windows NT
    - Modbus Presettings, 876
  - Invocation
    - DFB, 302, 351
    - FFB, 302, 351, 354
  - Invoke
    - Project, 671
- J**
- Jump
    - SFC, 228
- K**
- Key combinations, 679, 691, 692, 693, 695, 699, 705
  - key words
    - data type editor, 475
    - derived data type, 475
  - Keys, 679, 691, 692, 693, 695, 699, 705
- L**
- Ladder Diagram, 187
  - Ladder Logic 984, 363
  - LD, 187
    - actual parameters, 201
    - animation, 210
    - Calling a macro, 444
    - Closer, 192
    - code generation, 209
    - Coil - negated, 194
    - Coil - negative edge, 195
    - Coil - positive edge, 194
    - Coil - reset, 195
    - Coil - set, 195
    - Coils, 193
    - Contacts, 192, 193
    - Data flow, 207
    - derived function block, 198
    - EFB, 196

- 
- elementary function, 196
  - elementary function block, 197
  - EN, 200
  - ENO, 200
  - Execution sequence, 207
  - FFB, 196
  - function, 196
  - function block, 197
  - Icon bar, 686
  - link, 200
  - loops, 207
  - online functions, 210
  - Opener, 192
  - program creation, 213
  - Shortcut keys, 699
  - Text object, 203
  - UDEFB, 199
  - user-defined elementary function, 199
  - user-defined elementary function block, 199
  - Learn monitoring times
    - SFC, 257
  - Libraries, 8
  - Limitations
    - LL984, 366
  - Link
    - PLC, 518
    - FBD, 172
    - LD, 200
  - List of Symbols, 679, 687, 688
  - List of Tools, 679, 687, 688
  - Literals, 34
  - LL984, 363
    - Close Column, 372
    - Combination mode, 387
    - Dialog interaction, 369
    - Direct programming, 387
    - DX Zoom, 374
    - Edit, 368, 371
    - Editing Networks, 373
    - Equation network, 378, 379
    - Equation network, Syntax and Semantics, 383
    - List of Symbols, 688
    - Momentum first startup, 893, 909, 929, 946
    - Navigation, 368
    - Online Restriction, 369
    - Online Search, 375
    - Open Column, 372
    - Open Row, 372
    - Programming modes, 387
    - Reference Offset, 371
    - Reference Zoom, 373
    - References, 370
    - Replace References, 375
    - Requirements, 368
    - Section, 365
    - Segment, 365
    - Select, 372
    - Short Cut Keys, 705
    - Subroutines, 376
    - Trace, 375
    - Undo, 371
    - Variables, 370
  - LL984 processing
    - speed optimized, 535
  - LL984 section
    - Animation, 557
  - Load reference data, 497
  - Loadables, 78
    - CPU 424 02, 123
    - CPU X13 0X, 123
    - Atrium, 158
    - compact, 142
    - CPU 434 12, 131
    - CPU 534 14, 131
  - Loading, 548
  - Loading a project, 546
    - General information, 547
  - Loading firmware, 949
  - Local derived data type, 471
  - Local DFB, 394
  - Local macro, 429
  - Located variables
    - Changing signal states in RDE, 491
  - Lock
    - Section, 39
-

Loop

- FBD, 178
- LD, 207

**M**

Macro, 425, 428

- Calling up from SFC, 441
- Calls from FBD, 444
- Calls from LD, 444
- Create, 435
- Delete, 611
- Documentation, 601
- Exchange marking, 430
- context sensitive help, 433
- global, 429
- local, 429
- Convert, 837

Maximum supervision time, 221

MBX Driver

- Driver for connection between ModConnect Host interface adapters and 32 bit applications with Windows 98/2000/NT, 867

Memory

- Memory optimization for Compact CPUs, 139
- Memory Optimization for Quantum CPU X13 0X and 424 02, 114
- Optimize, 107, 111
- PLC-Independent Memory Optimization, 111
- Structure, 107
- memory optimization for Momentum CPUs, 149
- memory optimization for Quantum CPU 434 12 and 534 14, 128
- optimize, 110

Memory partitions, 47

Memory statistics, 544

Menu commands, 666

Minimum configuration, 47

Minimum supervision time, 222

MMS-Ethernet

- specify coupling modules, 86

Modbus

- Compact first startup, 884, 903
- Momentum first startup, 888, 893, 906, 909
- Quantum first startup, 880, 900
- Startup with DOS Loader, 899
- Startup with the EXECLoader, 879

Modbus communication, 49

Modbus network link, 522

Modbus Plus

- Atrium first startup, 922, 940
- Compact first startup, 918, 937
- Momentum first startup, 925, 929, 943, 946
- Quantum first startup, 914, 934
- Remote MBX Driver, 868
- Startup with DOS Loader, 933
- Startup with the EXECLoader, 913
- Virtual MBX Driver, 866

Modbus Plus Bridge, 528

Modbus Plus network link, 523

Modbus Plus network node, 87

Modbus Plus preferences

- installing the Modbus Plus driver in Windows 98/2000/NT, 865

Modbus Plus Presettings

- Installing the SA85, 860, 863
- Establishing the hardware connection, 871
- Startup, 859

Modbus Presettings

- Interface settings in Windows 98/2000, 874
- Interface Settings in Windows NT, 876
- Transfer problems, 877
- Establishing the hardware connection, 876
- Startup, 873

ModConnect, 841

MODIFIED, 519

Modifier

- IL, 267

Modsoft

- Conversion, 849
- Function compatibility, 858
- References, 855



- Momentum - Ethernet Bus System, 833
- Momentum - remote controller with local drop, 814
- Momentum configuration example
  - Ethernet bus system, 821
  - remote I/O bus, 813
- Momentum first startup
  - DOS Loader, 906, 909, 943, 946
  - EXECLoader, 888, 893, 925, 929
  - Modbus, 888, 893, 906, 909
  - Modbus Plus, 925, 929, 943, 946
- N**
- Names
  - Datatype editor, 479
  - Derived datatype, 479
- Navigation
  - LL984, 368
- Network Configuration
  - TCP/IP, 823
- Network link
  - Modbus, 522
  - Modbus Plus, 523
  - TCP/IP, 530
- NOT EQUAL, 519
- O**
- Objects
  - SFC, 220
  - insert, LD, 205
- Offline functions in the configurator, 69
- Online, 615, 617
  - SFC, 251
- Online animation
  - INI file, 960
- Online Control Panel, 536, 539
  - general information, 533
- Online diagnostics, 558
- Online functions, 14, 515
  - IL, 318
  - General information, 517
  - IL, 314, 315
  - ST, 359
  - FBD, 181
  - LD, 210
  - SFC, 252, 255
- Online functions in the configurator, 69
- Online help, 673
- ONLINE Operation
  - Presettings, 521
- Online Restriction
  - LL984, 369
- Online Search
  - LL984, 375
- Open
  - Project, 671
- Open Column
  - LL984, 372
- Open Row
  - LL984, 372
- Opener
  - LD, 192
- Operands
  - IL, 266
  - ST, 325
- Operators
  - IL, 269, 276
  - ST, 329
  - ST, 326
- Optimize
  - PLC Memory, 107, 111
  - PLC Memory Atrium CPUs, 155
  - PLC Memory Compact CPUs, 139
  - PLC Memory Momentum CPUs, 149
  - PLC Memory Quantum CPU X13 0X and 424 02, 114
  - PLC-Independent Memory Optimization, 111
  - PLC memory, 110
  - PLC memory Quantum CPU 434 12 and 534 14, 128
- Optional Configuration, 84

**P**

- Page breaks for sections, 605
- Parallel branch, 233
- Parallel connection, 234
- Parameterize ASCII interface, 88
- Parameterize interfaces
  - ASCII interface, 88
  - Modbus interface, 88
- Parameterize Modbus interface, 88
- Password Protection, 625, 626, 627, 634, 635
- Path for global DFBs
  - settings in the INI file, 957
- Path for help files
  - settings in the INI file, 957
- Peer Cop, 87
  - Quantum Configuration example, 791
- Peer Cop communication, 50
- Performance
  - hardware, 639
  - PLC family, 639
- PLC
  - Simulating, 613
  - Status, 663
- PLC Configuration, 46, 47, 63
  - Export, 597
  - Import, 597
  - export, 596
  - General information, 66
  - icons, 689
  - import, 596
- PLC family
  - performance, 639
- PLC Memory, 107, 110, 111
  - Atrium CPUs, 155
  - Compact CPUs, 139
  - Memory Optimization for Quantum CPU X13 0X and 424 02, 114
  - Momentum CPUs, 149
  - Optimize, 107, 111
  - PLC-Independent Memory Optimization, 111
  - Structure, 107
    - memory optimization for Quantum CPU 434 12 and 534 14, 128
    - optimize, 110
- PLC memory mapping, 77
- PLC selection, 72
- PLC state, 531, 543
- Position
  - FFB, FBD, 176
  - FFB, LD, 205
- Precondition for unconditional configuration, 72
- Presettings for Modbus
  - Startup, 873
- Presettings for Modbus Plus
  - Startup, 859
- Presettings for ONLINE operation, 521
- Print
  - settings in the INI file, 955
- Printing sections, 605
- Proceed in the following way with the configuration, 67
- Process
  - Actions, 241
  - Step properties, 239
  - transition, 246
- Processing
  - program, 30
  - project, 30
- PROFIBUS
  - specify coupling modules, 86
- Profibus DP controller, 778
  - Quantum configuration example, 777
- Profibus DP export settings in SyCon example 7, 778
- Program
  - Create, 43
  - Status, 663
  - Structure, 29
  - processing, 30
  - structure, 30
- Program creating
  - ST, 360
  - FBD, 184
  - LD, 213
- Programming, 6
- Programming languages, 9

- Programming modes
    - LL984, 387
  - Programs, 34
  - Project
    - Create, 43
    - Delete, 611
    - Documentation, 601
    - Invoke, 671
    - Open, 671
    - Protect, 635
    - Structure, 29
      - archive, 610
      - processing, 30
      - structure, 30
  - Project Browser, 459
    - Keyboard operation, 462
    - Mouse operation, 462
  - Project name definition
    - settings in the INI file, 956
  - Project symbol
    - Generate, 671
  - Projects
    - Convert, 837
  - Protect
    - DFB, 635
    - Project, 635
- Q**
- Quantum - INTERBUS controller, 765
  - Quantum - Peer Cop, 792, 793, 795, 797
  - Quantum - Profibus DP controller, 780
  - Quantum - remote controller with DIO, 755, 759
  - Quantum - remote controller with RIO, 736
  - Quantum - remote controller with RIO (series 800), 744
  - Quantum - SY/MAX controller, 770
  - Quantum Configuration example
    - Peer Cop, 791
    - INTERBUS control, 763
    - Profibus DP controller, 777
    - remote control with DIO, 754
    - remote control with RIO, 735
    - Remote control with RIO (series 800), 743
    - SY/MAX controller, 769
  - Quantum first startup
    - DOS Loader, 900, 934
    - EXECLoader, 880, 914
    - Modbus, 880, 900
    - Modbus Plus, 914, 934
  - Quantum Profibus DP controller, 784
- R**
- RDE, 487
    - converting RDE templates, 489
    - Cyclical setting of variables, 492
    - general information, 488
  - RDE editor
    - toolbar, 690
  - Reactivate flash save, 539
  - Reading global DFBs
    - settings in the INI file, 957
  - Reference data editor, 487
    - Changing signal states of a Located variable, 491
    - Cyclical setting of variables, 492
    - Replacing variable names, 497
    - converting RDE templates, 489
    - general information, 488
  - Reference Offset
    - LL984, 371
  - Reference Zoom
    - LL984, 373
  - References
    - LL984, 370
  - Register address format
    - settings in the INI file, 956
  - Remote control with DIO
    - Quantum configuration example, 754
  - Remote control with RIO, 740
    - Quantum configuration example, 735
  - Remote control with RIO (series 800), 748, 751
    - Quantum configuration example, 743
  - Remote controller with I/O bus (Momentum), 814, 818

- Remote I/O bus
  - Momentum configuration example, 813
- Remote MBX Driver
  - Modbus Plus, 868
- Replace
  - coil, LD, 206
  - contact, LD, 206
  - FFB, FBD, 177
  - FFB, LD, 206
- Replace References
  - LL984, 375
- Replacing variable names
  - Reference data editor, 497
- Requirements
  - LL984, 368
- RTU extension
  - Compact configuration, 99
  - Configure, 99
  
- S**
- Save To Flash, 536
- Scan
  - constant, 533
- Scan times
  - single, 534
- Search and Replace
  - Variable names and addresses, 450
- Searching and pasting
  - variable names and addresses, 454
- Searching and pasting variable names and Addresses, 454
- Section, 38
  - Animation, 555
  - Execution sequence, 38
  - Export, 564
  - Import, 568, 572, 583, 584, 585
  - import, 569
  - LL984, 365
  - Lock, 39
  - Status, 663
  - import, 580
- Security, 625, 626, 627, 634, 635
- Segment
  - LL984, 365
- Segment manager, 80
  
- Select
  - LL984, 372
- Select process information
  - General information, 543
  - Status and memory, 542
- Selecting process information
  - Status and memory, 542
- Separators
  - data type editor, 480
  - derived data type, 480
- Setting up and controlling the PLC, 532
- Setup and control PLC
  - general information, 533
- SFC
  - 'SFCSTEP\_STATE' variable, 223
  - 'SFCSTEP\_TIMES' variable, 222
  - Action, 223
  - Action variable, 224
  - Actions, 241
  - alternative branch, 230
  - Alternative connection, 232
  - animation, 252, 255
  - Calling up macros, 441
  - Edit, 236
  - edit, 235
  - Icon bar, 684
  - Identifier, 244
  - initial step, 221
  - Jump, 228
  - Learn monitoring times, 257
  - Link, 228
  - maximum supervision time, 221
  - minimum supervision time, 222
  - Objects, 220
  - Online, 251
  - online functions, 252, 255
  - Parallel branch, 233
  - Parallel connection, 234
  - Short Cut Keys, 695
  - Step, 221
  - step delay time, 221
  - step duration, 221
  - Step properties, 239
  - string, 255
  - Text object, 234
  - transition, 225, 246

- Transition diagnosis, 260
- Transition section, 226
- Transition variable, 227
- waiting step, 221
- Short Cut Keys, 679, 691, 692, 693, 695, 699, 705
- Simple sequences, 228
- Simulate
  - SPS, 615, 617
- Simulation, 613, 615, 617
- Single sweeps, 534
- Special options, 89
- Specific data transfer, 797
- Speed optimized LL984- Processing, 535
- ST, 321
  - Assign instructions, 336
  - Block call up, 350
  - Code generation, 358
  - Expressions, 324
  - Instructions, 337
  - List of Symbols, 687
  - Online functions, 359
  - Operands, 325
  - Operators, 326, 329
  - Program creation, 360
  - Short Cut Keys, 693
  - syntax check, 357
- ST Command
  - , 334, 334
  - &, 334
  - =, 333
  - AND, 334
  - Boolean AND, 334
  - Boolean OR, 335
  - Commands, 349
  - ELSE, 341
  - ELSIF...THEN, 342
  - Equal to, 333
  - Less than, 334
  - Less than or equal to, 334
  - Not equal to, 334
  - OR, 335
  - XOR, 335
- ST command
  - , 331, 333
  - (), 330
  - \*, 331
  - \*\* , 330
  - +, 332
  - >, 333
  - >=, 333
  - Addition, 332
  - Assignment, 337
  - Call function block, 351
  - CASE...OF...END\_CASE, 343
  - Complement formation, 331
  - Declaration, 338
  - Division, 332
  - Empty instruction, 349
  - EXIT, 349
  - Exponentiation, 330
  - FOR...TO...BY...DO...END\_FOR, 344
  - FUNCNAME, 330
  - function invocation, 354
  - Greater than, 333
  - Greater than/Equal to, 333
  - IF...THEN...END\_IF, 340
  - MOD, 332
  - Modulo, 332
  - Multiplication, 331
  - Negation, 331
  - NOT, 331
  - REPEAT...UNTIL...END\_REPEAT, 348
  - Subtraction, 333
  - Use of parentheses, 330
  - VAR...END\_VAR, 338
  - WHILE...DO...END\_WHILE, 346
- ST commandl
  - /, 332
- Start behavior
  - variable, 35
- Startup
  - Presettings for Modbus, 873
  - Presettings for Modbus Plus, 859
- Startup with DOS Loader
  - Modbus, 899
  - Modbus Plus, 933

- Startup with the EXECLoader
  - Modbus, 879
  - Modbus Plus, 913
- State of the PLC, 531
- Status, 519
- Status bar, 663
- ST-Command
  - Boolean Exclusive OR, 335
- Step, 221
  - alias designations, 248
- Step delay time, 221
- Step duration, 221
- Step properties
  - Process, 239
- Storage of global DFBs during upload
  - settings in the INI file, 957
- String
  - control, 255
- Structure
  - PLC Memory, 107
  - Program, 29
  - Project, 29, 30
  - program, 30
- Structured text, 321
- Structured variables
  - Import, 590
- Subroutines
  - LL984, 376
- SY/MAX Controller, 774
  - Quantum configuration example, 769
- Symax-Ethernet
  - specify coupling modules, 86
- Symbols, 679, 687, 688
- Syntax
  - Data type editor, 473
  - Derived Data Type, 473
- Syntax check
  - IL, 311
  - ST, 357

## T

- Tag
  - IL, 272
- TCP/IP
  - Network Configuration, 823
- TCP/IP network link, 530
- TCP/IP-Ethernet
  - specify coupling modules, 86
- Text Object
  - FBD, 174
  - LD, 203
  - SFC, 234
- Tool bar, 681, 682, 683, 684, 686, 690
- Tools, 15
- Trace
  - LL984, 375
- Transfer problems
  - Modbus Presettings, 877
- Transition, 225
  - alias designations, 248
  - declare, 246
  - process, 246
- Transition diagnosis, 260
- Transition section, 226
- Transition variable, 227

## U

- UDEFB
  - FBD, 172
  - LD, 199
- Unconditional Configuration, 71
  - precondition, 72
- Unconditional locking of a section, 494
- Undo
  - LL984, 371
- Uploading the PLC, 551
- User-defined Elementary Function
  - FBD, 172
  - LD, 199
- Utilities, 15
- Utility program, 15

**V**

- Variable
  - Export, 567
  - start behavior, 35
- Variable Editor
  - Declaration, 448
  - Exporting located variables, 457
  - Search and Replace, 450
  - searching and pasting, 454
- Variable storage
  - settings in the INI file, 956
- Variables, 34
  - ASCII message editor, 504
  - Import, 587, 590, 594
  - LL984, 370
  - import, 588
- Variables editor, 447
  - General, 448
- VARINOUT variables, 397
- Various PLC settings, 52
- Virtual MBX Driver
  - Modbus Plus, 866

**W**

- Waiting step, 221
- Warm start, 35
- Window, 661
- Window elements, 663
- Window types, 662
- Windows, 659
  - Check box, 670
  - Command buttons, 669
  - Dialog boxes, 668
  - Lists, 669
  - Menu commands, 666
  - Option buttons, 669
  - Status bar, 663
  - Text boxes, 669
  - Window, 661
  - Window elements, 663
- Windows
  - window types, 662

