




Allen-Bradley

***ControlNet
PLC-5
Programmable
Controllers***

***(Cat. No. 1785-L20C15,
-L40C15, -L80C15)***



Quick Start Phase 1.5

Important User Information

Because of the variety of uses for the products described in this publication, those responsible for the application and use of this control equipment must satisfy themselves that all necessary steps have been taken to assure that each application and use meets all performance and safety requirements, including any applicable laws, regulations, codes and standards.

The illustrations, charts, sample programs and layout examples shown in this guide are intended solely for purposes of example. Since there are many variables and requirements associated with any particular installation, Allen-Bradley does not assume responsibility or liability (to include intellectual property liability) for actual use based upon the examples shown in this publication.

Allen-Bradley publication SGI-1.1, *Safety Guidelines for the Application, Installation, and Maintenance of Solid-State Control* (available from your local Allen-Bradley office), describes some important differences between solid-state equipment and electromechanical devices that should be taken into consideration when applying products such as those described in this publication.

Reproduction of the contents of this copyrighted publication, in whole or in part, without written permission of Allen-Bradley Company, Inc., is prohibited.

Throughout this manual we use notes to make you aware of safety considerations:



ATTENTION: Identifies information about practices or circumstances that can lead to personal injury or death, property damage or economic loss.

Attention statements help you to:

- identify a hazard
- avoid the hazard
- recognize the consequences

Important: Identifies information that is critical for successful application and understanding of the product.

Preface

Read this preface to familiarize yourself with the rest of the manual. This preface covers the following topics:

- who should use this manual
- the purpose of this manual
- conventions used in this manual
- Rockwell Automation support

Who Should Use this Manual

To use this manual, you should understand programmable controllers and be able to interpret the ladder logic instructions required to control your application. For more information, see the documents listed on the following page or contact your local Rockwell Automation representative.

Purpose of this Manual

This manual introduces you to installing and using a ControlNet PLC-5 processor system. In addition, it shows you how to set up a system using a typical configuration. Since this is a Quick Start manual, we do not cover all of the ControlNet PLC-5 processor features, but give you enough information to get you started.

This manual includes:

- basic information needed to start using the ControlNet PLC-5 processor quickly and effectively
- high-level procedures with cross-references to other manuals for more details

Important: The recommended switch settings in this manual help you set up a test system and get it working. Actual switch settings depend upon your application.

How to Obtain a User Manual

There is a user manual associated with this product that contains detailed information about configuring, programming, and using a PLC-5 processor. To obtain a copy of the ControlNet PLC-5 Programmable Controllers User Manual, phase 1.5, publication number 1785-6.5.22, you can either:

- view or download an electronic version from the internet:
www.theautomationbookstore.com
- purchase a hardcopy from the internet:
www.theautomationbookstore.com
- contact your local distributor or Rockwell Automation representative to place an order.

See the table on the next page for other related publications.

Related Documentation

The following documents contain additional information concerning the products discussed in this manual.

For more information about:	See this publication:	Publication number:
ControlNet PLC-5 programmable controllers (1785-L20C15, -L40C15, and -L80C15)	ControlNet PLC-5 Programmable Controllers User Manual, phase 1.5	1785-6.5.22
	Enhanced and Ethernet PLC-5 Programmable Controllers User Manual	1785-6.5.12
	1785 Enhanced PLC-5 Processor System Overview	1785-2.36
	ControlNet System Overview	1786-2.12
	1785 PLC-5 Programmable Controllers Quick Reference	1785-7.1
	PLC-5 Programming Software Instruction Set Reference Manual	1785-6.1
	Industrial Automation Wiring and Grounding Guidelines	1770-4.1
ControlNet media	ControlNet Cable System Component List	AG-2.2
	ControlNet Cable System Planning and Installation Manual	1786-6.2.1
	ControlNet Coax Tap Installation Instructions	1786-2.3
	ControlNet Network Access Cable Installation Instructions	1786-2.6
	ControlNet Repeater Installation Instructions	1786-2.7
Universal 1771 I/O chassis	Universal I/O Chassis installation instructions	1771-2.210
power supply (1771-P4S)	Power Supply Modules (1771-P4S, -P6S, -P4S1, -P6S1) installation instructions	1771-2.135
	Allen-Bradley Publication Index (for your specific power supply)	SD499
DH+ network	Enhanced and Ethernet Programmable Controllers User Manual	1785-6.5.12
	Data Highway/Data Highway Plus/Data Highway II/Data Highway-485 Cable installation instructions	1770-6.2.2
communication card (1784-KTCx15)	ControlNet Communication Interface Card installation instructions	1784-5.20
	Allen-Bradley Publication Index (for your specific communication card)	SD499
communication interface (1770-KFC15)	ControlNet Communication Interface User Manual	1770-6.5.20
terms and definitions	Industrial Automation Glossary	AG-7.1

Conventions Used in This Manual

The following conventions are used throughout this manual:

- Bulleted lists provide information, not procedural steps.
- Numbered lists provide sequential steps or hierarchical information.
- *Italic* type is used for emphasis.
- Text in `this font` indicates words or phrases you should type.
- Key names match the names shown and appear in bold, capital letters (for example, **ENTER**).



Tip: We use this convention to call attention to helpful information.

Rockwell Automation Support

Rockwell Automation offers support services worldwide, with over 75 Sales/Support Offices, 512 authorized Distributors and 260 authorized Systems Integrators located throughout the United States alone, plus Allen-Bradley representatives in every major country in the world.

Local Product Support

Contact your local Rockwell Automation representative for:

- sales and order support
- product technical training
- warranty support
- support service agreements

Technical Product Assistance

If you need to contact Rockwell Automation for technical assistance, call your local Rockwell Automation representative.

Your Questions or Comments on this Manual

If you find a problem with this manual, please notify us by completing and sending the enclosed Publication Problem Report (in the back of this manual).

If you have any suggestions for how this manual could be made more useful to you, please contact us at the address below:

Rockwell Automation/Allen-Bradley Company, Inc.
Control and Information Group
Technical Communication
1 Allen-Bradley Drive
Mayfield Heights, Ohio 44124-6118

Telephone: (440) 646-5000

FAX: (440) 646-4320

Before You Begin

Chapter 1

What You Need to Do	1-1
Identify the Processor's Front Panel Components.	1-2
Check Your Components.	1-3
Compliance to European Union Directives	1-4
EMC Directive.	1-4
Low Voltage Directive	1-4

Set Up the Hardware

Chapter 2

Install the Hardware.	2-2
Configure the I/O Chassis	2-2
Ground the I/O Chassis	2-3
Install the Power Supply	2-4
Install the PLC-5 Processor	2-5
Powerup the System	2-6
Install the I/O Modules	2-6
Connect the Personal Computer to the PLC-5 Processor	2-6

Set Up the Software

Chapter 3

Install the Software and	
Set Up the Programming System	3-1
Start the Programming Software	3-2
Power Up the System.	3-2

Troubleshoot the Processor System

Chapter 4

Use the General Status Indicators	4-1
Use the ControlNet Status Indicators	4-3
Use the DH+/RIO Status Indicators	4-5
Monitor ControlNet Configuration and Status	4-6

Specifications

Appendix A

General.	A-1
------------------	-----

Notes

Before You Begin

The ControlNet network is a high-speed link that lets PLC processors and I/O devices (e.g., I/O racks, variable speed drives, Man-Machine Interface (MMI), and other automation devices) exchange data. The ControlNet PLC-5 processors have one logical ControlNet port consisting of two BNC connectors and one network access port; these processors let you connect to the ControlNet network.


What You Need to Do

If you need more information, see the ControlNet PLC-5 Programmable Controllers User Manual, phase 1.5, publication number 1785-6.5.22 (see page P-1 for information about how to obtain a copy of this manual).

*Set up the Hardware
(Chapter 2)*

*Set up the Software
(Chapter 3)*


*Troubleshoot the
Processor System
(Chapter 4)*



Identify the Processor's Front Panel Components



These pictures show the ControlNet PLC-5 processor front panel components.

PLC-5/20C Processor



¹ControlNet Redundant Media Ports - BNC; dedicated

PLC-5/40C and -5/80C Processors



ATTENTION: Make sure you understand the anti-static environment.

The processor is shipped in a static-shielded container to guard against electrostatic damage. Electrostatic discharge can damage integrated circuits or semiconductors in the processor module if you touch backplane connector pins. It can also damage the module when you set configuration plugs or switches inside the module. Avoid electrostatic damage by observing the following precautions.

- Remain in contact with an approved ground point while handling the module (by wearing a properly grounded wrist strap).
- Do not touch the backplane connector or connector pins.
- When not in use, keep the module in its static-shielded container.

Check Your Components

For this quick start, you need this hardware and software:

Product name:	Catalog number:
Hardware	
ControlNet PLC-5 processor	1785-L20C15, -L40C15, -L80C15
ControlNet network access cable	1786-CP
1771 I/O chassis	1771-A1B
power supply	1771-P4S
personal computer	
communication interface card	1784-KTCx15
Software	
RSLogix5 programming software ¹	<ul style="list-style-type: none"> • 9324-RL5300END (diskettes) • or 9324-RL5300ENE (CDROM)
RSNetWorx network configuration software ¹	9357-CNETL3
RSLink communication software ¹	9355-WAB

¹ You can order 9324-RWCNTENE to receive RSLogix 5, RSNetWorx, and RSLink on a single CD.

Compliance to European Union Directives

If this product has the CE mark it is approved for installation within the European Union and EEA regions. It has been designed and tested to meet the following directives.

EMC Directive

This product is tested to meet Council Directive 89/336/EEC Electromagnetic Compatibility (EMC) and the following standards, in whole or in part, documented in a technical construction file:

- EN 50081-2EMC – Generic Emission Standard, Part 2 – Industrial Environment
- EN 50082-2EMC – Generic Immunity Standard, Part 2 – Industrial Environment

This product is intended for use in an industrial environment.

Low Voltage Directive



This product is tested to meet Council Directive 73/23/EEC Low Voltage, by applying the safety requirements of EN 61131-2 Programmable Controllers, Part 2 – Equipment Requirements and Tests.

For specific information required by EN 61131-2, see the appropriate sections in this publication, as well as the following Allen-Bradley publications:

- Industrial Automation Wiring and Grounding Guidelines For Noise Immunity, publication 1770-4.1
- Guidelines for Handling Lithium Batteries, publication AG-5.4
- Automation Systems Catalog

Set Up the Hardware

- 1 Install the hardware
(page 2-2)
- 2 Connect the personal computer to
the PLC-5 processor
(page 2-6)






For more information, see the ControlNet PLC-5 Programmable Controllers User Manual, phase 1.5, publication number 1785-6.5.22.

Install the Hardware

Configure the I/O Chassis

1 Set the backplane switches.

-  Pressed in at top ON (closed)
 Pressed in at bottom OFF (open)



Switch	Last State
1	
on	Outputs of this I/O chassis remain in their last state when a hardware failure occurs. ¹
off	Outputs of this I/O chassis are turned off when a hardware failure occurs. ¹

Switches		Addressing
4	5	
off	off	2 - slot
off	on	1 - slot
on	off	1/2 - slot
on	on	Not allowed


Switches		EEPROM Transfer
6	7	
off	off	EEPROM memory transfer to processor memory at power-up. ^{2, 3}
on	on	EEPROM memory transfers to processor memory if processor memory not valid.
on	off	EEPROM memory does not transfer to processor memory. ⁴

Switch	Processor Memory Protection
8	
off	Processor memory protection disabled.
on	Processor memory protection enabled. ⁵

- ¹ Regardless of this switch setting, outputs are turned off when any of the following occurs:
 - processor detects a runtime error
 - an I/O chassis backplane fault occurs
 - you select program or test mode
 - you set a status file bit to reset a local rack
- ² If an EEPROM module is not installed and processor memory is valid, the processor's PROC LED indicator blinks, and the processor sets S:11/9, bit 9 in the major fault status word. To clear this fault, change the processor from program mode to run mode and back to program mode.
- ³ If the processor's keyswitch is set in REMote, the processor enters remote RUN after it powers up and has its memory updated by the EEPROM module.
- ⁴ A processor fault (solid red PROC LED) occurs if processor memory is not valid.
- ⁵ You cannot clear processor memory when this switch is on.

2 Set the power supply configuration jumper.

3 Install the keying bands.




20609-M




For more information, see the Universal I/O Chassis installation instructions, publication number 1771-2.10.

Ground the I/O Chassis




20626-M




For more information, see the Allen-Bradley Programmable Controller Wiring and Grounding Guidelines, publication number 1770-4.1.

Install the Power Supply




1 Set the jumpers on the back side of the power supply like this:



2 Connect the power cord to the 120Vac connector of the power supply module.

This side plugs into connector on the module.




3 Install the power supply in the chassis and snap the module-locking bar over the modules.



For more information, see the Power Supply Modules (1771-P4S, -P6S, -P4S1, -P6S1) Installation Instructions, publication number 1771-2.135.

Install the PLC-5 Processor




For detailed information about handling and disposing of the battery as well as other important guidelines, see publication AG-5.4.




For more information, see the ControlNet PLC-5 Programmable Controllers User Manual, publication number 1785-6.5.22.

- 1 Define the DH+ Station Address of Channel 1A by setting switch assembly SW-1 on the back of the processor. (See the side of the processor if you want to use another address.)




- 2 Specify the digital interface of channel 0.



- 3 Set the ControlNet network addresses by using the two 10-digit rotary switches on top of the module.

ControlNet PLC-5 processor's NET address = 1




- 4 To install the battery, slide the battery-side connector into the processor-side connector until you hear them snap together, and attach the battery cover.

- 5 Install the processor module.

Power Up the System

Power up the system. Check the LED display on the processor. If your system is operating properly, the PROC LED should be steady red. If the PROC LED is not red, see chapter 4 for troubleshooting information before you install any I/O modules.


Install the I/O Modules



Connect the Personal Computer to the PLC-5 Processor



For more information, see the installation instructions or user manual for the particular module you are installing.




For more information, see:

- ControlNet PLC-5 Programmable Controllers User Manual, phase 1.5, publication number 1785-6.5.22
- Enhanced and Ethernet PLC-5 Programmable Controllers User Manual, publication number 1785-6.5.12
- the documentation provided with your communication card
- Data Highway/Data Highway Plus/Data Highway II/Data Highway 485 Cable Installation Manual, publication 1770-6.2.2

Set Up the Software

- 1 *Install the software*
- 2 *Start the programming software*
- 3 *Powerup the system*



Use the following software packages to configure your ControlNet system.

Use:	To:
RSNetWorx for the ControlNet network	define ControlNet network parameters, such as: <ul style="list-style-type: none">• network update time• media redundancy• physical media configuration• maximum scheduled nodes• maximum unscheduled nodes
RSLogix5	<ul style="list-style-type: none">• enter user program files• create/delete/monitor data table files• enter module configuration• enter channel 0, 1A, 1B, and, 3 configuration• administer passwords and privileges



For information about using these software packages, see the online help systems for RSNetWorx for ControlNet and RSLogix5 software.

Install the Software and Set Up the Programming System

Before you install your programming software, make certain you meet the requirements for that software. Then, follow the procedures outlined in the online help and documentation to install the software and configure communication.

Start the Programming Software

Start the programming software by following the procedures described in your programming software documentation.

If you have difficulty, verify that the power supply is turned on.

To monitor your system as you configure and run it, check the processor LED display for the following indicators:


This LED:	lights when:
COMM	you establish communication, if connected via the serial port
BAT	no battery is installed or the battery voltage is low
FORCE	forces are present in your ladder program

Power Up the System

Power up the system if you have not done so already. Check the LED display on the processor. If you are using NAP cable, then the ControlNet LEDs will flash red. If you are using coaxial trunk cable, with taps and terminators, then the ControlNet channels that are connected will be steady green, and those that are unconnected will flash red.


Troubleshoot the Processor System

- 1 Use the general status indicators
- 2 Use the ControlNet status indicators
- 3 Use the DH+/RIO status indicators
- 4 Monitor the ControlNet configuration and status screens



Use the General Status Indicators

The general status indicators inform you of the general operational state of the processor.




Indicator	Color	Description	Probable Cause	Recommended Action
BATT	Red	Battery low	Battery low	Replace battery within 10 days
	Off	Battery is good	Normal operation	No action required
PROC	Green (steady)	Processor is in run mode and fully operational	Normal operation	No action required
	Green (blinking)	Processor memory is being transferred to EEPROM		
	Red (blinking)	Major fault	Run-time error	<ul style="list-style-type: none"> Check major fault bit in status file (S:11) for error definition Clear fault bit, correct problem, and return to run mode
	Alternating Red and Green	Processor in FLASH-memory programming mode	Normal operation if processor's FLASH memory is being reprogrammed	No action required – allow flash update to complete
			Processor FLASH memory checksum error	Contact your local A-B representative for a field firmware update
	Red (steady)	Major fault	<ul style="list-style-type: none"> Processor memory has checksum error Memory module error Internal diagnostics have failed 	<ul style="list-style-type: none"> Clear memory and reload program Check backplane switch settings and/or insert correct memory module Power down, reseal processor and power up; then, clear memory and reload your program. Replace EEPROM with new program; then, if necessary, replace the processor
	Off	Processor is in program load or test mode or is not receiving power		Check power supply and connections





Indicator	Color	Description	Probable Cause	Recommended Action
FORCE	Amber (steady)	SFC and/or I/O forces enabled	Normal operation	No action required
	Amber (blinking)	SFC and/or I/O forces present but not enabled		
	Off	SFC and/or I/O forces not present		
COMM	Off	No transmission on channel 0	Normal operation if channel is not being used	
	Green (blinking)	Transmission on channel 0	Normal operation if channel is being used	

Use the ControlNet Status Indicators

The ControlNet status indicators inform you of the operational state of the ControlNet network.



Indicator	Color	Description	Probable Cause	Recommended Action
I/O	Off	ControlNet I/O not present or not operating	Normal operation if Channel 2 not being used	No action required
	Steady Green	All nodes configured in the ControlNet map table present and operating properly	Normal operation	No action required
	Flashing Green/Off	At least one node configured for the ControlNet network not present or not operating properly	Cable(s) or connector(s) broken or not connected	Repair or replace cable(s) or connector(s), and reconnect
			Destination module(s) bad or missing	Repair or replace module(s)
			Node(s) not on network	Connect node to network
	Flashing Red/Off	All nodes configured for ControlNet not present or not operating properly	Cable(s) or connector(s) broken or not connected	Repair or replace cable(s) or connector(s), and reconnect
			Nodes not on network	Connect nodes to network

Indicator	Color ¹	Probable Cause	Recommended Action
 and  A and B	Off	Internal diagnostics failed	1. Turn power off, make sure ControlNet address is not 00, reseal processor, then power up 2. Clear memory and reload your program 3. Replace EEPROM with new program 4. If still an error, replace the processor
		No power	Check power supply
	Steady Red	Faulted unit	Cycle power or reset unit If fault persists, contact your Allen-Bradley Company, Inc. representative or distributor
	Flashing Green	Normal operation if processor is in FLASH memory program mode	No action required
	Flashing Red/Green	The processor's ControlNet address is above UMAX	Configure the ControlNet network so that UMAX is at least as high as the processor's ControlNet address. Set the processor's ControlNet address at or below UMAX.
	Alternating Red/Green	Self-test	No action required
	Alternating Red/Off	Incorrect node configuration	Check network address and other ControlNet configuration parameters
 or  A or B	Off	Channel disabled	No action required Configure for ControlNet communication
	Steady Green	Normal operation	No action required
	Flashing Green/Off	Temporary errors	No action required Make sure that ControlNet is properly terminated
	Flashing Red/Off	Media fault	Check media for broken cables, loose connectors, missing terminators, etc.
		No other nodes present on network	Add other nodes to the network
	Flashing Red/Green	Incorrect network configuration	Cycle power or reset unit If fault persists, contact your Allen-Bradley Company, Inc. representative or distributor

¹

Definition of terms:

- **alternating** – the two indicators alternate between the two defined states at the same time (applies to both indicators *viewed together*); the two indicators are always in opposite states, out of phase
- **flashing** – the indicator alternates between the two defined states (applies to each indicator *viewed independent* of the other); if both indicators are flashing; they flash together, in phase
- **steady** – indicator is on continuously in the defined state


Use the DH+/RIO Status Indicators

Indicator	Color	Channel Mode	Description	Probable Cause	Recommended Action
A or B	Green (steady)	Remote I/O Scanner	Active Remote I/O link, all adapter modules are present and not faulted	Normal operation	No action required
		Remote I/O Adapter	Communicating with scanner		
		DH+	Processor is transmitting or receiving on DH+ link		
	Green (blinking rapidly or slowly)	Remote I/O Scanner	At least one adapter is faulted or has failed	<ul style="list-style-type: none"> Power off at remote rack Cable broken 	<ul style="list-style-type: none"> Restore power to the rack Repair cable
		DH+	No other nodes on network		
	Red (steady)	Remote I/O Scanner Remote I/O Adapter DH+	Hardware fault	Hardware error	<ul style="list-style-type: none"> Turn power off, then on. Check that the software configurations match the hardware set-up. Replace the processor.
	Red (blinking rapidly or slowly)	Remote I/O Scanner	Faulted adapters detected	<ul style="list-style-type: none"> Cable not connected or is broken Power off at remote racks 	<ul style="list-style-type: none"> Repair cable Restore power to racks
		DH+	Bad communication on DH+	Duplicate node detected	Correct station address
	Off	Remote I/O Scanner Remote I/O Adapter DH+	Channel offline	Channel is not being used	Place channel online if needed

Monitor ControlNet Configuration and Status

Use the following software packages to configure your ControlNet system.

Use:	To:
RSNetWorx for the ControlNet network	define ControlNet network parameters, such as: <ul style="list-style-type: none">• network update time• media redundancy• physical media configuration• maximum scheduled nodes• maximum unscheduled nodes
RSLogix5	<ul style="list-style-type: none">• enter user program files• create/delete/monitor data table files• enter module configuration• enter channel 0, 1A, 1B, and, 3 configuration• administer passwords and privileges



For information about using these software packages, see the online help systems for RSNetWorx for ControlNet and RSLogix5 software.

Specifications

General

This table lists general specifications.

Backplane Current	PLC-5/20C15: 2.7A PLC-5/40C15, -5/80C15: 3.3A
Heat Dissipation	PLC-5/20C15: 54 BTU/hour PLC-5/40C15, -5/80C15: 59 BTU/hour
Environmental Conditions	Operating Temperature: 0 to 60° C (32-140° F) Storage Temperature: -40 to 85° C (-40 to 185° F) Relative Humidity: 5 to 95% (without condensation)
Shock	Operating 30 g peak acceleration for 11±1 ms duration Non-operating 50 g peak acceleration for 11±1 ms duration
Vibration	1 g @ 10 to 500 Hz 0.012 inches peak-to-peak displacement
Time-of-Day Clock/Calendar¹	Maximum Variations at 60° C: ± 5 min per month Typical Variations at 20° C: ± 20 s per month Timing Accuracy: 1 program scan
Battery	1770-XYC
Memory Modules	<ul style="list-style-type: none"> • 1785-ME32 • 1785-ME64 • 1785-M100
I/O Modules	Bulletin 1771 I/O, 1794 I/O, 1746 I/O, and 1791 I/O including 8-, 16-, 32-pt, and intelligent modules
Hardware Addressing	2-slot <ul style="list-style-type: none"> • Any mix of 8-pt modules • 16-pt modules must be I/O pairs • No 32-pt modules 1-slot <ul style="list-style-type: none"> • Any mix of 8- or 16-pt modules • 32-pt modules must be I/O pairs 1/2-slot – Any mix of 8-, 16-, or 32-pt modules
Communication	<ul style="list-style-type: none"> • Serial • DH+ • DH using 1785-KA • Remote I/O • ControlNet
Location	1771-A1B, -A2B, A3B, -A3B1, -A4B chassis; left-most slot
Weight	PLC-5/20C15: 3 lbs, 3 oz (1.45 kg) PLC-5/40C15: 3 lbs, 2 oz (1.42 kg) PLC-5/80C15: 3 lbs, 2 oz (1.42 kg)
Keying	<ul style="list-style-type: none"> • Between 40 and 42 • Between 54 and 56
Agency Certification (When product or packaging is marked)	<ul style="list-style-type: none"> • CSA certified • CSA Class I, Division 2 Groups A, B, C, D certified • UL listed • CE marked for all applicable directives







¹ Please note that the clock/calendar will update appropriately each year, including the year 2000.

		PLC-5/20C	PLC-5/40C	PLC-5/80C
Maximum User Memory Words		16K	48K ¹	100K ²
Maximum Total I/O	Any Mix	512	2048	3072
	Complimentary	512 in and 512 out	2048 in and 2048 out	3072 in and 3072 out
Program Scan Time		0.5 ms per K word (bit logic) 2 ms per K word (typical)		
ControlNet I/O ³	Transmission Rate	5M bit/s		
	Network Update Time (NUT)	2-100 ms (user selectable)		
	Number of ControlNet Ports	1 (redundant)		
	Maximum Number of Nodes per Link without a Repeater	48 – with 250 m (approx. 820 ft) cable length		
	Maximum Number of Nodes per Link with Repeaters	99		
	Maximum Link Cable Length without a Repeater	1,000 m (approximately 3,280 ft) – with 2 nodes 500 m (approximately 1,640 ft) – with 32 nodes 250 m (approximately 820 ft) – with 48 nodes		
	Maximum Number of I/O Map Entries	64	96	128
	Maximum DIF/DOF Size	2000 words	3000 words	4000 words
	Maximum Link Cable Length with Repeaters	6,000 m (approximately 19,680 ft) – with 2 nodes 3,000 m (approximately 9,840 ft) – typical		
Remote I/O and DH+	Transmission Rate	57.6K bit/s 115.2K bit/s 230.4K bit/s		
	I/O Scan Time (Typical)	10 ms per rack @ 57.6K bit/s 7 ms per rack @ 115.2K bit/s 3 ms per rack @ 230K bit/s		
	Maximum Number of Remote I/O Racks	3	15	23
	Maximum Number of Remote I/O Devices	12	60	92
	Number of Ports Configurable for DH+ or Remote I/O (Adapter or Scanner)	1	2	2
	Number of Dedicated DH+ Ports	1	0	0
Number of Serial Ports		1		
Number of Coprocessor Ports		1		
Maximum Number of MCPs		16		

¹ The PLC-5/40C processor has a limit of 32K words per data-table file.

² The PLC-5/80C processor has a limit of 56K words per program file and 32 K words per data table file. The PLC-5/80C processor has 64K words of total data table space.

³ For more information, see the ControlNet Cable System Planning and Installation Manual, publication 1786-6.2.1.

CSA Hazardous Location Approval	Approbation d'utilisation dans des emplacements dangereux par la CSA
<p>CSA certifies products for general use as well as for use in hazardous locations. Actual CSA certification is indicated by the product label as shown below, and not by statements in any user documentation.</p>	<p>La CSA certifie les produits d'utilisation generale aussi bien que ceux qui s'utilisent dans des emplacements dangereux. La certification CSA en vigueur est indiquee par l'etiquette du produit et non par des affirmations dans la documentation a l'usage des utilisateurs.</p>
<p>Example of the CSA certification product label</p> 	<p>Exemple d'étiquette de certification d'un produit par la CSA</p> 
<p>To comply with CSA certification for use in hazardous locations, the following information becomes a part of the product literature for this CSA-certified industrial control product.</p> <ul style="list-style-type: none"> This equipment is suitable for use in Class I, Division 2, Groups A, B, C, D, or non-hazardous locations only. The products having the appropriate CSA markings (that is, Class I, Division 2, Groups A, B, C, D) are certified for use in other equipment where the suitability of combination (that is, application or use) is determined by the CSA or the local inspection office having jurisdiction. 	<p>Pour satisfaire a la certification de la CSA dans des endroits dangereux, les informations suivantes font partie integrante de la documentation ce produit industriel de controle certifie par la CSA.</p> <ul style="list-style-type: none"> Cet equipement convient a l'utilisation dans des emplacements de Classe 1, Division 2, Groupes A, B, C, D, ou ne convient qu'a l'utilisation dans des endroits non dangereux. Les produits portant le marquage approprie de la CSA (c'est a dire, Classe 1, Division 2, Groupes A, B, C, D) sont certifies a l'utilisation pour d'autres equipements ou la convenance de combinaison (application ou utilisation) est determinee par la CSA ou le bureau local d'inspection qualifie.
<p>Important: Due to the modular nature of a programmable control system, the product with the highest temperature rating determines the overall temperature code rating of a programmable control system in a Class I, Division 2, location. The temperature code rating is marked on the product label as shown.</p>	<p>Important: Par suite de la nature modulaire du systeme de controle programmable, le produit ayant le taux le plus eleve de temperature determine le taux d'ensemble du code de temperature du systeme de controle d'un programmable dans un emplacement de Classe 1, Division 2. Le taux du code de temperature est indique sur l'etiquette du produit.</p>
<p>Temperature code rating</p>  <p>Look for temperature code rating here</p>	<p>Taux du code de température</p>  <p>Le taux du code de température est indique ici</p>
<p>The following warnings apply to products having CSA certification for use in hazardous locations.</p>  <p>ATTENTION: Explosion hazard –</p> <ul style="list-style-type: none"> Substitution of components may impair suitability for Class I, Division 2. Do not replace components unless power has been switched off or the area is known to be non-hazardous. Do not disconnect equipment unless power has been switched off or the area is known to be non-hazardous. Do not disconnect connectors unless power has been switched off or the area is known to be non-hazardous. Secure any user-supplied connectors that mate to external circuits on this equipment by using screws, sliding latches, threaded connectors, or other means such that any connection can withstand a 15 Newton (3.4 lb.) separating force applied for a minimum of one minute. Batteries must only be changed in an area known to be non-hazardous. 	<p>Les avertissements suivants s'appliquent aux produits ayant la certification CSA pour leur utilisation dans des emplacements dangereux.</p>  <p>AVERTISSEMENT: Risque d'explosion –</p> <ul style="list-style-type: none"> La substitution de composants peut rendre ce materiel inacceptable pour lesemplacements de Classe I, Division 2. Couper le courant ou s'assurer quel'emplacement est designe non dangereux avant de remplacer lescomposants. Avant de debrancher l'equipement, couper le courant ou s'assurer que l'emplacement est designe non dangereux. Avant de debrancher les connecteurs, couper le courant ou s'assurer que l'emplacement est reconnu non dangereux. Attacher tous connecteurs fournis par l'utilisateur et relies aux circuits externes de cet appareil a l 'aide de vis, loquets coulissants, connecteurs filetes ou autres moyens permettant aux connexions de resister a une force de separation de 15 newtons (3,4 lb. - 1,5 kg) appliquee pendant au moins une minute. Afin d'eviter tout risque d'explosion, s'assurer que l'emplacement est designe non dangereux avant de changer la batterie.

Notes



Allen-Bradley Publication Problem Report

If you find a problem with our documentation, please complete and return this form

Pub. Name ControlNet PLC-5 Programmable Controllers Quick Start, Phase 1.5

Cat. No. 1785-L20C15, -L40C15, -L80C15 Pub. No. 1785-10.6 Pub. Date November 1998 Part No. 955133-89


Check Problem(s) Type:	Describe Problem(s):	Internal Use Only
<input type="checkbox"/> Technical Accuracy	<input type="checkbox"/> text <input type="checkbox"/> illustration	
<input type="checkbox"/> Completeness What information is missing?	<input type="checkbox"/> procedure/step <input type="checkbox"/> illustration <input type="checkbox"/> definition	<input type="checkbox"/> info in manual (accessibility)
	<input type="checkbox"/> example <input type="checkbox"/> guideline <input type="checkbox"/> feature	<input type="checkbox"/> info not in manual
	<input type="checkbox"/> explanation <input type="checkbox"/> other	
<input type="checkbox"/> Clarity What is unclear?		
<input type="checkbox"/> Sequence What is not in the right order?		
<input type="checkbox"/> Other Comments Use back for more comments.		
Your Name _____	Location/Phone _____	

Return to: Marketing Communications, Allen-Bradley Co., 1 Allen-Bradley Drive, Mayfield Hts., OH 44124-6118
Phone: (440)646-3166
FAX: (440)646-4320


Other Comments

PLEASE FOLD HERE

PLEASE REMOVE



NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES



BUSINESS REPLY MAIL

FIRST-CLASS MAIL PERMIT NO. 18235 CLEVELAND OH

POSTAGE WILL BE PAID BY THE ADDRESSEE



Allen-Bradley

1 ALLEN BRADLEY DR
MAYFIELD HEIGHTS OH 44124-9705





Rockwell Automation helps its customers receive a superior return on their investment by bringing together leading brands in industrial automation, creating a broad spectrum of easy-to-integrate products. These are supported by local technical resources available worldwide, a global network of system solutions providers, and the advanced technology resources of Rockwell.

Worldwide representation.



Argentina • Australia • Austria • Bahrain • Belgium • Bolivia • Brazil • Bulgaria • Canada • Chile • China, People's Republic of • Colombia • Costa Rica • Croatia • Cyprus • Czech Republic • Denmark • Dominican Republic • Ecuador • Egypt • El Salvador • Finland • France • Germany • Ghana • Greece • Guatemala • Honduras • Hong Kong • Hungary • Iceland • India • Indonesia • Iran • Ireland • Israel • Italy • Jamaica • Japan • Jordan • Korea • Kuwait • Lebanon • Macau • Malaysia • Malta • Mexico • Morocco • The Netherlands • New Zealand • Nigeria • Norway • Oman • Pakistan • Panama • Peru • Philippines • Poland • Portugal • Puerto Rico • Qatar • Romania • Russia • Saudi Arabia • Singapore • Slovakia • Slovenia • South Africa, Republic of • Spain • Sweden • Switzerland • Taiwan • Thailand • Trinidad • Tunisia • Turkey • United Arab Emirates • United Kingdom • United States • Uruguay • Venezuela

Rockwell Automation Headquarters, 1201 South Second Street, Milwaukee, WI 53204 USA, Tel: (1) 414 382-2000, Fax: (1) 414 382-4444

Rockwell Automation European Headquarters SA/NV, avenue Hermann Debruyne, 46, 1160 Brussels, Belgium, Tel: (32) 2 663 06 00, Fax: (32) 2 663 06 40

Rockwell Automation Asia Pacific Headquarters, 27/F Citicorp Centre, 18 Whitfield Road, Causeway Bay, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846