



installation and start-up instructions

TWO-SPEED PURON® PLUS HEAT PUMP WITH PURON® REFRIGERANT

698B

Cancels: II 698B-24-3


II 698B-24-4
2-03

NOTE: Read the entire instruction manual before starting the installation.

SAFETY CONSIDERATIONS

Improper installation, adjustment, alteration, service, maintenance, or use can cause explosion, fire, electrical shock, or other conditions which may cause death, personal injury, or property damage. Consult a qualified installer, service agency, or your distributor or branch for information or assistance. The qualified installer or agency must use factory-authorized kits or accessories when modifying this product. Refer to the individual instructions packaged with the kits or accessories when installing.

Follow all safety codes. Wear safety glasses, protective clothing, and work gloves. Use quenching cloth for brazing operations. Have fire extinguisher available. Read these instructions thoroughly and follow all warnings or cautions included in literature and attached to the unit. Consult local building codes and National Electrical Code (NEC) for special requirements.

Recognize safety information. This is the safety-alert symbol . When you see this symbol on the unit and in instructions or manuals, be alert to the potential for personal injury.

Understand the signal words DANGER, WARNING, and CAUTION. These words are used with the safety-alert symbol. DANGER identifies the most serious hazards which **will** result in severe personal injury or death.

WARNING signifies hazards which **could** result in personal injury or death. CAUTION is used to identify unsafe practices which **would** result in minor personal injury or product and property damage. NOTE is used to highlight suggestions which **will** result in enhanced installation, reliability, or operation.



WARNING: Before installing, modifying, or servicing system, main electrical disconnect switch must be in the OFF position. There may be more than 1 disconnect switch. Lock out and tag switch with a suitable warning label. Electrical shock can cause personal injury or death.




CAUTION: Puron® (R-410A) systems operate at higher pressures than standard R-22 systems. Be certain that service equipment is rated for R-410A. Some R-22 service equipment may not be acceptable. Check with your distributor.

INSTALLATION RECOMMENDATIONS

NOTE: In some cases noise in the living area has been traced to gas pulsations from improper installation of equipment.

1. Locate unit away from windows, patios, decks, etc. where unit operation sound may disturb customer.
2. Ensure that vapor and liquid tube diameters are appropriate to capacity of unit.
3. Run refrigerant tubes as directly as possible by avoiding unnecessary turns and bends.



A01050



Fig. 1—Model 698B

4. Leave some slack between structure and unit to absorb vibration.
5. When passing refrigerant tubes through the wall, seal opening with RTV or other pliable silicon-based caulk. (See Fig. 2.)
6. Avoid direct tubing contact with water pipes, duct work, floor joists, wall studs, floors, and walls.
7. Do not suspend refrigerant tubing from joists and studs with a rigid wire or strap which comes in direct contact with tubing. (See Fig. 2.)
8. Ensure that tubing insulation is pliable and completely surrounds vapor tube.
9. When necessary, use hanger straps which are 1 in. wide and conform to shape of tubing insulation. (See Fig. 2.)
10. Isolate hanger straps from insulation by using metal sleeves bent to conform to shape of insulation.

When outdoor unit is connected to factory-approved indoor unit, outdoor unit contains system refrigerant charge for operation with indoor unit of the same size when connected by 15 ft of field-supplied or factory accessory tubing. For proper unit operation, check refrigerant charge using charging information located on control box cover or in the Check Charge section of this instruction.

IMPORTANT: Maximum liquid-line size is 3/8-in O.D. for all residential applications.

IMPORTANT: Always install the factory-supplied Puron® heat pump (bi-flow) liquid line filter drier. Obtain replacement filter driers from your distributor or branch.



A01383

Fig. 2—Connecting Tubing Installation
INSTALLATION

I. CHECK EQUIPMENT AND JOB SITE

A. UNPACK UNIT

Move to final location. Remove carton, taking care not to damage unit.

B. INSPECT EQUIPMENT

File claim with shipping company prior to installation if shipment is damaged or incomplete. Locate unit rating plate on unit corner panel. It contains information needed to properly install unit.

II. INSTALL ON A SOLID, LEVEL MOUNTING PAD

If conditions or local codes require the unit be attached to pad, tie down bolts should be used and fastened through knockouts provided in unit base pan. Refer to unit mounting pattern in Fig. 3 to determine base pan size and knockout hole location.

On rooftop applications, mount on level platform or frame. Place unit above a load-bearing wall and isolate unit and tubing set from structure. Arrange supporting members to adequately support unit and minimize transmission of vibration to building. Consult local codes governing rooftop applications.



CAUTION: Do not allow POE lubricant to come into contact with roofing material. POE may deteriorate certain types of synthetic roofing.


Roof mounted units exposed to winds above 5 mph may require wind baffles. Consult the Application Guideline and Service Manual for Residential Split System Air Conditioners and Heat Pumps using Puron® Refrigerant for wind baffle construction

NOTE: Unit must be level to within $\pm 2^\circ$ ($\pm 3/8$ in./ft) per compressor manufacturer specifications.

III. CLEARANCE REQUIREMENTS

When installing, allow sufficient space for airflow clearance, wiring, refrigerant piping, and service. Allow 30-in. clearance to service end of unit and 48 in. above unit. For proper airflow, a 6-in. clearance on 1 side of unit and 12 in. on all remaining sides must be maintained. Maintain a distance of 24 in. between units. Position so water, snow, or ice from roof or eaves cannot fall directly on unit.


On rooftop applications, locate unit at least 6 in. above roof surface.



A97375

UNIT SIZE	MINIMUM MOUNTING PAD DIMENSIONS		TIEDOWN KNOCKOUT LOCATIONS	
	Support Feet	Snow Stand	A	B
024	19 X 24	26 X 32	2-13/16	6-15/16
036-060	26 X 32	31 X 35	4	9-3/4

Fig. 3—Mounting Unit to Pad



A98532

Fig. 4—Accessory Support Feet

IV. OPERATING AMBIENT


The minimum outdoor operating ambient in cooling mode is 55°F, and the maximum outdoor operating ambient in cooling mode is 125°F.

V. ELEVATE UNIT



CAUTION: Accumulation of water and ice in base pan may cause equipment damage.

Elevate unit per local climate and code requirements to provide clearance above estimated snowfall level and ensure adequate drainage of the unit. Fig. 4 shows unit with accessory support feet installed. Use accessory snow stand in areas where prolonged freezing temperatures are encountered. Refer to separate Installation Instructions packaged with accessories.



A91277

Fig. 5—TXV Installed

VI. CHECK INDOOR EXPANSION DEVICE

	<p>CAUTION: For proper unit operation and reliability, units must be installed with balance port hard shutoff TXV specifically designed to operate with Puron® two-speed unit. Do not install with evaporator coils having capillary tube metering devices.</p>
--	--

A. FURNACE COILS

Puron® furnace coils come factory equipped with bi-flow, hard shutoff TXV s specifically designed for Puron® two-speed units. No changeout is required.

Remove existing Check-Flo-Rater™ piston from indoor coil and install field accessory TXV.

Install TXV kit to indoor coil as follows:

IMPORTANT: The TXV should be mounted as close to the indoor coil as possible and in a vertical, upright position. Avoid mounting the inlet tube vertically down. Valve is more susceptible to malfunction due to debris if inlet tube is facing down. A factory-approved filter drier must be installed in the liquid line.

PROCEDURE 1—INSTALLING TXV IN PLACE OF PISTON

1. Ensure coil has not been exposed to atmospheric pressure for more than 15 minutes.
2. Remove indoor coil inlet tube at piston body inlet. Use back-up wrench to prevent damage.
3. Remove piston retainer, being careful not to damage sealing surface of O-ring.
4. Remove and discard factory-installed piston. Replace retainer if O-ring is damaged.

NOTE: If the piston is not removed from the body, TXV will not function properly.

5. Reinstall piston retainer in piston body.
6. Replace indoor coil inlet tube. Use back-up wrench to prevent damage.

	<p>CAUTION: To prevent damage to the unit, use a brazing shield and wrap TXV with wet cloth or use heat sink material.</p>
--	---

7. Sweat swivel adapter (See Fig. 6D) to inlet of indoor coil and attach to TXV (See Fig. 6A) outlet. Use backup wrench to avoid damage to tubing or valve. Sweat inlet of TXV, marked "IN," to liquid line. Avoid excessive heat which could damage valve.

8. Install vapor elbow (See Fig. 6B) with equalizer adapter to suction tube of line set and suction connection to indoor coil. Adapter has a 1/4-in. male flare connector for attaching equalizer tube.
9. Connect equalizer tube of TXV to 1/4-in. equalizer fitting on vapor line adapter.
10. Attach TXV bulb to horizontal section of suction line using bulb strap provided. (See Fig. 6C.) Insulate bulb with factory-supplied insulation tape. (See Fig. 6E.) See Fig. 7 for correct positioning of sensing bulb.
11. Proceed with remainder of unit installation.

B. FAN COILS

Indoor unit (fan coil) comes factory equipped with a bi-flow shut-off TXV specifically designed for Puron® two-speed. No TXV changeout is required.

PROCEDURE 2—REPLACING R-22 TXV OR NON-BALANCE PORT PURON® TXV


1. Remove any existing refrigerant and ensure coil has not been exposed to atmospheric pressure for more than 15 minutes.
2. Remove coil access panel and fitting door from cabinet.
3. Remove and save TXV support clamp using a 5/16-in nut driver.
4. Remove TXV using a backup wrench on flare connections to prevent damage to tubing.
5. Using wire cutters, cut equalizer tube off flush with vapor tube inside cabinet.
6. Remove bulb from vapor tube inside cabinet.
7. Braze equalizer stub-tube closed. Use protective barrier as necessary to prevent damage to drain pan.

IMPORTANT: Route the equalizer tube of approved Puron® TXV through suction line connection opening in fitting panel prior to replacing fitting panel around tubing.

8. Install TXV (Fig. 6A) with 3/8-in. copper inlet tube through small hole in service panel. Use wrench and backup wrench, to avoid damage to tubing valve.
9. Reinstall TXV support clamp (removed in item 3).
10. Attach TXV bulb to vapor tube inside cabinet in same location as original was removed using supplied bulb straps. (See Fig. 6C.) Insulate bulb with factory-supplied insulation tape. (See Fig. 6E.) See Fig. 7 for correct positioning of sensing bulb.
11. Route equalizer tube through suction connection opening (large hole) in fitting panel and install fitting panel in place.
12. Sweat inlet of TXV, marked "IN," to liquid line. Avoid excessive heat which could damage valve.
13. Install vapor elbow (See Fig. 6B) with equalizer adapter to vapor line of line set and vapor connection to indoor coil. Adapter has a 1/4-in. male flare connector for attaching equalizer tube. (See Fig. 6B.)
14. Connect equalizer tube of TXV to 1/4-in. equalizer fitting on vapor line adapter. Use backup wrench to prevent damage to equalizer fitting.
15. Proceed with remainder of unit installation.

C. Long-Line Applications, Install Liquid-Line Solenoid Valve (LSV)

For refrigerant piping arrangements with equivalent lengths greater than 50 ft or when elevation difference between indoor and/or outdoor unit is greater than ± 20 ft, follow all requirements



A01418

Fig. 6—TXV Kit Contents

of the Long-Line Guideline section in the Application Guideline and Service Manual for Residential Split-System Air Conditioners and Heat Pumps Using Puron® Refrigerant. If required by Long-Line Application Guideline, install LSV kit Part No. KHALS0401LLS specifically designed for Puron® Heat Pumps. LSV should be installed between filter drier and indoor coil as close as possible to filter drier. Follow the Installation Instructions included with accessory kit.

IMPORTANT: Flow arrow must point toward outdoor unit.

VII. MAKE PIPING CONNECTIONS



WARNING: Relieve pressure and recover all refrigerant before system repair or final unit disposal to avoid personal injury or death. Use all service ports and open all flow-control devices, including solenoid valves.



CAUTION: Do not leave system open to atmosphere any longer than minimum required for installation. POE oil in compressor is extremely susceptible to moisture absorption. Always keep ends of tubing sealed during installation.



CAUTION: To prevent compressor damage DO NOT bury more than 36 in. of refrigerant tubing. If ANY tubing is buried, provide 6-in. vertical rise at service valve.

Outdoor units may be connected to indoor section using accessory tubing package or field-supplied refrigerant grade tubing of correct size and condition. Tubing diameters listed in Table 1 are adequate for equivalent lengths up to 50 ft. For tubing requirements beyond 50 ft, substantial capacity and performance losses can occur. Follow the recommendations in the Application Guideline and Service Manual for Residential Split-System Air Conditioners and Heat Pumps Using Puron® Refrigerant to minimize losses. Refer to Table 1 for field tubing diameters. Refer to Table 2 for accessory requirements.

If refrigerant tubes or indoor coil are exposed to atmosphere, they must be evacuated to 500 microns to eliminate contamination and

TABLE 1—REFRIGERANT CONNECTIONS AND RECOMMENDED LIQUID AND VAPOR TUBE DIAMETERS (IN.)

UNIT SIZE	LIQUID		VAPOR		VAPOR (LONG-LINE)	
	Connection Diameter	Tube Diameter	Connection Diameter	Tube Diameter	Connection Diameter	Tube Diameter
024	3/8	3/8	5/8	5/8	5/8	3/4
036	3/8	3/8	3/4	3/4	3/4	7/8
048	3/8	3/8	7/8	7/8	7/8	7/8
060	3/8	3/8	7/8	1-1/8	7/8	1-1/8

Notes:

1. Tube diameters are for lengths up to 50 equivalent ft and/or 20 ft vertical differential.
2. Do not increase or decrease tubing sizes.
3. If required by local codes, Pressure Guard™ kit is available. See Product Data Sheet for part numbers.

moisture in the system. Do not leave system open to atmosphere any longer than minimum required for installation. POE oil in compressor is extremely susceptible to moisture absorption. Always keep ends of tubing sealed during installation.

A. OUTDOOR UNIT CONNECTED TO FACTORY-APPROVED INDOOR UNIT

These outdoor units are carefully evaluated and listed with specific indoor coils for proper system performance.

IMPORTANT: Do not apply indoor coils which are not factory approved to these units.

IMPORTANT: For 036 size units matched with the FV/FK005 or FV/FK006 and the 698BNX048 matched with the FV/FK006, a piston change is required. Refer to the KHAPX0201BPA Installation Instructions for details.

B. INSTALL ADAPTER TUBE

1. Remove plastic retainer holding outdoor piston in liquid service valve.
2. Check to be sure outdoor piston is properly installed in liquid service valve.
3. Locate plastic bag taped to unit containing adapter tube.
4. Remove Teflon washer from bag and install on open end of liquid service valve. (See Fig. 8.)
5. Remove adapter tube from bag and connect threaded nut to liquid service valve. Tighten nut finger tight and then with wrench an additional 1/2 turn (15 ft-lb). DO NOT OVER TIGHTEN!

TABLE 2—ACCESSORY USAGE

ACCESSORY	REQUIRED FOR LONG-LINE APPLICATIONS* (OVER 50 FT)	REQUIRED FOR SEA-COAST APPLICATIONS* (WITHIN 2 MILES)
Coastal Filter	No	Yes
Support Feet	No	Recommended
Puron® Hard Shutoff TXV	Yes†	Yes†
Puron® Liquid-Line Solenoid Valve for Heating	LHALS0401LLS	No

* For tubing line sets between 50 and 175 ft, or more than 20 ft vertical differential refer to Application Guideline and Service Manual for Residential Split-System Air Conditioners and Heat Pumps using Puron® Refrigerant.

† Required for all applications.

TABLE 3—REQUIRED LIQUID-LINE TEMPERATURE (°F)

LIQUID PRESSURE AT SERVICE VALVE (PSIG)	REQUIRED SUBCOOLING TEMPERATURE (°F)			
	5	10	15	20
174	56	51	46	41
181	58	53	48	43
188	61	56	51	46
195	63	58	53	48
202	65	60	55	50
209	67	62	57	52
216	69	64	59	54
223	71	66	61	56
230	73	68	63	58
237	75	70	65	60
244	77	72	67	62
251	79	74	69	64
258	81	76	71	66
265	82	77	72	67
272	84	79	74	69
279	86	81	76	71
286	88	86	78	73
293	89	84	79	74
300	91	86	81	76
307	93	88	83	78
314	94	89	84	79
321	96	91	86	81
328	97	92	87	82
335	99	94	89	84
342	100	95	90	85
349	102	97	92	87
356	103	98	93	88
363	105	100	95	90
370	106	101	96	91
377	107	102	97	92
384	109	104	99	94
391	110	105	100	95
398	112	107	102	97
405	113	108	103	98
412	114	109	104	99
419	115	110	105	100
426	117	112	107	102
433	118	113	108	103
440	119	114	109	104
447	120	115	110	105
454	122	117	112	107
461	123	118	113	108
468	124	119	114	109
475	125	120	115	110
482	126	121	116	111
489	127	122	117	112
496	129	124	119	114
503	130	125	120	115
510	131	126	121	116
517	132	127	122	117
524	133	128	123	118
531	134	129	124	119
538	135	130	125	120
545	136	131	126	121
552	137	132	127	122
559	138	133	128	123
566	139	134	129	124
573	140	135	130	125
580	141	136	131	126
587	142	137	132	127
594	143	138	133	128
601	144	139	134	129
608	145	140	135	130

C. REFRIGERANT TUBING AND FILTER DRIER

CAUTION: Installation of filter drier in liquid line is required.

Connect vapor tubing to fittings on outdoor unit vapor service valve. Connect liquid tubing to filter drier. (See Table 1 and Fig. 9.) Use refrigerant grade tubing. Connect other end of filter drier to adapter tube on liquid service valve.

D. SWEAT CONNECTION

CAUTION: To avoid valve damage while brazing, service valves must be wrapped in a heat-sinking material such as a wet cloth.

Wrap service valves and filter drier with a wet cloth or heat-sinking material. Braze connections using either silver bearing or non-silver bearing brazing material. Do not use soft solder (materials which melt below 800°F). Consult local code requirements.

CAUTION: To prevent damage to unit or service valves, observe the following:

- Use a brazing shield.
- Wrap service valves with wet cloth or use a heat sink material.

E. LEAK CHECKING

Leak test all joints in indoor, outdoor, and refrigerant tubing.

F. EVACUATE REFRIGERANT TUBING AND INDOOR COIL

CAUTION: To avoid compressor damage never use the system compressor as a vacuum pump.

Refrigerant tubes and indoor coil must be evacuated using the recommended deep vacuum method of 500 microns. The alternate triple evacuation method may be used if the procedure outlined below is followed.

IMPORTANT: Never open system under vacuum to atmosphere without first breaking it open with nitrogen.





Fig. 7—Positioning of Sensing Bulb



A97556


Fig. 8—Liquid Service Valve with Sweat Adapter Tube
DEEP VACUUM METHOD

The deep vacuum method requires a vacuum pump capable of pulling a vacuum of 500 microns and a vacuum gage capable of accurately measuring this vacuum depth. The deep vacuum method is the most positive way of assuring a system is free of air and liquid water. (See Fig. 10.)

TRIPLE EVACUATION METHOD


The triple evacuation method should only be used when vacuum pump is only capable of pumping down to 28 in. of mercury and system does not contain any liquid water. Refer to Fig. 11 and proceed as follows:

1. Pump system down to 28 in. of mercury and allow pump to continue operating for an additional 15 minutes.
2. Close service valves and shut off vacuum pump.
3. Connect a nitrogen cylinder and regulator to system and open until system pressure is 2 psig.
4. Close service valve and allow system to stand for 1 hr. During this time, dry nitrogen will be able to diffuse throughout the system, absorbing moisture.
5. Repeat this procedure as indicated in Fig. 11. System will then contain minimal amounts of contaminants and water vapor.




A97555

Fig. 9—Filter Drier with Sweat Adapter Tube and Liquid Tube



A95424

Fig. 10—Deep Vacuum Graph



A95425

Fig. 11—Triple Evacuation Method

G. FINAL TUBING CHECK

IMPORTANT: Check to be certain factory tubing on both indoor and outdoor unit has not shifted during shipment. Ensure tubes are not rubbing against each other or any sheet metal. Pay close attention to feeder tubes, making sure wire ties on feeder tubes are secure and tight.


VIII. MAKE ELECTRICAL CONNECTIONS

	<p>WARNING: To avoid personal injury or death, do not supply power to unit with compressor terminal box cover removed.</p>
--	---

Be sure field wiring complies with local and national fire, safety, and electrical codes, and voltage to system is within limits shown on unit rating plate. Contact local power company for correction of improper voltage. See unit rating plate for recommended circuit protection device.

NOTE: Operation of unit on improper line voltage constitutes abuse and could affect unit reliability. See unit rating plate. Do not install unit in system where voltage may fluctuate above or below permissible limits.

NOTE: Use copper wire only between disconnect switch and unit.



A91306

Fig. 12—Line Power Connections

NOTE: Install branch circuit disconnect of adequate size per NEC to handle unit starting current. Locate disconnect within sight from and readily accessible from unit, per Section 440-14 of NEC.

A. ROUTE GROUND AND POWER WIRES

Remove access panel and control box cover to gain access to unit wiring. Extend wires from disconnect through power wiring hole provided and into unit control box. Size wires per NEC but not smaller than minimum wire size shown in Product Data Sheet.

⚠	<p>WARNING: The unit cabinet must have as uninterrupted or unbroken ground to minimize personal injury if an electrical fault should occur. The ground may consist of electrical wire or metal conduit when installed in accordance with existing electrical codes. Failure to follow this warning can result in an electric shock, fire, or death.</p>
---	--

B. CONNECT GROUND AND POWER WIRES

Connect ground wire to ground connection in control box for safety. Connect power wiring to leads provided as shown in Fig. 12.

C. CONNECT CONTROL WIRING

Route 24v control wires through control wiring grommet and connect to leads provided in control box. (See Fig. 13.)

Use No. 18 AWG color-coded, insulated (35°C minimum) wire. If thermostat is located more than 100 ft from unit, as measured along the control voltage wires, use No. 16 AWG color-coded wire to avoid excessive voltage drop.

All wiring must be NEC Class 1 and must be separated from incoming power leads.

The outdoor unit requires a minimum of 27va, 24v control power.

D. FINAL WIRING CHECK

IMPORTANT: Check factory wiring and wire connections to ensure terminations are secured properly. Check wire routing to ensure wires are not in contact with tubing, sheet metal, etc.

IX. INSTALL ELECTRICAL ACCESSORIES

A. GENERAL

Refer to the individual instructions packaged with kits or accessories when installing. The liquid line solenoid valve accessory is available on these units. See Fig. 14 for wiring diagram.

See Fig. 13 for typical accessory wiring diagrams.

X. MAKE AIRFLOW SELECTIONS

A. AIRFLOW SELECTION FOR 315AAV/315JAV FURNACES

The 315AAV/315JAV Non-Condensing Variable Speed Furnaces provide high- and low-speed blower operation to match the capacities of the compressor at high and low speeds. To select the

recommended airflow and for adjustments to the manual switches labeled SW1, A/C and CF on the control board refer to the furnace Installation, Start-Up, and Operating Instructions. The 315AAV/315JAV utilizes a control center that allows the installing technician to select the proper airflows. The A/C switch determines the airflow during high speed compressor operation. Airflow for high and low speed can be calculated at either 350 CFM per ton or 400 CFM per ton based on the positions of SW1-5.

→ B. AIRFLOW SELECTION FOR 355MAV FURNACES

The 355MAV Condensing Variable-Speed Furnaces provide high- and low-speed blower operation to match the capacities of compressor at high and low speeds. To select recommended airflow, refer to the 355MAV Installation Instructions. The 355MAV utilizes a control center that allows the installing technician to select proper airflow. For adjustments to the manual switches labeled A/C and CF and recommended switch positions, refer to Furnace Installation Instructions for setting required airflow. High-speed airflow is determined by the position of the A/C switches, and low-speed airflow is determined by the position of the CF switches.

→ C. AIRFLOW SELECTION FOR FK4 OR FV4 FAN COILS

The FK4 and FV4 provide high- and low-speed blower operation to match the capacities of compressor at high and low speeds. To select recommended airflow, refer to the FK4 or FV4 Installation Instructions. The FK4 and FV4 utilize an EASY SELECT control board that allows the installing technician to select proper airflow. The ORANGE SYSTEM TYPE JUMPER wire should be set to HP-EFF or HP-COMFORT. The BLUE AC/HP SIZE JUMPER is used to select airflow to match the outdoor unit nominal size in tons of cooling. The BLACK AC/HP CFM ADJUST jumper is used to make slight adjustments to the selected airflow tonnage. See the fan coil Installation Instructions for setting required airflow. This fan coil has an adjustable blower off delay factory set at 90 sec for high- and low-speed blower operation.

XI. START-UP


⚠	<p>CAUTION: To prevent compressor damage or personal injury, observe the following:</p> <ul style="list-style-type: none"> • Do not overcharge system with refrigerant. • Do not operate unit in a vacuum or at negative pressure. • Do not disable low-pressure switch.
---	--

⚠	<p>CAUTION: To prevent personal injury wear safety glasses, protective clothing, and gloves when handling refrigerant and observe the following:</p> <ul style="list-style-type: none"> • Back seating service valves are not equipped with Schrader valves. Fully back seat (counter clockwise) valve system before removing gage port cap.
---	--


⚠	<p>CAUTION: Do not vent refrigerant to atmosphere. Recover during system repair or final unit disposal.</p>
---	--

Follow these steps to properly start up the system:


1. The outdoor unit is equipped with a crankcase heater which operates when the compressor is OFF. Energize crankcase heater 24 hr before starting unit. To energize heater only, set indoor thermostat to OFF position and close power disconnect to unit.
2. Fully back seat (open) liquid and vapor tube service valves.
3. Unit is shipped with valve stem(s) front seated and caps installed. Replace stem caps after system is opened to refrigerant flow (back seated). Replace caps finger tight and tighten additional 1/12 turn (20 ft-lb torque) with wrench.




See notes 1, 2, and 3
A01475




See notes 1, 2, 3, 7, 8, 9, 10, and 11
A01422




See notes 1, 2, 3, and 4
A01476



See notes 1, 2, 3, 7, 8, and 12
A01423




See notes 1, 2, 3, 6, 9, and 10
A01429




See notes 1, 2, 3, 5, 7, 8, 9, 10, and 11
A01426


Fig. 13—Typical 24V Circuit Connections




See notes 1, 2, 3, 5, 7, 8, 9, 10, 11, and 13
A03033




See notes 1, 2, 3, 5, 7, 8, 9, 10, and 11
A03034



See notes 1, 2, 3, 5, 7, 8, and 12
A03035



See notes 1, 2, 3, 5, 7, 8, and 12
A03036



SUGGESTED DIP
SWITCH SETTINGS

See notes 1, 2, 3, 5, 7, 8, and 12
A01424




Fig. 13—Typical 24V Circuit Connections (Cont) and Wiring Diagram Legend

A01222

1. Wiring must conform to NEC or local codes.
2. Underlined letter on thermostat terminal indicates its usage. For example: O/W2 means O is energized in cooling mode.
3. Refer to indoor unit Installation Instructions for any additional features and wiring information.
4. Non-Programmable Model 2S01-B, when used in heat pump installations (jumper R19 NOT cut), uses O/W2 to control reversing valve.
5. Furnace must control its own second-stage operation via furnace control algorithms. Refer to furnace Installation Instructions for proper setup.
6. To activate dehumidify function on FK4 or FV4, remove J1 jumper at fan coil control board.
7. Heat pump MUST have a high-pressure switch for dual fuel applications.
8. Outdoor air temperature sensor must be attached in all dual fuel applications.
9. Thermidstat Dip Switch No. 1 should be set in ON position for heat pump installations.
10. Thermidstat Dip Switch No. 2 should be set in the ON position for dual capacity compressor operation.
11. Thermidstat Configuration Option No. 10 “Dual Fuel Selection” must be turned ON in all dual fuel applications.
12. Dual Fuel Dip Switch-D (no. 4) must be set in the ON position for dual capacity compressor operation.
13. The DE jumper located next to the DHUM terminal must be removed to enable the DEHUM input.

4. Close electrical disconnects to energize system.
5. Set room thermostat at desired temperature. Be sure the set point is below indoor ambient and is set low enough to energize desired speed.
6. Set room thermostat to COOL or HEAT and fan control to AUTO or ON as desired. Wait for appropriate time delay(s). Operate unit for 15 minutes. Check refrigerant charge.

XII. CHECK CHARGE

WARNING: Service valve gage ports are not equipped with Schrader valves. To prevent personal injury, make sure gage manifold is connected to the valve gage ports before moving valves off fully back seated position. Wear safety glasses and gloves when handling refrigerant.

Factory charge is shown on unit rating plate. To check charge in cooling mode, refer to Cooling Only Procedure. To charge in heating mode, weigh the charge in.



—10—

Adjust charge in both heating and cooling by following procedure shown on charging tables located on pink charging label on back side of access panel.

NOTE: Unit is to be charged in high capacity only. Charging in low capacity may cause compressor chattering and possible damage to the compressor.

B. COOLING ONLY PROCEDURE

1. Operate unit a minimum of 15 minutes before checking charge.
2. Measure liquid service valve pressure by attaching an accurate gage to service port.
3. Measure liquid line temperature by attaching an accurate thermistor type or electronic thermometer to liquid line near outdoor coil.
4. Refer to charging label for required subcooling temperatures.
5. Refer to Table 3. Find the point where required subcooling temperature intersects measured liquid service valve pressure.
6. To obtain required subcooling temperature at a specific liquid line pressure, add refrigerant if liquid line temperature is higher than indicated or reclaim refrigerant if temperature is lower. Allow a tolerance of $\pm 3^{\circ}\text{F}$.

C. HEATING CHECK CHARGE PROCEDURE

To check system operation during heating cycle, refer to the Heating Pump Charging Instructions on outdoor unit. This chart indicates whether a correct relationship exists between system operating pressure and air temperature entering indoor and outdoor units. If pressure and temperature do not match on chart, system refrigerant charge may not be correct. Do not use chart to adjust refrigerant charge.

NOTE: In heating mode, check refrigerant charge only when pressures are stable. If accessory vapor pressure switch is applied and operating conditions cause vapor pressure switch and thereby outdoor fan to cycle, check refrigerant charge in cooling or lower indoor dry bulb temperature. If in doubt, remove charge and weigh in correct refrigerant charge.

NOTE: When charging is necessary during heating season, charge must be weighed in accordance with unit rating plate ± 0.6 oz/ft of 3/8-in. liquid line above or below 15 ft respectively.

EXAMPLE:

To calculate additional charge required for a 25-ft line set:
 $25\text{ ft} - 15\text{ ft} = 10\text{ ft} \times 0.6\text{ oz/ft} = 6\text{ oz}$ of additional charge.

XIII. SYSTEM FUNCTIONS AND SEQUENCE OF OPERATION

The outdoor unit control system has special functions. The following is an overview of the two-speed control functions:

A. COOLING OPERATION

This product utilizes a 2-stage cooling indoor thermostat. With a call for first stage cooling (Y1), the outdoor fan and low capacity compressor are energized. If low capacity cannot satisfy cooling demand, high capacity is energized (Y1 and Y2 or just Y2) by the second stage of indoor thermostat. After second stage is satisfied, the unit returns to low-capacity operation until first stage is satisfied or until second stage is required again. When both one stage and two stage cooling are satisfied, the compressor will shut off.

NOTE: Outdoor fan motor will continue to operate for one minute after compressor shuts off, when outdoor ambient is greater than 100°F .




Fig. 15—Control Board

NOTE: When two-speed unit is operating in low-capacity cooling, system vapor (suction) pressure will be higher than a standard single-speed system or high-speed operation. This normal operation is due to the reduced capacity operating with typically larger indoor and outdoor coils.


B. ONE MINUTE SPEED CHANGE TIME DELAY

When compressor changes speeds from high to low or low to high, there is a 1-minute time delay before compressor restarts. The outdoor fan motor remains running.

C. HEATING OPERATION


This product utilizes a 3-stage heating indoor thermostat. With a call for first stage heating (Y1), the outdoor fan and low capacity compressor are energized. If low capacity cannot satisfy heating demand, high capacity is energized (Y1 and Y2) by the second stage of the indoor thermostat. Auxiliary or back up heat is controlled by third stage (W1). After second stage of heat is satisfied, the unit returns to low capacity operation until first stage is satisfied or until second stage is required again. When both one stage and two stage heating are satisfied, the compressor will shut off. See thermostat Installation Instructions for more staging information.

NOTE: If unit has not operated within the past 12 hr or following a unit power-up, upon the next thermostat high- or low-speed demand, unit operates for a minimum of 5 minutes on high speed.



A91431

Fig. 16—Resistance Values Versus Temperature



A02218

Fig. 17—View from Top of Base Pan

D. STATUS FUNCTION LIGHTS

A system control STATUS function light is located on the outdoor unit control board. (See Fig. 15). The STATUS light provides signals for several system operations. See Table 4 for codes and definitions. Table 4 also provides the order of signal importance.

NOTE: Only one code will be displayed on the outdoor unit control board (the most recent, with the highest priority).

E. FACTORY DEFAULTS

Factory defaults have been provided in the event of failure of outdoor air thermistor and/or outdoor coil thermistor. Refer to Table 6 for default and function.

F. COMPRESSOR OPERATION

When the compressor operates in two-capacity operation, the motor rotates clockwise. Both the lower and upper pistons are eccentric with the rotating crankshaft, and both compress refrigerant. When the compressor operates in single capacity the motor reverses direction (rotates counterclockwise). The lower piston becomes idle and the upper piston compresses refrigerant. During single-capacity operation the “start” and “run” windings are reversed.

G. CRANKCASE HEATER OPERATION

The two-speed control energizes the compressor crankcase heater during unit’s off cycle.

H. OUTDOOR FAN MOTOR OPERATION

The two-speed control energizes outdoor fan any time compressor is operating. The outdoor fan remains energized during the 1-minute speed change time delay and if a pressure switch or compressor overload should trip. Outdoor fan motor will continue to operate for one minute after the compressor shuts off when the outdoor ambient is greater than 100°F.

TABLE 4—LED CONTROL FUNCTION LIGHT CODE

CODE	DEFINITION	*
Constant flash No pause	No demand Stand by	10
1 flash w/pause	Low-speed operation	9
2 flashes w/pause	High-speed operation	8
3 flashes w/pause	Outdoor ambient thermistor failure	7
4 flashes w/pause	Outdoor coil thermistor failure	6
3 flashes pause 4 flashes	Thermistor out of range†	5
5 flashes pause 1 flash	Low pressure switch trip	4
5 flashes w/pause 2 flashes	High pressure switch trip	3
6 flashes w/pause	Compressor V_c/V_h trip	2
Constant light No pause No flash	Board failure	1

* Function light signal order of importance in case of multiple signal request; 1 is most important.

† Check both thermistors to determine which is faulty.

TABLE 5—DEFROST DIP SWITCH SETTINGS

TIME	DIP SWITCH #1	DIP SWITCH #2
30	up	down
60	down	up
90	down	down
120	up	up

After termination of a defrost cycle, the outdoor fan delays come on for 20 sec. This allows refrigerant system to recover outdoor coil heat and minimize the “steam cloud” effect.

I. DEFROST TIME SELECTION

The defrost interval can be field selected, dependent on local or geographical requirements. It is factory set at 90 minutes but can be changed to either 30, 60, or 120 minutes. To select defrost time, set dip switches located on the left side of the unit board (See Fig. 15). See Table 5 for Defrost Dip Switch Settings.

J. DEFROST

The dual capacity control logic for defrost function is the standard time and temperature initiated, time or temperature terminated.

Defrost only occurs at outdoor temperatures less than 50°F. The control initiates defrost when outdoor coil thermistor is 30°F (±2°) or less, and selected defrost time (interval) has been accumulated during unit operation. Termination occurs when coil thermistor reaches 80°F (±5°) or defrost period reaches a maximum of 10 minutes. Defrost will occur at the compressor capacity that is being called for. During defrost, unit operates in high or low capacity, energizes reversing valve O and auxiliary heat W2, and de-energizes outdoor fan. Upon termination, there is a 20-sec delay in outdoor fan being energized.

K. FIELD-INITIATED FORCED DEFROST

By placing a jumper across forced defrost terminals (See Fig. 15) for a minimum of 5 sec and then removing it, a defrost cycle can be initiated. The cycle occurs only if outdoor ambient is less than 50°F, regardless of outdoor coil temperature. The cycle terminates when coil thermistor reaches 80°F (±5°) or defrost period reaches a maximum of 10 minutes.

L. COMPRESSOR VOLTAGE FAILURE (6 FLASHES)

The control senses the voltage of the compressor run winding. If compressor voltage (Vc) is less than 90v when control board is calling for compressor operation, control shuts compressor off for 15 minutes with outdoor fan running. After 15 minutes (provided there is a call for Y1 or Y2), control attempts to start compressor. During this time, a code of 6 flashes appears at control board. If Vc trip occurs 3 consecutive times during a Y1 request, then low capacity operation is locked out and control responds to Y2 requests until a reset occurs. If 3 consecutive trips occur in a combination of Y1 and Y2 or all Y2 requests, then both low and high capacity operation will be locked out. The compressor voltage failure (6 flashes) can be caused by:

- compressor internal overload trip (refer to Table 7 for correct winding)
- no 208/230 volt power supply to outdoor unit
- failed compressor contactor(s)
- failure of start relay to pick-up properly.
- improper wiring.

M. PRESSURE SWITCH PROTECTION

The outdoor unit is equipped with high- and low-pressure switches. If the control senses the opening of the high or low pressure switch, it will respond as follows:

1. De-energize the compressor hi or low speed contactor,
2. Keep the outdoor fan operating for 15 minutes,

3. Display the appropriate error code on the status light (see Table 4).
4. After a 15 minute delay, if Y1 or Y2 inputs are on and the LPS or HPS is reset, energize appropriate compressor contactor, either low or high.
5. If LPS or HPS has not closed after 15 minute delay, outdoor fan is turned off. If the open switch closes anytime after the 15-minute delay, then resume operation on call for Y1 and/or Y2.

N. MAJOR COMPONENTS

TWO-SPEED CONTROL

The two-speed control board controls the following functions:

- Low- and high-compressor contactor operation
- Outdoor fan motor operation
- Crankcase heater operation
- Compressor protection
- Pressure switch monitoring
- Time delays
- Time/temperature defrost
- Defrost interval selection
- Electric heat operation during defrost mode

FIELD CONNECTIONS

The two-speed dual capacity control received 24v low-voltage control system inputs through the screw connections on the left side of the control board.

TWO-SPEED DUAL CAPACITY COMPRESSOR

The two-speed dual capacity compressor contains motor windings that provide 3500 RPM operation. Refer to Table 7 for correct winding resistance.

COMPRESSOR INTERNAL RELIEF

The compressor is protected by an internal pressure relief (IPR) which relieves discharge gas into compressor shell when differential between suction and discharge pressures exceeds 525 psi. The compressor is also protected by an internal overload attached to motor windings.

COMPRESSOR CONTROL CONTACTORS

Low and High capacity contactor coils are 24 volts. The electronic control board controls the operation of the low speed (C-L) and the high speed (C-H) contactors.

O. TEMPERATURE THERMISTORS

Thermistors are electronic devices which sense temperature. As the temperature increases, the resistance decreases. Thermistors are used to sense outdoor ambient and coil temperature. Refer to Fig. 16 for resistance values versus temperature.

If the outdoor ambient thermistor or coil thermistor should fail, a fault code appears at electronic control. The crankcase heater is turned on during all off cycles.

IMPORTANT: OUTDOOR AIR THERMISTOR PLACEMENT

Mount outdoor air thermistor underneath unit base pan lip on control box side of unit as shown in Fig. 17. Attach to base pan with adhesive tape or other field expedient means.

IMPORTANT: If outdoor air thermistor is not properly placed underneath base pan, unit may have nuisance thermistor out of range faults.

TABLE 6—FACTORY DEFAULTS

FAILED COMPONENT	FUNCTION	DEFAULT
Ambient Thermistor	Defrost Initiation	Defrost is initiated based on coil temperature and time.
Outdoor Coil Thermistor	Defrost Initiation and Termination	Defrost occurs at each time interval, but terminate after 5 minutes

XIV. FINAL CHECKS

IMPORTANT: Before leaving job, be sure to do the following:

1. Ensure that all wiring and tubing is secure in unit before adding panels and covers. Securely fasten all panels and covers.


**TABLE 7—TWO-SPEED COMPRESSOR
(WINDING RESISTANCE AT 70°F ± 20°)**

WINDING	2 TON	3 TON	4 TON	5 TON
Start (S-C)	2.280	1.850	1.459	0.740
Run (R-C)	0.770	0.745	0.552	0.356

2. Tighten service valve stem caps to 1/12-turn past finger tight.
3. Leave User's Manual with owner. Explain system operation and periodic maintenance requirements outlined in manual.
4. Fill out Dealer Installation Checklist and place in customer file.


CARE AND MAINTENANCE

For continuing high performance and to minimize possible equipment failure, periodic maintenance must be performed on this equipment. Frequency of maintenance may vary depending upon geographic areas, such as coastal applications.



A03030

→ **Fig. 18—Wiring Diagram—024, 036, 048**



A03031

→ Fig. 19—Wiring Diagram—060