



E-POW

INSTRUCTION MANUAL

1	05-09-2013	<i>DCurli</i>
REV.	DATE	R.T. Check and Approval

CONTENTS

1 FOREWORDPage 3

2 INSTALLATION.....Page 3

3 CONNECTIONS.....Page 3

4 OPERATIONPage 5

5 OUTLINE DIMENSIONS AND WEIGHTPage 6

DECLARATION OF CONFORMITY.....Page 7

TAKEDO-3VF NXP INSTRUCTION MANUAL (ATTACHED)

1 – FOREWORD

SMS wishes to thank you for choosing our products.

E-POW is a device that makes it possible to install an inverter operating in closed loop (with encoder) on any existing system without having to replace the control panel, the gearbox motor, or the electrical system of the shaft and car.

E-POW complies with European Directives 2004/108/EC and 95/16EC.

IMPORTANT

Included in E-POW there are an inverter of the very latest generation and the interface board for connection with control panel. They both contain a specific lift application software, which includes motor thermal protection.

2 – INSTALLATION

E-POW is supplied equipped with the following cables which are already connected to the relative terminals:

- one cable for connection of the device power supply to the A.C. mains.
- one shielded cable for connection of the device output to the panel.
- the shielded cables required for connection of the adaptation circuit board to the panel.

A further 8 meter length of shielded cable is supplied for the connection between control panel and motor.

E-POW is prearranged to be used in 2-speed motor existing lift systems, so that the existing shaft accessories (switches and magnets) are maintained, without any change to the wirings.

However, you need to modify the spaces, taking into consideration that the inverter default values are appropriated for slowing-down and stop distances as shown in the concerning TABLES in the inverter TAKEDO 3VF NXS/P Instruction Manual.

IMPORTANT : A free service is available: if the customer supplies, while ordering E-POW, the circuit diagram of the control panel in which the device is to be installed, SMS indicates on this diagram all the modifications required for a correct application.

3 – CONNECTIONS

CAUTION! Before making the connections bring the car to an intermediate floor and disconnect all the power circuits.

IMPORTANT : E-POW is prearranged for connection to panels with control voltage between 48Vdc and 120Vdc. If the control voltage is outside this range or AC, ensure you make a specific request for your application at the time of the order.

3.1 POWER CIRCUIT

The power connection of E-POW must be made up line of the power contactors: always check to ensure that the operation transformer supply is taken up line from E-POW.

- Connect the three-phase power supply to the input cable (3 Core + Earth, unshielded), which is connected to terminals L1, L2, L3.
- Connect the output cable (3 Core + Earth, shielded, connected to drive terminals U, V, W) to the panel contactors.

IMPORTANT

The connection between contactors and motor (i.e. between control panel and motor) must be made using the shielded cable (3-core + Earth) supplied with the equipment.

The cable shield must be connected to earth at both ends.

- Bond the earth conductors and the shield to the control panel earth and to the gearbox earth.

CAUTION!

When E-POW is connected, problems are created with type AC 30mA residual current devices. When installing an inverter drive, to avoid nuisance tripping of the residual current circuit breaker and ensure effective protection in compliance with regulations, proceed as follows:

- Make sure the building has an efficient earth circuit.
- **Install type B residual current devices rated 300mA.**
- Wire and bond earth connections efficiently (refer to the inverter drive manual).

3.2 ENCODER CONNECTION

Connect the encoder through the shielded cable it is equipped with, directly to the Encoder Board type NXOPTA5 installed inside the drive, following the hints existing on the TAKEDO 3VF NXP Manual.




Fig. 1 : Power connection

3.3 ADAPTATION CIRCUIT BOARD

List of conductors to connect to the adaptation circuit board:

QC1	Board power supply Connect to the point of the safety chain at which the contactor circuit is supplied.
QC2	Board power supply common. Connect the common of the control voltage feeding the contactor circuit.
CF1	Slow Speed Command. Connect directly to the low speed contactor, or connect between CF and CF1 a “free voltage” normally open contact of the same contactor.
QU, QUA	Command for the upward run contactor. Interrupt the connection between the up command of the control panel and the coil of the upward run contactor. Then connect the wire from the control panel command to terminal QU and the coil of the upward run contactor to terminal QUA.
QD, QDA	Command for the downward run contactor. Interrupt the connection between the down command of the control panel and the coil of the downward run contactor. Then connect the wire from the control panel command to terminal QD and the coil of the downward run contactor to terminal QDA.

QP+, QP-	Start permit. Connect respectively to the positive and negative poles of the operation circuit, <u>down line of the safety chain contacts</u> .
IM	Command for operation in inspection mode. Connect in such a way that, when the inspection service is enabled by means of the specific control station on the car roof, a contact closes between CF and IM. This is to assure the proper working sequence and the car run in medium speed (< 0,63 m/sec).

CAUTION!

In the event of uncertainty, please consult SMS for advice about the correct connection of the adaptation board.

3.4 BRAKE CONTROL

E-POW features internal contactor TF to control the BRAKE: the TAKEDO 3VF NXP drive manages the brake control logic directly so that the relative contactor opens only in conditions of safety (motor supplied with power, with current balanced on all three phases) and closes when the motor stops as the car reaches a floor.

Contactor TF is wired by SMS; the two conductors TFL2 – TFL3 must be connected in series with the brake coil power supply.




Fig. 2: Connection of the brake control contactor

3.5 FURTHER NOTES ABOUT THE APPLICATION

1. E-POW operates in closed loop, so, to assure the encoder right operation, it is essential that the run direction is managed by the drive, which has to control and reverse the motor phases.
In the existing control panel you need to modify the power circuit, in order that the up / down contactors don't reverse the motor phases.
2. E-POW controls the High Speed winding of the motor: disconnect the Low Speed winding.
3. Make sure that the door opening command for the automatic doors (if any) is enabled after the contactor de-energization (controlled by E-POW).
4. Make sure that the Retiring Cam (if any) unlocks the door after the contactor de-energization.

4 – OPERATION

When it receives an up or down run command from the control panel, E-POW activates the contactors and, via the inverter drive, causes the car to move.

If the SW1 switch is set to RUN and the CF1 command is OFF, the movement is performed at high speed; when the CF1 command from the control panel turns ON, the low speed level is set and the car decelerates. When the car reaches the floor level, CF1 and QU/QD are disabled: the drive stops the motor electrically and afterwards E-POW controls the brake deactivation and then contactors deactivation.

There isn't any MAXIMUM RUN TIME, neither in high speed nor in low speed, in order to avoid ill-timed action of these protections in case of last long runs or long distances covered in low speed, for instance during set-up (these controls are usually already included into the most recent control panels).

If the SW1 switch is set to MAN, the car moves in the selected direction at the inspection speed, as long as the control panel command or the up/down command from the board push-buttons remains active: when the command breaks off, the car stop instantly, with the brake release.

During all operations, E-POW controls the brake contactor TF. When the drive detects an alarm situation, the brake is released instantly.

4.1 SETUP

After having made the CONNECTIONS, open the cover of E-POW and close the main power switch, keeping the operation valve open.

The first task is to enter the motor data in the drive in the "BASIC PARAMETERS" group.

Instructions on how to edit parameters are provided in the attached TAKEDO 3VF NXS/P Manual.

The green IOK led must illuminate on the circuit board; the green MR led flashes.

Check that switch SW1 is set to RUN and close the operation valve.

Make a call for an upper floor, checking that the motor rotates in the correct direction. If the motor turns in the wrong direction, invert two of the conductors in the motor terminal box.

Then check if the encoder rotation direction is right (see TAKEDO 3VF NXP Instruction Manual).

Once you have checked the correct rotation directions, return the car to an intermediate floor. Make another call: the following Led will illuminate on the board: QU/QD, QUA/QDA, QP (if not already lit), RUN and TF.

The deceleration and stopping sequence is as follows: in the slowing-down zone the led CF lights on, the car decelerates and arrives at the floor. Led CF and QU/QD switch off and then the following leds switch off in sequence (with a short delay from one to the next): TF, RUN, QUA/QDA and QP.

Setting the SW1 switch to MAN; led IM should illuminate. In this condition E-POW controls the motor in up or down direction by pressing one of the buttons on the circuit board.

IMPORTANT

The push-buttons on the circuit board which control car movement when switch SW1 is set to MAN, only operate if Led QP is illuminated, i.e. only if the safety chain contacts are closed.

Once the operations described above have been concluded successfully, operation of the installation can be optimized. Acceleration, deceleration, and final deceleration can all be adjusted.

To reduce installation times it is good practice to make the adjustments on just one floor, performing up and down runs until obtaining satisfactory stopping performance. The magnets for the other floors must be identical and positioned in the same place, perfectly centred with respect to the floor.

4.2 KEY TO SIGNALLING LEDS

MR	= flashing: indicates the board is working correctly
IM	= inspection service
IOK	= inverter ready
QD	= down command
QU	= up command
QUA	= up contactor command
QDA	= down contactor command
CF	= low speed command
QP	= safety chain contacts closed
RUN	= run command for drive
TF	= brake contactor command

5 – OUTLINE DIMENSIONS AND WEIGHT

SIZE (kW)	Width (mm)	Height (mm)	Depth (mm)	Weight (kg) (approximate)
5,5 – 7,5 – 11 (*1)	300	615	240	17
15 – 18,5 – 22 (*2)	300	615	260	36

(*1) For sizes 7,5 – 11kW, N°1 EXTERNAL Braking Resistor (50Ω 1500W)

(*2) For sizes 15 – 18,5kW, N°2 EXTERNAL Braking Resistors (50Ω 1500W)

For size 22kW, N°3 EXTERNAL Braking Resistors (50Ω 1500W)

BRAKING RESISTOR	Width (mm)	Height (mm)	Depth (mm)	Weight (kg) (approximate)
50Ω 1500W	480	110	140	2

For further information and advice contact:

SMS SISTEMI e MICROSISTEMI s.r.l. (Gruppo SASSI HOLDING)

Cap. Soc. 260.000 i.v.

Via Guido Rossa, 46/48/50 40056 Crespellano BO

R.E.A 272354 CF - Reg. Imprese Bo 03190050371 P.IVA IT 00601981202

Tel. : +39 051 969037 Fax : +39 051 969303 Technical Service: +39 051 6720710

Web : www.sms.bo.it E-mail : sms@sms.bo.it



DECLARATION OF CONFORMITY

Manufacturer: **SMS SISTEMI E MICROSISTEMI s.r.l.**

Address: **Via Guido Rossa, 46/48/50 – 40056 Crespellano (BO)**

Product: **E-POW (equipped with VACON NXP inverter drive)**

The above product complies with the following EUROPEAN DIRECTIVES:

- **95/16/EC** **LIFTS**
- **2004/108/EC** **ELECTROMAGNETIC COMPATIBILITY**


when installed as prescribed by the relative user manual.

To evaluate the product's compliance, reference was made to the following STANDARDS:

- **UNI EN 81.1: 2010**
- **EN 12015: 2005**
- **EN 12016: 2008**

DATE: 21-12-2012

SMS Sistemi e Microsistemi s.r.l.



Ing. VITTORIO MAZZONI
CHIEF EXECUTIVE OFFICER