






Compact Performance CP Modules Electronics



Input modules type CP-E16...-M...-...
Output modules type CP-A08...-M12-...

FESTO

Manual
165 225 GB
9909c

Author: S. Breuer
Editors: H.-J. Drung, M. Holder
Layout: Festo, KI-TD
Typesetting: KI-TD

Edition: 9909c

© (Festo AG & Co., D-73726 Esslingen,
Federal Republic of Germany, 1999)

Printed on 100 % recycled paper

The copying, distribution and utilization of this document as well as the communication of its contents to others without expressed authorization is prohibited. Offenders will be held liable for the payment of damages. All rights reserved, in particular the right to carry out patent, utility model or ornamental design registrations.

Part no. 165 225
Title: Manual
Designation: P.BE-CPEA-GB

Contents

Designated use	IV
Target group	V
Important user instructions	V
Information on this manual	VII

1. Input module type CP-E16...-M...-...

1.1	Mode of operation of input modules CP-E16...-M...-...	1-3
1.1.1	Display and connecting elements	1-4
1.2	Fitting	1-6
1.3	Installation.	1-10
1.3.1	Configuring for PNP or NPN mode (type CP-E16-M8-Z only)	1-11
1.3.2	Connecting the separate sensor supply (type CP-E16-M8-Z only)	1-12
1.3.3	Connecting the sensors	1-15
1.3.4	Connecting the input module	1-26
1.4	Instructions on commissioning	1-28
1.5	Technical data	1-33

2. Output module type CP-A08...-M12-...

2.1	Overview.	2-3
2.2	Fitting	2-4
2.3	Installation.	2-5
2.3.1	Connecting the actuators	2-6
2.3.2	Connecting the output module	2-13
2.3.3	Connecting the load voltage.	2-14
2.4	Instructions on commissioning	2-17
2.5	Technical specifications	2-20

A. Index

Designated use

The CP modules described in this manual have been designed exclusively for use on a CP string, an axis interface string or a CP branch line in conjunction with a CP field bus node, the SPC200 Smart Positioning Controller or the Powerbox type CP-FB-TBOX-SUBD9. CP modules and CP cables may only be used as follows:

- as intended for use
- in original condition
- without unauthorized modifications
- in faultless technical condition

If used in conjunction with commercially-available components such as sensors and actuators, the specified limit values for pressures, temperatures, electrical data, torques etc. must be observed. Please comply also with national and local safety laws and regulations.

All CP modules comply with protection class III.

**WARNING**

Use only power units which guarantee reliable isolation of the operating voltages as per IEC 742/ EN 60742/VDE 0551 with at least 4 kV isolation resistance (protected extra low voltage, PELV). Switch power packs are permitted if they guarantee reliable isolation in accordance with EN 60950/ VDE 0805.

Target group

This manual is directed exclusively at technicians who are trained in control and automation technology.

Important user instructions

Danger categories

This manual contains instructions on the possible dangers which may occur if the CP modules are not used correctly. These instructions are always printed in italics, are framed and also signalled by pictograms.

A distinction is made between the following:



WARNING

This means that personal injury or damage to property may occur if these instructions are not observed.



CAUTION

This means that damage to property may occur if these instructions are not observed.



PLEASE NOTE

This means that this instruction must also be observed.

Pictograms Pictograms and symbols complement the danger warnings and draw attention to the nature and consequences of dangers.

The following pictograms are used:



Uncontrolled movements of loose tubing.



Unintentional movements of the connected actuators.



High voltages or undefined switching states of the electronic components which may influence connected circuits.



Electrostatically vulnerable components.
These will be damaged if you touch the contact surfaces.

Text markings



- This mark indicates activities which can be carried out in any order.

1. Figures indicate activities which must be carried out in the numerical order of the figures.

– Hyphens indicate general, non-compulsory activities.

Information on this manual

CP I/O modules are available both as PNP (positive-switching) and NPN (negative-switching). The positive-switching modules with M12 connection are available in 4-pin and 5-pin forms. The 5-pin design has an earth connection. This manual contains specific information on the method of operation, fitting, installation and commissioning of the following CP modules:

This manual refers to:	
	Input modules: PNP - CP-E16-M8 - CP-E16-M12x2 - CP-E16-M12x2-5POL NPN - CP-E16N-M8 - CP-E16N-M12x2 PNP or NPN - CP-E16-M8-Z
	Output modules: PNP - CP-A08-M12 - CP-A08-M12-5POL NPN - CP-A08N-M12

Information on further modules as well as basic information which must be observed in conjunction with the higher-order system, can be found in the manuals for the relevant system.

Manuals for the CP system				Peripherals
Manual	"CP system, Installation and commissioning" type P.BE-CPSYS-...			
Contents	General, basic information on operating, fitting, installing and commissioning CP systems.			
Manual	"CP field bus node, programming and diagnosing" type P.BE-CPV-...	"CPV valve terminal, CPA valve terminal, pneumatics" type P.BE-CPV-... or type P.BE-CPA-...	"CP modules, electronics"	
Contents	Special information on commissioning, programming and diagnosing related to the node used.	Information on fitting, installing and commissioning CP valve terminals	Information on fitting, installing and commissioning CP I/O modules	

Fig. 0/1: CP system manuals


Manuals on the SPC200 Smart Positioning Controller			Periphery
Manuals	SPC200 Smart Positioning Controller, User manual type P.BE-SPC200-...	Manual WinPISA type P.SW-WIN-PISA-...	<div>Manuals on:</div> <ul style="list-style-type: none">- proportional directional control valves- service unit- measuring system- cylinders or linear drives
Contents	Installation, commissioning and diagnosis with the SPC200; Standard components and modules	Functions of the WinPISA software package	
Manual	"CPV valve terminal, pneumatics" type P.BE-CPV-...	"CP modules, electronics" type P.BE-CPEA-...	
Contents	Information on the CPV valve terminals	Information on the CP-I/O modules	
<div><div></div></div>			

Fig. 0/2: Manuals for the SPC200

Chapter 1

Input module type CP-E16...-M...-...






Contents

Input module type CP-E16...-M...-...

1.1	Mode of operation of input modules CP-E16...-M...-...	1-3
1.1.1	Display and connecting elements	1-4
1.2	Fitting	1-6
1.3	Installation	1-10
1.3.1	Configuring for PNP or NPN operation (type CP-E16-M8-Z only)	1-11
1.3.2	Connecting the separate sensor supply (type CP-E16-M8-Z only)	1-12
1.3.3	Connecting the sensors	1-15
1.3.4	Connecting the input module	1-26
1.4	Instructions on commissioning	1-28
1.5	Technical data	1-33

1.1 Mode of operation of input modules CP-E16...-M...-...

The CP input modules contain digital inputs for connecting sensors, thereby enabling e.g. cylinder positions to be interrogated. A distinction is made between the following types:

Type	Explanation
CP-E16-M12X2-... 	Provides 16 PNP inputs; sensor connections via 8 sockets with M12 thread
CP-E16N-M12X2 	Provides 16 NPN inputs; sensor connections via 8 sockets with M12 thread
CP-E16-M8 	Provides 16 PNP inputs; sensor connections via 16 sockets with M8 thread
CP-E16N-M8 	Provides 16 NPN inputs; sensor connections via 16 sockets with M8 thread
CP-E16-M8-Z 	Provides 16 PNP or 16 NPN inputs and a separate connection for the sensor supply voltage

1. Input module type CP-E16...-M...-...

FESTO

1.1.1 Display and connecting elements

The diagram below shows the display and connecting elements using the example of input module CP-E16-M12x2.




Fig. 1/1: Display and connecting elements

1. Input module type CP-E16...-M...-...



The following illustration shows the additional display and connection points for the CP-E16-M8-Z input module.




Fig. 1/2: Additional features of type CP-E16-M8-Z

1.2 Fitting

Input modules are intended for fitting onto walls or hat rails. For fitting them onto walls you will require the following surface areas:

Type	Surface area
CP-E16-M8	Approx. 150 mm x 66 mm
CP-E16-M8-Z	Approx. 217 mm x 66 mm
CP-E16-M12x2-...	Approx. 141 mm x 78 mm

Fitting on
a wall

The diagram below shows the dimensions of the four threaded holes of screw size M4.




Fig. 1/3: Fitting dimensions CP-E16...-M...-...



PLEASE NOTE

For fitting the modules onto a hat rail you will require fastening kit CP-TS-HS35. This kit contains 2 fastenings, 2 M4x12 screws and 2 washers.

Fitting onto a
hat rail

In order to fit the modules onto a hat rail, proceed as follows:

1. Make sure that the fastening surface can support the weight of the module.
2. Fit a hat rail (support rail EN 50022 - 35x15; width 35 mm, height 15 mm).
3. Fasten the hat rail at least every 100 mm to the support surface.
4. Let both fastenings on the hat rail snap into the module (see Fig. 1/4).
5. Screw the housing on to the fastening with the screws supplied as shown in the diagram below.
6. Tighten the screws. The fastening and the housing will then be clamped tight on the hat rail.




Fig. 1/4: Fitting on a hat rail

In order to remove the module from a hat rail, proceed as follows:

1. Loosen the screws.
2. Remove the housing.
3. Use a screwdriver to prize open the hat rail and remove the module.




Fig. 1/5: Removing the module

1.3 Installation



WARNING

Before undertaking installation work, switch off the following:

- *the operating voltage supply and the load voltage supply on the higher-order system (e.g. CP field bus node)*
- *if necessary, the separately supplied voltage supplies.*



You thereby avoid:

- unintentional movements of the connected actuators.
- undefined switching states of the electronic components.




WARNING

Connect the earth cable on the side of the housing (see Fig. 1/1) with low impedance (short cable with large cross-sectional area) to the earth potential. In this way you can avoid interference caused by electromagnetic influences.

1.3.1 Configuring for PNP or NPN operation
(type CP-E16-M8-Z only)

The CP-E16-M8-Z input module provides PNP or NPN inputs. A bridge must be installed in the sensor supply socket for setting to either PNP or NPN mode. The following illustrations show the rear of the socket.



Pin assignment	
Pin 1	+ 24 V DC \pm 25 %
Pin 2	PNP/NPN
Pin 3	0 V
Pin 4	NC
Pin 5	Earth connection

Fig. 1/6: Configuring for PNP or NPN
(type CP-E16-M8-Z only)

1.3.2 Connecting the separate sensor supply
(type CP-E16-M8-Z only)



WARNING

Use only power units which guarantee reliable isolation of the operating voltages as per IEC 742/ EN 60742/VDE 0551 with at least 4 kV isolation resistance (protected extra low voltage, PELV). Switch power packs are permitted if they guarantee reliable isolation in accordance with EN 60950/ VDE 0805.



By using PELV power units, protection against electric shock (protection against direct and indirect contact) in accordance with EN 60204-1/IEC 204 is guaranteed on Festo valve terminals. Safety transformers with the adjacent designation must be used for supplying PELV networks. The CP input modules must be earthed in order to ensure their function (e.g. EMC).

The sensors are supplied with DC + 24 V through the sensor supply connection. The module allows sensors having higher current draw to be used (max. 125 mA per sensor).

The following illustration shows the pin assignment as well as a connection example for PNP mode (bridge between pins 2 and 3). See also "Configuring for PNP or NPN operation", section 1.3.1.




Fig. 1/7: Pin assignment and wiring example for sensor supply (PNP mode)



PLEASE NOTE

- *Always connect earth to pin 5 of the sensor supply.*
- *Make sure the connection between the earth terminal on the left housing side and GND is low-resistance (short lead, large gauge).*
- *Use low-resistance connections to ensure that the module housing and the earth connection on pin 5 are at the same potential and no compensation current flows.*

In this way you will avoid electromagnetic disturbances.

1.3.3 Connecting the sensors

**WARNING**

When using the CP-E16-M8-Z input module, make sure that pin 2 on the sensor supply connection is bridged according to the operating mode of your system (PNP or NPN, see section 1.3.1).

Use the following cable and plugs for connecting the sensors.

Type	Plug	Cable
CP-E16...-M12x2	SEA-GS-7 (PG7) SEA-WS-7 (PG7)	KM12-DUO-...
CP-E16-M12x2-5POL	Use the plug with union nut with thread M12x1.	
CP-E16...-M8 and CP-E16-M8-Z	Use the plug with union nut with thread M8x1 (outer diameter max. 12 mm).	KM8-M8-GSGD-...

Fasten the plugs with the aid of the union nuts in order to avoid unintentional loosening e.g. due to vibration. Seal the unused sensor connections with the protective caps supplied. Only then is compliance with class of protection IP65 ensured.

Pin assignment (inputs PNP and NPN)

The following diagrams show the pin assignment of the sensor connections of the different CP input modules.




Fig. 1/8: Pin assignment typ CP-E16...-M8 and CP-E16-M8-Z




Fig. 1/9: Pin assignment typ CP-E16...-M12x2

1. Input module type CP-E16...-M...-...

FESTO




Fig. 1/10: Pin assignment type CP-E16-M12x2-5POL

Internal layout of CP-E16-M8 (PNP inputs)
and CP-E16-M8-Z (PNP mode)




Fig. 1/11: Internal layout

Circuitry examples types CP-E16-M8 (PNP inputs)
and CP-E16-M8-Z (PNP mode)




Fig. 1/12: Circuitry examples

Internal layout of CP-E16-M12x2-... (PNP inputs)




Fig. 1/13: Internal layout

Circuitry examples of CP-E16-M12x2-...
(PNP inputs)




Fig. 1/14: Circuitry examples

Internal layout of CP-E16N-M8 (NPN inputs)
and CP-E16-M8-Z (NPN mode)




Fig. 1/15: Internal layout

Circuitry examples of CP-E16N-M8 (NPN inputs)
and CP-E16-M8-Z with NPN operation




Fig. 1/16: Circuitry examples

Internal layout of CP-E16N-M12x2 (NPN inputs)




Fig. 1/17: Internal layout

Circuitry examples of CP-E16N-M12x2
(NPN inputs)




Fig. 1/18: Circuitry examples

1.3.4 Connecting the input module



WARNING

Please observe the maximum permitted string lengths in each case. You will then avoid faults in data exchange between the input module and the higher-order system (e.g. the field bus node). Use only the following cables for connecting the modules:

For connection to	Max. permitted string length	Cable type
Field bus node with CP connection	10 m	- KVI-CP-1-... or - KVI-CP-2-... (can be used as drag chain)
Axis interface type SPC-AIF-...	See manual for SPC200 type P.BE-SPC200-...	
Powerbox type CP-FB-TBOX-...	See manual for higher-order system	

The following functions are provided for the module through the CP cable:

- Supply voltage for the internal electronics
- Data exchange connection
- For input modules not having a sensor supply connection: Operating voltage for the connected sensors.

Input modules can be connected to one of the following:

- the CP connection of the higher-order system (field bus node, axis interface or Powerbox)
- the CP connection of an output module
- the CP connection of a valve terminal

Further instructions can be found in the appropriate system manuals.

1.4 Instructions on commissioning



WARNING

Please be careful if you modify the line assignment of your CP system at a later stage. After saving the string assignment or hardware configuration, check the address assignment of your higher-order system before you start user programs.

You thereby avoid:

- addressing errors if CP modules are incorrectly fitted.

With the CP field bus node, the new string assignment must be saved if it has been modified (CP modules added or removed). To do this press the SAVE button on the node. Proceed as described in the manual "CP system, installation and commissioning."







With the SPC200, the new hardware configuration must also be saved if the string assignment has been modified. Proceed here as described in the manual for the SPC200 or for WinPISA.

Status LED

The operating status of the input module is shown by the status LED on the CP connection (see following table).

1. Input module type CP-E16...-M...-...

FESTO

Status LED	Sequence	Operating status	Error treatment
 LED lights up	ON  OFF	Operating voltage applied	None
 LED is out	ON  OFF	- Operating voltage not applied or no connection to higher-order system or In conjunction with CP node: - incorrect string assignment ascertained during operation In conjunction with SPC200: - see user manual for SPC200	<ul style="list-style-type: none"> • Check CP cable and operating voltage connection on higher-order system or • Correct string assignment • See user manual type P.BE-SPC200
 LED flashes	ON  OFF	- Test phase after voltage is switched on or - short circuit in sensor supply ³⁾ or Type CP-E16-M8-Z: - Sensor supply voltage too low (< 17 V) or In conjunction with CP node: - incorrect string assignment when voltage is switched on In conjunction with the SPC200: - see user manual for SPC200	<ul style="list-style-type: none"> • None or • Eliminate short circuit and delete error¹⁾ or • Eliminate undervoltage • Check string assignment²⁾ • See user manual type P.BE-SPC200

1) For type CP-E16-M8-Z the error is automatically cleared. In other modules the error is cleared by disconnecting the input module from the branch or by resetting the supply voltage on the host system.

2) After changing the branch configuration (adding or removing CP modules) the new branch configuration must be stored by pressing the SAVE button on the node (see "CP System, Installation and Commissioning").

3) With type CP-E16-M8-Z the short-circuit LED for the appropriate input group lights up.

Short circuit of the sensor supply on input module CP-E16-M8-Z

When there is a short circuit, the input module switches off the supply voltage for the corresponding input group and reports the fault to the host system. The short circuit LED on the corresponding input group lights up.




Fig. 1/19: Short circuit indicators for CP-E16-M8-Z

The status LEDs for the corresponding input group are switched off and the corresponding inputs are at 0. The other input group remains operational. After removing the short circuit the error is **self-clearing**.

Short circuit in sensor supply for input modules without sensor supply connection

If there is a short circuit, the input module will switch off the power supply to the sensors and lock them in this state. It will also communicate the error to the higher-order system. The status LEDs will be switched off and the inputs of the module will transmit a 0-signal. When the short circuit has been eliminated, you can delete this error as follows:

In conjunction with the CP field bus node:

- Disconnect the input module briefly from the line, or
- switch off the power supply at the node and then switch it on again.

In conjunction with the SPC200:

- Proceed as described in the user manual type P.BE-SPC200.

Replacing
the CP
module

If there is a fault in the CP module during operation, you can replace the module with one of the same type, even during operation.












PLEASE NOTE

Observe here the instructions in the manual for the higher-order system (e.g. CP system, CP field bus node, SPC200).

Status display

Next to the sensor connections there is/are one or two green LEDs. These indicate the state of the signal at the relevant input. The meanings are as follows:

Status LED	Sequence	Status
 LED lights up	ON  OFF 	1-signal
 LED is out	ON  OFF 	0-signal
 LED flashes	ON  OFF 	Only during switch-on phase: - if there is a 1-signal and - if there is a line assignment error.

**PLEASE NOTE**

*In conjunction with the CP field bus node:
If there is a line assignment error during the switch-on phase, the CP node will switch the power supply to the input module and also the power supply to the connected sensors on and off cyclically. In this case, the status LEDs and the LEDs of the connected sensors will therefore flash, providing they transmit a 1-signal.*

1.5 Technical data

Technical data	Type CP-E16-M8-Z positive-switching (PNP) or negative-switching (NPN) mode
Temperature range: - Operation - Storage/transport	- 5 °C... + 50 °C - 20 °C... + 70 °C
Relative humidity	95 % non condensing
Protection class as per EN 60529; plug connector attached or fitted with cover cap	IP65
Shock protection as per EN 60204/IEC 204	(Protection against direct and indirect contact) when connected to a PELV power supply (Protected Extra- Low Voltage)
Electromagnetic compatibility - Interference emission - Resistance to interference	Tested as per EN 55011 limit class B Tested as per EN 50082-2
Digital inputs - Type - Logic level positive-switching ON OFF - Logic level negative-switching ON OFF - Current consumption (at 24 V) (input current from sensor to input) - Response delay (at 24 V)	16 inputs as per IEC 1131-2 type 2 inputs 24 V DC positive or negative-switching PNP (referenced to 0 V): ≥ 8.6 V ≤ 6 V NPN (referenced to 24 V): ≤ 6 V ≥ 8.6 V For "logic 1" Typ. 8 mA Typ. 3 ms
Sensor supply V_D 24 V ± 25 %	Max. 1 A per input group (electronic short circuit protection per group)
Galvanic isolation	None
Internal current consumption (electronics)	< 40 mA

1. Input module type CP-E16...-M...-...

FESTO

Technical data	Positive-switching input modules (NPN) without separate sensor supply connection	
	Types CP-E16-M8 and CP-E16-M12x2	Type CP-E16-M12x2-5POL
Temperature range: - Operation - Storage/transport	- 5 °C... + 50 °C - 20 °C... + 70 °C	
Relative humidity	95 % non condensing	
Protection class as per EN 60529; plug connector attached or fitted with cover cap	IP65	
Shock protection as per EN 60204/IEC 204	(Protection against direct and indirect contact) when connected to a PELV power supply (Protected Extra-Low Voltage)	
Electromagnetic compatibility - Interference emission - Resistance to interference	Tested to EN 55011 limit class B Tested to EN 50082-2	Tested to EN 55011 limit class B Tested to EN 50082-2
Digital inputs - Type - Logic level: ON OFF - Current consumption (at 24 V) (input current from sensor to input) - Response delay (at 24 V)	16 inputs as per IEC 1131-2 type 2 inputs 24 V DC positive-switching > 11 V < 5 V For "logic 1" Typ. 8 mA Typ. 5 ms	16 inputs as per IEC 1131-2 type 2 inputs 24 V DC negative-switching ≥ 8.6 V ≤ 6 V For "logic 1" Typ. 6 mA Typ. 3 ms
Sensor supply V_D 24 V ± 25 %	Max. 0.5 A (electronic short circuit protection)	
Galvanic isolation	None	
Internal current consumption (electronics)	< 40 mA	Max. 90 mA

1. Input module type CP-E16...-M...-...

FESTO

Technical data	Negative-switching input modules (NPN)
	Type CP-E16N-M8 and type CP-E16N-M12x2
Temperature range: - Operation - Storage/transport	- 5 °C ... + 50 °C - 20 °C ... + 70 °C
Relative humidity	95 % non condensing
Protection class as per EN 60 529; plug connector attached or fitted with cover cap	IP65
Shock protection as per EN 60204/ IEC 204	(Protection against direct and indirect contact) when connected to a PELV power supply (Protected Extra-Low Voltage)
Electromagnetic compatibility - Interference emission - Resistance to interference	Tested as per EN 55011 limit value class B Tested as per EN 50082-2
Digital inputs - Type - Logic level: ON OFF - Current consumption (at 24 V) (input current from sensor to input) - Response delay (at 24 V)	16 inputs as per IEC 1131-2 type 2 inputs 24 V DC negative switching < V_D -11 V > V_D - 5 V For "logic 0" Typ. 8 mA Typ. 5 ms
Sensor supply V_D 24 V \pm 25 %	Max. 0.5 A (electronic short circuit protection)
Galvanic isolation	None
Internal current consumption (electronics)	Max. 90 mA

Chapter 2

Output module type CP-A08...-M12-...

Contents

Output module type CP-A08...-M12-...

2.1	Overview	2-3
2.2	Fitting	2-4
2.3	Installation.	2-5
2.3.1	Connecting the actuators	2-6
2.3.2	Connecting the output module	2-13
2.3.3	Connecting the load voltage.	2-14
2.4	Instructions on commissioning	2-17
2.5	Technical specifications	2-20

2. Output module type CP-A08...-M12-...

FESTO

2.1 Overview

Output module type CP-A08...-M12-... provides 8 universally usable digital outputs for controlling low-current consuming devices (bulbs, further valves etc). The following diagram shows the display and connecting elements on the output module.




Fig. 2/1: Display and connecting elements

2.2 Fitting

The output module is intended for fitting onto a wall or a hat rail. It requires a fitting surface of approximately 173 mm x 78 mm.

Fitting
on a wall

The diagram below shows the dimensions for the four threaded holes for the M4 screws.




Fig. 2/2: Fitting dimensions

Fitting on a
hat rail

Fitting onto a hat rail is undertaken in exactly the same way as with input modules CP-E16...-M... (see section 1.2).

2.3 Installation

**WARNING**

Before undertaking maintenance work, switch off:

- *the load voltage supply to the relevant output modules.*

Also switch off the following before undertaking installation work:

- *the voltage supply for the higher-order system*
- *the power supply to all the output modules.*



You thereby avoid:

- unintentional movements of the connected actuators.
- undefined switching states of the electronic components.

**WARNING**

Connect the earth cable on the side of the housing (see Fig. 2/1) with low impedance (short cable with large cross-sectional area) to the earth potential. In this way you can avoid interference caused by electromagnetic influences.

2.3.1 Connecting the actuators

Use plugs with union nuts with M12 thread for connecting the actuators. Fasten the plugs with the aid of the union nuts in order to avoid unintentional loosening e.g. due to vibration.

Seal the unused sensor connections with the protective caps supplied. Only then is compliance with class of protection IP65 ensured.

Pin assignment of the actuator connections
CP-A08-M12-... (PNP outputs)




Fig. 2/3: Pin assignment of output module CP-A08-M12

2. Output module type CP-A08...-M12-...

FESTO

By means of internal connections, two outputs can be connected to each of the output sockets 0, 2, 4 and 6 on the CP output module type CP-A08-M12-5POL.




Fig. 2/4: Pin assignment of output module CP-A08-M12-5POL

Internal layout of CP-A08-M12-... (PNP outputs)




Fig. 2/5: Internal layout of output module CP-A08-M12-...

Circuitry examples of CP-A08-M12-... (PNP outputs)




Fig. 2/6: Circuitry examples of output module CP-A08-M12-...

2. Output module type CP-A08...-M12-...

FESTO

Pin assignment of the actuator connections
CP-A08N-M12 (NPN outputs)




Fig. 2/7: Pin assignment of output module CP-A08N-M12

Internal layout of CP-A08N-M12 (NPN outputs)




Fig. 2/8: Internal layout of output module CP-A08N-M12

Circuitry examples of CP-A08N-M12 (NPN outputs)




Fig. 2/9: Circuitry examples of output module CP-A08N-M12

2.3.2 Connecting the output module



WARNING

Please observe the maximum permitted string lengths. In this way you will avoid faults in data exchange between the output module and the higher-order system (e.g. field bus node). Use only the following cables to connect the modules.

For connection to	Max. permitted string length	Cable type
Field bus node with CP connection	10 m	<ul style="list-style-type: none"> - KVI-CP-1-... or - KVI-CP-2-... (can be used as drag chain)
Axis interface type SPC-AIF-...	See manual for the SPC200 type P.BE-SPC200-...	
Powerbox type CP-FB-TBOX-...	See manual for the higher-order system	

Communication takes place via the CP cable and the operating voltage for the internal electronics of the module is also supplied via the CP cable.

The output module is connected directly to the CP connection of the higher-order system (field bus node, axis interface or Powerbox). Detailed instructions can be found in the relevant system manual.

2.3.3 Connecting the load voltage

**WARNING**

Use only power units which guarantee reliable isolation of the operating voltages as per IEC 742/ EN 60742/VDE 0551 with at least 4 kV isolation resistance (protected extra low voltage, PELV). Switch power packs are permitted if they guarantee reliable isolation in accordance with EN 60950/ VDE 0805.



By using PELV power units, protection against electric shock (protection against direct and indirect contact) in accordance with EN 60204-1/IEC 204 is guaranteed on Festo valve terminals. Safety transformers with the adjacent designation must be used for supplying PELV networks. The valve terminals must be earthed in order to ensure their function (e.g. EMC).

The connected actuators are supplied with + 24 V DC via the load voltage connection on the output module. Use a cable with sufficiently large cross-sectional area for the operating voltage.

2. Output module type CP-A08...-M12-...

FESTO

The diagram below shows the pin assignment of the load voltage connection on the output module as well as a connection example.




Fig. 2/10: Pin assignment of load voltage connection

**PLEASE NOTE**

- Always connect the earth potential to pin 4 of the load voltage connection.
- Connect the earth connection on the left-hand side of the housing with low impedance (short cable with large cross-sectional area) to the earth potential.
- By means of low impedance connections, make sure that the housing of the output module and the earth connection at pin 4 have the same potential and that there are no equalizing currents.

You can then avoid interference caused by electromagnetic influences.

**PLEASE NOTE**

Check your **EMERGENCY STOP** circuit to see which measures are necessary for placing your machine/system in a safe state in the event of an **EMERGENCY STOP** (e.g. switching off the operating voltage for the valves and output modules, switching off the compressed air).

2.4 Instructions on commissioning

**WARNING**

*Please be careful when modifying the string assignment at a later stage.
After saving the string assignment/hardware configuration, check the address assignment of your higher-order system before starting user programs.*

You can then avoid:

- addressing errors with incorrectly installed CP modules.

With CP field bus nodes, the new string assignment must be saved if it has been modified (CP modules added or removed). To do this press the SAVE button on the node. Proceed here as described in the manual "CP system, installation and commissioning."









With the SPC200, the new hardware configuration must also be saved after the string assignment has been modified. Proceed here as described in the manual for the SPC200 or for WinPISA.

Status LED

The operating status of the output module is shown by the status LED on the CP connection (see following table):

2. Output module type CP-A08...-M12-...

FESTO

Status LED	Sequence	Operating status	Error treatment
 LED lights up		Operating voltage applied	None
 LED is out		<ul style="list-style-type: none"> - Operating voltage not applied or no connection to node or In conjunction with the CP node - incorrect string assignment during operation In conjunction with the SPC200 - see user manual for the SPC200 	<ul style="list-style-type: none"> • Check CP cable and operating voltage connection on the node (pin 1) or • correct string assignment • See user manual type P.BE-SPC200-...
 LED flashes quickly		<ul style="list-style-type: none"> - Test phase when power supply is switched on or - short circuit/overload on at least one output module or In conjunction with the CP node - incorrect string assignment when power supply is switched on In conjunction with the SPC200 - see user manual for the SPC200 	<ul style="list-style-type: none"> • None or • eliminate short circuit/overload and reset output ¹⁾ or • check string assignment²⁾ • See user manual type P.BE-SPC200-...
 LED flashes slowly		Load voltage failure	Restore load voltage

1) If there is a short circuit/overload, all outputs of the module will be switched off automatically. The error must be eliminated when the outputs are reset e.g. by user program.

2) When the line assignment has been modified (CP modules added or removed), you must store the new string assignment by pressing the SAVE button on the node.

Short circuit/
overload

If there is a short circuit/overload, the output module will switch off all 8 outputs automatically and communicate the error to the node. When the short circuit has been eliminated, you can delete this error as follows:

- Reset all 8 outputs (e.g. by means of user program)

Replacing
the CP
module





If there is a fault on the CP module during operation, you can replace the module by another of the same type during operation.



PLEASE NOTE
Observe here the instructions in the manual for the higher-order system (e.g. CP system, CP field bus node, SPC200).

Status
display

There are two yellow LEDs next to the connections for the actuators. These indicate the status of the signal at the relevant output. The meanings are:

Status LED	Sequence	Status
 LED lights up	ON OFF 	Output supplies 1-signal
 LED is out	ON OFF 	Output supplies 0-signal

2.5 Technical specifications

Technical specifications	Positive-switching output modules
	Type CP-A08-M12 and type CP-A08-M12-5POL
Temperature range: - operation - storage/transport	- 5 °C ... + 50 °C - 20 °C ... + 70 °C
Relative humidity	95 % non condensing
Protection class as per EN 60529	Plug connector inserted or fitted with protective cap: IP65
Protection against electric shock as per EN 60204-1/IEC 204	(Protection against direct and indirect contact) by connecting to a PELV power unit (Protected Extra-Low Voltage)
Electromagnetic compatibility - interference emission - resistance to interference	Tested as per EN 55011 limit value class B Tested as per EN 50082-2
Load voltage connection - rated value (protected against incorrect polarity) - tolerance - residual ripple - isolation resistance - internal current consumption of electronic components	Electrically isolated load voltage via additional M18 plug connector. 24 V ± 25 % 4 Vpp (within tolerance) 500 V < 40 mA
Digital outputs - design - loading per digital output - electronic fuse (short circuit, overload) trigger current response time	8 outputs as per IEC 1131-2; 24 V DC positive switching 0.5 A
	min. 750 mA max. 1.5 ms

2. Output module type CP-A08...-M12-...

FESTO

Technical specifications	Negative-switching output modules
	Type CP-A08N-M12
Temperature range: - operation - storage/transport	- 5 °C ... + 50 °C - 20 °C ... + 70 °C
Relative humidity	95 % non condensing
Protection class as per EN 60529	Plug connector inserted or fitted with protective cap: IP65
Protection against electric shock as per EN 60204-1/IEC 204	(Protection against direct and indirect contact) by connecting to a PELV power unit (Protected Extra-Low Voltage)
Electromagnetic compatibility - interference emission - resistance to interference	Tested as per EN 55011 limit value class A Tested as per EN 50082-2
Load voltage connection - rated value (protected against incorrect polarity) - tolerance - residual ripple - isolation resistance - internal current consumption of electronic components	Electrically isolated load voltage via additional M18 plug connector. 24 V ± 25 % 4 Vpp (within tolerance) 500 V < 40 mA
Digital outputs - design - loading per digital output - electronic fuse (short circuit, overload) trigger current response time	8 outputs as per IEC 1131-2; 24 V DC negative switching 0.5 A typ. 1 A max. 1.5 ms

Appendix A

Index

Index

A

Actuators

connecting 2-6

C

CP module

replace during operation 2-19

D

Designated use IV

F

Fitting

input module 1-6

output module 2-4

I

Information on this manual. VII

Input module 1-32

circuitry examples CP-E16-M8 (PNP) 1-19

circuitry examples CP-E16-M12x2-... 1-21

circuitry examples CP-E16N-M12x2 1-25

circuitry examples CP-E16N-M8-... (NPN) 1-23

connect to node 1-26

fitting on a wall 1-6

fitting onto a hat rail 1-8

internal layout CP-E16-M12x2-.... 1-20

internal layout CP-E16-M8-... (PNP) 1-18

internal layout of CP-E16N-M12x2 1-24

internal layout of CP-E16N-M8-... (NPN) 1-22

L**LED**

status display of input module	1-32
status display of output module	2-19
status LED input module	1-28
status LED output module	2-17

O**Output module**

- connect to node	1-26
- replace during operation	1-31
circuitry examples CP-A08-M12	2-9
circuitry examples CP-A08N-M12	2-12
fitting on a hat rail	2-4
fitting on a wall	2-4
internal layout CP-A08-M12-...	2-8
internal layout CP-A08N-M12	2-11

P

Pictograms	VI
----------------------	----

Pin assignment

inputs	1-16
NPN output	2-10
operating voltage connection of CP-A08...-M12	2-15
PNP outputs	2-6

S**Sensors**

circuitry examples CP-E16-M8-... (PNP)	1-19
circuitry examples CP-E16N-M8-... (NPN)	1-23
circuitry examples CP-E16-M12x2	1-21
circuitry examples CP-E16N-M12x2	1-25
connecting	1-15

Short circuit	
overload	2-19
sensor supply	1-30, 1-31
sensor supply CP-E16-M8-Z	1-30
Status LED	
input module	1-28
output module	2-17

T

Target group	V
Technical data	
input module CP-E16-M...-... (PNP)	1-34
input module CP-E16-M8-Z (PNP/NPN)	1-33
input module CP-E16N-M... (NPN)	1-35
output module CP-A08...-M12-... (PNP)	2-20
output module CP-A08N-M12 (NPN)	2-21

U

User instructions	V
-----------------------------	---