

About This Manual

Contents of this Manual

This manual is applied to grid-connected inverters of JSI-10KTL, JSI-12KTL and JSI-15KTL.

This manual provides detailed product introduction, installation guide, operation guide and maintenance guide.

This document also provides very important safety instructions about installation, operation or maintenance.

Target Reader

The manual is provided to installation technicians and users.

The tasks of installation and troubleshooting in this manual must only be performed by the qualified personnel.

The tasks of menu operation and routine maintenance can be performed by the users.

Retention of this Manual

This document must be stored near installation site and must be available at all times.

Symbols Used

Important instructions contained in this manual should be followed during installation and maintenance of the inverter. And they will be highlighted by these symbols.



DANGER!

This symbol indicates a dangerous situation which, if not avoided, will cause death or severe injury.



WARNING!

This symbol indicates a dangerous situation which, if not avoided, could result in death or severe injury.



CAUTION!

This symbol indicates a dangerous situation which, if not avoided, could cause minor or moderate injury.



This symbol indicates a situation which can help the equipment optimal operation.

Symbols on the body of the inverter:

High Voltage!

There exists lethal voltage. Please wait at least five minutes and then perform any work with the inverter after disconnecting the electrical connection of the inverter.

Risk of Burning!

The surface will be very hot during running. Avoid touching the housing of equipment except LCD display panle and DC switch when it is working.

Contents

A	About This Manual	1
	Contents of this Manual	1
	Target Reader	1
	Retention of this Manual	1
	Symbols Used	1
1	Safety Instructions	1
2	Product Overview	5
	2.1 Intended Use	6
	2.2 Main Circuit	7
	2.3 Features of JSI-10K-12K-15KTL Inverters	7
	2.4 Product Description	8
3	Installation	9
	3.1 Unpacking and Inspection	10
	3.2 Packing List	10
	3.3 Nameplate	10
	3.4 Moving Inverter	1′
	3.5 The Requirements of Installation Site	
	3.6 Dimensions of Inverter	14
	3.7 Installation Procedure	15
4	Electrical Connection	19
	4.1 General Safety	20
	4.2 Overview of Electrical Installation	21
	4.3 Terminals Description	22
	4.4 Specification of Cables	23
	4.5 Connecting inverter to PV Arrays	24
	4.5.1 Safety	24
	4.5.2 Assembling DC Cable to Connector	25
	4.5.3 Wiring Procedure	27
	4.6 Connecting Inverter to AC Grid	28
	4.7 Grounding the Inverter	31

4.8 Connecting RS485 Cable	32
4.8.1 Installing Monitoring System	32
4.8.2 Assembling RS485 Cable to Connector	33
4.8.3 Connecting RS485 Cable	34
5 LCD Panel and DC Switch	37
5.1 LCD Panel	38
5.2 LED Indicator	38
5.3 Buttons	38
5.4 LCD Screen	39
5.5 Operation mode	40
5.6 DC Switch	41
6 Commissioning	43
7 Menu Operation	45
7.1 Overview of Menu	46
7.2 Default Menu	47
7.3 Adjust Contrast	47
7.4 Start Inverter	48
7.5 Stop Inverter	49
7.6 Monitor Running Information	50
7.7 Monitor Running Record	51
7.8 Monitor Fault Record	52
7.9 Parameters Setting	54
7.9.1 Set Language	54
7.9.2 Set Time	55
7.9.3 Setting Total Generated Power Adjustment	56
7.9.4 Load Default	57
7.9.5 Set Running Parameter	58
7.9.6 Set Protecting Parameter	59
7.9.7 Set Communication Parameter	61
8 Troubleshooting and Maintenance	63
8.1 Troubleshooting	64
8.1.1 Troubleshooting of LED Indicator	64
8.1.2 Troubleshooting of faults in LCD Screen	64
8.2 Maintenance	66
8.2.1 Clean Fan	66
8 2 2 Replace Fan	67

8.2.3 Clean Air Inlet and Outlet	67
9 Technical Specification	69
10 Appendix	73
10.1 Exclusion of Liability	74
10.2 Contact Us	75

Safety Instructions

About this Chapter

This chapter describes very important safety instructions. Please read "Safety Instructions" carefully before any work with the inverter.

The inverter is designed and tested according to international safety requirements. But as all electrical and electronic equipments, certain precautions should be observed during installing, operating and maintaining.

Incorrect operation or work performed incorrectly can result in damage to:

- The life and well-being of the operator or the third party
- The inverter and other properties that belong to the operator or the third party

Therefore in order to reduce risk of injury and ensure the safety of the inverter, you must carefully read and follow all instructions, cautions and warnings.



DANGER!

First disconnect the inverter from utility grid!



DANGER!

- Even when the inverter is disconnected, lethal voltages still exists within the inverter.
- Before any maintenance work, you should wait for at least five minutes and then perform work.



WARNING!

All tasks of installation and maintenance must only be performed by qualified personnel.

- They are trained specially.
- They have read this manual, and comprehend all operation methods and related safety instructions.



WARNING!

All electrical installations must be in accordance with local and national electrical codes.



WARNING!

Only after receiving prior approval from the utility company and qualified personnel installing the inverter, you can connect the inverter to the utility grid.



WARNING!

All cables must be firmly attached, undamaged, properly insulated and adequately dimensioned.



WARNING!

When choosing the installation site, this ingredient to ensure that there is no electromagnetic interference with other electrical and electronic equipments must be taken into consideration.



WARNING!

Risk of damage to the inverter due to improper modification.

Never modify the inverter or other components of the inverter. Otherwise it will lead to loss of any and all warranty right.



WARNING!

Any malfunction that can impair inverter safety must be repaired immediately before the inverter is switched on again.



WARNING!

Please contact your local authorized personnel if any maintenance is required.



WARNING!

Electrostatic discharge can damage the inverter.

During replacing or installing the inner components, the technical personnel should take appropriate protective measures such as electrostatic bracelet.



CAUTION!

All safety instructions and warning labels on the inverter body;

- Must be clearly visible
- Must not be removed, covered, pasted



These regulations should also be followed:

- The regulations related to the electricity fed into the grid
- The safety instructions related to the PV arrays



About this Chapter

This chapter introduces intended use, main circuits, features and its constituent parts.

2.1 Intended Use

Thank you for purchasing an inverter from Jalpower Company. JSI10KTL, JSI12KTL and JSI15KTL serial inverters are grid-connected, transformerless, robust and high conversion efficiency.

The inverter converts DC power generated from the PV arrays into stable AC current, and then feeds this into the utility grid. The grid is three-phase four-wire type or three-phase five-wire type. Inverter is crucial unit in the small-scaled PV power system.

An example about intended use of this inverter is show in Fig 2-1.




Fig 2-1 Inverter Applied in the PV Power System

Item	Description
А	PV Arrays
В	Inverter
С	Metering Device
D	Utility Grid



WARNING!


Any other or additional use is not permitted except the intended use.

The inverter must only be connected to public utility grid.



WARNING!

If output of inverter is connected to local loads (household appliance, lights, motor loads, etc.), the inverter will stop working.



2.2 Main Circuit

Following shows the main circuit of JSI15KTL----a transformerless grid-connected inverter. JSI10KTL and JSI12KTL have the similar main circuit.

There are two MPP trackers designed for input. The boost stage levels up the input DC voltage to a desirable value for the inverter. Then an IGBT three-level inverter circuit converts the DC power to AC power. This AC power is fed into the utility grid via AC EMI filter.




Fig 2-2 Main Circuit Diagram of Inverter

2.3 Features of JSI-10K-12K-15KTL

The following are technical features of JSI10K-12K-15KTL:

- Power reduction(100%,60%,30%,0%) meets German EEG requirements
- Reactive power control with power factor from 0.9 lagging to 0.9 leading
- Max efficiency at 98%
- Wide DC input voltage range with max. 1000V

- Double MPP trackers for different installation inclinations.
- Weather-proof design(IP65) for harshest working environment
- High reliability with full protective functions
- Compact design with high quality aluminium housing.
- Water-proof direct plug-in termimals
- TUV certification, KEMA DK5940

2.4 Product Description




Fig 2-3 Product Description

Item	Name	Description
1	Display panel	Running data and configuration parameters are displayed in the LCD screen. Detailed information will be introduced in following.
2	Air outlet	Hot air generated during running process is exhausted via the air outlet.
3	Handles	The handles are designed for transport and install the unit.
4	Air inlet	Entrance of cool air.
5	DC switch	In normal condition it is in "ON" state. It can be turned off manually in any emergency condition. And then the inverter will stop running.
6	Connection terminals	They are DC input terminals, AC output terminal and RS485 communication terminal.

3 Installation

About this Chapter

This chapter proposes how to choose installation site and gives step-by-step procedures to install the inverter onto the wall. And related safety instructions are also included.

3.1 Unpacking and Inspection

The unit is thoroughly tested and inspected strictly before delivery. Although sturdy package is adopted, damage may still happen during the shipping.

The first thing you should do is to check the packing box when receiving the inverter unit. Meanwhile please check the completeness of the delivery contents.

If damage to the packing box is visible, or if you find that the inverter unit is damaged after unpacking, please notify the shipping company and Jalpower Company. If a related photo is supplied, you will get faster and better service.

3.2 Packing List

- Inverter unit
- Backplate
- Fastener(M10*85)
- DC positive connectors*7
- DC negative connector*7
- RS485 connector User
- manual Qualification
- certificate Warranty
- card
- Product test report
- Packing list
- Delivery inspection report

3.3 Nameplate

Nameplate is shown on the package box and on the side of the inverter body. You can check whether the serial number and the type of inverter is right, as well as other parameters information.



Fig 3-1 Nameplate of Inverter

3.4 Moving Inverter



WARNING!

Risk of injury due to ignoring the weight of the inverter.

The inverter is about 50kg. Proper device is needed or with the help of other people to avoid damage to the inverter when installing or moving.




Fig 3-2 Moving the Inverter

3.5 The Requirements of Installation Site

This section provides guidelines to help you choose the best installation site, suggestions to make sure the unit optimal operation, the warnings to avoid damage to the unit or the operator.




WARNING!

When choosing the installation site, Ensure that there is no electromagnetic interference with other electrical and electronic equipments.

Requirements:

The wall selected should be strong enough to hold the weight of the inverter.

It is suggested that the inverter be installed vertically.



The inverter unit with IP65 can be installed outdoors.


Do not install the unit in the direct sunlight or in an enclosure exposed to the direct sunlight. Exposure to the sun may cause additional internal heating. This can result in reducing output power.

The chosen installation site maintains ambient temperature range from -25 $^{\circ}$ C to 60 $^{\circ}$ C. When the temperature exceeds 45 $^{\circ}$ C, the output power will reduce.

The humidity of chosen installation site never exceeds 95%. Moisture may result in corrosion to the lid and damage to the inner electronic components.

Do not install the inverter unit on flammable construction materials or on the building that contains flammable materials.

Take enough space for heat dissipation into consideration when choosing the site. The following suggestive value for the space to keep clear around the inverter should be adopted.



Orientation	Min. clearance suggested
Left	30cm
Right	30cm
Тор	10cm
Bottom	50cm
Front	20cm

Install the inverter at eye level. Meanwhile some space at the bottom needs to be kept for electrical connection.

Do not install the inverter in this site where the children can reach. The housing of the inverter will be very hot. It is risk of burning.

Do not install the inverter in living area. Noise can be produced during running of the inverter, which will affect your daily life.

3.6 Dimensions of Inverter




Fig 3-3 Outline Dimensions of Inverter

Item	Description
W	Width
Н	Height
D	Depth

Table 3-1 Dimension Value

Туре	W(cm)	H(cm)	D(cm)	Net weight(kg)
JSI-10KTL	64.8	69.5	23.2	45
JSI-12KTL	64.8	69.5	23.2	51
JSI-15KTL	64.8	69.5	23.2	55

3.7 Installation Procedure

There is a backplate and fasteners supplied to install the inverter. If you don't want to use the supplied backplate, you can drill holes refer to its dimension below.




Fig 3-4 Dimensions of Backplate

In the following pages we will introduce the installation procedures using the provided backplate and fasteners.


INSTALLATION PROCEDURE:

Step 1: Get the supplied backplate and fasteners from the package.

Step 2: Choose the best installation site according to above requirements. Place the backplate onto the chosen wall and adjust it until it is in a horizontal position.

Step 3: Mark the positions to drill holes using the backplate as the template.

Step 4: Drill seven holes at the marks you have made. The size of the hole is illustrated in the below picture.



Item	Description	
А	The depth of hole	
В	The diameter of hole	
С	Hole	
D	Wall	

Fig 3-5 Dimensions of Holes

Specification of expansion bolt	Hole size(mm)	
	Depth(A)	Diameter(B)
M10*85	65	14.5



DANGER!

In order to avoid electrical shock or other injury, inspect existing electronic or plumbing installations before drilling holes. **Step 5:** Insert the expansion bolts through the holes on the backplate and into the holes you have drilled.

Step 6: Fasten the backplate against the wall via washer, sping washer and hexagonal nut.




Fig 3-6 Demo Diagram of Backplate Fastening Process

Item	Description
А	Wall
В	Backplate
С	Expansion bolts
D	Washer
Е	Spring washer
F	Hexagonal nut



CAUTION!

Risk of damage to expansion bolt due to over-tightening the nut.

Step 7: Now you can hang the inverter onto the backplate as Fig 3-7 shows. Make sure the two recesses on the back of the inverter fit perfectly together with the backplate.




Fig 3-7 installing the inverter



About this Chapter

This chapter proposes step-by-step procedures to perform electrical connection and related safety instructions.

4.1 General Safety



WARNING!

Improper operation during the wiring process can cause fatal injury to operator or unrecoverable damage to the inverter.

Only qualified personnel can perform the wiring work.



WARNING!

All electrical installations must be in accordance with local and national electrical codes.



WARNING!

Only after receiving prior approval from the utility company and qualified personnel installing the inverter, you can connect the inverter to the utility grid.



WARNING!

All cables must be firmly attached, undamaged, properly insulated and adequately dimensioned.



CAUTION!

These regulations should also be followed:

- The regulations related to the electricity fed into the grid
- The safety instructions related to the PV arrays

4.2 Overview of Electrical Installation

Electrical connection of the inverter includes DC connection, AC connection and communication connection.




Fig 4-1 Electrical Connection Diagram

Item	Description	Remark
А	Connection area of inverter	It is located at the bottom of the inverter
В	AC circuit breaker	User equips this device
С	Grid	
D	PV arrays	

Item	Description	Remark	
Е	RS485-RS232 converter	User can order it from Jalpower	
F	Remote PC	User equips this device	
G	SunInfo [™] logger	User can order it from Jalpower	



The dashed line in the above diagram indicates that there is another way of communication connection. See "4.8 Connecting RS485 Cable".

4.3 Terminals Description

All electrical terminals are all located at the bottom of unit. Fig 4-2 shows the connection area.



Enough space should be kept for electrical connection at the bottom of the inverter when choosing the installation site.




Fig 4-2 Terminals Description

Item	Description
А	AC connector
В	RS485 connector
С	DC connectors
D	DC switch

4.4 Specification of Cables

DC cables and RS485 cables of PV power system are equipped with water-proof direct plug-in connector. You, II find these connectors in the package.

For electrical connection in PV power system, specification of all cables used should meet following requirements.

Table 4-1 Specification of cables

Items		Num	Min. cross area (mm²)	Max. cross area (mm²)	Recommended value (mm²)
DC positive cable		6	4	6	4
DC negative cable		6	4	6	4
AC cable	L1	1	6	8	6
	L2	1	6	8	6
	L3	1	6	8	6
	N	1	6	8	6
	GND	1	6	8	6
RS485 cable		2	0.75	2	0.75

4.5 Connecting inverter to PV Arrays

4.5.1 Safety

As input of the inverter in the PV power system, PV Arrays" features should be paid attention to. Please refer to PV module"s data sheet.

When designing PV arrays, following requirements should be met.



DANGER!

Lethal voltage exists!

Do cover the PV arrays. Exposed to sunlight, PV arrays will output lethal voltage.



WARNING!

Risk of damage to the inverter.

Make sure that the maximum open voltage of each string is within DC input voltage range of the inverter. Voltage over 1000V can damage to the inverter.



WARNING!

Risk of damage to the inverter.

Make sure that the maximum short current of each string is less than maximum input current. Please refer to chapter "9 Technical Specification".



CAUTION!


For each input zone, PV arrays should respectively have a homogenous structure, including the same type, the same number, identical tilt and identical orientation.

4.5.2 Assembling DC Cable to Connector

All DC cables are equiped with water-proof direct plug-in connectors, which mate with DC conectors at input zones.


DC positive assembling procedure:

Step 1: Unscrew the water-proof terminal in the following direction.



Step 2: Insert appropriately sized DC cable through water-proof terminal.


Step 3: Strip off insulation layer of DC cable. The length of strip insulation is approximate 8mm.




Step 4: Crimp cable core with hand crimping plier.



Step 5: Plug cable gland into connector housing until there is "Ka" voice.




Step 6: Tighten the water-proof terminal in opposite direction.




DC negative assembling procedure:

Step 1: Unscrew the water-proof terminal in the following direction.




Step 2: Insert appropriately sized DC cable through water-proof terminal.


Step 3: Strip off insulation layer of DC cable. The length of strip insulation is approximate 8mm.




Step 4: Crimp cable core with hand crimping plier.



Step 5: Plug cable gland into connector housing until there is "pa" voice.



Step 6: Tighten the water-proof terminal in opposite direction.




The positive and negative connectors are marked with polority symbols and colored cable. Red cable represents DC positive conector and blue one represents negative.

If positive and negative cable have been assembled, it is easy to plug these connectors to the corresponding connectors at the bottom of inverter.

When connectting connectors, they will be correctly locked in the mating place.



Release the locking part by pressing on the ribbling of the locking hooks and pull them outwords.



4.5.3 Wiring Procedure

There are DC1 input zone and DC2 input zone, each with its own MPP tracker, as Fig 4-2 shows.

Wiring Procedure:


Step 1: Assemble DC cable to connector at the inverter side. See "4.5.2 Assembling DC Cable to Connector".

Step 2: Manually rotate DC switch at the bottom of the inverter to "OFF" position.

Step 3: Check connection cable of one PV array string for correct polarity and that the maximum input voltage does not exceed 1000V.

Step 4: Plug DC positive and negative connector into corresponding terminasl.


If there is a "pa" sound, it means DC connector has attached to terminals.





WARNING!

It is not permitted for one input string to connect in the following way.



Step 4: Connect other strings in the same procedure.

4.6 Connecting Inverter to AC Grid



WARNING!

Only after receiving prior approval from the utility company you can connect the inverter to local utility grid.



WARNING!

The grid should meet these following requirements. Otherwise the inverter will not work.

• Grid Voltage 3*310V~3*450V


Grid Frequency 47~51.5Hz/57~61.5Hz

AC Wiring Procedure:

Step 1: Make sure that the AC circuit breaker is switched off.

Step 2: Dismantle the board with screwdriver.


Step 3: Unscrew the waterproof terminal in the direction shown in the following picture.



Step 4: Insert the cables via the holes of the AC terminals.


Step 5: Pull the cable from the other side.

Step 6: Strip off insulation layer of all AC cables. The length of strip insulation is approximate 10mm.




Step 7: Press down the two red latches of inner AC connector.

Step 8: Pull inner AC connector outside.



Step 9: Connect all cables to the terminal outside the inverter.




JSI10KTL-12KTL-15KTL User Manual

Step 10: Plug the section above into the fixed terminal inside the inverter.

Step 11: Fasten the board.

Step 12: Screw the waterproof terminals in the direction shown in the following picture.



Step 13: Connect AC circuit breaker to grid.

4.7 Grounding the Inverter



WARNING!

Because of the transformless design of the inverter, DC positive pole and DC negative pole are not permitted to be grounded. Otherwise the inverter can stop running.



WARNING!

All non-current carrying exposed metal parts of equipment and other enclosure in the PV power system should be grounded (e.g., PV arrays, DC circuit breaker and inverter).



WARNING!

For AC side, it is better to use a continuous irreversibly appropriately sized conductor bare to ground inverter.




Fig 4-3 AC Side of Inverter Grounding

4.8 Connecting RS485 Cable

4.8.1 Installing Monitoring System

The inverter provides RS485 interface to communicate with remote PC or logger. User can monitor the state of the inverter, observe current running information and history record via this interface.

There are three methods provided for user to install the monitoring system.

Data logger




Fig 4-4 Collecting Data with SunInfo Data Logger

Data logger+ PC




Fig 4-5 Collecting Data with SunInfo Data Logger and PC

PC




Fig 4-6 Collecting Data with PC and RS485/RS232 Converter



SunInfo[™] logger and RS232-RS485 converter are optional parts and can be orded from Jalpower.


4.8.2 Assembling RS485 Cable to Connector

All RS485 cables are equiped with water-proof direct plug-in connectors, which can mate with RS485 conectors at the bottom of inverter.

Assembling procedure:

Step 1: Dismantle RS485 connector in the same way of DC connector.

Step 2: Connect appropriately sized cables to pin1 and pin3, as shown in the following picture.





Pins are marked with symbols at the other side.

Step 3: Tighten its water-proof terminal.

4.8.3 Connecting RS485 Cable

RS485 is communication standard for bidirectional transmission of data between one or more inverters and a PC or a data logger.


If there is more than one inverter to communicate with a PC or a data logger, it is crucial to configure communication parameters of each inverter. See "7.9.7 Set Communication Parameter".



CAUTION!

RS485 bus' requirements to ensure quality of communication:


- RS485 bus should be shielding twist-pair
- Shielding layer of RS485 bus should be single-point grounding, grid indicating shielding layer in following pictures
- Data logger



Wiring procedure:

- **Step 1:** A resistance with 120Ω is connected at the initating terminal of RS485 bus.
- **Step 2:** Plug the connector of RS485 cable into corresponding RS485 terminal of Inverter 1.
- **Step 3:** The two lines of the other end of RS485 cable, labled A and B, connected to corresponding lines of RS485 bus, as the above diagram.
- **Step 4:** Connect other inverters to RS485 bus in the same way.
- **Step 5:** Connect the end of RS485 bus to A1 port and B1 port of SunInfo[™] logger.


Data logger+ PC



Wiring procedure:

- **Step 1:** A resistance with 120Ω is connected at the initating terminal of RS485 bus.
- **Step 2:** Plug the connector of RS485 cable into corresponding RS485 terminal of Inverter 1.
- **Step 3:** The two lines of the other end of RS485 cable, labled A and B, connected to corresponding lines of RS485 bus, as the above diagram.
- Step 4: Connect other inverters to RS485 bus in the same way.
- **Step 5:** Connect the end of RS485 bus to A1 port and B1 port of SunInfoTM logger.
- **Step 6:** Connect RS232 port of SunInfoTM logger to RS232 port of PC.

PC



Wiring procedure:

- **Step 1:** A resistance with 120Ω is connected at the initiating terminal of RS485 bus.
- **Step 2:** Plug the connector of RS485 cable into corresponding RS485 terminal of Inverter 1.

- **Step 3:** The two lines of the other end of RS485 cable, labled A and B, connected to corresponding lines of RS485 bus, as the above diagram.
- **Step 4:** Connect other inverters to RS485 bus in the same way.
- **Step 5:** At the end of RS485 bus, connect RS485 A cable to "RX+" port of RS232-RS485 converter and connect RS485 B cable to "TX-" port of RS232-RS485 converter.
- Step 6: Connect RS232 port of RS232-RS485 converter to RS232 port of PC.

5 LCD Panel and DC Switch

About this Chapter

This chapter proposes parts that user can operate——LCD panel and DC Switch.

5.1 LCD Panel

LCD panel comprise LED indicators, buttons and LCD screen. Leds indicate the current state of the inverter. The current running information and history information can be seen in the LCD screen with operating the buttons.




Fig 5-1 LCD Panel

5.2 LED Indicator

There are two LED indicators, "RUN" and "FAULT" respectively. User can observe these leds to get the current state.

Table 5-1 LED Indicator Description

Name	State	Description
"RUN"	On	Inverter is running.
	Off	Inverter is not running.
"FAULT"	On	A malfunction occurs
	Off	A malfunction doesn't occur.

5.3 Buttons

There are two buttons on the panel as Fig 5-1 shows. They are " and " an

Table 5-2 Description of Button Function

Name	Operation	Description
	Press less than two seconds	Move to last row, or move to previous page, or increase setting value.
	Press more than two seconds	Return to parent menu.
	Press less than two seconds	Move to next row, or move to previous page, or increase setting value.
	Press more than two seconds	Select menu item or confirm setting.



When the two buttons "o" and "o" are pressed more than three seconds, inverter will stop running and enter into the "Key-stop" state.



The background illumination of LCD screen will go out to save power if there is not button operation in two minutes. You can activate again by pressing any button.

5.4 LCD Screen

LCD screen can display the current state of inverter, current running information, history information and setting parameters menu. They can be accomplished with button operation, see "7 Menu Operation".

LCD screen and buttons provide a good human-computer interaction interface.

In its default interface, user can observe operation mode or fault type of inverter.




Fig 5-2 Default Interface



If there is no button operation in three minutes, it will go back to default menu.

5.5 Operation mode

This chapter illustrates the operation modes of inverter.

Stop

The inverter is shut down.

Stand-by

Stand-by mode is entered for insufficient input power (Ppv≈0 for 3 minutes). In stand-by mode the inverter will wait until the DC voltage recovers to 220V in standby time (set by user, see"7.9.5 Set Running Parameter").

Startup

The inverter is initializing and synchronizing with the grid.

Rur

After being energized, the inverter tracks the PV arrays" maximum power point (MPP) and converts the DC power to AC power. This mode is the normal operational mode.

Fault

If a fault occurs during running, the inverter will automatically stop operation, disconnect the AC relay and display the fault type in the LCD panel with the "Fault" LED lit.

Once the fault is removed inrecovery time (set by user, see"7.9.5 Set Running Parameter"), the inverter will automatically resume running.

Key-Stop

The inverter will stop operation by manual stop through LCD menu; this condition needs manual restart through LCD menu.




Fig 5-3 Mode Transition Explanation Diagram



5.6 DC Switch

DC switch is designed for stopping the inverter.

Inverter work automatically if input and output meet the requirements. If you want to interrupt its running or if a malfunction occurs, it can be rotated to "OFF" state. And then the inverter will stop running.



CAUTION!

If you want to restart the inverter, rotate DC switch to "ON" position again.

6 Commissioning

About this Chapter

This chapter demonstrates how to check before commissioning and operation procedures.

Verify before commissioning

Number	Item	Remark
1	Verify whether inverter is fastened onto the wall.	See "1".
2	Check whether all cables are undamaged, properly insulated and adequately dimensioned.	See " 4.4 Specification of Cables".
3	Check whether all cables are firmly attached and correctly.	See "4.5 Connecting inverter to PV Arrays" to "4.8 Connecting RS485 Cable"

Commissioning Procedure:

Step 1: Make sure all items above meet demands.

Step 2: Switch off external AC circuit breaker.

Step 3: Rotate DC switch to "ON" position.



After external circuit breaker is closed in the PV power system:

- PV arrays initialize and supply DC power to inverter;
- When DC voltage exceeds 250V, DC Bus starts to charge;
- Inverter verify whether grid conditions are OK;
- If the conditions are OK, inverter feeds AC power to grid and enters into the running state.

Step 4: Observe state of LED indicators and LCD screen.



CAUTION!

If inverter's commissioning fails, "FAULT" indicator will be lit. And " state " in the LCD screen will display type of malfunction.

In this case malfunction must be removed and then repeat step1 to step 4.



If inverter, s commissioning succeeds, "RUN" indicator will be lit.

If inverter, s commissioning succeeds, " state " in the LCD screen will display "RUN".

Menu Operation

About this Chapter

This chapter shows all menu operations. User can know how to check the state of the inverter, current running information and history information. And how to set the parameters of the inverter is also included.

7.1 Overview of Menu





Fig 7-1 Menu Tree-English

7.2 Default Menu

When inverter is energized, LCD screen will display the default menu.




1. In the default menu, LCD screen displays basic information.



There are also current date and time. See "7.9.2 Set Time" to adjust the current time

7.3 Adjust Contrast




7.4 Start Inverter



If conditions of DC side and AC side meet demands, or if malfunction is solved, the inverter will start to run automatically.


If you perform command "Stop" and want to restart again, it is needed to perform command "Start".




7.5 Stop Inverter




"Stop" command will switch off AC relay. It is needed to perform "Start" command to restart the inverter.



7.6 Monitor Running Information



7.7 Monitor Running Record



7.8 Monitor Fault Record




Table 7-1 Fault description

Fault type	Explanations
Vdc-high	DC voltage is too high
Vac-high	Grid voltage is too high
Vac-low	Grid voltage is too low
lac-high	AC power over load
F-fault	Grid frequency is abnormal
No-grid	Islandor grid is unavailable
IPM-flt	The IGBT power module occur malfunctions

Fault type	Explanations
Temp-flt	Temperature inside the enclosure is too high
Com-err	Communication occurs fault between LCD and DSP
Earth-flt	There is leakage current in the AC side
Bus-high	The inner DC bus(boost output) voltage is too high
Bus-low	The inner DC bus (boost output)voltage is too low
Samp-ft	Malfunction occurs in the sampling circuit
DC Inject	Output Current DC component is too high



The inverter can only store at most 20 latest fault records.


7.9 Parameters Setting



If you want to set inverter's parameters, you have to input correct password.

The default password is 1111.


7.9.1 Set Language





- 9. Short Press button "\overline" or "\overline" to set the number of language.
- 10. And then long press button
- "To confirm the choice.

7.9.2 Set Time




Time Date: 09/11/18 Time:18:35:55

- 9. Short Press button "O" or "O" to set date and time according to you local time.
- 10. And then long press button
- "

 " to confirm.

7.9.3 Setting Total Generated Power Adjustment



Energy-adj +0000 kWh

- 9. Short Press button "\overline" or "\overline" to set value.
- 10. And then long press button "To confirm."



The positive symbol "+" can also be changed to negative symbol "-".

It is needed to perform the "Energy-adj" command in case that the total power displayed in LCD (E-total) has difference with reading value from the external power measuring device (like an electrical meter).

The adjustable range is from -9999-+9999 kWh.


(Power-adj value)= (Real measured value)-(E-total reading value).

7.9.4 Load Default



CAUTION!

If you perform the command "Load default", all running information and history information will unrecoverable cleared.




1. Long press button "" to enter into the main control-menu in the default menu.



- 2. Short press button "\overline" to move arrow to "Set-param".
- 3. And then long press button "" to enter into the submenu.

Set-param Password: 1111	4. Short Press button "O" or "O" to input correct password.
Sys-param Run-param Pro-param Com-param	 5. Short press button "o" to move arrow to "Sys-param". 6. And then long press button "o" to enter into the submenu.
Language Time Energy-adj → Load default	 7. Short press button "o" to move arrow to "Load default". 8. And then long press button "o" to enter into the submenu.
Load default Password: 1111	 9. It is needed to input correct password again. Short Press button " or " to input the password. 10. And then long press button
	"♥" to confirm.

7.9.5 Set Running Parameter




Set-param Password: 1111	4. Short Press button " or " to input correct password.
Sys-param Run-param Pro-param Com-param	 5. Short press button "o" to move arrow to "Run-param". 6. And then long press button "o" to enter into the submenu.
Standby time 010s Recover time 030s Limit -p 100%	 7. Short Press button " or " or " to set running parameters. 8. And then long press button " oconfirm the setting.

NOTE

"Standby time" is the time from inverter starting to initialize to inverter feeding power to grid. This parameter ranges from 10s to 255s. And the default value is 10s.

"Recover time" is the time from the point that the fault is cleared to inverter recovering to feed power to grid. This parameter ranges from 30s to 300s. And the default value is 30s.

7.9.6 Set Protecting Parameter



Set-param Password: 1111	4. Short Press button "O" or "O" to input correct password.
Sys-param Run-param Pro-param Com-param	 5. Short press button "o" to move arrow to "Pro-param". 6. And then long press button "o" to enter into the submenu.
Vgrid-max 450V Vgrid-min 310V Fgrid-max 50.2Hz Fgrid-min 47.5Hz	 7. Short Press button " or " or " to set protecting parameters. 8. And then long press button " or "

NOTE


"Vgrid-max" and "Vgrid-min" are upper limit value and lower limit value of grid voltage respectively. "Fgrid-max" and "Fgrid-min" are upper limit value and lower limit value of grid frequency respectively.

Once grid voltage or frequency exceed this rang, the inverter will stop running and fault type is displayed in the LCD screen.

Table 7-2 Range of Protecting Parameters

Data name	Simple explanation	Adjustable range	Default value
Vgrid-max	maximum grid voltage	435V~455V	450V
Vgrid-min	minimum grid voltage	300V~315V	310V
Fgrid-max	maximum grid frequency	50.2Hz-51.5Hz	50.2Hz(for 50Hz system)
		60.2Hz-61.5Hz	60.2Hz(for 60Hz system)
Fgrid-min	minimum grid frequency	47.0Hz-49.5Hz	47.5Hz(for 50Hz system)
		57.0Hz-59.5Hz	57.5Hz(for 60Hz system)

7.9.7 Set Communication Parameter



NOTE

The range of communication address is 1~247.

And the baud rate of serial communication should be set 9600.



Troubleshooting and Maintenance

About this Chapter

This chapter illustrates troubleshooting and daily maintenance.

8.1 Troubleshooting

8.1.1 Troubleshooting of LED Indicator

See "Table 5-1LED Indicator Description" to see description of LED's state.

Type of fault	Troubleshooting
LED indicators and LCD cannot be lit	Disconnect AC circuit breaker. Rotate DC Switch to "OFF" position.
	Check the polarity of DC input.
"RUN" indicator goes out	Disconnect AC circuit breaker.
	2. Rotate DC Switch to "OFF" position.
	Check the correctness of electrical connection of inverter.
	See"4 Electrical ".
	Check whether the voltage of DC input exceeds start-up voltage of inverter.
	5. Check whether the grid condition meets the demands. See
	"Table 7-2 Range of Protecting Parameters".
	6. If all above conditions are OK, please contact Jalpower. See "10.2 Contact Us".
"Fault" indicator is lit	There is a fault which is not removed yet.
	Perform troubleshooting in according to fault type in LCD
	screen. See "8.1.2 Troubleshooting of faults in LCD Screen".
	3. If it can be solved, please contact Jalpower. See"10.2 Contact Us".

8.1.2 Troubleshooting of faults in LCD Screen

Type of fault	Troubleshooting
Vdc-high	 Disconnect AC circuit breaker. Rotate DC Switch to "OFF" position. Check the voltage of DC side. Restart the inverter until the DC voltage return to allowable range.
Vac-low	Disconnect AC circuit breaker. Rotate DC Switch to "OFF". Check the voltage of grid side.

Type of fault	Troubleshooting
Vac-high	4. If local grid condition exceeds AC demands of inverter, Reset the protecting parameters. See "7.9.6 Set Protecting Parameter". And if local grid voltage exceeds the upper limit value of "Vgrid-max", or if local grid voltage is under the lower limit value of "Vgrid-min", please contact your local electricity company to adjust the grid voltage. 5. If the fault can not be solved, please contact Jalpower. See "10.2 Contact Us".
F-fault	Disconnect AC circuit breaker. Rotate DC Switch to "OFF". Check the frequency of grid side.
	4. If local grid condition exceeds AC demands of inverter, Reset the protecting parameters. See "7.9.6 Set Protecting Parameter". And if local grid frequency exceeds the upper limit value of "Fgrid-max", or if local grid frequency is under the lower limit value of "Vgrid-min", please contact your local electricity company to adjust the grid frequency. 5. Close AC circuit breaker.
	6. If the fault can not be solved, please contact Jalpower. See "10.2 Contact Us".
IPM-flt	If this malfunction occurs, the reasons are very complicated. 1. Disconnect AC circuit breaker. 2. Rotate DC Switch to "OFF" position. 3. Check the temperature of radiator. If its temperature exceeds 80 ℃ Restart the inverter until it recovers to environment temperature. 4. Recover DC switch to "ON" position. 5. Close AC circuit breakeres. 7. If this malfunction happens again, please contact Jalpower. See "10.2 Contact Us".
No-grid	 Check whether AC circuit breaker is off. Check whether AC cables are all firmly connected. Check whether grid is cut off. If all conditions are OK and this malfunction still occurs in the LCD screen, please contact Jalpower. See "10.2 Contact Us".

Type of fault	Troubleshooting	
Tem-flt	Check whether AC output power exceeds rated power too much.	
	Check whether fans work normally and whether there are some abnormal from fans. Otherwise please replace broken fan.	
	See "8.2.2 Replace Fan". 3. Clean air grills of outlet. See "8.2.3 Clean Air Inlet and Outlet".	
	o. Clean an grins of outlet. See 6.2.3 Clean An Timet and Outlet .	
Com-flt	If this malfunction happens, wait for a while and observe whether fault can be cleared by the inverter itself.	
	Otherwise perform the command "Stop" or rotate DC switch to "OFF" position.	
	Perform the command "Start" to restart the inverter or rotate DC switch to "ON" position.	
	If this malfunction still exists, please contact Jalpower. See "10.2 Contact Us".	

8.2 Maintenance



WARNING!

Disconnect the connection between inverter and grid and then the connection between inverter and PV arrays before any maintenance work.

Lethal voltage still exists in the inverter. Please wait at least five minutes and then perform maintenance work.

8.2.1 Clean Fan

There are four fans in the inverter. They are used for ventilation. It is suggested that fans are cleaned every half year.

Procedure:

- **Step 1:** Disconnect the connection of input and output side.
- Step 2: Wait at least five minutes.
- **Step 3:** Dismantle inverter in the reversed direction of "Installation procedure".
- Step 4: Refasten the four fixed screws on the back of the inverter.
- **Step 5:** Clean the fan with soft brush or vacuum cleaner.
- Step 6: Reinstall the install onto the wall.

Step 7: Re-connect the inverter.

Step 8: Restart up the inverter.

8.2.2 Replace Fan

If there is "Tem-flt" and abnormal noise, please replace the fan.

Procedure:

- **Step 1:** Disconnect the connection of input and output side.
- Step 2: Wait at least five minutes.
- **Step 3:** Dismantle inverter in the reversed direction of "Installation procedure".
- Step 4: Refasten the four fixed screws on the back of the inverter.
- **Step 5:** Dismantle the metal panel which holds the fans.
- **Step 6:** Disconnect the connection of the fan.
- **Step 5:** Replace the broken fan.
- Step 6: Reinstall the install onto the wall.
- Step 7: Re-connect the inverter.
- Step 8: Restart up the inverter.

8.2.3 Clean Air Inlet and Outlet

There is huge heat generated in the process of running. Inverter adopts controlled forced-air cooling method.

In order to maintain good ventilation, please check there is something blocking the air inlet and outlet.

Clean the air inlet and outlet with soft brush or vacuum cleaner.

Technical Specification

About this Chapter

This chapter illustrates technical data, including input data, output data, system, display and communication and mechanical data.

	JSI10KTL	JSI12KTL	JSI15KTL		
Input Data					
Max. DC Voltage	1000V	1000V	1000V		
MPP Voltage Range	250~800V	250~800V	250~800V		
Max. DC Power	10.4kW	12.5kW	15.6kW		
Max. Input Current	40A (20A*2)	40A (20A*2)	40A (20A*2)		
Recommend PV Array Open Circuits Voltage	700V	700V	700V		
Output Data	Output Data				
Rated output power	10kW	12kW	15kW		
Rated Grid Voltage	400V	400V	400V		
Grid Voltage Range	310~450V	310~450V	310~450V		
Rated Grid Frequency	50/60Hz	50/60Hz	50/60Hz		
Grid Frequency Range	47.5~51.5Hz/	47.5~51.5Hz/	47.5~51.5Hz/		
	57~61.5Hz	57~61.5Hz	57~61.5Hz		
Output Current THD	<3% (at nominal power)	<3% (at nominal power)	<3% (at nominal power)		
DC Current Injection	<0.5%(at rated output current)	<0.5%(at rated output current)	<0.5%(at rated output current)		
PF	0.9(lagging)~0.9(leading)	0.9(lagging)~0.9(leading)	0.9(lagging)~0.9(leading)		
System					
Max. Efficiency	98.0%	98.0%	98.0%		
Euro. Efficiency	97.2%	97.2%	97.3%		

Protection Degree	IP65	IP65	IP65		
Operating Temperature	-25℃~60℃	-25℃~60℃	-25℃~60℃		
Relative Humidity	0~95%, non-condensing	0~95%, non-condensing	0~95%, non-condensing		
Cooling method	Controlled forced-air cooling	Controlled forced-air cooling	Controlled forced-air cooling		
Max. Altitude	2000m	2000m	2000m		
Display and Communication					
Display	LCD	LCD	LCD		
Communication Interface	RS485	RS485	RS485		
Mechanical Data					
Dimensions (W*H*D)	648*695*232	648*695*232	648*695*232		
Net weight	45kg	51kg	55kg		

10 Appendix

About this Chapter

This chapter proposes contents related to exclusion of liability and contact.

10.1 Exclusion of Liability

The contents of this manual will be periodically checked and revised if necessary. However discrepancies cannot be excluded. Please download the latest version of this manual via website www.Jalpower.com.. However discrepancies cannot be excluded. No guarantee is made for the completeness of these documents. Please contact our company or distributors to get the latest version.

Guarantee or liability claims for damages of any kind are excluded if they are caused by one or more of the following:

- Improper or inappropriate use of the product
- Operating the product in an unintended environment
- Operating the product when ignoring relevant safety regulations in the deployment location
- Ignoring safety warnings and instructions contained in all documents relevant to the product
- Operating the product under incorrect safety or protection conditions
- Altering the product or supplied software without authority
- The product malfunctions due to operating attached or neighboring devices beyond allowed limit values
- In case of unforeseen calamity or force majeure

10.2 Contact Us

If you have any questions about this product, our hotline will be happy to assist you. Please keep the following data when contacting Jalpower.



Address:

Jalpower Corporation Ltd.,

USA

107 East Meda Ave. Glendora , CA 91741 , USA Tel: +1-626-963-2054 Email:<u>sales@Jalpower.com</u>

Taiwan

2E., No.4, Aly. 1, Ln. 225, Sec. 1, Neihu Rd., Neihu Dist., Taipei City 114, Taiwan (R.O.C.)
Tel:+ 886-2-26593737
Email:support@jalpower.com

China

Room 2504, No.18#, Shun.Yi.Road, Shanghai, 200063, China Tel:+86 21 54259997 Email:sales@Jalpower.com