

USPIII Software Manual

Version 1.3 — November 2005



Themis Computer—Americas and Pacific Rim
47200 Bayside Parkway
Fremont, CA 94538
Phone (510) 252-0870
Fax (510) 490-5529
World Wide Web <http://www.themis.com>

Themis Computer—Rest of World
5 Rue Irene Joliot-Curie
38320 Eybens, France
Phone +33 476 14 77 80
Fax +33 476 14 77 89

Copyright © 2005 Themis Computer, Inc.

ALL RIGHTS RESERVED. No part of this publication may be reproduced in any form, by photocopy, microfilm, retrieval system, or by any other means now known or hereafter invented without the prior written permission of Themis Computer.

The information in this publication has been carefully checked and is believed to be accurate. However, Themis Computer assumes no responsibility for inaccuracies. Themis Computer retains the right to make changes to this publication at any time without prior notice. Themis Computer does not assume any liability arising from the application or use of this publication or the product(s) described herein.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the United States Government is subject to the restrictions set forth in DFARS 252.227-7013 (c)(1)(ii) and FAR 52.227-19.

TRADEMARKS

THEMIS[®] is a registered trademark of Themis Computer, Inc.

SOLARIS[™] is a trademark of Sun Microsystems

SPARC[®] and UltraSPARC[®] are registered trademarks of SPARC International

All other trademarks or registered trademarks used in this publication are the property of their respective owners.

Themis Customer Support

North America, South America, and Pacific Rim

Telephone: 510-252-0870

Fax: 510-490-5529

E-mail: support@themis.com

Web Site: <http://www.themis.com>

USPIIIi Software Manual, Version 1.3

November 2005

Part Number: 110615-023

Version Revision History

Version 1.3.....November 2005

- Replaced photo on page ix to reflect new logo (Preface/How to Use This Manual).
- Changed “will add” to “has added” in the second sentence in Section 2.1, "Themis OBP Commands," on page 2-1 (Chapter 2).
- Reworded paragraph 2 of Section 2.2, "OBP VME Environment Variables," on page 2-1 (Chapter 2).
- Added a note to Section 2.2, "OBP VME Environment Variables," on page 2-1, regarding rebooting the system to see modifications to the environment variables (Chapter 2).
- Corrected the following values in *Table 2-1* on page 2-2 and *Table 3-2* on page 3-5: vme-arbitration mode (from “round-robin” to “round-robin/priority”) and vme32-slave-base from “0–1048576” to “0–4294901760.”
- Better defined the software used on the USPIIIi in Section 3.1, "Introduction," on page 3-1 (Chapter 3).
- Revisions to the first paragraph in Section 3.2, "SUN OpenBoot PROM (OBP)," on page 3-1 to include the applicable versions of Sun Solaris and delete references to Wind River VxWorks. Also changed UltraSPARC-IIe to UltraSPARCIIIi (Chapter 3).
- Updated reference material revision and part numbers in Section 3.2, "SUN OpenBoot PROM (OBP)," on page 3-1 (Chapter 3).
- Updated *Table 3-2* on page 3-5 to match *Table 2-1* on page 2-2 (Chapter 3).
- Changed usp3i.rev1.6 to usp3i.rev3.7 in step 1 of Section 3.2.4, "Updating the System Flash PROM," on page 3-6.

- Deleted Table 3-3 from Section 3.2.5, “Additional OBP Commands” on page 3-8, and referred the reader to Table 2-2 (Chapter 3).
- Changed “Unix system administrator” to “Themis Technical Support” in the last paragraph of Section 3.2.4, “Updating the System Flash PROM,” on page 3-7 (Chapter 3).
- Added Section 3.2.4.2, “Updating the System Flash Prom From a SCSI Disk,” on page 3-8 (Chapter 3).
- In the last paragraph of Section 3.2.5.1, “Accessing VME Address Space from OBP,” on page 3-9, changed reset command to reset-all, and added the VME select-dev command (Chapter 3).
- Changed “Sun’s Solstice” to “smosservice and/or smdiskless” in the 2nd to last paragraph on page 3-14 in Section 3.3, “Overview of VME Interface Under Solaris (Chapter 3).
- Added sections 3.3 through 3.5.5 on pages 3-14 through 3-39 to include the VME program documentation from the USP-2 Programmer’s Guide manual (Chapter 3).
- Global changed driver names “themvme” to “pcivme” and “sbvmemem” to “vmemem” on pages 3-14 through 3-17 (Chapter 3).
- Global changed THEMISvme to THEMIS3ivme on pages 3-16 through 3-20 (Chapter 3).
- Added two paragraphs to the bottom of page 5-3 in Section 5.2, “Thermal Monitoring,” regarding detection of temperature error conditions (Chapter 5).
- Added 1 sentence to the bottom of page 5-7 in Section 5.2.1, “Setting Temperature Thresholds,” regarding the usp3i_temp -m utility (Chapter 5).
- Removed references to company-internal infrastructure (tintin) throughout the document.
- Changed “single-board computer” to “multi-slot VME computer” in the introduction of page ix (Preface).
- Added a note regarding the look of the “ok” prompt in Section 2.2, “OBP VME Environment Variables,” on page 2-1 (Chapter 2).
- Added footnote b, regarding VME address windows, to *Table 2-1* on page 2-2 (Chapter 2).
- Added a note to Section 2.3, “Additional VME OBP Commands,” on page 2-3, regarding OBP commands not available in all versions of OBP.
- Changed Openboot “3.x” to Openboot “4.x” in *Table 2-2* on page 2-3 (Chapter 2).
- Deleted obsolete commands from *Table 2-2* on page 2-3 (Chapter 2).
- Reworded the note on in Section 3.2.1 “OBP VME Environment Variables” on page 3-2 (Chapter 3).
- Revised and added text to the last paragraph on page 3-2, regarding different OBP environment variables in different OBP versions (Chapter 3).
- Deleted the values for the nvramrc environment variable in *Table 3-1* on page 3-4 (Chapter 3).
- Added a reference to the *Universe II VME-to-PCI Bus Bridge User’s Manual* after *Table 3-2* on page 3-5 (Chapter 3).
- Changed the default value for vme32-slave-size in *Table 3-2* on page 3-5 (Chapter 3).
- Edited and added text to Section 3.2.3.1, “probe-scsi-all,” on page 3-6 (Chapter 3).

- Added a new subhead to Section 3.2.4 (3.2.4.1, Updating the System Flash from the Network), and renumbered the subsequent subhead—pages 3-7 and 3-8 (Chapter 3).
- Added the first sentence in Section 3.2.4.1, stating that the user must have access to a tftp server . . . on page 3-7 (Chapter 3).
- Made multiple edits to Sections 3.2.4.1 and 3.2.4.2 on pages 3-7 through 3-9 (Chapter 3).
- Added a note to Section 3.2.5 on page 3-9, regarding OBP commands and versions (Chapter 3).
- Changed the four Universe II registers (bulleted list) at the top of page 3-10 in Section 3.2.5.1 (Chapter 3).
- Changed the sample commands (just above the note) on page 3-10 in Section 3.2.5.1 (Chapter 3).
- Added a note to Section 3.2.5.1 on page 3-10 regarding OBP commands and version (Chapter 3).
- Deleted the last sentence of the 1st paragraph in Section 3.2.5.2 on page 3-11 (Chapter 3).
- Added footnote “a” to *Table 3-3* on page 3-14 (Chapter 3).
- Changed multiple occurrences of “Solaris 2.x” to “Solaris” in Chapter 3.
- Changed SBus to PCI Bus throughout Chapter 3.
- Added a description of an alternate form of the pkgadd command to Section 3.3.1.2 on page 3-17 (Chapter 3).
- Revised the fourth paragraph of Section 3.3.1.2 (just before the note) on page 3-17 (Chapter 3).
- Updated the sample installation log of the VME nexus driver on page 3-18 (Chapter 3).
- Updated the sample installation log of the sample drivers on page 3-21 (Chapter 3).
- Updated the sample uninstallation log of sample drivers on page 3-23 (Chapter 3).
- Deleted explanations of “simplifiedma” and “testmbi” and added explanations for “sw_reset_n_sysfail” and “sysfail_test” sample drivers, in Section 3.3.4 on page 3-25 (Chapter 3).
- Added the last sentence to Section 3.4.2 on page 3-27, that reads “The corresponding variables . . .” (Chapter 3).
- Deleted the 3rd and 4th paragraphs (including the bulleted list) of Section 3.4.3 on page 3-27 (Chapter 3).
- Deleted the last two paragraphs of Section 3.4.5 on page 3-29 (Chapter 3).
- Rewrote the last sentence of the last paragraph of Section 3.4.5.1 on page 3-29 (Chapter 3).
- Changed the reference to “Chapter 8” to “Section 3.3.4” in the 4th paragraph of Section 3.5 on page 3-32 (Chapter 3).
- Changed the vector values in the 2nd to last paragraph of Section 3.5 (Chapter 3).
- Edited any mention of the SIGBUS signal in regards to accessing nonexistent address space, in multiple occurrences throughout Chapter 3.

- Added two PLD registers to the list on page 4-1: “user-and-boot-device-jumpers” and “RMW-semaphore-and-test” (Chapter 4).
- Changed 3 occurrences of “System LED” to “Enable LED” in the description of bit 1 under PLD register: offset0x06 on Page 4-6.
- Enhanced and updated the index.
- Made assorted minor revisions and grammatical corrections.

Version 1.2		July 2004
Version 1.1		December 2003
Version 1.0		September 2003

Table of Contents

How to Use This Manual	xi
1. USPIIIi Programming Guide	1-1
1.1 Introduction	1-1
1.2 Jbus Address Map	1-2
1.3 I2C Bus Topology	1-5
1.4 I2C Devices Address Map	1-6
1.5 Ebus Device Address Map	1-10
1.6 PLD Registers	1-10
1.7 PCI-Ebus Bridge Configuration EEPROM	1-11
1.8 Universe II VME Interface Registers	1-14
2. OBP Commands	2-1
2.1 Themis OBP Commands	2-1
2.2 OBP VME Environment Variables	2-1
2.3 Additional VME OBP Commands	2-3
3. Themis USPIIIi Software	3-1
3.1 Introduction	3-1
3.2 SUN OpenBoot PROM (OBP)	3-1
3.2.1 OBP VME Environment Variables	3-2
3.2.2 Setting and Reading VME OBP Environment in Hex	3-6
3.2.3 Support Commands	3-6
3.2.3.1 probe-scsi-all	3-6
3.2.4 Updating the System Flash PROM	3-6
3.2.4.1 Updating the System Flash PROM from the Network	3-7
3.2.4.2 Updating the System Flash Prom From a SCSI Disk	3-8

3.2.5	Additional OBP commands	3-9
3.2.5.1	Accessing VME Address Space from OBP	3-9
3.2.5.2	VME Mapping Support under OBP	3-11
3.2.5.3	USPIIIi OBP Device aliases	3-13
3.3	Overview of VME Interface Under Solaris	3-15
3.3.1	VMEbus Nexus Driver	3-16
3.3.1.1	Installing the USPIIIi VME Nexus Driver	3-17
3.3.1.2	Installing THEMIS3ivme	3-17
3.3.1.3	Removing THEMIS3ivme	3-20
3.3.2	Utility Drivers	3-21
3.3.3	Installing the Sample Drivers	3-21
3.3.3.1	Uninstalling the Sample Drivers	3-23
3.3.4	Sample VME Programs and VME Leaf Drivers	3-24
3.4	Writing Programs for the VMEbus	3-25
3.4.1	Solaris Device Hierarchy	3-25
3.4.2	Configuring the Software Interface of USPIIIi	3-27
3.4.3	Accessing the VMEbus from OBP	3-27
3.4.4	Accessing the VMEbus from Solaris	3-27
3.4.5	Using Read/Write	3-27
3.4.5.1	Using mmap	3-29
3.4.5.2	Slave Mode Access to Another VME Board	3-29
3.5	Writing VME Device Drivers	3-32
3.5.1	Probing Devices	3-34
3.5.2	Registering Interrupts	3-35
3.5.3	Allocating DVMA Space	3-37
3.5.4	Mapping VMEbus Space	3-39
3.5.5	Driving Devices Without Writing Device Drivers	3-39
3.5.6	Environmental Monitoring Programs	3-41
	usp3i_temp	3-41
	usp3i_voltage	3-41
	usp3i_uled	3-42
	usp3i_pld and plxdrv	3-42

4. Programmable Logic Device	4-1
4.1 PLD Function Upgrade	4-1
4.1.1 Examples	4-2
4.2 PLD Register Set	4-3
4.3 Output from <code>themis-show-pld</code>	4-11
5. Device Monitoring	5-1
5.1 Introduction	5-1
5.2 Thermal Monitoring	5-1
5.2.1 Setting Temperature Thresholds	5-4
5.3 Voltage Monitoring	5-8
Index.....	I-1

List of Figures

Figure 1-1	Jbus Address Space Mapping to PCI Configuration Space	1-4
Figure 1-2	I2C Bus Topology	1-5
Figure 1-3	UCSR Access Mechanism	1-14
Figure 3-1	Nexus Driver Directory Structure	3-16
Figure 3-2	USPIIIi Device Tree	3-26
Figure 5-1	Placement of USPIIIi Device Monitors	5-2
Figure 5-2	Outputs of the Temperature Sensor Controller	5-3


List of Tables

Table 1-1	Jbus ID Assignment	1-3
Table 1-2	Jbus Address Map	1-3
Table 1-3	USPIIIi I2C Devices	1-6
Table 1-4	USPIIIi Ebus Devices	1-10
Table 1-5	EEPROM Addresses and Data	1-11
Table 1-6	Universe II Register Map	1-15
Table 2-1	OBP VME Environment Variables	2-2
Table 2-2	VME OBP Commands	2-3
Table 3-1	OBP Environment Variables	3-3
Table 3-2	OBP VME Environment Variables	3-5
Table 3-3	List of OBP aliases	3-14
Table 3-4	VMEbus Interrupt Mapping	3-17
Table 3-5	vmem Device Driver	3-21
Table 3-6	VME Special Files	3-28
Table 3-7	Address Space	3-33
Table 3-8	Temperature Monitoring Commands	3-41
Table 3-9	Voltage Monitoring Command	3-42
Table 3-10	User Status LED Commands	3-42
Table 3-11	PLD Commands	3-42
Table 5-1	Voltages Monitored on the CPU-0 and CPU-1 Boards	5-8

How to Use This Manual

Introduction

The Themis Computer **USPIIIi** is an UltraSPARC-IIIi-based multi-slot VME computer (see photo below) that is SPARC version 9.0 compliant with a VMEbus interface. The software interface for the VMEbus and other on-board peripheral devices is transparently implemented under Solaris. Themis Computer has also developed custom software that enables software programmers to effectively use the powerful features of the VMEbus Interface.



The USPIIIi has a total of 14 models (see *Table 1*). All models are based on a combination of six different VME boards: the USPIIIi System board, two CPU boards (CPU-0 and CPU-1), the TGA3D/3D+ Graphics board, and two PMC Carrier boards (one with 2 PMC slots and one with 3 PMC slots).

In addition, several VME-backplane-connected paddle boards are available for the USPIIIi that provide I/O connections through the P2 backplane connector (for details, see the *USPIIIi Hardware Manual* [Themis P/N 110615-022]).

The *USPIIIi Hardware Manual* also provides information on the hardware design of the USPIIIi system, including a product overview, OBP commands, device monitoring, connector pinouts, jumper-pin and solder-bead configurations, circuit-board and front-panel diagrams, LED interpretation, and VME-slot configurations.



Note: To avoid confusion about the numbering of VME slots in the USPIIIi system (represented in *Table 1*), Themis Computer offers the following explanation:

Although the USPIIIi system may require multiple VME slots, the System Board is considered to be in *logical* VME slot 1, even though one or two VME slots to the left of the System Board may be *physically* occupied by CPU-0 and/or CPU-1.

Table 1. USPIIIi Model Configurations

Model /Configuration	CPU-1	CPU-0	System Board	TGA3D/3D+ Graphics Board		PMC Carrier Board (1 only)	
			VME Slot 1	VME Slot 2	VME Slot 3	2-PMC Slots VME Slot 2 or 3	3-PMC Slots VME Slot 2 or 3
USPIIIi/1-1		Yes	Yes				
USPIIIi/1-2	Yes	Yes	Yes				
USPIIIi/2G-1		Yes	Yes	Yes			
USPIIIi/2G-2	Yes	Yes	Yes	Yes			
USPIIIi/3G2-1		Yes	Yes	Yes	Yes		
USPIIIi/3G2-2	Yes	Yes	Yes	Yes	Yes		
USPIIIi/3GP2-1		Yes	Yes	Yes		Yes (VME Slot 3)	
USPIIIi/3GP2-2	Yes	Yes	Yes	Yes		Yes (VME Slot 3)	
USPIIIi/3GP3-1		Yes	Yes	Yes			Yes (VME Slot 3)
USPIIIi/3GP3-2	Yes	Yes	Yes	Yes			Yes (VME Slot 3)
USPIIIi/2P2-1		Yes	Yes			Yes (VME Slot 2)	
USPIIIi/2P2-2	Yes	Yes	Yes			Yes (VME Slot 2)	
USPIIIi/2P3-1		Yes	Yes				Yes (VME Slot 2)
USPIIIi/2P3-2	Yes	Yes	Yes				Yes (VME Slot 2)

Intended Audience

The custom software containing programs, documentation, and packaging, is targeted for various software users:

- System Administrators who install the software and perform the necessary software configuration.
- Users who perform day-to-day operations on USPIIIi systems.
- Application programmers who write user-level programs to access the VMEbus interface devices through the built-in VMEbus devices.
- System programmers/device-driver writers who develop kernel-level device drivers for VMEbus devices.

Some functions overlap one another. The basic concepts required for many of these functions are common. This manual is structured around the basic concepts of using a VMEbus system.

In Case Of Difficulties

If the USPIIIi does not behave as described or if you encounter difficulties installing or configuring the board, please call Themis Computer technical support at +1 (510) 252-0870, fax your questions to +1 (510) 490-5529, or e-mail to support@themis.com. You can also contact us via our web site: <http://www.themis.com>.

UNIX Commands

This document may not contain information on basic UNIX[®] commands and procedures such as shutting down the system, booting the system, and configuring devices.

See one or more of the following for this information:

- *Solaris Handbook for Sun Peripherals*, which contains Solaris™ software commands
- *A Practical Guide to Solaris*, Copyright 1999, Mark G. Sobell
- AnswerBook™ on-line documentation for the Solaris software environment
- Other software documentation that you received with your system

Shell Prompts

In UNIX, the primary method for telling the computer what to do is to type commands at a shell prompt. The following table shows the default prompts for four different Solaris software shells.

Shell	Prompt
C shell	<i>machine_name%</i>
C shell superuser	<i>machine_name#</i>
Bourne shell and Korn shell	\$
Bourne shell and Korn shell superuser	#

Website Information

Themis Computer's corporate and product information may be accessed on the World Wide Web by browsing the website at <http://www.themis.com>.

Notes, Cautions, Warnings, and Sidebars

The following icons and formatted text are included in this document for the reasons described:



Note: A note provides additional information that may be helpful in carrying out a procedure or action.



Caution: A caution describes a procedure or action that may result in injury to the operator or equipment. This may involve—but is not restricted to—heavy equipment or sharp objects. To reduce the risk, follow the instructions accompanying this symbol.



Warning: A warning describes a procedure or action that may cause injury to the operator or equipment as a result of hazardous voltages. To reduce the risk of electrical shock and danger, follow the instructions accompanying this symbol.



Sidebar: A “sidebar” adds detail to the section within which it is placed, but is not absolutely vital to the description or procedure of the section.

Your Comments are Welcome

We are interested in improving our documentation and welcome your comments and suggestions. You can email your comments to us at docfeedback@themis.com. Please include the document part number in the subject line of your email.

USPIIIi Programming Guide

1.1 Introduction

This document provides critical information for software programmers who must write the firmware code to control the extra hardware features implemented on the USPIIIi. The native firmware from Sun was modified by Themis to accommodate the topology differences between the Sun reference platform (the Sun Blade 2500 workstation) and the Themis USPIIIi.

The following is a list of features implemented on the USPIIIi:

- User 8MB flash memory (AMD device AM29LV065D)
- TTY C and D ports using the usual SAB 82532 from Infineon (formerly Siemens)
- User LED I²C driver
- Analog voltage I²C converter
- An additional I²C thermal sensor ADM1031 dedicated to the second CPU board temperature monitoring
- Dual fiber-channel controller ISP2312
- VME interface based on the Universe-II controller
- USPIIIi specific control/status registers implemented into a CY37512 programmable logic device from Cypress
- H/W read/modify write (or test and set) semaphores for shared resources

Themis modifications include:

- PCI segments topology and its IDsel assignments
- Interrupt assignment/mapping, which impacts the Tomatillo initialization
- I²C bus topology and its address map
- Jbus topology (although it will be transparent to the firmware/software)

1.2 Jbus Address Map

The Jbus has several agents. Each has its own Agent ID (JID) number, which is used in the decoding process. The Jbus address space has 43 address bits, or 8 Terabytes of address reach. This space is broken up into two 42-bit physical spaces, one for the memory space (cacheable), the other for the IO space (non-cacheable)

Main Memory 4TB I/O space 4TB	0x000.0000.0000
	includes 16GB for CPU0 cacheable memory space 16GB for CPU1 cacheable memory space
	0x400.0000.0000
	includes Jbus device configuration space PCI address spaces (Cfg/IO/Mem)
	0x800.0000.0000

Each agent on Jbus has its own 5-bit Jbus ID. It has 8 MB of non-cacheable address space assigned for its Jbus configuration registers. These 8-MB windows are defined by:

- PA[42:41] = 10b
- PA[40:28] = 0.0000.0000.0000b
- PA[27:23] = JID[4:0]
- PA[22:00] = 8MB for Jbus device configuration registers

Table 1-1. Jbus ID Assignment

Jbus Agent	JID[4..0]	Jbus Cfg space		
		Start address	End address	Size
Jalapeno CPU0	0x00	0x400.0000.0000	0X400.007f.ffff	8 MB
Jalapeno CPU1	0x01	0x400.0080.0000	0X400.00ff.ffff	8 MB
Jalapeno CPU2	0x02	0x400.0100.0000	0X400.017f.ffff	8 MB
Jalapeno CPU3	0x03	0x400.0180.0000	0X400.01ff.ffff	8 MB
Habanero	0x08	0x400.0400.0000	0X400.047f.ffff	8 MB
Tomatillo 0 (Slave)	0x1c	0x400.0e00.0000	0X400.0e7f.ffff	8 MB
Tomatillo 1 (Master)	0x1e	0x400.0f00.0000	0X400.0f7f.ffff	8 MB

Each Jbus agent has its own specific Jbus configuration space layout. The table below provides the layout for the Tomatillo.

Table 1-2. Jbus Address Map

Register	add to Jbus cfg base
Jbus Tomatillo ID register	0x0000.0000
UPA0 offset base register	0x0040.0000
UPA0 offset mask register	0x0040.0008
UPA1 offset base register	0x0040.0010
UPA1 offset mask register	0x0040.0018
PCI-A memory offset base register	0x0040.0040
PCI-A memory offset mask register	0x0040.0048
PCI-A Cfg offset base register	0x0040.0050
PCI-A Cfg offset mask register	0x0040.0058
PCI-B memory offset base register	0x0040.0060
PCI-B memory offset mask register	0x0040.0068
PCI-B Cfg offset base register	0x0040.0070
PCI-B Cfg offset mask register	0x0040.0078
Tomatillo CSR	0x0041.0000
PCI-A CSR base register	0x0050.0000
PCI-B CSR base register	0x0060.0000
lchip CSR base register	0x0078.0000




Figure 1-1. Jbus Address Space Mapping to PCI Configuration Space

1.3 I²C Bus Topology

The USPIIIi has several I²C busses numbered 1 to 6. Their topology is provided in *Figure 1-2*.




Figure 1-2. I²C Bus Topology

1.4 I²C Devices Address Map

The following table lists all I²C devices on the USPIIIi and provides relevant setting information for each of them.

Table 1-3. USPIIIi I²C Devices

Board	Device	I ² C Bus #	HW Physical Address	SW Virtual Address	I ² C Controller with Description
System	ADM1031	I ² C_1	0x58	0x58	<i>I²C controller:</i> PCF8584 on Xbus • Temperature monitoring on the system board • Therm output used for the thermal interrupt
System	ICS951601	I ² C_1	0xD2	0xD2	<i>I²C controller:</i> PCF8584 on Xbus • PCI clock generator
CPU-0	ADM1031	I ² C_2	0x5C	0x5C	<i>I²C controller:</i> PCF8584 on Xbus and IMAX I ² C to I ² C bus expander; I ² C_2 bus is attached to Port #0 of Imax • Temperature monitoring on the CPU-0 board Diode D1 = CPU-0 die Diode D2 = CPU-0 reference Temp1
CPU-0	PCF8591	I ² C_4	0x90	0x90	<i>I²C controller:</i> PCF8584 on Xbus and IMAX I ² C to I ² C bus expander; I ² C_4 bus is attached to Port #2 of Imax • DC/DC voltage monitoring on CPU-0 - AIN0 -> VCC (Vme backplane) - AIN1 -> 2.5V (DDR voltage) - AIN2 -> 1.5V (Jbus voltage) - AIN3 -> VCCP0 (CPU-0 core voltage)

Table 1-3. USPIII I²C Devices (Continued)

Board	Device	I ² C Bus #	HW Physical Address	SW Virtual Address	I ² C Controller with Description
CPU-0	PCF8574	I ² C_4	0x40	0x40	<i>I²C controller:</i> PCF8584 on Xbus and IMAX I ² C to I ² C bus expander; I ² C_4 bus is attached to Port #2 of Imax • Control of User LEDs - P0 -> User LED 0 - P1 -> User LED 1 - P2 -> User LED 2 - P3 -> User LED 3 - P4 to P7 unassigned
CPU-0	AT24C64	JIO Master U12601	0xAE	0xAE	USPIII system parameters stored in EEPROM
CPU-0	MC12430	JIO slave U10601	Pseudo	Pseudo	Jbus clock generator
Memory 0	24LCS52	I ² C_2	0xA0	0xB6	<i>I²C controller:</i> PCF8584 on Xbus and IMAX I ² C to I ² C bus expander; I ² C_2 bus is attached to Port #0 of Imax • DDR DIMM EEPROM SDF (1st DIMM)
Memory 0	24LCS52	I ² C_2	0xA2	0xB8	<i>I²C controller:</i> PCF8584 on Xbus and IMAX I ² C to I ² C bus expander; I ² C_2 bus is attached to Port #0 of Imax • DDR DIMM EEPROM SDF (2nd DIMM)
Memory 0	24LCS52	I ² C_2	0xA4	0xBA	<i>I²C controller:</i> PCF8584 on Xbus and IMAX I ² C to I ² C bus expander; I ² C_2 bus is attached to Port #0 of Imax • DDR DIMM EEPROM SDF (3rd DIMM)
Memory 0	24LCS52	I ² C_2	0xA6	0xBC	<i>I²C controller:</i> PCF8584 on Xbus and IMAX I ² C to I ² C bus expander; I ² C_2 bus is attached to Port #0 of Imax • DDR DIMM EEPROM SDF (4th DIMM)

Table 1-3. USPIII I²C Devices (Continued)

Board	Device	I ² C Bus #	HW Physical Address	SW Virtual Address	I ² C Controller with Description
CPU-1	ADM1031	I ² C_3	0x5A	0x5E	<i>I²C controller:</i> PCF8584 on Xbus and IMAX I²C to I²C bus expander; I²C_3 bus is attached to Port #1 of Imax • Temperature monitoring on the CPU-1 board Diode D1 = CPU-1 die Diode D2 = CPU-1 reference Temp2
CPU-1	PCF8591	I ² C_3	0x92	0x92	<i>I²C controller:</i> PCF8584 on Xbus and IMAX I²C to I²C bus expander; I²C_3 bus is attached to Port #1 of Imax • DC/DC voltage monitoring on CPU-1 - AIN0 -> VCC (VME backplane) - AIN1 -> 2.5V (DDR voltage) - AIN2 -> 1.5V (Jbus voltage) - AIN3 -> VCCP1 (CPU-1 core voltage)
Memory 1	24LCS52	I ² C_3	0xA0	0xC6	<i>I²C controller:</i> PCF8584 on Xbus and IMAX I²C to I²C bus expander; I²C_3 bus is attached to Port #1 of Imax • DDR DIMM EEPROM SDF (1st DIMM)
Memory 1	24LCS52	I ² C_3	0xA2	0xC8	<i>I²C controller:</i> PCF8584 on Xbus and IMAX I²C to I²C bus expander; I²C_3 bus is attached to Port #1 of Imax • DDR DIMM EEPROM SDF (2nd DIMM)
Memory 1	24LCS52	I ² C_3	0xA4	0xCA	<i>I²C controller:</i> PCF8584 on Xbus and IMAX I²C to I²C bus expander; I²C_3 bus is attached to Port #1 of Imax • DDR DIMM EEPROM SDF (3rd DIMM)
Memory 1	24LCS52	I ² C_3	0xA6	0xCC	<i>I²C controller:</i> PCF8584 on Xbus and IMAX I²C to I²C bus expander; I²C_3 bus is attached to Port #1 of Imax • DDR DIMM EEPROM SDF (4th DIMM)

The I²C to I²C bridge expander (IMAX) is a microcontroller located on the CPU0 board. This bridge expander fans out the main primary I²C bus (called I²C_1 in this document) in four secondary I²C busses called I²C_2 to I²C_5. Those I²C busses are attached to Port 0 to 3 respectively of the IMAX bridge. The IMAX is itself an I²C device, programmed by OBP through the Xbus-to-I²C bridge controlled by the Southbridge ASIC on the system board. (see I²C bus topology in *Figure 1-2* on page 1-5). The I²C address of the IMAX is 0x12.

All the programming details are provided by Sun into two documents. Those documents are:

- imax_code.pdf
- imax_info.pdf (the most relevant for the firmware programmer)

Because of the change on the I2C topology and the additional devices, the address filter bitmap, the routing table and the address translation page table in the Imax must be modified at the OBP level.

1.5 Ebus Device Address Map

Table 1-4 lists all the USPIIIi devices located on the Ebus, and provides relevant information for each of them. The Ebus controller is the PLX9030, which bridges the PCI-2A-33Mhz bus (Boot PCI bus) to the Ebus peripheral bus.

Table 1-4. USPIIIi Ebus Devices

Board	Device • Part Number • Reference Des.	Address Size	Description
System	Flash 8Mx8 • AMD29LV065 • U4701	0x80.0000	<i>User Flash - AMD29LV065</i> 8MBytes Attached to CS0 of the PLX9030
System	Serial controller • SAB82532 • U1101	0x80	<i>8-bit bus implementation</i> Implements TTY ports C&D Attached to CS2 of the PLX9030
System	PLD Cypress • CY37512 • U3901	0x100	<i>Cypress PLD</i> Implements miscellaneous registers Attached to CS3 of the PLX9030

The base address of each device will be assigned by OBP during the PCI probing process. Size information is located in the EEPROM configuration device attached to the PLX9030.

The AMD 29LV065 programming algorithm is fully described in the datasheet of this component.

1.6 PLD Registers

The various registers of the Cypress Programmable Logic Device (PLD or CPLD) are used to control many different functions of the USPIIIi.

[See Chapter 4, "Programmable Logic Device", for a full description of the PLD registers.]

1.7 PCI-Ebus Bridge Configuration EEPROM

The Ebus is controlled by the PLX PCI9030 bridge from PLX technology. The PCI configuration registers can be downloaded after reset from a non-volatile memory EEPROM companion device. The EEPROM contains the information that is specific to our implementation. When the EEPROM is not present or is blank, the PCI9030 ASIC will automatically set the PCI configuration registers to their default values. It is then possible to program from the PCI bus. Utility functions are available under OBP to program and/or reprogram the content of the EEPROM for the initialization phase of the product. Utility functions are also available to fix on-site issues without having to return the board to manufacturing for upgrade.

Table 1-5. EEPROM Addresses and Data

EEPROM Address	EEPROM Data	Comments
0x00	0x9030	PCI device ID
0x02	0x10B5	PCI Vendor ID
0x04	0xCA90	
0x06	0x0000	
0x08	0x0680	
0x0A	0x0000	The Rev ID should match the original rev ID.
0x0C	0x0000	
0x0E	0x0000	
0x10	0x0000	
0x12	0x0040	
0x14	0x0000	
0x16	0x0100	
0x18	0x4801	
0x1A	0x4801	
0x1C	0x0000	
0x1E	0x0000	

Table 1-5. EEPROM Addresses and Data (Continued)

EEPROM Address	EEPROM Data	Comments
0x20	0x0000	
0x22	0x4c06	
0x24	0x0000	
0x26	0x0003	
0x28	0x0F80	LAS0RR for User flash
0x2A	0x0000	8 Mbytes, memory space, No prefetch
0x2C	0x0000	LAS1RR not assigned
0x2E	0x0000	
0x30	0x0FFF	LAS2RR for TTY C/D
0x32	0xFF81	128 Bytes, IO space.
0x34	0x0FFF	LAS3RR for PLD registers
0x36	0xFF01	256 Bytes, IO space.
0x38	0x0000	
0x3A	0x0000	
0x3C	0x0000	
0x3E	0x0001	Enable Cs0 space address decoding on PCI
0x40	0x0000	
0x42	0x0000	Disable Cs1 space address decoding on PCI
0x44	0x0000	
0x46	0x0001	Enable Cs2 space address decoding on PCI
0x48	0x0000	
0x4A	0x0001	Enable Cs3 space address decoding on PCI
0x4C	0x0000	
0x4E	0x0000	
0x50	0x5431	

Table 1-5. EEPROM Addresses and Data (Continued)

EEPROM Address	EEPROM Data	Comments
0x52	0xB8C0	
0x54	0x0000	
0x56	0x0000	
0x58	0x5431	
0x5A	0xB8C0	
0x5C	0x5431	
0x5E	0xB8C0	
0x60	0x0000	
0x62	0x0000	
0x64	0x0080	
0x66	0x0001	
0x68	0x0000	
0x6A	0x0000	
0x6C	0x0000	
0x6E	0x0081	
0x70	0x0000	
0x72	0x0101	
0x74	0x0030	
0x76	0x0040	
0x78	0x0078	
0x7A	0x0000	
0x7C	0x0024	
0x7E	0x9240	

1.8 Universe II VME Interface Registers

The Universe II Control and Status Registers (UCSR) facilitate host system configuration and allow you to control Universe II operational characteristics. The registers are divided into the following groups:

- VMEbus Configuration and Status Registers
- Universe II Device Specific Status Registers
 - The Universe II registers have little-endian byte-ordering
- PCI Configuration Space

A Universe-II register map is shown in *Table 1-6* on page 1-15.




Figure 1-3. UCSR Access Mechanism

Table 1-6. Universe II Register Map

Offset	Register	Name
000	PCI Configuration Space ID Register	PCI_ID
004	PCI Configuration Space Control and Status Register	PCI_CSR
008	PCI Configuration Class Register	PCI_CLASS
00C	PCI Configuration Miscellaneous 0 Register	PCI_MISC0
010	PCI Configuration Base Address 0 Register	PCI_BS0
014	PCI Configuration Base Address 1 Register	PCI_BS1
018-024	PCI Unimplemented	
028	PCI Reserved	
02C	PCI Reserved	
030	PCI Unimplemented	
034	PCI Reserved	
038	PCI Reserved	
03C	PCI Configuration Miscellaneous 1 Register PCI_MISC1	PCI_MISC1
040-0FF	PCI Unimplemented	
100	PCI Target Image 0 Control Register	LSI0_CTL
104	PCI Target Image 0 Base Address Register	LSI0_BS
108	PCI Target Image 0 Bound Address Register	LSI0_BD
10C	PCI Target Image 0 Translation Offset Register	LSI0_TO
110	Reserved	
114	PCI Target Image 1 Control Register	LSI1_CTL
118	PCI Target Image 1 Base Address Register	LSI1_BS
11C	PCI Target Image 1 Bound Address Register	LSI1_BD
120	PCI Target Image 1 Translation Offset Register	LSI1_TO
124	Reserved	
128	PCI Target Image 2 Control Register	LSI2_CTL
12C	PCI Target Image 2 Base Address Register	LSI2_BS

Table 1-6. Universe II Register Map (Continued)

Offset	Register	Name
130	PCI Target Image 2 Bound Address Register	LSI2_BD
134	PCI Target Image 2 Translation Offset Register	LSI2_TO
138	Reserved	
13C	PCI Target Image 3 Control Register	LSI3_CTL
140	PCI Target Image 3 Base Address Register	LSI3_BS
144	PCI Target Image 3 Bound Address Register	LSI3_BD
148	PCI Target Image 3 Translation Offset Register	LSI3_TO
14C-16C	Reserved	
170	Special Cycle Control Register	SCYC_CTL
174	Special Cycle PCI Bus Address Register	SCYC_ADDR
178	Special Cycle Swap/Compare Enable Register	SCYC_EN
17C	Special Cycle Compare Data Register	SCYC_CMP
180	Special Cycle Swap Data Register	SCYC_SWP
184	PCI Miscellaneous Register	LMISC
188	Special PCI Target Image Register	SLSI
18C	PCI Command Error Log Register	L_CMDERR
190	PCI Address Error Log Register	LAERR
194-19C	Reserved	
1A0	PCI Target Image 4 Control Register	LSI4_CTL
1A4	PCI Target Image 4 Base Address Register	LSI4_BS
1A8	PCI Target Image 4 Bound Address Register	LSI4_BD
1AC	PCI Target Image 4 Translation Offset Register	LSI4_TO
1B0	Reserved	
1B4	PCI Target Image 5 Control Register	LSI5_CTL
1B8	PCI Target Image 5 Base Address Register	LSI5_BS
1BC	PCI Target Image 5 Bound Address Register	LSI5_BD
1C0	PCI Target Image 5 Translation Offset Register	LSI5_TO

Table 1-6. Universe II Register Map (Continued)

Offset	Register	Name
1C4	Reserved	
1C8	PCI Target Image 6 Control Register	LSI6_CTL
1CC	PCI Target Image 6 Base Address Register	LSI6_BS
1D0	PCI Target Image 6 Bound Address Register	LSI6_BD
1D4	PCI Target Image 6 Translation Offset Register	LSI6_TO
1D8	Reserved	
1DC	PCI Target Image 7 Control Register	LSI7_CTL
1E0	PCI Target Image 7 Base Address Register	LSI7_BS
1E4	PCI Target Image 7 Bound Address Register	LSI7_BD
1E8	PCI Target Image 7 Translation Offset Register	LSI7_TO
1EC-1FC	Reserved	
200	DMA Transfer Control Register	DCTL
204	DMA Transfer Byte Count Register	DTBC
208	DMA PCI Bus Address Register	DLA
20C	Reserved	
210	DMA VMEbus Address Register	DVA
214	Reserved	
218	DMA Command Packet Pointer Register	DCPP
21C	Reserved	
220	DMA General Control and Status Register	DGCS
224	DMA Linked List Update Enable Register	D_LLUE
228-2FC	Reserved	
300	PCI Interrupt ENABLE Register	LINT_EN
304	PCI Interrupt Status Register	LINT_STAT
308	PCI Interrupt Map 0 Register	LINT_MAP0
30C	PCI Interrupt Map 1 Register	LINT_MAP1

Table 1-6. Universe II Register Map (Continued)

Offset	Register	Name
320	Interrupt Status/ID Out Register	STATID
324	VIRQ1 STATUS/ID Register	V1_STATID
328	VIRQ2 STATUS/ID Register	V2_STATID
32C	VIRQ3 STATUS/ID Register	V3_STATID
330	VIRQ4 STATUS/ID Register	V4_STATID
334	VIRQ5 STATUS/ID Register	V5_STATID
338	VIRQ6 STATUS/ID Register	V6_STATID
33C	VIRQ7 STATUS/ID Register	V7_STATID
340	PCI Interrupt Map 2 Register	LINT_MAP2
344	VME Interrupt Map 1 Register	VINT_MAP2
348	Mailbox 0 Register	MBOX0
34C	Mailbox 1 Register	MBOX1
350	Mailbox 2 Register	MBOX2
354	Mailbox 3 Register	MBOX3
358	Semaphore 0 Register	SEMA0
35C	Semaphore 1 Register	SEMA1
360-3FC	Reserved	
400	Master Control Register	MAST_CTL
404	Miscellaneous Control Register	MISC_CTL
408	Miscellaneous Status Register	MISC_STAT
40C	User AM Codes Register	USER_AM
410-EFC	Reserved	
F00	VMEbus Slave Image 0 Control Register	VSIO_CTL
F04	VMEbus Slave Image 0 Base Address Register	VSIO_BS
F08	VMEbus Slave Image 0 bound Address Register	VSIO_BD
F0C	VMEbus Slave Image 0 Translation Offset Register	VSIO_TO

Table 1-6. Universe II Register Map (Continued)

Offset	Register	Name
F10	Reserved	
F14	VMEbus Slave Image 1 Control Register	VSI1_CTL
F18	VMEbus Slave Image 1 Bound Address Register	VSI1_BS
F1C	VMEbus Slave Image 1 Bound Address Register	VSI1_BD
F20	VMEbus Slave Image 1 Translation Offset Register	VSI1_TO
F24	Reserved	
F28	VMEbus Slave Image 2 Control Register	VSI2_CTL
F2C	VMEbus Slave Image 2 Bound Address Register	VSI2_BS
F30	VMEbus Slave Image 2 Bound Address Register	VSI2_BD
F34	VMEbus Slave Image 2 Translation Offset Register	VSI2_TO
F38	Reserved	
F3C	VMEbus Slave Image 3 Control Register	VSI3_CTL
F40	VMEbus Slave Image 3 Bound Address Register	VSI3_BS
F44	VMEbus Slave Image 3 Bound Address Register	VSI3_BD
F48	VMEbus Slave Image 3 Translation Offset Register	VSI3_TO
F4C-F60	Reserved	
F64	Location Monitor Control Register	LM_CTL
F68	Location Monitor Base Address Register	LM_BS
F6C	Reserved	
F70	VMEbus Register Access Image Control Register	VRAI_CTL
F74	VMEbus Register Access Image Base Address Register	VRAI_BS
F78	Reserved	
F7C	Reserved	
F80	VMEbus CSR Control Register	VCSR_CTL
F84	VMEbus CSR Translation Offset Register	VSCR_TO
F88	VMEbus AM Code Error Log Register	V_AMERR

Table 1-6. Universe II Register Map (Continued)

Offset	Register	Name
F8C	VMEbus Address Error Log Register	VAERR
F90	VMEbus Slave Image 4 Control Register	VSI4_CTL
F94	VMEbus Slave Image 4 Bound Address Register	VSI4_BS
F98	VMEbus Slave Image 4 Bound Address Register	VSI4_BD
F9C	VMEbus Slave Image 4 Translation Offset Register	VSI4_TO
FA0	Reserved	
FA4	VMEbus Slave Image 5 Control Register	VSI5_CTL
FA8	VMEbus Slave Image 5 Bound Address Register	VSI5_BS
FAC	VMEbus Slave Image 5 Bound Address Register	VSI5_BD
FB0	VMEbus Slave Image 5 Translation Offset Register	VSI5_TO
FB4	Reserved	
FB8	VMEbus Slave Image 6 Control Register	VSI6_CTL
FBC	VMEbus Slave Image 6 Bound Address Register	VSI6_BS
FC0	VMEbus Slave Image 6 Bound Address Register	VSI6_BD
FC4	VMEbus Slave Image 6 Translation Offset Register	VSI6_TO
FC8	Reserved	
FCC	VMEbus Slave Image 7 Control Register	VSI7_CTL
FD0	VMEbus Slave Image 7 Bound Address Register	VSI7_BS
FD4	VMEbus Slave Image 7 Bound Address Register	VSI7_BD
FD8	VMEbus Slave Image 7 Translation Offset Register	VSI7_TO
FDC-FEC	Reserved	
FF0	VME CR/CSR Reserved	
FF4	VMEbus CSR Bit Clear Register	VCSR_CLR
FF8	VMEbus CSR Bit Set Register	VCSR_SET
FFC	VMEbus CSR Address Register	VCSR_BS

OBP Commands

2.1 Themis OBP Commands

The USPIIIi incorporates Sun's standard OBP version 4.x as the default firmware. Themis has added specific OBP functions to support the additional Fibre Channel and VME functions. The VME commands are summarized in the remaining sections of this chapter.

2.2 OBP VME Environment Variables

The environment variables (see *Table 2-1* on page 2-2) may be set at the “ok” prompt in OBP by using the `setenv` command:



Note: The “ok” prompt appears differently for different systems. For example, on a single-processor system, the prompt appears as “ok.” However, on a system with two CPUs (such as the UltraSPARC), the prompt may be designated as “{0} ok” or “{1} ok.” For the purposes of this manual, future references to the “ok” prompt, will be designated, simply, as “ok.”

```
ok    setenv variable_name value
```

When running Solaris, the `eeeprom` command can view or modify environment variables (the syntax may vary depending on the type of command-line shell being used):

```
#    eeeprom variable_name=value
```



Note: Modified environment variables will not take effect until you reboot the system. There are a number of ways to reboot the system. For example, you can execute the OBP command `reset-all` or you can recycle power. From within Solaris, execute the `reboot` command to shut down the operating system and then reboot.

Table 2-1. OBP VME Environment Variables^a

Variable Name	Value	Default Value	Description
force-system-controller	true/false	false	If set to "true", Universe II is forced to be the system controller. If set to false, the system-controller status is determined by auto-sensing circuitry.
vme-bus-request-level	0–7	0	Level used to request the VME bus.
vme-request-mode	fair/demand	fair	When the Universe II requests the VME bus, it can use either "fair" or "demand" mode.
vme-release-mode	ror/rwd	ror	When the Universe II releases the VME bus, it can use either "ror" (release on request) or "rwd" (release when done).
vme-arbitration-mode	round-robin/priority	round-robin	Arbitration mode used if the USPIII is the system controller.
vme-irq-to-service	1, 2, 3, 4, 5, 6	1, 2, 3, 4, 5, 6	VME bus interrupt level to be serviced by the VME leaf driver.
vme32-master-base	0–4294967295	0	Defines a master window on VME. All subsequent VME mappings that fall within this window will use this window instead of allocating one of the remaining Universe II register sets to define a new window. The best use of this master window is to define it to encompass all other VME device addresses (if possible) that will be accessed by the USPIII.
vme32-master-size	0–4294967295	0	Size of the master VME-bus address window. Must be less than 1.2 GB.
vme32-master-mode	24, 32	32	If 32 (decimal) is used, space is A32D32. If 24 (decimal) is used, space is A24D32.
vme32-slave-base	0–4294901760	1048576	Slave window base address in A32 mode ^b .
vme32-slave-size	0–4294967295	4294967295	Slave window size in A32 mode ^b .
vme24-slave-base	0–16777216	0	Slave window base address in A24 mode.
vme24-slave-size	0–16777216	16777216	Slave window size in A24 mode.

a. Numerical values are decimal.

b. To avoid self-reference, the VME address window defined by `vme32-slave-base` and `vme32-slave-size` should not overlap the VME address window defined by `vme32-master-base` and `vme32-master-size`.

2.3 Additional VME OBP Commands

The following table describes a list of OBP commands that are accessible when the current node is VME. To set the current node to VME, execute the OBP command “vme select-dev”.



Note: Some versions of OBP do not employ the “vme select-dev” command. If this command does not work on your system, use the command: “cd /pci@1e,600000/THEMIS,pci vme”.

Table 2-2. VME OBP Commands

Command	Description
show-universe-regs	Reads and displays all the Universe II registers.
<offset> universe-reg@	Reads and places on the OBP stack, the Universe II register content located at offset <offset> from the Universe II base address (Consult the Sun <i>Open-Boot 4.x Command Reference</i> for instructions on displaying stack contents; for example, the command <code>showstack.</code>)
<offset> universe-reg@ .	Reads and displays the Universe II register contents located at offset <offset> from the Universe II base address.
<data> <offset> universe-reg!	Writes the value <data> into the Universe II register located at offset <offset> from the Universe II base address.

Themis USPIIIi Software

3.1 Introduction

This chapter describes the software used on the Themis USPIIIi. This includes the OBP firmware, Sun Solaris 8 2/04, Sun Solaris 9 4/04 or later, or Sun Solaris 10 Operating Systems. The default firmware is Sun's Open Boot Prom (OBP) that has been modified to support VME. OBP will boot the Solaris operating system.

3.2 SUN OpenBoot PROM (OBP)

The Themis USPIIIi OBP is based on OBP 4.x from Sun. Themis has added several OBP command extensions that are specific to the USPIIIi. All other OBP commands are the same as the Sun UltraSPARC-IIIi Platform (as implemented in the Sun Blade 2500 workstation). Specific details of the OBP architecture are defined in the IEEE 1275 specification document. Reference materials that describe the OBP include:

- OpenBoot 4.x Command Reference—Sun Part Number: 816-1177-10
- OpenBoot Quick Reference 3.x—Sun Part Number: 806-2908-10
- Writing FCode 3.x Programs—Sun Part Number: 806-1379-10

3.2.1 OBP VME Environment Variables

The environment variables (see *Table 3-1* below and *Table 3-2* on page 3-5) may be set at the `ok` prompt in OBP by using the `setenv` command.

```
ok setenv variable_name value
```

when running Solaris with the command line (the syntax may vary depending on the shell used):

```
# eeprom variable_name=value
```

A board RESET is required for the new values to take effect.



Note: In OBP all values are in decimal form, so you would enter the command as follows: `eeprom vme32-slave-size=0x800000`. However, this can be inconvenient when dealing with values that are better represented in hexadecimal, such as VME addresses. Refer to Section 3.2.2, "Setting and Reading VME OBP Environment in Hex," on page 3-6 for instructions on how to easily use hexadecimal numbers in the command line.

The Solaris command line will accept hexadecimal values if they are preceded by `0x`. From within Solaris type the command as follows:
`eeprom vme32-slave-size=8388608.`

Table 3-1 shows an example of the results of the `printenv` command. Your results might show more or less environment variables, depending on what version of OBP you have.

Table 3-1. OBP Environment Variables

{1} ok printenv		
Variable Name	Value	Default Value
themis-switch-value	255	255
force-system-controller	false	false
vme-bus-request-level	0	0
vme-request-mode	fair	fair
vme-release-mode	ror	ror
vme-arbitration-mode	round-robin	round-robin
vme-irq-to-service	1,2,3,4,5,6	1,2,3,4,5,6
vme32-master-base	0	0
vme32-master-size	0	0
vme32-master-mode	32	32
vme32-slave-base	1048576	1048576
vme32-slave-size	4294967295	4294967295
vme24-slave-base	0	0
Variable Name	Value	Default Value
vme24-slave-size	16777216	16777216
extra-64m-segments	1	1
vme-init	3735928559	3735928559
themis-cpu-count	2	2
test-args		
diag-passes	1	1
therm-reset-hold	disabled	disabled
audio-device?	disabled	disabled
system-low-limit	0	0
system-therm-limit	110	80
system-high-limit	100	70
cpu1-low-limit	5	5
cpu1-therm-limit	115	115
cpu1-high-limit	105	105
cpu0-low-limit	5	5
cpu0-therm-limit	115	115
cpu0-high-limit	105	105
local-mac-address?	true	true
fcode-debug?	false	false
silent-mode?	false	false
scsi-initiator-id	7	7

Table 3-1. OBP Environment Variables (Continued)

oem-logo		No default
oem-logo?	false	false
oem-banner		No default
oem-banner?	false	false
ansi-terminal?	true	true
screen-#columns	80	80
screen-#rows	34	34
ttyb-rts-dtr-off	false	false
ttyb-ignore-cd	true	true
ttya-rts-dtr-off	false	false
ttya-ignore-cd	true	true
Variable Name	Value	Default Value
ttyb-mode	9600,8,n,1,-	9600,8,n,1,-
ttya-mode	9600,8,n,1,-	9600,8,n,1,-
output-device	screen	screen
input-device	keyboard	keyboard
auto-boot-on-error?	false	false
load-base	16384	16384
auto-boot?	false	true
boot-command	boot	boot
diag-file	kadb -rv	
diag-device	/pci@1d,700000/scsi@4/di ...net	
boot-file		
boot-device	disk:a disk5	disk net
use-nvramrc?	false	false
nvramrc		
security-mode	none	No default
security-password		No default
security-#badlogins	0	No default
diag-script	none	none
diag-level	min	max
diag-switch?	true	false
error-reset-recovery	boot	boot
{1} ok		

Table 3-2. OBP VME Environment Variables^a

Name	Value	Default Value	Description
force-system-controller	true/false	false	If set to “true”, Universe II is forced to be the system controller. If set to false, the system-controller status is determined by auto-sensing circuitry.
vme-bus-request-level	0–7	0	Level used to request the VME bus.
vme-request-mode	fair/demand	fair	When the Universe II requests the VME bus, it can use either “fair” or “demand” mode.
vme-release-mode	ror/rwd	ror	When the Universe II releases the VME bus, it can use either “ror” (release on request) or “rwd” (release when done).
vme-arbitration-mode	round-robin/priority	round-robin	Arbitration mode used if the USPIII is the system controller.
vme-irq-to-service	1, 2, 3, 4, 5, 6	1, 2, 3, 4, 5, 6	VME bus interrupt level to be serviced by the VME leaf driver.
vme32-master-base	0–4294967295	0	Defines a master window on VME. All subsequent VME mappings that fall within this window will use this window instead of allocating one of the remaining Universe II register sets to define a new window. The best use of this master window is to define it to encompass all other VME device addresses (if possible) that will be accessed by the USPIII.
vme32-master-size	0–4294967295	0	Size of the master VME-bus address window. Must be less than 1.2 GB.
vme32-master-mode	24, 32	32	If 32 (decimal) is used, space is A32D32. If 24 (decimal) is used, space is A24D32.
vme32-slave-base	0–4294901760	1048576	Slave window base address in A32 mode.
vme32-slave-size	0–16777216	16777216	Slave window size in A32 mode.
vme24-slave-base	0–16777216	0	Slave window base address in A24 mode.
vme24-slave-size	0–16777216	16777216	Slave window size in A24 mode.

a—Numerical values are decimal.

For a more detailed description of the VME values, refer to the *Universe II VME-to-PCI Bus Bridge User's Manual* (P/N 80A3010_MA001_03), available from Tundra Semiconductor Corporation.

3.2.2 Setting and Reading VME OBP Environment in Hex

Because an OBP environment variable is an integer, commands like `setenv` or `printenv` use the integer format. This makes setting the base address and base size awkward. To use hex number format, enter general variables to set and read address and base. For example,

```
ok 200000 to vme24-slave-size
```

and

```
ok vme24-slave size .h
```

3.2.3 Support Commands

3.2.3.1 probe-scsi-all

The command `probe-scsi-all` probes the first SCSI bus (SCSI A), the second SCSI bus (SCSI B), and the two FC-AL ports. This command behaves in a similar fashion to the standard OBP command `probe-scsi`.



Note: Probing FC-AL ports that are not connected to an FC-AL drive and do not have loopback connectors installed, will result in an “Link not ready - Loss of Sync” error message.

3.2.4 Updating the System Flash PROM



Warning: Great care must be taken when performing a Flash upgrade. If an invalid or corrupted PROM file was downloaded, or if you experience a power outage during the process, the USPIIIi may not be bootable. DO NOT interrupt the command while it is in progress.

3.2.4.1 Updating the System Flash PROM from the Network

To update the system flash PROM from the network, you will need to have access to a tftpboot server. To update the system flash PROM device:

1. First download the OBP image from the tftpboot server. To do this, type

```
4000 dload obpimage-file
```

For example,

```
{1} ok 4000 dload usp3i.rev3.7
```

```
Boot device: /pci@1f,700000/network@2:,usp3i.rev3.7
```

```
File and args:
```

```
1000 Mbps full-duplex
```

```
Timeout waiting for ARP/RARP packet
```

```
104000
```

```
Server IP address: 198.211.242.2
```

```
Client IP address: 198.211.242.62
```

2. Next, type the flash-update command to write the OBP image to the flash

```
{1} ok flash-update
```

which results in:

```
Update flash with the downloaded OBP image
```

```
Erasing ... done
```

```
Copying ..
```

```
Verifying ..
```

This command writes the previously downloaded obp image file to flash.

It is best to update your flash PROM directly after resetting the system.

Call your Themis Technical Support in case of problems.

3.2.4.2 Updating the System Flash Prom From a SCSI Disk



Note: When your system powers up, make sure it boots to the "ok" OBP prompt and then STOPS! It may be necessary for you to temporarily set the OBP variable "auto-boot?" to false, to prevent Solaris from automatically booting. The flash-update command described below will only work after a fresh power-up to the "ok" prompt. Flash-update will not work if you perform a STOP-A or Ctrl-Break key combination to interrupt the power-on self-test Solaris boot process. Nor will it work if Solaris is already running and you issue a "halt" or "init 0" command to arrive at the "ok" prompt.

To update the system flash PROM device using a SCSI disk:

1. Download the most recent OBP binary image file from the Themis ftp server.

Call Themis Customer Support at 510-252-0870 to obtain a user name and password that will allow you to access the Themis ftp server.

To find the OBP image file on the Themis ftp server, navigate through the subdirectories (or folders) as follows:

outgoing→Release→obp→USPIIIi→(select the folder with the appropriate rev. e.g., rev3.7)→(select the binary file with the appropriate name, e.g., 111068-080-usp3i_obp_revx.x_chk_5891.bin).

2. Copy the OBP image file to the root directory of the primary SCSI disk.

This procedure assumes that Solaris is already installed on the disk and was used to copy the OBP file to the root directory.

3. Make sure that "auto-boot?" is set to false, then shut down Solaris and power the USPIIIi off and on again. At the "ok" prompt, issue the following commands:

4. `ok load no-such-file`

Boot device: /pci@1d,700000/scsi@4/disk@0,0 File and args:no-such-file

5. `ok go`

Boot: cannot open no-such-file

Enter filename[no-such-file]

6. Send a break key-combination (see note, below).

Type 'go' to resume.



Note: The easiest way to send a break key-combination is to press STOP-A from a Sun keyboard, CTRL-Break from a PS/2 keyboard, or CTRL-Break from a HyperTerminal on a Windows XP desktop PC. If you are connected to the USPIIIi via TTYA, the method for sending a break character is dependent on the terminal or terminal-emulator software you are using. And, in fact, some versions of OBP will not accept a break event from the TTYA connection.

7. `ok load disk:,|usp3i.rev3.7`

8. Next type the flash-update command to write the OBP image to the flash:

```
ok flash-update
```

3.2.5 Additional OBP commands

To view a list of OBP commands that are accessible when the current node is VME, refer to *Table 2-2* on page 2-3. To set the current node to VME, execute the OBP command:

```
"vme select-dev"
```



Note: Some versions of OBP do not employ the “vme select-dev” command. If this command does not work on your system, use the command: “cd /pci@1e,600000/THEMIS,pcivme”.

3.2.5.1 Accessing VME Address Space from OBP

Prior to actually accessing VME from OBP, you need to make sure that the Universe II PCI target images are set correctly. A PCI target image is actually a window from PCI Bus to VMEbus. Each image or window defines a contiguous range of PCI addresses (base address and size). When a PCI cycle is issued by the USPIIIi CPU with an address falling inside a particular window address range, the Universe II will propagate that cycle to the VME. The VME cycle will be formed according to the attributes defined in the window registers:

- VME address
- VME Address modifier

(Please refer to the Universe II User's Manual for details.) The Themis OBP command `show-universe-regs` can be used to view the settings of the 8 address windows. Each window is controlled by four Universe II registers:

- LSx_CTL: control register
- LSx_BS: PCI base address of the window
- LSx_BD: PCI bound address of the window
- LSx_TO: Translation register

Suppose we want to access VME A32:0xaa00.0000:

```
ok aa00.0000 to vme32-master-base
ok 1000.0000 to vme32-master-size
ok reset-all
.....
ok vme select-dev
ok show-universe-regs
```



Note: Some versions of OBP do not employ the “vme select-dev” command. If this command does not work on your system, use the command: “cd /pci@1e,600000/THEMIS,pcivme”.

By carefully reviewing the output of the `show-universe-regs` command, we see that the mapping we defined using the `vme32-master-base` and `vme32-master-size` Themis OBP variables is controlled by the 7th window (LS7_CTL, LS7_BS, LS7_BD, LS7_TO). The LS7_BS register contains the base PCI address of that window (should be 0x800.0000). Now we can access VME using the OBP `space` command, which permits us to use physical addresses by bypassing the CPU MMU:

```
ok 1234 1ff.0800.0000 15 spacel! (writes 1234 to VME address A32:0xaa00.0000)
ok 1ff.0800.0000 15 spacel? (reads back from that address)
```

0x1ff.0000.0000 is the base address of the PCI bus through which VME is accessed. 0x15 is the SPARC ASI (address space identifier) that is defined for PCI accesses.



Note: The above VME accesses were made using the 0x09 Address modifier code. This could be a problem when trying to access other VME boards (like the Themis USPIIIi-1v, since it is programmed to accept supervisor address modifiers). To set the address modifier to be 0x0d (supervisor), simply enter:

```
ok ldc universe-reg@ 1000 or ldc universe-reg!
```

This will set the SUPER bit in LSI7_CTL.

That was for A32 VME accesses. These accesses are done using the 8 PCI target image windows. For A24 and A16 accesses a special Universe II window is used: the special PCI target image. The mechanism is the same as for A32 accesses. Please refer to the Universe II User's Manual for details.

3.2.5.2 VME Mapping Support under OBP

Due to the design of Tomatillo, whenever a non-existing VME location is accessed, a parity-error is recorded within Tomatillo that causes OBP to fail in the family of `peek` and `poke` (`cpeek`, `wpeek`, `lpeek`, `cpoke`, `wpoke`, and `lpoke`).

To circumvent this problem, OBP has been enhanced to use the DMA engine inside the Universe chip to do the `peek` and `poke` so that both can still work in the OBP.

Because `peek` and `poke` use virtual addresses, `map-in` and `map-out` commands have been enhanced to track the mapping to the VME Bus; hence the operations of `peek`, `poke`, memory access, etc., are transparent to the user. Thus, the syntax in the OBP reference manual has been preserved in the Themis USPIIIi VME node.

To help you read the mapping, the following symbols are defined:

```
7d value A24D32
6d value A16D32
3d value A24D16
2d value A16D16
4d value A32D32
0d value A32D16
```

Examples:

```
\ To test a register in VME A32D32 space.
showstack
a000.0000 A32D32 1000.0000 map-in value a32va
a32va 100 + value register-a
register-a map?
1234.5678 register-a lpoke
register-a lpeek
register-a l?
a32va 0040.0000 map-out
\ !!! Required after OBP testing is done.
```

```
\ To test a register in VME A24D16 space.
showstack
a0.0000 A24D16 10.0000 map-in value a24va
a24va 100 + value register-b
register-b map?
1234 register-b wpoke
register-b wpeek
register-b w?
a24va 10.0000 map-out
\ Not required after OBP testing is done.
```

```
\ To test a register in VME A16D16 space.
showstack
a000 A16D16 1000 map-in value a16va
a16va 100 + value register-c
register-c map?
12 register-c cpoke
register-c cpeek
register-c c?
a16va 1000 map-out
\ Not required after OBP testing is done.
```

Constraints:

Mapping a CPU virtual address to VME address space requires many resources. First, the MMU maps the CPU virtual address to a PCI physical address. Universe-II register sets are then used to map the PCI physical address to a VME address.

For A24 and A16 devices, due to its small physical size, PCI address space is preallocated and the Universe-II mapping register (the Special PCI Target Image Register at offset 0x188) is dedicated. Thus, at the end of OBP testing, `map-out` for A16 and A24 devices is not required.

For A32 devices, PCI address space and Universe-II mapping registers (PCI Target Image [0-7] at offset 0x100 to 0x1e8) are managed by the VME Nexus device driver when Solaris is running. Thus, at the end of OBP testing for A32 devices, the resource must be released by executing the `map-out` command. Otherwise, when Solaris is running, certain PCI addresses will be answered by more than one PCI target image.

Also, due to the complexity of managing resources using `fcode`, only one `map-in` is supported for all A32 space. Subsequent `map-in` for A32 devices will wipe out the mapping established in the previous `map-in`. The workaround for this is to map a huge region with a single `map-in` command. The VME node can map in more than 1 GByte of VME space in a single command.

For A24 and A16 devices, as many `map-in` commands can be used as the applications require and the mapping resources *don't* need to be freed at the end of testing using the `map-out` command.

3.2.5.3 USPIIIi OBP Device aliases

The `devalias` command displays the list of OBP aliases for the USPIIIi, as shown in *Table 3-3*.

Table 3-3. List of OBP aliases

ok devalias ^a	
net	/pci@1f,700000/network@2
ide	/pci@1e,600000/ide@d
cdrom	/pci@1d,700000/scsi@4/disk@6,0:f
disk1	/pci@1d,700000/scsi@4/disk@1,0
disk0	/pci@1d,700000/scsi@4/disk@0,0
disk	/pci@1d,700000/scsi@4/disk@0,0
scsi	/pci@1d,700000/scsi@4
ttyb	/pci@1e,600000/isa@7/serial@0,2e8
ttya	/pci@1e,600000/isa@7/serial@0,3f8

a—If your system has a graphics card installed, you will also see a screen alias defined, for your particular graphics card. For example, a Themis TGA-100 card screen alias would look like this:

screen /pci@1c,600000/pci@2/SUNW,XVR-100@2

3.3 Overview of VME Interface Under Solaris

Great effort has been expended to achieve complete compatibility between Sun VME implementations and the device driver interface implemented for the USPIIIi board under Solaris.

This section is primarily concerned with the implementation and programming of USPIIIi specific features that are not common to the Sun UltraSPARC family of workstations and servers. It assumes that the reader is familiar with the Sun4u architecture and concepts of the VMEbus and the device drivers.

The VMEbus interface of the USPIIIi is transparently implemented under Solaris 2. The software interface is fully compatible with generic Sun4u VME architecture systems. Any VME device driver that conforms to the appropriate Solaris Device Driver Interface will run unmodified on Themis platforms.

Themis Computer has developed a number of device drivers to provide the necessary software interface needed by system programmers. The drivers can be classified into three categories:

- VMEbus Nexus driver
- Utility drivers
- Sample drivers

The drivers are described in the following subsections. Themis also provides online manual pages for all the drivers included in the software interface. These manual pages include more detailed information on the drivers.

The USPIIIi can run the Solaris OS from either a local disk or from the Ethernet network as a diskless client. In the case of a local disk, the Solaris OS will be loaded from the Sun Solaris CD-ROM. To install the USPIIIi as a diskless client, users need to run `smosservice` and/or `smdiskless` on a boot server system. Please refer to Sun's documentation on how to install the Solaris Operating System.

In order to be able to access VME from Solaris, users need to install the Themis VME Nexus driver for the USPIIIi. The VME Nexus driver is a Solaris package, that is installed/removed using the `pkgadd (1M) /pkgrm (1M)` Solaris command. The installation is menu driven, and users should always reboot the system in the reconfiguration mode (`boot -r`) right after installing the VME Nexus driver.

3.3.1 VMEbus Nexus Driver

The pcivme Nexus driver forms the core of the software interface provided by Themis Computer. It is a bus Nexus driver that encapsulates all the architectural features of supporting the Themis USPIIIi board on Solaris systems. This driver is configured to be permanently loaded as the bus Nexus driver for the VMEbus.




Figure 3-1. Nexus Driver Directory Structure

Any driver that specifies its class or parent as “vme” will be attached to the pcivme driver. The pcivme driver provides support for all VMEbus operations, including VME interrupt processing, Direct Virtual Memory Access (DVMA) on the VMEbus, mapping of registers on the VMEbus to kernel space, mapping of VMEbus memory to user address space through `mmap()`, etc.

The pcivme driver recognizes the standard configuration file for VME device drivers. The configuration of any VME device driver specifies the VMEbus interrupt level and the interrupt vector. The mapping of the VMEbus interrupt level to the SPARC interrupt priority level is as follows:

Table 3-4. VMEbus Interrupt Mapping

System	Interrupt Level							
VMEbus		1	2	3	4	5	6	7
SPARC ip	1	2	3	5	7	9	11	13

3.3.1.1 Installing the USPIIIi VME Nexus Driver

The software interface for USPIIIi is distributed as a software package for Solaris systems. The software package is named **THEMIS3ivme** and can be installed and removed like other standard Solaris software packages, by using the `pkgadd` and `pkgrm` commands.

3.3.1.2 Installing THEMIS3ivme

The **THEMIS3ivme** package is distributed on standard media and can be installed directly from the media. To install the package, place the installation media in the appropriate slot and execute this command:

```
# pkgadd -d <media name>
```

where `<media name>` is the name of the media on your system. The `pkgadd` command will copy the contents of the package to the appropriate directories and perform the necessary installation. After the command completes, the system has to be rebooted for the new software to be operational. The `pcivme` and the `vmemem` drivers will be added to the system.

Another form of the `pkgadd` command is: `pkgadd -d <filename>`, where `<filename>` is the name of the binary file containing the package. It may be necessary to use this form of the `pkgadd` command after downloading a new version of the **THEMIS3ivme** package from the Themis FTP site.

You may choose to install sample leaf drivers by executing a script provided for that purpose. The sample drivers are not required for the normal operation of the USPIIIi system, however they are required to enable the VME programs to work properly. Refer to Section 3.3.4, "Sample VME Programs and VME Leaf Drivers," on page 3-24.



Note: The sample drivers will not be installed by this procedure. See Section 3.3.3, "Installing the Sample Drivers," on page 3-21.

During the course of installation, pkgadd will prompt you for input on optional configuration. The first prompt will ask you to choose the packages to be installed:

```
# pkgadd -d THEMIS3ivme.file

The following packages are available:
  1  THEMIS3ivme      Themis VME Drivers for SPARC USPIIIi (32/64-bit
Solaris 9)
                        (sparc) USPIIIi Release 1.1

Select package(s) you wish to process (or 'all' to process
all packages). (default: all) [?,??,q]:

Processing package instance <THEMIS3ivme> from </THEMIS3ivme.file>

Themis VME Drivers for SPARC USPIIIi (32/64-bit Solaris 9)
(sparc) USPIIIi Release 1.1
Themis Computer

You are about to install the vme nexus driver for Solaris 9
(32/64-bit version) to use the VMEbus interface on the Themis
USPIIIi

The package replaces the functionality of the vmemem
driver from the original Sun distribution.
However current versions of the files will be retained.
Please ensure that the vmemem drivers are not currently used.

After the installation, execute 'reboot -- "-r"'
to reboot the system using 64-bit kernel, or, execute
'reboot -- "-rD kernel/unix"' to use 32-bit kernel.
If the system cannot be rebooted at this time,
you may abort the installation of the package now.

Continue installation? [n] [y,n,?,q] y

Where should the driver objects be installed
[/platform/sun4u/kernel/drv] [?,q]
Using </> as the package base directory.
## Processing package information.
## Processing system information.
   9 package pathnames are already properly installed.
## Verifying disk space requirements.
## Checking for conflicts with packages already installed.
## Checking for setuid/setgid programs.

This package contains scripts which will be executed with super-user
permission during the process of installing this package.

Do you want to continue with the installation of <THEMIS3ivme> [y,n,?]
y
```

Installing Themis VME Drivers for SPARC USPIIIi (32/64-bit Solaris 9)
as <THEMIS3ivme>

```
## Executing preinstall script.
## Installing part 1 of 1.
[ verifying class <none> ]
[ verifying class <devlink> ]
[ verifying class <system> ]
/platform/sun4u/kernel/drv/pcivme
/platform/sun4u/kernel/drv/sparcv9/pcivme
/platform/sun4u/kernel/drv/sparcv9/sysfail
/platform/sun4u/kernel/drv/sparcv9/vmedma
/platform/sun4u/kernel/drv/sparcv9/vmemem
/platform/sun4u/kernel/drv/sysfail
/platform/sun4u/kernel/drv/sysfail.conf
/platform/sun4u/kernel/drv/vmedma
/platform/sun4u/kernel/drv/vmedma.conf
/platform/sun4u/kernel/drv/vmemem
/platform/sun4u/kernel/drv/vmemem.conf
[ verifying class <drv> ]
/usr/include/themis/sysfailio.h
/usr/include/themis/vmebustypes.h
/usr/include/themis/vmectllo.h
/usr/include/themis/vmedmaio.h
/usr/include/themis/vmedvma.h
/usr/include/themis/vmeintr.h
[ verifying class <include> ]
/usr/share/man/man7/vmedma.7
/usr/share/man/man7/vmedvma.7
/usr/share/man/man7/vmeintr.7
[ verifying class <manpage> ]
/opt/THEMIS3ivme/DOC/ddi_peekpoke.DOC
/opt/THEMIS3ivme/DOC/mailbox.DOC
/opt/THEMIS3ivme/DOC/sw_reset_n_sysfail.DOC
/opt/THEMIS3ivme/DOC/vmeintr.DOC
/opt/THEMIS3ivme/RELEASE.notes
/opt/THEMIS3ivme/drv/README.first
/opt/THEMIS3ivme/drv/bin/ddi_peekpoke32
/opt/THEMIS3ivme/drv/bin/sparcv9/ddi_peekpoke64
/opt/THEMIS3ivme/drv/bin/sparcv9/vmedvma
/opt/THEMIS3ivme/drv/bin/sparcv9/vmeintr
/opt/THEMIS3ivme/drv/bin/vmedvma
/opt/THEMIS3ivme/drv/bin/vmedvma.conf
/opt/THEMIS3ivme/drv/bin/vmeintr
/opt/THEMIS3ivme/drv/bin/vmeintr.conf
/opt/THEMIS3ivme/drv/install.sample
/opt/THEMIS3ivme/drv/remove.sample
/opt/THEMIS3ivme/drv/src/Makefile
/opt/THEMIS3ivme/drv/src/vmedvma.c
/opt/THEMIS3ivme/drv/src/vmeintr.c
```

```
/opt/THEMIS3ivme/drv/themis/universe.h
/opt/THEMIS3ivme/drv/themis/vmebustypes.h
/opt/THEMIS3ivme/drv/themis/vmedvma.h
/opt/THEMIS3ivme/drv/themis/vmeintr.h
/opt/THEMIS3ivme/example/Makefile
/opt/THEMIS3ivme/example/dmatest
/opt/THEMIS3ivme/example/dmatest.c
/opt/THEMIS3ivme/example/sparcv9/dmatest
/opt/THEMIS3ivme/example/sparcv9/sw_reset_n_sysfail
/opt/THEMIS3ivme/example/sparcv9/sysfail_test
/opt/THEMIS3ivme/example/sparcv9/vme_dvma
/opt/THEMIS3ivme/example/sparcv9/vme_intr
/opt/THEMIS3ivme/example/sparcv9/vme_mmap
/opt/THEMIS3ivme/example/sparcv9/vme_rw
/opt/THEMIS3ivme/example/sw_reset_n_sysfail
/opt/THEMIS3ivme/example/sw_reset_n_sysfail.c
/opt/THEMIS3ivme/example/sysfail_test
/opt/THEMIS3ivme/example/sysfail_test.c
/opt/THEMIS3ivme/example/vme_dvma
/opt/THEMIS3ivme/example/vme_dvma.c
/opt/THEMIS3ivme/example/vme_intr
/opt/THEMIS3ivme/example/vme_intr.c
/opt/THEMIS3ivme/example/vme_mmap
/opt/THEMIS3ivme/example/vme_mmap.c
/opt/THEMIS3ivme/example/vme_rw
/opt/THEMIS3ivme/example/vme_rw.c
[ verifying class <sample> ]
## Executing postinstall script.
Reboot client to install driver.
Reboot client to install driver.
Reboot client to install driver.
Reboot client to install driver.
```

It will be necessary to do a reconfiguration reboot after driver installation.

Execute 'reboot -- "-r"' to reboot the 64-bit kernel, or
execute 'reboot -- "-rD kernel/unix"' to use the 32-bit kernel.
The new vme drivers will not be functional till a reboot is done.

```
Installation of <THEMIS3ivme> was successful.
#
```

3.3.1.3 Removing THEMIS3ivme

If you want to remove the software interface of USPIII for any reason, you can execute the `pkgrm` command to remove the THEMIS3ivme package:

```
# pkgrm THEMIS3ivme
```

`pkgrm` will remove all the files contained in the package. The original contents of VME drivers before the package was installed will be restored.

3.3.2 Utility Drivers

These drivers are a standard part of the software interface provided by Themis Computer. These drivers provide a useful interface to system programmers who wish to utilize the different features of the VMEbus architecture.

The **vmemem** device driver provides the standard /dev devices for accessing the VMEbus from user processes:

Table 3-5. vmemem Device Driver

Device File	Address Size	Data Transfer Size
/dev/vme32d32	32	32
/dev/vme32d16	32	16
/dev/vme24d32	24	32
/dev/vme24d16	24	16
/dev/vme16d16	16	16

read(), write() and mmap() calls are supported and no special ioctl() calls are required to configure the interface.

3.3.3 Installing the Sample Drivers

The sample drivers (vmeintr, dvma, testmbi, simplifiedma) are not required for the normal operation of the USPIII system and therefore are not installed by the installation procedure described Section 3.3.1.2, "Installing THEMIS3ivme," on page 3-17. You may choose to install these drivers by executing a script provided for that purpose:

```
# cd /
# cd /opt
# ls -la
total 10
drwxr-xr-x  5 root    sys      512 Aug 23 15:02 .
drwxr-xr-x 23 root    root     512 Aug 23 15:04 ..
drwxr-xr-x  3 root    bin      512 Aug 17 12:15 SUNWits
drwxr-xr-x  5 root    sys      512 Aug 17 12:20 SUNWrtvc
drwxr-xr-x  6 bin     bin      512 Aug 23 15:02 THEMIS3ivme
# cd THEMIS3ivme
# ls -la
total 14
drwxr-xr-x  6 bin     bin      512 Aug 23 15:02 .
drwxr-xr-x  5 root    sys      512 Aug 23 15:02 ..
```

```

drwxr-xr-x  2 bin      bin      512 Aug 23 15:02 DOC
-rwxr-xr-x  1 bin      bin      382 Mar  4 2004 RELEASE.notes
drwxr-xr-x  6 bin      bin      512 Aug 23 15:02 drv
drwxr-xr-x  3 bin      bin      512 Aug 23 15:02 example
drwxr-xr-x  3 bin      bin      512 Aug 23 15:02 man
#
#
# ls -la
total 14
drwxr-xr-x  6 bin      bin      512 Aug 23 15:02 .
drwxr-xr-x  5 root     sys      512 Aug 23 15:02 ..
drwxr-xr-x  2 bin      bin      512 Aug 23 15:02 DOC
-rwxr-xr-x  1 bin      bin      382 Mar  4 2004 RELEASE.notes
drwxr-xr-x  6 bin      bin      512 Aug 23 15:02 drv
drwxr-xr-x  3 bin      bin      512 Aug 23 15:02 example
drwxr-xr-x  3 bin      bin      512 Aug 23 15:02 man
# cd drv
# ls -la
total 28
drwxr-xr-x  6 bin      bin      512 Aug 23 15:02 .
drwxr-xr-x  6 bin      bin      512 Aug 23 15:02 ..
-rw-r--r--  1 bin      bin      2964 Mar  4 2004 README.first
drwxr-xr-x  3 bin      bin      512 Aug 23 15:02 bin
-rwxr-xr-x  1 bin      bin      2474 Mar  4 2004 install.sample
-rwxr-xr-x  1 bin      bin      1797 Mar  4 2004 remove.sample
drwxr-xr-x  2 bin      bin      512 Aug 23 15:02 src
drwxr-xr-x  2 bin      bin      512 Aug 23 15:02 sys
drwxr-xr-x  2 bin      bin      512 Aug 23 15:02 themis
#
# ./install.sample

```

```

*****
*           Installation Script for           *
*           Themis USPIIIi Solaris 9         *
*           sample device drivers            *
*****

```

This script installs the sample device drivers for Solaris 9 to use the VMEbus interface on the Themis USPIIIi.

The script creates symbolic links under /dev for the device special files.

=====

If you want to proceed, type y or Y. Otherwise, press any other key to abort.

y

```
... Replacing vmeintr interrupt driver
```

```
... Replacing vmedvma DVMA driver
```

```
... Updating /etc/devlink.tab
```

```
Installing new drivers
```

```
Copying header files
```

```
Installation completed.
```

```
#
```

3.3.3.1 Uninstalling the Sample Drivers

To uninstall the sample drivers:

```
# cd /opt/THEMIS3ivme/drv
#
# ls -la
total 28
drwxr-xr-x  6 bin      bin          512 Aug 23 15:02 .
drwxr-xr-x  6 bin      bin          512 Aug 23 15:02 ..
-rw-r--r--  1 bin      bin        2964 Mar  4  2004 README.first
drwxr-xr-x  3 bin      bin          512 Aug 23 15:02 bin
-rwxr-xr-x  1 bin      bin        2474 Mar  4  2004 install.sample
-rwxr-xr-x  1 bin      bin        1797 Mar  4  2004 remove.sample
drwxr-xr-x  2 bin      bin          512 Aug 23 15:02 src
drwxr-xr-x  2 bin      bin          512 Aug 23 15:02 sys
drwxr-xr-x  2 bin      bin          512 Aug 23 15:02 themis
#
# ./remove.sample
```

```
*****
*          Remove Script for                      *
*          Themis USPIIIi Solaris 9                *
*          sample device drivers                  *
*****
```

This script removes the sample device drivers for Solaris 9 to use the VMEbus interface on the Themis USPIIIi.

```
=====
```

If you want to proceed, type y or Y. Otherwise, press any other key to abort.

```
y
```

```
... Removing vmeintr interrupt driver

... Removing vmedvma DVMA driver

... Updating /etc/devlink.tab

Removing installed drivers

Removing header files

Removal completed.

#
```

3.3.4 Sample VME Programs and VME Leaf Drivers

The software interface provided for the USPIIIi platform fully supports standard VMEbus device drivers written for Solaris environments. It is the intention of Themis Computer to fully support users who wish to write their own VME device drivers that would function on USPIIIi platforms. To aid these users and to illustrate the specific features of the VMEbus architecture, Themis provides a number of sample device drivers. Themis provides the complete source code and the necessary configuration files for these drivers. The drivers are located under the /opt/THEMIS3ivme directory.

- **vmeintr**: This sample illustrates the vectored interrupt mechanism of the VMEbus. The vmeintr driver relies on the driver configuration files to specify the interrupts it should handle. Each instance of the driver registers the interrupts with the system. Through the ioctls implemented by the driver, you can generate interrupts and send them to the appropriate driver instances. The interrupt generator and the interrupt receiver need to run on different computers.
- **vmedvma**: This sample driver illustrates the use of Direct Virtual Memory Access within a device driver. You can ask the driver to allocate a DMA region on the VMEbus. The driver allocates all the necessary resources to support a DVMA transfer to this region. The driver also implements mechanisms by which you program can write to or read from the DVMA region.

Furthermore, the VME NEXUS package includes example programs to help users build their own application or test VME. The programs are:

- **dmatest**: This program uses the Universe II DMA engine. Several options can be selected by command line parameters.
- **vme_dvma**: This program sets the USPIIIi to be accessible from VME by enabling a slave window.

- **vme_intr:** This program uses the example driver `vmeintr` to send/receive VME interrupts.
- **vme_mmap:** This program accesses VME using the Solaris `mmap(2)` system calls. The system calls work by programming the MMU to map VME memory within the address space of the calling program. Further VME accesses are done using simple references, like C language pointers.
- **vme_rw:** This program accesses VME using the more traditional UNIX approach of doing I/Os. VME memory is accessed using the UNIX `read(2)` and `write(2)` system calls. This will result in slower VME transfer speed.
- **sw_reset_n_sysfail:** This program demonstrates the support of programmable VME RESET (software reset) and `sysfail`. It is an interactive program that allows you to explore the supported features.
- **sysfail_test:** This program tests the THEMIS `sysfail` driver. The `ioctl()` functions include:
 - SIOCENSYSF: Enable `sysfail` interrupts
 - SIOCREGSYSF: Sends a SIGSEGV if a SYSFAIL interrupt happens
 - SIOCUNREGSYSF: Unregister

3.4 Writing Programs for the VMEbus

The software interface of the USPIIIi is transparently implemented under Solaris. The software interface is fully compatible with the generic Sun4u VME architecture systems. Any VME device driver that conforms to the appropriate Solaris Device Driver Interface will run unmodified on Themis platforms.

This section is intended for system programmers who are not familiar with the Solaris architecture and the concepts of the VMEbus. The guide discusses the concepts of Solaris drivers and VMEbus devices as they pertain to the Themis USPIIIi product. The section is intended as a general introduction of the basic concepts of using the USPIIIi product under Solaris.

3.4.1 Solaris Device Hierarchy

Solaris systems support architecture independence of devices by using a layered approach. Devices and buses are represented in a data structure resembling an inverted tree. Each node in the tree structure has a specific device function. Standard devices are associated with leaf nodes. The drivers for these devices are called leaf drivers. The intermediate nodes in the tree are associated with buses, like PCI bus, VMEbus etc. These nodes are called bus nexus nodes and the drivers associated with

them are called bus nexus drivers. The bus nexus driver encapsulates all the architectural dependencies of a particular bus. The leaf driver only needs to know the kind of bus it is connected to.

The device tree for USPIII systems is shown below.




Figure 3-2. USPIII Device Tree

In this diagram, root, pcivme, and PCI bus are bus nexus drivers. The pcivme driver encapsulates all the details of the implementation of the VMEbus interface. The vmemem driver, which is a leaf driver, only needs to know that it is connected to the VMEbus.

Solaris, like other UNIX systems, represents devices as special files in the file systems. These files are advertised by the device driver and are maintained by the `drvconfig(1M)` program. Usually the special files are created under the `/devices` directory and represent the hardware layout of a particular machine. `sysdef(1)` and `prtconf(1)` can be used to view the internal device tree. Symbolic links are created from the `/dev` directory to the special files in the `/devices` directory. User programs normally use the files from the `/dev` directory.

VMEbus devices are not self-identifying, i.e., they do not provide information about themselves to the system. Drivers for VMEbus devices need to have a `probe()` entry so that the kernel can determine if the device is really present. Additional information about the device must be provided in a hardware configuration file. See `driver.conf(4)` for more information.

VMEbus interrupts are vectored. When a device interrupts, it provides the priority as well as an interrupt vector. The kernel uses the information to uniquely identify the interrupt service routine to be called. The hardware configuration file must specify each priority-vector pair that the device may issue.

3.4.2 Configuring the Software Interface of USPIIIi

The USPIIIi board can be accessed in a slave mode from another board on the VMEbus chassis. This type of access requires specifying the slave base address and the size of the slave access region of the USPIIIi board. Distinct values can be specified for 24-bit addresses and 32-bit addresses. On a VMEbus chassis with multiple boards, each processor board is required to have a non-overlapping region for slave mode access. The OBP variables `vme32-slave-base` and `vme24-slave-base` can be used to set the slave base addresses of a USPIIIi board. The corresponding variables `vme32-slave-size` and `vme24-slave-size` control the size of these slave windows.

3.4.3 Accessing the VMEbus from OBP

It is often convenient to access the VMEbus from the Open Boot PROM. For example, after adding a new memory board on the chassis, the OBP can be used to quickly test the proper installation and configuration of the memory board. Further testing of the board can then be done under the Solaris environment.

For a description of OBP commands themselves, please refer to the document named OpenBoot Command Reference.

3.4.4 Accessing the VMEbus from Solaris

This section describes the many features of the software interface provided by Themis Computer. The features provide the system programmer with powerful ways of accessing the VMEbus from the Solaris Operating System environment. Themis Computer has developed several sample programs that illustrate ways to use the software interface provided. These programs are available with the source code and can be used to test the configuration of a VME system. They can also be used as example programs for the use of the different features provided by the software interface.

The following subsections introduce the concepts of accessing the VMEbus from user programs. The reader may note that though the examples in this section use VMEbus memory boards, the usage can be extended to any type of VMEbus board.

3.4.5 Using Read/Write

The `vmemem` driver from Themis Computer enables you to access any VMEbus address from a user program. Depending on the address space used by the particular VMEbus card, different device files need to be used.

Table 3-6. VME Special Files

File	Address Size	Data Transfer Size	Physical Address Range
/dev/vme16d16	16 bits	16 bits	0x0-0xFFFF
/dev/vme24d16	24 bits	16 bits	0x0-0xFFFFFFFF
/dev/vme32d16	32 bits	16 bits	0x0-0xFFFFFFFF
/dev/vme24d32	24 bits	32 bits	0x0-0xFFFFFFFF
/dev/vme32d32	32 bits	32 bits	0x0-0xFFFFFFFF

For example, to access a VME card that supports 24-bit addresses and 32-bit data transfers, you need to use the file /dev/vme24d32.

Using /dev/vmeXXdYY files is very similar to using normal files; the user program opens the file, uses the memory address as an offset for the lseek system call, and does a read or write operation at the offset. The 'offset' must fall within the physical address range of the file that was opened; also there should be a VMEbus device that would respond to the address.

To access 16 bytes at the VMEbus address 0xa0000, the following code snippet can be used:

```
..
int fd;
int vme_base;
char buffer[16];

if ( ( fd = open( "/dev/vme24d32", O_RDWR ) < 0 )
{
    perror("In opening file /dev/vme24d32");
    return(-1);
}

vme_base = 0xa0000;
if ( lseek ( fd, vme_base, SEEK_SET) < 0 )
{
    perror("In lseeking to 0xa0000");
    close(fd);
    return(-1);
}

if ( read ( fd, buffer, sizeof(buffer) ) != sizeof(buffer) )
{
    perror("In reading 16 bytes");
    close(fd);
    return(-1);
}
.
.
```

In the above example, if there is no device on the VMEbus at address 0xa0000, the VMEbus operation will time-out and the program will return -1 with `errno` set to `EFAULT`.

3.4.5.1 Using `mmap`

A faster way to access VMEbus space is to use the `mmap(2)` system call. `mmap()` establishes a mapping between the user process's address space and a memory object represented by an open file. The `/dev/vmeXXdYY` files can be used for `mmap()` as well. For example, to access a region of length 1000 bytes in the VMEbus space, starting from location 0x500, the following code segment can be used:

```
.
int vme;
caddr_t pageptr;
.

if ((vme = open("/dev/vme32d32", O_RDWR)) < 0) {
    perror("open error on VME file");
    return;
}

if ((pageptr = mmap((caddr_t)0L, roundup( 1000, PAGE_SIZE),
    PROT_READ|PROT_WRITE, MAP_SHARED, vme,
    (off_t)(0x500 & PAGEMASK))) == (caddr_t)-1) {
    perror("mmap error");
    return;
}
.
```

Note that the 'off' parameter to `mmap()` is constrained to be aligned at a page boundary. The 'len' parameter does not have a size or alignment constraint. The success of `mmap()` does not imply that the specified range of VMEbus is valid and accessible. If the region specified by [off, off+len] is not a valid VMEbus address region, access to the region will panic (crash) the Solaris kernel.

3.4.5.2 Slave Mode Access to Another VME Board

Memory on the USPIII board can be accessed from another board on the VMEbus chassis. This type of access is called slave mode access. Slave mode access under Solaris is tied to the concept of Direct Virtual Memory Access (DVMA). DVMA is a facility present on SPARC hardware that allows a device driver to specify virtual addresses rather than physical addresses for a DMA operation. The kernel maintains a map that specifies the correspondence between the DVMA address and the physical memory.

In a typical operation, the master issues an address on the VMEbus; this address falls within the slave address range of another board on the chassis. The VME controller on the slave board then converts the VME address into an PCI bus virtual address. The VME controller then performs a DVMA operation on the PCI bus to access the physical memory location. The PCI bus virtual address generated by the VME slave access must be configured in the IOMMU translation table. Themis Computer provides a driver that performs this configuration; the driver allocates a DVMA region and sets it up for VMEbus slave access at a particular VMEbus address. The master board simply uses this VMEbus address and generates a slave access operation on the VMEbus. The system that allocated the DVMA memory can also access the region by using special ioctl calls provided by the driver. Please refer to Section 3.3.4, "Sample VME Programs and VME Leaf Drivers," on page 3-24 for more information on the vmedvma driver.

The following code segment sets up a memory region of size 8192 bytes for DVMA access:

```
.
#include <themis/vmedvma.h>
.
.
.
int fd;
struct vme_dvmacopy dma_req;
/* open the device */
if ((fd = open("/dev/vmedvma", O_RDWR)) < 0)
{
    perror("can't open /dev/vmedvma");
    exit(1);
}
/* allocate a DVMA region */
dma_req.size = 8192;
if (ioctl(fd, VDMA_ALLOCATE, &dma_req) != 0)
{
    perror("In allocating DVMA");
    close(fd);
    return(-1);
}
printf("Allocated a DVMA region id : %d, at virtual address : %x\n",
dma_req.id, dma_req.addr);
.
.
.
```

The 'virtual address' output by this program can be used by other boards on the VMEbus chassis to gain access to this DVMA region. For example, if a second board on the same chassis needs to access this region, one can execute this command:

```
od -x /dev/vme24d32 {slave_address}
```

where {slave_address} is the virtual address output by the program.

The DVMA region can be accessed from the same system by invoking the `ioctl()` calls implemented by the `vmedvma` driver. The following code segment fills a DVMA region with zeros, starting from offset 0x500.

```
.
struct vme_dvmacopy dma_write;
char * buffer;
.
.
buffer = malloc( 4096);

dma_write.id = 1;
dma_write.addr= (caddr_t) buffer;
dma_write.size= 4096;
dma_write.offset= 2048;

if (ioctl(fd, VDMA_WRITE, &dma_write) != 0)
{
perror("In initializing DVMA region");
close(fd);
return(-1);
}
.
```

3.5 Writing VME Device Drivers

A device driver is a kernel module responsible for managing low-level I/O operations for a particular hardware device. Some device drivers manage ‘fake’ devices that exist only in software. A device driver contains all the device-specific code to communicate with a device. Like the system call interface protects application programs from the specifics of the platform, the device drivers protect the kernel from the specifics of the devices. A device driver also provides a standard I/O interface to the rest of the system; i.e., a user program should be able to open a ‘device file’ and issue (in most cases a subset of) standard system calls to the file.

The VMEbus interface of Themis Computer’s USPIIIi is transparently implemented under Solaris. Note that no software support is provided for Solaris 1.x. The software interface is fully compatible with the generic Sun4u VME architecture systems. Any VME device driver that conforms to the appropriate Solaris Device Driver Interface will run unmodified on Themis platforms.

This guide is intended to highlight the VMEbus specific features that influence the design of drivers for VMEbus devices. It tries to provide basic information, and when needed, refers to sources for more detailed information on specific concepts. A full introduction to the principles of writing device drivers is beyond the scope of this guide. The book “SunOS 5.x Writing Device Drivers” has extensive information on writing device drivers for Solaris systems.

Themis Computer has developed a number of sample device drivers that illustrate the concepts covered in this chapter. Please see Section 3.3.4, “Sample VME Programs and VME Leaf Drivers,” on page 3-24, for more information on the sample device drivers. These drivers, along with user level programs that interface to them, are provided in source code format.

The last section in the guide discusses the situations where developing a custom device driver may not be necessary. It discusses mechanisms by which most device operations can be performed from the user level.

Driver configuration files pass information about device drivers and their configuration to the system. Since VMEbus devices are not self-identifying, drivers for these devices need to use driver configuration files to inform the system that the device hardware may be present. The configuration file also must specify the device addresses on the VMEbus and any interrupt capabilities that the device may have.

The syntax of an entry in the configuration file is:

```
name="driver name" class="vme" reg="...." interrupts="...";
```

Specifying class as "vme" indicates to the kernel that the device driver is for a VMEbus device and should be attached to the VMEbus nexus driver. On USPIII systems, the bus nexus driver is named pcivme.

Two common properties of interest to VME device drivers are the reg and interrupts properties. The reg property is an array of 3-tuples: address space, offset and length. Each 3-tuple describes a contiguous resource (registers) that can be mapped. The value of the address space is derived from the following table:

Table 3-7. Address Space

Address Space	Value
A16:D16	0x2D
A24:D16	0x3D
A32:D16	0xD
A16:D32	not supported
A24:D32	0x7D
A32:D32	0x4D

As an example, for a device that supports A24D32 and has a set of registers that are 32-byte long and start at address 0xee00, the following 3-tuple can be used: 0x7d, 0xee00,32. Multiple register sets are separated by commas.

VMEbus supports vectored interrupts. The interrupts property in the driver configuration file specifies all the interrupts that the device may generate. The interrupts property is an array of 2-tuples: VMEbus interrupt level, VMEbus vector number. For example, for a device that generates interrupts at VME level 3 with a vector of 0x84, this two-tuple can be used: 2, 0x84. The VMEbus interrupt level has a value between 1 and 7, and the vector a value between 2 and 254.

All VMEbus device drivers must provide reg properties. The first two integer elements of this property are used to construct the address part of the device name under /devices. Only devices that generate interrupts need to provide interrupt properties.

Note that the DDI/DKI functions are capable of handling the VMEbus specific features, provided that the hardware configuration file is correct. e.g., if the hardware configuration file correctly defines a register set, the `ddi_map_regs()` function can be used to map the register set into kernel address space, without any extra effort from the driver code.

3.5.1 Probing Devices

Since VME devices are not self-identifying, drivers for these devices are required to have a probe entry point. Usually the probe entry point tries to map the registers and then attempt to access the hardware using any of the peek and poke routines. The probe entry point should not initialize the device in any way; it also should not initialize any of the software state.

Mapping registers from VMEbus space do not need any special considerations. The `ddi_map_regs()` function call can be used to map the registers; this function will take care of the VMEbus address space that the register set is in.

The following code segment is an example of mapping a register set and 'carefully' accessing a byte in the set.

```
/*
 * xxprobe      - probe for this device
 */
static int
xxprobe(dev_info_t *dip)
{
    struct my_reg_str *regs; /* Device registers */
    caddr_t kaddr;          /* mapped register address */
    int retval;             /* return value */

    /*
     * If we're self-identifying, then we're here.
     */
    if (ddi_dev_is_sid(dip) == DDI_SUCCESS)
        return DDI_PROBE_SUCCESS;

    /*
     * Probe the device by mapping the registers, and reading the
     * command register and the parm7 register...This assures that
     * *something* is there. The attach routine will try to run
     * more rigorous checks. So this simple check is all we
     * really need here.
     */
}
```

```

    if ((retval = ddi_map_regs(dip, 0, &kaddr, 0, 0)) != DDI_SUCCESS) {
        cmn_err(CE_WARN, "xx%d(probe): can't map my registers, error%d\n",
            ddi_get_instance(dip), retval);
        return DDI_PROBE_FAILURE;
    }

    regs = (struct my_reg_str *)kaddr;
    retval = ddi_peekl(dip, (long *)&regs->command, (long *)0)
        == DDI_SUCCESS ? DDI_PROBE_SUCCESS : DDI_PROBE_FAILURE;
    if (retval == DDI_PROBE_SUCCESS)
        retval = ddi_peekl(dip, (long *)&regs->parm7, (long *)0)
            == DDI_SUCCESS ? DDI_PROBE_SUCCESS : DDI_PROBE_FAILURE;
    ddi_unmap_regs(dip, 0, &kaddr, 0, 0);
    return retval;
}

```

3.5.2 Registering Interrupts

VMEbus interrupts are vectored. When a device interrupts, it provides the priority as well as an interrupt vector. The kernel uses the information to uniquely identify the interrupt service routine to be called. The hardware configuration file must specify each priority-vector pair that the device may issue. Once this has been done, the driver code can call the `ddi_add_intr()` function to register the interrupts. On return from this function, the fourth argument contains a pointer that points to useful information like the VMEbus interrupt priority and the VMEbus vector number.

The following code segment provides an example of registering an interrupt with the kernel; the code first gets the number of interrupt specifications in the configuration file; then it registers an interrupt handler for each interrupt specification.

```

static int
xxattach(dev_info_t * dip, ddi_attach_cmd_t cmd)
{
    struct xxstat * xsp;
    int nbint, i;
    .

    if ( cmd != DDI_ATTACH)
        return (DDI_FAILURE);
    .
    .
    /* get the number of interrupt definitions */
    if (ddi_dev_nintrs(devi, &nbint) == DDI_FAILURE)
    {
        cmn_err(CE_WARN, "xx: No interrupts property.");
        return (DDI_FAILURE);
    }
}

```

```
for ( i=0; i < nbint; i++)
{
/* Register first with a null handler so that the interrupt
 * routine doesn't grab the mutex
 */
if ( ddi_add_intr(dip, i, &xsp->iblock_cookie[i],NULL,
( (u_int (*) (caddr_t) nulldev, NULL) != DDI_SUCCESS)

{
cmn_err(CE_WARN,"xx: cannot register interrupt.");
return (DDI_FAILURE);
}

/* Initialize the mutex now. */
mutex_init ( &xsp->mu, "xx mutex", MUTEX_DRIVER,
(void *) xsp->iblock_cookie[i]);

/* Remove the interrupt and register again with the correct
 * interrupt handler.
 */
ddi_remove_intr ( dip, i, xsp->iblock_cookie[i]);
if ( ddi_add_intr(dip, i, &xsp->iblock_cookie[i],
&xsp->idevice_cookie[i], xxintr, NULL) != DDI_SUCCESS)

{
cmn_err(CE_WARN,"xx: cannot register interrupt.");
return (DDI_FAILURE);
}

cmn_err (CE_NOTE,"Registered interrupt %d with priority %d and vector
0x%x",
i, xsp->idevice_cookie[i].idev_priority,
xsp->idevice_cookie[i].idev_vector);
}
.
.
```

Themis Computer provides a sample device driver, `vmeintr`, to illustrate the use of interrupts in device drivers. This driver is provided along with the source code and a sample configuration file. The reader may wish to study the source code for this driver to gain a better understanding of handling interrupts in device drivers.

3.5.3 Allocating DVMA Space

Direct Virtual Memory Access is a facility present on SPARC hardware that allows a device to specify virtual addresses rather than physical addresses for a DMA operation.

The kernel maintains a map that specifies the correspondence between the DVMA address and the physical memory. It is the responsibility of the device driver to set up the memory region for DVMA access.

Setting up a DVMA region is a two-step process: allocating memory and allocating DMA resources for this memory region. The following code segment is an example of setting up a DVMA region of size 'len' bytes.

While allocating memory and setting it up for DVMA, the driver can describe the capabilities of the DMA engine to the kernel by using a `ddi_dma_lim_t` structure. On USPIII systems, the capabilities are as follows:

```
.
static ddi_dma_lim_t limits =
{
    0x0,
    0xffffffff,
    0xffffffff,
    07f,
    0x1,
    0
};
.
.
caddr_t kmem_base;
int req_id, real_len, req_len;
ddi_dma_handle_t handle;
ddi_dma_cookie_t cookie;
dma_req_t *reqp;
.
.
req_len = len;
real_len = 0;

/* allocate memory */
if (ddi_mem_alloc (xsp->dip, &limits,
                  (size_t)req_len, 0, &kmem_base,
                  (uint *) &real_len) != DDI_SUCCESS)
{
    cmn_err (CE_NOTE, "ddi_mem_alloc failed.");
    return (ENOMEM);
}
```

```
/* set it up for DMA access */
    if (ddi_dma_addr_setup (xsp->dip, (struct as *) NULL,
        kmem_base, real_len,
        DDI_DMA_RDWR, DDI_DMA_DONTWAIT, 0, &limits,
        &handle) != DDI_DMA_MAPPED)
    {
        ddi_mem_free (kmem_base);
        cmn_err (CE_NOTE, "ddi_dma_addr_setup failed.");
        return (EFAULT);
    }

/* extract the virtual address of the memory region.
 * this can be obtained from the DMA cookie structure.
 */

    if (ddi_dma_htoc (handle, 0, &cookie) != DDI_SUCCESS
        ||
        ddi_dma_sync (handle, 0, real_len, DDI_DMA_SYNC_FORDEV)
        != DDI_SUCCESS)
    {
        ddi_dma_free (handle);
        ddi_mem_free (kmem_base);
        cmn_err (CE_NOTE, " ddi_dma_sync() failed\n");
        return (EFAULT);
    }

    cmn_err ( CE_NOTE,"Virtual address of memory  is 0x%x",kmem_base);
    cmn_err ( CE_NOTE,"Virtual address of the DVMA region is 0x%x",
        (caddr_t) cookie.dmac_address );
    .
    .
    .
```

The address contained in the 'DMA cookie' is the 'virtual address' of the DVMA memory region and can be used to access the memory region over the VMEbus. e.g., if the 'virtual address' printed by the second `cmn_err` statement is 0x588, you can access this memory region from another system on the VMEbus chassis by using this command:

```
# od -x /dev/vme24d32 0x588
```

3.5.4 Mapping VMEbus Space

On some occasions, it would be convenient to map a chunk of VMEbus address space into the system's memory. From the user level, this can be done by doing an `mmap()` operation on the appropriate `/dev/vmeXXdYY` file. From the driver level, mapping VMEbus address space can be done by using the `ddi_map_regs()` function. As an example, to map two pages of VMEbus space starting at location `0x66000000`, the following code segment can be used:

```
if (ddi_map_regs(dip, 0, &map_space, 0x66000000, (off_t) 8192) !=
    DDI_SUCCESS)
{
    return (EFAULT);
}
```

On return from the function, `map_space` contains the base address of the kernel virtual region. There are many caveats to using `ddi_map_regs()` to map a portion of VMEbus address space.

- An A32:D32 device can only map a chunk from A32:D32 address space.
- The address space indicated by `[offset, offset+len]` must be a valid region on the VMEbus.
- Access to the mapped region should be localized. Subsequent access to locations that are far apart will result in many page faults, particularly on regions of larger sizes.

It is prudent to use the `ddi_peek()` and `ddi_poke()` routines to access a region mapped using `ddi_map_regs()`.

3.5.5 Driving Devices Without Writing Device Drivers

As mentioned before, device drivers protect the rest of the kernel from the specifics of hardware devices. Most hardware devices would necessitate the development of a device driver before they can be used on a computer system. However the features of the VMEbus and the design and implementation of the Themis Computer software interface for VME alleviate the need for specialized device drivers for most simple VME devices. This provides a tremendous advantage to programmers writing applications for these simple devices.

In Solaris device drivers are dynamically loadable. This avoids the need to relink the kernel and reboot the system whenever a driver is modified. However, a fault in the driver could still cause the kernel to panic, resulting in long downtimes for the machine. Further, an abnormal shutdown of the machine, as in the case of kernel panic, could cause the disk to be corrupted and some important files to be lost. These problems can be avoided if the program driving the device executes in user mode instead of kernel mode.

This section discusses some ways by which a user program can do device operations that are traditionally performed by a device driver. The section is intended to clue the programmer on to the possibilities of accessing devices from user level. The reader is encouraged to go through the source code of the sample drivers to gain an insight into how they can be used for user-level access.

In simplistic terms, a device can be viewed as a collection of registers that are addressable. Almost all of these registers can be either read from or written to. Some of them allow both read and write access. Access to many of the registers results in effects like resetting the value of the register, clearing the interrupt etc. Some registers require a particular sequence of accessing them. Some registers have specific data widths that can be used to access them. Though there are some devices that have some very peculiar behavior, most devices can be modeled as a collection of registers. Such devices, if they are VMEbus devices, can be programmed and used without the need for a specialized device driver.

As mentioned before, VMEbus addresses are not distinguishable from memory addresses. The `vmemem` driver from Themis Computer, which is the device driver for the `/dev/vmeXXdYY` files, enables a user program to access any address in the VMEbus space.

This feature can be used to access the registers of a device from a user program. The user program needs to open the appropriate `/dev/vmeXXdYY` file, `lseek` to the address of the device registers and do a read or write operation. The `vmemem` driver performs the read/write operation 'carefully' by using the `ddi_peek()` and `ddi_poke()` calls. If the user program opens the appropriate file and the read/write access meets the alignment criteria of the device, the device registers can be easily programmed from the user program.

For example, to access a device that supports 32 address bits and has 32-bit data, with the registers starting at offset `0x7e000000`, the user program needs to open `/dev/vme32d32` and `lseek` to offset `0x7e000000`. Please note that the registers of this device could be 8-bit wide, 16-bit wide or 32-bit wide. If the read/write call is issued with the appropriate length, the `vmemem` driver will issue the appropriate `ddi_peek` or `ddi_poke` call.

Note that the `mmap()` interface of the `vmemem` driver does not use the `ddi_peek/ddi_poke` calls. In such cases, access to all nonexistent address space will panic (crash) the Solaris kernel.

Devices that issue interrupts pose more of a problem when accessed from the user level. In some cases the devices can be programmed to not raise interrupts. Input/output in such cases may be done by making the user program 'busy-wait'. In other cases, the `vmeintr` driver can be used to receive the interrupt and signal a user program when the interrupt is raised. The user program can then look at the device registers and take appropriate actions.

3.5.6 Environmental Monitoring Programs

The following Solaris application programs have been written specifically for the USPIIIi system:

usp3i_temp

The `usp3i_temp` application (see *Table 3-8*) interfaces with the ADM1031 temperature monitors that are installed on the System, CPU0, and CPU1 boards.

Table 3-8. Temperature Monitoring Commands

Command	Description
<code>usp3i_temp</code>	Dumps the temperature and threshold settings
<code>usp3i_temp -c</code>	This is an interactive method for changing temperature thresholds. This change will remain in effect until the next power cycle. To make permanent threshold changes, use the OBP environment variable (see Section 5.2.1, "Setting Temperature Thresholds," on page 5-4).
<code>usp3i_temp -m</code>	Causes the system to run in an infinite loop, monitoring abnormal conditions and reporting to the console.

usp3i_voltage

The `usp3i_voltage` application (see *Table 3-9*) interfaces with the PCF8591 device that is used for DC/DC voltage monitoring on both CPU0 and CPU1.

Table 3-9. Voltage Monitoring Command

Command	Description
usp3i_voltage	Dumps all voltages (backplane, memory, Jbus, and CPU core).

usp3i_uled

The `usp3i_uled` application (see *Table 3-10*) interfaces with the PCF8574 device on the CPU0 board that controls the four User Status LEDs.

Table 3-10. User Status LED Commands

Command	Description
usp3i_uled -e led#	Turns ON the specified User LED (# = 1 through 4).
usp3i_uled -d led#	Turns OFF the specified User LED (# = 1 through 4).

usp3i_pld and plxdrv

The `usp3i_pld` program is an application to get and set bytes in the PLD registers. `plxdrv` is a device driver for the PLX PCI9030 bridge chip that maps the memory space for the Cypress PLD (CPLD) residing on the ebus (see *Table 3-11*).

To add the `plxdrv` driver to the system, use the following command:

```
cp plxdrv /usr/kernel/drv/sparcv9/plxdrv
add_drv -i 'pci10b5,9030' plxdrv
```

Table 3-11. PLD Commands

Command	Description
usp3i_pld	Dumps all the PLD registers.
usp3i_pld -g <offset>	Gets the byte at the specified register <i>offset</i> .
usp3i_pld -p <offset> <value>	Puts the new <i>value</i> at the specified register <i>offset</i> .

Programmable Logic Device

The USPIIIi Programmable Logic Device (PLD) is accessible through the EBus and has many registers that are used to control a variety of different functions. These registers are described in the final section of this chapter. Access and control of PLD registers require a knowledge of PLD functions, described in the following section.

4.1 PLD Function Upgrade

Certain PLD functions have been added to OBP 3.2 to facilitate the operation and analysis of the USPIIIi system. These include:

<code>themis-show-pld</code>	<i>Displays a list of all functions</i>
<code>pld-revision-status</code>	<i>See PLD register 0x00</i>
<code>user-and-boot-device-jumpers</code>	<i>See PLD register 0x02</i>
<code>jumper-status vme-slot</code>	<i>See PLD register 0x03</i>
<code>vme-reset-mode</code>	<i>See PLD register 0x04</i>
<code>temperature-sensor-status</code>	<i>See PLD register 0x05</i>
<code>miscellaneous-status</code>	<i>See PLD register 0x06</i>
<code>scsi-termination-status</code>	<i>See PLD register 0x07</i>
<code>tty-kbm-ac97-status</code>	<i>See PLD register 0x08</i>
<code>scsi-termination-control</code>	<i>See PLD register 0x09</i>
<code>scsi-termppwr-status</code>	<i>See PLD register 0x0a</i>
<code>RMW-semaphore-and-test</code>	<i>See PLD register 0xf0</i>
<code>dump-pld</code>	<i>Performs a PLD register dump</i>

In addition, the following functions are available to read and write PLD registers directly as a character (c) or byte, word (w), or long word (l):

```
pldc@ \ ( offset -- data ) .....Read the byte content of the PLD register at offset
pldw@ \ ( offset -- data ) .....Read the 16-bit word of the PLD register at offset
pldl@ \ ( offset -- data ) .....Read the 32-bit word of the PLD register at offset
pldc! \ ( data offset -- ) .....Write the byte data into the PLD register at offset
pldw! \ ( data offset -- ) .....Write the 16-bit data into the PLD register at offset
pldl! \ ( data offset -- ) .....Write the 32-bit data into the PLD register at offset
```

4.1.1 Examples

The following examples illustrate how a typical function works:

1. Read PLD register 0x04:

```
ok 4 pldc@ . <Enter>

ok f \ ..... Bit values returned are [ 0 0 0 0 1 1 1 1 ]
```

2. Set bit 4 and bit 5 of PLD register 0x04 to 1:

```
ok 3f 4 pldc! <Enter>
```

3. Verify that bit 4 and bit 5 of PLD register 0x04 have been set to 1:

```
ok 4 pldc@ . <Enter>

ok 3f \ ..... Bit values returned are [ 0 0 1 1 1 1 1 1 ]
```

4.2 PLD Register Set

The following is extracted from the register descriptions written in the VHDL source code of the PLD itself.

```

-----
-- PLD register : offset 0x00
-- Description  : PLD revision and ID
-- Width       : 8-bit
-- Vector name  : pld_reg(0,i)
-----
-- Description
-- bits [3..0] : Revision of this PLD
--             0x0 and 0xf are reserved for engineering
-- bits [7..4] : CPU family ID
-- 0001 ----> Hummingbird
-- 0010 ----> Phantom
-- 0011 ----> Corsair
-- 0100 ----> CPU 3i
-----

-----
-- PLD register : offset 0x02
-- Description  : User jumper and Boot device jumper
-- Width       : 8-bit
-- Vector name  : pld_reg(1,i)
-----
-- Description
-- bit 0 : (RO) - Status of Jumper JP3901
--         0 : JP3901 jumper is OFF
--         1 : JP3901 jumper is installed.
-- bit 1 : (RO) - Status of Jumper JP3902
--         0 : JP3902 jumper is OFF      - Boot device is the external Rombo.
--         1 : JP3902 jumper is installed. - Boot device is the on-board OBP flash.
-- bit 2 : (RO) - Status of Jumper JP3903
--         0 : JP3903 jumper is OFF
--         1 : JP3903 jumper is installed - Boot flash WRITE is enabled.
-- bit 3 : (RO) - Status of Jumper JP3908
--         0 : JP3908 jumper is OFF      - The shutdown condition will force the board under reset
--         1 : JP3908 jumper is installed. - The shutdown condition will not put the board under
--         reset. (Battle mode)
-- bit 4 : (RO) - Status of Solder Bead SB3502 (the M66en signal for PCI1A).
--         0 : The PCI bus PCI1A is running at 33Mhz
--         1 : The PCI bus PCI1A is running at 66Mhz
-- bit 5 : (RO) - Status of Solder Bead SB3503 (the M66en signal for PCI1B).
--         0 : The PCI bus PCI1B is running at 33Mhz
--         1 : The PCI bus PCI1B is running at 66Mhz
-- bit 6 : (RO) - Status of the M66en signal for PCI2A.
--         0 : The PCI bus PCI2A is running at 33Mhz
--         1 : The PCI bus PCI2A is running at 66Mhz
-- bit 7 : (RO) - Status of Solder Bead SB3501 (the M66en signal for PCI2B).
--         0 : The PCI bus PCI2B is running at 33Mhz
--         1 : The PCI bus PCI2B is running at 66Mhz
-----

```

```

-----
-- PLD register : offset 0x03
-- Description : VME slot geographical ID
-- Width      : 8-bit
-- Vector name : pld_reg(2,i)
-----
-- Description
-- bit 0 : (RO) - Status of VME P1 signal GA0 (pin P1.D10)
--           0 : GA0 pull-up
--           1 : GA0 tied to GND (by the VME64X backplane).
-- bit 1 : (RO) - Status of VME P1 signal GA1 (pin P1.D11)
--           0 : GA1 pull-up
--           1 : GA1 tied to GND (by the VME64X backplane).
-- bit 2 : (RO) - Status of VME P1 signal GA2 (pin P1.D13)
--           0 : GA2 pull-up
--           1 : GA2 tied to GND (by the VME64X backplane).
-- bit 3 : (RO) - Status of VME P1 signal GA3 (pin P1.D15)
--           0 : GA3 pull-up
--           1 : GA3 tied to GND (by the VME64X backplane).
-- bit 4 : (RO) - Status of VME P1 signal GA4 (pin P1.D17)
--           0 : GA4 pull-up
--           1 : GA4 tied to GND (by the VME64X backplane).
-- bit 5 : (RO) - Status of VME P1 signal GAP (pin P1.D9)
--           0 : GAP pull-up
--           1 : GAP tied to GND (by the VME64X backplane).
-- bit 6 : (RO) - Read as '0'.
-- bit 7 : (RO) - Read as '0'.
--
-- Encoding table for the GAx register bits.
--   GAP  GA4  GA3  GA2  GA1  GA0      slot ID
--   0  0  0  0  0  1  0x01 -> 1
--   0  0  0  0  1  0  0x02 -> 2
--   1  0  0  0  1  1  0x23 -> 3
--   0  0  0  1  0  0  0x04 -> 4
--   1  0  0  1  0  1  0x25 -> 5
--   1  0  0  1  1  0  0x26 -> 6
--   0  0  0  1  1  1  0x07 -> 7
--   0  0  1  0  0  0  0x08 -> 8
--   1  0  1  0  0  1  0x29 -> 9
--   1  0  1  0  1  0  0x2a -> 10
--   0  0  1  0  1  1  0x0b -> 11
--   1  0  1  1  0  0  0x2c -> 12
--   0  0  1  1  0  1  0x0d -> 13
--   0  0  1  1  1  0  0x0e -> 14
--   1  0  1  1  1  1  0x2f -> 15
--   0  1  0  0  0  0  0x10 -> 16
--   1  1  0  0  0  1  0x31 -> 17
--   1  1  0  0  1  0  0x32 -> 18
--   0  1  0  0  1  1  0x13 -> 19
--   1  1  0  1  0  0  0x34 -> 20
--   0  1  0  1  0  1  0x15 -> 21
--   0  0  0  0  0  0  0x00 -> No VME64X compliant
--   other values are illegal (symptom of a problem)
-----

```

```

-----
-- PLD register : offset 0x04
-- Description : VME reset control/status
-- Width      : 8-bit
-- Vector name : pld_reg(3,i)
-----
-- Description
-- bit 0 : (RO) - Status of the Jumper JP2101
--          0 : The jumper is OFF and the board set in auto-sensing mode.
--          1 : The jumper is ON and the board set as system controller.
-- bit 1 : (RO) - Status of the Jumper JP2201
--          0 : The jumper is OFF and the board CANNOT transmit a reset on the VME.
--          1 : The jumper is ON and the board CAN assert a reset on the VME.
-- bit 2 : (RO) - Status of the Jumper JP2301
--          0 : The jumper is OFF and the board CANNOT receive a reset from the VME.
--          1 : The jumper is ON and the board COULD be reset by the VME.
--          (see also programmable bit pld_reg(3,4) below.)
-- bit 3 : (RO) - Status of the Universe controller
--          0 : The Universe is NOT the VME system controller.
--          1 : The Universe is currently the VME system controller.
-- bit 4 : (RW) - Programmable incoming VME reset enable bit.
--          0 : A reset on the VME bus cannot reset the board.
--          1 : A reset on the VME bus COULD reset the board, assuming
--              bit pld(3,2) is also set to 1.
--          Upon power-up of the VME backplane, this bit is cleared.
--          and remains unchanged upon Front panel reset assertion.
-- bit 5 : (RW) - Programmable enable bit for the Universe local LRST signal.
--          0 : Will prevent the Universe from propagating a reset to the IIIi board thru the Lrst (pin
--              R1) signal.
--          1 : Will allow the Universe to propagate a reset into the IIIi board thru the Lrst (pin R1)
--              signal.
--          Upon power-up of the VME backplane, this bit is cleared.
--          and remains unchanged upon Front panel reset assertion.
-- bit 6 : (RW) - reserved for future use
--          Upon power-up of the VME backplane, this bit is cleared.
-- bit 7 : (RW) -
--          1 : When over-temp occurs in non-battle mode, hold board in reset until power is recycled.
--          0 : When over-temp occurs in non-battle mode, hold board in reset until temperature
--              drops 5 degrees below shutdown level.
-----

```

```

-----
-- PLD register : offset 0x05
-- Description : Temperature sensor status register
-- Width      : 8-bit
-- Vector name : pld_reg(4,i)
-----
-- Description
-- bit 0 : (RO) - Status of the CPU0 board over-temperature sensor.
--          0 : No over-temperature condition detected.
--          1 : Over-temperature condition detected.
-- bit 1 : (RO) - Status of the CPU1 board over-temperature sensor.

```

```

--          0 : No over-temperature condition detected.
--          1 : Over-temperature condition detected.
-- bit 2 : (RO) - Status of the system board over-temperature sensor.
--          0 : No over-temperature condition detected.
--          1 : Over-temperature condition detected.
-- bit 3 : (RO) - Over-temperature (CPU-0, CPU-1, or System board) is detected and latched.
--          0 : No.
--          1 : Yes.
-- bit 4 : (RO) - Status of the CPU0 board warning temperature indicator.
--          0 : Temperature below the warning threshold.
--          1 : Temperature ABOVE the warning threshold.
-- bit 5 : (RO) - Status of the CPU1 board warning temperature sensor.
--          0 : Temperature below the warning threshold.
--          1 : Temperature ABOVE the warning threshold.
-- bit 6 : (RO) - Status of the system board warning temperature sensor.
--          0 : Temperature below the warning threshold.
--          1 : Temperature ABOVE the warning threshold.
-- bit 7 : (RO) - Read as '0';
-----

-----
-- PLD register : offset 0x06
-- Description   : miscellaneous & patch control/status register
-- Width        : 8-bit
-- Vector name   : pld_reg(5,i)
-----
-- Description
-- bit 0 : (RO) - 0 means the PLD clock divider is set to normal mode (CLK10HZ clock = 10 Hz)
--           and solder bead SB3901 is not installed.
--           1 means the PLD clock divider is set to test mode (CLK10HZ clock = 1 MHz)
--           and solder bead SB3901 is installed.
-- bit 1 : (RW) - This bit controls the Enable LED
--           0 : turn-off the Enable LED.
--           1 : turn-on the Enable LED.
--           Upon board reset, the LED is turned-off.
-- bit 2 : (RO) - User flash status bit
--           0 : The User flash is busy executing a programming command in progress.
--           1 : The User flash is ready to accept a new command.
-- bit 3 : (RO) - Status of the MXAbus multiplexer control signal.
--           0 : The MXA bus is used to drive the JTAG bus and is isolate from the XAbus.
--               (Solder bead SB4000 connected to 2-3).
--           1 : The MXA bus is connected to the XA bus. (Solder bead SB4000 set to 1-2)
-- bit [6..4] : (RO) - Status of the Jumpers JP3906, JP3905, JP3904
--           0 : The jumper is installed.
--           1 : The jumper is removed.
--           Those jumpers are used to set a "patch" number.
--           The generic IIIi will have those three jumpers installed.
-- bit 7 : (RO) - Status of the jumper JP3907. (signal xjp3907_1)
--           0 : The jumper is installed (ON).
--           1 : The jumper is removed (OFF).
-----

```



```

-----
-- PLD register : offset 0x07
-- Description : SCSI termination status register
-- Width      : 8-bit
-- Vector name : pld_reg(6,i)
-----
-- Description
-- bit 0 : (RO) - 0 : NO SCSI peripheral has been plugged on the Front panel SCSI A connector.
--           1 : A SCSI device has been plugged into the front panel SCSI A connector.
-- bit 1 : (RO) - 0 : NO SCSI peripheral has been plugged on SCSI A thru the VME P2 interface.
--           1 : A SCSI device has been plugged on the SCSI-A bus thru the VME P2 interface.
-- bit 2 : (RO) - 0 : The lower section of the SCSI-A front panel termination is disabled.
--           1 : The lower section of the SCSI-A front panel termination is enabled.
--           Lower section : SCSI control lines and SCSI data lines [0..7].
-- bit 3 : (RO) - 0 : The upper section of the SCSI-A front panel termination is disabled.
--           1 : The upper section of the SCSI-A front panel termination is enabled.
--           Upper section : SCSI data lines [8..15].
-- bit 4 : (RO) - 0 : The lower section of the SCSI-A P2 termination is disabled.
--           1 : The lower section of the SCSI-A P2 termination is enabled.
-- bit 5 : (RO) - 0 : The upper section of the SCSI-A P2 termination is disabled.
--           1 : The upper section of the SCSI-A P2 termination is enabled.
-- bit 6 : (RO) - Status of the solder bead SB1604 used to indicate what kind of termination
--           devices are used on the system board.
--           0 means UNITRODE UCC5673.
--           1 means Dallas DS2119.
-- bit 7 : (RO) - Status of the solder bead SBX1701 used to indicate what kind of termination
--           devices are used on the SCSI adaptor board.
--           0 means UNITRODE UCC5673.
--           1 means Dallas DS2119.
-----

```

```

-----
-- PLD register : offset 0x08
-- Description : KBM, USB, TTY-A, TTY-B physical port setting
-- Width      : 8-bit
-- Vector name : pld_reg(7,i)
-----
-- Description
-- bit [1..0] : (RO) - These bits provide info on the setting of the PS/2 and USB
--           Case of DIN8 connector
--           0 1 : PS/2 on Front - No USB
--           1 1 : PS/2 on P2  - No USB
--           1 0 : PS/2 on P2  - USB on the front
--           0 0 : No PS/2    - USB on the front
--           Case of USB connector
--           0 1 : No PS/2    - USB on the front
--           1 1 : PS/2 on P2  - USB on the front
--           1 0 : PS/2 on P2  - USB on the front
--           0 0 : No PS/2    - USB on the front
-- bit 0 : (RO) - is the status of the solder bead SB12201.
--           When the solder-bead is set to 2-3, this bit is set to '0'
--           When the solder-bead is set to 1-2, this bit is set to '1'
-- bit 1 : (RO) - is the status of the solder bead SB2505.

```

```

--          When the solder-bead is set to 2-3, this bit is set to '1'
--          When the solder-bead is set to 1-2, this bit is set to '0'
-- bit 2 : (RO) - Read as '0'
-- bit 3 : (RO) - 0 : The USB power IC (U12202 - TPS2402) does not report a power failure.
--              1 : The USP power IC (U12202 - TPS2402) reports a power failure.
-- bit 4 : (RO) - Status of JP4401 which controls the TTY B front panel transceiver mode.
--              0 : The TTY B interface transceiver on the front is set to RS422.
--                  The jumper JP4401 is ON.
--              1 : The TTY B interface transceiver on the front is set to RS232.
--                  The jumper JP4401 is OFF.
-- bit 5 : (RO) - Status of the jumper JP4403 which controls the TTY B port front panel versus P2
--              0 : The TTY B port is accessible on the front panel
--                  The jumper JP4403 is OFF.
--              1 : The TTY B port is accessible on VME P2 connector.
--                  The jumper JP4403 is ON.
-- bit 6 : (RO) - Status of the jumper JP4402 which controls the TTY A port front panel versus P2
--              0 : The TTY A port is accessible on the front panel
--                  The jumper JP4402 is OFF.
--              1 : The TTY A port is accessible on VME P2 connector.
--                  The jumper JP4402 is ON.
-- bit 7 : (RO) - Status of the jumper JP2502 which controls the AC97 port on PMC carrier or on P2
--              0 : The AC97 Audio port is accessible on the PMC carrier
--                  The jumper JP2502 is OFF.
--              1 : The AC97 Audio port is accessible on VME P2 connector.
--                  The jumper JP2502 is ON.
-----

```

```

-----
-- PLD register : offset 0x09
-- Description  : SCSI_A termination control register
-- Width       : 8-bit
-- Vector name  : pld_reg(8,i)
-----
-- Description
-- bit [1..0] : (RW) - These bits control the SCSI-A lower section of the Front panel termination
--              (SCSI-A control signals and SCSI-A data lines [0..7])
--              0 0 => The termination are forced in the "disabled" state.
--              0 1 => The termination are forced in the "enabled" state.
--              1 X => The termination setting depends on the state of the corresponding
--                  sense pins.
--                  Upon reset, those bits are set to '1'.
-- bit [3..2] : (RW) - These bits control the SCSI-A upper section of the Front panel termination
--              (SCSI-A data lines [8..15])
--              0 0 => The termination are forced in the "disabled" state.
--              0 1 => The termination are forced in the "enabled" state.
--              1 X => The termination setting depends on the state of the corresponding
--                  sense pins.
--                  Upon reset, those bits are set to '1'.
-- bit [5..4] : (RW) - These bits control the SCSI-A lower section of the P2 termination
--              (SCSI-A control signals and SCSI-A data lines [0..7])
--              0 0 => The termination are forced in the "disabled" state.
--              0 1 => The termination are forced in the "enabled" state.
--              1 X => The termination setting depends on the state of the corresponding
--                  sense pins.

```

```
--          Upon reset, those bits are set to '1'.
-- bit [7..6] : (RW) - These bits control the SCSI-A upper section of the P2 termination
--                (SCSI-A data lines [8..15])
--          0 0 => The termination are forced in the "disabled" state.
--          0 1 => The termination are forced in the "enabled" state.
--          1 X => The termination setting depends on the state of the corresponding
--                sense pins.
--          Upon reset, those bits are set to '1'.
-----
```

```
-----
-- PLD register : offset 0x0a
-- Description  : SCSI-A/B termination power control
-- Width       : 8-bit
-- Vector name  : pld_reg(9,i)
-----
-- Description
-- bit 0 : (RW) - Upon reset, this bit is cleared.
-- bit 1 : (RW) - Upon reset, this bit is cleared.
-- bit 2 : (RW) - Upon reset, this bit is cleared.
-- bit 3 : (RW) - Control the termination power on SCSI-A.
--          0 : The termination power on SCSI-A is enabled.
--          1 : The termination power on SCSI-A is shutdown.
-- bit 4 : (RW) - Control the termination power on SCSI-B.
--          0 : The termination power on SCSI-B is enabled.
--          1 : The termination power on SCSI-B is shutdown.
-- bit 5 : (RO) - Status of the sense pin on the SCSI-B interface.
--          0 : NO scsi device plugged onto SCSI-B interface
--          1 : a SCSI device is plugged onto SCSI-B interface
-- bit 6 : (RO) - Read as '0'
-- bit 7 : (RO) - Read as '0'
-----
```

```
-----
-- PLD register : offset 0xF0 to 0xFF
-- Description  : Atomic RWM semaphore and Test
-- Width       : 8-bit
-- Vector name  : semaphore_reg(i)
-----
-- Description
-- This register is dedicated for the implementation of a Test And Set
-- function. It has a very peculiar behavior which is described in full details
-- hereafter :
-- The semaphore register can be accessed in two ways.
-- One way is for testing purpose. The other is the normal operating mode.
-- For test,          the address 0b11110xx1 is used.
-- For operating mode, the address 0b11110xx0 is used.
-- The semaphore is dedicated for the management of shared resources among
-- multiple CPU owners. Only one CPU can own the shared resources at any
-- given time. Bit 0 of the semaphore is used as the busy (or owned) bit.
-- When this bit is set to 1, it means the semaphore is used by somebody
-- and any other pretender to access to the shared resources must wait for
```

```
-- this owned/busy bit to be cleared by the owner. In order to identify
-- who is the owner (to troubleshoot an ownership conflict problem), it is
-- suggested to use the two "don't care" address bits [2:1] as the Owner ID.
-- This means that the S/W responsible to manage the semaphore resource
-- will assign a different address (one out of four) for each of the owners
-- (maximum of 4).
--
-- Behavior in operating mode:
--
-- Upon reset, the semaphore content is cleared. This means no one owns the
-- semaphore.
-- When a CPU wants to get ownership of a shared resource, it will first get
-- ownership of the semaphore. It will do so by polling the semaphore and
-- checking the ownership bit. If the ownership bit is read as 0, that means
-- that the semaphore was free and, thanks to the H/W mechanism implemented
-- in this logic, the CPU is now becoming the owner of the semaphore. When
-- the read occurs, the logic checks if the owned/busy bit is set. If it is
-- set, the address bits [2:1] which, by convention identifies the owner,
-- is stored into the semaphore bits[2..1]. If it is not set, the owner ID bits
-- of the semaphore are left unchanged.
-- Upon read, the semaphore owned/busy bit is always set to 1 (meaning owned/busy
-- is asserted.) only after the previous content has been provided to the polling CPU.
-- The setting of the owned/busy bit occurs "atomically" on the trailing edge of the
-- read access.
-- When the CPU wants to release the ownership of the semaphore, it simply writes to
-- the semaphore with bit D0 set to 0. The write access automatically clears the owner ID
-- to 0.
--
-- Behavior in test mode:
--
-- The register behaves like any standard REad/WriTe register. Only bits[2..0] are writable.
--
--                               In test mode
--
-- bit [2..0] : (RW) - Upon reset, these bits are cleared.
-- bit [7..3] : (RO) - Read as '0'.
--
--                               In operating mode
--
-- bit 0 : (Read to Write 1) - Upon reset, this bit (called Busy bit) is cleared.
--                               A read access automatically sets this bit to 1 AFTER the read
--                               has been completed and BEFORE anyone accesses to it.
--                               A write access will set the bit according to the value on D0.
--
-- bit [2..1] : (exotic RW) - Upon reset, these bits (called Owner ID) are cleared.
--                               On read access, address bits [2..1] will be stored in this
--                               register bits if the Busy bit is clear at the beginning of the
--                               read access. If the Busy bit is set at the beginning of the
--                               read access, these bits return the ID of the current owner of
--                               the semaphore.
--                               On write access, those bits are automatically cleared.
-- bit [7..3] : (RO) - Read as '0'.
-----
```

4.3 Output from themis-show-pld

The following is a typical output response to the themis-show-pld command:

```
{1} ok themis-show-pld

      UspIIIIi - revision / ID register    0x7ee.0100.0c00

Revision level : 0xf
Board ID : UspIIIIi

      User jumper and boot device jumper status 0x7ee.0100.0c02

JP3901 INSTALLED
JP3902 INSTALLED, USPIIIi will boot from the on-board system flash
JP3903 INSTALLED, Enable system flash write
JP3908 NOT INSTALLED, USPIIIi will go into reset mode under over-
temperature condition
PCI1A running at 33Mhz
PCI1B running at 66Mhz
PCI2A running at 33Mhz
PCI2B running at 33Mhz

      UspIIIIi - VME64X slot ID register    0x7ee.0100.0c03

No VME64X backplane

      VME reset mode control register      0x7ee.0100.0c04

JP2101 NOT INSTALLED, VME SYSCON set using autosensing
JP2201 INSTALLED, Board CAN assert an outgoing VMEbus sysreset
JP2301 INSTALLED, Board CAN receive an incoming VMEbus sysreset
Board is THE VME SYSTEM CONTROLLER
The IIIi is isolated from any incoming VME SYSRST
UNIVERSE local reset effect has no effect

      Temperature sensor status register 0x7ee.0100.0c05

CPU0 board temperature no OVER-temperature condition
CPU1 board temperature no OVER-temperature condition
```

system board temperature no OVER-temperature condition
CPU0 board temperature is below the warning threshold
CPU1 board temperature is below the warning threshold
system board temperature is below the warning threshold

Miscellaneous status register 0x7ee.0100.0c06

SB3901 NOT INSTALLED, PLD clock output (CLK10HZ) set to normal :
10HZ

System LED turned-off

User Flash busy executing a programming command

JP4001 INSTALLED, (1-2set) Rombo interface is used to access to
the external boot PROM

JP3904 NOT INSTALLED

JP3905 NOT INSTALLED

JP3906 NOT INSTALLED

JP3907 NOT INSTALLED

SCSI-A termination status register 0x7ee.0100.0c07

No SCSI device plugged on front panel SCSI-A interface

No SCSI device plugged on P2 SCSI-A interface

SCSI-A front panel termination / lower section enabled

SCSI-A front panel termination / upper section enabled

SCSI-A P2 termination / lower section enabled

SCSI-A P2 termination / upper section enabled

SB1604 NOT INSTALLED, System board SCSI termination set to Dallas
DS2119

SBX1701 NOT INSTALLED, SCSI adaptor termination set to Dallas
DS2119

KBM/USB/TTY-A&B setting register 0x7ee.0100.0c07

Solderbead SB12201 set to 1-2

Solderbead SB2505 set to 1-2

USB power rail OK

JP4401 NOT INSTALLED, TTY-B Front panel interface set to RS232

JP4403 NOT INSTALLED, TTY-B interface accessible on the front
panel

JP4402 NOT INSTALLED, TTY-A interface accessible on the front
panel

JP2502 INSTALLED, AC97-Audio interface accessible on P2

SCSI-A termination control register 0x7ee.0100.0c09

SCSI-A front panel termination (lower section) is controlled by the sense pins

SCSI-A front panel termination (upper section) is controlled by the sense pins

SCSI-A P2 termination (lower section) is controlled by the sense pins

SCSI-A P2 termination (upper section) is controlled by the sense pins

SCSI-A/B termination power control register 0x7ee.0100.0c0a

SCSI-A termination power is enabled

SCSI-B termination power is enabled

No device plugged on the SCSI-B interface

Device Monitoring

5.1 Introduction

The USPIIIi design contains two categories of monitoring devices:

- Thermal measurement
- DC/DC converter voltage measurement

5.2 Thermal Monitoring

USPIIIi thermal sensors are all based on the I²C ADM1031 device from Analog Devices. There are a total of three thermal sensors, one on each major board of the USPIIIi; namely, the System board, the CPU-0 board, and the CPU-1 board.

Each ADM1031 sensor is able to report three temperatures: the first temperature is that of the ADM1031 device itself, the second and third temperatures are those of the two remote diodes used as sensors.

On both the CPU-0 and CPU-1 boards, one of the diodes is on the CPU die; therefore its temperature can be considered the CPU junction temperature. The second diode is a discrete component placed on the board in a location that is given in *Figure 5-1* on page 5-2.

On the System board, the two remote diodes are discrete components, one placed at the inlet, the other at the exhaust. Their locations are provided in detail in *Figure 5-1*.




Figure 5-1. Placement of USPIII Device Monitors

The temperature sensor controller ADM1031 provides two outputs. One (THERM) is asserted to report that the temperature has risen above the warning threshold (called Therm-limit in the ADM1031 datasheet), and is deasserted when the temperature reaches a full 5°C below the Therm-limit threshold.

The other (INT or SMBALERT) is asserted when the temperature is out of the programmable temperature low and high thresholds.

The behavior of these two signals is illustrated (in a simplistic way) in *Figure 5-2*.




Figure 5-2. Outputs of the Temperature Sensor Controller

The default behavior of the OBP is to initialize the temperature sensors in *non-interrupt* mode. However, interrupt mode is enabled if a temperature-related error condition occurs during the OBP boot process. If this occurs, the appropriate CPU1/CPU0 OVER TEMP or SYS OVER TEMP front panel LED lights up, indicating an error condition.

To detect over/under temperature conditions under Solaris, run the utility `usp3i_temp` in monitor mode (-m). Upon detection of a temperature-error condition, the sensor interrupt bit is turned on and the appropriate front-panel LED lights up (as defined in the previous paragraph).

5.2.1 Setting Temperature Thresholds

The following environment variables are used to set the temperature thresholds for the three sensors:

system-low-limit	0	0
system-therm-limit	80	80
system-high-limit	70	70
cpu1-low-limit	5	5
cpu1-therm-limit	115	115
cpu1-high-limit	105	105
cpu0-low-limit	5	5
cpu0-therm-limit	115	115
cpu0-high-limit	105	105

To change the temperature threshold, type:

```
{1} ok setenv system-therm-limit 85
```

To see the current temperature reading on the different sensors, type:

```
{1} ok .env
```

```

      System Board
Inlet           :    +33 C
Outlet          :    +39 C
Local           :    +33 C

      CPU 0
Die             :    +64 C
Board Sensor    :    +50 C
Local           :    +39 C
Voltage on Ain0 (Backplane +5V ) input : 4980 mV
Voltage on Ain1 (Memory   +2.6V ) input : 2578 mV
Voltage on Ain2 (Jbus     +1.5V ) input : 1503 mV
Voltage on Ain3 (CPU core  +Vcore) input : 1347 mV

      CPU 1
Die             :    +64 C
Board Sensor    :    +47 C
Local           :    +33 C
Voltage on Ain0 (Backplane +5V ) input : 4980 mV
Voltage on Ain1 (Memory   +2.5V ) input : 2578 mV
Voltage on Ain2 (Jbus     +1.5V ) input : 1484 mV
Voltage on Ain3 (CPU core  +Vcore) input : 1386 mV

```

To see a more detailed listing of the sensor temperatures and their threshold settings:

```
{1} ok themis-show-temp
System Board Temperature
-----
      I2C address :      58
      Device      : ADM1031 (Analog devices)

ADM1031 device ID (0x31)      : 31
Company ID (0x41)            : 41
Revision                     : 3
Remote 1 temperature parameters :
      Temperature High limit : +100
      Temperature Low limit  : +0
      Temperature THERM limit : +110
      Temperature -----> Remote 1 : +32
Remote 2 temperature parameters :
      Temperature High limit : +100
      Temperature Low limit  : +0
      Temperature THERM limit : +110
      Temperature -----> Remote 2 : +36
Local temperature parameters :
      Temperature High limit : +70
      Temperature Low limit  : +0
      Temperature THERM limit : +80
      Temperature -----> local : +31
CPU0 Temperature
-----
      I2C address :      5c
      Device      : ADM1031 (Analog devices)

ADM1031 device ID (0x31)      : 31
Company ID (0x41)            : 41
Revision                     : 3
Remote 1 temperature parameters :
      Temperature High limit : +105
      Temperature Low limit  : +5
      Temperature THERM limit : +115
      Temperature -----> Remote 1 : +60
Remote 2 temperature parameters :
      Temperature High limit : +105
      Temperature Low limit  : +5
      Temperature THERM limit : +115
```

```

                Temperature  ---->      Remote 2 :    +45
Local temperature parameters :
    Temperature High  limit :    +70
    Temperature Low   limit :    +0
    Temperature THERM limit :    +80
                Temperature  ---->      local :    +35
CPU1 Temperature
-----
    I2C address :      5e
    Device      : ADM1031 (Analog devices)

ADM1031 device ID (0x31)      : 31
Company ID (0x41)            : 41
Revision                     : 3
Remote 1 temperature parameters :
    Temperature High  limit :    +105
    Temperature Low   limit :    +5
    Temperature THERM limit :    +115
                Temperature  ---->      Remote 1 :    +59
Remote 2 temperature parameters :
    Temperature High  limit :    +105
    Temperature Low   limit :    +5
    Temperature THERM limit :    +115
                Temperature  ---->      Remote 2 :    +41
Local temperature parameters :
    Temperature High  limit :    +70
    Temperature Low   limit :    +0
    Temperature THERM limit :    +80
                Temperature  ---->      local :    +30

```

Under Solaris, you can dump the temperature of the different sensors using the following command:

```

# ./usp3i_temp
Sys local  temperature is  38
    Therm limit:   80
    High limit :   70
    Low limit  :    0
Sys inlet  temperature is  30
    Therm limit:   80
    High limit :   70
    Low limit  :    0

```

```

Sys outlet  temperature is    41
    Therm limit:    80
    High limit  :    70
    Low limit   :    0
CPU-0 local temperature is    48
    Therm limit:    80
    High limit  :    70
    Low limit   :    0
CPU-0 die   temperature is    85
    Therm limit:   115
    High limit  :   105
    Low limit   :    5
CPU-0 board temperature is    60
    Therm limit:   115
    High limit  :   105
    Low limit   :    5
CPU-1 local temperature is    34
    Therm limit:    80
    High limit  :    70
    Low limit   :    0
CPU-1 die   temperature is    77
    Therm limit:   115
    High limit  :   105
    Low limit   :    5
CPU-1 board temperature is    49
    Therm limit:   115
    High limit  :   105
    Low limit   :    5
#

```

You can also change the thresholds by typing `"/usp3i_temp -c"`:

```

# ./usp3i_temp -c
Sys local  temperature is    38
    Therm limit:    80
                                new value:

```

Type the new value or simply hit enter to continue without changing.

To run the utility in monitor mode, type:

```

# ./usp3i_temp -m

```

5.3 Voltage Monitoring

The USPIIIi CPU-0/CPU-1 boards have many built-in DC/DC converters. The voltage output must be set to very specific values in order to get maximum performance. As a result, it is vital to implement a capability to monitor these critical voltages.

Design of the USPIIIi contains an I²C A/D converter on each CPU board that allows us to read the current voltage of the many critical DC/DC converters outputs. The voltages monitored are listed in *Table 5-1*.

Table 5-1. Voltages Monitored on the CPU-0 and CPU-1 Boards

CPU-0	CPU-1
VCC (+5V) backplane	VCC (+5V) backplane
2.5V DDR memory0 voltage	2.5V DDR memory1 voltage
1.5V Jbus termination voltage	1.5V Jbus termination voltage
VCCP0 CPU core voltage	VCCP1 CPU core voltage

To see the current Voltage levels, type the OBP command:

```
{1} ok themis-show-voltage
CPU0 Voltage
-----
Voltage on Ain0 (Backplane +5V ) input : 4980 mV
Voltage on Ain1 (Memory +2.5V ) input : 2578 mV
Voltage on Ain2 (Jbus +1.5V ) input : 1503 mV
Voltage on Ain3 (CPU core +Vcore) input : 1367 mV
CPU1 Voltage
-----
Voltage on Ain0 (Backplane +5V ) input : 4980 mV
Voltage on Ain1 (Memory +2.5V ) input : 2578 mV
Voltage on Ain2 (Jbus +1.5V ) input : 1484 mV
Voltage on Ain3 (CPU core +Vcore) input : 1386 mV
{1} ok
```

Index

A

- A/D converter 5-8
- address map
 - Ebus device 1-10
 - I2C devices 1-6
 - Jbus 1-2, 1-3
- address space 3-33
 - mapping to PCI, Jbus 1-4
- ADM1031
 - datasheet 5-3
 - device 5-1
 - sensor 5-3
- allocating DVMA space 3-37
- AMD device AM29LV065D 1-1
- analog voltage I2C converter 1-1

B

- bridge expander (IMAX) 1-9
- bridge, Xbus-to-I2C 1-9

C

- commands
 - additional OBP 3-9
 - additional OBP VME 2-3
 - OBP 2-1
 - OBP support 3-6
 - PLD 3-42
 - temperature monitoring 3-41
 - themis-show-pld 4-11
 - UNIX *xiv*
 - user status LED 3-42
 - voltage monitoring 3-42
- Comments are Welcome *xvi*
- configuring the USPIIIi software 3-27
- CPU junction temperature 5-1
- CPU-0 *xii*
- CPU-0 board 5-1

- CPU-1 *xii*
- CPU-1 board 5-1
- CY37512 programmable logic device 1-1
- Cypress PLD (CPLD) 1-10, 3-42
 - See also* PLD

D

- DC/DC converter 5-1, 5-8
- device aliases, OBP 3-13
- device drivers 3-39
- device monitors 5-2
- devices, probing 3-34
- dmatest 3-24
- documentation feedback,
 - docfeedback@themis.com *xvi*
- documentation, SUN 1-9
- drivers
 - sample 3-21
 - sample VME leaf 3-24
 - utility 3-21
 - VME device 3-32
- DVMA space, allocating 3-37

E

- Ebus
 - bridge 1-11
 - device address map 1-10
 - peripheral bus 1-10
- EEPROM 1-11
 - addresses and data 1-11
- environment variables
 - OBP VME 2-1, 3-2, 3-6
- environmental monitoring programs 3-41
 - usp3i_pld 3-42
 - usp3i_temp 3-41
 - usp3i_uled 3-42
 - usp3i_voltage 3-41

F

fiber-channel controller ISP2312 *1-1*
firmware *1-1*
Flash PROM, updating *3-6, 3-8*
 from a SCSI disk *3-8*

H

hex *3-6*
hierarchy, Solaris 2.x device *3-25*

I

I2C
 ADM1031 device *5-1*
 bus topology *1-2, 1-5*
 devices address map *1-6*
 I2C to I2C bridge expander (IMAX) *1-9*
 thermal sensor ADM1031 *1-1*
ID assignment, Jbus *1-3*
IDsel assignments *1-2*
In Case Of Difficulties *xiv*
installing THEMIS3ivme *3-17*
INT *5-3*
Intended Audience *xiv*
interrupt mapping *1-2, 3-17*
interrupts *3-35*

J

Jbus
 address map *1-2, 1-3*
 address space *1-2*
 address space mapping to PCI *1-4*
 configuration space layout *1-3*
 ID assignment *1-3*
 topology *1-2*
JID *1-2*

M

mapping
 OBP VME *3-11*
 VMEbus interrupt *3-17*
 VMEbus space *3-39*

medvma *3-24*
mmap *3-29*
model configurations, USP111i *xiii*
monitoring devices
 thermal measurement *5-1*
 voltage measurement *5-1*

N

native firmware *1-1*
Nexus driver *3-16*

O

OBP *3-1*
 accessing the VMEbus *3-27*
 accessing VME address space from OBP *3-9*
 additional commands *3-9*
 commands *2-1, 2-3*
 device aliases *3-13*
 support commands *3-6*
 VME environment variables *3-2, 3-6*
 VME mapping *3-11*

P

PCI
 configuration space *1-4*
 segments topology *1-2*
PCI-Ebus bridge *1-11*
PLD *1-10, 4-1*
 commands *3-42*
 register set *4-3*
 registers *1-10*
PLD functions *4-1*
 dump-pld *4-1*
 examples *4-2*
 jumper-status vme-slot *4-1*
 miscellaneous-status *4-1*
 pldc! *4-2*
 pldc@ *4-2*
 pdl! *4-2*
 pdl@ *4-2*
 pld-revision-status *4-1*
 pldw! *4-2*

pldw@ 4-2
 scsi-termination-control 4-1
 scsi-termination-status 4-1
 scsi-termprwr-status 4-1
 temperature-sensor-status 4-1
 themis-show-pld 4-1
 tty-kbm-ac97-status 4-1
 vme-reset-mode 4-1
 PLX PCI9030 bridge chip 3-42
 PLX9030 Ebus controller 1-10
 plxdrv application 3-42
 PMC Carrier boards *xii*
 probing devices 3-34
 Programmable Logic Device (PLD). *See* PLD or CPLD
 programming guide 1-1
 programs
 environmental monitoring 3-41
 sample VME 3-24
 writing for the VMEbus 3-25
 prompts, shell *xv*

R

read/write 3-27
 register map, Universe II 1-15
 removing THEMIS3ivme 3-20

S

SAB 82532, Infineon 1-1
 sample drivers 3-21
 sbvmemem 3-21
 semaphores 1-1
 shared resources 1-1
 shell prompts *xv*
 slave mode 3-29
 slot configurations, VME *xiii*
 SMBALERT 5-3
 software
 configuring the USPIIIi 3-27
 environmental monitoring programs 3-41
 installing THEMIS3ivme 3-17
 plxdrv device driver 3-42

programming guide 1-1
 SUN Open Boot PROM. *See* OBP
 SUN Solaris Operating System 3-15
 usp3i_pld program 3-42
 usp3i_temp program 3-41
 usp3i_uled program 3-42
 usp3i_voltage program 3-41
 USPIIIi 3-1
 VME Nexus driver 3-17
 Solaris 3-1, 3-15
 device hierarchy 3-25
 SPARC version 9.0 *xi*
 Sun documentation 1-9
 Sun native firmware 1-1
 SUN OBP (Open Boot Prom). *See* OBP
 SUN Solaris 3-15
 System board *xii*, 5-1

T

temperature 3-41
 monitoring commands 3-41
 thresholds 5-4
 temperature sensor
 controller ADM1031 5-3
 THERM output 5-3
 TGA3D/3D+ Graphics board *xii*
 Themis website, www.themis.com *xv*
 THEMIS3ivme 3-17, 3-20
 themis-show-pld command 4-11
 themvme 3-16
 THERM output 5-3
 thermal measurement 5-1
 thermal sensors 5-1
 thresholds, temperature 5-4
 Tomatillo 1-2, 1-3
 TTY C and D ports 1-1
 TTY-C/D 8-bit bus 1-10

UUCSR access mechanism *1-14*uninstall, sample drivers *3-23*

Universe II

 controller *1-1* register map *1-15*UNIX commands *xiv*updating Flash PROM *3-6, 3-8* from a SCSI disk *3-8*User Flash - AMD29LV065 *1-10*User LED I2C driver *1-1*user status LED commands *3-42*

USPIIIi

 device monitors *5-2* device monitors, placement of *5-2*

environmental monitoring applications

 usp3i_pld *3-42* usp3i_temp *3-41* usp3i_uled *3-42* usp3i_voltage *3-41* I2C devices *1-6* installing the VME Nexus driver *3-17* models *xiii* photo of *xi* programming guide *1-1* slot configurations *xiii* software *3-1*utility drivers *3-21***V**

VME

 environment variables table *2-2* interface registers *1-14* leaf drivers, sample *3-24* P2 Paddle board *xii* programs, sample *3-24* slot configurations *xiii* special files *3-28*vme_dvma *3-24*vme_intr *3-25*vme_rw *3-25*

VMEbus

 accessing from OBP *3-27* accessing from Solaris *3-27* interface *xi* mapping *3-39* Nexus driver *3-16*vmeintr *3-24*voltage measurement *5-1*voltage monitoring commands *3-42*

voltages monitored

 CPU-0 and CPU-1 Boards *5-8***W**warning threshold, temperature *5-3*website, www.themis.com *xv*writing programs *3-25*writing VME device drivers *3-32***X**Xbus-to-I2C bridge *1-9*