

To our customers,

Old Company Name in Catalogs and Other Documents

On April 1st, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: <http://www.renesas.com>

April 1st, 2010
Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (<http://www.renesas.com>)

Send any inquiries to <http://www.renesas.com/inquiry>.

Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: "Standard", "High Quality", and "Specific". The recommended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as "Specific" without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as "Specific" or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is "Standard" unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.

"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.

"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.

"Specific": Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.

8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

To all our customers

Regarding the change of names mentioned in the document, such as Hitachi Electric and Hitachi XX, to Renesas Technology Corp.

The semiconductor operations of Mitsubishi Electric and Hitachi were transferred to Renesas Technology Corporation on April 1st 2003. These operations include microcomputer, logic, analog and discrete devices, and memory chips other than DRAMs (flash memory, SRAMs etc.) Accordingly, although Hitachi, Hitachi, Ltd., Hitachi Semiconductors, and other Hitachi brand names are mentioned in the document, these names have in fact all been changed to Renesas Technology Corp. Thank you for your understanding. Except for our corporate trademark, logo and corporate statement, no changes whatsoever have been made to the contents of the document, and these changes do not constitute any alteration to the contents of the document itself.

Renesas Technology Home Page: <http://www.renesas.com>

Renesas Technology Corp.
Customer Support Dept.
April 1, 2003

Cautions

Keep safety first in your circuit designs!

1. Renesas Technology Corporation puts the maximum effort into making semiconductor products better and more reliable, but there is always the possibility that trouble may occur with them. Trouble with semiconductors may lead to personal injury, fire or property damage.
Remember to give due consideration to safety when making your circuit designs, with appropriate measures such as (i) placement of substitutive, auxiliary circuits, (ii) use of nonflammable material or (iii) prevention against any malfunction or mishap.

Notes regarding these materials

1. These materials are intended as a reference to assist our customers in the selection of the Renesas Technology Corporation product best suited to the customer's application; they do not convey any license under any intellectual property rights, or any other rights, belonging to Renesas Technology Corporation or a third party.
2. Renesas Technology Corporation assumes no responsibility for any damage, or infringement of any third-party's rights, originating in the use of any product data, diagrams, charts, programs, algorithms, or circuit application examples contained in these materials.
3. All information contained in these materials, including product data, diagrams, charts, programs and algorithms represents information on products at the time of publication of these materials, and are subject to change by Renesas Technology Corporation without notice due to product improvements or other reasons. It is therefore recommended that customers contact Renesas Technology Corporation or an authorized Renesas Technology Corporation product distributor for the latest product information before purchasing a product listed herein.
The information described here may contain technical inaccuracies or typographical errors. Renesas Technology Corporation assumes no responsibility for any damage, liability, or other loss rising from these inaccuracies or errors.
Please also pay attention to information published by Renesas Technology Corporation by various means, including the Renesas Technology Corporation Semiconductor home page (<http://www.renesas.com>).
4. When using any or all of the information contained in these materials, including product data, diagrams, charts, programs, and algorithms, please be sure to evaluate all information as a total system before making a final decision on the applicability of the information and products. Renesas Technology Corporation assumes no responsibility for any damage, liability or other loss resulting from the information contained herein.
5. Renesas Technology Corporation semiconductors are not designed or manufactured for use in a device or system that is used under circumstances in which human life is potentially at stake. Please contact Renesas Technology Corporation or an authorized Renesas Technology Corporation product distributor when considering the use of a product contained herein for any specific purposes, such as apparatus or systems for transportation, vehicular, medical, aerospace, nuclear, or undersea repeater use.
6. The prior written approval of Renesas Technology Corporation is necessary to reprint or reproduce in whole or in part these materials.
7. If these products or technologies are subject to the Japanese export control restrictions, they must be exported under a license from the Japanese government and cannot be imported into a country other than the approved destination.
Any diversion or reexport contrary to the export control laws and regulations of Japan and/or the country of destination is prohibited.
8. Please contact Renesas Technology Corporation for further details on these materials or the products contained therein.

SH7055 E8000 Renesas
Debugging Interface
HS7055D8IW1SE
User's Manual

Cautions

1. Hitachi neither warrants nor grants licenses of any rights of Hitachi's or any third party's patent, copyright, trademark, or other intellectual property rights for information contained in this document. Hitachi bears no responsibility for problems that may arise with third party's rights, including intellectual property rights, in connection with use of the information contained in this document.
2. Products and product specifications may be subject to change without notice. Confirm that you have received the latest product standards or specifications before final design, purchase or use.
3. Hitachi makes every attempt to ensure that its products are of high quality and reliability. However, contact Hitachi's sales office before using the product in an application that demands especially high quality and reliability or where its failure or malfunction may directly threaten human life or cause risk of bodily injury, such as aerospace, aeronautics, nuclear power, combustion control, transportation, traffic, safety equipment or medical equipment for life support.
4. Design your application so that the product is used within the ranges guaranteed by Hitachi particularly for maximum rating, operating supply voltage range, heat radiation characteristics, installation conditions and other characteristics. Hitachi bears no responsibility for failure or damage when used beyond the guaranteed ranges. Even within the guaranteed ranges, consider normally foreseeable failure rates or failure modes in semiconductor devices and employ systemic measures such as fail-safes, so that the equipment incorporating Hitachi product does not cause bodily injury, fire or other consequential damage due to operation of the Hitachi product.
5. This product is not designed to be radiation resistant.
6. No one is permitted to reproduce or duplicate, in any form, the whole or part of this document without written approval from Hitachi.
7. Contact Hitachi's sales office for any questions regarding this document or Hitachi semiconductor products.

IMPORTANT INFORMATION

READ FIRST

- **READ** this user's manual before using this emulator product.
- **KEEP the user's manual handy for future reference.**

Do not attempt to use the emulator product until you fully understand its mechanism.

DEFINITION OF SIGNAL WORDS

CAUTION

CAUTION used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, may result in property damage.

NOTE emphasizes essential information.

Preface

The SH7055 E8000 Hitachi Debugging Interface (referred to as the HDI) is a software tool that supports program development by using an emulator for the Hitachi microprocessor SH7055 (referred to as the emulator).

This manual is the Debugging Platform User's Manual, which is a separate volume to the Hitachi Debugging Interface User's Manual, and describes the HDI functions and its usage. Read this manual and the following manuals before using the HDI.

For details on the emulator,

- SH7055 E8000 Emulator User's Manual
- Description Notes on Using the PC Interface Board (HS6000EII01H)
- Description Notes on Using the PC Card Interface (HS6000EIP01H) for the E6000/E8000 Emulator
- Description Notes on Using the PCI Interface Board (HS6000EIC01H) for the E6000/E8000 Emulator
- Description Notes on Using the PCI Interface Board (HS6000EIC02H) for the E6000/E8000 Emulator
- Description Notes on Using the USB Adapter (HS6000EIU01H) for the E6000/E8000 Emulator
- Description Notes on Using the LAN Adapter (HS6000ELN01H) for the E6000/E8000 Emulator
- SH7055 E8000 Emulator Diagnostic Program Manual

For details on the related software manuals,

- Hitachi Debugging Interface User's Manual
- Hitachi Embedded Workshop User's Manual
- SuperH™ RISC engine C/C++ Compiler User's Manual
- SuperH™ RISC engine Cross Assembler User's Manual
- H Series Linkage Editor Librarian, Object Converter User's Manual
- SuperH™ RISC Engine C/C++ Compiler, Assembler, Optimizing Linkage Editor User's Manual

For details on the SH7055-series microprocessor,

- SH7055 Hardware Manual
- SH7055 Programming Manual

Refer to section 2, Installation, for details on HDI installation.

In this user's manual, the operating environment is assumed to be the English version Windows[®] 95 on the IBM PC.

- Notes:
1. Windows[®], Windows[®] 95, Windows[®] 98, Windows[®] 98SE, Windows NT[®] 4.0, Windows[®] Me, and Windows[®] 2000 are operating system names controlled by Microsoft Corporation in the United States.
 2. IBM PC is a registered trademark of International Business Machines Corporation.
 3. Pentium[®] is a registered trademark of Intel Corporation.
 4. Adobe[®], Adobe logo, Adobe[®] Acrobat[®], and Adobe Acrobat logo are the trademarks of Adobe System Incorporated.

All product names and brand names used in this user's manual are trademarks or registered trademarks of each company.

Contents

Section 1	Overview	1
1.1	Overview	1
1.1.1	Features	1
1.2	Operating Environment	2
1.3	Configuration of the CD-R	3
Section 2	Installation	7
2.1	Installation Procedures	7
2.1.1	Installing the Acrobat® Reader™	7
2.1.2	Setting up the E8000 Emulator	7
2.2	Setting Up with Windows® Operating Systems	7
2.2.1	Setting Up with Windows® 95, Windows® 98, Windows® 98SE, or Windows® Me Operating System	8
2.2.2	Setting Up with Windows NT® 4.0 Operating System	10
2.2.3	Setting Up with Windows® 2000 Operating System	11
2.2.4	PC Interface Board Specifications (ISA Bus Specifications)	12
2.3	Installing the System Program	16
2.4	Checking the System	22
2.5	Troubleshooting	25
2.5.1	Connection Error of the PC Interface Board	25
2.5.2	Connection Error of the Emulator	25
2.6	Uninstallation	27
2.6.1	Uninstalling Software	27
2.6.2	Uninstalling the Acrobat® Reader™	27
Section 3	Tutorial	29
3.1	Introduction	29
3.2	Running the HDI	30
3.2.1	Selecting the Target Program	31
3.3	Setting up the Emulator	33
3.3.1	Setting the [Configuration] Dialog Box	34
3.3.2	Setting the Memory Map	36
3.4	Downloading the Tutorial Program	39
3.4.1	Downloading the Tutorial Program	39
3.4.2	Displaying the Source Program	41
3.5	Setting the Software Breakpoint	43

3.6	Executing the Program.....	44
3.7	Reviewing Breakpoints.....	46
3.8	Viewing Memory.....	47
3.9	Watching Variables.....	48
3.10	Stepping Through a Program.....	51
	3.10.1 Executing [Step In] Command.....	53
	3.10.2 Executing [Step Out] Command.....	54
	3.10.3 Executing [Step Over] Command.....	56
3.11	Displaying Local Variables.....	58
3.12	Setting the Hardware Break Conditions.....	59
3.13	Setting the Sequential Break Conditions.....	67
3.14	Using the Trace Buffer.....	77
	3.14.1 Displaying the Trace Buffer.....	77
	3.14.2 Setting the Trace Filter.....	78
3.15	Trace Acquisition Condition Setting.....	82
3.16	Saving the Session.....	90
3.17	What Next?.....	91
 Section 4 Function.....		93
4.1	Windows and Dialog Boxes.....	93
4.2	Command Descriptions.....	96
 Section 5 Use of Diagnostic Program.....		101
5.1	Diagnostic Program Operation.....	101
	5.1.1 Diagnostic Program Installation on the HDI.....	101
	5.1.2 TARGET.INI File Setting.....	101
	5.1.3 Diagnostic Program Start-Up.....	102
	5.1.4 Diagnostic Program Termination.....	104
 Section 6 Error Messages.....		105
6.1	Error Messages.....	105

Figures

Figure 2.1	Selecting [System Install] from the [Start] Menu.....	17
Figure 2.2	[Browse for Folder] Dialog Box	18
Figure 2.3	[E8000 Load Files] Dialog Box	19
Figure 2.4	[System Install Completed!!] Dialog Box	20
Figure 2.5	[E8000 Load Files] Dialog Box	21
Figure 2.6	[Start] Menu	22
Figure 2.7	[Select Session] Dialog Box.....	23
Figure 2.8	[Driver Details] Dialog Box (When Selecting ISA Driver)	23
Figure 2.9	Status Bar during the HDI Initiation	24
Figure 2.10	Status Bar at the HDI Initiation Completion	24
Figure 2.11	PC Interface Board Connection Error Message Box.....	25
Figure 2.12	Emulator Connection Error Message Box.....	25
Figure 3.1	[Start] Menu	30
Figure 3.2	[Select Session] Dialog Box.....	31
Figure 3.3	HDI Window.....	32
Figure 3.4	[Configuration] Dialog Box	34
Figure 3.5	[Memory Mapping] Window (Before Setting).....	36
Figure 3.6	[Edit Memory Mapping] Dialog Box.....	37
Figure 3.7	[Memory Mapping] Dialog Box (at Setting).....	38
Figure 3.8	[Load Program] Dialog Box.....	39
Figure 3.9	[HDI] Dialog Box.....	40
Figure 3.10	[Open] Dialog Box	41
Figure 3.11	[Source] Window (Displaying the Source Program).....	42
Figure 3.12	[Program] Window (Setting a Software Breakpoint)	43
Figure 3.13	[ResetGo] Button.....	44
Figure 3.14	[Source] Window (Break State)	44
Figure 3.15	[System Status] Window	45
Figure 3.16	[Breakpoints] Window	46
Figure 3.17	[Open Memory Window] Dialog Box.....	47
Figure 3.18	[Word Memory] Window.....	47
Figure 3.19	[Instant Watch] Dialog Box	48
Figure 3.20	[Watch] Window (Displaying the Array).....	48
Figure 3.21	[Add Watch] Dialog Box	49
Figure 3.22	[Watch] Window (Displaying the Variable)	50
Figure 3.23	[Watch] Window (Displaying Array Elements).....	50
Figure 3.24	[Source] Window (Step Execution)	52
Figure 3.25	[Step In] Button.....	53

Figure 3.26	[Source] Window (Step In)	53
Figure 3.27	[Step Out] Button	54
Figure 3.28	[Source] Window (Step Out).....	54
Figure 3.29	[Source] Window (Step Out -> Step In).....	55
Figure 3.30	[Source] Window (Before Step Over Execution).....	56
Figure 3.31	[Step Over] Button	57
Figure 3.32	[Source] Window (Step Over).....	57
Figure 3.33	[Locals] Window	58
Figure 3.34	[Breakpoints] Window (Before Hardware Break Condition Setting)	61
Figure 3.35	[Condition A] Page ([Break] Dialog Box)	62
Figure 3.36	[Address] Page ([Break Condition A1] Dialog Box)	63
Figure 3.37	[Bus State] Page ([Break Condition A1] Dialog Box)	64
Figure 3.38	[Break] Dialog Box (After Hardware Break Condition Setting).....	65
Figure 3.39	[Breakpoints] Window ([Break Condition A] Setting)	66
Figure 3.40	[Configuration] Dialog Box (When Sequential Break is Set)	69
Figure 3.41	[Breakpoints] Window (Before Sequential Break Conditions Setting).....	70
Figure 3.42	[Break] Dialog Box ([Break Condition UBC] Page).....	71
Figure 3.43	[Break Condition UBC2] Dialog Box (Condition 2 [Address] Page)	72
Figure 3.44	[Break Condition UBC2] Dialog Box (Condition 2 [Bus State] Page)	73
Figure 3.45	[Break] Dialog Box (After [Break Condition UBC2] Condition Setting).....	74
Figure 3.46	[Breakpoints] Window (After Sequential Break Condition Setting).....	75
Figure 3.47	[Program] Window at Execution Halt (Sequential Break).....	76
Figure 3.48	Contents of [System Status] Window (Sequential Break).....	76
Figure 3.49	[Trace] Window (Free Trace Results).....	77
Figure 3.50	[General] Page ([Trace Filter] Dialog Box)	79
Figure 3.51	[Address] Page ([Trace Filter] Dialog Box).....	80
Figure 3.52	[Bus & Area] Page ([Trace Filter] Dialog Box).....	81
Figure 3.53	[Trace] Window (Trace Filter Results)	81
Figure 3.54	[Trace Acquisition] Dialog Box	84
Figure 3.55	[Condition A] Page ([Trace Acquisition] Dialog Box)	85
Figure 3.56	[General] Page ([Trace Condition A1] Dialog Box)	86
Figure 3.57	[Address] Page ([Trace Condition A1] Dialog Box).....	87
Figure 3.58	[Bus State] Page ([Trace Condition A1] Dialog Box).....	88
Figure 3.59	[Condition A] Page ([Trace Acquisition] Dialog Box)	89
Figure 5.1	HDI Installation Dialog Box	101
Figure 5.2	Example of TARGET.INI File Display.....	101
Figure 5.3	Diagnostic Program Start-Up Confirmation Dialog Box	102
Figure 5.4	Diagnostic Program Start-Up Window	102
Figure 5.5	Diagnostic Program Termination	104

Tables

Table 1.1	Operating Environments	2
Table 1.2	Combination of the OS and Acceptable Interface	2
Table 1.3	CD-R Files	3
Table 2.1	Contents of Emulator System Programs	16
Table 2.2	Types of Connections and Drivers.....	17
Table 3.1	Configuration of Sample Program.....	29
Table 3.2	Setting the [Configuration] Dialog Box.....	35
Table 3.3	Memory Type	37
Table 3.4	Step Option	51
Table 3.5	Dialog Boxes for Setting Hardware Break Conditions	59
Table 3.6	Main Break Conditions	60
Table 3.7	Dialog Boxes for Setting Sequential Break Conditions	67
Table 3.8	Main Sequential Break Functions	68
Table 3.9	Main Trace Search Conditions.....	78
Table 3.10	Dialog Boxes for Setting Trace Acquisition Conditions	82
Table 3.11	Main Trace Acquisition Conditions	83
Table 4.1	List of Windows and Dialog boxes in the SH7055 E8000 HDI	93
Table 4.2	SH7055 E8000 HDI Commands.....	97
Table 6.1	Error Messages	105

Section 1 Overview

1.1 Overview

The SH7055 E8000 Hitachi Debugging Interface (referred to as the HDI) promotes efficient debugging of programs written in C/C++ or assembly language in the environment using the emulator for the SH7055 microprocessor.

1.1.1 Features

The HDI has the following features:

- High-speed downloading of load module files.
- A comprehensive set of break functions, trace conditions, and functions to set or edit memory maps are enabled by the HDI windows.
- Large-capacity trace information can be displayed (a maximum of 64-k bus cycles are displayed on the window).
- Command line functions (command system for the HDI).

1.2 Operating Environment

The HDI is provided on CD-R. The following shows the acceptable operating environments:

Table 1.1 Operating Environments

Item	Operating Environment
Host computer	Built-in Pentium® or higher-performance CPU (300 MHz or higher is recommended); IBM PC or compatible
OS	Windows® 95, Windows® 98, Windows® 98SE, Windows® ME, Windows NT® 4.0, or Windows® 2000
Minimum memory capacity	32 Mbytes or more (twice the load module size or more is recommended).
Display	800 x 600 (SVGA) or better resolution.
Hard disk capacity	Installation disk capacity: 40 Mbytes or more. Prepare enough area by taking the swap area into account (four-times or more the memory capacity is recommended).
Corresponding interface	ISA or PCI bus slot, PC card (PCMCIA), USB adapter, LAN adapter (conforms to IEEE802.3, 10BASE-T/100BASE-TX)
A pointing device such as a mouse	A pointing device such as a mouse that can be connected to the host computer and can be used for each OS.
CD-ROM drive	To install the E8000 emulator software or to refer to the user's manual.

Table 1.2 Combination of the OS and Acceptable Interface

	PCI Interface Board (PCI)	PC Card Interface (PCMCIA)	PC Interface Board (ISA)	LAN Adapter (LAN)	USB Adapter (USB)
Windows® 95	O	O	O	O	X
Windows NT® 4.0	O	O	O	O	X
Windows® 98	O	O	O	O	X
Windows® 98SE	O	O	O	O	O
Windows® Me	O	O	X	O	O
Windows® 2000	O	O	X	O	O

Note: O: Can be used.
X: Cannot be used.

1.3 Configuration of the CD-R

The CD-R includes the E8000 emulator software and the user's manual for SH7055 E8000 emulator. See table 1.3.

Table 1.3 CD-R Files

Directory Name	File Name	Contents	Note
	setup.exe	Installer	
System	E8000.sys ^[*1]	System program for the SH7055 E8000 emulator	
System	shdct705.sys ^[*1]	Control program for the SH7055 E8000 emulator	
System	shcnf705.sys ^[*1]	Configuration file for the SH7055 E8000 emulator	
System	diag.sys ^[*1]	Diagnostic and maintenance program	
System	ipw.exe ^[*1]	Interface software	
System	setup.cc ^[*1]	Script file for automatic installation (IPW)	
Drivers\Pci\95	pchei.inf	Setup information (PCI)	For Windows [®] 95, Windows [®] 98, Windows [®] 98SE, and Windows [®] Me
Drivers\Pci\95	pchei.vxd	Virtual driver (PCI)	For Windows [®] 95, Windows [®] 98, Windows [®] 98SE, and Windows [®] Me
Drivers\Pci\Nt	pchei.sys	System file (PCI)	For Windows NT [®]
Drivers\Pci\2000	pchei.sys	System file (PCI)	For Windows [®] 2000
Drivers\Pci\2000	pchei2k.inf	Setup information (PCI)	For Windows [®] 2000
Drivers\Iisa\Nt	emulator.sys	System file (ISA)	For Windows NT [®]
Drivers\Pcmcia\95	ulepcc.inf	Setup information (PCMCIA)	For Windows [®] 95, Windows [®] 98, Windows [®] 98SE, and Windows [®] Me

Table 1.3 CD-R Files (cont)

Directory Name	File Name	Contents	Notes
Drivers\Pcmcia\95	ulepcc.vxd	Virtual driver (PCMCIA)	For Windows® 95, Windows® 98, Windows® 98SE, and Windows® Me
Drivers\Pcmcia\Nt	ulepcnt.sys	System file (PCMCIA)	For Windows NT®
Drivers\Pcmcia\2000	ulepcc2k.sys	System file (PCMCIA)	For Windows® 2000
Drivers\USB\	uleusb.inf	Setup information (PCI)	For Windows® Me, Windows® 98SE, and Windows® 2000
Drivers\USB\	uleusb.sys	System file	For Windows® Me, Windows® 98SE, and Windows® 2000
Drivers\Pcmcia\2000	ulepcc2k.inf	Setup information (PCMCIA)	For Windows® 2000
Manuals\Japanese	HS6400DIIW5SJ.pdf ^[*2]	Hitachi Debugging Interface user's manual	PDF documents in Japanese ^[*5]
Manuals\Japanese	HS7055D8IW1SJ.pdf ^[*2]	SH7055 E8000 Hitachi Debugging Interface User's Manual	PDF documents in Japanese ^[*5]
Manuals\Japanese	HS7055EDD81HJ(*) ^[*3] .pdf ^[*2]	SH7055 E8000 Emulator User's Manual	PDF documents in Japanese ^[*5]
Manuals\Japanese	HS7055EDD81HJ-ER(*) ^[*3] .pdf ^[*2]	Errata for SH7055 E8000 Emulator User's Manual	PDF documents in Japanese ^[*5]
Manuals\Japanese	HS7055TM81HJ(*) ^[*3] .pdf ^[*2]	Descriptive Notes on the Diagnostic Program for the SH7055 E8000 Emulator	PDF documents in Japanese ^[*5]
Manuals\Japanese	HS7055EBK81HJ(*) ^[*3] .pdf ^[*2]	SH7055 E8000 Evaluation Chip Board HS7055EBK81H User's Manual	PDF documents in Japanese ^[*5]
Manuals\English	HS6400DIIW4SE.pdf ^[*4]	Hitachi Debugging Interface user's manual	PDF documents in English ^[*5]
Manuals\English	HS7055D8IW1SE.pdf ^[*4]	SH7055 E8000 Hitachi Debugging Interface User's Manual	PDF documents in English ^[*5]

Table 1.3 CD-R Files (cont)

Directory Name	File Name	Contents	Notes
Manuals\English	HS7055EDD81HE (* ^[*3]).pdf ^[*4]	SH7055 E8000 Emulator User's Manual	PDF documents in English ^[*5]
Manuals\English	HS7055EDD81HE- ER(* ^[*3]).pdf ^[*4]	Errata for SH7055 E8000 Emulator User's Manual	PDF documents in English ^[*5]
Manuals\English	HS7055TM81HE(* ^[*3]).pdf ^[*4]	Descriptive Notes on the Diagnostic Program for the SH7055 E8000 Emulator	PDF documents in English ^[*5]
Manuals\English	HS7055EBK81HE (* ^[*3]).pdf ^[*4]	SH7055 E8000 Evaluation Chip Board HS7055EBH81H User's Manual	PDF documents in English ^[*5]
Pdf_read\Japanese	Ar500jpn.exe	Acrobat [®] Reader [™] 5.0 installer	Japanese version
Pdf_read\English	Ar500eng.exe	Acrobat [®] Reader [™] 5.0 installer	English version

- Notes: 1. Installed on your host computer by the installer.
2. This is the Japanese version of the manual. It cannot be installed by the installer.
3. (*) indicates a manual revision.
4. This is the English version of the manual. It cannot be installed by the installer.
5. Use the Acrobat[®] Reader[™] to see PDF documents.

Section 2 Installation

2.1 Installation Procedures

Sections below describe the installation procedures when the HDI is used.

2.1.1 Installing the Acrobat® Reader™

Acrobat® Reader™ 5.0 is required to view the online manual. Acrobat® Reader™ is provided on the CD-R of this product. The installation of Acrobat® Reader™ is described below. If you have already installed Acrobat® Reader™, do not carry out this procedure.

1. Install the CD-R of this product in the CD-ROM drive.
2. Click [Run...] from the [Start] menu.
3. Specify Ar500eng.exe in Pdf_read\English directory in the [Run] dialog box (e.g. D:\Pdf_Read\English\Ar500eng.exe) then click the [OK] button.
4. Install according to the instructions displayed in the screen.

2.1.2 Setting up the E8000 Emulator

For details on setting up the E8000 emulator, refer to section 3, Preparation before Use, in Part I of the SH7055 E8000 Emulator User's Manual in the CD-R. Note that the full content of the emulator system disk which is referred to in the SH7055 E8000 Emulator User's Manual is in the system directory of the CD-R.

2.2 Setting Up with Windows® Operating Systems

The following describes the setup procedure for Windows® operating systems.

Since hardware is set up during installation, the installation procedure may differ according to the operating system and interface used (ISA, PCI, USB, PCMCIA, or LAN). Proceed with installation according to the procedures for the environment in use.

To connect the host computer to the emulator, either a PC interface board (HS6000EII01H), PCI interface board (HS6000EIC01H and HS6000EIC02H), USB interface board (HS6000EIU01H), PC interface card (HS6000EIP01H), or a LAN adapter (HS6000ELN01H) can be selected.

For details on the connection of the PC interface board (ISA bus specifications), refer to section 2.2.4, PC Interface Board Specifications (ISA Bus Specifications), and the user's manual. For details on other connections, refer to the related user's manual.

To install the provided software, insert the CD-R in the CD-ROM drive. If there are any applications running, exit from them before installing the software.

Click [Run...] from the [Start] menu. The [Run] dialog box will be displayed. Enter <Drive>:\setup.exe and click the [OK] button. <Drive> is the drive name of the CD-ROM drive.

Proceed with installation by following instructions provided by the install wizard.

2.2.1 Setting Up with Windows® 95, Windows® 98, Windows® 98SE, or Windows® Me Operating System

When Using the PCI Interface Board:

- Install the provided software. Select [PCI Card Driver] as the component.
- Exit the operating system, shut down the host computer, and turn off the power switch.
- Install the PCI interface board into the host computer.
- Turn on the host computer. Hardware will be acknowledged and driver installation will start automatically.
- Select [Search for the best driver for your device] for driver installation, and select [Specify a location] for the location.
- Specify <Drive>:\DRIVERS\PCI\95 for the location. <Drive> is the drive name of the CD-ROM drive.
- Check that PCIHEI Rev 1 has been detected and complete driver installation.

When Using the PC Interface Card:

- Install the provided software. Select [PC Card Driver (PCMCIA)] as the component.
- Install the PC interface card into the host computer.
- Hardware will be acknowledged and driver installation will start automatically.
- Select [Search for the best driver for your device] for driver installation, and select [Specify a location] for the location.
- Specify <Drive>:\DRIVERS\PCIMCIA\95 for the location. <Drive> is the drive name of the CD-ROM drive.
- Check that E6000 PC Card has been detected and complete driver installation.

When Using the PC Interface Board:

- Refer to section 2.2.4, PC Interface Board Specifications (ISA Bus Specifications), and set the operating system environment and install the ISA bus interface board.
- Install the provided software. Select [ISA Driver] as the component.

Note: The PC interface board cannot be used under Windows® Me.

When Using the LAN Adapter:

- Install the provided software. Select [E8000 LAN Driver] as the component.
- Connect the LAN adapter to the local network and turn the LAN adapter on.
- Select [SH7055 E8000 Emulator Software]-[Tools]-[LAN Adapter Configuration] from [Start]-[Programs] to start the LAN Adapter Configuration.
- Set the LAN adapter by LAN Adapter Configuration.
- Turn the LAN adapter off and connect the LAN adapter to the target network and turn the LAN adapter on. In this procedure, LAN adapter must be turned off even when the network is not changed.

Note: When using a LAN adapter that has already been set, it is unnecessary to set it again. Use LAN Adapter Configuration to define only the host computer. For details on the usage of the LAN Adapter Configuration, refer to the online help of the LAN Adapter Configuration.

When Using the USB Adapter:

- Install the provided software. Select [E8000 USB Driver] as the component.
- Install the USB adapter into the host computer.
- Hardware will be acknowledged and the USB adapter will be automatically acknowledged.
- Select [Search for the best driver for your device] for driver installation, and select [Specify a location] for the location.
- Specify <Drive>:\DRIVERS\USB for the location. <Drive> is the drive name of the CD-ROM drive.
- Check that E8000/E6000 USB Adapter has been detected and complete driver installation.

Note: The USB adapter is not supported in Windows® 95 and Windows® 98.

2.2.2 Setting Up with Windows NT® 4.0 Operating System

When Using the PCI Interface Board:

- Exit from the operating system, shut down the host computer, and turn off the power switch.
- Install the PCI bus interface board into the host computer.
- Turn on the host computer. Log-on as Administrator.
- Install the provided software. Select [PCI Card Driver] as the component.
- Restart the host computer.

When Using the PC Interface Card:

- Exit from the operating system, shut down the host computer, and turn off the power switch.
- Install the PC interface card into the host computer.
- Turn on the host computer. Log-on as Administrator.
- Install the provided software. Select [PC Card Driver (PCMCIA)] as the component. Check the values specified for use by the PC interface card before the information is requested during installation. Select and start [Programs]-[Administrative Tools (Common)]-[Windows NT Diagnostics] from [Start]-[Programs] to check the current status of IRQ, I/O ports, and memory in the resource panels, and set values that will not cause contention with other devices. Required resources are as follows: one channel for IRQ, H'F bytes for I/O ports, H'4000 bytes for use as memory.
- Restart the host computer.

Note: Default settings start all the drivers selected as [Drivers] components after the activation of the host computer. When the host computer is activated without a given card or an inappropriate driver is installed, it is not possible to start the given driver. The service control manager informs the user of the error, but it causes no other problem.

When Using the PC Interface Board:

- Refer to section 2.2.4, PC Interface Board Specifications (ISA Bus Specifications), and set the operating system environment and install the ISA bus interface board.
- Log-on as Administrator.
- Install the provided software. Select [ISA Driver] as the component.
- Restart the host computer.

When Using the LAN Adapter:

- Log-on as Administrator.
- Install the provided software. Select [E8000 LAN Driver] as the component.
- Connect the LAN adapter to the local network and turn on the LAN adapter.

- Select [SH7055 E8000 Emulator Software]-[Tools]-[LAN Adapter Configuration] from [Start]-[Programs] and start the LAN Adapter Configuration.
- Set the LAN adapter by LAN Adapter Configuration.
- Turn off the LAN adapter and connect the LAN adapter to the target network and turn on the LAN adapter. Then LAN adapter must be turned off even when the network is not changed.

Note: When using a LAN adapter that has already been set, it is unnecessary to set it again. Use LAN Adapter Configuration to define only the host computer. For details on the usage of the LAN Adapter Configuration, refer to the online help of the LAN Adapter Configuration.

Support of the USB Adapter:

The USB adapter is not supported in Windows NT[®].

2.2.3 Setting Up with Windows[®] 2000 Operating System

Support of the PC Interface Board:

The PC interface board is not supported in Windows[®] 2000.

When Using the PCI Interface Board:

- Log-on as Administrator.
- Install the provided software. Select [PCI Card Driver] as the component.
- Exit from the operating system, shut down the host computer, and turn off the power switch.
- Install the PCI bus interface board into the host computer.
- Turn on the host computer. Hardware will be acknowledged and driver installation will start automatically.
- Select [Search for a suitable driver for my device (recommended)] for driver installation, and select [Specify a location] for the location.
- Specify <Drive>:\DRIVERS\PCI\2000 for the location. <Drive> is the drive name of the CD-ROM drive.
- Check that E6000 PCI Card has been detected and complete driver installation.

When Using the PC Interface Card:

- Log-on as Administrator.
- Install the provided software. Select [PC Card Driver (PCMCIA)] as the component.
- Install the PC interface card into the host computer.
- Hardware will be acknowledged and driver installation will start automatically.
- Select [Search for a suitable driver for my device (recommended)] for driver installation, and select [Specify a location] for the location.

- Specify <Drive>:\DRIVERS\PCMCIA\2000 for the location. <Drive> is the drive name of the CD-ROM drive.
- Check that E6000 PC Card has been detected and complete driver installation.

When Using the LAN Adapter:

- Log-on as Administrator.
- Install the provided software. Select [E8000 LAN Driver] as the component.
- Connect the LAN adapter to the local network and turn on the LAN adapter.
- Select [SH7055 E8000 Emulator Software]-[Tools]-[LAN Adapter Configuration] from [Start]-[Programs] and start the LAN Adapter Configuration.
- Set the LAN adapter by LAN Adapter Configuration.
- Turn off the LAN adapter and connect the LAN adapter to the target network and turn on the LAN adapter. Then LAN adapter must be turned off even when the network is not changed.

Note: When using a LAN adapter that has already been set, it is unnecessary to set it again. Use LAN Adapter Configuration to define only the host computer. For details on the usage of the LAN Adapter Configuration, refer to the online help of the LAN Adapter Configuration.

When Using the USB Adapter:

- Log-on as Administrator.
- Install the provided software. Select [E8000 USB Driver] as the component.
- Install the USB adapter into the host computer.
- Hardware will be acknowledged and the USB adapter will be automatically acknowledged.
- Select [Search for the best driver for your device] for driver installation, and select [Specify a location] for the location.
- Specify <Drive>:\DRIVERS\USB for the location. <Drive> is the drive name of the CD-ROM drive.
- Check that E8000/E6000 USB Adapter has been detected and complete driver installation.

2.2.4 PC Interface Board Specifications (ISA Bus Specifications)

A PC interface board (HS6000EII01H, ISA bus specifications) is available for use as the interface for communications between the emulator and the HDI. Firstly, the PC interface board must be inserted to the empty expansion slot.

The PC interface board is a memory-mapped board; the memory area to be used by the PC interface board must be defined in the emulation memory before the PC interface board is placed in an unused expansion slot. Otherwise, programs may accidentally use the area of memory required by the PC interface hardware.

CAUTION

Be careful not to allocate the PC interface board to a memory area to which other boards have been allocated. If you fail to take care of this point, correct operation cannot be guaranteed.

When the PC interface board is shipped, the switch settings are for allocation to the address range from H'D0000 to H'D3FFF.

For details on installing the PC interface board, refer to the SH7055 E8000 Emulator User's Manual and the Description Notes on Using the PC Interface Board (HS6000EII01H).

Setting Up the PC Interface Board on Windows® 95, Windows® 98, or Windows® 98SE:

Description of setting up a PC interface board (HS6000EII01H) is given below, taking settings under Windows® 95 as an example.

- Start Windows® 95.
- Click the [My Computer] icon with the right mouse button and select [Properties] from the pop-up menu.

The [System Properties] dialog box will be displayed.

- Double-click the [Computer] icon in the [Device Manager] panel to open the [Computer Properties] dialog box.
- Click the [Memory] radio button in the [View Resources] panel to display the memory resources.

Select one of the address ranges that is not listed in the [Computer Properties] dialog box. For example, if you select the range H'D8000 to H'DBFFF, the corresponding switch number will be 6.

Define the memory area so that Windows® 95 does not use this area as follows:

- Click [Memory] in the [Reserve Resources] panel and click [Add...].

The [Edit Resource Setting] dialog box will be displayed.

- Enter the memory area addresses in [Start value] and [End value] and click [OK].
- Shut down the host computer (do not restart it) and turn off the power switch.
- Power on the host computer.
- Check that the area selected in the [Computer Properties] dialog box are displayed as [System Reserved] in the list.

The next step prevents the memory area for the PC interface board being accessed by another program. Modify the CONFIG.SYS file. Use the SYSEDIT program to edit the file.

- Select [Run] from the [Start] menu.
- Type SYSEDIT and click [OK]. The SYSEDIT will start.

When EMM386.EXE is used in the CONFIG.SYS file, the CONFIG.SYS file must be modified. If the CONFIG.SYS file is not used, or if EMM386.EXE is not used even when the CONFIG.SYS file is used, go to the next procedure for modifying the SYSTEM.INI file.

- Locate the line in the CONFIG.SYS file that reads:

```
device=C:\WINDOWS\EMM386.EXE RAM
```

- Change the line so that it reads as shown below.

```
device=C:\WINDOWS\EMM386.EXE RAM X=aaaa-bbbb
```

Here, *aaaa* is the upper four digits of [Start value] and *bbbb* is the upper four digits of [End value]. For example, for the switch set to 6 with memory area H'D8000 to H'DBFFF selected, you would set the line to read:

```
device=C:\WINDOWS\EMM386.EXE RAM X=D800-DBFF
```

- Save the CONFIG.SYS file.

The following is about modifying the SYSTEM.INI file.

- Add the following line to the [386Enh] section in the SYSTEM.INI file:

```
EMMExclude=aaaa-bbbb
```

Here, *aaaa* is the upper four digits of [Start value] and *bbbb* is the upper four digits of [End value]. For example, for the switch set to 6 with memory area H'D8000 to H'DBFFF selected, you would set the line to read:

```
EMMExclude = D800-DBFF
```

- Save the SYSTEM.INI file and exit the SYSEDIT.
- Restart the host computer.

Setting Up the PC Interface Board on Windows NT[®] 4.0: The description given below is about setting up the PC interface board (HS6000EII01H) on Windows NT[®] 4.0.

For the installation of the PC interface board to the ISA bus slot, refer to the manual of your host computer.

This section describes the general procedure for installing the PC interface board in the host computer.

Log-on to the host computer as Administrator. Check which upper memory areas have already been used.

Start Windows NT[®] 4.0.

- Execute [Start]-[Programs]-[Administrative Tools (Common)]-[Windows NT Diagnostics].
- Click the [Memory] button in the [Resource] tab and, in the following form, make a note of the upper memory areas that have already been used.
- Exit Windows NT[®] 4.0.
- Register the memory area for the PC interface board. Select one of the memory areas that correspond to the following PC interface board switch settings, and no other devices can access the selected memory area.

If the Intel P&P BIOS disk is supplied with the host computer, register the memory area as follows:

- Start the host computer with the Intel P&P BIOS disk.
- Check the upper memory areas that have already been used, with [View]-[System Resources].
- Add [Unlisted Card] with [Configure]-[Add Card]-[Other...].
- Click [No] in the dialog box displayed because there is no .CFG file.
- Move to the [Memory [hex]] list box in the [Configure Unlisted Card] dialog box.
- Click the [Add Memory...] button to display the [Specify Memory] dialog box.
- Enter a memory area range that is not used by any other device and that corresponds to one of the PC interface board switch settings.
- Save the file.
- Exit the current setup program.
- Shut down Windows NT[®] 4.0 and turn off the host computer power switch.
- Turn on the host computer.

2.3 Installing the System Program

The E8000 system program must be transferred to flash memory in the E8000 emulator station. The E8000 emulator cannot be used without the E8000 system program.

The system programs are stored in the SYSTEM directory under the HDI installation directory. Table 2.1 is a list of system programs with descriptions.

Table 2.1 Contents of Emulator System Programs

No.	File Name	Contents of File
1	E8000.SYS	System program for the emulator. Controls the evaluation board and executes various commands such as emulation. Loaded to the memory of the emulator at the start of the emulator system program.
2	SHDCT705.SYS	MCU control program. Controls the MCU in the evaluation chip board. Loaded to the memory of the E8000 emulator at the start of the emulator system program.
3	SHCNF705.SYS	Configuration file to store the MCU operation mode and MAP information. Loaded with the emulator system program.
4	DIAG.SYS	Diagnostic/maintenance program. Loaded to the memory in the E8000 emulator station for maintenance.

The system program is defined by using a dedicated E8000 system installation tool (hereafter referred to as ESI). There are two methods for registering the system program: auto installation and custom installation.

First, auto installation is described below.

- Select [Programs]-[SH7055 E8000 Emulator Software]-[Tools]-[System Install Tool] from the [Start] menu.




Figure 2.1 Selecting [System Install] from the [Start] Menu

When the ESI has been initiated, [Select Driver] dialog box will be displayed. Select the driver that corresponds to the connection between the host computer and the E8000 emulator via [Driver]. Table 2.2 shows the types of connections and drivers.

Table 2.2 Types of Connections and Drivers

Connecting Form	Contents of File
When connecting the E8000 emulator to PC interface board	Emulator ISA Driver
When connecting the E8000 emulator to USB adapter	E8000 USB Driver
When connecting the E8000 emulator to LAN adapter	E8000 LAN Driver
When connecting the E8000 emulator to PCI interface board	Emulator PCI Card Driver
When connecting the E8000 emulator to PC interface card	Emulator PC Card Driver

“Link up” appears on the status bar when the ESI has been successfully initiated.

Select the [Auto Install] radio button in the [Select Install] dialog box. When the [Browse for Folder] dialog box is displayed, select the director that the system program has been saved. (The default directory name is \SYSTEM under the HDI installation directory.)




Figure 2.2 [Browse for Folder] Dialog Box

When the [OK] button is clicked, the [E8000 Load Files] dialog box is displayed. Check the name of the file to be installed.




Figure 2.3 [E8000 Load Files] Dialog Box

Click the [OK] button. The system program is registered to the emulator. The file name that has been registered on the status bar is displayed. When the [Cancel] button is clicked, the [Select Install] dialog box will be returned.

When registration has been completed, the [System Install Completed!!] dialog box is displayed.




Figure 2.4 [System Install Completed!!] Dialog Box

Click the [OK] button. Registration of the system program to the emulator is completed and ESI ends. Turn the emulator off.

Next, custom installation is described below.

When the [Select Install] dialog box is displayed, select the [Custom Install] radio button. The [E8000 Load Files] dialog box is displayed to select the file to be added or changed.




Figure 2.5 [E8000 Load Files] Dialog Box

Each check box corresponds to the combo box that is located at the right side. Select the check box that corresponds to the file to be registered. Place a cursor in the combo box and press the [Browse] button. When the [Browse] button is clicked, a dialog box for selecting the file is displayed.

Select the file to be registered. When the selected file is not registered, do not select the check box. In this case, the file is displayed in gray and is not registered.

Click the [OK] button. The system program is registered to the emulator. The file name that has been registered on the status bar is displayed. Then take the same procedure as for auto installation. When the [Cancel] button is clicked, the [Select Install] dialog box will be returned.

For error messages that are displayed during ESI operation, refer to the troubleshooting for the ESI help. To see the ESI help, select [Programs]-[SH7055 E8000 Emulator Software]-[Tools]-[System Install Tool Help] from the [Start] menu.

2.4 Checking the System

The next step is to check that the E8000 emulator and the HDI are initiated correctly.

- Turn on the E8000 emulator after confirming that the S7 and S8 DIP switches of SW1 on the E8000 emulator are turned on.
- Select [SH7055 E8000 Emulator Software] from the [Start] menu.




Figure 2.6 [Start] Menu

The [Select Session] dialog box will be displayed. Select the target emulator name in the combo box then click the [OK] button.




Figure 2.7 [Select Session] Dialog Box

When the HDI is started up for the first time, the [Driver Details] dialog box will be displayed. Use [Driver] to select the right driver for the connected interface (PC interface board, PCI interface board, PC interface card, USB adapter, or LAN adapter) to click the [Close] button. Refer to table 2.2, Types of Connections and Drivers. The example below is when the E8000 emulator is to be connected to the PC interface via the ISA bus.




Figure 2.8 [Driver Details] Dialog Box (When Selecting ISA Driver)

During the HDI initiation, the following messages are shown on the status bar of the HDI window.




Figure 2.9 Status Bar during the HDI Initiation

A message box will be displayed, as shown in figure 5.3, to ask whether to initiate the diagnostic program when [Diagnostic Test Program] has been selected in the component selection dialog box during installation. Click the [Yes] button to initiate the diagnostic program. For details, refer to section 5, Use of Diagnostic Program.

“Link up” appears on the status bar when the HDI has successfully started up.



Figure 2.10 Status Bar at the HDI Initiation Completion

2.5 Troubleshooting

2.5.1 Connection Error of the PC Interface Board

The HDI displays the following message box when the PC interface board for connecting to the emulator cannot be detected.



Figure 2.11 PC Interface Board Connection Error Message Box

The following causes can be considered:

- The memory area reserved in the CONFIG.SYS file differs from the setting of the rear-panel switch of the PC interface board.
- The selected memory area has already been used for another application.

2.5.2 Connection Error of the Emulator

The HDI displays the following message box when the emulator cannot be detected.




Figure 2.12 Emulator Connection Error Message Box

The following causes can be considered:

- An AC adapter power supply is not connected to the emulator, or the emulator is not switched on. Check the power LED of the emulator.
- The PC interface cable is not correctly connected between the PC interface board and the emulator.

2.6 Uninstallation

2.6.1 Uninstalling Software

This section describes the procedure for uninstalling software. Be sure to terminate all executing applications before uninstalling software.

1. Click [Settings]-[Control Panel] from the [Start] menu.
2. Double-click the [Add/Remove Programs] icon.
3. Click [SH7055 E8000 Emulator Software] from the [Install/Uninstalls] tab and double-click the [Add/Remove...] button.
4. Select [SH7055 E8000 Emulator Software] from the list box and click the [Add/Remove...] button.

The setup program is executed again to allow the modification, correction, or removal of the installed applications. Select removal to uninstall applications.

Note: Shared files may be detected during uninstallation. Do not remove shared files if they might be used by other HDIs. When Windows NT[®] 4.0 is used, you might be asked whether you want to remove information registered in the driver's registry. Do not remove information registered in the registry, if it might be used by other HDIs. If other HDIs will no longer start up because of uninstallation, reinstall the other HDIs.

2.6.2 Uninstalling the Acrobat[®] Reader[™]

Only uninstall the Acrobat[®] Reader[™] if it is necessary. Click [Settings]-[Control Panel] from the [Start] menu. Double-click the [Add/Remove Programs] icon. Click [Adobe Acrobat Reader x.x] from the list box on the [Install/Uninstall] tab page and click the [Add/Remove...] button. Follow the directions on the screen.

Section 3 Tutorial

3.1 Introduction

The following describes a sample program for sorting random data in order to introduce the main functions of the HDI.

The sample program performs the following actions:

- The main function generates 10 pieces of random data to be sorted.
- The sort function sorts the random data in ascending order.
- The change function changes the data in descending order.

Table 3.1 shows the configuration of the sample program.

Table 3.1 Configuration of Sample Program

No.	Item	Description
1	HEW workspace file*	\\HEW\HDI5\E8000\7055\TUTORIAL\TUTORIAL.HWS
2	ELF/DWARF2 load module	\\HEW\HDI5\E8000\7055\TUTORIAL\TUTORIAL\DEBUG\TUTORIAL.ABS
3	Source file (main program)	\\HEW\HDI5\E8000\7055\TUTORIAL\TUTORIAL\TUTORIAL.C

Note: The sample program is created using the SuperH RISC engine C/C++ compiler package (V6.0.0r1).

3.2 Running the HDI

To execute the HDI, select [SH7055 E8000 Emulator Software] – [Hitachi Debugging Interface] from the [Start] menu.




Figure 3.1 [Start] Menu

3.2.1 Selecting the Target Program

When the HDI is initiated, the dialog box for selecting the current session platform is displayed. Select E8000 SH7055 Emulator.




Figure 3.2 [Select Session] Dialog Box

The target platform can be selected by selecting [New Session...] from the [File] menu.

When the emulator is correctly set up, Link Up is displayed on the status bar and the HDI window will be displayed. The main functions of the HDI window are given below.




Figure 3.3 HDI Window

Numbers in figure 3.3 indicate the following:

1. Menu bar
Indicates the access to the HDI commands for the use of the HDI debugger.
2. Toolbar
Contains convenient buttons as shortcuts of menu commands most frequently used.
3. Status bar
Indicates the state of the emulator and progress information about downloading.
4. [Help] button
Activates the context-sensitive help concerning features of the HDI user interface.

3.3 Setting up the Emulator

The following MCU conditions must be set up before downloading the program:

- Device type
- Operating mode
- Operating clock
- Execution operating mode
- Memory map

The following describes how to set up the emulator correctly for the tutorial programs.

3.3.1 Setting the [Configuration] Dialog Box

Select [Configure Platform...] from the [Setup] menu to set configuration. The following dialog box is displayed:




Figure 3.4 [Configuration] Dialog Box

Set options as follows:

Table 3.2 Setting the [Configuration] Dialog Box

Page	Option	Value
[General] page	CPU operating mode [Mode]	Advanced Mode without Internal ROM (CS0 Area 8-bit bus)
	Emulation clock [Clock]	Emulator Clock (5 MHz) (using the emulator clock)
	Emulation mode [Emulation mode]	Normal (normal execution)
	Memory access enabled/disabled during execution [Prohibit R/W on the fly]	Enabled (no check)
[Execution Mode1] page	Program counter display interval [Execution status display interval]	About 200 ms (default setting)
	Timer resolution [The minimum time to be measured by Go command execution]	1.6 us (default setting)
	User-wait control [Enable user wait]	Valid (default setting)
	Multi-break function [Enable the multi break of External probe No. 1]	Invalid (default setting)
	BREQ signal control [Enable the BREQ signal input]	Invalid (default setting)
[Execution Mode2] page	Trigger output control 1 at break [TRGU Option]	Upper (default setting)
	Trigger output control 2 at break [TRGB Option]	Upper (default setting)

- Click the [OK] button to set any changes in the configuration.

3.3.2 Setting the Memory Map

In the next step, allocate the emulation memory for the developing application.

- Select [Memory Mapping Window] from the [View] menu to display the current memory map.

The [Memory Mapping] window is displayed.




Figure 3.5 [Memory Mapping] Window (Before Setting)

The emulator can allocate the optional memory area as one of the following five types:

Table 3.3 Memory Type

Memory Type	Description
USER AREA Read-Only	Sets the user memory area to be write-protected.
USER AREA Guarded	Sets the user memory area to be access-inhibited.
EMULATION AREA	Sets the address range of the emulation memory area.
EMULATION Read-Only	Sets the emulation memory area to be write-protected.
EMULATION Guarded	Sets the emulation memory area to be access-inhibited.

When the [Add] button is clicked, the [Edit Memory Mapping] dialog box is displayed.




Figure 3.6 [Edit Memory Mapping] Dialog Box

For this tutorial, allocate the memory area of addresses ranging from H'00000000 to H'003FFFFFF as an emulation memory area.

- Set the [From] and [To] edit boxes to H'00000000 and H'003FFFFFFF, respectively, set the [Setting] combo box to [EMULATION AREA], and click the [OK] button.

The [Memory Mapping] window will now show the modified ranges.




Figure 3.7 [Memory Mapping] Dialog Box (at Setting)

- Click the close box [X] in the upper-right corner of the [Memory Mapping] window to close the window.

3.4 Downloading the Tutorial Program

3.4.1 Downloading the Tutorial Program

Download the ELF/DWARF2 tutorial program.

- Select [Load Program...] from the [File] menu. The [Load Program] dialog box will be displayed.
- Select the [Browse...] button. The [Open] dialog box will be displayed.
- Select the file TUTORIAL.ABS and click the [Open] button.
- Click the [Open] button in the [Load Program] dialog box.




Figure 3.8 [Load Program] Dialog Box

When the file has been loaded, the following dialog box showing the loaded program address is displayed.




Figure 3.9 [HDI] Dialog Box

- Click the [Open] button to continue.

3.4.2 Displaying the Source Program

The [Source] window allows the user to debug a program at the source level, such as displaying the C/C++-language source program, setting the breakpoints, executing the program, and selecting variables in the [Source] window, so that the user can see a list of the C/C++ program alongside the machine code as the user debugs. To do this, the C/C++ source file that corresponds to the object file needs to be read.

- Select [Source] from the [View] menu. The [Open] dialog box will be displayed.




Figure 3.10 [Open] Dialog Box

- Select [tutorial.c] and click the [Open] button. The [Source] window is displayed.
- If necessary, select the [Font] option from the [Customize] submenu on the [Setup] menu to select a font and size suitable for the host computer.

The screenshot shows a window titled 'Tutorial.c' with a table of assembly addresses and their corresponding C source code. The table has four columns: Line, Address, BP, Label, and Source. The source code includes a main function and a sort function.

Line	Address	BP	Label	Source
24	00003000		_main	void main(void)
25				{
26				long a[10],min,max;
27				long j;
28				int i;
29				
30	00003002			for(i=0; i<10; i++){
31	0000300a			j = rand();
32	00003012			if(j < 0){
33	00003016			j = -j;
34				}
35	0000301a			a[i] = j;
36				}
37	00003036			sort(a);
38	0000303e			min = a[0];
39	00003042			max = a[9];
40	00003046			min = 0;
41	0000304a			max = 0;
42	0000304e			change(a);
43	00003056			min = a[9];
44	0000305a			max = a[0];
45	0000305e			while (1);
46				}
47				
48	0000306c		_sort	void sort(long *a)
49				{

Figure 3.11 [Source] Window (Displaying the Source Program)

3.5 Setting the Software Breakpoint

A breakpoint is one of the easy debugging functions.

The [Source] window provides a very simple way of setting a breakpoint at any point in a program. For example, to set a breakpoint at the sort function call:

- Double-click the [BP] column on the line containing the sort function call. The word Break will be displayed on the line containing the sort function to show that a software breakpoint is set at that address.




Figure 3.12 [Program] Window (Setting a Software Breakpoint)

Note: The software breakpoint cannot be set in the ROM area. (It can be set in the internal ROM area.)

3.6 Executing the Program

- To execute the program, select [ResetGo] from the [Run] menu, or click the [ResetGo] button on the toolbar.



Figure 3.13 [ResetGo] Button

The program will be executed up to the breakpoint that has been inserted, and a statement will be highlighted in the [Source] window to show the position that the program has halted.




Figure 3.14 [Source] Window (Break State)

The user can see the cause of the last break in the [System Status] window.

- Select [Status Window] from the [View] menu. The [System Status] window is displayed.
- Select the [Platform] sheet of the [System Status] window.




Figure 3.15 [System Status] Window

The [Cause of last break] line shows that the cause of the break is the breakpoint.

3.7 Reviewing Breakpoints

The user can see all the breakpoints set in the program in the [Breakpoints] window.

- Select [Breakpoints] from the [View] menu.




Figure 3.16 [Breakpoints] Window

The [Breakpoints] window also allows the user to set breakpoints, define new breakpoints, and delete breakpoints.

- Close the [Breakpoints] window.

3.8 Viewing Memory

The user can view the contents of a memory block in the [Memory] window. For example, to view the memory corresponding to the main function in word size:

- Select [Memory...] from the [View] menu. The [Open Memory Window] dialog box is displayed.
- Enter `main` in the [Address] edit box, and set the [Format] combo box as [Word].




Figure 3.17 [Open Memory Window] Dialog Box

- Click the [OK] button. The [Memory] window showing the specified area of memory is displayed.




Figure 3.18 [Word Memory] Window

3.9 Watching Variables

As the user steps through a program, it is possible to watch the values of variables used in the program. For example, set a watch on the long-type array `a` declared at the beginning of the program, by using the following procedure:

- Click the left of displayed array `a` in the [Source] window to position the cursor.
- Click the [Source] window with the right mouse button, and select [Instant Watch...] from a pop-up menu.

The following dialog box will be displayed.




Figure 3.19 [Instant Watch] Dialog Box

- Click the [Add Watch] button to add a variable to the [Watch] window.




Figure 3.20 [Watch] Window (Displaying the Array)

The user can also add a variable to the [Watch] window by specifying its name.

- Click the [Watch] window with the right mouse button and select [Add Watch] from the pop-up menu.

The following dialog box will be displayed.




Figure 3.21 [Add Watch] Dialog Box

- Input variable **max** and click the [OK] button.

The [Watch] window will now also show the long-type variable max.




Figure 3.22 [Watch] Window (Displaying the Variable)

Double-click the + symbol to the left of any variable in the [Watch] window to expand the variable and watch all the elements in the array.




Figure 3.23 [Watch] Window (Displaying Array Elements)


3.10 Stepping Through a Program

The HDI provides a range of step menu commands that allow efficient program debugging.

Table 3.4 Step Option

Menu Command	Description
Step In	Executes each statement within a function, or one instruction of the assembly language. (Stops execution at the top of the function call.)
Step Over	Executes a function in a single step, or one instruction of the assembly language. (A function call is executed in one step.)
Step Out	Steps out of a function, and stops at the next statement that called the function in the program.
Step...	Steps the specified counts repeatedly at a specified rate.

To demonstrate program stepping, confirm that the sort function statement at address H'00003036 has been executed.



Line	Address	BP	Label	Source
24	00003000		_main	void main(void)
25				{
26				long a[10],min,max;
27				long j;
28				int i;
29				
30	00003002			for(i=0; i<10; i++){
31	0000300a			j = rand();
32	00003012			if(j < 0){
33	00003016			j = -j;
34				}
35	0000301a			a[i] = j;
36				}
37	00003036	● Break		sort(a);
38	0000303e			min = a[0];
39	00003042			max = a[9];
40	00003046			min = 0;
41	0000304a			max = 0;
42	0000304e			change(a);
43	00003056			min = a[9];
44	0000305a			max = a[0];
45	0000305e			while (1);
46				}
47				
48	0000306c		_sort	void sort(long *a)
49				{

Figure 3.24 [Source] Window (Step Execution)

3.10.1 Executing [Step In] Command

The [Step In] steps into the called function and stops at the first statement of the called function.

- To step through the sort function, select [Step In] from the [Run] menu, or click the [Step In] button in the toolbar.



Figure 3.25 [Step In] Button




Figure 3.26 [Source] Window (Step In)

- The highlighted line moves to the first statement of the sort function in the [Source] window.

3.10.2 Executing [Step Out] Command

The [Step Out] command steps out of the called function and stops at the next statement of the sort calling statement.

- To step out of the `sort` function, select [Step Out] from the [Run] menu, or click the [Step Out] button in the toolbar.



Figure 3.27 [Step Out] Button




Figure 3.28 [Source] Window (Step Out)

- The data of variable `a` displayed in the [Watch] window is sorted in ascending order.

- To execute two steps, use [Step In] twice.




Figure 3.29 [Source] Window (Step Out -> Step In)

- The value of max displayed in the [Watch] window is changed to the maximum data value.

3.10.3 Executing [Step Over] Command

The [Step Over] executes a function call as a single step and stops at the next statement of the main program.

- To demonstrate the [Step Over] command, execute two steps to reach the change function statement.




Figure 3.30 [Source] Window (Before Step Over Execution)

To step through all statements in the change function at a single step, select [Step Over] from the [Run] menu, or click the [Step Over] button in the toolbar.



Figure 3.31 [Step Over] Button




Figure 3.32 [Source] Window (Step Over)

When the last statement of the change function is executed, the data of variable a, which is displayed in the [Watch] window, is sorted in descending order.

3.11 Displaying Local Variables

The user can display local variables in a function using the [Locals] window. For example, the local variables in the main function, which declares five local variables: a, j, i, min, and max, will be examined.

- Select [Local Variable Window] from the [View] menu.

The [Locals] window is displayed. Initially, the [Locals] window is empty because local variables have not yet been declared.

- Select [Step In] from the [Run] menu to execute a single step.

The [Locals] window will now show the local variables and their values.




Figure 3.33 [Locals] Window

- Double-click the + symbol to the left of array a in the [Locals] window to display the elements of array a.
- Refer to the elements of array a before and after the execution of the sort function, and confirm that random data is sorted in ascending or descending order.

3.12 Setting the Hardware Break Conditions

The emulator has powerful hardware break functions. In the HDI, these hardware break conditions can be set by using dialog boxes. The dialog boxes for setting hardware break conditions, and the corresponding break conditions, are described below.

Table 3.5 Dialog Boxes for Setting Hardware Break Conditions

Dialog Box	Function						
	Address Bus Condition (Address)	Data Bus Condition (Data)	Bus State Condition (Bus State)	External Probe Signal Condition (Probe)	Interrupt Signal Condition (Interrupt)	Satisfaction Count (Count)	DELAY Condition (Delay)*3
[Break Condition UBC1] dialog box	O	O	O	X	X	O	X
[Break Condition UBC2/3/4] dialog box	O	O	O	X	X	X	X
[Break Condition A] dialog box*2	O	O	O	O	O	X	X
[Break Condition B] dialog box*2	O	O	O	O	O	O	O
[Break Condition C] dialog box*2	O	X	O	X	X	X	X

Notes: 1. O: Can be set in the dialog box.

X: Cannot be set in the dialog box.

2. Eight break condition points can be set independently in each of the [Break Condition A/B/C] dialog boxes.
3. Only Break Condition B7 can be set for the DELAY condition in the [Break Condition B] dialog box.

Table 3.6 Main Break Conditions

Break Condition	Description
Address bus condition (Address)	Breaks on a match of the MCU address bus value.
Data bus condition (Data)	Breaks on a match of the MCU data bus value. Byte, word, or longword can be specified as the access data size and bus position.
Bus state condition (Bus State)	There are two bus state condition settings: Read/write condition: Breaks when the MCU RD or RDRW signal level matches the specified condition. Bus state condition: Breaks when the operating state in the MCU memory access cycle, DMA cycle, or vector fetch cycle matches the specified condition.
External probe signal condition (Probe)	Breaks when an external probe signal (PRB1 to PRB4) level matches the specified condition.
Interrupt signal condition (Interrupt)	Breaks when the NMI signal or an external interrupt signal (IRQ0 to IRQ7) level matches the specified condition.
Satisfaction Count (Count)	Breaks when all the above conditions have been satisfied the number of times specified in this condition. (A maximum count of 65,535 can be specified.)
DELAY condition (Delay)	Breaks when all the above conditions have been satisfied and the bus cycles specified in this condition have been executed. (A maximum of 32,767 bus cycles can be specified.)

An example is given below in which the address bus condition and read cycles for state condition are set in Break Condition A as hardware break conditions.

- Select [Breakpoints] from the [View] menu. The [Breakpoints] window is displayed.
- When the right button of the mouse is clicked in the [Breakpoints] window, a pop-up menu appears.
- Click the [Add] button.




Figure 3.34 [Breakpoints] Window (Before Hardware Break Condition Setting)

The [Break] dialog box is displayed. For hardware break conditions, the [Break] dialog box pages required for the setting must be selected.

- Select [Condition A] to display the [Condition A] page.




Figure 3.35 [Condition A] Page ([Break] Dialog Box)

Up to eight breakpoints can be set independently for the Break Condition A (B, C) hardware break conditions. In the example, one point is set for the Break Condition A hardware break conditions.

- Highlight the first point in the [Condition] list box.
- Click the [Edit...] button. The [Break Condition A1] dialog box is displayed.
- Make the [Don't Care] check box in the [Address] page invalid.
- Select the [Address] radio button and input address **H' 3058** as the value in the [Start] edit box.




Figure 3.36 [Address] Page ([Break Condition A1] Dialog Box)

- Select [Bus State] to display the [Bus State] page.
- Select the [Read] radio button.




Figure 3.37 [Bus State] Page ([Break Condition A1] Dialog Box)

- Click the [OK] button.
- The [Break] dialog box is displayed, and the first point display in the [Condition] list box changes from 'Empty' to 'address H'3058 direction read'.




Figure 3.38 [Break] Dialog Box (After Hardware Break Condition Setting)

- Click the [Close] button.

The newly set hardware breakpoint is displayed in the [Breakpoints] window. With this setting, 'Break Condition A1:Enable address H'3058 direction read' is displayed in [Type] in the [Breakpoints] window.

This completes the setting of the Break Condition A1 hardware break conditions. When the program is executed, a break will occur when address H'3058 is accessed in a read cycle.




Figure 3.39 [Breakpoints] Window ([Break Condition A] Setting)

3.13 Setting the Sequential Break Conditions

The emulator has powerful sequential break functions. In the HDI, these sequential break conditions can be set by using dialog boxes. The dialog boxes for setting sequential break conditions, and the corresponding sequential break functions, are described below.

Table 3.7 Dialog Boxes for Setting Sequential Break Conditions

Dialog Box	Function						
	Address Bus Condition (Address)	Data Bus Condition (Data)	Status Condition (Status)	External Probe Condition (Probe)	Interrupt Condition (Interrupt)	Satisfaction Count (Count)	DELAY Condition (Delay)
[Break Condition UBC1] dialog box	O	O	O	X	X	O	X
[Break Condition UBC2] dialog box	O	O	O	X	X	X	X
[Break Condition UBC3] dialog box	O	O	O	X	X	X	X
[Break Condition UBC4] dialog box	O	O	O	X	X	X	X
[Break Sequence] dialog box	O	X	X	X	X	X	X

Note: "O" indicates that relevant functions can be set in relevant dialog boxes, and "X" indicates that they cannot be set.

Table 3.8 Main Sequential Break Functions

Sequential Break Function	Description
Break Sequence	<p>A sequential break function using software breaks.</p> <p>Up to seven address points and one reset point address can be set. When all the set points are passed in sequence, the program is stopped.</p>
Break Condition UBC1,2,3,4	<p>Sequential break functions by combining satisfaction conditions of hardware break conditions, i.e., Break Condition UBC1, 2, 3 and 4. Combinations of the following satisfaction conditions can be selected:</p> <ul style="list-style-type: none">• Program execution is halted when conditions are satisfied in the order of UBC2 and UBC1. (Sequential break mode UBC 2 -> 1)• Program execution is halted when conditions are satisfied in the order of UBC3, UBC2 and UBC1. (Sequential break mode UBC 3 -> 2 -> 1)• Program execution is halted when conditions are satisfied in the order of UBC4, UBC3, UBC2 and UBC1. (Sequential break mode UBC 4 -> 3 -> 2 -> 1) <p>One point of reset point address can be set to the respective combinations.</p>

After passing the reset point addresses, these functions make sequential break conditions already passed so far invalid and resume checking break conditions from the first one.

As an example of a sequential break function, the case when sequential break mode UBC2 -> 1 is set is described below.

Before executing the program, change the [Configuration] dialog box. When not changing it, the sequential break does not function.

- Select [Configure Platform...] from the [Setup] menu, and the [Configuration] dialog box will appear.
- Select [Sequential break mode UBC2 -> 1] from the [Emulation Mode] combo box.




Figure 3.40 [Configuration] Dialog Box (When Sequential Break is Set)

An example is given below in which Break Condition Sequence is used as the sequential break function. Set break conditions as follows:

Break condition 1: A break is executed when address H'3056 is accessed in a read cycle. (Break Condition UBC1)

Break condition 2: A break is executed when address H'3046 is accessed in a read cycle. (Break Condition UBC2)

After Break Condition 2 is satisfied and Break Condition 1 is satisfied in succession, a program being executed will stop. Then, set the sequential break conditions.

- Select [Breakpoints] from the [View] menu.

The [Breakpoints] window is displayed.

- When the right button of the mouse is clicked in the [Breakpoints] window, a pop-up menu appears. Select [Delete All] and cancel all the breakpoints that have been set.
- Display a pop-up menu again and select [Add...]. The [Break] dialog box is displayed.




Figure 3.41 [Breakpoints] Window (Before Sequential Break Conditions Setting)

The [Break] dialog box appears. To set sequential break conditions, select [Condition UBC] and display the [Condition UBC] page.




Figure 3.42 [Break] Dialog Box ([Break Condition UBC] Page)

Set Break Condition 2 of the sequential break conditions to Break Condition UBC2 and set Break Condition 1 to Break Condition UBC1.

- Highlight the second line in the [Condition] list box.
- Click the [Edit] button.

The [Break Condition UBC2] dialog box will appear.

- Make the [Don't Care] check box in the [Address] page invalid.
- Select the [Address] radio button and enter the address **H'3046** as the value in the [Start] edit box.




Figure 3.43 [Break Condition UBC2] Dialog Box (Condition 2 [Address] Page)

- Select [Bus State] to display the [Bus State] page.
- Select [Read] radio button.




Figure 3.44 [Break Condition UBC2] Dialog Box (Condition 2 [Bus State] Page)

- Click the [OK] button.
- The [Break] dialog box is displayed, and the second point display in the [Condition] list box changes from Empty to address H'3046 direction read.




Figure 3.45 [Break] Dialog Box (After [Break Condition UBC2] Condition Setting)

This completes the setting of break condition 2. Next, set break condition 1 as follows:

- Highlight the first point in the [Condition] list box.
- Click the [Edit...] button.

The [Break Condition UBC1] dialog box is displayed.

The setting can then be made in the same way as for break condition 1.

- After setting break conditions 1 and 2, click the [Close] button.

Break Condition UBC1 and Break Condition UBC2 are displayed in [Type] in the [Breakpoints] window.




Figure 3.46 [Breakpoints] Window (After Sequential Break Condition Setting)

- Click the [ResetGo] button.

The program is executed up to the conditions of Break Condition UBC1 and comes to a halt.

Line	Address	BP	Label	Source
24	00003000		_main	void main(void)
25				{
26				long a[10],min,max;
27				long j;
28				int i;
29				
30	00003002			for(i=0; i<10; i++
31	0000300a			j = rand();
32	00003012			if(j < 0){
33	00003016			j = -j;
34				}
35	0000301a			a[i] = j;
36				}
37	00003036			sort(a);
38	0000303e			min = a[0];
39	00003042			max = a[9];
40	00003046			min = 0;
41	0000304a			max = 0;
42	0000304e			change(a);
43	00003056			min = a[9];
44	0000305a			max = a[0];
45	0000305e			while (1);
46				}
47				
48	0000306c		_sort	void sort(long *a)

Figure 3.47 [Program] Window at Execution Halt (Sequential Break)

The contents of the [System Status] window are as follows:

Item	Status
Connected To:	E8000 SH7055 Emulator
CPU	SH7055
Mode	Advanced Mode without Internal ROM(CS0 Area 8-bit bu
Clock source	Emulator Clock (5MHz)
Run status	Break
Cause of last break	BREAK CONDITION SB

Session Platform Memory Events


Figure 3.48 Contents of [System Status] Window (Sequential Break)

3.14 Using the Trace Buffer

3.14.1 Displaying the Trace Buffer

Using the trace buffer, it is possible to verify execution results upstream of the MCU cycles.

- Select [Trace] from the [View] menu to open the [Trace] window.
- If necessary, adjust the column width by dragging the column divider beside the label immediately below the title bar.



Cycle	Label	PC	Code	AB	DB	Area	R/W
-000032				0000312b	*****d0	EXT	R
-000031				0000303c	*****00	EXT	R
-000030				0000303d	*****09	EXT	R
-000029		0000303e	MOV.L @(H'10:4,R15),R3	0000303e	*****53	EXT	R
-000028				0000303f	*****f4	EXT	R
-000027		00003040	MOV.L R3,@(H'0C:4,R15)	00003040	*****1f	EXT	R
-000026				00003041	*****33	EXT	R
-000025		00003042	MOV.L @(H'34:4,R15),R2	00003042	*****52	EXT	R
-000024				00003043	*****fd	EXT	R
-000023				003fffc8	*****00	EXT	R
-000022				003fffc9	*****00	EXT	R
-000021				003ffcca	*****65	EXT	R
-000020				003ffccb	*****d8	EXT	R
-000019		00003044	MOV.L R2,@(H'08:4,R15)	00003044	*****1f	EXT	R
-000018				00003045	*****22	EXT	R
-000017		00003046	.DATA.W H'0000	00003046	*****00	EXT	R
-000016				00003047	*****00	EXT	R

Figure 3.49 [Trace] Window (Free Trace Results)

3.14.2 Setting the Trace Filter

In a free trace, the [Trace] window displays all the MCU cycles. By setting the specific search condition, it is possible to display only the trace contents that match the search condition in the [Trace] window.

Table 3.9 Main Trace Search Conditions

Break Condition	Description
Address bus condition (Address)	Searches for an item that matches the MCU address bus value.
Data bus condition (Data)	Searches for an item that matches the MCU data bus value. Access data size (byte, word, or longword) and data bus location can be specified.
Bus state condition (Bus & Area)	There are three bus state condition settings: Read/write condition: Searches for an item for which the MCU RD or RDRW signal level matches the specified condition. Bus state condition: Searches for an item for which the conditions of MCU memory access cycle, DMA cycle, or vector fetch cycle match the specified condition. Area condition: Searches for an item for which the memory space accessed in an MCU bus cycle matches the specified condition.
External probe signal condition (Probe)	Searches for an item for which an external probe signal (PRB1 to PRB4) level matches the specified condition.
Interrupt signal condition (Interrupt)	Searches for an item for which the levels of the NMI signal, external interrupt signals (IRQ0 to IRQ7), and the RESET signal matches the specified condition.
Time condition (Time)	Searches for an item for which the time stamp value or range matches the specified condition.

Click the right mouse button on the [Trace] window, and select [Filter...] from the pop-up menu.

The [Trace Filter] dialog box then appears.

The filter conditions that limit the cycles to be displayed in the trace buffer can then be set.

- Select the [Pattern] radio button in [Type].




Figure 3.50 [General] Page ([Trace Filter] Dialog Box)

- Select [Address] to display the [Address] page.

- Clear the [Don't Care] check box in the [Address] page.
- Select [Address] and input address H'3042 as the value in the [Start] edit box.




Figure 3.51 [Address] Page ([Trace Filter] Dialog Box)

- Select [Bus & Area] to display the [Bus & Area] page.

- Select the [Read] radio button.




Figure 3.52 [Bus & Area] Page ([Trace Filter] Dialog Box)

- Click the [OK] button to save the trace filter.




Figure 3.53 [Trace] Window (Trace Filter Results)

3.15 Trace Acquisition Condition Setting

The emulator has powerful realtime trace functions. Trace information for up to 131,070 bus cycles can be acquired. In the HDI, trace acquisition conditions can be set by using dialog boxes. The dialog boxes for setting trace acquisition conditions and the corresponding trace acquisition conditions are described below.

Table 3.10 Dialog Boxes for Setting Trace Acquisition Conditions

Dialog Box	Function			
	Subroutine Trace	Range Trace	Trace Stop	Subroutine Range Trace
[Trace Condition A] dialog box	X	O	O	X
[Trace Condition B] dialog box	O	O	O	O
[Trace Condition C] dialog box	O	O	O	X

Note: O: Can be set in the dialog box.

X: Cannot be set in the dialog box.

Table 3.11 Main Trace Acquisition Conditions

Trace Acquisition Condition	Description
Free trace	Acquires trace information continuously from the start of execution of the user program until the program breaks. If Trace Conditions A,B,C is not set, this mode is entered.
Subroutine trace	Performs trace acquisition of instructions or operand accesses between the start address and end address of the specific subroutine with Trace Condition B,C.
Range trace	Performs trace acquisition only for places where the condition specified by Trace Condition A,B,C is satisfied. Specifiable conditions are: Address bus condition Data bus condition Read/write condition Bus state condition (DMA cycle, execution cycle, and vector fetch cycle) System control signal (BREQ) External probe condition
Trace stop	Stops trace acquisition when the condition specified by Trace Condition A,B,C is satisfied. Specifiable conditions are: Address bus condition Data bus condition Read/write condition Bus state condition (DMA cycle, execution cycle, vector fetch cycle) System control signal (BREQ) External probe condition DELAY condition
Subroutine range trace	Performs trace acquisition only for places where a subroutine instruction and an operand that have been specified by Trace Condition B are accessed, and that the condition is satisfied.

An example is given below in which trace stop mode (in which address bus condition and read cycles for bus state condition are set) is selected for Trace Condition A as the trace acquisition condition.

- Click the right mouse button on the [Trace] window. The pop-up menu is displayed.

- Select [Acquisition] from the pop-up menu to display the [Trace Acquisition] dialog box.




Figure 3.54 [Trace Acquisition] Dialog Box

For trace acquisition conditions, the [Trace Acquisition] dialog box pages required for the setting must be selected.

- Select [Condition A] to display the [Condition A] page.




Figure 3.55 [Condition A] Page ([Trace Acquisition] Dialog Box)

- Highlight the first point in the [Condition] list box.
- Click the [Edit] button.
- The [Trace Condition A1] dialog box is displayed.




Figure 3.56 [General] Page ([Trace Condition A1] Dialog Box)

- Select [Trace Stop] radio button as [Mode] in the [General] page.
- Select [Address] to display the [Address] page.
- Clear the [Don't Care] check box in the [Address] page.
- Select the [Address] radio button and input **H'3046** as the value in the [Start] edit box.




Figure 3.57 [Address] Page ([Trace Condition A1] Dialog Box)

- Select [Bus State] to display the [Bus State] page.
- Select [Read] radio button.




Figure 3.58 [Bus State] Page ([Trace Condition A1] Dialog Box)

- Click the [OK] button.
- The [Trace Acquisition] dialog box is displayed, and the first point display in the [Condition] list box changes from 'Empty' to 'type stop address H'3046 direction read'.




Figure 3.59 [Condition A] Page ([Trace Acquisition] Dialog Box)

This completes the setting of the Trace Condition A1 trace acquisition condition. When the program is executed, trace acquisition will stop when address H'3046 is accessed in a read cycle.

3.16 Saving the Session

Saving the present debugging session before quitting will allow debugging to be resumed from the same state in the next session.

Select [Exit] from the [File] menu to exit the HDI. At this time, a window for specifying the file name is displayed. Input the session file name in the window and click the [OK] button.

3.17 What Next?

This tutorial has described the major features of the emulator and the use of the HDI.

Sophisticated debugging can be carried out by using the emulator in combination with the emulation tools it offers. This provides for effective investigation of hardware and software problems by accurately isolating the conditions under which such problems arise.

Further details on the use of the HDI can be found in the Hitachi Debugging Interface User's Manual on the CD-R.

Section 4 Function

4.1 Windows and Dialog Boxes

Table 4.1 shows the SH7055 E8000 HDI-specific windows and dialog boxes. For more information, see the online-help. To see the online-help, select [Index] in the [Help] menu, or click [Help] button. Also the related commands in "The E8000 emulator user's manual" are described in it.

Table 4.1 List of Windows and Dialog boxes in the SH7055 E8000 HDI

Category	Name of Window and Dialog box	Description	Related E8000 commands
Emulation condition	[System Status] window	It displays the set-up condition and the program execution time of the emulation-associated functions in the emulator.	CLOCK, EXECUTE_MODE, GO, MODE
	[Configuration] dialog box	It sets the emulation condition in the emulator.	CLOCK, EXECUTE_MODE, GO, MODE
Break condition	[Breakpoint] window	It lists the all break conditions having been set up.	BREAK, BREAK_SEQUENCE, BREAK_CONDITION_A, BREAK_CONDITION_B, BREAK_CONDITION_C, BREAK_CONDITION_UBC
	[Break] dialog box	It displays the set-up state of each break condition.	BREAK, BREAK_SEQUENCE, BREAK_CONDITION_A, BREAK_CONDITION_B, BREAK_CONDITION_C, BREAK_CONDITION_UBC
	[Breakpoint] dialog box	It can set up to 256 software breakpoints.	BREAK

Table 4.1 List of Windows and Dialog boxes in the SH7055 E8000 HDI (cont)

Category	Name of Window and Dialog box	Description	Related E8000 commands
Break condition	[Break Sequence] dialog box	It can set the software sequential break with up to seven passing points and one reset point.	BREAK_SEQUENCE
	[Break Condition A] dialog box [Break Condition B] dialog box [Break Condition C] dialog box	Each can set up to eight hardware break conditions.	BREAK_CONDITION_A, BREAK_CONDITION_B, BREAK_CONDITION_C
	[Break Condition UBC] dialog box	It can set up to four UBC hardware break conditions.	BREAK_CONDITION_UBC
	[Break Condition UBC Reset] dialog box	It can set a reset point of a sequential break with UBC.	BREAK_CONDITION_UBC
Trace condition	[Trace] window	It displays the contents of the Trace buffer.	TRACE, TRACE_SEARCH, TRACE_CONDITION_A, TRACE_CONDITION_B, TRACE_CONDITION_C, TRACE_MODE
	[Trace Acquisition] dialog box	It sets trace acquisition conditions and displays the setting state.	TRACE_CONDITION_A, TRACE_CONDITION_B, TRACE_CONDITION_C
	[Trace Condition A] dialog box [Trace Condition B] dialog box [Trace Condition C] dialog box	Each can set up to eight acquisition condition of the trace information.	TRACE_CONDITION_A, TRACE_CONDITION_B, TRACE_CONDITION_C
	[Trace Filter] dialog box	It only displays the trace result which matches the condition having been set up, among the results displayed in the [Trace] window.	TRACE_SEARCH
	[Trace Find] dialog box	It can search the trace result which matches the condition having been set up, among the trace results displayed in the [Trace] window.	TRACE_SEARCH

Table 4.1 List of Windows and Dialog boxes in the SH7055 E8000 HDI (cont)

Category	Name of Window and Dialog box	Description	Related E8000 commands
Memory map	[Memory Mapping] window	It can display and edit the information about the emulation memory allocation.	MAP
	[Edit Memory Mapping] dialog box	It can set and modify the information about the emulation memory allocation.	MAP

4.2 Command Descriptions

The SH7055 E8000 HDI-specific commands are shown in table 4.2. For more information, see the online-help. To see the online-help, select [Index] in the [Help] menu, or execute the HELP command from the [Command Line] window.

Example

To open the online-help related to the BREAKPOINT command:

```
help BREAKPOINT (RET)
```

Table 4.2 SH7055 E8000 HDI Commands

No	Command	Abb.	Function	Related E8000 Commands
1	BKGRND_INT	BI	Sets and displays the user interrupt receive function during a command-wait state.	BACKGROUND_INTERRUPT
2	BREAKCONDITION_CLEAR	BCC	Clears hardware breakpoints (break conditions) that have been set.	BREAK_CONDITION_A,B,C
3	BREAKCONDITION_DISPLAY	BCD	Displays hardware breakpoints (break conditions) that have been set.	BREAK_CONDITION_A,B,C
4	BREAKCONDITION_ENABLE	BCE	Enables or disables hardware breakpoins (break conditions) that have been set.	BREAK_CONDITION_A,B,C
5	BREAKCONDITION_SET	BCS	Sets hardware breakpoints (break conditions) that have been set.	BREAK_CONDITION_A,B,C
6	BREAKSEQUENCE_CLEAR	BSC	Clears software sequential breakpoints that have been set.	BREAK_SEQUENCE
7	BREAKSEQUENCE_DISPLAY	BSD	Displays software sequential breakpoints that have been set.	BREAK_SEQUENCE
8	BREAKSEQUENCE_ENABLE	BSE	Enables or disables software sequential breakpoints that have been set.	BREAK_SEQUENCE
9	BREAKSEQUENCE_SET	BSS	Sets software sequential breakpoints.	BREAK_SEQUENCE
10	BREAKPOINT	BP	Sets software breakpoints.	BREAK
11	BREAKPOINT_CLEAR	BC	Clears software breakpoints that have been set.	BREAK
12	BREAKPOINT_DISPLAY	BD	Displays software breakpoints that have been set.	BREAK
13	BREAKPOINT_ENABLE	BE	Enables or disables software breakpoints that have been set.	BREAK

Table 4.2 SH7055 E8000 HDI Commands (cont)

No	Command	Abb.	Function	Related E8000 Commands
14	CLOCK	CK	Selects a CLOCK signal used by the SH7055.	CLOCK
15	COVERAGE_CLEAR	CVC	Initialize the coverage trace.	SET_COVERAGE
16	COVERAGE_DISPLAY	CVD	Display the result of coverage trace.	DISPLAY_COVERAGE
17	COVERAGE_SET	CVS	Display the range of coverage trace.	SET_COVERAGE
18	DEVICE_TYPE	DE	Displays the MCU type currently selected.	None
19	END	END	Returns to a user program execution state when the emulator enters the parallel mode due to trace condition satisfaction.	END
20	EXECUTION_MODE	EM	Sets debugging conditions during user program execution.	EXECUTE_MODE
21	GO_OPTION	GP	Sets the emulation mode during user program execution.	GO
22	ID	ID	Displays an emulator type and a version number.	ID
23	MAP_SET	MS	Sets emulator memory-map.	MAP
24	MODE	MO	Selects emulator mode.	MODE
25	MOVE_TO_RAM	MR	Stores a user program on ROM into RAM.	MOVE_TO_RAM
26	PERFORMANCE_ANALYSIS	PA	Displays program execution state.	PERFORMANCE_ANALYSIS1 to 8
27	PERFORMANCE_CLEAR	PC	Clears performance conditions that have been set.	PERFORMANCE_ANALYSIS1 to 8
28	PERFORMANCE_SET	PS	Sets performance conditions.	PERFORMANCE_ANALYSIS1 to 8
29	STATUS	STS	Displays emulator state information.	None

Table 4.2 SH7055 E8000 HDI Commands (cont)

No	Command	Abb.	Function	Related E8000 Commands
30	TRACEACQUISITION_CLEAR	TAC	Clears trace conditions that have been set.	TRACE_CONDITION_A,B,C TRACE_SEQUENCE
31	TRACEACQUISITION_DISPLAY	TAD	Displays trace conditions that have been set.	TRACE_CONDITION_A,B,C TRACE_SEQUENCE
32	TRACEACQUISITION_SET	TAS	Sets trace conditions that acquire trace information.	TRACE_CONDITION_A,B,C TRACE_SEQUENCE
33	TRACE_DISPLAY	TD	Display the acquisition of trace information.	TRACE
34	TRACE_MODE	TM	Sets the trace information acquisition mode.	TRACE_MODE
35	TRACE_SEARCH	TS	Searches for information corresponding to acquired trace information.	TRACE_SEARCH
36	UBC_CLEAR	UBC	Clears UBC breakpoints that have been set.	BREAK_CONDITION_UBC
37	UBC_DISPLAY	UBD	Displays UBC breakpoints that have been set.	BREAK_CONDITION_UBC
38	UBC_ENABLE	UBE	Enables or disables UBC breakpoints that have been set.	BREAK_CONDITION_UBC
39	UBC_SET	UBS	Sets UBC breakpoints.	BREAK_CONDITION_UBC

Section 5 Use of Diagnostic Program

5.1 Diagnostic Program Operation

An E8000 emulator diagnostic program can be used on the HDI. The installation procedure and operating details of diagnostic program are given in the SH7055 E8000 Emulator Diagnostic Program Operation Manual. This section describes how to run the diagnostic program on the HDI.

5.1.1 Diagnostic Program Installation on the HDI

To use the diagnostic program, the [Yes] button must be clicked in the dialog box displayed when installing the HDI in order to install the diagnostic program.




Figure 5.1 HDI Installation Dialog Box

5.1.2 TARGET.INI File Setting

In HDI installation, a file named TARGET.INI is created. This file contains resource information indicating whether or not the diagnostic program is to be started when the HDI is activated.

```
[E8000 HDI TARGET]
Diagnostic Program=Y
```

Figure 5.2 Example of TARGET.INI File Display

If the diagnostic program is to be run when the HDI is activated, set the “Diagnostic Program” resource information in the TARGET.INI file as follows:

```
Diagnostic Program=Y
```

Diagnostic Program=Y is set in the default TARGET.INI file.

If the diagnostic program is not to be run, change the setting as follows:

Diagnostic Program=N

5.1.3 Diagnostic Program Start-Up

When the HDI is activated, the following dialog box is displayed.




Figure 5.3 Diagnostic Program Start-Up Confirmation Dialog Box

When the [Yes] button is clicked, the diagnostic program is started and the following window is displayed.




Figure 5.4 Diagnostic Program Start-Up Window

- Display area
Displays the diagnostic program test results.
- [COMMAND] edit box
For input of a diagnostic program operation command.
- [STOP] button
Stops the diagnostic program test and switches to the diagnostic program operation command input mode.
- [END] button
Terminates the diagnostic program and activates the HDI.

5.1.4 Diagnostic Program Termination

To terminate the diagnostic program, either click the [END] button or else click the [STOP] button to stop the test and then enter Q in the [COMMAND] edit box.




Figure 5.5 Diagnostic Program Termination

Note: The diagnostic program can only be terminated when waiting for user input.

Section 6 Error Messages

6.1 Error Messages

The HDI outputs error messages to notify the user of operating errors. The error messages output by the HDI are shown in table 6.1.

Table 6.1 Error Messages

Message	Cause and Countermeasure
Can not set target configuration (Clock mode option)	A mode in which the emulator is not supported has been selected in [Clock] in the [Configuration] window.
Can not set target configuration (CPU mode option)	A mode in which the emulator is not supported has been selected in [CPU mode] in the [Configuration] window.
Can not set target configuration (Execution mode option)	A mode in which the emulator is not supported has been selected in [Execution mode] in the [Configuration] window.
Cannot use command when user program executing	Command line input has been performed when a command cannot be issued to the emulator. Wait for processing to finish.
Command timeout	The HDI has timed out because no response has been received from the emulator after the HDI issued a command. Terminate the HDI, power on the emulator, and restart the HDI.
Emulator command send/receive check error	Communication with the emulator was not performed correctly on HDI activation. Terminate the HDI, power on the emulator, and restart the HDI. If the illegal communication is not corrected, inform a Hitachi sales representative or agency of the situation.
Emulator firmware not ready	“EMULATOR FIRMWARE NOT READY” is output from the emulator. Terminate the HDI and check whether the emulator is functioning normally.
Emulator timeout	A timeout message has been detected from the emulator. Terminate the HDI and check whether the emulator is functioning normally.
Failed to find matching trace record	The HDI has failed in searching for trace information. This message is also output when there is no trace information.

Table 6.1 Error Messages (cont)

Message	Cause and Countermeasure
Hardware register read/write check error	An error was detected when the emulator hardware registers were tested. Check whether the emulator is functioning normally.
Invalid version number in target configuration	The current e8705532.dll version is different from the version when the session file was created. Invalid the low version number of session file.
System ID error	An emulator different from the SH7055 E8000 emulator is connected. Check the SH7055 E8000 emulator connection to the host computer.
Target internal error	Commands cannot be issued to the emulator. Wait for processing to finish.
User system not ready	“No clock” has been detected. The HDI is terminated.