

MULTI CONTROLER USER MANUAL

HLDC-15A




- (1) PV:
①normal mode : present value.
②parameter mode : parameter name.
- (2) SV:
①normal mode :Setting value.
②parameter mode : parameter value.
③manual output mode : manual output%.
- (3) UNIT : Temperature or parameter unit
- (4) F Key : parameter level and parameter select key.
- (5) Set key : Set enable and digital shift key.
- (6) Decrement key : Setting number decrease.
- (7) Increment key : Setting number increase.
- (8) Auto/Manual mode key.
- (9) Output indicator : Light up when instrument output.
- (10) Alarm indicator : Light up when alarm happen.
- (11) Fuse 1 indicator : Light up when fuse 1 break.
- (12) Fuse 2 indicator : Light up when fuse 2 break.
- (13) Manual mode indicator : Light up when instrument is in manual mode.
- (14) Sensor input indicator : Light up when K type was selected.
- (15) PID tuning indicator : In PID tuning progress indicator flash.
- (16) SV2 indicator Execute SV2.
- (17) Power switch.

1-4-2 Operation modes

TC5E divide into Main mode and parameter mode. In main mode, press could entry parameter mode.

Main mode : Controller display PV and SV use for SV modification.

Parameter mode: Controller display parameter name and its value. use for value modification




1-4-3 Control modes

Auto mode The instrument make temperature control.

Manual mode : The instrument follow parameter NoP and make output.
(UNIT field display "P")

manual /auto mode change :



Exchange SV1 and SV2


≡ +Δ+3sec : SV1 temperature control.

≡ +Δ+3sec : SV2temperatyre control.

※ Execute SV2temperature control indicator flash.

(Refer 1-3-1faceplate description)

1-4-4 process control



1-4-5 Error message

(1)---: Input break.

(2) : Input reverse

1-4-6 Wiring

