

AGS SERIES

ELECTRONIC WEIGHING SCALE

OPERATION MANUAL

PLEASE READ THIS MANUAL VERY CAREFULLY
BEFORE ATTEMPT TO OPERATE THE SCALE

Specifications subject to change without prior notice

CONTENTS

CAUTIONS

1. INSTALLATION
2. SPECIFICATIONS
3. KEYBOARD LAYOUT AND DESCRIPTION
4. INITIAL SETUP
5. INSTRUCTION FOR USE
6. TROUBLE SHOOTING
7. DAILY CARE AND MAINTENANCE

CAUTIONS

1. This unit is legal for trade only when it is sealed (and/or stamped) and bearing a serial number. Do not attempt to break the seal (or stamp) affixed to this scale or remove the serial number. Contact your dealer for more information and after sales service.
2. For most accurate weighing result, do not use this scale in where or when the environment condition falls beyond as those listed on **SPECIFICATIONS**.
3. Do not attempt to open this unit or conduct any trouble shootings other than those listed on **TROUBLE SHOOTING**.
4. Do not use this scale for chemical substances or in any environment that contains chemical vapor.
5. Precision measuring instrument, handle with care.
6. Do not open scale. No user serviceable parts inside.

1. INSTALLATION

- 1.1 Check and make sure that the following accessories are included:
 - Operation Manual x 1
 - Scale x 1
 - Stainless steel platter x 1
 - Power adaptor x 1
 - Dust Cover x 1Contact your dealer if any item is missing.
- 1.2 Place the stainless steel platter on the scale.
- 1.3 Power on the scale
 - a. Before charging the scale or power on with the adaptor supplied. Please make sure the input voltage listed on the back of the adaptor matches with the local voltage. If not, do not use it and contact your dealer immediately.
 - b. Before first time use, charge the scale for at least 8 hours to ensure the best performance.

2. SPECIFICATIONS

Model No.	Capacity (Max)	Division (e)		
		OIML	Non-OIML	Extended
AGS-1500	1500g	0.5g	0.2g	0.05g
AGS-3000	3000g	1g	0.5g	0.1g
AGS-6000	6000g	2g	1g	0.2g
AGS-15K	15kg	0.005kg	0.002kg	0.0005kg
AGS-30K	30kg	0.01kg	0.005kg	0.001kg
Tare Range	Full Tare Range			
Power-on Zero Range	±10% Max			
Zero Range	±2% Max			
Min. Load	20e*			
Power Source	By Built-in Rechargeable Battery or AD/DC Power Adaptor			
Operating Environment	0°~40°C (32°~104°F), Non-condensed. R.H. ≤85%			

Specifications subject to change without notice

NOTE 1:


OIML = Legal for trade (1/3000)

Non-OIML = Not legal for trade (1/6000~1/7500)

NOTE 2:

Extended Display Function does not support avoirdupois weight units (lb/lb and lb/oz)

3. KEYBOARD LAYOUT AND DESCRIPTION



1. OFF KEY

Press this key to turn scale off

2. ON/ZERO KEY

Press this key to turn scale on or set weight to zero

3. MODE KEY

Press this key to shift among different weight units and/or turn backlight on/off

4. TARE KEY

Press this key to tare off the weight of a container.

5. FUNCTION KEY

Press this key to enter counting function or percentage function

6. SAMPLE KEY

Press this key to sample the weight place on the platter and engage the counting function or percentage function

7. MODE INDICATOR

This indicator shows current weight unit or operating mode engaged

8. ZERO INDICATOR

This indicator appears to indicate a zero weight status

9. NET INDICATOR

This indicator appears to indicate the tare function is in operation and weight displayed is net weight

10. LO-BAT INDICATOR

When this indicator appears, recharge the scale immediately. Failure to do so may cause unrecoverable damage to the rechargeable battery inside scale

4. INITIAL SETUP

4.1 PLACING THE SCALE

In order to obtain an accurate weighing result, the scale must be placed on a strong and level surface.

If required, adjust the adjustable feet underneath scale to obtain a level position. Refer to the bubble indicator for leveling condition.

4.2 INTERNAL SETTING

4.2.1 Display Segment Check

User can enter this function to check to see if the display and backlight (if purchased) are functioning properly.

- a. Scale is off
- b. Press and hold **TARE**, then press **ON/ZERO**
- c. Scale displays **F.1**
- d. Press **TARE** once
- e. Scale displays **F.2**
- f. Press **MODE** and all segments will light up to allow user to check the condition of display
- g. Press **TARE** for next function setup or **ON/ZERO** to restart the scale

4.2.2 Select Auto Power Off Setting

The scale is equipped with **Auto Power Off Function**. The scale will power off automatically if it is not used for 4 minutes. Follow the below steps to enable/disable **Auto Power Off Function**.

- a. Scale is off
- b. Press and hold **TARE**, then press **ON/ZERO**
- c. Scale displays **F.1**
- d. Press **TARE** three times
- e. Scale displays **F.4**
- f. Press **MODE** to shift between **0._OFF** and **4._OFF**
 - To enable **Auto Power Off Function**, press **TARE** when **4._OFF** appears
 - To disable **Auto Power Off Function**, press **TARE** when **0._OFF** appears
- g. Press **ON/ZERO** to restart the scale or **TARE** for next function setup

4.2.3 Select Auto Tare Function

This scale is equipped with auto tare function which tares off the initial weight automatically when this function is engaged. The tare weight is automatically cleared when everything is removed from platter.

- a. Scale is off
- b. Press and hold **TARE**, then press **ON/ZERO**
- c. Scale displays **F.1**

- d. Press **TARE** six times
- e. Scale displays **F.9**
- f. Press **MODE** to select between “Tr_on” or “TroFF”
 - To enable **Auto Tare Function**, press **TARE** when **Tr_on** appears
 - To disable **Auto Tare Function**, press **TARE** when **TroFF** appears
- g. Press **ON/ZERO** to confirm and restart the scale or **TARE** for next function setup

5. INSTRUCTION FOR USE

5.1 BEFORE WEIGHING

Make sure that:

- a. The stainless steel platter is placed correctly on top of load receptor.
- b. The scale is placed on a level and strong surface.
- c. The scale is turned on.
- d. The **ZERO INDICATOR** is on. If not, press **ON/ZERO** to set display to zero.

5.2 WEIGHING

- a. Always place an object onto the platter gently. Excessive force applied to platter may cause damages to sensor inside scale.
- b. The weight of the object would be displayed automatically.
- c. It is a good practice to remove all loads from platter after weighing. It would prolong the lifetime of scale.

5.3 SELECT WEIGHT UNIT

Press **MODE** to shift between metric or avoirdupois weight units. The weight unit used before power off would be employed when the scale

is turned on again.

NOTE:

To comply with the law of certain countries and certain approval requirements, the avoirdupois weight units may be disabled. Contact your dealer for more information.

5.4 SET BACKLIGHT

Follow the below steps to turn on and off backlight (if purchased).

- a. Scale is on
- b. Press and hold **ON/ZERO** until backlight is activated; or press **MODE** to shift between metric and avoirdupois weight to turn on and off backlight

5.5 SMART POWER SAVING FUNCTION

The backlight function will turn off when constant/zero weight is detected and remains stable for about 20/10 seconds.

Backlight will be automatically turned on again when a new weight is detected.

5.6 SET DISPLAYED VALUE TO ZERO WHEN UNLOADED

By pressing **ON/ZERO**, a positive or negative weight displayed will be set to zero and **ZERO INDICATOR** appears.

Refer to **SPECIFICATIONS** for maximum zero range.

NOTE:

-When scale is set at OIML and application is legal for trade. User only needs to press **ON/ZERO** once when setting the value to zero.

The re-zero function will take place when reading is stabled

-When scale is set at Non-OIML and application is not legal for trade.

User can set the value to zero at anytime when pressing **ON/ZERO**

5.7 TARE OFF THE WEIGHT OF A CONTAINER

When a container is used, follow the below steps to manually tare off the weight of container and get the net weight.

- a. Remove all loads away from platter
- b. Make sure that the **ZERO INDICATOR** is on
- c. Place the container on the platter
- d. Press **TARE**

After **TARE** is pressed, the **NET INDICATOR** would appear.

Refer to **5.2** for weighing procedures. Weight displayed under is the net weight of the subject matter. Refer to **SPECIFICATIONS** for maximum tare range.

NOTE:

- When scale is set at OIML and application is legal for trade. User

only needs to press **TARE** once when tare off a weight. The tare function will take place when reading is stabled

- When scale is set at Non-OIML and application is not legal for trade. User can tare off the weight anytime when pressing **TARE**

5.8 CLEAR THE TARE FUNCTION

- a. Remove all loads from platter
- b. The tare effect will be cancelled:
 - Automatically if automatic tare function is employed, or
 - By pressing **TARE**
- c. After **TARE** is pressed, the **NET INDICATOR** would disappear.

5.9 MEMORY FUNCTION

5.9.1 How to Accumulate a Weighing Result to Memory

- a. Refer to 5.2 to 5.3 for weighing
- b. Press **M+** to save and accumulate the result to memory.
- c. Scale will display "**P. X**" and then follow by the accumulated weighing result stored while both **M+ INDICATOR** and **MEMORY RECALL INDICATOR** appear pointing to **M+** and **MR** on the overlay respectively
- d. Scale return to normal after 2 seconds and **MEMORY RECALL INDICATOR** will turn off automatically but **M+ INDICATOR** will remain on display to indicate that memory contains a stored data
- e. Repeat **a** to **c** for subsequent transactions

NOTE 1: “**P. X**” means the total number of transactions accumulated to memory

NOTE 2: No weighing result will be stored to memory if it is less than the minimum load. Please refer to **SPECIFICATIONS** for more information

NOTE 3:

- When scale is set at OIML and application is legal for trade. User only needs to press **M+** once when trying to store a value to memory. The weight accumulation function will take place when reading is stabled

- When scale is set at Non-OIML and application is not legal for trade. User can save the shown value to memory at anytime when pressing **M+**

5.9.2 Memory Recall

- a. Press **MR**
- b. Scale displays “**P. X**” and then follow by the accumulated weighing result while **MEMORY RECALL INDICATOR** appears pointing at **MR**
- c. Scale return to normal after 2 seconds and **MEMORY RECALL INDICATOR** will switch off with only **M+ INDICATOR** remain on

display

5.9.3 Memory Clear

- a. Press **MR** and TARE at the same time
- b. Scale displays “**P. 0**” and **MR INDICATOR** at the same time and return to normal after 2 seconds and **M+ INDICATOR** will switch off

5.10 EXTENDED DISPLAY

This scale is equipped with extended display function for reference purpose only. To activate the function, press and hold **MODE** for 2 seconds and display will flash the extended digit for 5 seconds before return to normal.

5.11 RECHARGE THE SCALE

The scale is equipped with a built-in rechargeable battery. When the **LO-BAT INDICATOR** appears, recharge the scale immediately. Failure to do so may cause unrecoverable damage to the rechargeable battery.

6. TROUBLE SHOOTING

Syndrome **Scale cannot be turned on**

Check: Is the scale charged?

Action: Recharge the scale for at least 8 hours before first time use or plug in the power adaptor before power on the scale.

Check Is the power adaptor inserted properly into both the electricity outlet and the DC inlet of scale.

Action: Secure both ends of the power adaptor and try again.

Syndrome **Scale turned off automatically**

Check Is **Auto Power Off Function** employed?

Action Refer to **4.2.2** to disable **Auto Power Off Function**.

Check Is the **LO-BAT INDICATOR** on?

Action Apply the power adaptor.

Syndrome **Rated capacity cannot be reached**

Check Is the **NET INDICATOR** on?

Action: Turn the scale off. Remove all loads from platter and turn on again.

Check Is there anything obstructing the platter?

Action Remove all obstacles.

Syndrome **Weighing result is not accurate**

Check Is the scale placed in a level condition?

Action Adjust the adjustable feet to a level condition.

Check Is the scale affected by airflow, vibration or RFI?

Action: Place the scale away from all disturbances.

Check Is the scale calibrated correctly?

Action Contact your dealer.

Check Is the correct weight unit employed?

Action Refer to **5.3** for weight unit setting and usage.

Syndrome **Display shows 00000 after counting down**

Check Is the load applied to platter excess the rated capacity of scale?

Action Remove all loads from platter and try again.

7. DAILY CARE AND MAINTENANCE

- 7.1 Clean the scale with a soft and damp cloth. If necessary, apply a mild detergent.
- 7.2 Do not use any harsh, abrasive material, acetone, volatile solvent, thinner or alcohol for cleaning.
- 7.3 Verify the accuracy of scale periodically. Re-calibrate the scale if necessary.

NOTE: In some countries, calibration requires authorized/qualified agent. Contact your dealer for more information.

- 7.4 It is a good practice to apply the dust cover when operating the scale.
- 7.5 The scale must be placed horizontally during transportation or long time storage.
- 7.6 Remove platter from scale before transportation or long time storage.
- 7.7 Store scale in a dry and clean place.