

U *SER MANUAL*




Manual Number 6806956-R3

cascade[®]
corporation


Cascade is a Registered Trademark of Cascade Corporation

	Page
OVERVIEW	1
WARNINGS & SAFETY MEASURES	2
INSTALLATION	3
USING DISPLAY	5
Functions	5
Other Features	6
USING iFORKS	7
Dos and Don'ts	7
Weighing Load - Basic	8
Weighing a Load - Net/Tare/Gross Weight	9
Weighing a Load - Add to the Total & Reset	11
Piece Counting	12
AUTO SHUT-OFF	13
BATTERIES	14
iForks Indication	14
Changing iFork Battery Packs	15
Changing Display Batteries	17
DISPLAY OPTIONS	18
User Settings	18
User Settings - Submenus	19
PRINTER OPTION	22
PERIODIC MAINTENANCE	24


This manual describes the installation and use of the iForks. Read this manual carefully. The installer must be informed of the contents of this manual. Follow the contents of the manual precisely. Always do things in the correct order. This manual should be kept on a safe and dry place. In case of damage or loss the user may request a new copy of the manual from Cascade RAVAS.




***Read through
user manual***




Review parts



***Install iForks
system on truck***




Install batteries



Use system




***Recharge or
change batteries***



***Perform 2000 Hour
Maintenance***

WARNINGS & SAFETY MEASURES




When using the iFork, please observe carefully the instructions and guidelines contained in this manual. Always perform each step in sequence. If any of the instructions are not clear, contact Cascade RAVAS.



READ CAREFULLY

- All safety regulations that apply on the truck remain valid and unchanged.
- No weighing operations are allowed if any persons or objects are in the vicinity; around, under or close to the load.
- Cascade RAVAS is not responsible for any physical harm done to the operator because of the presence of the indicator in the cabin.
- Any modifications done to the system must be approved in writing from the supplier, prior to any work being completed.
- It is the sole responsibility of the purchaser to train their own employees in the proper use and maintenance of this equipment.
- Do not operate this unit unless you have been fully trained of its capabilities.
- Check the accuracy of the scale on a regular basis to prevent faulty readings.
- Only trained and authorized personnel are allowed to service the scale.
- Always follow the operating, maintenance and repair instructions of this truck and ask the supplier when in doubt.
- Cascade RAVAS is not responsible for errors that occur due to incorrect weighings or inaccurate scales.

CAUTION: Do not Pressure Wash



Should you have any further questions after reading this manual then you can contact Cascade RAVAS.


IMPORTANT: Tampering or removing iForks NTEP Security wire or label will void NTEP Certification.

INSTALLATION


1 Install iForks

IMPORTANT: Truck mast must be vertical.

- A Remove standard forks.
- B Unlock iForks.
- C Install iForks.




2 Lock iForks



3 Install battery packs into the iForks


- A Lift up battery holder locking clip.
- B Position battery pack.
- C Click into the battery holders.
- D Secure the locking clips down.



6 Locate and mount the display

Find a suitable location for readout and easy access to display.




NOTE: If required, install batteries into display. Refer to Batteries Section, "Changing Display Batteries", page 17.



7 Install display bracket and support, if required

A Install bracket to display.

B Install bracket/display to the support.



USING DISPLAY

Functions

Left of Display

When ◀ appears:

- ~ The weighing system (including load) is stable
- >0< The weight shown is within the zero range
- NET The display is showing the net weight

When ■ appears, the weight shown is negative

Middle of Display

When ▼ appears:


- e1** Weight shown is in .44 lb (.2 kg) steps; only for weight that ranges 0-441 lb (0-200 kg).
- e2** Weight shown is in 1.1 lb (.5 kg) steps; only for weight that ranges 441-1102 lb (200-500 kg).
- e3** Weight shown is in 2.2 lb (1 kg) steps; only for weight that ranges 1102-4850 lb (500-2200 kg).
- F1** Fork 1 relay setpoint 1 is activated.
- F2** Fork 2 relay setpoint 2 is activated.

NOTE: Smaller loads are weighed with higher accuracy. Example: If an original load with **e2** range selected is removed, and a smaller load qualified for **e1** range, the **e2** range will remain selected until the forks are zeroed.

Right of Display


When the following appears:

- kg** Weight shown is in kilograms
- lb** Weight shown is in pounds
- pcs** Amount displayed is the number of pieces on the scale
- ☹ Low battery indicator




Display Button	Short Key Press	3 Second Key Press	Entry Mode
<p>ID CODE</p>	<p>>0< Zero Setting - Manually zeros the display</p>	<p>ID CODE Code Entry - A 5-digit code useful for a weighing system connected to peripheral equipment for later processing.</p>	<p>↵ Enter (accept value)</p>
<p>PT</p>	<p>>T< Automatic Tare - Allows the tare weights to be reset to zero automatically. Added and subtracted weights can be determined.</p>	<p>PT Manual Tare - An entered tare weight at any moment.</p>	<p>▼ Decrease the value of the digit flashing</p>
<p>TOTAL</p>	<p>⊕ Weighed load is added to total weight. If printer is installed, a printout is made.</p>	<p>TOTAL Check subtotal and print total.</p>	<p>▲ Increase the value of the digit flashing</p>
<p>PCS</p>	<p>Sampling a piece weight - Determined an unknown piece weight by sampling a certain number of pieces. Standard sampling amount is 10 pieces.</p>	<p>PCS Enter a piece weight - The last used piece weight or an entered value.</p>	<p>◀ Shift to the next digit on the left</p>
<p>KG/LB</p> <p>CLR</p>	<p>I On/Off</p>	<p>KG/LB Toggle Units</p>	<p>CLR Clear entry</p>

Display Menus



Weigh Mode

Options:
 Net/Tare/Gross (Auto/Manual Tare)
 Add weight/Subtotal weight/Total weight
 Piece weight
 Toggle units
 Manual zero
 On/off



User Settings

Auto shut-off time
 Light intensity
 Deactivate/Activate Com Port 1
 Deactivate/Activate Com Port 2
 Alibi Memory

FK0041.eps

Select Weight Type




2 Wait 5 seconds to switch units




1 Hold for 3 seconds

FK0042.eps

PRIOR TO WEIGHING




Verify iForks are free of obstacles prior to zeroing




FK0043.eps

WEIGHING


NTEP Temperature Range:
15° F (10° C) minimum
105°F (40° C) maximum



FK0044.eps



FK0045.eps




FK0046.eps

USING iFORKS

Weighing a Load – Basic

To weigh a load:

2 Press the on/off key. Wait 5 seconds.




3 Display will zero. If necessary, zero manually.

IMPORTANT:

- If front face or bottom of iForks touches the load or pallet, it will not weigh correctly.
- Unstable weight readings indicate debris between fork and fork shoe.

1 Press the blue button on each battery pack




FK0047.eps

5 Weigh load. Before next weighing, check zero point.




4 Position load on forks, raise forks



FK0048.eps

USING iFORKS

Weighing a Load - Net/Tare/Gross Weight



$$\text{Net (A) + Tare (B) = Gross (C)}$$

NET – The weight of the load to weigh

TARE – The weight of an unladen load that is not included (pallet, bin, etc).

GROSS – The weight of the load and unladen load weights combined.

Net Weighing: Automatic Tare

To weigh a load but disregard part of the load with an **unknown** weight (example: pallet):

NOTE: Display must be in basic weighing mode prior to performing the following steps (press on/off button for 3 seconds).

1 Lift pallet

2 Press the tare button

3 Arrow will appear next "NET" and display will set to zero

4 Weigh load

5 Press the tare button

6 Net value will show (Load weight only)

Gross Weight (Pallet + Load Weight)

NET arrow goes away

1000 kg

FK0050.eps

FK0051.eps

Net Weighing: Manual Tare

To weigh a load but disregard part of the load with a **known** weight (example: pallet):

NOTE: Display must be in basic weighing mode prior to performing the following steps (press power button for 3 seconds).

2 Hold Tare button for 3 seconds

Gross weight

1000 kg

Unladen load (Example: Pallet weight = 25kg)

1 Lift pallet and load

FK0052.eps

3 Enter in TARE weight (weight must be known)

A B C D

For flashing digit, while in entry mode, pressing buttons:

B OR
 ↓ ↑
 Decrease the value Increase the value

C
 <
 Shift to the next digit on the left

D
 ←
 Accept the value

FK0053.eps

4 NET arrow will show

NET weight will show

NOTE: Pressing the Tare button again will show the gross weight

FK0054.eps

When no load is on the pallet (tare weight entered):

No load, the value is zero

Pallet only

When no load and pallet on forks (tare weight entered):


No pallet and load, the value will be negative

Forks only


USING iFORKS

Weighing a Load - Add to the Total & Reset

To add a series of load weights and total:



During the next 3 seconds, the following flashes:



If one of the buttons is pressed during flashing:



Total is reset



KG/LB



For printer option, total is printed and total is reset


NOTE: If no button is pressed during the flashing, the subtotal stays in memory, and the system returns to the weighing mode after 60 seconds.

FK0058.eps


Piece Counting:

To determine an unknown weight by sampling a number of pieces. The number of pieces taken from or placed on the iForks determines the accuracy of the sampling. The standard sampling amount is 10 pieces (95 pieces maximum).

NOTE: Piece counting is not NTEP approved.




Enter a Piece Weight (known weight):




AUTO SHUT-OFF

After 2 minutes of no action:




On the indicator: Countdown Screen Shows

Press any key to cancel auto shut-off and return to weighing mode.



After 20 seconds, off screen will appear



FK0061.eps

Indicator screen will be blank



4 *After 2 hours of no weighing, the iForks will turn off.*


NOTE: To turn on, refer to "Weighing a Load – Basic", Page 9

FUNCTIONALITY BLUE LED'S	
DURING POWERING ON	ON for 5 sec.
FULL BATTERY	Blink Time Interval
Working Mode	Once every 1.5 sec.
Sleep Mode	Once every 4 sec.
LOW BATTERY	
Working Mode	Twice every 10 sec.
Sleep Mode	Twice every 10 sec.

The display will show when there is a low battery on the iforks:


Arrows for fork will blink:
F1 = Fork 1
F2 = Fork 2
F1 & F2 = Fork 1 & Fork 2

Low Battery Indicator



FK0062.eps

Low Battery Indicator:
The blue LED on the related fork will start blinking (2 times every 10 seconds)



FK0063.eps

NOTE: The battery packs will switch off automatically after 10 minutes of low battery.


BATTERIES

Changing iFork Battery Packs

To change batteries on iForks, perform the following:


1 Remove batteries

- A Unlock batteries.
- B Remove battery packs.



2 Remove D-Cells from battery packs

- A Remove the capscrews.
- B Remove top housing of battery pack.
- C Remove batteries.




BATTERIES

Changing iFork Battery Packs (Continued)

3 Install battery packs in iForks


- A** Install four batteries in each battery pack.
- B** Replace the top housing of the battery pack.
- C** Install capscrews finger tight.
- D** Install battery packs into the iForks.



4 Charge battery packs, if equipped with rechargeable batteries


NOTE: Rechargeable batteries are NiMH with a charge capacity of 10,000 mAh.

- A** Lift up locking clips of charger module.
- B** Position the battery packs into charger.
- C** Click batteries into charger.
- D** Push locking clips down.
- E** Plug the charger adapters into the main voltage. Red LED on charger will light.
- F** Charge for 8 hours. Red LED will stay on after batteries are fully charged.



BATTERIES

Changing Display Batteries (if equipped)




Low battery indicator will flash

FK0068.eps


The display is equipped with four AA batteries.

- 1 Remove capscrews from display lid using M5 allen wrench




FK0069.eps

- 2 Open display and remove old batteries




FK0070.eps

- 3 Install new batteries.
NOTE: Check the position and polarity of batteries.



FK0071.eps

- 4 Install display lid and tighten capscrews



FK0072.eps

DISPLAY OPTIONS

User Settings

1 Enter user settings

Multiple screens will flash




FK0073.eps

Hold for 10 seconds

2 Choose a menu option

User Settings Menu Mode



Select menu option


Scroll through menu options:

- Auto Shut-Off Time (Display)
- Light Intensity
- Deactivate/Activate Com Port 1 (Bluetooth board)
- Deactivate/Activate Com Port 2 (Printer board)
- Alibi Memory


3 Continue to desired submenu (see next page)

4 Exit menu


Exit & Save:



Hold for 3 seconds




Changes are being saved




Weigh Mode

OR

Exit without Saving:



FK0074.eps



Weigh Mode


Press CLR button

DISPLAY OPTIONS


User Settings – Submenus

Auto Shut-Off Menu (Display)


NOTE: Auto shut-off can be set to 0 only when the display is hardwired to the truck power.




Backlight Intensity Menu



Com Port 1 Menu (Bluetooth Board)



Com Port 2 Menu (Printer Board)



DISPLAY OPTIONS


User Settings – Submenus (Continued)

Alibi Memory

This option is only active for forks that require NTEP or OIML certification. The memory (1 Mb capacity) stores every weight, date, time and an Alibi reference number. This data can be used for dispute. Once memory is full, the oldest data will be overwritten first.

2 Use Entry Mode to look up alibi number information


Enter alibi number (based on printout or PC data)




1 Enter Alibi Menu



Date Setting: Day



Date Setting: Month



Date Setting: Year



Time Setting: Hour



Time Setting: Minute

Entry Mode Guide

C **A** **B**

For flashing digit, while in entry mode, pressing buttons:

A		OR	
	↓		↑
	Decrease the Value		Increase the Value

B		C	
	←		↶
	Shift to the next digit on the left		Accept the value


FK0079.eps

Continue to next page


DISPLAY OPTIONS

User Settings – Submenus (Continued)


Alibi Memory (Continued)



"Gross" shows for 5 seconds



Gross weight will show
Press enter zero key to move onto next information menu




"Net" shows for 5 seconds

OR



"Net_C" shows for 5 seconds



Net: weight is measured
Net_C: Weight is calculated
Press enter zero key to move onto next information menu




"Tare" shows for 5 seconds


OR



"Ptare" shows for 5 seconds




Tare: Weight is measured
Ptare: Weight is keyed in
Press enter zero key to move onto next information menu



"Code" shows for 5 seconds



Code will show.
If no code was used
"0" will show.




Arrow: Search for another weighing
CLR: Return to the normal weighing mode

FK0080.eps

NOTE: For troubleshooting, refer to iForks service manual.

Print Weight




Print Total Weight



Change Time & Date Printout

2 Change current settings (shown in entry mode guide). To accept current settings, press the enter button.




1 Hold for 6 seconds




Time Setting: Hour




Time Setting: Minute



Date Setting: Day



Date Setting: Month



Date Setting: Year

Entry Mode Guide

For flashing digit, while in entry mode, pressing buttons:

<p>A</p> <div style="display: flex; justify-content: center; align-items: center;"> >T< OR +/- </div> <div style="display: flex; justify-content: center; align-items: center; margin-top: 5px;"> v Decrease the value ^ Increase the value </div>	<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>B</p> <div style="text-align: center; margin-bottom: 5px;"> < </div> <p>Shift to the next digit on the left</p> </div> <div style="width: 45%;"> <p>C</p> <div style="text-align: center; margin-bottom: 5px;"> >0< ↶ </div> <p>Accept the value</p> </div> </div>
---	---

FK0083.eps

100-Hour

Every time the lift truck is serviced or every 100 hours of truck operation, whichever comes first, complete the following maintenance procedures:

- Check for debris between fork and fork shoe.
- Check for pinched wires at bottom of batteries.
- Tighten fork shoe capscrews after initial 100 hours of service. Tighten to a torque of 83 ft.-lbs. (112 Nm).


2000-Hour

After 2000 hours of truck operation, forks in use shall be inspected at intervals of not more than 12 months (for single shift operations) or whenever any defect or permanent deformation is detected. Severe applications will require more frequent inspection.

Inspect fork hooks and carriage bar clearance

NOTE: Use go/no-go Wear Gauge Part No. 209560 (Class II) or 209561 (Class III).

- A** Inspect the fork lower hooks and carriage bar. If the gauge fits between the carriage bar and lower hook, repair or replacement is needed.
- B** Inspect the upper carriage bar. If the gauge arrow touches the carriage bar, repair or replacement is needed.
- C** Inspect the fork upper hooks. If the gauge arrow touches the hook, repair or replacement is needed.




2000-Hour (Continued)

Inspect forks

NOTE: Use fork calipers on fork up to and including 4 in. (100 mm) thick. Fork calipers indicates a 10% wear factor would be when calipers are applied to the blade cross-section.

- A** Remove fork shoe from forks. For reassembly, tighten to a torque of 80 ft.-lbs. (108 Nm).
- B** Measure the fork shank thickness with the caliper outer teeth approximately 2 in. (50 mm) above top of blade. Hold this setting for step C.
- C** Position the caliper inner teeth on the fork arm blade approximately 2 in. (50 mm) out from the face of the shank.
 - If the inside teeth of the caliper hit the fork, it has less than 10% wear and requires no replacement.
 - If the inside teeth of the caliper pass over the fork freely, the fork must be taken out of service. The fork has 10% wear and 20% reduction in capacity.



FK0088.eps

Do you have questions you need answered right now? Call your nearest Cascade RAVAS Service Department. Visit us online at www.cascorp.com

**Cascade Corporation
U.S. Headquarters**
2201 NE 201st
Fairview, OR 97024-9718
Tel: 800-CASCADE (227-2233)
FAX: 888-329-8207

Cascade Canada Inc.
5570 Timberlea Blvd.
Mississauga, Ontario
Canada L4W-4M6
Tel: 905-629-7777
FAX: 905-629-7785

Cascade-Xiamen
No. 668 Yangguang Rd.
Xinyang Industrial Zone
Haicang, Xiamen City
Fujian Province
P.R. China 361026
Tel: 86-592-651-2500
FAX: 86-592-651-2571

Cascade Korea
121B 9L Namdong Ind.
Complex, 691-8 Gojan-Dong
Namdong-Ku
Inchon, 405-310 Korea
Tel: 82-32-821-2051
FAX: 82-32-821-2055

**Cascade India Material
Handling Private Limited**
No 9, Global Trade Centre
1/1 Rambaugh Colony
Lal Bahadur Shastri Road, Navi
Peth, Pune 411 030
(Maharashtra) India
Phone: 020 2433 5460/5490
Fax: 020 2433 0881

**Sunstream Industries
Pte Ltd.**
No. 3 Tuas Link 1
2263
Singapore
Tel: 65-6863-3488
FAX: 65-6863-1368

Cascade Australia
1445 Ipswich Road
Rocklea, QLD 4107
Australia
Tel: 1-800-227-223
FAX: 617-3373-7333

Cascade New Zealand
15 Ra Ora Drive
East Tamaki, Auckland
New Zealand
Tel: 64-9-273-9136
FAX: 64-9-273-9137

Cascade (Africa) Pty. Ltd.
PO Box 625, Isando 1600
60A Steel Road
Sparton, Kempton Park
South Africa
Tel: 27-11-975-9240
FAX: 27-11-394-1147

**Cascade do Brasil
LTDA**
Rua João Guerra, 134
Macuco, Santos - SP
Brasil 11015-130
Tel: 55-13-2105-8800
Fax: 55-13-2105-8899

