

mSSD IDE4K

1.8" and 2.5"

Product Specification and User Manual

November 2006
DC-000294 Rev. 2.4

Document Control Information

DCO No.:

| | Title | Name | Date |
|--------------------|------------------------------------|--------------|--------------------|
| Issued by: | VP Marketing, Embedded Division | Ofer Tsur | March 21, 2004 |
| Updated by: | Product Manager, Embedded Division | Guy Freikorn | June 7, 2004 |
| Updated by: | Product Manager, Embedded Division | Guy Freikorn | January 2, 2005 |
| Updated by: | Product Manager, Embedded Division | Guy Freikorn | September 19, 2005 |
| Updated by: | Product Manager, Embedded Division | Guy Freikorn | June 5, 2006 |

Revision History

| Revision | Date | Description | Reference |
|-----------------|--------------------|---|--|
| 2.0 | June 7, 2004 | Added information for new 1.8" form factor | -- |
| 2.1 | January 2, 2005 | Updated available capacity information Updated reliability information Updated supported temperature ranges Updated CHS settings information | Section 1.2.8 Section 1.2.9 Sections 1.3.1, 9 Section 1.2.8 |
| 2.2 | September 19, 2005 | Updated CHS settings information Updated label information Added information about RoHS support | Section 1.2.8 Section 6 Sections 1.4, 5, 9 |
| 2.3 | June 5, 2006 | Removed unsupported capacities | Section 9 |
| 2.4 | November 9, 2006 | Updated performance Updated current consumption Updated CHS settings information | 1.2.3 1.2.7 Section 1.2.8 |

Table of Contents

| | |
|--|-----------|
| Product Specification and User Manual..... | 1 |
| 1. Specifications | 4 |
| 1.1 Critical Item Definition | 4 |
| 1.2 Characteristics..... | 4 |
| 1.2.1 Interface Definition | 4 |
| 1.2.2 IDE Transfer Modes | 4 |
| 1.2.3 Performance..... | 4 |
| 1.2.4 Access Time | 4 |
| 1.2.5 Seek Time..... | 4 |
| 1.2.6 Input Voltage | 4 |
| 1.2.7 Current Consumption..... | 5 |
| 1.2.8 Memory Capacity | 5 |
| 1.2.9 Endurance..... | 6 |
| 1.2.10 Mean Time Between Failures (MTBF) | 6 |
| 1.2.11 Physical | 6 |
| 1.3 Environmental | 9 |
| 1.3.1 Temperature | 9 |
| 1.3.2 Altitude..... | 10 |
| 1.3.3 Relative Humidity..... | 10 |
| 1.3.4 Shock | 10 |
| 1.3.5 Vibration..... | 10 |
| 1.3.6 Storage Life and Data Retention..... | 10 |
| 1.4 RoHS Support..... | 10 |
| 2. Drive Configuration | 11 |
| 3. Interface Connectors..... | 12 |
| 4. Supported IDE Commands..... | 13 |
| 5. Compliance with Standards | 14 |
| 6. Label Information..... | 15 |
| 7. Using the IDE 4000 Flash Disk | 16 |
| 7.1 Unpacking the Drive | 16 |
| 7.2 Handling Instructions..... | 16 |
| 7.3 Installing the Drive in a PC | 16 |
| 7.4 Using the IDE 4000 in an MS-DOS-Based Platform | 17 |
| 7.5 Troubleshooting | 17 |
| 7.6 How to Get Help | 18 |
| 8. Warranty | 19 |
| 9. Ordering Information | 20 |
| How to Contact Us | 21 |

1. Specifications

1.1 Critical Item Definition

The dimensions of the mSSD IDE4K (formerly, IDE 4000 flash disk) enable mounting in a standard 2.5" or 1.8" disk drive bay, as described in Section 1.2.11.

Note: The information written in this document refers to both IDE 4000 2.5" and 1.8" unless otherwise stated.

1.2 Characteristics

1.2.1 Interface Definition

The IDE 4000 supports the commands listed in Section 4, in compliance with ATA-4 standards.

1.2.2 IDE Transfer Modes

The IDE 4000 supports the following transfer modes:

- PIO modes 0 through 4
- DMA modes 0 through 2

1.2.3 Performance

The IDE 4000 complies with the performance requirements described in Table 1.

Table 1: IDE 4000 Transfer Rates

| Operation | Burst Rate (MB/sec) | Sustained Rate (MB/sec) |
|-----------|---------------------|-------------------------|
| Read | 16.6 | 5.0 |
| Write | 16.6 | 3.4 |

Performance was measured on a system with the following configuration:

- Computer with ASUS P4T533-C motherboard and Intel 2.4 GHz processor
- Windows XP Professional operating system
- IDE transfer mode: Multiword DMA 2
- IDE 4000 disk capacity: 4GB

The HDTACH v2.61 benchmark utility was used to measure IDE 4000 performance. See for measurement results.

1.2.4 Access Time

Standby to active (typical.): 0.1 msec

1.2.5 Seek Time

The IDE 4000 has no seek time, as it has no moving parts.

1.2.6 Input Voltage

The IDE 4000 input voltage is 3.3VDC to 5.0VDC.

1.2.7 Current Consumption

The current consumption at an input voltage of +5 VDC is described in Table 2.

Table 2: IDE 4000 Input Current Consumption with +5 VDC Input Voltage

| Function/Mode | Current (Max) mA DC |
|---------------|---------------------|
| Read | 35.0 |
| Write | 35.0 |
| Idle/Sleep | 8.6 |

1.2.8 Memory Capacity

As of software version 1.09, the CHS (Cylinder, Heads, Sectors) settings listed in Table 3 apply to all IDE 4000 products, in all capacities for both 2.5" and 1.8" versions.

Table 3: CHS Settings for IDE 4000

| Capacity (MB) | Cylinder | Heads | Sectors |
|---------------|----------|-------|---------|
| 128 | 500 | 16 | 32 |
| 256 | 1000 | 16 | 32 |
| 512 | 1015 | 16 | 63 |
| 640 | 1262 | 16 | 63 |
| 768 | 1522 | 16 | 63 |
| 1,024 | 2026 | 16 | 63 |
| 1,536 | 3052 | 16 | 63 |
| 2,048 | 4066 | 16 | 63 |
| 2,560 | 5088 | 16 | 63 |
| 3,072 | 6106 | 16 | 63 |
| 3,584 | 7125 | 16 | 63 |
| 4,096 | 8145 | 16 | 63 |
| 5,120 | 10187 | 16 | 63 |
| 6,144 | 12225 | 16 | 63 |
| 7,168 | 14265 | 16 | 63 |
| 8,192 | 16305 | 16 | 63 |

1.2.9

Endurance

The IDE 4000 provides 2,000,000 write/erase cycles and an unlimited number of read cycles. Performance is enhanced by the following features:

- **Wear-Leveling Algorithm:** This algorithm guarantees the use of all flash components at the same level of the write/erase cycle.
- **EDC/ECC (Error Detection Code/Error Correction):** The enhanced Reed-Solomon EDC/ECC extends disk endurance by detecting and then fixing flash blocks.

1.2.10 Mean Time Between Failures (MTBF)

Table 4 summarizes the MTBF prediction results for various IDE 4000 configurations. The analysis was performed using a RAM Commander™ failure rate prediction.

Table 4: IDE 4000 MTBF

| Product | Condition | MTBF (Hours) | Failure Rate per Million Hours |
|-------------------|----------------------------|--------------|--------------------------------|
| IDE 4000 1GB | Telcordia SR-332, GB, 25°C | 2,893,495 | 0.3456 |
| IDE 4000 2GB | Telcordia SR-332, GB, 25°C | 2,188,066 | 0.4570 |
| IDE 4000 3GB | Telcordia SR-332, GB, 25°C | 1,759,180 | 0.5684 |
| IDE 4000 4 to 8GB | Telcordia SR-332, GB, 25°C | 1,470,874 | 0.6799 |

A detailed MTBF report can be furnished upon request.

1.2.11 Physical

1.2.11.1 Weight

The weight of the IDE 4000 complies with the values defined in Table 5.

Table 5: IDE 4000 Maximum Weight

| Memory Capacity (MB) | 2.5" Unit Weight (g) | 1.8" Unit Weight (g) |
|----------------------|----------------------|----------------------|
| 8192 | 90 | 30 |

1.2.11.2 Dimensions

Table 6 describes the nominal dimensions of the IDE 4000. Refer to Figure 1 for detailed mounting configuration dimensions.

Table 6: Nominal Dimensions

| Dimensions | IDE 4000 2.5" | | IDE 4000 1.8" | |
|------------|---------------|-----------|---------------|---------|
| | | | | |
| Height | 0.291 in | 7.40 mm | 0.339 in | 8.6 mm |
| Width | 2.750 in | 69.85 mm | 2.008 in | 51.0 mm |
| Depth | 3.945 in | 100.20 mm | 3.004 in | 76.3 mm |




Figure 1: IDE 4000 2.5" Assembly




Figure 2: IDE 4000 1.8" Assembly

- Notes:
1. All dimensions are in mm [in].
 2. General tolerance is ± 0.25 mm [± 0.01 in].

1.2.11.3 Connector Interface

The pinout for the IDE 4000 interface connector is detailed in Table 7 and in Figure 3.

Table 7: J1 Pin Assignment

| Pin Number | Signal Name | Pin Number | Signal Name |
|------------|-------------|------------|-------------|
| 1 | RESET- | 2 | GND |
| 3 | HD7 | 4 | HD8 |
| 5 | HD6 | 6 | HD9 |
| 7 | HD5 | 8 | HD10 |
| 9 | HD4 | 10 | HD11 |
| 11 | HD3 | 12 | HD12 |
| 13 | HD2 | 14 | HD13 |
| 15 | HD1 | 16 | HD14 |
| 17 | HD0 | 18 | HD15 |
| 19 | GND | 20 | KEY |
| 21 | N.C. | 22 | GND |
| 23 | H1OW- | 24 | GND |
| 25 | H1OR- | 26 | GND |
| 27 | IORDY | 28 | CSEL |
| 29 | N.C. | 30 | GND |
| 31 | INTRQ | 32 | IOCS16- |
| 33 | HA1 | 34 | PDIAG- |
| 35 | HA0 | 36 | HA2 |
| 37 | CS0- | 38 | CS1- |
| 39 | DASP- | 40 | GND |
| 41 | VCC | 42 | VCC |
| 43 | GND | 44 | RSVD |

Table 8: J2 Pin Assignment

| Pin Number | Signal Name | Pin Number | Signal Name |
|------------|--------------|------------|--------------|
| 47 | Master/Slave | 48 | Master/Slave |
| 49 | Master/Slave | 50 | Master/Slave |




Figure 3: IDE 4000 Pin Configuration

1.3 Environmental

The IDE 4000 meets the performance requirements specified below, after exposure to non-operating environmental conditions, or during and after exposure to operating environmental conditions.

1.3.1 Temperature

1.3.1.1 Operating

The IDE 4000 operates without degradation at a pressure of 1 atm over the following ambient temperature range:

- Commercial temperature version: 0°C to +70°C for IDE 4000 2.5" and 1.8"
- Extended temperature version: -40°C to +85°C for IDE 4000 2.5"

The maximum temperature change rate shall not exceed 5°C per minute.

1.3.1.2 Non-Operating

The IDE 4000 commercial temperature version meets the performance requirements specified in this document after having been tested via exposure to a nominal ambient temperature of -55°C for not less than 3 days, and +95°C for a period of not less than 6 hours.

The maximum temperature change rate shall not exceed 5°C per minute.

1.3.1.3 Airflow Requirements

General airflow guideline: 3-5 cu.feet/min.

1.3.2 Altitude

The IDE 4000 sustains full operation at altitudes ranging from sea level to 80,000 feet above sea level. It is also capable of full operation during air transportation via non-pressurized flights at altitudes greater than 80,000 feet above sea level.

1.3.3 Relative Humidity

The IDE 4000 withstands conditions of 8% to 95% non-condensing relative humidity (operation and non-operation).

1.3.4 Shock

The IDE 4000 sustains full operation after being subjected to 1000 G shock testing in the vertical axis.

1.3.5 Vibration

The IDE 4000 remains operational without degradation while being subjected to a 15 G vibration condition.

1.3.6 Storage Life and Data Retention

The IDE 4000 can be placed in non-operational storage in shipping containers or crates for a period of up to 3 years without its capabilities being permanently affected. The IDE 4000 has a data retention span of over 10 years.

1.4 RoHS Support

IDE 4000 products in a 2.5" form factor are available in an RoHS compliant version for all capacities.

2. Drive Configuration

The IDE 4000 must be configured as shown in Figure 4 before being mounted in the system's drive bay.




Figure 4: IDE 4000 Disk Address Setting by Jumper

3. Interface Connectors

The IDE 4000 has a 2-mm pitch interface connector located on the rear panel. It accesses the DC power source and the IDE bus through a non-shielded 44-pin flat cable. Figure 5 provides an example of a connector that can be used to interface with this connector, but any compatible connectors may be used.




Figure 5: IDE 4000 Interface Connector

In order to prevent damage to the disk by connecting the cable with a 180° rotation, ensure that the special plastic key at pin 20 mating connector is blocked, as shown in Figure 5. This key should be ordered from the connector manufacturer.

IDE Cable

The cable length should not exceed 18 inches.

4. Supported IDE Commands

The IDE 4000 supports the commands listed in Table 9.

Table 9: IDE Commands

| Command Name | Command Code |
|---------------------------------------|--------------|
| CHECK POWER MODE | 98h E5h |
| EXECUTE DEVICE DIAGNOSTIC | 90h |
| FORMAT TRACK | 50h |
| IDENTIFY DEVICE | Ech |
| IDLE | 97h E3h |
| IDLE IMMEDIATE | 95h E1h |
| INITIALIZE DEVICE PARAMETERS | 91h |
| READ BUFFER | E4h |
| READ DMA (with retry) | C8h |
| READ DMA (without retry) | C9h |
| READ MULTIPLE | C4h |
| READ SECTOR(S) (with retry) | 20h |
| READ SECTOR(S) (without retry) | 21h |
| READ LONG | 22h 23h |
| READ VERIFY SECTOR(S) (with retry) | 40h |
| READ VERIFY SECTOR(S) (without retry) | 41h |
| RECALIBRATE | 10h |
| SEEK | 70h |
| SET FEATURES | Efh |
| SET MULTIPLE MODE | C6h |
| SLEEP | 99h E6h |
| STANDBY | 96h E2h |
| STANDBY IMMEDIATE | 94h E0h |
| WRITE BUFFER | E8h |
| WRITE DMA (with retry) | CAh |
| WRITE DMA (without retry) | CBh |
| WRITE MULTIPLE | C5h |
| WRITE SECTOR(S) (with retry) | 30h |
| WRITE SECTOR(S) (without retry) | 31h |
| WRITE LONG | 32h 33h |

5. Compliance with Standards

The IDE 4000 complies with the following CE requirements and FCC standards:

- FCC Part 15 Class B
- EN 55022 Class B, CISPR 22 Class B (MIC)
- V-3/2001.04 Class B (Japan), AS/NZS 3548 Class B (Australia/NZ)
- BSMI CNS 13438 Class B (Taiwan)
- CAN/CSA-CISPR 22-96 Class B (Canada) CFR 47 FCC Class B
- EN 55024, EN 61000 (EMC)

Additionally, IDE 4000 in a 2.5" form factor is available in lead-free version for all capacities that complies with the RoHS directive.

6. Label Information

The IDE 4000 1.8" and 2.5" outer labels contain the following information:




Figure 6: IDE 4000 2.5" Outer Label




Figure 7: IDE 4000 1.8" Outer Label

7. Using the IDE 4000 Flash Disk

The IDE 4000 is shipped with the following components:

- Warranty certificate indicating msystems' 36-month warranty
- Four screws and one jumper, in kit no. 48-PK-001-00

If any of these items is missing, please contact your dealer.

7.1 Unpacking the Drive

Before unpacking or handling a drive, take all proper electrostatic discharge (ESD) precautions, including personnel and equipment grounding.

Before you begin installing the IDE 4000 in your system, perform a visual inspection and follow the recommendations below:

- If the shipping container appears to be damaged or water-stained, notify your dealer.
- Remove the disk from its shipping enclosure and inspect it for any damage that may have occurred during shipment. If any damage is observed, notify your dealer.
- Record the disk serial number and shipment date.
- Retain the original shipping enclosure and all packing material for re-shipment.

7.2 Handling Instructions

You can prolong the life of your IDE 4000, increase its reliability, and prevent unnecessary damage by following the instructions listed below. Failure to follow any of these instructions may void your warranty.

- Always take all proper electrostatic discharge (ESD) precautions, including personnel and equipment grounding.
- Always operate the flash disk within the environmental specifications.
- Always use a grounded wrist strap when handling the flash disk.
- Never switch DC power to the drive by plugging an electrically live source cable into the drive's power connector.
- Pay attention to the cable polarity whenever connecting the drive to the cable.

7.3 Installing the Drive in a PC

To install the IDE 4000:

1. Power off the PC and remove the cover.
2. Configure the IDE 4000 jumper settings according to the information provided in Section 2.
3. Connect a 44-pin ribbon cable between the IDE 4000 and the adapter. Make sure to orient the cable so that pin 1 of the IDE 4000 is connected to pin 1 of the host adapter.
4. Mount the IDE 4000 in a free drive bay.
5. Close the PC cover and power on the PC.

The host BIOS sign-on message appears and displays a key sequence to enter the BIOS setup. Set up the BIOS to recognize the IDE 4000.

7.4 Using the IDE 4000 in an MS-DOS-Based Platform

After installing the IDE 4000, it must be installed as a disk drive under DOS. Run the DOS commands listed below and follow the instructions displayed for each command. For more information regarding DOS commands, refer to your DOS manual.

- Run the DOS FDISK program to partition the IDE 4000.
- Run the DOS FORMAT command to high-level format the IDE 4000.
- If you want the IDE 4000 to be a bootable drive, run the DOS SYS command and change the partition to active.

7.5 Troubleshooting

The problems that arise in most installations can be summarized below:

Cables:

- Homemade, short, flat ribbon cables with bad contacts or cheap cables
- Mixing round cables with flat cables.

Cable Length:

- The cable exceeds the length specified in the standard
- Cables are too long to support the transfer rate.

Device Address Conflict:

- A new device was added with an IDE setting identical to an existing device on the bus.
- Connection problems.
- A cable was connecting with reverse polarity.

7.6 How to Get Help

If you need technical assistance with the installation and configuration of your IDE 4000, please contact your customer support representative and have the following information available:

- Product and serial number of your IDE 4000
- Description of your computer hardware (manufacturer, model, attached devices, etc.)
- Description of your IDE host adapter and associated drivers
- Description of your software (operating system, version, application software, etc.)
- A complete description of the problem
- The exact wording of any error messages

Before contacting msystems directly, first contact your dealer (if you did not purchase you IDE 4000 directly from msystems). If your dealer cannot provide the help you need, you can obtain technical support directly from msystems at one of the numbers in the list of offices on the last page of this manual, or from the msystems website www.m-systems.com.

8. Warranty

The warranty period of the IDE 4000 is 36 months (3 years). For details, please refer to the warranty certificate, which is included with the IDE 4000.

9. Ordering Information

Ordering information for the IDE 4000 2.5": IDE-4K-25-CCCC-T-P

Ordering information for the IDE 4000 1.8": IDE-4K-18-CCCC

Where:

| | | | |
|-------|-------------------|--|--|
| CCCC: | Capacity (MB) | 128, 256, 512, 768, 1024, 1536, 2048, 2560, 3072, 3584, 4096, 5120, 6144, 7168, 8192 | |
| T: | Temperature Range | Blank | Commercial: 0°C to +70°C (for 2.5" and 1.8") |
| | | X | Extended: -40°C to +85°C (for 2.5" only) |
| P: | RoHS Support | Blank | Leaded version |
| | | P | Lead-free version |

Note: the IDE 4000 in a 1.8" casing is available only in commercial temperature range and is not RoHS compliant.

How to Contact Us

USA

msystems, Inc.
555 North Mathilda Avenue, Suite 220
Sunnyvale, CA 94085
Phone: +1-408-470-4440
Fax: +1-408-470-4470

Japan

msystems Japan Inc.
Asahi Seimei Gotanda Bldg., 3F
5-25-16 Higashi-Gotanda
Shinagawa-ku Tokyo, 141-0022
Phone: +81-3-5423-8101
Fax: +81-3-5423-8102

Taiwan

msystems Asia Ltd.
14 F, No. 6, Sec. 3
Minqan East Road
Taipei, Taiwan, 104
Tel: +886-2-2515-2522
Fax: +886-2-2515-2295

China

msystems China Ltd.
Room 121-122
Bldg. 2, International Commerce & Exhibition Ctr.
Hong Hua Rd.
Futian Free Trade Zone
Shenzhen, China
Phone: +86-755-8348-5218
Fax: +86-755-8348-5418

Europe

msystems Ltd.
7 Atir Yeda St.
Kfar Saba 44425, Israel
Tel: +972-9-764-5000
Fax: +972-3-548-8666

Internet

<http://www.m-systems.com/mobile>

General Information

info@m-systems.com

Sales and Technical Information

techsupport@m-systems.com

This document is for information use only and is subject to change without prior notice. msystems Ltd. assumes no responsibility for any errors that may appear in this document. No part of this document may be reproduced, transmitted, transcribed, stored in a retrievable manner or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without prior written consent of msystems.

msystems' products are not warranted to operate without failure. Accordingly, in any use of the Product in life support systems or other applications where failure could cause injury or loss of life, the Product should only be incorporated in systems designed with appropriate and sufficient redundancy or backup features.

Contact your local msystems sales office or distributor, or visit our website at www.m-systems.com to obtain the latest specifications before placing your order.

© 2006 msystems Ltd. All rights reserved.

msystems, mDOC, mDOC Millennium, DiskOnKey, DiskOnKey MyKey, FFD, Fly-By, imDOC, iDOC, mmDOC, mDOC, Mobile mDOC, Smart DiskOnKey, SmartCaps, SuperMAP, TrueFFS, umDOC, uDOC, and Xkey are trademarks or registered trademarks of msystems Ltd. Other product names or service marks mentioned herein may be trademarks or registered trademarks of their respective owners and are hereby acknowledged. All specifications are subject to change without prior notice.