



USB TO RS485-422 Converter



USER MANUAL

I. Introduction

USB to RS485-422 converter comes with the following advantages:

- 1) to realize the communication between the RS485-422 device and the host computer that does not have RS232 serial port (for example, Laptop)
- 2) to increase the transmission rate during RS485 or 422 communication, as USB transmission rate can be up to 10Mbps
- 3) USB port can supply strong power need for the converter.

How USB to RS485-422 works?

- 1) Connect the converter to host computer.
- 2) Install the driver.
- 3) The driver will create virtual serial port, like COM3, or COM4, COM5, etc
- 4) For laptop computer without COM port, COM1 is usually created.
- 5) Application software chooses the created serial port to work.

II. Application

USB to RS485 –422 usually works in these applications:

Industrial control automatic system, Barcode scanner, Palm, PLC&PLD, PDA(Win CE system), Label printer, POS system, Data collection system, Access control system, etc.

III. Features

- USB port to serial port signal conversion.
- Regular voltage range of RS-485 port:-7V~+12V
- Support Windows98/ME and Windows2000/XP
- Support MAC Apple and Linux v5.0
- Compatible with USB v1.1 and USB CDC V1.1
- USB full-speed transmission

- USB bus self-powered
- Transmission speed up to 57.6kbps in the distance of 1200m
- RS485-422 standard of TIA/EIA
- Support remote waking up and power management

TIPS

The transmission speed of USB to RS485-422 is decided by the distance. The longer the distance, the lower the speed rate would be. (Table)

Distance	0~10m	300m	1200m	5000m
Rate (Max)	230kbps	115kbps	57.6kbps	9600bps

IV. PIN OUT

RS485-RS422 Terminal

RS485-422	T-/D-	T+/D+	R+	R-	GND
-----------	-------	-------	----	----	-----

V. LED Indication

LED Color	Definition
Red light	Power indicator
Green light	Sending signal
Yellow light	Receiving signal

VI. System requirement

- Intel CPU compatible 486DX4-100 MHz or higher
- One standard USB interface (4-pin)
- Windows 98/Me or Windows 2000/XP operating system or above

VII. Driver installation

- 1) Put in drive disk
- 2) Plug in USB to RS485/422.
- 3) Follow Windows OS pop up window to install the driver.

4) **[Tips]:** If any other driver for USB to RS485/422 had been installed, please remove it first, then install FTDI USB to RS485/RS422 driver. Please refer to vender's manual for how to remove the driver.