



Installation User and Service Manual



Œ

www.aosmithinternational.com

your installer



| Read this manual carefully | Warning Read this manual carefully before starting up the water heater. Failure to read this manual and to follow the instructions in this manual may lead to accidents, personal injury, and damage to the appliance. Copyright © 2008 A.O. Smith water Products Company | | |
|----------------------------|---|--|--|
| | All rights reserved. Nothing from this publication may be copied, reproduced and/or published by means of printing, photocopying or by whatsoever means, without the prior written approval of A.O. Smith water Products Company. | | |
| | A.O. Smith water Pr stated in this manua | oducts Company reserves the right to modify specifications al. | |
| Trademarks | Any brand names m respective owners. | nentioned in this manual are registered trademarks of their | |
| Liability | A.O. Smith water Products Company accepts no liability for claims from third parties arising from improper use other than that stated in this manual and in accordance with the General Conditions registered at the Eindhoven Chamber of Commerce. | | |
| | Refer further to the General Conditions. These are available on request, free of charge. | | |
| | comprehensive des | ble care has been taken to ensure a correct and suitably cription of all relevant components, the manual may n errors and inaccuracies. | |
| | | iny errors or inaccuracies in the manual, we would be I inform us. This helps us to further improve our | |
| More information | | nments or queries concerning any aspect related to the ase do not hesitate to contact: | |
| | A.O. Smith water Products Company | | |
| | PO Box 70 | | |
| | 5500 AB Veldhover | 1 | |
| | Netherlands | | |
| | Telephone: | (free) 008008 - AOSMITH | |
| | General: | 0870 - 267 64 84 +31 40 294 25 00 | |
| | Fax: | +31 40 294 25 30 | |
| | E-mail : | info@aosmith.nl | |
| | Website: | www.aosmithinternational.com | |
| | | | |

In the event of problems with connecting to the gas, electricity or water supply, please contact your installation's supplier/installation engineer .






Table of contents

| 1.1 About the appliance 9 1.2 What to do if you smell gas- 9 1.3 Regulations 9 1.4 Target groups 10 1.5 Maintenance 10 1.6 Forms of notation 10 1.7 Overview of this document 11 2 Working principle of the appliance 13 2.1 Introduction 13 2.2 General working principle of the appliance 13 2.3 The appliance's heating cycle 14 2.4 Protection for the appliance 15 2.5 Safety of the solar heating system 17 2.6 Protection for the solar heating system 17 2.7 Safety of the solar heating system 19 3.1 Introduction 19 3.2 Packaging 19 3.4 Technical specifications 22 3.5 Installation diagram 26 3.6 Gas connections, Unvented 28 3.8 Gas connections, Unvented 28 3.9 <t< th=""><th>1</th><th></th><th>Introduction9</th></t<> | 1 | | Introduction9 |
|--|---|------|---|
| 1.3 Regulations 9 1.4 Target groups 10 1.5 Maintenance 10 1.6 Forms of notation 10 1.7 Overview of this document 11 2 Working principle of the appliance 13 2.1 Introduction 13 2.2 General working principle of the appliance 13 2.3 The appliance's heating cycle 14 2.4 Protection for the appliance 15 2.5 Safety of the installation 17 2.6 Protection for the solar heating system 17 2.7 Safety of the solar heating system 18 3 Installation 19 3.1 Introduction 19 3.2 Packaging 19 3.3 Environmental conditions- 20 3.6 Installation diagram 26 3.6 Water connections, Unvented 27 3.7 Water connections, Unvented 28 3.8 Gas connection 29 3.10 Solar heating system< | | 1.1 | About the appliance 9 |
| 1.4 Target groups 10 1.5 Maintenance 10 1.6 Forms of notation 10 1.7 Overview of this document 11 2 Working principle of the appliance 13 2.1 Introduction 13 2.3 The appliance's heating cycle 14 2.4 Protection for the appliance 15 2.5 Safety of the installation 17 2.6 Protection for the solar heating system 17 2.7 Safety of the solar heating system 18 3 Installation 19 3.1 Introduction 19 3.2 Installation 19 3.4 Technical specifications 22 3.5 Installation diagram 26 3.6 Water connections, Unvented 27 3.7 Water connections, Vented 28 3.8 Gas connection 29 3.9 Air supply and flue 29 3.10 Solar heating system 35 3.12 Electrically connecting the solar | | 1.2 | |
| 1.5 Maintenance- 10 1.6 Forms of notation 10 1.7 Overview of this document - 11 2 Working principle of the appliance 13 2.1 Introduction - 13 2.2 General working principle of the appliance 13 2.3 The appliance's heating cycle 14 2.4 Protection for the appliance 15 2.5 Safety of the installation 17 2.6 Protection for the solar heating system 17 2.7 Safety of the solar heating system 18 3 Installation 19 3.1 Introduction 19 3.2 Packaging - 19 3.3 Environmental conditions- 19 3.4 Technical specifications 22 3.5 Installation diagram 26 3.6 Water connections, Wented 27 3.7 Water connections, Wented 28 3.8 Gas connection 29 3.11 Electrical connection - 29 3.12 | | 1.3 | 5 |
| 1.6 Forms of notation 10 1.7 Overview of this document 11 2 Working principle of the appliance 13 2.1 Introduction 13 2.2 General working principle of the appliance 13 2.3 The appliance's heating cycle 14 2.4 Protection for the appliance 15 2.5 Safety of the installation 17 2.6 Protection for the solar heating system 17 2.7 Safety of the solar heating system 18 3 Installation 19 3.1 Introduction 19 3.2 Packaging - 19 3.3 Environmental conditions- 19 3.4 Technical specifications 22 3.5 Installation diagram 266 3.6 Water connections, Unvented 27 3.7 Water connections, Vented- 28 3.8 Gas connection - 29 3.10 Solar heating system 35 3.11 Electrical connection - 35 3. | | 1.4 | |
| 1.7 Overview of this document 11 2 Working principle of the appliance 13 2.1 Introduction 13 2.2 General working principle of the appliance 13 2.3 The appliance's heating cycle 14 2.4 Protection for the appliance 15 2.5 Safety of the installation 17 2.6 Protection for the solar heating system 17 2.7 Safety of the solar heating system 17 2.6 Protection for the solar heating system 18 3 Installation 19 3.1 Introductions 19 3.2 Packaging - 19 3.3 Environmental conditions 19 3.4 Technical specifications 22 3.5 Installation diagram 26 3.6 Water connections, Unvented 27 3.7 Water connections, Vented 29 3.10 Solar heating system 35 3.11 Electrical connection 35 3.12 Electroica connection + 29 < | | 1.5 | |
| 2 Working principle of the appliance 13 2.1 Introduction 13 2.2 General working principle of the appliance 13 2.3 The appliance's heating cycle 14 2.4 Protection for the appliance 15 2.5 Safety of the installation 17 2.6 Protection for the solar heating system 17 2.7 Safety of the solar heating system 18 3 Installation 19 3.1 Introduction 19 3.2 Packaging - 19 3.3 Environmental conditions- 19 3.4 Technical specifications 22 3.5 Installation diagram 26 3.6 Water connections, Unvented 27 3.7 Water connections, Vented 28 3.8 Gas connection 29 3.10 Solar heating system 35 3.11 Electrical connections 29 3.10 Solar heating system 35 3.11 Electrical connection 36 3.12 </th <th></th> <th>1.6</th> <th></th> | | 1.6 | |
| 2.1 Introduction 13 2.2 General working principle of the appliance 13 2.3 The appliance's heating cycle 14 2.4 Protection for the appliance 15 2.5 Safety of the installation 17 2.6 Protection for the solar heating system 17 2.7 Safety of the solar heating system 18 3 Installation 19 3.1 Introduction 19 3.2 Packaging 19 3.3 Environmental conditions 19 3.4 Technical specifications 22 3.5 Installation diagram 26 3.6 Water connections, Unvented 27 3.7 Water connections, Unvented 29 3.9 Air supply and flue 29 3.10 Solar heating system 35 3.11 Electrical connection 35 3.12 Electrical connection endure pressure 41 4 Conversion to a different gas category 45 5 Filling 51 <td< th=""><th></th><th>1.7</th><th>Overview of this document 11</th></td<> | | 1.7 | Overview of this document 11 |
| 2.2 General working principle of the appliance 13 2.3 The appliance's heating cycle 14 2.4 Protection for the appliance 16 2.5 Safety of the installation 17 2.6 Protection for the solar heating system 17 2.7 Safety of the solar heating system 18 3 Installation 19 3.1 Introduction 19 3.2 Packaging 19 3.3 Environmental conditions 19 3.4 Technical specifications 22 3.5 Installation diagram 26 3.6 Water connections, Unvented 27 3.7 Water connections, Vented 27 3.7 Water connections, Vented 29 3.10 Solar heating system 35 3.11 Electrical connection 29 3.10 Solar heating system 35 3.11 Electrically connecting the solar heating system controller 38 3.13 Checking the supply pressure and burner pressure 41 4 Conversion | 2 | | Working principle of the appliance 13 |
| 2.3 The appliance's heating cycle 14 2.4 Protection for the appliance 15 2.5 Safety of the installation 17 2.6 Protection for the solar heating system 17 2.7 Safety of the solar heating system 18 3 Installation 19 3.1 Introduction 19 3.2 Packaging 19 3.3 Environmental conditions 19 3.4 Technical specifications 22 3.5 Installation diagram 26 3.6 Water connections, Unvented 27 3.7 Water connections, Vented 28 3.8 Gas connection 29 3.0 Solar heating system 35 3.11 Electrical connection 29 3.12 Electrical connection 35 3.13 Checking the supply pressure and burner pressure 41 4 Conversion to a different gas category 45 5 Filling 50 5.1 Filling the appliance 50 5.2 <th></th> <th>2.1</th> <th>Introduction 13</th> | | 2.1 | Introduction 13 |
| 2.3 The appliance's heating cycle 14 2.4 Protection for the appliance 15 2.5 Safety of the installation 17 2.6 Protection for the solar heating system 17 2.7 Safety of the solar heating system 18 3 Installation 19 3.1 Introduction 19 3.2 Packaging 19 3.3 Environmental conditions 19 3.4 Technical specifications 22 3.5 Installation diagram 26 3.6 Water connections, Unvented 27 3.7 Water connections, Vented 28 3.8 Gas connection 29 3.0 Solar heating system 35 3.11 Electrical connection 29 3.12 Electrical connection 35 3.13 Checking the supply pressure and burner pressure 41 4 Conversion to a different gas category 45 5 Filling 50 5.1 Filling the appliance 50 5.2 <th></th> <th>2.2</th> <th>General working principle of the appliance 13</th> | | 2.2 | General working principle of the appliance 13 |
| 2.5 Safety of the installation 17 2.6 Protection for the solar heating system 17 2.7 Safety of the solar heating system 18 3 Installation 19 3.1 Introduction 19 3.2 Packaging 19 3.3 Environmental conditions 19 3.4 Technical specifications 22 3.5 Installation diagram 26 3.6 Water connections, Unvented 27 3.7 Water connections, Vented 28 3.8 Gas connection 29 3.11 Electrical connection 29 3.12 Electrical connection 35 3.12 Electrically connecting the solar heating system controller 38 3.13 Checking the supply pressure and burner pressure 41 4 Conversion to a different gas category 45 5.1 Filling 50 5.2 Filling the appliance 50 5.3 Draining unvented installations 54 6.4 Draining solar heating system <td< th=""><th></th><th>2.3</th><th></th></td<> | | 2.3 | |
| 2.6 Protection for the solar heating system 17 2.7 Safety of the solar heating system 18 3 Installation 19 3.1 Introduction 19 3.2 Packaging 19 3.3 Environmental conditions 19 3.4 Technical specifications 22 3.5 Installation diagram 26 3.4 Technical specifications, Unvented 27 3.7 Water connections, Unvented 27 3.7 Water connections, Vented 28 3.8 Gas connection 29 3.1 Electrical connection - 29 3.11 Electrical connection - 35 3.12 Electrically connecting the solar heating system controller 38 3.13 Checking the supply pressure and burner pressure 41 4 Conversion to a different gas category 45 5 Filling 50 5.1 Filling the appliance 50 5.2 Filling unvented installations 54 6 Draining unvented installations | | 2.4 | Protection for the appliance 15 |
| 2.7 Safety of the solar heating system 18 3 Installation 19 3.1 Introduction 19 3.2 Packaging 19 3.3 Environmental conditions 19 3.4 Technical specifications 22 3.5 Installation diagram 22 3.6 Water connections, Unvented 27 3.7 Water connections, Vented 28 3.8 Gas connection 29 3.9 Air supply and flue 29 3.10 Solar heating system 35 3.11 Electrical connection + 29 3.10 Solar heating system 35 3.11 Electrical connection + 29 3.10 Solar heating system 35 3.11 Electrical connecting the solar heating system controller 38 3.13 Checking the supply pressure and burner pressure + 41 4 Conversion to a different gas category 45 5.1 Filling the appliance + 50 5.2 Filling solar heating system - 51 < | | 2.5 | , |
| 3 Installation 19 3.1 Introduction 19 3.2 Packaging 19 3.3 Environmental conditions 19 3.4 Technical specifications 22 3.5 Installation diagram 26 3.6 Water connections, Unvented 27 3.7 Water connections, Vented 28 3.6 Gas connection 29 3.10 Solar heating system 29 3.11 Electrical connection + 29 3.12 Electrically connecting the solar heating system controller- 38 3.12 Electrically connecting the solar heating system controller- 38 3.13 Checking the supply pressure and burner pressure 41 4 Conversion to a different gas category 45 5 Filling - 49 5.1 Filling the appliance 50 5.2 Filling solar heating system 51 6 Draining unvented installations 54 6.3 Draining solar heating system 55 7 The control panel- | | 2.6 | |
| 3.1 Introduction 19 3.2 Packaging - 19 3.3 Environmental conditions- 19 3.4 Technical specifications 22 3.5 Installation diagram 26 3.6 Water connections, Unvented 27 3.7 Water connections, Vented 28 3.8 Gas connection 29 3.9 Air supply and flue 29 3.10 Solar heating system- 35 3.11 Electrical connection - 35 3.12 Electrical connecting the solar heating system controller- 38 3.13 Checking the supply pressure and burner pressure 41 4 Conversion to a different gas category 45 5 Filling - 49 5.1 Filling the appliance 50 5.2 Filling solar heating system 51 6 Draining unvented installations 54 6.1 Draining unvented installations 55 7.3 The control panel- 57 7.1 Introduction 57 | | 2.7 | Safety of the solar heating system 18 |
| 3.2 Packaging | 3 | | Installation |
| 3.3 Environmental conditions- 19 3.4 Technical specifications 22 3.5 Installation diagram 26 3.6 Water connections, Unvented 27 3.7 Water connections, Unvented 28 3.8 Gas connection 29 3.9 Air supply and flue 29 3.10 Solar heating system 35 3.11 Electrical connection - 35 3.12 Electrically connecting the solar heating system controller 38 3.11 Checking the supply pressure and burner pressure 41 4 Conversion to a different gas category 45 5 Filling - 49 5.1 Filling the appliance 50 5.2 Filling solar heating system 51 6 Draining unvented installations 54 6.2 Draining unvented installations 54 6.3 Draining solar heating system 55 7 The control panel 57 7.1 Introduction 57 7.2 Controls - 57 | | 3.1 | Introduction 19 |
| 3.4 Technical specifications 22 3.5 Installation diagram 26 3.6 Water connections, Unvented 27 3.7 Water connections, Vented 28 3.8 Gas connection 29 3.9 Air supply and flue 29 3.10 Solar heating system 35 3.11 Electrical connection 35 3.12 Electrically connecting the solar heating system controller 38 3.13 Checking the supply pressure and burner pressure 41 4 Conversion to a different gas category 45 5 Filling 50 5.1 Filling the appliance 50 5.2 Filling solar heating system 51 6 Draining unvented installations 54 6.1 Draining unvented installations 55 7 The control panel 57 7.1 Introduction 57 7.2 Controls 57 7.3 Meaning of icons 57 7.4 Electronic controller ON/OFF switch 57 < | | 3.2 | Packaging |
| 3.5 Installation diagram 26 3.6 Water connections, Unvented 27 3.7 Water connections, Vented- 28 3.8 Gas connection 29 3.9 Air supply and flue 29 3.10 Solar heating system 35 3.11 Electrical connection 35 3.12 Electrically connecting the solar heating system controller 38 3.12 Checking the supply pressure and burner pressure 41 4 Conversion to a different gas category 45 5 Filling 49 50 5.1 Filling the appliance 50 5.2 Filling solar heating system 51 6 Draining unvented installations 54 6.1 Draining unvented installations 55 6.3 Draining solar heating system 55 7 The control panel 57 7.1 Introduction 57 7.2 Controls 57 7.3 Meaning of icons 57 7.4 Electronic controller ON/OFF switch 57 </th <th></th> <th>3.3</th> <th>Environmental conditions 19</th> | | 3.3 | Environmental conditions 19 |
| 3.6 Water connections, Unvented 27 3.7 Water connections, Vented- 28 3.8 Gas connection - 29 3.9 Air supply and flue - 29 3.10 Solar heating system - 35 3.11 Electrical connection - 35 3.12 Electrical connecting the solar heating system controller - 38 3.12 Electrically connecting the solar heating system controller - 38 3.12 Electrically connecting the solar heating system controller - 38 3.13 Checking the supply pressure and burner pressure - 41 4 Conversion to a different gas category - 45 5.1 Filling the appliance - 50 5.2 Filling solar heating system - 50 6 Draining unvented installations - 53 6.1 Draining unvented installations - 55 6.3 Draining solar heating system - 55 7 The control panel - 57 7.1 Introduction - 57 7.3 Meaning of icons - 57 7.4 Electronic controller | | 3.4 | Technical specifications 22 |
| 3.7 Water connections, Vented- 28 3.8 Gas connection 29 3.9 Air supply and flue - 29 3.10 Solar heating system - 35 3.11 Electrical connection - 35 3.12 Electrical connecting the solar heating system controller- 38 3.12 Electrically connecting the solar heating system controller- 38 3.12 Electrically connecting the solar heating system controller- 38 3.11 Electrical to a different gas category 41 4 Conversion to a different gas category 45 5 Filling - 49 5.1 Filling the appliance - 50 5.2 Filling solar heating system - 51 6 Draining unvented installations - 53 6.1 Draining unvented installations - 55 6.3 Draining solar heating system - 55 7 The control panel - 57 7.1 Introduction - 57 7.2 Controls - 57 7.3 Meaning of icons - 57 < | | 3.5 | 0 |
| 3.8 Gas connection 29 3.9 Air supply and flue 29 3.10 Solar heating system 35 3.11 Electrical connection 35 3.12 Electrical connecting the solar heating system controller 38 3.11 Electrically connecting the solar heating system controller 38 3.12 Electrically connecting the solar heating system controller 38 3.13 Checking the supply pressure and burner pressure 41 4 Conversion to a different gas category 45 5 Filling 49 5.1 Filling the appliance 50 5.2 Filling solar heating system 50 5.2 Filling solar heating system 51 6 Draining unvented installations 54 6.2 Draining vented installations 55 6.3 Draining solar heating system 55 7 The control panel 57 7.1 Introduction 57 7.2 Controls 57 7.3 Meaning of icons 57 7.4 < | | 3.6 | |
| 3.9 Air supply and flue | | - | |
| 3.10 Solar heating system 35 3.11 Electrical connection 35 3.12 Electrically connecting the solar heating system controller- 38 3.13 Checking the supply pressure and burner pressure - 41 4 Conversion to a different gas category 45 5 Filling - 49 5.1 Filling the appliance 50 5.2 Filling solar heating system 51 6 Draining 53 6.1 Draining unvented installations 54 6.2 Draining vented installations 55 6.3 Draining solar heating system 55 7 The control panel 57 7.1 Introduction 57 7.2 Controls 57 7.3 Meaning of icons 57 7.4 Electronic controller ON/OFF switch 57 7.5 Navigation buttons 58 | | | |
| 3.11 Electrical connection | | | |
| 3.12 Electrically connecting the solar heating system controller- 38 3.13 Checking the supply pressure and burner pressure - 41 4 Conversion to a different gas category 45 5 Filling - 49 5.1 Filling the appliance 50 5.2 Filling solar heating system- 51 6 Draining 53 6.1 Draining unvented installations 54 6.2 Draining vented installations 55 6.3 Draining solar heating system 55 7 The control panel- 57 7.1 Introduction 57 7.3 Meaning of icons- 57 7.4 Electronic controller ON/OFF switch 57 7.5 Navigation buttons - 58 | | | |
| 3.13 Checking the supply pressure and burner pressure 41 4 Conversion to a different gas category 45 5 Filling 49 5.1 Filling the appliance 50 5.2 Filling solar heating system 51 6 Draining 53 6.1 Draining unvented installations 54 6.2 Draining vented installations 55 6.3 Draining solar heating system 55 7 The control panel 57 7.1 Introduction 57 7.2 Controls 57 7.3 Meaning of icons 57 7.4 Electronic controller ON/OFF switch 57 7.5 Navigation buttons 58 | | - | |
| 4 Conversion to a different gas category 45 5 Filling - 49 5.1 Filling the appliance 50 5.2 Filling solar heating system 51 6 Draining 53 6.1 Draining unvented installations 54 6.2 Draining vented installations 55 6.3 Draining solar heating system 55 7 The control panel 57 7.1 Introduction 57 7.2 Controls 57 7.3 Meaning of icons 57 7.4 Electronic controller ON/OFF switch 57 7.5 Navigation buttons 58 | | - | |
| 5 Filling | | 3.13 | Checking the supply pressure and burner pressure 41 |
| 5.1 Filling the appliance 50 5.2 Filling solar heating system- 51 6 Draining | 4 | | Conversion to a different gas category 45 |
| 5.1 Filling the appliance 50 5.2 Filling solar heating system- 51 6 Draining | 5 | | Filling 49 |
| 5.2 Filling solar heating system- 51 6 Draining 53 6.1 Draining unvented installations 54 6.2 Draining vented installations 55 6.3 Draining solar heating system 55 7 The control panel 57 7.1 Introduction 57 7.2 Controls 57 7.3 Meaning of icons 57 7.4 Electronic controller ON/OFF switch 57 7.5 Navigation buttons 58 | | 5.1 | |
| 6.1 Draining unvented installations | | 5.2 | |
| 6.1 Draining unvented installations | 6 | | Draining |
| 6.2 Draining vented installations - - - - 55 6.3 Draining solar heating system - - - - 55 7 The control panel - - - - - 57 7.1 Introduction - - - - - 57 7.2 Controls - - - - - 57 7.3 Meaning of icons - - - - - 57 7.4 Electronic controller ON/OFF switch - - - - 57 7.5 Navigation buttons - - - - - 58 | Ŭ | 61 | 5 |
| 6.3 Draining solar heating system | | | 0 |
| 7.1 Introduction - - - 57 7.2 Controls - - - 57 7.3 Meaning of icons - - - 57 7.4 Electronic controller ON/OFF switch - - - 57 7.5 Navigation buttons - - - - 58 | | | |
| 7.1 Introduction - - - 57 7.2 Controls - - - 57 7.3 Meaning of icons - - - 57 7.4 Electronic controller ON/OFF switch - - - 57 7.5 Navigation buttons - - - - 58 | 7 | | The control nanel, |
| 7.2 Controls | ' | 71 | • |
| 7.3Meaning of icons-577.4Electronic controller ON/OFF switch577.5Navigation buttons-58 | | | |
| 7.4Electronic controller ON/OFF switch577.5Navigation buttons58 | | | |
| 7.5 Navigation buttons 58 | | | |
| | | | |
| | | | • |

| 8 | | Status of the appliance 59 |
|-----|-------|---|
| | 8.1 | Introduction |
| | 8.2 | Operating modes |
| | 8.3 | Error conditions |
| | 8.4 | Service condition |
| | 8.5 | Collector temperature warning |
| | 8.6 | Q/T Sensor warning |
| | | v |
| 9 | | Starting and running 61 |
| | 9.1 | Introduction |
| | 9.2 | Starting the appliance |
| | 9.3 | The appliance's heating cycle |
| | 0.0 | |
| 10 | | Shutting down 63 |
| | 10.1 | Introduction |
| | 10.2 | Shut the appliance down for a brief period ("OFF mode") |
| | 10.3 | Electrically isolating the appliance |
| | 10.4 | Shutting the appliance down for a long period |
| | 10.4 | |
| 11 | | Main menu 65 |
| ••• | 11.1 | |
| | 11.2 | Notational convention for menu-related instructions |
| | 11.2 | Switching on the "ON mode" |
| | 11.3 | Setting the water temperature |
| | 11.5 | Week program |
| | 11.6 | Starting and stopping the week program |
| | 11.0 | Changing the appliance's standard week program |
| | 11.8 | Adding times to a week program |
| | 11.0 | Deleting times from a week program |
| | 11.10 | Extra period |
| | 11.10 | Programming an extra period |
| | 11.11 | Settings |
| | 11.12 | Settings/1 |
| 12 | | Service program 73 |
| 12 | 12.1 | |
| | 12.1 | Setting the hysteresis |
| | 12.2 | Displaying the error history |
| | 12.3 | Displaying the appliance history |
| | 12.4 | Displaying the appliance |
| | 12.5 | Switching the pump on or off |
| | 12.0 | Setting the service interval |
| | 12.7 | Setting legionella prevention |
| | 12.0 | Solar heating system configuration |
| | 12.9 | Solar heating system configuration |
| | 12.10 | |
| 13 | | Troubleshooting 77 |
| | 13.1 | |
| | 13.2 | Troubleshooting table for general errors |
| | 13.2 | Troubleshooting table for displayed errors |
| | 13.3 | Displayed warnings |
| | 13.4 | Displayed warnings |
| 14 | | Maintenance frequency 91 |
| | 14.1 | |
| | 14.2 | Determining service interval |
| | | |

| | Performing maintenance 93 |
|------|--|
| 15.1 | Introduction 93 |
| 15.2 | Preparation for maintenance 93 |
| 15.3 | Water-side maintenance 95 |
| 15.4 | Gas-side maintenance 96 |
| 15.5 | Solar collector maintenance 96 |
| 15.6 | Finalizing maintenance96 |
| | Warranty (certificate) 97 |
| 16.1 | General warranty 97 |
| 16.2 | Tank warranty 97 |
| 16.3 | Collector warranty 97 |
| 16.4 | Conditions for Installation and use 97 |
| 16.5 | Exclusions 98 |
| 16.6 | Scope of the warranty 98 |
| 16.7 | Claims 98 |
| 16.8 | Obligations of A.O. Smith 98 |
| | Appendices99 |
| 17.1 | Introduction 99 |
| 17.2 | Menu structure |
| 17.3 | Electrical diagram for the appliance |
| 17.4 | Electrical diagram, solar heating system |
| 17.5 | Week program card |
| | 15.2 15.3 15.4 15.5 15.6 16.1 16.2 16.3 16.4 16.5 16.6 16.7 16.8 17.1 17.2 17.3 17.4 |

Table of contents



1

Introduction

1.1 About the appliance



1.2 What to do if you smell gas

This manual describes how to install, service and use the SGE appliance. The SGE appliance is a condensing boiler with a fan in the air intake. The water is heated partly by means of an external heat exchanger that can be connected to e.g. a solar energy source.

The SGE can be installed as either an open or room-sealed appliance. A concentric chimney connector is fitted standard to the appliance, but a parallel system can also be connected.

The alternative installation types are B23, C13, C33, C43, C53 and C63. The information in this manual applies to the: SGE 40 and SGE 60.

The appliance has been manufactured and equipped in accordance with the European standard for gas-fired storage water heaters for the production of domestic hot water (EN 89). The appliances are therefore compliant with the European Directive for Gas Appliances, and and are entitled to bear the CE mark.

Warning

Read this manual carefully before starting up the water heater. Failure to read the manual and to follow the printed instructions may lead to personal injury and damage to the appliance.

🕼 Warning

If there is a gas smell:

No naked flames! No smoking!

Avoid causing sparks! Do not use any electrical equipment or switch, i.e. no telephones, plugs or bells

Open windows and doors!

Shut off the mains gas supply valve!

Warn occupants and leave the building!

After leaving the building, alert the gas distribution company or your installation engineer.

1.3 Regulations

As the (end) user, installation engineer or service and maintenance engineer, you must ensure that the entire installation complies, as a minimum, with the official local:

- building regulations;
- · energy supplier's directives for existing gas installations;
- · directives and technical guidelines for natural gas installations;
- · safety requirements for low-voltage installations;
- · regulations governing the supply of drinking water;
- regulations governing ventilation in buildings;
- regulations governing the supply of air for combustion;
- regulations governing the discharge of products of combustion;
- · requirements for installations that consume gas;
- regulations governing indoor waste water disposal;
- regulations imposed by fire brigade, power companies and municipality.



Furthermore, the installation must comply with the manufacturer's instructions.

Note

Later amendments and/or additions to all regulations, requirements and guidelines published on or prior to the moment of installing, will apply to the installation.

1.4 Target groups

The three target groups for this manual are:

- · (end) users;
- installation engineers;
- · service and maintenance engineers.

Symbols on each page indicate the target groups for whom the information is intended. See the table.

Target group symbols

| Symbol | Target group |
|--------|----------------------------------|
| | (End) user |
| | Installation engineer |
| × | Service and maintenance engineer |

1.5 Maintenance

A service should be carried out at least once a year, both on the water side and on the gas side. Maintenance frequency depends, among other things, on the water quality, the average burning time per day and the set water temperature.

Note

To determine the correct maintenance frequency, it is recommended to arrange for the service and maintenance engineer to check the appliance on both the water and gas side within three months following installation. Based on this check, the best maintenance frequency can be determined.

Note

Regular maintenance extends the service life of the appliance.

🔊 Note

Both the end user and the service and maintenance engineer are responsible for regular maintenance. They will need to establish clear agreements on this.

Note

If the appliance is not regularly maintained, the warranty will become void.

1.6 Forms of notation

The following notation is used in this manual:

Note

Important information.

📕 Caution

Ignoring this information can lead to the appliance being damaged.

, Warning

Failure to carefully read this information may lead to personal injury and serious damage to the appliance.



1.7 Overview of this document

| Chapter | Target groups | Description |
|--|---------------|---|
| Working principle of the appliance | | This chapter describes the working principle of the appliance. |
| Installation | | This chapter describes the installation activity to be completed before you start the appliance for the first time. |
| Conversion to a different gas category | | This chapter describes the activities required to convert the appliance to a different gas category. |
| Filling | | This chapter describes how to fill the appliance. |
| Draining | | This chapter describes how to drain the appliance. |
| The control panel | | This chapter describes the general control of the appliance using the display. |
| Status of the appliance | | This chapter describes the status (mode or condition) that the appliance may have, and possible actions to take. |
| Starting and running | | This chapter describes how to start the appliance running. The general heating cycle of the appliance is also described. |
| Shutting down | | This chapter describes how to shut the appliance down for a brief or long period of time. |
| Main menu | | This chapter describes the main menu of the display. This is the actual menu for the user, however the installation engineer and service and maintenance engineers will also need to use this menu. |
| Service program | | This chapter describes the service menu. It is mainly intended for the installation engineer and service and maintenance engineers. End users may also refer to this chapter for additional information about the appliance. |
| Troubleshooting | | This chapter is mainly intended for the installation engineer and the service and maintenance engineer. It describes appliance errors. These errors are indicated on the display. A troubleshooting table of possible causes and solutions is provided. End users may also refer to this chapter for additional information about the appliance. |
| Maintenance frequency | A. X | This chapter describes how to determine the optimum frequency at which to carry out maintenance. Both the end user and the service and maintenance engineer are responsible for regular maintenance. They need to reach clear agreement on this. |
| | | Note If the appliance is not regularly maintained, the warranty will become void. |
| Performing maintenance | × | This chapter sets out the maintenance tasks to be carried out during a service. |
| Warranty (certificate) | | This chapter states the warranty terms and conditions. |

Introduction





2

Working principle of the appliance

2.1 Introduction

2.2 General working principle of the appliance

Topics covered in this chapter:

- General working principle of the appliance;
- The appliance's heating cycle;
- Protection for the appliance;
- Safety of the installation;
- Protection for the solar heating system.

The figure shows a cut-away view of the appliance.

In this appliance, the cold water enters the bottom of the tank through the cold water inlet (14). The water is heated by means of a heat exchanger (55) connected to a solar heating system (2.6 "Protection for the solar heating system") and a gas-fired heat exchanger (11). The air required by the latter for combustion is forced into the burner (17) by the fan (18).

The heated tap water leaves the tank through the hot water outlet (2). Once the appliance is completely filled with water, it will constantly be under mains water pressure. As hot water is drawn from the appliance, cold water is immediately added.

The gas is fed to the burner via the gas control (16). The modulated supply of gas and air ensures that the optimum gas/air mixture is always achieved. The special construction of the burner causes the mixture to form a vortex (cyclone effect) before it becomes ignited. This vorticity improves the ignition on the hot surface igniter (20), as well as ensuring optimum combustion efficiency. The special design of the heat exchanger (11) ensures that the flue gases are first led downwards via the combustion chamber, then upwards via the heat exchanger, and downwards again alongside the water in the tank. The flue gases gradually become cooler in the process. Because the cooled flue gases flow alongside the cold water lower down in the tank, they start to condense. This condensation causes latent heat energy to be transferred to the cooler water, thereby increasing the performance of the unit. The condensate yielded by this process is discharged via the siphon (23).

The insulation layer (24) prevents heat loss. The inside of the tank is enamelled to protect against corrosion. The anodes (9) provide extra protection against corrosion.

The appliance has an inspection and cleaning opening (12) for maintenance.



Cut-away view of the appliance

Legend

Only applicable numbers are mentioned.1. cover2. hot water outlet3. electrical connector block4. electronic controller

- 5. pressure switch
- 6. control panel
- 7. temperature sensor T_1
- 8. combustion chamber
- 9. anode
- 10. tank
- 11. heat exchanger
- 12. inspection and cleaning opening
- 13. temperature sensor T₂
- 14. cold water inlet
- 15. drain valve
- 16. gas control
- 17. burner
- 18. fan
- 19. air supply hose
- 20. hot surface igniter
- 21. flame probe
- 22. chimney pipe
- 23. siphon
- 24. insulation layer
- 29. pallet
- 55. heat exchanger (e.g. solar heating system)
- 56. temperature sensor S₂

2.3 The appliance's heating cycle

1)-2 3 O (4) (19) (5) (21) 9 (8) -22 Ø) (13) Ø) (10 (23) Ð (15 Ø 24 IMD-0574 R1

The net water temperature (T_{net}) in the appliance is used to regulate when both the gas burner and the solar heating system are started and stopped. T_{net} is the curve shown in the figure. The controller uses two measured values to calculate this temperature: T₁ (7) and T₂ (13). In addition, temperatures S₁ and S₂ are used by the solar heating system controller. S₁ is measured in the solar collector and S₂ between the inlet and outlet of the heat exchanger (55).

The other settings that govern the control behaviour are:

 T_{set} T_{set} is the the required water temperature that has been set on the appliance (11.4.1 "Setting the water temperature via the SET POINT MENU"). As soon as T_{net} falls below T_{set} , the water heating via the solar heating system is started, however, only if the temperature of the heating fluid (S₁) is a certain (adjustable) value higher than the temperature measured at the appliance (sensor S₂). As soon as ($T_{net} = T_{set} = T_{solar limit}$), heating via the solar heating system is stopped. There is one exception to this rule, and that is when $T_{solar limit}$ is set to a higher value than T_{set} .



• Hysteresis


The moment T_{net} falls below ($T_{set} - T_{solar \ diff} - Hysteresis$), the controller registers such a heat demand that the gas burner and the solar heating system jointly heat the water. The solar heating system is only employed when the temperature measured by S_1 is a certain (adjustable) value grater than that of S_2 .

Tsolar diff

When T_{net} exceeds ($T_{set} - T_{solar diff}$), the gas burner is shut off and the water is heated exclusively by the solar heating system. When T_{net} rises above T_{set} (provided $_{Tset} = T_{solar limit}$), the solar heating system switches off. The value of $T_{solar diff}$ is adjustable (12.9.5 "Setting the solar difference").

 T_{solar limit} Preset (12.9.4 "Setting the solar limit temperature") water temperature at which heating via the solar heating system is stopped.

Graphical representation of heating cycle



Note

T_{net} can rise above T_{set}. However, this is only possible if T_{solar limit} is increased via the service menu.

Note

T_{solar limit} can be lower than T_{set} ; this will mean that T_{net} can never be equal to T_{set} .

2.4 Protection for the appliance

2.4.1 Introduction

The electronic controller monitors the water temperature, helps ensure the safe use of the solar heating system, and ensures safe combustion. This takes place using:

- the Appliance water temperature protection
- the Gas valve
- the Fan
- the Pressure switch
- the Flame probe



2.4.2 Appliance water temperature protection

The electronic controller (4) controls and monitors the safety of the appliance by means of sensors T_1 and T_2 . S_2 is also used for protection of the appliance. However, this is primarily intended for control of the solar heating system (2.6 "Protection for the solar heating system").

The table explains the functioning of these temperature sensors.

Temperature protection

| Protection | Description |
|---|--|
| Against frost: - T ₁ < 5°C - T ₂ < 5°C | The frost protection cuts in. The water is heated to 20°C. |
| For maximum water temperature: - $T_1 > 85^{\circ}C$ - $T_2 > 85^{\circ}C$ - $S_2 > 85^{\circ}C$ | The high-limit safeguard serves to prevent overheating and/or excessive formation of scale in the appliance. If the high-limit safeguard is activated, the heating is stopped. This causes the water in the tank to cool down. Once the water has cooled sufficiently ($T_1 < 78^{\circ}$ C), the electronic controller resets the appliance. |
| For extra safety: - T ₁ > 93°C - T ₂ > 93°C - S ₂ > 93°C | A lockout error of the water heater controller takes place. The controller must be manually reset before the appliance can resume operation (8.3 "Error conditions"). The reset may only be performed if $T_1 < 78^{\circ}$ C. |

2.4.3 Gas valve

The electronic controller opens the gas valve so that gas can be supplied to the burner. As a safety measure, the gas valve has a double shut-off. The double shut-off guarantees complete isolation of the appliance from the gas supply.

To help ensure smooth ignition, the gas valve opens gradually ('softlite").

2.4.4 Fan

The fan (18) provides an optimum air supply when there is a heat demand. As a safety feature, the fan ensures that any gases present in the combustion chamber are removed, both before and after combustion. We refer to this as pre- and post-purge.

The fan speed is continuously monitored by the electronic controller (4). The electronic controller takes control if the speed of rotation varies too much from the set value.

2.4.5 Pressure switch

The pressure switch ensures the discharge of flue gases and the supply of incoming air during the pre-purge and normal running of the appliance. The default state of the pressure switch is open. When sufficient pressure difference is reached, the pressure switch closes. However, in the event of a fault, the pressure switch is tripped open, and the heating cycle is interrupted. The table shows the trip point per appliance.

🔊 Note

The trip point of the pressure switch is not adjustable.

Pressure switch trip points

| Appliance | Closing pressure difference | Opening pressure difference |
|-----------|--------------------------------|--------------------------------|
| SGE 40 | | |
| SGE 60 | <u>></u> 675 Pa | <u><</u> 645 Pa |



2.4.6 Flame probe

To ensure that no gas can flow when there is no combustion, the water heater is fitted with a flame probe (21). The electronic controller uses this probe to detect the presence of a flame, by means of ionisation detection. The electronic controller closes the gas control the instant it detects that there is a gas flow but no flame.

2.5 Safety of the installation

In addition to the appliance's standard built-in safety monitoring, the appliance must also be protected by an expansion vessel, expansion valve, pressure reducing valve, non-return valve and a T&P valve.

The use of an expansion vessel, expansion valve and/or pressure reducing valve depends on the type of installation: unvented or vented.

2.5.1 Unvented installation

With an unvented installation, an expansion valve valve and expansion vessel prevent the buildup of excessive pressure in the tank. This prevents damage being caused to the enamelled coating (in the appliance) or to the tank. A non-return valve prevents excessive pressure buildup in the water supply system. This valve also prevents water from flowing backwards from the tank into the cold water supply system. The pressure reducing valve protects the installation against an excessively high water supply pressure (> 8 bar). These components are fitted to the cold water pipe (3.7 "Water connections, Vented").

2.5.2 Vented installation

With a vented installation, excess pressure is taken up by the open cold water head tank. The height of the head tank determines the working pressure in the water heater, which may not exceed 8 bar. The installation must also be fitted with a vent pipe from the hot water pipe, that opens into the cold water tank.

Ideally, the vent pipe should discharge into a separate tundish/drain or otherwise to the open cold water head tank. The water heater should also be fitted on the hot water side with a stop valve (3.6.2 "Hot water side").

2.5.3 T&P valve

A T&P valve is only mandatory in an unvented installation. However, A.O. Smith also recommends the use of a T&P valve in vented installations.

A T&P (Temperature and Pressure Relief) valve monitors the pressure in the tank and the water temperature at the top of the tank. If the pressure in the tank becomes excessive (> 10 bar) or the water temperature is too high (> 97°C), the valve will open. The hot water can now flow out of the tank. Because the appliance is under water supply pressure, cold water will automatically flow into the tank. The valve remains open until the unsafe situation has been rectified. The appliance is fitted standard with a connecting point for a T&P valve (3.6.2 "Hot water side").

2.6 Protection for the solar heating system

2.6.1 Drain-back tank

The solar heating system may optionally be equipped with a drain-back tank. The tank fills itself with the heating fluid when there is no heat demand. This avoids overheating of the solar heating system. The high insulation factor of the tank also protects the system from freezing of the fluid. The use of the drainback tank also serves to extend the useful life of the fluid.

The presence of a drain-back tank is set (12.9.1 "Setting the drain-back tank") during the installation. Refer to the solar heating system manual for more details.



2.6.2 Fluid temperature

The heat exchanger of the solar heating system may be filled with glycol. If the temperature of the heating fluid is too high, a signal is sent to the controller of the solar collector and the pump of the solar collector is switched off. This signal is passed to the controller by temperature sensor S_1 .

At present, no heating fluids other than glycol are supported. The heating fluid type is set (12.9.2 "Setting the heating fluid type in the solar heating system") during installation.

Temperature protection for solar heating system

| Protection | Description |
|--|---|
| Maximum temperature S_1 , if solar heating system is filled with glycol: - $S_1 > 130^{\circ}C$ | The pump of the solar heating system switches off when the temperature of the heating fluid at S_1 exceeds the maximum value. The solar heating system enters error mode. The error is also visible on the display of the SGE appliance |

2.7 Safety of the solar heating system

2.7.1 Expansion vessel

The solar heating system must be equipped with an expansion vessel (16). An expansion vessel serves to limit pressure variations in the system. The expansion vessel in the solar heating system can withstand a maximum pressure of 6 bar. The supply pressure to the expansion vessel depends on the static head of the system.

Besides the expansion vessel, the system is protected from overpressure by an expansion valve (2.7.2 "Expansion valve").

2.7.2 Expansion valve

The solar heating system is equipped with an expansion valve (23). The expansion valve monitors the pressure in the solar heating system. If the pressure is excessive (> 6 bar), then the valve will open. The hot water can now flow out of the installation. The valve remains open until the unsafe situation has passed, i.e. until the pressure has fallen back below 6 bar.



Because the installation is always under pressure and is not automatically filled, the system will again need to be replenished (5 "Filling").



3

Installation

🕅 Warning

Installation work should be carried out by an approved installation engineer in compliance with the general and local regulations imposed by the gas, water and power supply companies and the fire service.

The appliance may only be installed in a room that complies with the requirements stated in national and local ventilation regulations (1.3 "Regulations").

3.1 Introduction

- This chapter describes the installation activities to be carried out before you actually start using the appliance (9 "Starting and running"), namely:
- Packaging;
- Environmental conditions;
- Technical specifications;
- Water connections, Vented;
- Water connections, Unvented;
- Water connections, Vented;
- Gas connection;
- Solar heating system;
- Air supply and flue;
- Electrical connection;
- Checking the supply pressure and burner pressure.

For conversion to a different gas category, see conversion (4 "Conversion to a different gas category").

3.2 Packaging

To avoid damaging the appliance, remove the packaging carefully.

We recommend unpacking the appliance at or near its intended location.

Caution

The appliance may only be manoeuvred in an upright position. Take care that the appliance is not damaged after unpacking.

3.3 Environmental conditions The appliance is suitable for either open or room-sealed combustion. If installed as a room-sealed appliance, then the availability of the necessary external air supply will depend on the place of installation. In this event, there are no additional ventilation requirements.

If the appliance is to be installed as an open system, then it will be subject to the guidelines and ventilation regulations that are in force locally.

The alternative installation types are B23, C13, C33, C43, C53 and C63.

Caution

The appliance may not be used in rooms where chemical substances are stored or used, due to the risk of explosion and/or corrosion of the appliance. Some propellants, bleaching agents, degreasing agents etc. disperse vapours which are explosive and/or which cause accelerated corrosion. If the appliance is used in a room in which such substances are present, the warranty will be void.



3.3.1 Air humidity and ambient temperature

The boiler room must be frost-free, or be protected against frost. The table shows the environmental conditions that must be adhered to for correct functioning of the electronics present in the appliance to be guaranteed.

Air humidity and ambient temperature specifications

| Air humidity and ambient temperature | |
|--------------------------------------|---------------------------------------|
| Air humidity | max. 93% RV at +25°C |
| Ambient temperature | Functional: $0 \le T \le 60^{\circ}C$ |

3.3.2 Appliance maximum floor load

In connection with the appliance's weight, take account of the maximum floor loading, refer to the table.

Weight specifications related to maximum floor load

| Weight (kg) of the appliance filled with water | |
|--|-----|
| SGE 40 and 60 | 615 |

3.3.3 Water composition

The appliance is intended for heating drinking water. The drinking water must comply with the regulations governing drinking water for human consumption. The table gives an overview of the specifications.

Water specifications

| Water composition | |
|-----------------------------------|--|
| Hardness (alkaline earth ions) | > 1.00 mmol/l: German hardness> 5.6° dH French hardness > 10.0° fH English hardness > 7.0° eH |
| Conductivity | > 125 µS/cm |
| Acidity (pH value) | 7.0 < pH value < 9.5 |

Note

If the water specifications deviate from those stated in the table, then the tank protection cannot be guaranteed (16 "Warranty (certificate)").



3.3.4 Working clearances

For access to the appliance, it is recommended that the following clearances are observed (see figure):

- AA: around the appliance's control column and cleaning openings: 100 cm.
- BB: all sides of the appliance: 50 cm.
- Above the appliance (room to replace the anodes):
 - 100 cm if using fixed anodes, or
 - 50 cm if using flexible anodes.


If the available clearance is less than 100 cm, flexible magnesium anodes may be ordered.

Note

When installing the appliance, be aware that any leakage from the tank and/or connections can cause damage to the immediate environment or floors below the level of the boiler room. If this is the case, the appliance should be installed above a wastewater drain or in a suitable metal leak tray.

The leak tray must have an appropriate wastewater drain and must be at least 5cm deep with a length and width at least 5cm greater than the diameter of the appliance.

Working clearances





3.4 Technical specifications


The appliance is supplied without accessories. Check the


dimensions (3.4.1 "Dimensions of the appliance"), gas data (3.4.3 "Gas data") and other specifications (3.4.2 "General and electrical specifications") of any accessories you plan to use.

3.4.1 Dimensions of the appliance

Plan and elevation of the appliance

Legend See the table.





IMD-0573 R1



| Dime nsion | Description | SGE 40 | SGE 60 |
|---------------|---|--------|---------------------------------|
| А | Total height | | 2055 |
| С | Position on pallet | | 490 |
| D | Appliance diameter | | 705 |
| Е | Depth | | 925 |
| F | Width | | 755 |
| G | Diameter of chimney flue | | 100 / 150 |
| Н | Height of chimney flue | | 1995 |
| Hx | x position of chimney flue outlet | | 260 |
| Hy | y position of chimney flue outlet | | 370 |
| К | Height of gas/burner connection | | 1945 |
| М | Height of cold water supply | | 185 |
| Ν | Height of hot water outlet | | 2055 |
| Ny | y position of hot water outlet | | 205 |
| Р | Height of cleaning opening | | 365 |
| R | Height of drain valve connection | | 180 |
| S | Height of T&P valve connection | | 1485 |
| Т | Height of coil inlet | | 630 |
| U | Height of coil outlet | | 305 |
| V | Height of recirculation connection | | 1035 |
| W | Height of condensation drain | | 765 |
| Х | Height of heat exchanger supply | | 1465 |
| Y | Height of heat exchanger discharge | | 855 |
| Z | Height of electric element connection | | 755 |
| 1 | Cold water supply connection (male) | | R 1 ¹ / ₂ |
| 2 | Hot water outlet (male) | | R 1 ¹ / ₂ |
| 3 | Gas control connection (female) | | R ³ / ₄ |
| 4 | Drain valve connection (female) | | ³ / ₄ " |
| 5 | T&P valve connection (female) | | 1 - 11.5 NPT |
| 6 | Cleaning/inspection opening | | 95 x 70 |
| 7 | Condensation drainage connection (female) | | Rp 1 |
| 9 | Coil inlet connection (female) | | Rp 1 |
| 10 | Coil outlet connection (female) | | Rp 1 |
| 11 | Electric element connection (female) | | R 1 ¹ / ₂ |
| 12 | Heat exchanger supply conn. (female) | | Rp 1 |
| 13 | Heat exchanger discharge conn. (female) | | Rp 1 |
| 14 | Recirculation connection (female) | | Rp 1 |

Dimensions (all dimensions in mm, unless otherwise stated)



3.4.2 General and electrical specifications

General and electrical specifications

| DESCRIPTION | Unit | SGE 40 | SGE 60 |
|--|------------|--------|--------|
| Capacity | litres | | 370 |
| Empty weight | kg | | 245 |
| Maximum operating pressure | bar | | 8 |
| Maximum temperature of control thermostat | °C | | 80 |
| Number of anodes | - | | 4 |
| Fan speed at ignition | rpm | | 4920 |
| Working speed of fan | rpm | | 6300 |
| Diameter of air restrictor | mm | | 34.0 |
| Heating-up time $\Delta T = 45^{\circ}C$ | minutes | | 11 |
| Electrical power consumption | W | | 275 |
| Power consumption of solar heating system controller | W | | 700 |
| Supply voltage (-15% +10% VAC) | volts | | 230 |
| Mains frequency | Hz (± 1Hz) | | 50 |
| IP class | - | | 30 |

3.4.3 Gas data

Gas data

| Description II _{2H3+} | Unit | SGE 40 | SGE 60 |
|---|--------|-----------|-----------|
| Gas category 2H: G20 - 20 mbar | | I | |
| Orifice diameter | mm | - | 8.70 |
| (1) = No burner pressure regulator(2) = Burner pressure regulator | 1 or 2 | | 2 |
| Nominal load (upper value) | kW | - | 63.2 |
| Nominal output | kW | - | 59.7 |
| Supply pressure | mbar | - | 20 |
| Burner pressure ^(†) | mbar | - | 10.0 |
| Gas consumption ^(*) | m³/h | - | 6.0 |
| Gas category 3+: G30 - 30mbar | · · · | | |
| Orifice diameter | mm | - | 4.00 |
| (1) = No burner pressure regulator(2) = Burner pressure controller | 1 or 2 | - | 1 |
| Nominal load (upper value) | kW | - | 61.7 |
| Nominal output | kW | - | 59.7 |
| Supply pressure | mbar | - | 30 |
| Burner pressure ^(†) | mbar | - | - |
| Gas consumption ^(*) | kg/h | - | 4.5 |




| Description II _{2H3+} | Unit | SGE 40 | SGE 60 |
|---|--------|-----------|-----------|
| Gas category 3+: G31 - 37 mbar | | | |
| Orifice diameter | mm | - | 4.00 |
| (1) = No burner pressure regulator(2) = Burner pressure controller | 1 or 2 | - | 1 |
| Nominal load (upper value) | kW | - | 61.8 |
| Nominal output | kW | - | 59.7 |
| Supply pressure | mbar | - | 37 |
| Burner pressure ^(†) | mbar | - | - |
| Gas consumption (*) | kg/h | - | 4.5 |


(7) If using a blank plate instead of a burner pressure regulator, it is assumed that the burner pressure is equal the supply pressure. In practice, however, the burner pressure will be lower.



3.5 Installation diagram

This figure shows the installation diagram. This diagram is used in the sections in which the actual connection process is described.





Щ9

IMD-0581 R2

26



Legend

Only applicable numbers are mentioned.

- 1. pressure-reducing valve (mandatory if the mains water pressure exceeds 8 bar)
- 3. T&P valve (mandatory)
- 4. stop valve (recommended in pipe C 16. expansion vessel (mandatory) and mandatory in pipe A)
- 5. non-return valve (mandatory)
- circulation pump (optional)
- 9. drain valve (mandatory)
- 10. manual gas valve (mandatory)
- 20. pressure valve (mandatory)
- 26. air bleed (mandatory)

3.6 Water connections. Unvented

- 11. service stop valve (recommended) 38. solar heating system pump station
- 12. temperature gauge (recommended)
- 13. condensation drainage (mandatory)
- 14. hot water draw-off points
- 15. expansion valve (mandatory)
- 17.3-way aeration valve (recommended)
- 18. water tank
- 19. float valve
- 23. pressure valve (mandatory)
- 37. combined Q/T sensor (optional)

- (modulating mandatory)
 - A. cold water supply
 - B. hot water supply
 - C. circulation pipe
 - D. gas supply
 - E. overflow pipe
 - heat exchanger supply E.
 - G. heat exchanger return
 - H. overflow safety
 - S1.collector sensor (mandatory)
 - S2.tank sensor (mandatory)
 - S4.heat exchanger discharge sensor (optional)

Warning

The installation should be carried out by an authorised installation engineer, in compliance with general and local regulations (1.3 "Regulations").

3.6.1 Cold water side

See (A) in the installation diagram (3.5 "Installation diagram").

- Fit an approved stop valve (4) on the cold water side as required by 1. applicable regulations (1.3 "Regulations").
- 2. The maximum working pressure of the appliance is 8 bar. Because the pressure in the water pipe at times can exceed 8 bar, you must fit an approved pressure-reducing valve (1).
- 3. Fit a non-return valve (5) and an expansion vessel (16).
- 4. Fit an expansion valve (15) and connect the overflow side to an open wastewater pipe.

3.6.2 Hot water side

See (B) in the installation diagram (3.5 "Installation diagram").

Note

- Insulating long hot water pipes will prevent unnecessary energy loss.
- 1. Optional: fit a temperature gauge (12) so you can check the temperature of the tap water.
- 2. Fit the T&P valve (3).
- 3. Fit a stop valve (11) in the hot water outlet pipe for servicing.

3.6.3 **Circulation pipe**

See (C) in the installation diagram (3.5 "Installation diagram").

If an immediate flow of hot water is required at draw-off points, a circulation pump can be installed. This improves comfort and reduces water wastage.

- 1. Fit a circulation pump (6) of the correct capacity for the length and resistance of the circulation system.
- 2. Fit a non-return valve (5) behind the circulation pump to guarantee the direction of circulation.
- 3. Fit two stop valves for service purposes (4).
- 4. Connect the circulation pipe to the cold water supply pipe.



3.6.4 Condensation drainage

1. Fit a sloping wastewater pipe to the siphon (13) for condensation drainage and connect this to the wastewater discharge in the boiler room.

🖌 Caution

All fittings behind the siphon must be condensation-resistant.

3.7 Water connections, Vented

Warning

The installation should be carried out by an authorised installation engineer, in compliance with general and local regulations (1.3 "Regulations").

3.7.1 Cold water side

See (A) in the installation diagram (3.5 "Installation diagram").

 Fit an approved stop valve (4) on the cold water side between the cold water head tank (18) and the appliance, as required by regulations (1.3 "Regulations").

3.7.2 Hot water side

See (B) in the installation diagram (3.5 "Installation diagram").

Note

Insulating long hot water pipes prevents unnecessary energy loss.

- 1. Fit the T&P valve (3).
- 2. Optional: fit a temperature gauge (12) so you can check the temperature of the tap water.
- 3. Fit a stop valve (4) in the hot water outlet pipe, for use when servicing.
- 4. If a circulation pipe is required, continue further by installing the circulation pipe (3.6.3 "Circulation pipe").

3.7.3 Circulation pipe

See (C) in the installation diagram (3.5 "Installation diagram").

If an immediate flow of hot water is required at draw-off points, a circulation pump can be installed. This improves comfort and reduces water wastage.

- 1. Fit a circulation pump (6) of the correct capacity for the length and resistance of the circulation system.
- 2. Fit a non-return valve (5) behind the circulation pump to guarantee the direction of circulation.
- 3. Fit two stop valves for service purposes (4).
- 4. Connect the circulation pipe to the cold water supply pipe.

3.7.4 Condensation drainage

1. Fit a sloping wastewater pipe to the siphon (13) for condensation drainage and connect this to the wastewater discharge in the boiler room.

Caution

All fittings behind the siphon must be condensation-resistant.



3.8 Gas connection

Warning

The installation should be carried out by an authorised installation engineer, in compliance with general and local regulations (1.3 "Regulations").

Caution

Make sure that the diameter and length of the gas supply pipe are large enough to supply sufficient capacity to the appliance.

See (D) in the installation diagram (3.5 "Installation diagram").

- 1. Fit a manual gas valve (10) in the gas supply pipe.
- 2. Blow the gas pipe clean before use.
- 3. Close the manual gas valve.
- 4. Fit the gas supply pipe to the gas control.

👔 Warning

After fitting, check for leaks.

3.9 Air supply and flue

3.9.1 Introduction

This section covers the following subjects:

- Requirements for flue gas discharge materials
- Concentric connections
- Parallel connections

3.9.2 Requirements for flue gas discharge materials

Warning

The installation should be carried out by an authorised installation engineer, in compliance with general and local regulations (1.3 "Regulations").

Depending on the approved installation types, there are several alternatives for connecting the air supply and flue gas discharge.


The appliances are approved for installation types B23, C13, C33, C43, C53 and C63.

The figure and table give information about these appliance types. For an explanation of the possibilities, please contact the manufacturer.

Installation



Types of appliances





Explanation of type of appliance

| Type of appliance | Description | | |
|--|---|--|--|
| B23 | Air for combustion is drawn from the boiler room. | | |
| C13 | Concentric and / or parallel wall flue terminal | | |
| C33 Concentric and / or parallel roof flue terminal | | | |
| C43 Appliances on common air supply and flue gas discharge (concer parallel) in multi-storey building. | | | |
| C53 | Air supply and flue terminal types mixed. | | |
| C63 | Appliances supplied without flue components and / or terminal. These appliances must be installed in compliance with local regulations. | | |

Note

Make sure that the chimney discharges into an area where this is permitted for this category of appliance.

3.9.3 Concentric connections

The table shows the requirements for concentric systems.

🗱 Warning

Install flue gas discharge pipe runs with a run-off of 5 mm per metre.

| Chimney flue requirements for concentric systems (C13, C33) |
|---|
|---|

| Appliance | Diameter | Maximum length | Maximum number of 90° bends |
|-----------|------------|----------------|-----------------------------------|
| SGE 40 | | | |
| SGE 60 | 100/150 mm | 15 m | 4 |

, Caution

Both conditions stated in the table must be fulfilled.

Even if there are less bends than the stated maximum, the maximum pipe length may **not** be exceeded.

Even if the total pipe length is less than the stated maximum, the maximum number of bends may **not** be exceeded.



The following example illustrates how to use the table.

Practical example of concentric chimney flue

Example

The figure shows a SGE 60 installation. The appliance must be fitted with 10 m of concentric pipe (C13/C33) and four 90 degree bends. The configuration must be checked for compliance with the requirements stated in the table.

Appliance with concentric flue gas discharge material



According to the table, the maximum length allowed is 15 metres, and there may be up to three 90 degree bends 4. Both requirements are fulfilled.

Specifications

📕 Caution

For type C13 and C33 installations, A.O. Smith prescribes the use of a roof or wall-mounted terminal, exclusively of a type approved for the appliance. Use of an incorrect roof or wall-mounted flue terminal can cause the installation to malfunction.



C13 Concentric wall flue terminal specifications

| Subject | | Description | |
|--|--------------|---|--|
| Wall flue terminal set: | Art. No. | 0302 504 ¹ | |
| 1x Wall flue terminal (incl. wall flange & clamping ring) 1x Pipe 500 mm 1x Bend 90° | Construction | Concentric | |
| | Manufacturer | Muelink & Grol | |
| | Туре | M2000 MDV SEC | |
| Pipe material | Construction | Concentric | |
| | Chimney flue | Thick-walled aluminium with lip ring seal | |
| | Air supply | Thin-walled galvanised sheet steel | |
| Pipe diameters | Chimney flue | Ø 100 mm | |
| | Air supply | Ø 150 mm | |
| (1) No other wall flue terminal is permitted. Use this item number to order the wall conduit set from supp. | | | |

(1) No other wall flue terminal is permitted. Use this item number to order the wall conduit set from *supplier*, manufacturer or wholesaler.

| C33 concentric roof flue | terminal specifications |
|--------------------------|-------------------------|
|--------------------------|-------------------------|

| | Description | |
|--------------|--|--|
| Art. No. | 0304 423 ¹ | |
| Construction | Concentric | |
| Manufacturer | Muelink & Grol | |
| Туре | M2000 DDV HR-C | |
| Construction | Concentric | |
| Chimney flue | Thick-walled aluminium with lip ring seal | |
| Air supply | Thin-walled galvanised sheet steel | |
| Chimney flue | Ø 100 mm | |
| Air supply | Ø 150 mm | |
| _ | Construction Manufacturer Type Construction Chimney flue Air supply Chimney flue | |

supplier, manufacturer or wholesaler.

3.9.4 Parallel connections

The table states the maximum pipe lengths for parallel systems. The maximum pipe length depends on the chosen diameter.

Warning

chimney flue.

Install flue component pipe runs with a run-off of 5 mm per metre.

Chimney flue requirements for parallel systems

| Appliance | Diameter ¹ | Maximum total length | L _{equivalent} 90° bend | L _{equivalent} bend 45° |
|--|-----------------------|-------------------------|-------------------------------------|-------------------------------------|
| SGE 40 | | | | |
| SGE 60 | 100 mm | 25 m | 4.6 m | 1.2 m |
| SGE 40 | | | | |
| SGE 60 | 130 mm | 100 m | 2.4 m | 1.4 m |
| 1) Parallel systems with diameter of 130 mm or 150 mm. If the maximum total length for a diameter of 130 mm is insufficient, 150 mm diameter must be used. Any diameter enlargement must be carried out on both air supply and | | | | |




You must use the longest pipe when calculating the pipe length. For example, if the chimney pipe is 35 metres and the air supply pipe is 32 metres, use 35 metres as the length for the calculation. Next, add the L *equivalent* for *every* 90° and 45° bend to this 35 metres, in _{both} the air supply and chimney flue. The following practical example illustrates how to use the table.

Practical example of parallel chimney flue

Example

The figure shows a SGE 60 installation. This has to be fitted with a 25 m parallel pipe of 100 mm diameter, and eight 90 degree bends. The configuration must be checked for compliance with the requirements stated in the table.



The longest pipe must be used to check the maximum length. In this case, the chimney pipe is the longest. This is 25 metres. This 25 metres is the sum of pipe sections 1, 2, 3, 4 and 5. The length of the transition piece can be ignored. The total number of bends used *in the chimney flue and air supply* is 8. The bend in the transition piece can be ignored. According to the table, 4.6 metres per bend must be added. This brings the total pipe length to:

(2.4 x 8) + 25 = 19.2 + 25 = 44.2 m.

This is less than the maximum length of 800 metres stated in the table. The installation therefore fulfils the requirements.

Appliance with parallel flue gas discharge material



| 3.10 | Solar heating system | Note For the solar heating system connections, refer to the electrical |
|------|----------------------|--|
| | | diagram (17.4 "Electrical diagram, solar heating system") and the table. ("Electrical connector block") |
| | | Connect the supply from the solar collector to the inlet (F) of the heat exchanger (55). |
| | | 2. Connect the return pipe to the solar collector to the outlet (G) of the heat exchanger (55). |
| | | 3. Connect the lead from the solar heating system controller to sensor S2, see: |
| | | electrical diagram (17.3 "Electrical diagram for the appliance") and connections table (3.11.2 "Preparation"). |
| | | Connect the communication cable between the solar heating system controller and the appliance, see: |
| | | electrical diagram (17.4 "Electrical diagram, solar heating system") and |
| | | - connections table (3.11.2 "Preparation"). |
| | | Warning The installation diagram shows a non-return valve in the pump station. This non-return valve may be used solely in closed (pressure) systems. In systems with a drain-back tank, it is prohibited to fit a non-return valve in the solar heating system. |
| 3.11 | Electrical | ų, Warning |

3.11 Electrical connection

The installation should be carried out by an authorised installation engineer, in compliance with general and local regulations (1.3 "Regulations").

3.11.1 Introduction

Topics covered in this paragraph:

- Preparation
- Connecting the mains voltage

Optionally, it is possible to connect an isolating transformer, a continuous pump, a program-controlled pump, an extra ON mode switch and an extra alarm signal to the appliance. For these options, see:

- Isolating transformer
- Connecting continuous pump
- Connecting a program-controlled pump
- Connecting an extra ON mode switch ("Tank ON")
- Connecting an extra error signal ('Alarm OUT')

Connecting the solar heating system is also described:

- Connecting communication cable to solar heating system
- Note

The optional components are not included in the rating for electrical power consumption stated in the table (3.4.2 "General and electrical specifications").



3.11.2 Preparation

, Caution

The appliance is phase-sensitive. It is **absolutely essential** to connect the mains phase (L) to the phase of the appliance, and the mains neutral (N) to the neutral of the appliance.

, Caution

There may be **no potential difference** between neutral (N) and earth $(\frac{1}{2})$. If this is the case, then an isolating transformer must be applied in the supply circuit (3.11.4 "Isolating transformer").


For more information or to order this isolating transformer, please contact A.O. Smith water Products Company.

The figure shows a view of the electrical connector block, and the table shows the appropriate connections.

Connector block

Legend

- A. screws
- B. protective cap
- C. connector block



IMD-0077 R2

In preparation, you must first remove the two plastic covers and the protective cap of the electrical section.

- 1. Undo the screws of the plastic covers.
- 2. Carefully remove the covers from the appliance. The electrical section is now visible.
- Loosen the 2 screws (A) of the electrical section, and remove the protective cap (B) from the electrical section. The connector block (C) is now visible.

Note

Consult the table for the connections and consult the electrical diagram for the electrical component connections.



Electrical connector block

| Bus- link | Un- used | _ | nk N | Continuous pump | | Program- Alarm controlled pump | | arm (| Off | Isolating transformer | | | | r | Mains voltage | | | | | | |
|--------------|-------------|----|---------|--------------------|---|--------------------------------------|----|-------|-----|-----------------------|----|----|----|-------|------------------|----|------|-----|----|----|----|
| (1) | | | | | | | | | | | | | p | orima | ry | se | cond | ary | | | |
| X5, X6 | | X1 | X2 | ÷ | L | Ν | Ν | L | Ŧ | X1 | X2 | Ŧ | Ν | L | ч́г | Ν | L | Ŧ | Ν | L | Ŧ |
| 1-2 | 3-4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 |

(1) For connection to solar heating system

3.11.3 Connecting the mains voltage

The appliance is supplied without a power cable and isolator.

Note

In order to receive electrical power, the appliance has to be connected to the mains power by means of a permanent electrical connection. A double-pole isolator with a contact gap of at least 3 mm must be fitted between this permanent connection and the appliance. The power cable must have cores of at least $3 \times 1.0 \text{ mm}^2$.

🕼 Warning

Leave the appliance isolated until you are ready to start it up.

- Connect phase (L), neutral (N) and earth ([⊥]/₌) of the power cable to terminals 22 through 24 of the connection block as indicated in the table (3.11.2 "Preparation").
- 2. Fit the power cable in the strain relief.
- 3. Connect the power cable to the isolator.
- 4. If you have no more connections to make:
 - Fit the cap on the electrical terminal block.
 - Fit the plastic covers onto the appliance.

3.11.4 Isolating transformer

An isolating transformer should be used if there is a case of 'floating neutral'.

- 1. Refer to fitting instructions provided with the isolating transformer. (Contact the supplier for details of the correct isolating transformer.)
- Connect phase (L), neutral (N) and earth (≟) to terminals 16 through 21 of the terminal block as stated in the table (3.11.2 "Preparation").
- 3. Fit the cables in the strain relief.
- 4. If you have no more connections to make:
 - Fit the cap on the electrical terminal block.
 - Fit the plastic covers onto the appliance.
- 5. Connect the power cable to the isolator.

3.11.5 Connecting continuous pump

- 1. Connect phase (L), neutral (N) and earth (=) to terminals 7, 8 and 9 as stated in the table (3.11.2 "Preparation").
- 2. Fit the cable in the strain relief.
- 3. If you have no more connections to make:
 - Fit the cap on the electrical terminal block.
 - Fit the plastic covers onto the appliance.



3.11.6 Connecting a program-controlled pump

- 1. Connect phase (L), neutral (N) and earth (≟) to terminals 10, 11 and 12 as stated in the table (3.11.2 "Preparation").
- 2. Fit the cable in the strain relief.
- 3. If you have no more connections to make:
 - Fit the cap on the electrical terminal block.
 - Fit the plastic covers onto the appliance.

3.11.7 Connecting an extra ON mode switch ("Tank ON")

Tank ON is a facility for connecting an external ON/OFF switch. In the OFF position, the programmed operating mode is active. In the ON position, the programmed operating mode is overruled, and the "ON mode" is active.

- Connect cables (X₃ and X₄) to terminals 5 and 6 as indicated in the table (3.11.2 "Preparation").
- 2. Fit the cable in the strain relief.
- 3. If you have no more connections to make:
 - Fit the cap on the electrical terminal block.
 - Fit the plastic covers onto the appliance.

3.11.8 Connecting an extra error signal ('Alarm OUT')

Alarm OUT is a potential free terminal that is switched when an error is detected. This can be used to signal errors, for example with a lamp. A 230 V circuit can be directly powered. Other voltages require a relay prescribed by the manufacturer.

- Connect the phase cables (X₁ and X₂) to terminals 13 and 14 according to the table (3.11.2 "Preparation"). If required, connect earth ([⊥]/₌) to terminal 15.
- 2. Fit the cable in the strain relief.
- 3. If you have no more connections to make:
 - Fit the cap on the electrical terminal block.
 - Fit the plastic covers onto the appliance.

3.11.9 Connecting communication cable to solar heating system

You must connect a communication cable between the controllers of the appliance and the solar heating system.

- 1. Connect the cables (X5 and X6) to terminals 1 and 2 as indicated in the table (3.11.2 "Preparation").
- 2. Fit the cable in the strain relief.
- 3. If you have no more connections to make:
 - Fit the cap on the electrical terminal block.
 - Fit the plastic covers onto the appliance.

Topics covered in this paragraph

- 3.12 Electrically connecting the solar heating system controller
- Preparation
 Connecting the main
- Connecting the mains power
- Connecting pump station modulating pump
- Connecting solar collector
- Connecting tank sensor
- Connecting communication cable

Optionally you can connect an extra head pump and Q/T sensor:

- Connecting extra head pump
- Connecting Q/T sensor



3.12.1 Preparation

| | following termin | | |
|------|------------------|-----------------|------|
| n.a. | Pump ON/OFF | Modulating pump | n.a. |

Undo the screws of the cap over the terminal block of the collector. This has the

| I | Power | | | n.a. | | Pump ON/OFF | | Modulating pump | | | n.a. | | | | | | | | |
|----|-------|---|---|------|---|-------------|----------------|-----------------|----|----------------|------|----|----|----|----|----|----|----|----|
| ı۲ | L | Ν | - | - | - | Ŧ | L ₁ | Ν | Ŧ | L ₂ | Ν | М | - | - | - | - | - | - | - |
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 |

| n.a. | n.a. | n.a. | n.a. | Power 5 V | Sensor S4 | Ŧ | Flow signal | n.a. | Sensor S1 | n.a. | Semsor S1 | n.a. | Sensor S2 | n.a. | Sensor S2 |
|------|------|------|------|-----------|-----------|---|-------------|------|-----------|------|-----------|------|-----------|------|-----------|
| 1 | 2 | 3 | 4 | 1 | 2 | 3 | 4 | 1 | 2 | 3 | 4 | 1 | 2 | 3 | 4 |
| J3 | | | | ٦ | 12 | | | ٦ | 13 | | | J | 14 | | |

3.12.2 Connecting the mains power

Note

Just as with the appliance controller, the solar heating system controller must have a permanent electrical connection to the mains power supply. There must be a double-pole isolator installed in the permanent connection. This is the same double-pole isolator as installed between the mains power supply and the appliance itself. Whenever this isolator is operated, both controllers can be switched on or off.

- 1. Connect earth, live and neutral to terminals 1 through 3
- 2. Fit the cables in the strain relief.
- 3. Connect the power cable to the isolator.
- 4. Continue (3.12.3 "Connecting pump station modulating pump").

3.12.3 Connecting pump station - modulating pump

The pump station contains a modulating pump (4-wire connection). You must connect this pump to the controller of the solar heating system.

- 1. Connect earth, live and neutral to terminals 10 through 12.
- 2. Connect the fourth lead to terminal 13
- 3. Fit the cables in the strain relief.
- 4. Continue (3.12.4 "Connecting solar collector").

3.12.4 Connecting solar collector

Note

This sensor must be mounted in the solar collector; refer to the solar collector installation manual.

Connect the sensor to the appliance as follows:

- 1. Connect the sensor to terminal 2 and 4 of J13.
- 2. Fit the cables in the strain relief.
- 3. Continue (3.12.5 "Connecting tank sensor").



3.12.5 Connecting tank sensor

Note

This sensor is already mounted in the tank prior to delivery. The sensor is mounted between the inlet and outlet of the heat exchanger. However, you must still connect the lead to the solar heating system controller.

- 1. Connect the sensor lead with the blade connectors to the sensor.
- 2. Connect the other end to terminals 2 and 4 of J14.
- 3. Fit the cables in the strain relief.
- 4. Continue (3.12.6 "Connecting communication cable").

3.12.6 Connecting communication cable

Note

>The communication cable must always be connected, otherwise neither the appliance nor the solar heating system controller will run.

- 1. Connect the double connector to J16.
- 2. Fit the cable in the strain relief.
- 3. Connect the other end of the communication cable to the terminal block of the appliance. See:
 - connecting communication cable to appliance (3.11.9 "Connecting communication cable to solar heating system")
 - electrical diagrams (17.3 "Electrical diagram for the appliance").
- 4. Connect the optional head pump (3.12.7 "Connecting extra head pump") or QT sensor (3.12.8 "Connecting Q/T sensor").
- 5. If you have no more connections to make:
 - Fit the cap on the electrical terminal block.
 - Fit the plastic covers onto the appliance.

3.12.7 Connecting extra head pump

Note

This pump is essential if a greater head is required. When the system has such a high resistance (>110 kPa) that the pump in the pump station is insufficient, you can connect a second (ON/OFF) pump to the solar heating system controller.

- 1. Connect earth (=), live and neutral to terminals 7 through 9.
- 2. Fit the cable in the strain relief.
- If you need to connect an extra head pump continue (3.12.8 "Connecting Q/T sensor"), otherwise:
 - Fit the cap on the terminal block.
 - Fit the covers onto the appliance.

3.12.8 Connecting Q/T sensor

Note

You can optionally add a Q/T sensor to the installation. This enables you to calculate the energy contribution of the system. For more information or to order the Q/T sensor, please contact your supplier.

- 1. Connect the 5V to J12-1.
- 2. Connect sensor S_4 to J12-2.



3. Connect earth to J12-3.

- 4. Connect the "flow signal" to J12-4.
- 5. Fit the cable in the strain relief.
- 6. If you have no more connections to make:
 - Fit the cap on the electrical terminal block.
 - Fit the plastic covers onto the appliance.

Note

Before starting the appliance and/or checking the supply pressure and burner pressure, you must fill (5 "Filling") the appliance.

, Caution

Before starting up for the first time or after conversion, you must always check the supply pressure and burner pressure.

Note

The easiest way to check the gas pressures is by using two pressure gauges. This procedure assumes that these two gauges are available.

Gas control

Legend


Only applicable numbers are mentioned.

3.13 Checking the supply

pressure

pressure and burner

- 1. supply pressure test nipple
- 2. burner pressure test nipple
- 3. burner pressure regulator
- 4. burner pressure control cap
- 5. burner pressure control adjusting screw





3.13.1 Preparation

To check the supply pressure and burner pressure, proceed as follows:

- 1. Isolate (10.3 "Electrically isolating the appliance") the water heater from the power supply.
- 2. Undo the screws of the plastic covers.
- 3. Carefully remove the covers from the top of the appliance. The electrical section is now visible.

3.13.2 Procedure to check pressures

- 1. There are two test nipples on the gas control:
 - a supply pressure nipple (1)
 - a burner pressure nipple (2)


Sealing screws are located inside the test nipples. Loosen both sealing screws by a few turns. Do not completely loosen them; they can be difficult to re-tighten.

- 2. Connect a pressure gauge to the burner pressure nipple (2).
- 3. Open the gas supply and vent the gas supply line with the supply pressure nipple (1).
- 4. Connect a pressure gauge to the supply pressure nipple (1) when gas starts to flow from this nipple.
- 5. Switch on the power to the appliance using the isolator on the appliance.
- 6. Switch the electronic controller **ON** by setting the 0/I switch to **position I**.



IMD-0588 R0

The display will now show INTERNAL CHECK for about 10 seconds and go to the main menu.



| MB | ENU | |
|----|------|---------|
| - | +0FF | |
| ٠ | ON | |
| Ŧ | WEEK | PROGRAM |



- 7. Activate the "ON mode" by going through the following steps:
 - Press the blue arrow once (♣) to position the cursor in front of ON and press ENTER. The display shown here will appear.



Confirm the ENTERby pressing START OPERATION.

The appliance is now in the "ON mode" and will ignite.

- Once the display shows the text RUNNING you must wait about 1 minute before reading the dynamic pressures (the fan needs this time to run up to full rotational speed).
- 9. Use the pressure gauge to read the supply pressure at 1nipple (1) (3.4.3 "Gas data").



Consult the mains gas supply company if the supply pressure is not correct.

10. Use the pressure gauge to read the burner pressure at nipple (2) (3.4.3 "Gas data").

If the burner pressure is not correct and the appliance is fitted with a blank plate, you will not be able to adjust the pressure. Finalise (3.13.4 "Finalising"), and in this case, consult your installation engineer or supplier.

If the appliance is indeed fitted with a burner pressure regulator, the pressure can be adjusted as described in the procedure (3.13.3 "Adjusting the pressure").

3.13.3 Adjusting the pressure

- 1. Remove the cap (4) from the burner pressure regulator (3).
- 2. Correct the burner pressure by turning the adjusting screw (5), depending on the correction required:
 - Adjustment screw anticlockwise: burner pressure decreases.
 - Adjustment screw clockwise: burner pressure increases.
- 3. Cover the opening of the adjusting screw and check the burner pressure against the value given in the gas table (3.4.3 "Gas data").
- 4. If the pressure is not set correctly, repeat the preceding steps until the correct pressure is attained.
- 5. Fit the cap (4) back on the burner pressure regulator.
- 6. Activate the "OFF mode" of the electronic controller:

| ME | ENU | |
|----|------|---------|
| ÷ | +0FF | |
| * | ON | |
| Ŧ | WEEK | PROGRAM |

- 7. If the MENU is not displayed: press and the MENU is not displayed: press and the mean of the mean o
 - Use ↑ and ↓ to place the cursor beside OFF.
 - Confirm with ENTER.
- 8. Wait until the fan has stopped, and switch the electronic controller off.

, Caution

Failure to wait until the fan stops can cause damage to the appliance.

9. Finish off (3.13.4 "Finalising").



3.13.4 Finalising

- 1. Shut off the gas supply.
- 2. Disconnect the two pressure gauges and retighten the sealing screws in the test nipples.
- 3. Replace the cover.

Note

Before starting-up the appliance, take time to fill in the warranty card supplied with the appliance. This enables us to guarantee the quality of our systems, and to further enhance our warranty procedure.

Please return this card as soon as possible. Your customer will then receive a warranty certificate with our warranty conditions.



Conversion to a different gas category

🚛 Caution

The conversion may only by carried out by an authorised installation engineer.

If the appliance must operate on a family of gases (LP gas or natural gas) or other gas category than that for which the appliance has been set at the factory, the appliance will have be adapted using a special conversion kit.


📕 Caution

You must check the supply pressure and burner pressure once the conversion is complete.

Orifice assembly

Legend

- 1. connector
- 2. gas coupling
- 3. air supply hose
- 4. pressure switch hose
- 5. gas/air distribution plate
- 6. stamped figures



IMD-0078 R3



- 1. Isolate the water heater from the power supply (10.3 "Electrically isolating the appliance").
- 2. Shut off the gas supply.
- 3. Undo the screws of the plastic covers.
- 4. Carefully remove the covers from the top of the appliance.
- 5. Detach the connector (1) that connects the leads of the hot surface igniter and the flame probe to the controller.
- 6. Detach the three-part gas coupling (2) adjacent to the burner.
 - Detach the air supply hose (3).
 - Detach the pressure switch hose (4).
- 7. Remove the burner as complete assembly.
- 8. Place and fit the burner with parts from the conversion kit.

Note


The burner for LP gases can be recognised by the letter 'P' which is stamped into the metal of the gas/air distribution plate (5).

 Select and fit the correct orifice from the conversion kit, based on the gas table (3.4.3 "Gas data"). The injector diameter is stamped into each injector (6).

Conversion of gas control

Legend

- 7. burner pressure regulator
- 8. blank plate
- 9. gas control connector



IMD-0079b R2



10. Check whether there is a burner pressure regulator (7) attached to the top of the gas control, or simply a blank plate (8).

Note

In the event of the supply pressure for a gas category being the same as the burner pressure (3.4.3 "Gas data"), the gas control must be fitted with a blanking plate with a cork gasket. A burner pressure that deviates with respect to the supply pressure requires a burner pressure regulator with rubber gasket to be used. Each conversion kit contains all the necessary components.

11. If the blank plate or burner pressure regulator need to be replaced:


- Unscrew the connector (9) from the gas control.
- If necessary, remove the blank plate or burner pressure regulator (7).
- If necessary, fit the blank plate or burner pressure regulator supplied with the conversion kit.
- Fit the gas control's connector (9).
- 12. Fit the connector (1) of the hot surface igniter and flame probe to the controller.
- 13. Fit the 3-part gas coupling (2).
- 14. Check the burner pressure and supply pressure (3.13 "Checking the supply pressure and burner pressure").
- 15. Replace the cover.
- 16. Remove the sticker showing the new gas category from the conversion kit, and attach it below the appliance's rating plate. This clearly indicates that the appliance may no longer be run on the gas for which it was originally supplied.





5

Filling



IMD-0581 R2

Legend

Only applicable numbers are mentioned.

- 1. pressure-reducing valve (mandatory if the mains water pressure exceeds 8 bar)
- 3. T&P valve (mandatory)
- 4. stop valve (recommended in pipe C 16. expansion vessel (mandatory) and mandatory in pipe A)
- 5. non-return valve (mandatory)
- circulation pump (optional)
- 9. drain valve (mandatory)
- 10. manual gas valve (mandatory)
- 20. pressure valve (mandatory)
- 26. air bleed (mandatory)

5.1 Filling the appliance

- 11. service stop valve (recommended) 38. solar heating system pump station
- 12. temperature gauge (recommended)
- 13. condensation drainage (mandatory)
- 14. hot water draw-off points
- 15. expansion valve (mandatory)
- 17.3-way aeration valve (recommended)
- 18. water tank
- 19. float valve
- 23. pressure valve (mandatory)
- 37. combined Q/T sensor (optional)

- (modulating mandatory)
 - A. cold water supply
 - B. hot water supply
 - C. circulation pipe
 - D. gas supply
 - E. overflow pipe
 - F. heat exchanger supply
 - G. heat exchanger return
 - H. overflow safety
 - S1.collector sensor (mandatory)
 - S2.tank sensor (mandatory)
 - S4.heat exchanger discharge sensor (optional)

5.1.1 Filling unvented installations

To fill the appliance, proceed as follows:

- 1. Open the stop valve (11) in the hot water pipe and, if present, the stop valves (4) for the circulation pump (6).
- 2. Close the drain valve (9).
- Open the nearest hot water draw-off point (14).
- 4. Open the stop valve (4) on the cold water side (A) so that cold water flows into the appliance.
- 5. Completely fill the appliance. When a full water jet flows from the nearest draw-off point, the appliance is full.
- 6. Bleed the entire installation of air, for example by opening all draw-off points.
- 7. The appliance is now under water supply pressure. There should be no water coming out of the expansion valve (15), nor the T&P valve (3). If this does happen, the cause might be:
 - The water supply pressure is greater than the specified 8 bar. Rectify this by fitting a pressure reducing valve (1).
 - The expansion valve in the protected cold supply setup is defective or incorrectly fitted.

5.1.2 Filling vented installations

To fill the appliance, proceed as follows:

- 1. Open the stop valve (11) in the hot water pipe and, if present, the stop valves (4) for the circulation pump (6).
- 2. Close the drain valve (9).
- 3. Open the nearest hot water draw-off point (14).
- 4. Open the stop valve (4) on the cold water side (A) so that cold water flows into the appliance.
- 5. Completely fill the appliance. When a full water jet flows from the nearest draw-off point, the appliance is full.
- 6. Bleed the entire installation of air, for example by opening all draw-off points.
- 7. The appliance is now under water supply pressure. There should be no water coming out of the T&P valve (3). If this does happen, the T&P valve might be defective or incorrectly fitted.





5.2 Filling solar heating

system

5.2.1 Filling solar heating system with glycol

Note

No special safety measures are required when working with the diluted glycol solution specified by the manufacturer. For more information about the fluid, please contact the manufacturer.

Warning

Before filling the solar heating system to replenish the heating fluid, make certain that:

- The appliance is switched off (10.2 "Shut the appliance down for a brief period ("OFF mode")").

- The solar heating system is switched off. Refer to the documentation of the solar heating system.

- The appliance has cooled down sufficiently to prevent personal injury (burns).

Note

The filling procedure described in this manual is intended for the pump system supplied by the supplier of the appliance. For any other system, you should follow the procedure for that system.

🕼 Warning

To avoid contaminating the glycol, you should flush the solar heating system through with water before filling.

Flushing with water

- 1. Connect a water supply to the filling point of the pump station.
- 2. Connect a drain hose to the drain point.
- 3. Open the taps of both supply and drain point.
- 4. Open the water supply tap.
- 5. Allow the system to spool through until no further contamination comes out of the drain hose.
- 6. Then shut off the water supply.
- 7. Drain all remaining water from the system.
- 8. Now you can fill the system with glycol.

Filling with glycol

- 1. Insert the hose of the glycol pump into the jerry can containing the glycol.
- 2. Tighten the pump onto the jerry can using the swivel.
- 3. Connect the hose of the glycol pump to the inlet combination of the pump station.
- 4. Open the valve of the inlet combination.
- 5. Plug the glycol pump into a mains socket.
- 6. Start the glycol pump using the ON/OFF switch on the glycol pump.
- 7. Stop the glycol pump as soon as the pressure gauge on the pump station begins to rise.
- 8. Completely bleed the system of air at the air bleed point (26, see installation diagram).
- 9. Close the air bleed when no further air comes out.



10. Repeat steps 6 through 9 until glycol runs out of the air bleed (26).

Note

The system does not need be filled to a certain pressure. The pressure in the system will increase when the fluid heats up and expands.

- 11. Switch off the glycol pump.
- 12. Close the valve of the inlet combination and disconnect the glycol pump (including the hoses).

Note

Dispose of the residual glycol in the filler hose in an environment-friendly manner, and according to local regulations.

, Caution

The very first time the appliance is started, the correct fluid must be set (12.9.2 "Setting the heating fluid type in the solar heating system") using the Service Menu.


Note


If the system is equipped with a drain-back tank, then the system must be filled to a certain pressure. For the installation and filling of a drain-back tank, please refer to the installation and users manual of the solar collector.



6

Draining





IMD-0581 R2

Legend


Only applicable numbers are mentioned.

- 1. pressure-reducing valve (mandatory if the mains water pressure exceeds 8 bar)
- 3. T&P valve (mandatory)
- 4. stop valve (recommended in pipe C 16. expansion vessel (mandatory) and mandatory in pipe A)
- 5. non-return valve (mandatory)
- 6. circulation pump (optional)
- 9. drain valve (mandatory)
- 10. manual gas valve (mandatory)
- 20. pressure valve (mandatory)
- 26. air bleed (mandatory)

6.1 **Draining unvented** installations

- 11. service stop valve (recommended) 38. solar heating system pump station
- 12. temperature gauge (recommended)
- 13. condensation drainage (mandatory)
- 14. hot water draw-off points
- 15. expansion valve (mandatory)
- 17.3-way aeration valve (recommended)
- 18. water tank
- 19. float valve
- 23. pressure valve (mandatory)
- 37. combined Q/T sensor (optional)

- (modulating mandatory)
- A. cold water supply
- B. hot water supply
- C. circulation pipe
- D. gas supply
- E. overflow pipe
- F. heat exchanger supply
 - G. heat exchanger return
 - H. overflow safety
- S1.collector sensor (mandatory)
- S2.tank sensor (mandatory)
- S4.heat exchanger discharge sensor (optional)
- 1. Activate the MENU with and



- 2. Position the cursor in front of OFF.
- Confirm OFF with ENTER.
- 4. Wait until the fan has stopped. The symbol 🗐 is then dimmed.

Caution

Failure to wait until the fan stops purging can cause damage to the appliance.

5. Switch the appliance OFF (position 0) using the ON/OFF switch on the control panel.



IMD-0588 R0

- 6. Isolate the water heater from the power supply by putting the isolator between the appliance and the mains power supply to position 0.
- 7. Shut off the gas supply (10).
- 8. Close the stop valve (11) in the hot water pipe.
- 9. Close the supply valve (4) in the cold water supply (A).
- 10. Open the drain valve (9).
- 11. Bleed the appliance (or installation) so that it drains completely.



6.2 Draining vented installations

- 1. Activate the MENU with and.
- 2. Position the cursor in front of OFF.
- 3. Confirm OFF with ENTER.
- 4. Wait until the fan has stopped. The symbol 🗐 is then dimmed.

🚛, Caution

Failure to wait until the fan stops purging can cause damage to the appliance.

5. Switch the appliance OFF (position 0) using the ON/OFF switch on the control panel.



IMD-0588 R0

- 6. Isolate the water heater from the power supply by putting the isolator between the appliance and the mains power supply to position 0.
- 7. Shut off the gas supply (10).
- 8. Close the stop valve (11) in the hot water pipe.
- 9. Close the stop valve (4) between the water tank and the cold water inlet (A).
- 10. Open the drain valve (9).
- 11. Bleed the appliance (or installation) so that it drains completely.

6.3 Draining solar heating system

6.3.1 Draining glycol-filled system

Note

No special safety measures are required when working with the diluted glycol solution specified by the manufacturer. For more information about the fluid, please contact the manufacturer.

1. Activate the MENU with and.

| ME | ENU | |
|----|------|---------|
| - | +0FF | |
| * | ON | |
| Ŧ | WEEK | PROGRAM |

- 2. Position the cursor in front of OFF.
- 3. Confirm OFF with ENTER.



4. Wait until the fan has stopped. The symbol 🗐 is then dimmed.

, Caution

Failure to wait until the fan stops purging can cause damage to the appliance.

Warning

The fluid in the pipes and the pipes themselves can be extremely hot! Wait therefore until the appliance has cooled down sufficiently.

Note

The draining procedure described in this manual is intended for the pump system supplied by the appliance supplier. For any other system, you should follow the procedure for that system.

- 1. Switch off the solar heating system.
- 2. Connect a hose to the lowest drain point in the solar heating system.
- 3. Insert the hose into the glycol jerry can.
- 4. Open the valve of the lowest drain point.
- 5. Open the air bleed point (26) of the solar heating system.
- 6. Close the drain point when the jerry can is full.
- 7. Insert the hose into a new jerry can, and connect it to the drain point.
- 8. Repeat steps 6 and 7 until no further glycol comes out of the system.
- 9. Close the air bleed point and the valve of the drain point.
- 10. Remove the hose.

Note

Dispose of the drained glycol in an environment-friendly manner, and according to local regulations.



The control panel

7.1 Introduction

Topics covered in this chapter:

- Controls;
- Meaning of icons;
- Electronic controller ON/OFF switch;
- Navigation buttons;
- PC connection.

7.2 Controls

The figure shows the electronic controller.



IMD-0588 R0

The control panel is completely menu-driven, and comprises:

- a 4-line display with 20 characters per line;
- 6 pushbuttons for operating the appliance (below the display);
- 6 graphical symbols (above the display);
- a connector for a service PC;
- an ON/OFF switch.

The pushbuttons are divided into three groups:

- Navigation buttons:

 - Enter: ENTER;
 - Reset button: RESET
- the service program (12 "Service program"): Device This chapter is specifically intended for the service and maintenance engineer and installation engineer.

In this manual, the display of the electronic controller is shown as in the figure, both with and without icons.

→START OPERATION CHANGE SETPOINT Tset=70°C

7.3 Meaning of icons

The table explains the meanings of the icons.

Icons and their meaning

| | Name | Meaning |
|-----|-----------------|-------------------------------|
| | Heat demand | Heat demand detected |
| Ð | Purge | Pre- and post-purge using fan |
| Θ | Pressure switch | Pressure switch is closed |
| 1/2 | Glowing | (Pre)glow |
| F | Gas control | Gas control open/ignition |
| Î | Flame detection | Appliance operational |

7.4 Electronic controller ON/OFF switch

The ON/OFF switch of the electronic controller is used to switch the appliance ON and OFF. Note that in the OFF position the appliance remains electrically live, in order for the continuous pump to stay running.

INTERNAL CHECK

After switching on, the text INTERNAL CHECK appears on the display for about 10 seconds. Themain menu (11 "Main menu") then appears. If no selection is made in the main menu, the appliance automatically switches to the OFF mode (8.2 "Operating modes").

Note

To electrically isolate the appliance, you must use the isolator between the appliance and the mains power supply.



7.5 Navigation buttons

The use of these buttons is explained with the help of the figure that shows the main menu (11 "Main menu").

The navigation buttons are:

- Buttons for UP **↑**, and DOWN **↓**;
- Enter: ENTER;
- Reset button: RESET.

The $\stackrel{*}{\neg}$ arrows and $\stackrel{*}{\neg}$ indicate that you can scroll up and/or down. Use the buttons \Uparrow and \clubsuit to scroll.

| MENU OFF | |
|------------------------------------|--|
| [↑] →ON ▼ WEEK PROGRAM | |
| EXTRA PERIOD SETTINGS | |

The cursor \Rightarrow points to the option to be activated. In the display as shown in the figure, you can scroll through the main menu.

The main menu comprises: OFF, ON, WEEK PROGRAM, EXTRA PERIOD and SETTINGS. You have to scroll down further to see the options EXTRA PERIOD and SETTINGS.

The selected option is confirmed using ENTER.

Pressing the **RESET** button takes you back one page in a menu and discards all options selected in the current menu.

Note

The **RESET** button is also used to reset the appliance following an error.

7.6 PC connection

The PC connection is solely intended to enable technicians from A.O. Smith to display the status and history of the appliance. These details can be important for troubleshooting and/or responding to complaints.



8

Status of the appliance

8.1 Introduction

Topics covered in this chapter:

- Operating modes;
- Error conditions;
- Service condition.

8.2 Operating modes

When running, the appliance has four basic operating modes, namely:

- OFF
- ON
- EXTRA
- PROG

8.2.1 OFF

In this mode, the frost protection is activated. The figure shows the display with the following information:

- line one: the text OFF;
- line two: the time, the day and alternately (9.3 "The appliance's heating cycle") T₁ and T_{net}.
- Ines three and four: the text
 FROST PROTECTION ACTIVATED.



8.2.2 ON

In this mode, the appliance continually responds to the hot water demand. The figure shows the display with the following information:

- line one: the text ON;
- line two: the time, the day and alternately (9.3 "The appliance's heating cycle") T₁ and T_{net}.
- line three: the programmed water temperature T_{set};
- line four: blank when the appliance is idle, or depending on the heating cycle (9.3 "The appliance's heating cycle"), displays a text such as HEAT DEMAND.

| ON | Thursday | 67°C |
|-------|----------|------|
| 13:45 | Tset | 75°C |
| | | |

8.2.3 EXTRA


In this mode, one extra period is programmed and activated. In this mode, the DFF or PRDG mode is temporarily overruled to fulfil a single period of demand. Once the period has passed, the appliance automatically returns to the previous operating mode. The figure shows the display with the following information:

- line one: the text EXTRA;
- line two: the time, the day and alternately (9.3 "The appliance's heating cycle") T₁ and T_{net};
- line three: the switch-on time, and the related water temperature setting;
- line four: the text PERIOD ACTIVATED.

| EXTRA | | |
|---|--------|------|
| 12:30 Thur | sday | 76°C |
| TH 12:45 | Tset | 75°C |
| EXTRA 12:30 Thur TH 12:45 PERIOD ACT | IVATED |) |

8.2.4 PROG

In this mode a preset week program is active, and the appliance responds continually to demand within the time periods set in the week program. There are two distinct situations possible in this mode:



1. The current time falls within a set time period of the week program.

The figure shows the display with the following information:

- line one: the text PROG;
- line two: the time, the day and T₁ and T_{net} alternately (9.3 "The appliance's heating cycle");
- line three: the next scheduled switch-off time and the water temperature T_{set} of the active period;





- line four: is empty, or depending on the heating cycle (9.3 "The appliance's heating cycle"), a text such as HEAT DEMAND.

PROG 76°C 12:00 Monday MO 11:15 PERIOD ACTIVATED

2. The current time falls outside a set time period of the week program.

The figure shows the display with the following information:

- line one: the text PROG;
- line two: the time, the day and T₁ and T_{net} alternately (9.3 "The appliance's heating cycle");
- line three: the next scheduled switch-on time;
- line four: displays the text PERIOD ACTIVATED.

In all modes, the temperature may at any moment drop below the desired temperature. The appliance then enters a heating cycle. This heating cycle is identical (9.3 "The appliance's heating cycle") for all basic operating modes.

Note

Setting and if necessary programming of the basic operating modes are described in the main menu (11 "Main menu") chapter.

8.3 Error conditions

The figure shows an example of an error condition. If the appliance enters this condition, the display will show the following information:

- line one: error code comprising a letter and two digits, followed by the error description;
- lines two to four: alternately, a brief explanation of the error, and a brief action to resolve the error.

| S04: | SENS(| DR I | ERROR | | | | | | | |
|-------|-------|------|-------|--|--|--|--|--|--|--|
| CHECK | | | | | | | | | | |
| SE | INSOR | OR | DUMMY | | | | | | | |

, Caution

The displayed action to resolve the error may only be performed by a service and maintenance engineer.

There are various types of errors:

- LOCK OUT ERRORS
 - When the cause has been removed, these errors require a reset with the button **RESET** before the appliance can resume operation.
- BLOCKING ERRORS

These errors disappear automatically once the cause of the error has been removed, after which the appliance resumes operation by itself.

The display does not show what type of error has been detected. A comprehensive overview of the errors is provided elsewhere in the manual (13 "Troubleshooting").

If, as end-user, you find the appliance in an error condition, you may attempt to restart the appliance by pressing the RESET button

However, if the error returns or occurs several times in a short time you must contact your service and maintenance engineer.

8.4 Service condition

The figure shows the message

| !!! | WARNI | NG | ! | ! | ! |
|-----|-----------------|----|---|---|---|
| | BURNI VICE F | | | | |

SERVICE REQUIRED.Should this message appear, then the appliance is in need of a service and maintenance inspection. In that case, contact your service and maintenance engineer.



The message SERVICE REQUIRED based on the number of expired burning hours and the preset service interval. Should the service interval have been incorrectly selected, contact the service and maintenance engineer for instructions on how to adjust this. Information on the maintenance frequency is provided elsewhere in the manual (14 "Maintenance frequency").

8.5 Collector temperature warning

This message appears whenever the collector temperature is excessive. This message disappears automatically. If the message does not disappear, you must contact your service and maintenance engineer.

| ! | ! | ł | WARNING | ! | ! | ļ | |
|---|---|---|-------------|---|---|---|--|
| | | | TEMPERATURE | | | | |
| | | | COLLECTOR | | | | |
| | | | TOO HIGH | | | | |

8.6 Q/T Sensor warning

This message appears if the Q/T sensor is incorrectly connected. If the message appears, you must contact your service and maintenance engineer.

| ! | ! | ! | WARNING | ! | ļ | ! | 1 |
|----|----|----|-----------|-------|---|----|---|
| - | | - | | | - | - | |
| | | ~ | T CENCOD | иот | | | |
| | | w. | /T SENSOR | NOT | | | |
| CC | DF | SĽ | ECTLY COM | INECT | Ē | ED | |



Starting and running

9.1 Introduction

Topics covered in this chapter:

- Starting the appliance.
- The appliance's heating cycle.

Note

The first time the appliance is started, you must enter (12.9 "Solar heating system configuration") the settings of the solar heating system

9.2 Starting the appliance

Start the appliance as follows:

- 1. Fill the appliance (5 "Filling").
- 2. Open (3.5 "Installation diagram") the manual gas valve.
- 3. Switch on the power to the appliance using the isolator between the appliance and the power supply.
- 4. Switch the electronic controller **ON** by setting the ON/OFF switch to **position I**.



The display will now show INTERNAL CHECK for about 10 seconds, and will then go to the main menu.



[] @ — ፼ ① [] @ MENU →OFF


≜ ON

▪ WEEK PROGRAM

Note

The first time the appliance is started, you must set (12.9.2 "Setting the heating fluid type in the solar heating system") the heating fluid type of the solar heating system.

5. Press once on the blue arrow (♣) to position the cursor beside ŪN, then press ENTER:



6. Confirm the selection START OPERATION with ENTER.

The appliance is now in "ON mode". If there is a heat demand, the appliance will run through the heating cycle (9.3 "The appliance's heating cycle").

If the heating cycle is not run, then there is no demand; should this happen, then Tset will probably need to be set (11.4 "Setting the water temperature").

9.3 The appliance's heating cycle

The appliance's heating cycle is activated as soon as the measured water temperature (T_{net}) falls below the threshold value (T_{set}). This threshold value depends on the currently selected appliance operating mode. For example, if the appliance is in "OFF mode" (frost protection), then this value is 5°C. If the appliance is in "ON mode", then this threshold value is selectable, for example, 65°C.

The heating cycle runs in turn through the following states:

- 1. HEAT DEMAND;
- 2. PRE-PURGE;
- 3. PRESSURE SWITCH;
- 4. PRE-GLOW;
- 5. IGNITION;
- 6. RUNNING;
- 7. POST-PURGE.



The complete cycle is explained in the following example, which assumes the appliance is in the basic mode ON.

Note

The same heating cycle applies to the other operating modes.

Once the appliance starts, it will run through the following steps:

- 1. The water temperature drops below the set temperature of (for example) 65°C. The electronic controller detects a demand and starts the heating cycle.
 - The icon 🛙 is activated.
 - The message HEAT DEMAND appears.

| ON u |
|---------------------|
| 13:45 Thursday 63°C |
| Tset 65°C |
| HEAT DEMAND |

- 2. Once demand is registered, the fan is started to exhaust any gases that may be present. This phase is called pre-purge and lasts about 15 seconds.
 - The icon 🖲 is activated.
 - The message PRE PURGE appears.

| ON LL |
|---------------------|
| 13:45 Thursday 63°C |
| Tset 65°C |
| PRE PURGE |

- 3. During the pre-purge, the pressure switch closes.
 - The icon 🕀 is activated.
 - The message PRESSURE SWITCH appears.

| ON LLL |
|---------------------|
| 13:45 Thursday 63°C |
| Tset 65°C |
| PRESSURE SWITCH |

- 4. After some time, the pre-purge ceases and the electronic controller reduces the fan speed to the ignition speed. This is followed by the (pre-)glow of the hot surface igniter.
 - The icons $\textcircled{\ }$ and $\textcircled{\ }$ are dimmed
 - The icon 🖾 is activated.

| ON u u | | | | | |
|---------------------|--|--|--|--|--|
| 13:45 Thursday 63°C | | | | | |
| Tset 65°C | | | | | |
| GLOW PLUG | | | | | |

- 5. After a number of seconds pre-glow, the gas control is opened and ignition takes place.
 - The icon 🗊 is activated.
 - The message IGNITION appears.

| | 1 🖲 🖯 |) 🛱 🗊 💽 |
|--------|----------|---------|
| ON | ц | υ υ |
| 13:45 | Thursday | €3°C |
| | Tse | et 65°C |
| IGNITI | ON | |

- 6. After ignition, the flame is detected and the appliance will be running. This means that actual heating has started. The fan speed then increases to the normal working speed, and the pressure switch closes:
 - The icon 🖾 is dimmed.
 - The icons $\ensuremath{\widehat{}}$ and $\ensuremath{\widehat{}}$ are activated.
 - The message RUNNING appears.

| | | | 2 8 0 |
|--------|--------|-----|-------|
| ON | ц | ц | чu |
| 13:45 | Thurso | łay | 63°C |
| | ٦ | set | 65°C |
| RUNNIN | łG | | |

- 7. When the water is up to temperature, the heat demand drops off and the post-purge starts. This lasts about 25 seconds.
 - The icons \mathbb{I} , \mathbb{I} and \mathbb{I} are dimmed.
 - The icon 🗐 is activated.
 - The message POST PURGE appears.

| ON | <u>ц</u> |
|--------|---------------|
| 13:45 | Thursday 65°C |
| | Tset 65°C |
| POST I | PURGE |

- 8. Following the post-purge, the fan stops and the pressure switch opens:
 - The icons \boxdot and B are dimmed.
 - The message POST PURGE vanishes.

| | 1 🖻 🕀 (| |
|-------------|----------|------|
| ON 14:05 | Thursday | 65°C |

With any subsequent heat demand, the heating cycle will resume from step 1.



0 Shutting down

10.1 Introduction

This chapter describes:

- Shut the appliance down for a brief period ("OFF mode");
- Electrically isolating the appliance;
- Shutting the appliance down for a long period.

10.2 Shut the appliance down for a brief period ("OFF mode")

To shut the appliance down for a brief period, you must activate the frost protection.

You can use the frost protection to prevent water freezing in the appliance.

Activate the frost protection as follows:

- Use ↑ and ↓ to position the cursor in front of OFF. Confirm with ENTER.

OFF 13:45 Thursday 6°C FROST PROTECTION ACTIVATED

The frost protection cuts in if the water temperature drops below 5°C. The text FR05T will then appear on line one of the display. The appliance heats the water to 20°C (T_{set}) and drops back to the 0FF mode.

Note

These values of 5°C and 20°C cannot be adjusted.

10.3 Electrically isolating the appliance

The appliance should only be isolated from mains power in the correct way. The correct procedure is as follows:

- 1. Activate the MENU with and
- 2. Position the cursor in front of OFF.
- 3. Confirm OFF with ENTER.

MENU

- ÷OFF
- ↑ ON
- ▼ WEEK PROGRAM

∭, Caution

Failure to wait until the fan stops purging can cause damage to the appliance.

- 4. Wait until the fan has stopped. The 🗐 symbol is then dimmed.
- 5. Switch the appliance **OFF (position 0)** using the ON/OFF switch on the control panel.



IMD-0588 R0

6. Isolate the appliance from the power supply by setting the isolator between the appliance and the mains power supply to position 0.

10.4 Shutting the appliance down for a long period

Drain the appliance if you are shutting it down for a long period. Proceed as follows:

- Isolate the appliance from the power supply (10.3 "Electrically isolating the appliance").
- 2. Shut off the gas supply.
- 3. Close the stop valve in the hot water pipe.
- 4. Open the drain valve
- 5. Bleed the appliance (or installation) so that it drains completely.

10

Shutting down





Main menu

11.1 Introduction

The MENU is reached by pressing the $rac{2}{2}$ button on the electronic controller.

| - | >OFF |
|---|--------------|
| ۰ | ON |
| Ŧ | WEEK PROGRAM |
| | EXTRA PERIOD |
| | SETTINGS |

The main menu comprises:

• 0FF

Select this option if you wish to turn off (10 "Shutting down") the appliance for a brief period, but do not wish to drain it. In this mode, the frost protection is active. This prevents water from freezing in the appliance.

□N In this mode, the appliance continually responds to the hot water demand. (11.3 "Switching on the "ON mode"")

WEEK PROGRAM Select this option to allow the appliance to respond to demand only during pre-programmed periods (11.5 "Week program"). Outside those periods, only frost protection is active.

EXTRA PERIOD Select this option to overrule the OFF mode or PROG mode (i.e. Week program) so that a single temporary period (11.10 "Extra period") of heat demand will be fulfilled.

SETTINGS Select this option to set (11.12 "Settings") the language and the time. You can also use this option to display the regulation interval (temperature), and the ignition and working speeds of the fan.

Note

If you fail to make any selection with the main menu open, then after 30 seconds, the appliance will automatically return to the mode it was previously in.

11.2 Notational convention for menu-related instructions

The MENU () of the electronic controller is divided into submenus. For example, SETTINGS is one of the functions reached from the main menu. The SETTINGS menu is divided into submenus in turn.

For example, LANGUAGE is a submenu of SETTINGS. So, for example, to select the LANGUAGE menu, this manual uses the following notational convention:

: SETTINGS | LANGUAGE
 Confirm with ENTER.

This means:

- 1. 🖙 : Activate the main menu with 🚌.
- 2. SETTINGS: Use the ↑ and/or ↓ buttons to go to SETTINGS and confirm with ENTER.
- 3. LANGUAGE: Use the ↑ and/or ↓ buttons to go to LANGUAGE
- 4. Confirm with ENTER. After entering ENTER, you will have activated the LANGUAGE submenu.

11.3 Switching on the "ON mode"

You can switch the appliance to the ON mode from any operational mode, as follows:

1. 🚌:ON|START OPERATION

Confirm with ENTER.

Note

First consult the chapter about switching on (9 "Starting and running") too.

11.4 Setting the water temperature

11.4.1 Setting the water temperature via the SET POINT MENU

Set the water temperature via:

1. 🚌: ON | CHANGE SETPOINT

Confirm with ENTER.

| START OPERATION |
|-------------------|
| ★→CHANGE SETPOINT |
| ▼ Tset=65°C |
| |

- 2. Use:
- to increase the value;
- to decrease the value.
- Confirm with ENTER.After confirming, the appliance enters "ONmode".

SETPOINT

→ 65°C



11.4.2 Setting water temperature during ON mode

The water temperature can also be directly adjusted when the appliance is in the "ON mode". Simply use:

- to increase the value;
- to decrease the value.
- Confirm with ENTER.

ON 13:45 Thursday 65°C Tset→65°C

11.5 Week program

Using the week program, you can set the water temperature for the days and times you want.

If the appliance is running under a week program, this is indicated on the display by the PROG text on the first line (see the figure). The second line shows the time of day, the day of the week and the temperature. The third line shows the next switching time of the week program and the programmed temperature. The fourth line shows the PROGRAM ACTIVATED text.

```
PROG
07:55 Monday 64°C
MO 08:00 Tset 75°C
PROGRAM ACTIVATED
```

The appliance's default week program switches the appliance on every day at 00:00 and off at 23:59. The default water temperature setting is 65° C.

If you want, you can change every setting in the appliance's standard week program.

If the water temperature becomes too low while the week program is running, the appliance will run through the heating cycle (9.3 "The appliance's heating cycle") and return to the week program.

This following are discussed:

- Starting and stopping the week program
- Changing the appliance's standard week program
- Adding times to a week program
- Deleting times from a week program

11.6 Starting and stopping the week program

The week program can be started up from any other operating mode, as follows:

A week program can be shut down simply by activating a different operating mode, for example the "ON mode".

11.7 Changing the appliance's standard week program

Note

First fill-in the desired week program on the supplied week program card.

A week program is made up of a number of programmable periods in which you can have the appliance switch on and off. A period consists of:

- switch-on time: day of the week, hours and minutes:
- switch-off time: hours and minutes;
- the water temperature setting;
- on/off setting for a program-controlled pump.

Note

The switch-off time must always be followed by a switch-off time on the same day of the week. A maximum of **three** periods may be programmed per day. You can program a maximum of **21** periods.

Call up the menu for the week program as follows:

WEEK PROGRAM

START OPERATION ↑→PROGRAM OVERVIEW



The display shows the menu for the week program, see the figure below. With the default setting, the program switches on and off every day at 00:00 and 23:59 hours respectively, the water temperature is 65° C and the pump is switched on (F).

| | DAY | TIME | Tset | |
|------------|------|---------|-------|---|
| ON - | ∙SU | 00:00 | 65°C | Ρ |
| OFF | SU | 23:59 | | |
| ON | MO | 00:00 | 65°C | Р |
| OFF | MO | 23:59 | | |
| ON | ΤU | 00:00 | 65°C | Ρ |
| OFF | ΤU | 23:59 | | |
| ON | WΕ | 00:00 | 65°C | Ρ |
| OFF | WΕ | 23:59 | | |
| ON | ΤH | 00:00 | 65°C | Ρ |
| OFF | ΤH | 23:59 | | |
| ON | FR | 00:00 | 65°C | Ρ |
| OFF | FR | 23:59 | | |
| ON | SA | 00:00 | 65°C | Ρ |
| 0FF | SA | 23:59 | | |
| | INSE | ERT | | |
| | DEL | ETE | | |
| | STAP | RT OPER | RATIO | 4 |
| | | | | |

Example

As an example, we will set the switch-on time for Sunday to 08:15 hours, and the matching switch-off time to 12:45 hours. The water temperature will be set to 75 °C and the pump will run continuously. The following settings are entered one by one via the menu: the switch-on time, the switch-off time, the desired water temperature, and the mode of the program-controlled pump.

11.7.1 Week program: setting the switchon time

1. Bring the cursor to SU Confirm with ENTER.

| ON ÷ | SU 0 | 0:00 | |
|-------------|------|------|--|
| ON ÷ OFF | SU 2 | 3:59 | |
| Tset | 65°C | | |
| PUMP | ON | SAVE | |

The day indicated by ÷ flashes.

 Use ↑ and ↓ to set the desired day. In the example this is 5U (Sunday).

Confirm with ENTER.

| ON OFF | SU→00:00 | |
|--------------|----------|------|
| OFF | SU 00:59 | |
| Tset | 65°C | |
| Tset PUMP | ON | SAVE |
| | | |

The cursor moves to the hour digits, which flash.

Use ↑ and ↓ to set the hours. In the example, this is 08.

Confirm with ENTER.

The cursor moves to the minute digits, which flash.

| ON | SU | 08÷00 | |
|------|-----|-------|------|
| | | 08:00 | |
| Tset | 65' | °C | |
| PUMP | | | SAVE |

Note

Because the switch-off time can never be earlier than the switch-on time, the switch-off time setting is automatically adjusted with the switch-on time.

 Use ↑ and ↓ to set the minutes. In the example, this is 15.

Confirm with ENTER.

The cursor moves to the switch-off hour digits, which flash.

| ON | SU 08:1 | 5 |
|------|---------|------|
| OFF | SU÷08:1 | 5 |
| Tset | 65°C | |
| PUMP | ON | SAVE |

11.7.2 Week program: setting the switchoff time

Use ↑ and ↓ to set the hours. In the example, this is 12.

Confirm with ENTER.

The cursor moves to the minute digits, which flash.

| ON | SU 08:15 | |
|------|----------|------|
| OFF | SU 12→15 | |
| Tset | 65°C | |
| PUMP | ON | SAVE |

 Use ↑ and ↓ to set the minutes. In the example, this is 45.

Confirm with ENTER.

The cursor moves to the desired water temperature.

ON SU 08:15 OFF SU 12:45 Tset→65°C PUMP ON SAVE

11.7.3 Week program: setting the water temperature

Use ↑ and ↓ to set the water temperature. In the example this is 75°C.

Confirm with ENTER.

The cursor moves to PUMP ON

| ON | SU | 08: | 15 | |
|-------|-----|-----|------|--|
| | | 12: | 45 | |
| Tset | 75° | °C | | |
| PUMP: | ۰ON | | SAVE | |



11.7.4 Week program: setting the programcontrolled pump

 If required, a pump can be controlled during the period. Use ↑ and ↓ to set PUMP ON . The pump ensures a regular circulation of hot water in the hot water pipes. You can skip this step if you there is no pump in your hot water circuit.

Confirm with ENTER.

The cursor moves to SAVE.

| ON | SU | 08: | 15 | |
|-------|-----|-----|------|--|
| OFF | SU | 12: | 45 | |
| Tset | 75° | °C | | |
| PUMP÷ | ON | | SAVE | |
| | | | | |

2. Confirm with ENTER.

The display shown in the figure will appear.

| | DAY | TIME | Tset | |
|------|-----|-------|------|---|
| ON H | ∙SU | 08:15 | 75°C | Р |
| OFF | SU | 12:45 | | |
| ON | MO | 00:00 | 65°C | Р |
| OFF | MO | 23:59 | | |
| ON | TU | 00:00 | 65°C | Р |
| OFF | ΤŪ | 23:59 | | |
| | | | | |


- 3. If you wish, you can use ↓ to scroll to another day, and change more switch-on times (11.7.1 "Week program: setting the switch-on time") and switchoff times (11.7.2 "Week program: setting the switch-off time").

11.8 Adding times to a week program

Call up the menu to INSERT switch-on and switch-off times into a week program as follows:

1. 🚌: WEEK PROGRAM | PROGRAM OVERVIEW.

Confirm with ENTER.



The display shows the menu for the week program. The cursor points to the active period.

| DAY | TIME 1 | set |
|--------|---------|--------|
| ON →SU | 08:15 7 | '5°C P |
| OFF SU | 12:45 | |
| ON MO | 00:00 6 | 5°C P |
| | | |
| | | |
| OFF SA | 23:59 | |
| INSE | RT | |
| DELE | TE | |
| STAR | T OPERF | ATION |

Confirm with ENTER.

The sub-menu for adding a period will appear.

| ON →SU 08:15 | |
|---------------------------|--|
| OFF SU 12:45 | |
| Tset 75°C | |
| Tset 75°C PUMP ON SAVE | |

Example

As an example, we will program an extra period in which the switch-on time is set to 18:00 hours, and the corresponding switch-off time to 22:00 hours. The water temperature will be set to 75 °C and the pump will run continuously.

| DAY | TIME | Tset | |
|--------|--------|--------|--|
| | | 75°C P | |
| OFF SU | 22:00 | | |
| ON MO | 00:00 | 65°C P | |
| OFF MO | 23:59 | | |
| | | | |
| | | | |
| OFF SA | 23:59 | | |
| INSE | RT | | |
| DELE | ΤE | | |
| STAR | T OPER | RATION | |

- 3. Proceed as follows:
 - a. Set the switch-on time (11.7.1 "Week program: setting the switch-on time").
 - b. Set the switch-off time (11.7.2 "Week program: setting the switch-off time").
 - c. Set the water temperature (11.7.3 "Week program: setting the water temperature").
 - d. Set the program-controlled pump (11.7.4 "Week program: setting the program-controlled pump").



11.9 Deleting times from a week program

All switch-on/off times are shown sequentially in the display. Assume that the switch-on/off times for the appliance are programmed as in the figure.

| | DAY | TIME | Tset | |
|------|-------|--------|--------|--|
| ON H | ∙SU | 08:15 | 75°C P | |
| OFF | SU | 12:45 | | |
| ON | SU | 18:00 | 75°C P | |
| OFF | SU | 22:00 | | |
| | | | | |
| | | | | |
| OFF | SA | 23:59 | | |
| | INSE | RT | | |
| | DFI F | TF | | |
| | CTOD | T ODEE | OTTON | |
| | SIHK | T OPER | HIION | |

To delete a period, proceed as follows:

| MENU | |
|--------|---------|
| OFF | |
| *→0N | |
| ➡ WEEK | PROGRAM |

WEEK PROGROM

| START O | PERATION |
|-------------------|----------|
| ^ →PROGRAM | OVERVIEW |
| Ŧ | |

The display shows the menu for the week program.

Confirm with ENTER.

To warn you that you are now working in the delete sub-menu, the cursor is replaced with an exclamation mark (!) and the period settings flash.

| ON ! OFF | SU | TIME 08:15 12:45 | Tset 75°C P |
|-------------|---------|------------------------|----------------|
| | | | |
| ON | SU | 18:00 | 75°C P |
| OFF | SU | 22:00 | |
| • • • • | • • • • | | |
| | | | |
| OFF | SA | 23:59 | |
| | INSE | RT | |
| | DELE | TE | |
| | стор | T OPER | оттом |
| | DIHR | I OFER | MITON |

 Scroll with to the day to be deleted. For example, 5U (Sunday) in the second period. See the figure.

Confirm with ENTER.

| | DAY | TIME | Tset | |
|------|------|--------|--------|--|
| ON ! | SU | 18:00 | 75°C P | |
| OFF | SU | 22:00 | | |
| ON | MO | 00:00 | 65°C P | |
| 0FF | MO | 23:59 | | |
| | | | | |
| | | | | |
| OFF | SA | 23:59 | | |
| | INSE | RT | | |
| | DELE | ΤE | | |
| | STAR | T OPER | RATION | |

5. The lines showing switch-on/off times are replaced by the text DELETE BLOCK?. See the figure.

Confirm with ENTER. (or use RESET to cancel)

| | | TIME Tset | |
|-----|----|--------------------------------|---|
| ON | ! | DELETE | |
| OFF | | BLOCK? | |
| ON | MO | DELETE BLOCK? 00:00 65°C | Р |

The switching period has been deleted. You will return now to the week program menu. The cursor points to the first programmed period.

| | DAY | TIME | Tset | |
|------|-------|--------|---------|--|
| ON → | ·SU | 08:15 | 75°C P | |
| OFF | SU | 12:45 | | |
| ON | MO | 00:00 | 65°C P | |
| OFF | MO | 23:59 | | |
| | | | | |
| | | | | |
| OFF | SA | 23:59 | | |
| | INSE | RT | | |
| | DELE | TF | | |
| | | T OPFR | οττον | |
| | - 1 m | | (millon | |

Confirm with ENTER.

The week program is active.

11.10 Extra period

Use an extra period when you either want to have the appliance switch on and off for a certain period, either without modifying the active week program, or without taking the appliance out of the OFF mode (frost protection active).

If the appliance is running under an "extra period", then this is indicated in the display with the text EXTRA.

| EXTRA | |
|-----------------------------------|------|
| | 76°C |
| MO 11:15 Tset PERIOD ACTIVATED | 75°C |
| PERIOD ACTIVATED |) |



If the water temperature becomes too low during the extra period (11.11 "Programming an extra period"), the appliance will run through the heating cycle (9.3 "The appliance's heating cycle") and fall back into the extra period.

The same settings can be made for an extra period as for a week program (11.7 "Changing the appliance's standard week program") period.

11.11 Programming an extra period

- 1. Call up the menu for entering an extra period via:
- 2. 🚌 EXTRA PERIOD

Confirm with ENTER.

| MENU |
|----------------|
| ON |
| ↑ WEEK PROGRAM |
| ★→EXTRA PERIOD |

The display show the settings for the extra period. **Setting the switch-on time**

 Use ↑ and ↓ to set the day. In the example this is SU.

Confirm with ENTER.

The cursor moves to the hour digits, which flash.

| ON | SU+00:0 | 9 |
|------|---------|-------|
| 0FF | SU 00:5 | 9 |
| Tset | 65°C | |
| PUMP | ON | START |

 Use ↑ and ↓ to set the switch-on hour to the desired value. In the example, this is Ø8.

Confirm with ENTER.

The cursor moves to the minute digits, which flash.

| ON | SU 08÷00 |
|------|----------|
| OFF | SU 08:00 |
| Tset | 65°C |
| PUMP | ON START |

Note

Because the switch-off time can never be earlier than the switch-on time, the switch-off time setting is automatically adjusted with the switch-on time.

 Use ↑ and ↓ to set the minutes. In the example, this is 15.

Confirm with ENTER.

The cursor moves to the hour digits of the switchoff period.

| ON | SU 08: | 15 |
|------|--------|-------|
| OFF | SU÷08: | 15 |
| Tset | 65°C | |
| PUMP | ON | START |

Setting the switch-off time

 Use ↑ and ↓ to set the hours. In the example, this is @12.

Confirm with ENTER.

The cursor moves to the minute digits, which flash.

| ON | SU 08:15 |
|------|----------|
| OFF | SU 12+15 |
| Tset | 65°C |
| PUMP | |

 Use ↑ and ↓ to set the minutes. In the example, this is 45.

Confirm with ENTER.

The cursor moves to the water temperature. See the figure

| ON | SU | 08:15 |
|-------|------|-------|
| OFF | SU | 12:45 |
| Tset÷ | •65° | °C |
| PUMP | ΟN | START |

Setting the water temperature

 Use ↑ and ↓ to set the water temperature. In the example this is 75°C.

Confirm with ENTER.

The cursor moves to PUMP ON

| ON | SU | 08:15 | |
|-------|-----|-------------|--|
| OFF | SU | 12:45 | |
| Tset | 75° | °C START | |
| PUMP+ | +ON | START | |

Setting the program-controlled pump

 If required, a pump can be controlled during the period. Use ↑ and ↓ to set PUMP ON. The pump ensures a regular circulation of hot water in the hot water pipes. You can skip this step if you there is no pump in your hot water circuit.

Confirm with ENTER. The cursor moves to START.

| ON OFF | SU 08:15 |
|-----------|-----------|
| OFF | SU 12:45 |
| Tset | 75°C |
| PUMP | ON →START |
| | |

2. Confirm with ENTER.

The extra period has been programmed.

Note

Once the extra period has completed running, the controller returns to the mode ON, OFF or WEEK PROGRAM. The following week, the extra period will **NOT** be automatically switched on.



11.12 Settings

Using the SETTINGS option, you can adjust certain settings and read certain appliance data:

- Adjustable settings
 - Language of the menu.
 - Current day of week and time.
- Displayable appliance specifications, this category is only relevant to the installation engineer and/or service and maintenance engineer
 - Control range (water temperature).
 - Ignition speed of fan.
 - Working speed of fan.

11.12.1 Setting menu language

To set menu language:

| MENU | |
|----------------|--|
| WEEK PROGRAM | |
| ▲ EXTRA PERIOD | |
| ★→SETTINGS | |

- 1. Call up the menu for selecting the language as follows:
- 2. 🚓: SETTINGS.

Confirm with ENTER.

The display shows the menu for settings.

3. The cursor is positioned beside LANGUAGE Confirm with ENTER.

The display shows the language selection menu.

| LANGUAGE ENGLISH ▲ NEDERLANDS ★→DEUTSCH | |
|--|--|
| FRANCAIS ITALIANO CZECH ESPANOL | |

 Scroll with ↓ to the desired language. Confirm with ENTER.

The language is set.

11.12.2 Setting day and time

To enter the time and day:



- 1. Call up the menu for entering the day and time as follows:
- 2. 🚌: SETTINGS.

Confirm with ENTER.

The display shows the menu for settings.

 Scroll with ↑ and ↓ to DAY/TIME Confirm with ENTER.

COMMIN WILLENTER.

| SETTINGS | |
|------------------------------------|--|
| LANGUAGE | |
| ^→DAY/TIME | |
| SPECIFICATIONS | |

The display shows the sub-menu for adjusting the day.

| DP | γγ |
|----|-----------|
| - | ≻Sunday |
| ж. | Monday |
| Ŧ | Tuesday |
| | Wednesday |
| | Thursday |
| | Friday |
| | Saturday |

4. The cursor is positioned beside Sunday.

Scroll with **↑** and **↓** to the desired day. Confirm with ENTER.

The day has been set. The display shows the submenu for adjusting the time.



The cursor moves to the hour digits, which flash.
 Scroll with ↑ and ↓ to the current hour, for example 15.


Confirm with ENTER.



 The cursor moves to the minute digits, which flash. Scroll with ↑ and ↓ to the next minute, for example 45.



Confirm the minute setting with ENTER



The time has been set.

Note

The appliance takes no account of daylight saving.

11.12.3 Displaying appliance specifications (SGE)

Note

This category is solely intended for the installation engineer and/or service and maintenance engineer.

The table shows the correct settings.

| | SGE 40 | SGE 60 |
|--|--------|---------|
| Ignition fan speed (rpm) | | 4920 |
| Working speed of fan (rpm) | | 6300 |
| Regulation interval ([°] C) | | 40 - 80 |

Call up the menu to display the appliance specifications as follows:

1. 🚌: SETTINGS.

Confirm with ENTER.



- EXTRA PERIOD
- →SETTINGS

Confirm with ENTER.

| SETTINGS |
|-----------------|
| LANGUAGE |
| ▲ DAY/TIME |
| →SPECIFICATIONS |

The display shows the sub-menu for displaying appliance specifications.

| SF | PECIFICATIONS |
|----|---------------------------------------|
| ÷F | REGULATION INTERVAL IGNITION SPEED |
| - | IGNITION SPEED WORKING SPEED |
| | WORKTHO JIEED |

3. Scroll with ↓ to the section to be displayed, for

example REGULATION INTERVAL.

The relevant display appears.

REGULATION INTERVAL

40-80°C




12 Service program

12.1 Introduction

The service program is used by the installation engineer or service and maintenance engineer for:

- Setting the hysteresis
- Displaying the error history
- · Displaying the appliance history
- Display the selected appliance
- · Setting the service interval
- Setting legionella prevention
- Solar heating system configuration
- Setting the central heating configuration



These sub-menus are briefly described in the following paragraphs. If you are not familiar in general with how to use the displays and menus, first read the relevant chapter (7 "The control panel").

Note

The notation convention for the service menu is identical to that of the main menu (11.2 "Notational convention for menu-related instructions"). The difference is, you use to bring up the service program, instead of the which brings up the main menu.

12.2 Setting the hysteresis

Call up the menu to set the hysteresis as follows:

HYSTERESE DOWN →3°C

| Appliance | Default | Range |
|-----------|---------|---------|
| 40 | - °C. | - °C. |
| 60 | 5 °C. | 2 7 °C. |

12.3 Displaying the error history

Display the error history as follows:

• ∞ HISTORY OF ERRORS

The controller will display an overview of "Blocking errors" and "Lock out errors". In both cases, the electronic controller reserves 15 lines for the last 15 error messages. If there are fewer than 15 error messages, an ellipsis (...) is displayed. The display first shows the "Blocking errors". When ENTER is pressed, the "Lock out errors" are then displayed.

The figure shows an example of "Blocking errors". In this case, the text HISTORY OF ERRORS is followed by (B).

| H] | STOR | :Y 0 | IF E | ERR | ORS | (8) |
|----|------|------|------|-----|-----|-----|
| | SØ4 | SEN | ISOF | 8 E | RRO | R |
| | F06 | ION | IIZA | ÌΤΙ | ON | |
| Ŧ | C02 | 50 | ΗZ | ER | ROR | |

The figure shows an example of "Lock out errors". In this case, the text <code>HISTORY OF ERRORS</code> is followed by (L).

HISTORY OF ERRORS(L) F02 FAN F07 FLAME ERROR

🔊 Note

For an overview of all errors and the possible causes, please refer to the relevant chapter (13 "Troubleshooting").

12.4 Displaying the appliance history

The appliance history submenu is used to display the burning hours, the number of ignitions, the number of flame errors and the number of ignition errors.

Call up the menu for displaying the appliance history as follows:

• ∞ APPLIANCE HISTORY

The figure shows an example.



| APPLIA | ACE HIST | FORY |
|-----------------|----------------|--------|
| BURNI | 4GHOURS | 000410 |
| ≜ IGNIT: | [ONS | 001000 |
| ₩ FLAME | ERRORS | 000021 |
| IGNIT | ERROR | 000013 |

12.5 Display the selected appliance

Call up the menu for displaying the appliance selection as follows:

• ∞ SELECT APPLIANCE

The appliance number can be found on the rating plate.

The appliance selection has been correctly preset in the factory.

| SELECT →5934 | APPLIANCE |
|------------------|-----------|
| ↑ 8576 ▼ 3379 | |
| 6527 | |


12.6 Switching the pump on or off

If a program-controlled pump is

installed (3.11.6 "Connecting a program-controlled pump"), it can be switched ON or OFF as follows:

• ∞=: PUMP RELAY

The standard setting for the pump relay is OFF.



If the mode WEEK PROGRAM or EXTRA PERIOD is active, then the setting for mode WEEK PROGRAM or EXTRA PERIOD has priority over the ON/OFF selection for the pump relay in the service menu.

Example

One of the week program periods is currently active. During this period, the pump relay setting is OFF. If the pump relay is set ON in the service menu, the pump will nonetheless remain OFF. The pump will only switch ON once the week program period has ended.

12.7 Setting the service interval

To aid servicing, the electronic controller includes a service interval which is used to set the frequency of maintenance interval (14.2 "Determining service interval") by the service and maintenance engineer, based on the number of burning hours.

The service interval is based on the number of burning hours. This can be set to 500, 1000 and 1500 hours. The standard setting for number of hours is **500**. Once the preset number of hours is reached, a message (8.4 "Service condition"). to this effect will

ఌ≕: SERVICE INTERVAL

appear. Adjust the service interval via:

| SE | RVICE | E INTERVA | ΑL |
|----|-------|-----------|-------|
| | > 500 | | |
| ÷ | 1000 | BURNING | HOURS |
| Ŧ | 1500 | | |

12.8 Setting legionella prevention

To prevent infection with legionella bacteria, the appliance heats the water to 65 °C once per week, for 1 hour. This period is adjustable. By default, this period is set to Monday from 02:00 to 03:00 hours.

12.8.1 Switching legionella prevention on and off

To switch legionella prevention on or off, select:

≫:ANTI LEGIONELLA

| ANTI LEGIONELLA | |
|-----------------|--|
| →YES | |
| NO | |
| | |

- Select NO to switch legionella prevention off.
- Select YES to switch legionella prevention on. The following display appears:

| ON MO 02:00 LEG | |
|----------------------------|--|
| OFF MO 03:00 | |
| Tset 65°C | |
| Tset 65°C →START CHANGE | |

 Select START to activate the period currently displayed.

The following display appears. This display indicates that legionella prevention is switched on.

| LEG L L L L 02:45 Monday 60°C MO 03:00 Tset 65°C |
|--|
| 02:45 Monday 60°C |
| MO 03:00 Tset 65°C |
| RUNNING |

12.8.2 Changing legionella prevention start time

If you wish to change the start time, select:

② ⇒: ANTI LEGIONELLA | YES | CHANGE

The following display appears.


| ON →MO 02:00 OFF MO 03:00 | LE6 |
|------------------------------|-----|
| OFF MO 03:00 | |
| Tset 65 o C | |
| START | |



- Now set the day and time the same way as described for setting an extra period in the week menu (11.11 "Programming an extra period"). In this case however, the pump will be automatically started.
- Select START to start.

12.9 Solar heating system configuration

Use the solar heating system settings menu to reach the menus shown here:



12.9.1 Setting the drain-back tank

Use this menu to specify whether the solar heating system is equipped with a drain-back tank for the heating fluid. Call up the menu as follows:

• ∞=:SETTINGS SOLAR|DRAIN BACK

The default is NO.

| BACK |
|------|
| |
| |
| |
| |

Note


The first time the appliance is started, it is necessary to check whether this setting corresponds with the configuration of the solar heating system.

12.9.2 Setting the heating fluid type in the solar heating system

Use this menu to specify the type of heating fluid used to fill the solar heating system (2.6 "Protection for the solar heating system"). Call up the menu as follows:

● D=: SETTINGS SOLAR | TYPE OF FLUID

You can select from Glucol and Water. The default is Glucol.



Note

The first time the appliance is started, it is necessary to check whether this setting corresponds with the configuration of the solar heating system.

Note

The setting Water is currently not possible

12.9.3 Setting threshold temperature of pump in solar heating system

The pump of the solar heating system is switched on when the difference (9.3 "The appliance's heating cycle") between the temperature at the top of the solar collector (sensor S_1) and that in the appliance (sensor S_2) exceeds a certain value. This value can be set to between 5 and 20 °C. Call up this menu as follows:

• ∞ SETTINGS SOLAR | DELTA T SOLAR The default value is 10 °C.

| DELTA | Т | SOLAR | |
|-------|---|-------|--|
| 10°C | | | |
| | | | |

12.9.4 Setting the solar limit temperature

The solar limit temperature is the maximum water temperature obtained in the appliance via the solar heating system (measured by sensor T_1).

This value can be set between 65 ... 80 $^\circ\text{C}.$ The default value is 65 $^\circ\text{C}.$

If you set the solar limit higher than the set point (11.4 "Setting the water temperature"), then once the set point is reached, the solar pump will be started to heat the water further. However, this only makes sense if the solar heating system is actually generating heat. This makes use of the difference between the temperature at the top of the solar collector (S_1) and that in the appliance (measured by S_2). This value is also adjustable (12.9.3 "Setting threshold temperature of pump in solar heating system").

Call up the menu for the solar limit as follows:

• ∞ SETTINGS SOLAR | SOLAR LIMIT

SOLAR LIMIT 65°C

12.9.5 Setting the solar difference

The solar difference is a value that influences how the heating cycle of the appliance proceeds. Call up the menu as follows:



• ೨≕: SETTINGS SOLAR | SOLAR DIFFERENCE

SOLAR DIFFERENCE

• ☜: SETTINGS HEATING

SETTINGS HEATING

5°C

| Appliance | Default | Range |
|-----------|---------|-------|
| 40 | - °C. | - °C. |
| 60 | 0 8°C. | 5 °C. |

12.9.6 Setting the QT sensor yes/no

The energy contribution of the solar heating system can be calculated (12.9.7 "Reading the energy contribution of the solar heating system") with the aid of the Q/T sensor. This calculation is only possible if your installation is equipped with such a Q/T sensor. If this is the case, then you must set this value to YES, otherwise NO. Call up the applicable menu as follows:

∞ SETTINGS SOLAR | QT SENSOR

| QT SENSOR |
|-----------|
| YES |
| 160 |
| →NO |
| 110 |
| |
| |

12.9.7 Reading the energy contribution of the solar heating system

This option enables you to read out how much energy the solar heating system supplies. For this data to be displayed, the installation must be equipped with a QT sensor (12.9.6 "Setting the QT sensor yes/no").

3 values are reported on the display:

- ACTUAL, actual energy: the amount of energy currently being supplied.
- LAST 24hr, energy supplied over last 24 hours.
- TOTAL, total energy supplied since day 1.

Call up this menu as follows:

• ∞ SETTINGS SOLAR | CONTRIBUTION

CONTRIBUTION ACTUAL 00000 kW LAST 24hr 00000 kJ TOTAL 00000 Mj

12.10 Setting the central heating configuration

Use this menu to specify whether a central heating system is connected to the installation.

Note

This function is not yet available.



Troubleshooting

13.1 Introduction

A distinction is made between:

General errors

- General errors are not reported on the display. General errors are:
- Gas smell
- Display does not light up
- Insufficient or no hot water.
- Water leakage
- Explosive ignition.

The manual includes a table with general errors (13.2 "Troubleshooting table for general errors").

Displayed errors

Errors are reported on the display as follows:

- Line one: an error code and a brief description. The code consists of a letter and two digits.
- Lines two, three and four: a long description, alternating with a recommended action. See the figures. The first shows a possible error, the second shows the appropriate checking action.

S02: SENSOR ERROR TOP TANK SENSOR 1 NOT CONNECTED

S02: SENSOR ERROR

CHECK TOP TANK SENSOR

There are various types of errors, all falling into one of two groups:

- LOCK OUT ERRORS When the cause has been removed, these errors require a reset with the RESET button, before the appliance can resume operation.
- BLOCKING ERRORS
 These errors disappear automatically once the cause of the error has been removed, after which the appliance resumes operation by itself.

The manual includes a table of error messages that can appear on the display (13.2 "Troubleshooting table for general errors").

Warnings on the display

The warnings (13.4 "Displayed warnings") can also apply to the solar heating system.



13.2 Troubleshooting table for general errors

Warning Maintenance may only be performed by a qualified service and maintenance engineer.

General errors

| Symptom | Cause | Solution | Remark |
|----------------|---------------------------|---|--|
| Gas smell | Gas leak | Warning Close the main gas valve immediately. Warning Do not operate any switches. Warning No naked flames. Warning Ventilate the boiler room. | Warning Contact your installation engineer or local gas company immediately. |
| Display is off | Appliance is turned off | Start the appliance up (9 "Starting and running") | |
| | No supply voltage present | Check if the isolator is ON. Check that there is power to the isolator. Check whether the ON/OFF switch of the electronic controller is ON (position I). Check whether there is power to the electrical connector block. The measured voltage must be 230 VAC (-15%, +10%). | See the SGE electrical diagram (17 "Appendices") If the error persists, consult your installation engineer. |
| | Defective fuse(s) | Replace fuse(s) | To replace the fuses, you must contact your installation engineer. |



| Symptom | Cause | Solution | Remark |
|------------------------|---|---|--|
| Water leakage | Leakage from a water connection (threaded) | Tighten the threaded connection | If the leak persists, consult your installation engineer |
| | Condensate leakage | Check that the condensation water discharge is working properly. Rectify if necessary | |
| | Leakage from another nearby water appliance or pipe segment | Trace the leak | |
| | Leakage from the appliance's tank | Consult the supplier and/or manufacturer | |
| Explosive ignition | Incorrect supply pressure and/or burner pressure | Set the correct supply pressure and/or burner pressure. (3.13 "Checking the supply pressure and burner pressure") | If ignition is not improved, consult your installation engineer. |
| | Contaminated burner | Clean the burner(s) (15.4.2 "Clean the burner(s)") | |
| | Contaminated orifice | Clean the orifice(s) (15.4.3 "Clean the orifice(s)") | |
| Hot water supply | Appliance is turned off | Start the appliance up (9 "Starting and running") | |
| insufficient or absent | No supply voltage present | 1. Check if the isolator is ON. | See the SGE electrical diagram (17 "Appendices") |
| | | 2. Check that there is power to the isolator. | If the error persists, consult your installation engineer. |
| | | Check whether the ON/OFF switch of the electronic controller is ON (position I). | |
| | | 4. Check whether there is power to the electrical connector block. | |
| | | 5. The measured voltage must be 230 VAC (-15%, +10%). | |
| | Hot water supply is used up | Reduce hot water consumption and give the appliance time to heat up. | If there continues to be insufficient hot water, or none at all, consult your installation engineer. |
| | The controller is in OFF mode. | Switch the controller to the ON mode (11.3 "Switching on the "ON mode"") | |
| | Temperature (T _{set}) is set too low. | Adjust (11.4 "Setting the water temperature") temperature (T _{set}) to a higher value. | |



| Symptom | Cause | Solution | Remark |
|----------------|--|---|---|
| Glycol leakage | Leakage from a fluid connection (threaded) | Tighten the threaded connection. | If the leak persists or a component needs replacement, consult your installation engineer |
| | Leakage from a component | Tighten component joints Any defective components must be replaced | |
| | Leakage from solar heating system | Consult the supplier and/or manufacturer | |



13.3 Troubleshooting table for displayed errors

Displayed errors

| Code + Description | Cause | Solution | Remark |
|---|---------------------------------------|---|---|
| S01 (blocking error) | Sensor is not (correctly) connected | Connect the sensor lead to JP3 | See the SGE electrical diagram (17 "Appendices") |
| Open circuit from temperature sensor T2 at bottom of the tank | Damaged cable or defective sensor | Replace the sensor | To replace the necessary parts, you must contact your installation engineer |
| S02 (blocking error) | Sensor is not (correctly) connected | Connect the sensor lead to JP5 | See the SGE electrical diagram (17 "Appendices") |
| Open circuit in sensor 1 of temperature sensor T_1 at the top of the tank ⁽¹⁾ . | Damaged cable or defective sensor | Replace sensor T ₁ | To replace the necessary parts, you must contact your installation engineer |
| S03 (blocking error) | Sensor is not (correctly) connected | Connect the sensor lead to JP5 | See the SGE electrical diagram (17 "Appendices") |
| Open circuit in sensor 2 of temperature sensor T1 at the top of the tank (1). | Damaged cable or defective sensor | Replace sensor T ₁ | To replace the necessary parts, you must contact your installation engineer |
| S04 (blocking error) | Dummy is not (correctly) connected | Connect the dummy sensor (dummy sensor 1 and 2) leads to JP4. | See the SGE electrical diagram (17 "Appendices") |
| Open circuit from dummy 1 | Defective dummy | Replace the dummy sensor | To replace the necessary parts, you must contact your installation engineer |
| S05 (blocking error) | Dummy is not (correctly) connected | Connect the dummy sensor (dummy sensor 1 and 2) leads to JP4. | See the SGE electrical diagram (17 "Appendices") |
| Open circuit from dummy 2 | Defective dummy | Replace the dummy sensor | To replace the necessary parts, you must contact your installation engineer |
| S07 (blocking error) Open circuit from | Sensor is not (correctly) connected | Connect the sensor lead to J14 (port 2 and 4) of the solar controller | See the SGE electrical diagram (17 "Appendices") |
| temperature sensor S2 at bottom of tank | Damaged cable or defective sensor | Replace the sensor | To replace the necessary parts, you must contact your installation engineer |



| Code + Description | Cause | Solution | Remark |
|---|-------------------------------------|---|---|
| S08 (blocking error) Open circuit from | Sensor is not (correctly) connected | Connect the sensor lead to J13 (port 2 and 4) of the solar controller | See the SGE electrical diagram (17 "Appendices") |
| temperature sensor S1 in the collector | Damaged cable or defective sensor | Replace the sensor | To replace the necessary parts, you must contact your installation engineer |
| S11 (blocking error) Short circuit in the temp. sensor T2 at the bottom of the tank | Short circuit in sensor circuit | Replace sensor T ₂ | To replace the necessary parts, you must contact your installation engineer |
| S12 (blocking error) Short circuit in sensor 1 of temperature sensor T_1 at the top of the tank ⁽¹⁾ | Short circuit in sensor circuit | Replace sensor T ₁ | To replace the necessary parts, you must contact your installation engineer |
| S13 (blocking error) Short circuit in sensor 2 of temperature sensor T1 at the top of the tank ⁽¹⁾ | Short circuit in sensor circuit | Replace sensor T ₁ | To replace the necessary parts, you must contact your installation engineer |
| S14 (blocking error) Short circuit from dummy 1 | Short circuit in sensor circuit | Replace the dummy sensor ⁽²⁾ | To replace the necessary parts, you must contact your installation engineer |
| S15 (blocking error) Short circuit from dummy 2 | Short circuit in sensor circuit | Replace the dummy sensor ⁽²⁾ | To replace the necessary parts, you must contact your installation engineer |
| S17 (blocking error) Short circuit in temp. sensor S1 at bottom of tank | Sensor is not (correctly) connected | Replace sensor S2 | To replace the necessary parts, you must contact your installation engineer |



| Code + Description | Cause | Solution | Remark |
|---|--|---|---|
| S18 (blocking error) Short circuit in temp. sensor S1 in the collector | Short circuit in sensor circuit | Replace sensor S1 | To replace the necessary parts, you must contact your installation engineer |
| F01 (blocking error) Defect in power supply | Live and neutral connected wrong way round | Connect live and neutral correctly (3.11 "Electrical connection"); the appliance is phase-sensitive | See the SGE electrical diagram (17 "Appendices") |
| circuit | Condensation on the | 1. Disconnect the lead at the flame probe | If errors persist, contact your installation engineer |
| | flame probe | 2. Ignite the appliance three times, with an interrupted ionisation circuit | |
| | | 3. Reconnect the ionisation lead to the flame probe | |
| | | 4. Ignite the appliance again | |
| | | The repeated ignition attempts will have caused the condensation to evaporate | |
| | Floating neutral | Install an isolating transformer (3.11.4 "Isolating transformer") | Contact your installation engineer to have an isolating transformer installed |
| F02 (lock out error) | Defective motor and/or | 1. Check the motor and rotor | See the SGE electrical diagram (17 "Appendices") |
| Fan fails to run at | rotor. | 2. Replace the fan if the motor or rotor is defective. | To have the wiring replaced and a new fan fitted, you must contact |
| correct speed. | | 3. Reset appliance controller | your installation engineer |
| | Damaged wiring | 1. Check the wiring between the fan and the controller. | |
| | | 2. If any wires are damaged, the wiring harness must be replaced. | |
| | | 3. Reset appliance controller | |
| | Dirty or blocked fan | 1. Check if the fan is dirty | |
| | | 2. Check that the rotor can rotate freely | |
| | | 3. Reset appliance controller | |
| | Because of a drop in | 1. Check the supply voltage, this must be 230 VAC (-15%, +10%). | 1 |
| | the supply voltage, the fan is not running at the correct speed. | 2. Reset appliance controller | |



| Code + Description | Cause | Solution | Remark |
|--|--------------------------------|---|--|
| F03 (lock out error) | Damaged wiring/Open circuit | Check the wiring between the pressure switch and the controller | If the error cannot be resolved or is persistent, contact your installation engineer |
| The pressure switch fails to work correctly | | 2. If necessary, replace the wiring | To replace the necessary parts, you must contact your installation engineer |
| | Pressure switch not closing | 1. Check the running speed of the fan (12.5 "Display the selected appliance") | |
| | | 2. Check that the hoses on the pressure switch and the air supply hose between fan and burner are correctly fitted. Refit them if necessary | |
| | | 3. Check for cracks in the hoses on the pressure switch and in the air supply hose between fan and burner. If necessary, replace the hoses. | |
| | | 4. Check that the flue gas outlet is compliant (3.9 "Air supply and flue"). | |
| | | Check for blockage in the flue gas discharge. Remove any blockage that may be present | |
| | | Check for blockage in the condensation water discharge. Remove any blockage that may be present. | |
| | | 7. Measure the pressure differential across the pressure switch. See the table in Preparation for maintenance (15.2 "Preparation for maintenance"). If there is insufficient pressure differential, clean the heat exchanger. If the pressure differential is acceptable, check that the pressure switch is closing, using a multimeter. | |



| Code + Description | Cause | Solution | Remark |
|--|--|---|--|
| F04 (lock out error) | No gas | 1. Open the main gas valve and/or the manual gas valve supplying the water heater | To repair the gas supply, contact your installation engineer |
| Three unsuccessful ignition attempts. | | 2. Check the supply pressure to the gas control | |
| ignition attempte: | | 3. If necessary, repair the gas supply | |
| | Air in the gas pipes | Bleed the air out of the gas pipe | See Checking the supply pressure and burner pressure for how to |
| | No burner pressure | 1. Check the burner pressure to the gas control | bleed air from the gas line, and measure the supply pressure and burner pressure. |
| | | 2. Check that the gas valve(s) open and shut correctly | To replace the necessary parts, you must contact your installation |
| | | 3. If necessary, replace the gas control. | engineer |
| | Defect in the hot | 1. Check that the hot surface igniter is correctly connected (JP2). | If the error persists, contact your installation engineer. |
| | surface igniter circuit | 2. Check the wiring of the hot surface igniter. | To replace the necessary parts, you must contact your installation engineer |
| | | 3. Measure the resistance across the hot surface igniter. This must lie between 2 and 5 ohms. | |
| | | 4. Check that the hot surface igniter lights up during ignition. | |
| | | 5. If necessary, replace the hot surface igniter. | |
| | Defect in the ionisation circuit | 1. Check that the flame probe is correctly connected (JP2) | |
| | | 2. Check the wiring of the flame probe | |
| | | Measure the ionisation current. This must be at least 1.5 microamps. | |
| | | 4. Replace the wiring if necessary. | |
| | Supply voltage too low | Check the supply voltage, this must be 230 VAC (-15%, +10%). | |
| F05 (lock out error) Too many flame errors have been signalled. | Incorrect roof or wall conduit. Recirculating flue gases. | Check that the correct roof or wall flue conduit (3.9 "Air supply and flue") has been fitted. | If the error cannot be resolved or is persistent, contact your installation engineer |
| | | 2. If necessary, install the correct roof or wall conduit. | |
| | 3 | 3. Check that the roof or wall conduit discharges into a permitted area. | |



| Code + Description | Cause | Solution | Remark |
|---|--|--|--|
| F06 (lock out error) Short circuit between | Damaged cable in contact with metal surface. | Check the wiring of the flame probe. If necessary, replace the wiring. | If the error persists, contact your installation engineer. To replace the necessary parts, you must contact your installation engineer |
| flame probe and earth | Ceramic part of the flame probe is broken/cracked. | Check that the ceramic part of the flame probe is still intact in the vicinity of the burner's air distribution plate. | |
| | DIOREII/CIACREU. | 2. If not, the flame probe must be replaced. | |
| F07 (lock out error) | Defective gas valves | Check whether there is still burner pressure present after the gas valves have closed. | If the error cannot be resolved or is persistent, contact your installation engineer |
| A flame has been detected after the gas valve was closed. | | 2. Check whether a flame is still present after the gas valves have closed. | To replace the necessary parts, you must contact your installation engineer |
| | | 3. If this is the case, the gas control must be replaced. | |
| F08 (lock out error) | Flame detection before the gas valve opened. | 1. Reset the electronic controller. | If the error cannot be resolved or is persistent, contact your installation engineer |
| Error message from safety relay | | 2. If the error reappears, replace the electronic controller. | To replace the necessary parts, you must contact your installation engineer |
| F09 (lock out error) | The temperature at the | 1. Check that the circulation pump (if present) is working | If the error cannot be resolved or is persistent, contact your |
| Water temperature | top of the tank exceeds 93 °C. | 2. Check the position of the temperature sensor T_1 . | installation engineer |
| safety. | | 3. Reset appliance controller | |



| Code + Description | Cause | Solution | Remark |
|--|--------------------------------|---|--|
| F10 (lock out error) | Pressure switch not closing | 1. Check the running speed of the fan (12.5 "Display the selected appliance") | If the error cannot be resolved or is persistent, contact your installation engineer |
| Restriction on the number of ignition attempts based on pressure switch state | | 2. Check that the hoses on the pressure switch and the air supply hose between fan and burner are correctly fitted. Refit them if necessary | To replace the necessary parts, you must contact your installation engineer |
| changes. | | 3. Check for cracks in the hoses on the pressure switch and in the air supply hose between fan and burner. If necessary, replace the hoses. | |
| | | 4. Check that the flue gas outlet is compliant (3.9 "Air supply and flue"). | |
| | | Check for blockage in the flue gas discharge. Remove any blockage that may be present | |
| | | Check for blockage in the condensation water discharge. Remove any blockage that may be present. | |
| | | 7. Measure the pressure differential across the pressure switch. See the table in Preparation for maintenance (15.2 "Preparation for maintenance"). If there is insufficient pressure differential, clean the heat exchanger. If the pressure differential is acceptable, check that the pressure switch is closing, using a multimeter. | |
| F11 (blocking error) | Defective gas valves | See F07. | |
| Flame detection with closed gas valve. | | | |
| F17 (blocking error) | No power supply at | 1. Check that there is power to the solar heating system controller | |
| Communication error | solar controller | 2. The measured voltage must be 230VAC (-15%, +10%) | If the error persists, consult your installation engineer |
| | No cable or damaged cable | Check the wiring (communication cable) between the main controller and the solar heating system controller | See the SGE electrical diagram (17 "Appendices") For replacement of the cable, contact your installation engineer |
| | | 2. If cable missing, connect the cable | |
| | | 3. If cable damaged, replace the cable | |



| Code + Description | Cause | Solution | Remark |
|--|---|--|---|
| C02 (lock out error) Error message from the appliance controller. Internal error message from the appliance controller. | Incorrect reference voltage from the AD converter. • EEPROM read error • 50 Hz error • Internal communication error | Reset electronic controller. Check that the frequency of the power supply is compliant (3.4.2 "General and electrical specifications"). If this is not the case, contact your installation engineer If the frequency is correct but the error persists, replace the electronic controller. | To replace the necessary parts, you must contact your installation engineer |
| Internal error message from the appliance controller. | Gas valve relay error Safety relay error Ignition relay error RAM error EEPROM error EEPROM contents do not match the software version Processor software error | | |
| C03 (blocking error) Reset error | Too many resets in too short a period. | Wait for the error to disappear (maximum 1 hour). If the error does not disappear, replace the appliance controller. | To replace the necessary parts, you must contact your installation engineer |
| C04 (blocking error) Appliance selection error | Incorrect appliance selection / Incorrect selection resistor | Check whether the correct appliance is selected (12.5 "Display the selected appliance"). If the correct appliance is selected, fit the correct selection resistor. If incorrect appliance selected, select the correct one. | If the error cannot be resolved or is persistent, contact your installation engineer To replace the necessary parts, you must contact your installation engineer |



| Code + Description | Cause | Solution | Remark | | |
|---|--|---|---|--|--|
| E01 (blocking error) The temperature protection at the top of the tank has been activated. | The temperature of the water at the top of the tank is > 85 °C. | None. This is a temporary message that may appear from time to time, but will disappear automatically. | | | |
| E03 (lock-out error) Error in temperature sensor T_1 at the top of the tank. | The two temperature sensors in the tank detect a differential of \geq 10 °C over a period of at least 60 seconds. | Check sensor position and wiring. If necessary, reset the electronic controller. Replace the sensor if the error persists. | To replace the necessary parts, you must contact your installation engineer | | |
| E04 (lock-out error) Error in dummy sensor ⁽²⁾ . | The two dummy sensors in the tank detect a differential of \geq 10 °C over a period of at least 60 seconds. | Check leads from dummy 1 and dummy 2. If necessary, reset the electronic controller. Replace the dummy sensor if the error persists. | To replace the necessary parts, you must contact your installation engineer | | |
| | 1) Temperature sensor T ₁ is a '2 in 1' sensor, T ₁ contains 2 NTCs for the high-limit thermostat and safety thermostat protection. (2) The dummy sensor / flue gas sensor comprises dummy sensor / flue gas sensor 1 and dummy sensor / flue gas sensor 2. | | | | |



13.4 Displayed warnings

Displayed warnings

| Symptom | Cause | Solution | Remark |
|--|--|---|--|
| Q/T sensor not correctly connected | reactly connected incorrectly connected | | Properly connect Q/T sensor and the warning will disappear If correctly wired but the warning remains, replace sensor |
| | | | Note: To have the sensor connected or replaced, contact your installation engineer |
| Collector temperature excessive | Temperature S1 is higher than T _{collector} | The pump in the solar circuit switches off, until S1 < 70°C | 1. You can let the message disappear automatically by allowing the heating fluid to cool down |
| | max | | 2. You can also manually eliminate the message by pressing the RESET and ENTER button simultaneously |
| Maximum burning hours: Service required | The actual burning hours have exceeded the preset burning hours | Appliance runs, but displays a warning | For maintenance to your appliance, contact your installation engineer |



14

Maintenance frequency

| 14.1 | Introduction | A service should be carried out at least once a year, both on the water side and on the gas side. Maintenance frequency depends, among other things, on the water quality, the average burning time per day and the set water temperature. |
|------|------------------------------|---|
| | | Note Regular maintenance extends the service life of the appliance. To determine the correct maintenance frequency, it is recommended to arrange for the service and maintenance engineer to check the appliance on both the water and gas side, three months after installation. Based on this check, the best maintenance frequency can be determined. |
| 14.2 | Determining service interval | To aid servicing, the electronic controller has a service interval with which the service and maintenance engineer can determine the frequency of maintenance, based on the number of burning hours. |
| | | The service interval can be set to: 500, 1000 or 1500 burning hours. The standard setting is 500 burning hours. |
| | | <i>Example</i> In the first three months, the appliance has burnt 300 hours. During maintenance, it is evident that one service per year will be sufficient. Therefore, after one year, some 1200 burning hours will have elapsed. The first value below 1200 hours that can be selected is 1000 burning hours. |
| | | In this case, the service and maintenance engineer sets the interval to 1000. |
| | | In the first three months, the appliance has burned for 300 hours. During maintenance, it is evident (perhaps due to the water quality) that service will be required at least once every 6 months. |
| | | Therefore, after six months, some 600 burning hours will have elapsed. The first value below 600 hours that can be selected is 500 burning hours. |
| | | In this case, the service and maintenance engineer sets the interval to 500. |
| | | |

!!! WARNING !!!

MAX. BURNINGHOURS: SERVICE REQUIRED

Once the set number of burning hours has elapsed, the message SERVICE REQUIRED will appear on the display. When this message appears, the service and maintenance engineer must be contacted.





Performing maintenance

15.1 Introduction

15

, Caution

Maintenance may only by carried out by an approved service and maintenance engineer.

At each service, the appliance undergoes maintenance on both the water side and the gas side. The maintenance must be carried out in the following order.

- 1. Preparation for maintenance
- 2. Water-side maintenance
- 3. Gas-side maintenance
- 4. Solar collector maintenance
- 5. Finalizing maintenance

Note

Before ordering spare parts, it is important to write down the appliance type and model, and the full serial number of the appliance. These details can be found on the rating plate. Only by ordering with this information can you be sure to receive the correct spare parts.

15.2 Preparation for maintenance

To test whether all components are still working properly, complete the following steps:

- 1. Activate the MENU with and.
- Use: ↑ and ↓ to place the cursor beside OFF.
- 3. Confirm OFF with ENTER.




4. Wait until the fan has stopped. The 🖲 icon is then dimmed.

🚛 Caution

Failure to wait until the fan stops purging can cause damage to the appliance.

Switch the appliance OFF (position 0) using the ON/OFF switch on the control panel.





IMD-0588 R0

6. Switch the electronic controller **ON** by setting the ON/OFF switch to **position I**.



The display will now show INTERNAL CHECK for about 10 seconds, and will then go to the main menu.

| MB | MENU | | | | |
|----|------|---------|--|--|--|
| - | +0FF | | | | |
| * | ON | | | | |
| Ŧ | WEEK | PROGRAM | | | |

7. Activate "ON mode" by going through the following steps:

- Press once on the blue arrow (♣) to position the cursor beside DN, then press ENTER.
- Confirm the selection START OPERATION with ENTER.
- If there is no heat demand, increase Tset (11.4 "Setting the water temperature"). Note the original setting. Draw some hot water off to create heat demand.
- 9. Check whether the heating cycle runs correctly (9.3 "The appliance's heating cycle").
- 10. If you have adjusted T_{set}, return it to the desired value (11.4 "Setting the water temperature").
- 11. Remove the plastic cover on the top of the appliance.
- 12. Check the supply and burner pressure (3.13 "Checking the supply pressure and burner pressure"), and adjust them if necessary.
- 13. Check that all components of the chimney flue system are properly attached.
- 14. Check the pressure differential across the orifice plate of the pressure switch (see the table). If the pressure difference is too low, the heat exchanger must be cleaned (15.4.4 "Cleaning the heat exchanger").

Pressure switch pressure differential

| Appliance | Observed pressure differential across the pressure switch (Pa) |
|-----------|--|
| SGE 40 | |
| SGE 60 | <u>≥</u> 675 |

- 15. Test the operation of the overflow valve of the protected cold supply setup. The water should spurt out.
- 16. Test the overflow operation of the T&P valve. The water should spurt out.



- 17. Check the drain pipes from the discharge points of all valves and remove any lime buildup that may be present.
- 18. Drain the appliance (see Draining).

15.3 Water-side maintenance

15.3.1 Introduction

The following steps must be carried out on the water side:

- 1. Checking the anodes.
- 2. Descaling and cleaning the tank.
- 3. Cleaning condensation water discharge.

15.3.2 Checking the anodes

Timely replacement of the anodes extends the service life of the appliance. The appliance's anodes must be replaced as soon as they are 60% or more consumed (take this into consideration when determining the maintenance frequency).

- 1. Loosen the anodes using suitable tools.
- 2. Check the anodes, and if necessary, replace them.


15.3.3 Descaling and cleaning the tank

Scale and lime buildup prevent effective conduction of the heat to the water. Periodic cleaning and descaling prevents buildup of these deposits. This increases the service life of the appliance, and also improves the heating process.

Take the rate of scale formation into account when deciding on maintenance frequency. Scale formation depends on the local water composition, the water consumption and the water temperature setting. A water temperature setting of maximum 60°C is recommended for prevention of excessive scale buildup.

To guarantee a good, watertight seal around the cleaning opening, replace the gasket, washers, bolts and, if necessary, the lid with new parts before reassembly (see the figure). A special set is obtainable from the supplier/manufacturer.

To simplify descaling and cleaning of the tank, the appliance is equipped with two cleaning openings.



IMD-0080 R1

- 1. Remove the cover plate (1) on the outer jacket (see the figure).
- 2. Undo the bolts.
- 3. Remove the cover and the gasket.
- 4. Inspect the tank and remove the loose scale deposits and contamination.



- If the scale cannot be removed by hand, then the appliance will need to be descaled using a descaling agent. Contact the supplier for advice on the preferred descaling agent.
- 6. Close the cleaning opening. To avoid damage to the tank, tighten the bolts that fasten the lid with a torque no greater than 50 Nm. Use suitable tools for this.

15.3.4 Cleaning condensation water discharge

Regular cleaning of the condensation drain and siphon is essential for prevention of blockages.

15.4 Gas-side maintenance

15.4.1 Introduction

The following steps must be carried out on the gas side:

- 1. Clean the burner(s).
- 2. Clean the orifice(s).
- 3. Cleaning the heat exchanger.
- 4. Finalizing maintenance.

15.4.2 Clean the burner(s)

- 1. Detach the burner(s)
- 2. Remove all contamination present on the burner(s).
- 3. Fit the burner(s)

15.4.3 Clean the orifice(s)

- 1. Detach the orifice(s)
- 2. Remove all contamination present in the orifice(s).
- 3. Fit the orifice(s)

15.4.4 Cleaning the heat exchanger

- 1. Detach the burner.
- 2. Clean the combustion chamber of the heat exchanger using a vacuum cleaner and a soft brush.
- 3. Detach the flue gas discharge.
- 4. Clean the end of the heat exchanger using tap water.
- 5. Fit the burner.
- 6. Fit the flue gas discharge.

Note

Check the pressure differential again after cleaning. If the pressure difference is too low following cleaning, please contact the supplier of the appliance.

15.5 Solar collector See installation or users' manual for the solar collector. If this topic is not covered in the manual, then contact the supplier of the collectors.

15.6 Finalizing maintenance

To finalize the maintenance carry out the following steps:

- 1. Fill the appliance (5 "Filling").
- 2. Start the appliance (9 "Starting and running").
- 3. Erase the message SERVICE REQUIRED. Do this by pressing once on RESET then once on ENTER.



16

Warranty (certificate)

| | | warrar certific Compa | ister your warranty, you should complete and return the enclosed ity card after which a warranty certificate will be sent to you. This ate gives the owner of a appliance supplied by A.O. Smith water Products any B.V. of Veldhoven, The Netherlands (hereinafter "A.O. Smith") the the warranty set out below, defining the commitments of A.O. Smith to oner. |
|------|--|---|---|
| 16.1 | General warranty | A.O. S section function | n one year of the original installation date of a water heater supplied by mith, following verification, and at the sole discretion of A.O. Smith, a n or part (with exclusion of the tank) proves to be defective or fails to on correctly due to manufacturing and/or material defects, then A.O. Smith epair or replace this section or part. |
| 16.2 | Tank warranty | A.O. S glass- the wa with an period warrar that st used, | In 3 years of the original installation date of a water heater supplied by smith, following inspection, and at the sole discretion of A.O. Smith, the ined steel tank proves to be leaking due to rust or corrosion occurring on ter side, then A.O. Smith shall offer to replace the defective water heater in entirely new water heater of equivalent size and quality. The warranty given on the replacement water heater shall be equal to the remaining ity period of the original water heater that was supplied. Notwithstanding ated earlier in this article, in the event that unfiltered or softened water is or allowed to stand in the water heater, the warranty shall be reduced to ear from the original installation date. |
| 16.3 | Collector warranty | | arranty and installation and conditions of use, please see the manual ed with the collectors. |
| 16.4 | Conditions for Installation and use | The w | arranty set out in article 1 and 2 will apply solely under the following ons: |
| | | a. | The water heater is installed under strict adherence to A.O. Smith installation instructions for the specific model, and the relevant government and local authority installation and building codes, rules and regulations in force at the time of installation. |
| | | b. | The water heater remains installed at the original site of installation. |
| | | C. | The appliance is exclusively used with drinking water, which at all times can freely circulate (a separately installed heat exchanger is mandatory for heating salt water or corrosive water). |
| | | d. | The tank is safeguarded against harmful scaling and lime buildup by means of periodic maintenance. |
| | | e. | The water temperatures in the heater do not exceed the maximum setting of the thermostats, which form a part of the water heater. |
| | | f. | The water pressure and/or heat load do not exceed the maximum values stated on the water heater rating plate. |
| | | g. | The water heater is installed in a non-corrosive atmosphere or environment. |
| | | h. | The water heater is connected to a protected cold supply arrangement, which is: approved by the relevant authority; with sufficient capacity for this purpose; supplying a pressure no greater than the working pressure stated on the water heater; and where applicable by a likewise approved |

| | 16 | | | | |
|------|------------------------------|--|--|--|--|
| | 16 | Warranty (certificate) | | | |
| | | temperature and pressure relief valve, fitted in accordance with installation instructions of A.O. Smith applying to the specific model of water heater, and further in compliance with the government and local authority installation and building codes, rules and regulations. i. The appliance is at all times fitted with cathodic protection. If sacrificial anodes are used for this, these must be replaced and renewed when, and as soon as, they are 60% or more consumed. When electric anodes are used, it is important to ensure that they continue to work properly. | | | |
| 16.5 | Exclusions | The warranty set out in articles 1 and 2 will not apply in the event of: | | | |
| | | a. damage to the water heater caused by an external factor; | | | |
| | | b. misuse, neglect (including frost damage), modification, incorrect and/or unauthorised use of the water heater and any attempt to repair leaks; | | | |
| | | c. contaminants or other substances having been allowed to enter the tank; | | | |
| | | d. the conductivity of the water being less than 125 μS/cm and/or the hardness (alkaline-earth ions) of the water being less than 1.00 mmol/litre (3.3.3 "Water composition"); | | | |
| | | e. unfiltered, recirculated water flowing through or being stored in the water heater; | | | |
| | | f. any attempts at repair to a defective water heater other than by an approved service engineer. | | | |
| 16.6 | Scope of the warranty | The obligations of A.O. Smith pursuant to the specified warranty do not extend beyond free delivery from the Veldhoven warehouse of the replacement sections, parts or water heater respectively. Shipping, labour, installation and any other costs associated with the replacement will not be accepted by A.O. Smith. | | | |
| 16.7 | Claims | A claim on grounds of the specified warranty must be submitted to the dealer from whom the water heater was purchased, or to another authorised dealer for A.O. Smith water Products Company products. Inspection of the water heater as referred to in articles 1 and 2 shall take place in one of the laboratories of A.O. Smith water Products Company. | | | |
| 16.8 | Obligations of A.O. Smith | A.O. Smith grants no other warranty or guarantee over its water heaters nor the (sections or parts of) water heaters supplied for replacement, other than the warranty expressly set out in this Certificate. | | | |
| | | Under the terms of the supplied warranty, A.O. Smith is not liable for damage to persons or property caused by (sections or parts, or the glass-lined steel tank of) a (replacement) water heater that it has supplied. | | | |



17.1 Introduction


17

This appendix contains:

- Menu structure of the main menu (17.2 "Menu structure")
- Appliance electrical diagram (17.3 "Electrical diagram for the appliance")
- Electrical diagram, solar heating system (17.4 "Electrical diagram, solar heating system")
- Week program card



17.2 Menu structure




HEATING SETPOINT





17.3 Electrical diagram for the appliance

Electrical diagram



1 = brown, 2 = blue, 3 = green, 4 = black, 5 = white, 6 = grey/beige, 7 = red, 8 = dark green, 9 = yellow




Main control components

| A | Controller |
|----|--|
| В | Flame probe |
| С | Hot surface igniter |
| D | Gas control |
| E | Burner earth connection |
| F | Extra ON mode switch |
| G | Continuous pump |
| J | Program-controlled pump |
| К | Extra error signal connection |
| L | Double-pole isolator |
| М | Controller 0/I switch |
| Ν | Display |
| 0 | Fan |
| Р | Temperature sensor (T2 - bottom of tank) |
| Q | Dummy |
| R | Temperature sensor (T1 - top of tank) |
| S | Selection resistor |
| Т | Pressure switch |
| U | Solar heating system controller (BUS-link) |
| | |
| F1 | Fuse |
| F3 | Fuse |

Main controller terminal strip

| 1 | X5 | | |
|----|----|-----------------------------------|--|
| 2 | X6 | BUS-link | |
| 3 | - | n.a. | |
| 4 | - | n.a. | |
| 5 | X3 | External ON/OFF | |
| 6 | X4 | | |
| 7 | Ť | | |
| 8 | L5 | Continuous pump | |
| 9 | N | | |
| 10 | Ν | | |
| 11 | L4 | Program-controlled pump | |
| 12 | ÷ | | |
| 13 | X2 | | |
| 14 | X1 | Extra error signal connection | |
| 15 | ÷ | | |
| 16 | Ν | | |
| 17 | L2 | Isolating transformer (primary) | |
| 18 | ÷ | | |
| 19 | Ν | | |
| 20 | L3 | Isolating transformer (secondary) | |
| 21 | Ŧ | | |
| 22 | Ŧ | | |
| 23 | L1 | Power | |
| 24 | Ν | | |



1 = brown, 2 = blue, 3 = green, 4 = black, 5 = white, 6 = grey/beige, 7 = red, 8 = dark green, 9 = yellow



17.4.1 Solar system electrical diagram legend

Solar heating system control components

| AA | Controller |
|----|--|
| BB | Extra head pump for solar heating system (ON/OFF) |
| CC | Solar heating system pump (modulating) |
| DD | Temperature sensor (S1 - solar collector) |
| EE | Temperature sensor (S2 - tank) |
| FF | Combined Q/T sensor (incl. temperature sensor S4 - solar collector return) |
| GG | Controller (BUS-link) |

| F2 Fuse |
|---------|
|---------|

1 ÷ 2 L1 Power 3 Ν 4 n.a. 5 n.a. _ 6 n.a. _ 7 ÷ 8 L1 Solar heating system pump (ON/OFF) 9 Ν 10 Ť Solar heating system pump (modulating) 11 L2 12 Ν 13 Μ 14 n.a. 15 _ n.a. 16 n.a. 17 _ n.a. 18 _ n.a. 19 _ n.a. 20 _ n.a. J3 1 n.a. 2 n.a. 3 n.a. 4 n.a. J12 1 Power 5V 2 Solar collector return sensor (S4) 3 Earth 4 Flow signal J13 1 n.a. 2 Solar collector sensor (S1) 3 n.a. 4 Solar collector sensor (S1) J14 1 n.a. 2 Tank sensor (S2) 3 n.a. 4 Tank sensor (S2) J15 1 n.a. 2 n.a. 3 n.a. J16 1 **BUS-link** 2 J17 1 n.a. 2 n.a.

Terminal block for solar heating system controller



17.5 Week program card

You can cut the week program card out and keep it near the appliance.

| Pei | riod | DAY | TIME | Tset | Pump |
|-----|------|-----|------|------|-----------|
| 1. | ON | | | °C | ON /OFF |
| 1. | OFF | | | 0 | |
| 2. | ON | | | °C | ON /OFF |
| ۷. | OFF | | | 0 | 011 / 011 |
| 3. | ON | | | °C | ON /OFF |
| 0. | OFF | | | 0 | 011 / 011 |
| 4. | ON | | | °C | ON /OFF |
| 7. | OFF | | | 0 | |
| 5. | ON | | | °C | ON /OFF |
| 5. | OFF | | | 0 | |
| 6. | ON | | | °C | ON /OFF |
| 0. | OFF | | | 0 | |
| 7. | ON | | | °C | ON /OFF |
| 1. | OFF | | | | |
| 8. | ON | | | °C | ON /OFF |
| 0. | OFF | | | 0 | |
| 9. | ON | | | °C | ON /OFF |
| 9. | OFF | | | 0 | |
| 10. | ON | | | °C | ON /OFF |
| 10. | OFF | | | 0 | |
| 11. | ON | | | °C | ON /OFF |
| 11. | OFF | | | 0 | |

Example

| Period | | DAY | TIME | Tset | Pump |
|--------|-----|-----|-------|------|---------|
| 1. | ON | MO | 14:30 | 70°C | ON /OFF |
| | OFF | MO | 16:15 | | |

| Period | | DAY | TIME | Tset | Pump |
|--------|-----|-----|------|------|---------|
| 12. | ON | | | °C | ON /OFF |
| | OFF | | | | |
| 13. | ON | | | °C | ON /OFF |
| | OFF | | | | |
| 14. | ON | | | °C | ON /OFF |
| | OFF | | | | |
| 15. | ON | | | °C | ON /OFF |
| | OFF | | | | |
| 16. | ON | | | °C | ON /OFF |
| 10. | OFF | | | | |
| 17. | ON | | | °C | ON /OFF |
| | OFF | | | | |
| 18. | ON | | | °C | ON /OFF |
| | OFF | | | | |
| 19. | ON | | | °C | ON /OFF |
| | OFF | | | | |
| 20. | ON | | | °C | ON /OFF |
| | OFF | | | | |
| 21. | ON | | | °C | ON /OFF |
| | OFF | | | | |



Index

Α

ambient temperature 20 appliance displaying history 73 displaying selection 74 types 9, 19

В

burner pressure 41

С

claims 98 connect 28 air supply 29 Alarm OUT 38 circulation piping 27, 28 cold water side 27, 28 condensation drainage 28 continuous pump 37 electrical 35 flue gas discharge 29 gas 29 hot water side 27 isolating transformer 37 program-controlled pump 38 Connect Alarm OUT 38 connecting air supply 29 connecting circulation pipe 27, 28 connecting cold water side 27, 28 connecting condensation drainage 28 connecting continuous pump 37 connecting flue gas discharge 29 connecting hot water side 27 connecting isolating transformer 37 connecting the program-controlled pump 38 controls 65 conversion to a different gas category 45

D

display 57 displaying error history 73 draining 53

Ε

electrical connection 35 electrical connector block 36 environmental conditions 19 error 60 extra period 59 operating mode 59 settings 70

F

fan 16 filling 49 flame probe 17 forms of notation 10 frost protection 59

G

gas category, conversion to different 45 gas connection 29 gas control 16 general specifications 3

Н

heat demand 61 heating cycle 14, 61 humidity 20

L

icons (pre)glow 57 explanation 57 flame detection 57 gas control 57 heat demand 57 ignition 61 installation diagram 26 installation engineer 10 isolator 37

L

language setting 71 liability 3

Μ

mains power 37 maintenance burner 96 condensation water discharge 96 finalising 96 gas-side 96 heat exchanger 96 orifice 96 scale 95 to descale 95 water-side 95 mode ERROR 60 EXTRA 59 **HEAT DEMAND 61 IGNITION 61** OFF 59 ON 59 POST-PURGE 61 PRE-GLOW 61 PRE-PURGE 61 **PRESSURE SWITCH 61** PROG 59 **RUNNING 61 SERVICE REQUIRED 60**

Ν

navigation buttons 58

0

off 59

Index

on 59 ON mode 65 on/off switch 57 operating modes EXTRA 59 general 59 OFF 59 ON 59 PROG 59

Ρ

packaging 19 PC connection 58 post-purge 61 power cable 37 pre-glow 61 pre-purge 61 pressure switch 61 prog 59 protection 15 pump 74 push buttons 57

R

running 61

S

scale 95 scrolling 58 service check 10, 91 service engineer 10 service required 60 setting date 71 setting service interval 74 softlite 16 specifications 22 supply pressure 41 symbol installation engineer 10 service engineer 10 user 10

Т

target groups 10 ThermoControl 57 controls 57 ON/OFF switch 57 to descale 95 to shut down electrically isolating 63 longer period 63 short period 63 trademarks 3

U

user 10

W

warranty 97 exclusions 98 general 97 installation and conditions of use 97 scope 98 water composition 20 week program 59