



Instruction Manual

Ex-PMR 500 



Contents		page
1.	Use	2
2.	Safety Advice	2
3.	Error and Excessive Load	2
4.	Safety Regulations	2 - 3
5.	Precautionary Advice	3
6.	Ex-Data	3
7.	Technical Data	3
8.	Operating Instructions	4
8.1	Indicating and operating elements, connections	4 - 5
8.2	Functions	6 - 7
8.3	Power Supply	7
	Accumulator charging	7 - 8
	Accumulator change	8
	Accumulator Care	8
	Safety Advice	8
8.4	Integrated Aerial	9
8.5.	Operating elements and connections	9
	Connections and regulator on the top	9
	Operating elements on the left and right sides	10
	Buttons on the front	10 - 13
8.6.	Indicator/Display	14 - 15
8.7.	Operation	16
	Switching radio equipment on and off	16
	Adjusting Volume	16
	Tuning and memory operation	16 - 17
	Low noise barrier/squelch	17 - 18
	Search	18 - 19
	Light Display	19
	Button locking device	19
	Surveillance function	20 - 22
	Acoustic signaling	22
	Clone function	22 - 23
	Pilot process DCS and CTCSS	23 - 26
	Automatic transmission time boundaries	27
	Transmission time delay	27 - 28
	RESET	28
8.8.	Legality and technology	28 - 29
9.	Repair	29
10.	Cleaning	29
11.	Guarantee and Liability	30
12.	EG Conformity of declaration	31
13.	EG Certificate of conformity	31 - 33

1. Use

The Ex-PMR 500 is, in many European countries, a registration free piece of radio equipment in the range of 446-Mhz for use in hazardous areas (apart from fire damp holes) according to zones 2 and 1 according to IEC/CENELEC.

2. Safety Advice

The following safety regulations contain information and precautionary advice, which must comply with the described conditions to guarantee a safe operation. Before use it is imperative to read these safety regulations and operating instructions! In case of doubt (due to translation and/or printing errors) reference should be made to the original German instruction manual.

3. Error and Excessive Load

In order to avoid interference with the safety of the equipment, the equipment must be taken out of operation and removed immediately from the hazardous area. The unintentional putting back into operation must be prevented. We recommend that the equipment should be returned to the manufacturer for testing.

The safety of the equipment can become damaged if;

- Damages are visible on the casing
- Equipment is exposed to improper loads
- Equipment is stored improperly
- Equipment has suffered damage whilst in transit
- Equipment labeling is illegible
- Functioning errors occur
- The authorized boundaries are exceeded (see 7. and 13.)

4. Safety Regulations

When using the equipment the user is required to follow the usual safety advice to prevent any operating errors on the equipment.

- The equipment must not be opened within the hazardous area
- The accumulator pack must only be changed outside of the hazardous area
- When connecting the accu pack, the user must pay attention to a safe engaging of the six point plug.
- The carrying of additional accu in the hazardous area is not permitted.
- The accu pack may only be charged with the accompanying charging device Lt-500* outside the hazardous area.
- Only those accu belonging to the work AM500 can be used.
- The use of deviant accu is strictly forbidden. They lead to the removal of the protection and present a safety risk.
- The equipment may only be used in the hazardous area with the accompanying leather case.

- Pay attention when using the equipment that the leather case is always completely fastened.
- Only ECOM's permitted equipment may be used.

5. Precautionary Advice

Electromagnetic waves can cause disturbance and can damage your health! Since no defined statements can be made with reference to the interfering immunity of the pacemakers, we recommend that pacemaker carriers refrain from general contact with the radio transceiver. Transmission should not take place in the vicinity of people with pacemakers!


6. Ex-Data

EG Certificate of Conformity no.: TÜV01 ATEX 1713X

EG Marking:  II 2 G EEx ia IIC T4

Authorised for zone 1 equipment group II, gas group C hazardous gasses, humidity or mist, temperature class T4.


7. Technical Data

Surrounding temperature Ta:	-20...+50 deg C
Storage temperature:	-20...+60 deg C (without ex-accu pack)
Power supply:	Ex Accupack "AM500"
Running duration:	7-12 hours (90% standby, 5% TX, 5% RX)
Dimensions:	58 x 145 x 27 mm (B x H x T)
Weight:	about 410g (with accupack)
IP Protective level:	IP22
Frequency range:	446,00625 – 446,09375 MHz
Reception switch:	super double with 1.ZF 21,4 MHz and 2. ZF 455 kHz
Sensitivity:	about 0,20 µV for 12 dB SINAD
Tuning framework:	12,5 kHz
Transmission power:	500 mW EIRP
Secondary wavelength/harmonic:	better than – 60 dB
NF – Initial performance:	max. 0,5 W on 16 Ohm
CE Marking:	 0102
Radio admission:	ICT D801 459L

8. Operating Instructions

Please read thoroughly through these operating instructions to enable you to get to know all functions of your Ex-PMR 500 and to enable you to use it. For your own information and safety read the advice on the following pages!

8.1 Indicator and operating elements, connections



Front

1. MO/Fr/Ch: squelch bridge, changeover frequency/channel indicator, changeover: CTCSS-frequency or DCS code
2. DOWN/TS: Channel and functions, turn downwards, adjust CTCSS sound or DCS code.
3. UP/TO: turn the channel and functions upwards, activate the CTCSS operation ON/OFF, CTCSS or DCS code
4. Lighting ON/OFF, reception tone ON/OFF, CTCSS or DCS code reception receipt ON/OFF
5. MR/MW: memory, storage
6. SC/DW: search ON/OFF, two channel surveillance ON/OFF
7. PS/LOCK: battery-economy switch, button locking device
8. Microphone
9. Loudspeaker
10. Accu area

Top

1. VOL/OFF: high volume regulator, switch ON/OFF
2. SQ: low noise barrier-regulator/squelch
3. Aerial
4. MIC/SPK: connection for external microphone and external loudspeaker: protective cover

Safety Advice:

Here, only connect equipment released by **ECOM!**

Left side, reverse, right side

1. transmission button PTT: transmission and reception switch
2. FUNC: secondary function activated by buttons

8.2. Functions

All 8 channels are very easily changeable.

The Ex-PMR 500 can operate on all 8 channels.

10 storage spaces

So that you always have sufficient regular alternatives for your radio partner.

Search finds active channels

The automatic search (scanner) searches and finds occupied channels where it then stops.

CTCSS and DCS pilot system

For accurate callings of partner systems, two pilot systems are eligible. In the CTCSS procedure there are 47 tones or numbers available, in the DCS process, there are 83 three part numbers.

Acoustic signaling

On request the reception of a suitable pilot can be acoustically (alarm sound) announced.

Surveillance function

This procedure offers the opportunity to observe people. The Ex PMR 500 reacts to sound.

Emergency calling mode

To activate the surveillance function, an emergency signal is sent out by pressing the button PS.

6 varied calling sounds

By pressing the transmission button at the same time as another button, 6 varied calling tones are sent out.

Clone function

With the help of the clone function all of the altered adjustments can be transferred from an ExPMR 500 (master) to another EX PMR 500 (slave) by the user.

Tone scan mode

This function allows the investigation of received signals depending on which tone squelch – frequency they contain. This method only operates in CTCSS operations.

Maximal transmission power

The transmission power is 1 Watt and completely exhausts the 500 Watt radiation licence settings on the integrated aerial.

As a result – according to the surroundings- radio contacts are possible over more kilometers.

Storage of recent adjustments/alterations

The last channel adjustments can be stored by switching off (with a charged FM for crystal clear connections

The transmission occurs in frequency modulations (FM) which with UKW radio, guarantees a lifelike and slighter interference reproduction.

FM for crystal clear connections

The transmission occurs in frequency modulations (FM) which with UKW radio, guarantees a lifelike and slighter interference reproduction.

Monitor – function for weak signals

To receive much weaker signals the low noise barrier must bridge the gap.

Lighting Display

All functions of the EX-PMR 500 can be read on the display – eg, the adjusted radio-channel. The display can be lit up by pressing a button for a better reading when it is half-light or dark.

Button locking device to avoid errors

The buttons lock themselves electronically. Inadvertent errors will be avoided – like, e.g. an unintentional change of channel, when the radio equipment is secured by a belt, and ready for operation.

Double channel surveillance "Dual watch"

Thanks to the double channel surveillance, one can hear from one channel whilst a different channel is being observed automatically – as a result no call can be missed!

Economical dealings with the accu

An accu saving switch (PS) like an eligible automatic switching off, ensures that the accu are maintained longer. If it is time therefore, for an accu charging or a change of accu, it would be signaled on the display.

Sockets for loud speakers and microphone

Apart from the installed loudspeaker and microphone, the sockets allow a combination of an external loudspeaker and an external microphone or an ear piece/microphone connection on the top.

Warning, only that of ECOM's released equipment may be plugged in!

8.3. Power Supply

Before using the ExPMR 500, the accumulator pack must be charged. If the accu pack is almost completely discharged, the accu symbol will flash. The accu must then be charged.

Accu charging

- Switch the device off during charging
- The accu may only be charged with the charging device Lt-500Ex* outside the hazardous area.

- In addition place the radio equipment Ex-PMR 500 in the charging case.
- The red LED on the device indicates that the accu is being charged.
For conservational charging, the green LED shines.

Advice: The charging socket is deactivated on the side of the equipment.

Accu change

Only the Ex accumulator module Type AM 500 may be used.

- Remove the equipment from the hazardous area
- Open the leather case and remove the Ex PMR 500
- Push the lock LOCK to the front of the device
- Place your thumb on the lid of the accu pack and press and remove downwards.
Remove the pack from the accu area and carefully remove the plug.

Warning: Do not pull on the cable!

- Insert a substitute accu and connect.

Pay attention to a safe engagement of the six pin plug!

- Seal the accu area with a lid, afterwards, the accu area must be secured with the lock bolt LOCK.
- Secure the Ex PMR 500 in a leather case and seal completely.

Warning: Do not carry the substitute accu in the hazardous area!

Accu care

- Before use, the accu should be charged completely.
- Ensure that the maximal capacity of the accu is reached according to approximately 6 charging and discharging cycles.
- Since the efficiency of the accu decreases in the course of time, one should occasionally discharge it completely so that the full capacity can be maintained.
- In addition the equipment can be left on until it turns itself off. The accu "AM500" must be completely charged outside of the hazardous area.

Safety advice

- Do not drop the accu pack, do not damage, do not dismantle and do not expose to unauthorized temperatures (-20 to +50 deg C)!
- Only charge the pack as described in the operating instructions!
- Never leave a discharged pack for a long time in unused equipment!
- Do not store the pack for longer than 6 months without discharging and recharging in the meantime!
- Under no circumstances must one throw the accu into an open fire or into domestic rubbish!

8.4. Integrated aerial

The Ex PMR 500 is delivered with a flexible integrated rubber spiral aerial and must only be used with this aerial!

This integrated aerial is insoluble via a SMA socket, when connected with the radio telephone device.

Advice:

- Never send without the integrated aerial!
- The final transmission stage of your radio equipment could become damaged on other ways!
- Never place the radio equipment on the aerial!
- The connection of another aerial is a punishable offence!

8.5 Operating elements and connections

In this section the meaning of the single connections and buttons will be explained in great detail. Please take the positions described on page 4.

Connections and regulator on the top

① VOL/OFF

With the inner part of the double regulator, switch the radio equipment on or off and adjust the volume. The radio equipment is switched off if this regulator is on the left side. To switch on turn to the right (click).

Turn the regulator clockwise in order to raise the volume.

Warning: Do not turn the loudspeaker on too high, especially for operations using headphones!! Ear damage could be consequential!

② SQ

Regulator for low noise barrier. This has no function for pilot procedures CTCSS. On the left side the low noise barrier is switched off. If you turn the regulator clockwise then the level recorder of the low noise barrier is raised. The low noise barrier should be installed so that no murmurs sound from the loudspeaker.

③ 3. Integrated aerial/aerial connections

The integrated aerial is connected to this SMA socket.

④ 4. Sockets MIC and SPK

Under the protective cap the connections for an external microphone MIC and an external loudspeaker SPK can be found. If this is used e.g. as equipment containing speech, the internal microphone or the internal loudspeaker will be switched off. If the sockets are not used, cover them with protective caps so that neither spray water nor dust can enter.

Warning: One may only use equipment that has been released for operation for the ExPMR 500 by ECOM.

Operating elements on the left and right as well as the back

① 1. Transmission and receiving change over, PTT Button

If you press the **PTT** button, it should change from reception to transmission. Let go of the **PTT** button in order to change it back to reception.

Advice; The abbreviation **PTT** stands for "push to talk".

② 2. FUNC button functioning

Some buttons have two functions. Their second function is available as long as though the **FUNC** button is pressed – indicator **F**, top left on the display.

Buttons on the front

① MO/Fr/Ch

This button has many functions:

- By directly pressing this button, the low noise barrier can be bridged as long as though the button **MO** is then released.
- If the button is pressed for longer than one second, statistical information will be received one after the other for the different pilots as well as the search jump-function.

After work the indicator receives **rc off** and **tc off** for switched off CTCSS operations as well as **SCSP off**, because no channel is marked to jump.

For a switched on operation and activated sound squelch, **rc** and **tc** will be indicated as well as the switched on CTCSS sound. If a channel is marked to jump, then indicator **on01** will follow from **SCSP** (for channel one in this case). Afterwards the frequency can be read from the display.

- For the second function, the frequency and channel indicator can be changed on the large display. Hold the **FUNC** button (indicator **F**) and simultaneously press the **MO/Fr/Ch** button.

② (DOWN) ▼ / TS

This button has two functions;

- By pressing this button ▼, the channel or frequency can be switched back in one step. The button has a replay function. If it is pressed for longer, the channels will regularly be switched back downwards.
- When using the second function, the CTCSS pilots or DCS code for reception and transmission or general sounds can be indicated and then altered.

③ (UP) ▲ / TO

This button has two functions;

- By pressing this button ▲ directly, the channel or frequency can be switched upwards in one step. The button has a replay function; if it is pressed for longer, the channels will be switched back up.

- For the second function, the CTCSS operation or DCS operation can be switched on (indicator **TSQ** disappears); Hold the **FUNC** button and simultaneously press the **TO** button (indicator **TSQ**). To turn off, press the **FUNC** button again and simultaneously press the **TO** button (indicator **TSQ** disappears). The button labeled **TO** stands for Tonruf (tone sound operation).

④ **Display-lighting (☼), reception tone and surveillance function**

This button has three functions;

- By directly pressing button ☼, the display lighting can be turned on or off. After a few seconds, the display lighting will automatically disappear in order to save electricity.
- If the ☼ button is held for longer than two seconds, the display lighting will remain switched on, until it is switched back off by pressing the button ☼ once again.
- For the second function, the receipt tone, which acoustically confirms every pressing of the button and every error input, can be switched on or off. The switched on receipt tone is marked by a music symbol in the top right of the display. To switch the reception tone on or off; Hold the **FUNC** button (indicator **F**) and simultaneously press button ☼ /**BP**. The music symbol will appear or disappear. For the switched off reception tone, the battery consumption will be somewhat reduced. The marking **BP** stands for BEEP.
- The third function activates the surveillance function. To turn on the surveillance function; For turned off radio equipment press button ☼/**BP** and simultaneously turn the equipment on by using the VOL regulator on the top. The indicator **bAby-15** will appear.

⑤ **MR/MW**

This button has two functions;

- By directly pressing the button one can switch from a tuning to a memory operation.
- The second function stores selected frequencies in its memory store.

⑥ **Search/Two channel-surveillance SC/DW**

This button has more functions and operates as the automatic surveillance of all frequencies.

- By pressing the **SC/DW** button, the search for all frequencies or memory space is started by closed low noise barriers.

They are searched one after the other. The search stops at a channel where a signal with installed regulator crosses the threshold of the low noise barrier. If the signal is below this level recorder it continues its search after a short pause. During the search, the decimal point flashes between 1-MHz and 100-kHz posi-

tions of the frequency indicator or for the channel indicator between **H** and the contact line. The point also flashes if the search stops at an active channel. If a channel is marked to jump, it will not be recorded in this search. During the search, the search direction can be turned around with the **DOWN ▼** or **UP ▲** buttons.

If the pilot operation CTCSS or DCS code is activated, the search only stops when a signal is received with the CTCSS tone (stored under **rC** or **cc**).

If the search stops at a channel which should be jumped across in wider cycles, the **FUNC** button should be pressed. As a result, the indication delete will appear. All channels are marked in this way. In the attempt to mark the 69 channels, the display reacts with the short indicator **EMPtY**. After switching your radio equipment on and off, these markings will disappear again.

Ending/stopping the search

Simply press the **PTT** button (or **SC** button).

After turning the radio equipment off and back on again, the search is likewise ended.

- The two channel surveillance (dual watch **DW**) has the **SC/DW** button as a second function at its disposal.

- The radio equipment changes automatically every three seconds from actual channels to preferred channels. If activity is there, which lies above the installed SQ regulator threshold of low noise barrier, the radio equipment remains on this preferred channel. Otherwise it will change again for three seconds to the actual work frequency and the surveillance begins again.

Firstly, switch on the channel/frequency that you want to survey in the background (preferred channel).

Then activate the function "Two channel surveillance";

Hold the **FUNC** button and simultaneously press the **SC/DW** button – indication **DW** in the top left.

Turn to the desired work frequency by using the **DOWN ▼** or **UP ▲** button.

The radio equipment changes every three seconds between this work frequency and the preferred channel, even when one receives a station immediately on the working channel. The two channel surveillance stops at the preferred channel as soon as an activity is found with the SQ regulator.

If the activity sinks below this level recorder, the radio equipment will switch to the previous working channel after a short pause. The two channel surveillance will begin again.

- To switch off the two channel surveillance;

Give the **PTT** button a short press – the equipment will change to the preferred channel.

Or press the **F** button and simultaneously press the **SC/DW** button.

In both cases, the indicator **DW** will appear.

⑦ **Accu saving switch/ electronic locking button**



This button has two functions;

- By directly pressing the **PS/LOCK** button, the battery saving switch (Power Saver, **PS**) will be activated – indicator **PS**. If the low noise barrier is closed, the indicator flashes after a short time and signalizes that important parts of the equipment will be turned on and off to save electricity. However, as soon as a signal is received by the **SQ** regulator, the battery saving switch will be disconnected. (indicator **PS** can be seen constantly). It will begin again (**PS** flashes) shortly after the signal falls below the so-called threshold.

Turning off the battery saving switch

- Press the **PS/LOCK** button, indicator **PS** disappears.

For the second function, the electronic button lock is activated. As a result, the alterations of the preferred channels or installation can be avoided.

Press button **F** and simultaneously press the **PS/LOCK** button – indicator  top right of the display). Switching of buttons; Press button **F** and simultaneously press the **PS/LOCK** button – indicator  disappears from top right of display.

⑧ **Microphone**

Behind the front cover, a high quality electric microphone can be found for a clear speech transmission. Hold the device at a distance of some 5-10 cm from the mouth and speak at a normal volume. Speaking too loudly can lead to distortion and as a result to a decline in understanding. Also, the range will not be greatened through loud speech. If an external microphone is put in the **MIC** socket above, the internal microphone will be turned off automatically.

⑨ **Loudspeaker**


Behind the front cover, a high quality loudspeaker can be found for clearly spoken reports. Turn on the volume **VOL** on the top for the best report. Too great a volume can lead to the distortion and also to a deterioration of understanding. Also, the electricity consumption will increase. If an external loudspeaker is put in the **SPK** socket on the top, the internal loudspeaker will turn off automatically.

⑩ **Accu-area**

Here, the necessary accupack AM500 will be used for the voltage supply. Advice, see page 8.

8.6. Indication/Display

Picture of display



1. Transmission indicator TX

Indicates that the radio device locates itself on transmission

2. Dual function activation – indicator F

This indicator can be seen as long as though the function button (left side) has activated the second function of the button. Release the **FUNC** button and the indicator disappears. Only the first function of the button is available.

3. Three channel surveillance – indicator DW

Signalises that the two channel surveillance is activated

4. Pilot procedure TSQ

Indicates that the pilot procedure CTCSS or DCS is activated. The abbreviation stands for tone-squelch.

5. Mechanical signal giver

The mechanical signal giver is deactivated by this device.


6. Accu saving switch PS

If the activated battery saving switch can be seen, the closed low noise barrier flashes.

7. Button locking

Indicates that the buttons are locked to avoid inadvertent alterations. Switch free by pressing FUNC + PS/LOCK

8. Reception tone

If the reception tone is activated, a music symbol  can be seen.

9. Acoustic signaling

If this symbol can be seen, the receiving will be signaled by an acoustic sound.

10. Surveillance function

This status indicator informs about the activated surveillance function.

11. Memory storage indicator CTCSS or DCS number

Here, the memory storage can always be read from the operation, from which the radio equipment is installed. For frequency indication, read the CTCSS or DCS number from here.

12. Channel or frequency indicator 

Here, you can see the alternatively installed channels (**CH01**) or the frequency in MHz (**446.0062**)

13. Indicator for signal power/transmission power – S/RP

For reception you can see the relative signal power of the received stations from this 10 part scale. The more the beam can be seen, the stronger the signal is. Weak signals are marked by one or two beams, strong ones by 8-10 for transmission, in addition to indicator **TX** all 10 beams can be seen.

14. Battery level indicator (under load) – BAT

Even under pressure – when transmitting – one can tell how much capacity the accu still shows. In addition, simply press the monitor button during transmission (top left of front). The symbol **BAT** can be seen in the indication and the indicator scale indicates the remaining capacity of the accu. The shorter the scale, the less the remaining capacity.

15 Battery level indicator 

With this indicator, the capacity level can also be seen through reception in four steps. The more scale seen, the more capacity the accu shows. If the battery symbol flashes, then charge the accu.

16. Suitable call receiving – indicator CALL

As soon as you have received a call with the appropriate CTCSS or DCS tone, you will see the **CALL** indicator on the display.

17. Reception indication BUSY

Signalises that a signal is being received which exceeds the installed threshold with the **SQ** regulator. (low noise barrier opened).

8.7. Operation

Radio equipment switching on/off

The Ex-PMR 500 is switched off and on with the knob VOL/OFF on the top. If this is on the left side and there is no indicator on the display, the radio device is switched off. To switch on, turn the regulator 90 degrees clockwise.;

The equipment switches on with a click and the last installed channel appears on the display e.g. CH 1 for channel 1 or the last tuned in frequency. At the same time, you will hear a greeting melody.

Adjusting volume

Firstly, put the regulator on the top left. Then put the outer regulator on the left – the low noise barrier is turned off. Carefully turn the regulator **VOL/OFF** to the top in a clockwise direction. You will hear a loud noise emerging.

Advice; Adjust the volume so that you can hear the partner station well. The greater the volume is adjusted, the greater the electricity consumption. Take care when adjusting the volume, that no-one is disturbed by the reproduction.

Tuning in and memory work

When tuning in, your radio equipment offers the reception and transmission possibilities of all 8 frequencies. Above that, there is the memory operation in which the operation is limited to a maximal 10 previously stored frequencies. Alternate between tuning in and memory work with the **MR/MW** button. The storage work is characterized by the indicator **MR** on the right of the display. As detailed below, the tuning in and then storage operation is explained.

Tuning in; channel and frequency indicator.

You can only build a connection with radio equipment which is tuned into the same channel or same frequency. Your radio equipment offers either the frequency or channel indicator on the display. For the frequency indicator the exact transmission and reception frequency is shown in MHz e.g. 446.0062 MHz. The channels are labeled continuously from 01 to 08 and change between frequency and channel indication or vice versa;

Hold the **FUNC** button and simultaneously press the **MO/Fr/Ch** button.

Tuning in; channels /frequency adjustments

Adjust the desired channels/frequencies by using the **UP ▲** or **DOWN ▼** buttons.

- Press button **UP ▲** for a higher channel number/frequency adjustment..

- Press the **DOWN ▼** button to find the lower channel/frequency number

Each channel/frequency change is accompanied with a reception tone.

The buttons have a replay function; If you press the **UP ▲** or **DOWN ▼** button for longer, you can continuously switch further.

If you release the button, the **Ex PMR 500** stops at the corresponding channel. A continual channel/frequency change will not receive simultaneously!

Storage-operation: input

Your radio equipment offers 10 storage spaces which are labeled with digits from 01 to 10. In storage work, you can store e.g. all channels exclusive of the alternative channels with possible interference and then observe the search either manually or automatically. No storage space is occupied in the adjustment (**EMPTY**).

Now adjust the desired frequency by using the **DOWN ▼** or **UP ▲** button. If **CTCSS** tones and analysis are stored for this, they can likewise be adjusted.

- Hold the **FUNC** button and simultaneously press the **MR/MW** button.

Select the desired storage space by using the **UP ▲** or **DOWN ▼** buttons (**MR** and storage space number flashes).

- Confirm with the **PTT** button (**MR** and storage space number will stop flashing)

Use the **MR** button to return to tuning.

Storage work: call

The storage spaces are called in succession in the storage operation;

Change tuning with the **MR/MW** button in the working and select the desired storage space by using the **DOWN ▼** or **UP ▲** buttons.

Occupied storage spaces can be seen by the indicator **MR** on the right of the display underneath the relevant installed storage space number.

Low noise barrier/squelch

Your Ex PMR 500 is fitted with an adjustable low noise barrier (squelch), which restrains the tiresome noise to a free channel when waiting. As a result, the battery power is saved. The low noise barrier can be reconciled with the **MO** monitor button on the radio equipment.

The place from where the signal volume widens the low noise barrier can be adjusted with the **SQ** regulator on the top of the equipment. If this is found on the left side, the low noise barrier is switched off. The more the regulator is turned to the right, the stronger the signals must be in order to switch to a repetition.


In order to hear very soft signals, which lay just between low noise and squelch location (see marking), turn the regulator to the left. Then switch to a free channel where only a low noise can be heard.

Then turn the **SQ** regulator clockwise until the noise disappears – ready.

The broken noise barrier can be recognized visually by the indicator **BUSY** on the display. In case the signal volume of the partner station falls under the squelch threshold during a conversation e.g. if you hear your partner move past a "radio shadow", you should press the **MO** button. Thereby, in many cases a "chopped off" reception is avoided. Signals which are in the low noise (see labeling) can no longer be heard when pressing the **MO** button. The working of the low noise

barrier and **MO** is shown in the following drawing:

Diagram of signal volume:



Advice; the **SQ** regulator only functions in the described ways if the received evaluation of the **CTCSS** and **DCS** pilot procedure is switched off (indicator **TSQ** cannot be seen on the display). If it is switched on, the loudspeaker on the equipment reacts when receiving the suitable pilots only! The **MO** button also works with activated pilots and offers the opportunity to listen into the channels.

Transmission/Reception

Press the transmission button on the left side. Your Ex PMR 500 switches from reception to transmission – indicator **TX**

Hold down the transmission button and speak clearly from a distance of about 5-10cms into the microphone.

Loud speech does not improve the report!

Release the transmission button to receive – indicator **TX** disappears.

Advice; Make sure that you have tuned in a free channel before transmission. Otherwise other stations will be distorted and you will not be able to hear your partner station.

Search: Finding occupied channels

The automatic search is used in order to find active channels much quicker when tuning. It scans all 8 channels itself, in the storage operation, all occupied storage spaces. It stops as soon as a signal exceeds the squelch threshold. Your Ex PMR 500 remains at this channel for 5 seconds and then begins anew. In addition the channel indicator flashes. If the signal breaks off before its course of 5 seconds (e.g. if interference is a cause), then it begins its search immediately without further delay. If one wishes to stay on a certain channel for longer, one can simply switch off the search.

- Set the **MR/MW** button to tuning or storing
- Press the **SC/DW** button and release again. You will hear a receiving tone. The search begins at the same time and the changed channel numbers or frequencies can be recognized on the display. The scan direction can be adjusted with the **UP** or **DOWN** buttons. The search stops at the next occupied channel. The strength of signal can be adjusted via squelch location function so that it stops. When stopping, the decimal point flashes between 1-MHz and 100 kHz places of the frequency indicator or for the channel indicator between H and the connection line. The indicator **BUSY** appears later, top left of display. After a good 5 seconds, the search automatically starts again – if the signal is received. If you wish to stop the search at the indicated channel, simply give the SC button a short press. You can also stop the search by pressing the **PTT** button. **Advice;** The search can then only start its memory running if at least two storage spaces are occupied.

Search; jumping channels

If the search repeatedly stops at channels that don't interest you, these channels can be jumped;

- If it stops simply press the **FUNC** button – short indicator delete, before the search continues.

When tuning one can tune up to 7 channels, when memory running, up to 9 channels. Afterwards, the indicator reads **EMPTY**. After the equipment is switched on and off, these markings to jump will disappear again automatically.

Display-lighting on/off (also permanent).

The lighting display can be read better in the dark by switching on the ☀/BP button.

Press the ☀ /BP button and then release. The light will be switched on with reception tone for about three seconds and will then disappear automatically.

Because it is automatic, the battery power will be saved.

If you hold the ☀ button for longer than 2 seconds, the display lighting will remain on until the ☀ button is pressed once more and switched off.

Electronic locking buttons/unlocking

To prevent operational errors, the buttons can be locked electronically. It will also prevent inadvertent adjustments of channels during reception.

Press the **FUNC** button and simultaneously press the **PS/LOCK** button – indicator ☞ appears top right on the display.

Now all buttons are locked (apart from **MO/Fr/Ch** and **PTT**).

To unlock the buttons; Press the **FUNC** button and simultaneously press the **PS/LOCK** button.

Indicator☞ disappears from the top right of the display.

Tone Scan Mode

During tuning, this function is turned off.

It will be prepared as follows;

- If the equipment is turned off;
- Hold the **FUNC** button and turn on the equipment
- Press the **FUNC** button and select the **tSC** menu using the **UP ▼** or **DOWN ▲** buttons Indicator **tSC-oFF**
- Switch the indicator **tSC on** with the **UP** or **DOWN** buttons
- Confirm with the **PTT** button.

Activating the tone scan mode

Hold down the **FUNC** button and press the **TO** button twice. The indicator **TSC** flashes.

Example:

Device A works on channel 2 with a tone frequency of 67.0 Hz (indicator **01**)

The tonescan mode is activated (**TSQ** flashes). Equipment B works on channel 2 with a tone frequency of 254.1 Hz (indicator **47**).

The tone scanning mode is not activated by this device (**TSQ** is always lit).

Transmission can be heard with device A when transmitting from device B. The tone level number (01) and the received tone number (47) flash alternately on the indicator. The following procedure must now be carried out by device A to receive contact with device B.

- Hold the **FUNC** button and press the **TS** button. Indicator **CTCSS?**
- Press the **MO** button. Indicates the tone squelch, frequency and number (254.1/47)
- Confirm using the **PTT** button.

Deactivating tone scanning mode

- Hold down the **FUNC** button and press the **TO** button twice. Indicator **TSQ** disappears.

Surveillance function with emergency call/panic alarm

This function is activated to observe people. In this method, a radio connection between receiving equipment and transmission equipment is built in order to transmit sound. The reception device is also aimed at querying the transmission device in operation. If it indicates that the transmission device no longer answers, an outer range announcement will be indicated as well as producing an alarm tone. The receiving device questions each minute, whether the transmission device is ready for operation again. As soon as a valid answer signal is present on the transmission device, the outer range announcement will be turned off again on the receiving equipment. Switch both radio devices to the same channel and adjust the low noise barrier (so that no noise can be heard).

To select the reception device

- If the radio is turned off;
- To turn the radio on, press the ☀ button – indicated **bAbY-15**.
- Hold down the functioning button and press the **UP ▼** button – indicated **bAbY-M**.
- Confirm by pressing the **PTT** button – indicated **MothEr**.

To select the transmission device

- If the radio equipment is turned off;
- To turn on the radio equipment press the button – indicated **bAbY-15**.
- Select the response time for the baby device by pressing the **UP ▼** or **DOWN ▲** buttons.
- The response time can be adjusted in more steps from 0 to 60 seconds.
- Confirm by pressing the **PTT** button.
- Select the sound sensitivity. (H=sensitive, N=normal, L=insensitive) by pressing the **MR** button several times.
Confirm by pressing the **PTT** button.
Position the radio device as close as possible to the observed object.

Advice: If the transmission equipment is adjusted to “00“, the transmission button **PTT** should be pressed to receive sound.

Operating the receiving device

The reception device sends a query per minute to the transmission device to check if the radio connection still works.

The query can be activated by pressing the **PTT** button. After releasing the **PTT** button, the receiving equipment switches itself to reception (indicated **BUSY**) because the transmission device sends a short response.

If the device is not turned on, adjusted to the wrong channel or outside of the range, an alarm tone can be heard and the indicator;

Out rng appears on the display.

If the transmission equipment picks up sound, an 8 second long alarm tone is released from the receiving device and a heart symbol will flash. After which, the transmission device switches to transmission for the selected time. If the transmission device should be queried manually, the **PTT** button should be pressed for 2 seconds. Afterwards the transmission device switches to transmission for the selected time.

Operating the transmission device

After operating the transmission mode, the micro sensor becomes focused after its course of 20 seconds. The heart symbol flashes on the indicator. The transmission button **PTT** is turned off in the transmission mode. As soon as a sound exceeds the installed level (H,N,L) the transmission device sends an 8 second

long alarm tone. The microphone is activated for the selected transmission time and all sounds during this time are transferred to the receiving equipment. After this transfer, the transmission equipment finds itself in silent mode for 20 seconds. In rest mode, the heart symbol is constantly visible. Afterwards, the heart symbol flashes to show that the equipment is tuned in again.

Emergency call (panic alarm)


In surveillance function, an emergency call can be released by pressing the **PS** button for 2 seconds. The **Ex PMR 500** sends out a 14 second long emergency signal and afterwards changes to sound surveillance mode. The sign **HELP** appears on the display. The user can simply speak into the microphone where a 5 second delay operates to force the radio equipment to transmit and to transfer the softest of sounds by itself.

Afterwards, the **EX PMR 500** remains under surveillance mode. The alarm function is switched off by pressing the **PS** button. Then the surveillance function is activated once more.

Mechanical and acoustic call signaling

The **EX PMR 500** has an acoustic signaling with alarm tones at its disposal. The mechanical signaling is deactivated.


Acoustic signaling

- To activate pilot procedures
- Hold down button **F** and press the **PTT** button – indicator 
- If a call is received, a fivefold alarm tone will sound and the bell symbol will flash (call signal).
- If the **PTT** button is pressed, the acoustic signaling is renewed for activation.

Mechanical signaling

Not available

Varied call tones

When pressing the transmission button and additionally pressing the **DOWN ▼** or **UP ▲**, **MR**, **SC**, **PS** or  buttons, a different tone will be released.

This offers e.g. the differentiation of different partner stations.

Clone function

With the help of the clone function, all altered adjustments can be transferred by a Ex PMR 500 (master) to another Ex PMR 500 slave);

- To turn off both radio devices:
- Connect both Ex PMR 500 by using the connecting cable, in which the 2.5mm plug can be plugged into the external microphone socket and the 3.5mm plug can be plugged into the loudspeaker socket.

- To transfer the master equipment, press the **F** button as well as the **UP ▼** button and hold both buttons. The master equipment is turned on – indicator **Clon**, afterwards **Master**.
- For the receiving equipment Slave, press the **F** button as well as the **DOWN ▼** button and hold both. Switch the slave device on – indicator **Clon** and then **Slave**.
- To transfer data, press the **MO/Fr/Ch** button on the master equipment – indicator **Send**, and after good and after **MAStEr**.
The indicator receive appears on the receiving equipment (slave).
After data taking (about 25 seconds), the indicator; **good** appears on the slave equipment.

Important: Switch both radio devices off and remove the connecting cable.

Advice: Do not, under any circumstances, remove from the connection cable during data transmission.

- If both Ex PMR 500 do not react, check the plug connections and the connecting cable.

Safety Advice: The radio equipment must not be connected via a connection cable within the Ex area!

Pilot procedures CTCSS and DCS

Your radio equipment offers 2 so-called pilot procedures with which you can receive singular partner stations or speak to groups. The used tones and codes correspond closely to a telephone number: Select the correct number and you almost always receive connection to the inner range of your radio equipment. If you programme in the wrong number, the equipment does not react, not even if it finds itself within the radio range. For CTCSS procedures, there are 47 tones or call numbers available, for the DCS procedures there are 83 three digit numbers; tones and numbers are listed in the following table.

The Ex PMR 500 offers the opportunity in pilot procedures for the transmitter and receiver to choose 2 different values. They will be indicated under **rc** and **td**. After work, the radio equipment is adjusted to the same transmission and reception tones (indicated **CC** or **Cd**)

rc CTCSS-receiving tone

tc CTCSS-transmission tone

CC CTCSS-transmitting and receiving tone

rd DCS-receiving tone

td DCS-transmitting tone

Cd DCS=transmitting an receiving tone

Pilot procedures, CTCSS – general reception and transmission tones

- Hold button **F** and simultaneously press the **TS** button – indicator **CTCSS?**
- Press the **MO/Fr/Ch** button (after work, indicator **CC 67.0**)
- With the **UP ▲** or **DOWN ▼** buttons, select the desired pilot frequencies (see table p. 25)
- Press the **PTT** button to confirm selection
The small indicator on the display, bottom right, shows the tone number.
- The pilot procedures can be activated with the **F** and **TO** buttons, but take care that your partner station uses the same pilots (indicator **TSQ**).

Pilot procedures, CTCSS – different receiving and transmitting tones

- Switch your radio to the frequency indicator.
- Hold button **F** and simultaneously press button **TS** (ind. **CTCSS?**)
- Press the **MO/Fr/Ch** button (after work; ind. **CC 67.0**)
- Hold the **F** button and simultaneously press the **UP ▲** button (ind. **Rc 67.0**)
- Select the desired pilot receiving frequency using the **DOWN ▼** or **UP ▲** buttons.
- Hold the **F** button and simultaneously press the **UP ▲** button (ind. **tc 67.0**)
- Select the desired pilot transmitting frequency by using the **UP ▲** or **DOWN ▼** buttons (see table p.25)
- Press the **PTT** button to confirm selection
The tone number will be shown for reception.
- Activate the pilot procedures by using the **TO** button but take care that the receiving tone of the partner stations are programmed to the transmission tone of the equipment and vice versa (ind. **TSQ**).

Pilot-CTCSS frequency tables

CTCSS Tone-Nr.	Frequency Hz	LCD Display	CTCSS Tone-No.	Frequenz Hz	LCD Display
01	67.0	1	26	162.2	26
02	71.9	2	27	167.9	27
03	74.4	3	28	173.8	28
04	77.0	4	29	179.9	29
05	79.7	5	30	186.2	30
06	82.5	6	31	192.8	31
07	85.4	7	32	203.5	32
08	88.5	8	33	210.7	33
09	91.5	9	34	218.1	34
10	94.8	10	35	225.7	35
11	97.4	11	36	233.6	36
12	100.0	12	37	241.8	37
13	103.5	13	38	250.3	38
14	107.2	14	39	69.3	39
15	110.9	15	40	159.8	40
16	114.8	16	41	183.5	41
17	118.8	17	42	189.9	42
18	123.0	18	43	196.6	43
19	127.3	19	44	199.5	44
20	131.8	20	45	206.5	45
21	136.8	21	46	229.1	46
22	141.3	22	47	254.1	47
23	146.2	23			
24	151.4	24			
25	156.7	25			

Selective call process, DCS general receiving and transmitting code

- Switch your radio equipment to the frequency indicator.
- Hold button **F** and simultaneously press button **TS** (ind. **CTCSS?**)
- Press the **UP ▲** or **DOWN ▼** buttons (ind. **dCS?**)
- Press the **MO/Fr/Ch** button (after work; ind. **Cd 023**)
- Select the desired call code using **UP ▲** or **DOWN ▼** buttons
- Press the **PTT** button to confirm selection.
- The small symbol on the display, bottom right, shows the **DCS** number in the following table.
- Activate the selective call process using the **F** and **TO** buttons and take care that the partner stations use the same code (ind. **TSQ**).

Selective call procedure, DCS different receiving and transmitting codes:

- Switch your radio to the frequency symbol.
- Hold button **F** and simultaneously press the **TO** button (ind. **CTCSS?**)
- Press the **DOWN ▼** or **UP ▲** buttons (ind. **DCS?**)
- Press button **MO/Fr/Ch** (after work; ind. **Cd 023**)
- Select the desired selective call reception code using **UP ▲** or **DOWN ▼** buttons.
- Hold button **F** and simultaneously press the **DOWN ▼** button (ind. **td 023**)
- Select the desired selective call transmitting code using the **UP ▲** or **DOWN ▼** buttons.
- Press the **PTT** button to confirm selection.
- Activate the selective process using the **F** and **TO** buttons and take care that the receiving code of your partner station is programmed to the transmission codes of your equipment and vice versa (ind. **TSQ**).

Pilots-DCS-frequency table

DCS Code-No.	LCD Display	DCS Code-No.	LCD Display	DCS Code-No.	LCD Display
023	A1	174	C9	445	F7
025	A2	205	d0	464	F8
026	A3	223	d1	465	F9
031	A4	226	d2	466	G0(60)
032	A5	243	d3	503	G1(61)
043	A6	244	d4	506	G2(62)
047	A7	245	d5	516	G3(63)
051	A8	251	d6	532	G4(64)
054	A9	261	d7	546	G5(65)
065	b0	263	d8	565	G6(66)
071	b1	265	d9	606	G7(67)
072	b2	271	E0	612	G8(68)
073	b3	306	E1	624	G9(69)
074	b4	311	E2	627	H0
114	b5	315	E3	631	H1
115	b6	331	E4	632	H2
116	b7	343	E5	654	H3
125	b8	346	E6	662	H4
131	b9	351	E7	664	H5
132	C0	364	E8	703	H6
134	C1	365	E9	712	H7
143	C2	371	F0	723	H8
152	C3	411	F1	731	H9
155	C4	412	F2	732	I0
156	C5	413	F3	734	I1
162	C6	423	F4	743	I2
165	C7	431	F5	754	I3
172	C8	432	F6		

Automatic transmission time boundary

The transmission time is limited each time to a time between 10 seconds and 990 seconds. After this time, the radio automatically changes to receive – before a short indicator **tot** – time out timer is the automatic transmission turn off. Release the transmission button! If one presses the transmission button again, the radio is switched to transmit and the time surveillance begins again. This function is not just used as a gabbling lock, but also for if the transmission button is inadvertently jammed and the equipment is continually on transmission. In both cases, battery power is saved and is ready to receive again after the given time. When running this function is turned off.

- For a turned off radio, hold the **FUNC** button and simultaneously switch the radio on.
- Hold the **FUNC** button and simultaneously select the menu **tot** using the **UP ▲** or **DOWN ▼** button.
- Release the **FUNC** button!
- Install the desired time in 10 second intervals using the **UP ▲** or **DOWN ▼** button (can be repeated by a longer press or pressing **oFF**)
- Press the **PTT** button slightly to lock.

Transmission locking for an active channel

Since one can only be heard when transmitting to a free channel, the transmission button can be locked when receiving a station (ind. **BUSY**).

This also avoids the inadvertent distortion of other stations.

When running this function is switched off.

- For switched off radio equipment, hold the **FUNC** button and simultaneously switch on the radio.
- Keep the **FUNC** button pressed and simultaneously select the menu **bCLO** using the **UP ▲** or **DOWN ▼** button – indicator **oF** for the turned off transmission locking or on for active transmission locking.
- Release the **FUNC** button and install the desired function on or off using the **UP ▲** or **DOWN ▼** button.
- Press the **PTT** button to lock.

Advice: If the transmission button is pressed by the switched on locking device and occupied channel, the radio will not switch to transmission (ind. **bSY LOC** on the display) and the radio remains on reception. The abbreviation **bCLO** stands for "busy channel lock out " (locking device for an occupied channel).

Transmission time delay

For the correct changing of low noise barrier, a short time delay after releasing the transmission button can be useful. The radio equipment offers the opportunity of a delay of 0.2 seconds or a switching off.

- For turned off radio equipment, hold the **FUNC** button and simultaneously switch the radio on.

- Keep pressing the **FUNC** button and simultaneously search for the menu t-dY using the **UP ▲** or **DOWN ▼** button (ind. **oF** for switched off delay or on for active delays)
- Release the **FUNC** button and adjust to the desired function on or off using the **UP ▲** or **DOWN ▼** button.
- Press the **PTT** button slightly to lock.

Advice: The abbreviation t-dY stands for "transmission delay" = delay of transmission time

Delay of new/starting searches

If the search leads to an active channel it stops and remains there until the signal disappears under the **SQ** levels regulated. Then it begins anew. This is also true for the 2 channel surveillance. This automatic new start can delay between 1 and 30 seconds. A longer delay time can be selected by an unstable connection, which in the meantime is omitted, so that the search does not start again, possibly stops at another channel and consequently, the partner on the other channel does not receive anymore.

- For switched off radio equipment hold the **FUNC** button and simultaneously switch the radio on.
- Keep pressing the **FUNC** button and simultaneously go to the **SdLY** menu using the **UP ▲** or **DOWN ▼** button (ind. of the time delay in secs = 1-30)
- Release the **FUNC** button and adjust to the desired delay time using the **UP ▲** or **DOWN ▼** button.
- The **PTT** button can be locked with a slight press.

Advice: the abbreviation **SdLY** stands for "scan delay" = delay when starting a new search.

RESET – if nothing happens

In case you wish to transfer your radio with all data and adjustments in its delivery condition, you must carry out a RESET. This is also the case if for some reason buttons and indicators no longer react as expected to.

- For switched off equipment, hold the **FUNC** button and the **MO/Fr/Ch** button and simultaneously switch on the equipment. (ind. **INITIAL.**) After a short time, a receiving tone announces the successful RESET and the display returns to its usual indicator.
- Release buttons.

8.8 Legality and technology

Legal regulations and technology

Your Ex PMR 500 is a radio device for the general authorized person – radio in the 70cm band of officially so-called "small power radio". This offers the ideal solution to everyday communication problems for a wider user circle.

No registration – no fees

Your radio equipment is authorized free of registration and charge for the short range radio in many European countries.

General Advice for the use of hand radio telephone devices (short range radio) of non-public mobile land lines. (Nöml)

1. The use of this equipment is registration free and free of charge.
2. The hand radio telephones in the frequency area 446.00625-446.09375 MHz are intended for the transmission of speech. Only radio telephone devices with integrated aeriels may be used.
3. When using the frequency, other telephone communication systems as well as other radio systems may not be distorted.
4. Connections with other radio systems radio networks or public telecommunication networks are not permitted.
5. The radio telephone devices must correspond to the European norm **ETS 300296** according to the authorization regulation **BAPT 222 ZV 100** and must be characterized with a German authorization symbol.
6. The radio telephone devices must fulfill the EMVG regulations and also carry a CE characterization.
7. The listening to and recording of messages, which are intended for others, is not permitted. The content of such messages as well as the details of the message must not be shared with others, even if the reception happens unintentionally.
8. If this general assignment dissolves, the orders of the **RegTP** regulator are to follow the conditions of the radio, which come under this general authorization.

9. Repairs

The conditions of **ELEX V** are valid for repairs. We recommend the repairs take place at the manufacturers since a safe technical examination is required when making repairs.

10. Cleaning

Equipment must only be cleaned with a damp cloth or sponge. Only use water and soapy water to clean. Solutions or scrubbing materials are not suitable for cleaning.

11. Guarantee and maintenance

ECOM grants a guarantee of two years for the functioning and material of this product under normal operating and maintenance conditions. This guarantee does not apply to products that are altered or neglected or used, accidental damage or exposed improperly to unusual operating conditions as well as improper handling.

Guarantee claims can only be granted if the defective equipment is returned. We reserve the right to repairs, new adjustments or exchanges of equipment.

The existing guarantee regulations are the only right to compensation of earnings and are valid exclusively in place of all other contract or legal agreements. ECOM takes no responsibility for special unavoidable consequential damages as well as loss including loss of data, irrelevant of whether or not handling, proper or improper, can be traced back to violation of the guarantee.

In the case of those countries whose restrictions of legal guarantee as well as the exception or restriction of consequential damage is not permitted, it could be that the above mentioned limitations and exceptions are not valid for every purchase. Should any condition of these regulations be found ineffective or not acceptable by a court, the effectiveness or forcibility of any other operation of these regulations will remain untouched.

12. Conformity Declaration

The product fulfills all relevant regulations according to guideline 94/9/EG (ATEX 100a) for equipment and protective systems in hazardous areas. The granted EG conformity declaration confirms that the product corresponds to all relevant health and safety demands.

Leading harmonized norms;

EN 50014:1997 electric method operation for hazardous areas,
general regulations

EN 50020:1994 electrical method of operation for haz. Areas, own safety.

ETS 300296 radio equipment and systems – mobile land radio, technical values and test regulations for radio equipment with inbuilt aerials, which are mainly used for analogue speech transmission.

ETS 300 279 radio equipment and systems, electromagnetic digestibility of radio equipment of non-public land radios and additional fittings


ETS 300 683 radio equipment and systems, electromagnetic digestibility of radio equipment in reduced ranges, which work in frequencies between 9kHz and 25Ghz.

The product has the CE marking to confirm that all relevant guidelines are fulfilled.

ECOM Rolf Nied GmbH

Assamstadt, November 2001

Rolf Nied
Managing Director





Translation

EC TYPE-EXAMINATION CERTIFICATE

- (1)
- (2) Equipment or protective system intended for use in potentially explosive atmospheres - **Directive 94/9/EC**
- (3) EC-Type Examination Certificate Number



TÜV 01 ATEX 1713 X

- (4) Equipment: Explosion-proof radio station type Ex-PMR 500
- (5) Manufacturer: ECOM Rolf Nied GmbH
- (6) Address: D-97959 Assamstadt, Industrie Str.2
- (7) This equipment or protective system and any acceptable variation thereto is specified in the schedule to this certificate and the documents therein referred to.
- (8) The TÜV Hannover/Sachsen-Anhalt e.V., TÜV CERT-Certification Body, notified body number N° 0032 in accordance with Article 9 of the Council Directive of the EC of March 23, 1994 (94/9/EC), certifies that this equipment or protective system has been found to comply with the Essential Health and Safety Requirements relating to the design and construction of equipment and protective systems intended for use in potentially explosive atmospheres given in Annex II to the Directive.

The examination and test results are recorded in the confidential report N° 01 PX 10310.

- (9) Compliance with the Essential Health and Safety Requirements has been assured by compliance with:
EN 50 014: 1997 **EN 50 020: 1994**
- (10) If the sign "X" is placed after the certificate number, it indicates that the equipment or protective system is subject to special conditions for safe use specified in the schedule to this certificate.
- (11) This EC-type examination certificate relates only to the design and construction of the specified equipment or protective system according to Directive 94/9/EC. Further requirements of this Directive apply to the manufacture and placing on the market of this equipment or protective system.
- (12) The marking of the equipment or protective system must include the following:

II 2 G EEx ia IIC T4

TÜV Hannover/Sachsen-Anhalt e.V.
TÜV CERT-Zertifizierungsstelle
Am TÜV 1
D-30519 Hannover

Hanover, 2001-07-25

Head of the
Certification Body



© 2001 TÜV Hannover GmbH

This certificate may only be reproduced without any change, schedule included. Excerpts or changes shall be allowed by the TÜV Hannover/Sachsen-Anhalt e.V.



SCHEDULE

(13)

(14) EC-TYPE EXAMINATION CERTIFICATE N° TÜV 01 ATEX 1713 X

(15) Description of equipment

The explosion-proof radio station type Ex-PMR may be operated in hazardous explosive areas that require equipment of category 2 and 3.

The maximum permissible ambient temperature is 50°C.

HF power ≤ 1 W

Electrical data

Supply (accumulator pack)	8 pc. NiMH accumulator cells; U = 10,4 V (modified accumulator of the manufacturer type AM 500)
------------------------------	--

Head Set connection (jack)	in type of connection "Intrinsic Safety" EEx ia IIC only for the connection of head sets type CMP 123, ML-02 or ML-03
-------------------------------	---

(16) Test documents are listed in the test report No.: 01 PX 10310.

(17) Special conditions for safe use

In the hazardous explosive area the radio station must only be used with the associated leather bag.

It is only allowed to charge and replace the accumulator pack outside of the hazardous area.

The modified accumulator type AM 500 must be used only.

For the charging of the accumulator packs only the following components must be used:

Mains adaptor LT 500F with	recharge terminal LT500*
Mains adaptor LT 500G with	recharge terminal LT500*
Mains adaptor LT 500H with	recharge terminal LT500*
Mains adaptor LT 500I with	recharge terminal LT500*

(18) Essential Health and Safety Requirements

no additional ones



ecom instruments GmbH

Industriestraße 2 • D-97959 Assamstadt

Tel.: +49 (0) 62 94 / 42 24-0 • Fax: +49 (0) 62 94 / 42 24-90

E-Mail: sales@ecom-ex.com • Internet: www.ecom-ex.com