

SMARTGUIDER



User Manual - version ENG 1.1 -

1. Item Checklist

Thank you for purchasing the LVI SmartGuider autoguiding camera! Upon receipt, please check that your package is complete and contains the following items:

1. *Control hand paddle ("Control Paddle").*
2. *SmartGuider camera head with T-2 nosepiece.*
3. *One power supply cable*
4. *One 8-pin RJ cable (Control paddle to camera head)*
5. *One 6-pin RJ cable (Control paddle to mount's ST-4 port)*
6. *User's manual*

2. Quick Start Guide

Thanks to its ease of use, you can hook up your SmartGuider and be ready within minutes. Once your imaging rig has been set up, polar aligned and carefully balanced, here are the main steps to follow:

1. *Make all the necessary connections:*
 - a. *Attach the camera to the guide scope, carefully locking the setscrews.*
 - b. *Connect the Control Paddle to both the camera head and the mount's ST-4 port using the appropriate RJ cables.*
 - c. *Connect the Control Paddle to a 12V DC power supply.*
2. *Turn the LVI SmartGuider on*
3. *Search for a suitable guide star*
4. *Focus with the SmartEye parfocal eyepiece (*)*
5. *Calibrate the mount (*)*
6. *Set the camera's advanced options (*)*
7. *Start autoguiding.*

(*) The steps marked with a star, such as focusing and calibration, could not always be necessary. Please consult Section 4 ("Tips and Tricks") for details.


3. Using the SmartGuider

The SmartGuider's control paddle features a wide pixel matrix screen, whose colors (amber on a black background) and brightness do not compromise the eye's delicate adaptation to darkness.

In this section we describe the content and functionality of all of the available user screens: for a quick and effective overview of their usage, please check out the flowchart available in the download section of LVI's web site. Most screens can have up to three different options on their bottom line, which can be activated by pressing the corresponding button on the control paddle (from left to right).

After connecting the power supply, **turn the camera on by pressing and holding the central button** until the LVI logo shows up; shortly thereafter, the message **"YOUR SMARTGUIDER IS READY"** informs you that the startup phase is complete and the camera has come online.

Press **OK** to go to the **first user screen**:




In the above screen, you can turn off the camera by pressing and holding the left button (**OFF**), while selecting **BASIC** with the central button will take you to the **basic settings screen (MENU BASIC)**:



With **EXIT** you can go back to the previous menu, while **FOCUS** takes you to the next step (guide star focusing). **OPTION** enables to adjust the display and keyboard **backlight** level and the buzzer **volume**.

The two basic settings menus are shown below: **brightness** (left) and **buzzer** volume (right):




You can adjust both the brightness and the buzzer volume with the two triangular keys on the control paddle: four levels are available, from 1 (minimum) to 4 (maximum). **EXIT** takes you back to the basic settings screen.

Now let's have a closer look at the focusing procedure.

Before mounting the camera onto the guide scope's drawtube, you have first to center the brightest star in the field of view which is closest to your imaging target with a wide-field, low-power eyepiece; use then the special SmartEye eyepiece to focus the guide scope and fine tune the position of the star chosen. This eyepiece will deliver a perfectly focused and centered star in the camera's FOV.

Never unscrew the original Baader T-2 nosepiece! This should cause a serious problem with camera focusing when using the dedicated SmartEye eyepiece!

When you press on **FOCUS**, the SmartGuider scans the whole frame to look for the previously selected guide star:



After a while (the actual duration of the search phase is not always the same), the SmartGuider will inform you of the outcome with a simple message: “**STAR FOUND!**” or “**STAR NOT FOUND!**”:




If the guide star was not found (upper right), the SmartGuider goes automatically back to the **MENU BASIC** screen: in this case a brighter star has to be chosen. If the star has been found (upper left), we can proceed to the important **focusing menu**:





In this screen, the X and Y offsets (1 offset unit = 4 sensor pixels) denote the position of the guide star relative to the detector center, and the small cross in the rectangular box (see above) indicates the star's approximate location in a graphical form. If the star happens to be lying too close to the sensor's edges (Bounds: X OFFSET ± 82 , Y OFFSET ± 46), you can try to center it by CAREFULLY nudging the mount along the four directions with the drive keypad at guiding speed. If the star is thrown off the active area, it will be lost (**STAR LOST!** message pops up) and you will have to start over with focusing.

Two focusing aids are available: the **FOCUS STAR** index and the circle on the right-hand side of the screen: they both show the diameter of the star (in pixels) on the detector in numerical and graphical form respectively. Therefore, the lower the number, the better the focus: a properly focused star should be 3 to 8 pixels wide according to the brightness and air turbulence.


Once the guide star has been correctly centered and focused, we can select **CALIBR** to get to the calibration screen: press **OK** to start calibrating the mount.



The calibration process can last up to a few minutes. Upon completion, the new calibration parameters are automatically stored into the camera's non-volatile memory (the **SAVE** icon showed here on the bottom left). In case you want to reuse the parameters from last calibration, just choose **LOAD** from the focusing menu (screen on the lower right). *Please see note on calibration on page 9.*



At this point we come to the **autoguiding screens**:




The SmartGuider is standing by (**Status: READY**, screen on the upper left) before starting the actual autoguiding phase (**Status: GUIDING**, screen on the upper right) by selecting **START**. The two graphs allow real-time monitoring of guiding corrections issued to the mount. You can interrupt the autoguiding process by pressing **STOP** at any time, while **EXIT** will take you back to the basic settings screen.

It might happen the guide star get lost (1 beep per second and **STAR LOST**): this can be due to a number of different reasons, e.g. because the sky has clouded over, the optics have dewed up, or the star has been thrown off the field of view by a wind gust or even because the telescope has been touched. If the star remains invisible for **up to 30 seconds**, the camera will still be able to resume autoguiding; otherwise, the current session is aborted and the execution flow goes back to the **MENU BASIC** screen to search for a new guide star.

From the autoguiding screen, pressing the **ADVAN** menu item brings up the advanced settings screen:



EXIT will take us back to the previous menu, while by pressing **AGGRESS X** we come to the following screens:



With the two triangular arrows (**UP** and **DOWN**), you can adjust the aggressiveness in the X axis (upper left) and in the Y axis (upper right).

The aggressiveness in both axes can range from 1 to 6 (1-2=LOW, 3-4=MILD, 5-6=HIGH) and expresses the degree of reactivity of corrections: a high value will urge the camera to immediately correct for the slightest displacement, whereas a low value will yield a much smoother behavior. See more details at page 10.

4. Tips and Tricks

The SmartGuider is very simple and intuitive to use. However there are some phases, namely selection of a suitable guide star, focusing and calibration, which are critical in maximizing the performance of your SmartGuider and therefore deserve special attention. For further details, please contact LVI.

4.1 Error messages

> **STAR LOST!** – This message may occur in such cases:

1. *Clouds rolling in (during **AUTOGUIDING READY** and **GUIDING**).*
2. *Lenses getting wet (during **AUTOGUIDING READY** and **GUIDING**).*
3. *Too high guiding speed (during **MOVING MOTORS...**).*

Case 1 and 2: the SmartGuider warns the user both with a visual message and an audible signal, one beep per second until the star becomes visible again, for up to 30 seconds. Case 3 and 4: adjust the guiding speed to a lower level through the mount controls or check the Control Paddle to ST-4 mount cable.

> **STAR NOT FOUND!** – This message may occur when the SmartGuider camera cannot find a suitable star after **STAR SEARCH...** command.

> **MOTOR NOT MOVING!** – This message may occur when the SmartGuider camera cannot move mount's motors during calibration. You might want to check the autoguiding cable or the mount's autoguiding port pin assignment.

> **COMMUNICATION ERROR!** – The following message is displayed if the cable connecting the CPU and the camera head gets accidentally disconnected, or in case of problems with the electrical connections or the power supply.

4.2 Choosing a suitable guide scope

Thanks to its sub-pixel guiding capability, the SmartGuider does not call for telescopes with very long focal length or particularly wide aperture. As a rule of thumb, when imaging with digital SLRs or CCDs (pixel size between 5 and 8 microns), the guide scope should have no less than the half of the focal length as that of the main instrument. In any case, it is advisable to use refractors instead

of slow catadioptric reflectors (e.g. Maksutovs with f /ratio of 10 and upwards), since focusing by movable primary mirror can easily lead to exposure trailing even if the tracking performance looks apparently good. Moreover, there are cases where high magnification is not always an advantage, due to lower brightness and increased sensitivity to atmospheric turbulence (*seeing*).

4.3 Guiding Speed adjustment

The SmartGuider automatically adjusts the exposure time according to the guide star's brightness: shorter for bright stars, longer for dim ones. This also affects the frequency of corrections to the mount: bright stars allow for continuous position control, which also ensures that all sorts of tracking errors, including the component resulting from periodic error and atmospheric turbulence, will be easily guided out. Bright stars are best to compensate for the most erratic periodic errors, or with guide scopes having a shorter focal length than that of the main optics. In this case, we advise using a moderate guiding speed (0.15 - 0.5X) with HIGH aggressiveness.

On the other hand, fainter stars imply a less frequent correction of tracking errors: this makes them not as suitable for mounts with an irregular periodic error. However, long exposure times required by faint stars could come in handy to minimize the influence of bad seeing. Here we suggest a very low guiding speed, best if no higher than 0.25X with MILD aggressiveness.

Medium brightness stars (visual magnitude between 3 and 6) generally yield best performance.

4.4 Search for a suitable guide star

The telescope must not be touched during calibration, otherwise the relevant parameters could not be calculated correctly. This also applies to the Control Paddle unit which must not stay in your hand!

If the search for the guide star fails, you can manually move the guide scope looking for a brighter star.

If the camera does not manage to find a sufficiently bright star, a micrometric guide scope support will help. In case an off-axis guider is being used, the pick-off prism and tube can be moved and/or rotated to find a brighter star.

4.5 Mount calibration

The telescope must not be touched during calibration, otherwise the relevant parameters could not be calculated correctly. This also applies to the Control Paddle unit which must not stay in your hand!

Once calibration is over, the parameters are permanently stored into the SmartGuider's internal memory (EEPROM) for later use, provided that the following precautions are taken into account:

1. *Always guide on stars lying in the same side of the sky (with respect to the local meridian) as that where the calibration was last performed;*
2. *NEVER take the camera off the guide scope;*
3. *NEVER rotate the camera in the guide scope focuser.*

In all other cases, the camera must **always** be recalibrated.

It might take a relatively long time for the calibration process to complete, especially with guide scopes of short focal length (under 500 mm).

It is also advisable not to use too dim a star for calibration, otherwise just a few thin clouds or a little dew on the lenses could cause the star to be lost and jeopardize the final result of this important process.

4.6 Autoguiding and aggressiveness

In practice, the *aggressiveness* parameter defines the "reaction threshold" (in terms of sensor pixels), i.e. the value of the offset between two consecutive exposure cycles above which the camera will make a correction.

The lower the aggressiveness, the higher the tracking error allowed and vice-versa.

HIGH values are suitable when using small refractors featuring a focal length 1,5-2 times smaller than the main instrument. **MILD** values are for guide scopes

of about the same focal length and **LOW** ones are best in case of very long guide scopes or off axis guiding (typically SCTs).

During autoguiding, the trend of the X and Y graphs should always be staying as smooth as possible. It is advisable to start off with default values for aggressiveness and guiding speed; then both parameters can be fine tuned to achieve the best possible sync between your SmartGuider and your telescope.

If you notice any significant oscillations about the zero position of one or both graphs (*overcorrection*), the guiding speed should be decreased with the mount drive keypad until the oscillation becomes less important (ideally, almost negligible). Anyway, it must be noted that a *little* oscillation across the zero line is acceptable since both graphs depict the offset between two consecutive exposures with a 2X scale. So, **two pixels on the tracking graph** are actually equivalent to **one single pixel on the detector**. If the oscillation continues even with the guiding speed at its lowest possible value, the aggressiveness has to be decreased.

In case the profile of one or both graphs keeps steadily above or below the zero value (*undercorrection*), the guiding speed has to be slowly increased until the graph profile goes back to hovering around the zero position. If no improvement is seen even with the guiding speed at its highest value, the aggressiveness must be increased.

On nights of bad seeing, and especially with long focal length guide scopes, it could be worthwhile to slightly defocus the guide star, so that the effect of high-frequency twinkling is mitigated somewhat and the camera won't try to "guide the seeing out".

Should the graphs still be showing a small, jerky oscillation in spite of the above precautions, please make sure your equipment is properly balanced in both axes.

It must be stressed that a perfect balance of all the weights, the quality and solidity of all the mechanical supports and adapters is of paramount importance in getting round stars and well-tracked exposures! Sometimes, trailing due to differential flexure can ruin your pictures even with apparently smooth tracking.

5. Technical Specifications

CAMERA

Sensor.....	Mono 1/3" Aptina MT9V032
Sensor resolution.....	752x480, 6- μ m square pixels
Exposure time range.....	Auto, 0.001 - 2 seconds
Housing.....	Aluminium, with polycarbonate lid
Nosepiece.....	Standard 1.25-inch (31.8mm) with filter thread
Connectors.....	8-pin RJ45
Size and weight.....	D=65mm, H=50mm, Weight: 110g

CONTROL PADDLE

Case.....	ABS, black color
Keypad.....	Three membrane keys with amber back-illumination
Display.....	2.5-inch amber graphical LCD, 128x64 pixel resolution
Connectors.....	8 pin RJ45, 12V DC jack, 6 pin RJ12 pin
Size and weight.....	LxHxD: 55x96x28mm, Weight: 220g
Power requirements.....	6~14V DC, 90~200mA

FEATURES

- Automatic guide star search
- Real-time monitoring of guide star position and focus
- Automatic axis calibration with permanent storage of parameters
- Adjustable display backlight and buzzer volume.
- Adjustable dual-axis aggressiveness
- High-precision 2X sub-pixel autoguiding

GUIDE STAR BRIGHTNESS

60-mm guide scope.....	approx. 7.5
80-mm guide scope.....	approx. 8.0
100-mm guide scope.....	approx. 8.5

FIELD WIDTH AND IMAGE SCALE

Scope with $F = 300\text{mm}$	FOV: 51.7x33.0 arcmin.....	scale: 4.13 arcsec/px
Scope with $F = 500\text{mm}$	FOV: 31.0x19.8 arcmin.....	scale: 2.48 arcsec/px
Scope with $F = 800\text{mm}$	FOV: 19.4x12.4 arcmin.....	scale: 1.55 arcsec/px