

# ELECTRIC VARIABLE GRIPPER EVG 55



Dear Customer,

Congratulations on choosing a SCHUNK product. By choosing SCHUNK, you have opted for the highest precision, top quality and best service.

**You are going to increase the process reliability of your production and achieve best machining results – to the customer's complete satisfaction.**

**SCHUNK products are inspiring.**

Our detailed assembly and operation manual will support you.

Do you have further questions? You may contact us at any time – even after purchase. You can reach us directly at the mentioned addresses in the last chapter of these instructions.

Kindest Regards,

Your SCHUNK GmbH & Co. KG  
Precision Workholding Systems  
Bahnhofstr. 106 - 134  
D-74348 Lauffen/ Neckar

Tel. +49-7133-103-2503  
Fax +49-7133-103-2189  
automation@de.schunk.com  
www.schunk.com

Document last updated: 20.11.2008





**Contents**

<b>1</b>	<b>SAFETY</b> .....	<b>4</b>
1.1	EXPLANATION OF SYMBOLS .....	4
1.2	INTENDED USE .....	4
1.3	UNINTENDED USE.....	4
1.4	ENVIRONMENTAL AND OPERATING CONDITIONS.....	4
1.5	SAFETY INFORMATION .....	5
<b>2</b>	<b>WARRANTY</b> .....	<b>8</b>
<b>3</b>	<b>SCOPE OF DELIVERY</b> .....	<b>8</b>
<b>4</b>	<b>TECHNICAL DATA</b> .....	<b>9</b>
4.1	BASIC DATA .....	9
4.2	FACTORY SETTINGS OF ALL MODULES.....	9
4.3	GRIPPING FORCE DIAGRAMS .....	10
<b>5</b>	<b>DESCRIPTION OF THE MODULE</b> .....	<b>11</b>
5.1	DESIGN OF THE MODULE.....	11
5.2	OPERATING PRINCIPLE .....	12
5.3	INFORMATION ON CONTROLLER MCS-06 .....	13
5.3.1	<i>DVD</i> .....	13
5.3.2	<i>Technical data for MCS-06</i> .....	13
5.3.3	<i>Layout of the MCS-06 controller</i> .....	14
<b>6</b>	<b>ASSEMBLY</b> .....	<b>15</b>
6.1	MECHANICAL CONNECTION .....	15
6.2	ASSEMBLY.....	16
6.3	SPECIAL CONNECTION DIMENSIONS.....	17
6.4	MCS-06 ELECTRICAL CONNECTION.....	18
6.4.1	<i>Notes</i> .....	18
6.4.2	<i>Connection principle</i> .....	18
6.4.1	<i>Power supply requirements</i> .....	18
6.4.2	<i>EMV fitting for the connection cable on the gripper</i> .....	19
6.4.3	<b>Connection assignment at X1 terminal</b> .....	22
6.4.4	<b>Connection assignment at X2 terminal</b> .....	23
6.4.5	<i>Connection assignment at X3 terminal</i> .....	24
6.4.6	<i>Connection assignment at X4 terminal</i> .....	25
6.5	CONNECTION ASSIGNMENT OF THE INTERFACES .....	26
6.5.1	<i>CAN connection assignment</i> .....	26
6.5.2	<i>PROFIBUS connection assignment</i> .....	27
6.5.3	<i>RS232 connection assignment</i> .....	28
<b>7</b>	<b>FUNCTION AND HANDLING</b> .....	<b>29</b>
7.1	PRE-POSITIONING .....	30
7.2	EXAMPLE OF AN OPTIMIZED GRIPPING PROCEDURE .....	30
<b>8</b>	<b>SYSTEM INTEGRATION OF THE UNIT</b> .....	<b>31</b>
8.1	NOTES .....	31
8.2	SYSTEM STRUCTURE.....	31
8.3	SCHUNK MOTION-PROTOCOL.....	32
8.4	OVERVIEW OF SELECTED COMMANDS AND MESSAGES.....	33
8.4.1	<i>Commands for the module</i> .....	33
8.4.2	<i>GET_STATE</i> .....	34
8.4.3	<i>Responses (Acknowledge) or spontaneous message from module</i> .....	34
8.4.4	<i>Error messages from the module</i> .....	34
<b>9</b>	<b>EXAMPLES FOR DATA EXCHANGE BETWEEN MASTER CONTROLLER AND GRIPPER</b> .....	<b>35</b>
9.1	APPLICATION EXAMPLE FOR RS232 .....	35
9.1.1	<i>Reference run</i> .....	35



9.1.2	Position run.....	36
9.1.3	Acknowledgment of an error message.....	36
9.2	APPLICATION EXAMPLE FOR CAN .....	37
9.2.1	Reference run.....	37
9.2.2	Position run.....	38
9.2.3	Acknowledgment of an error message.....	38
9.3	APPLICATION EXAMPLE FOR PROFIBUS DP .....	39
9.3.1	Reference run.....	39
9.3.2	Position run.....	40
9.3.3	Acknowledgment of an error message.....	41
<b>10</b>	<b>TROUBLESHOOTING .....</b>	<b>42</b>
<b>11</b>	<b>REPLACEMENT OF THE MODULE .....</b>	<b>43</b>
<b>12</b>	<b>COMPLETELY REMOVING A UNIT FROM THE MACHINE .....</b>	<b>43</b>
<b>13</b>	<b>MAINTENANCE AND CARE.....</b>	<b>44</b>
13.1	CLEANING.....	44
13.1.1	Gripper.....	44
13.1.1	Controller.....	44
13.2	LUBRICATION.....	45
<b>14</b>	<b>DISASSEMBLY OF THE MODULE.....</b>	<b>45</b>
<b>15</b>	<b>CONTACT .....</b>	<b>46</b>

Air-Oil Systems, Inc. www.airoil.com

## 1. Safety

### 1.1. Explanation of symbols



This symbol is displayed wherever there is a possibility of **danger to life and limb**.



This symbol is displayed wherever there is a possibility of **damage to the unit** exists.



This symbol denotes **important information** about the product and its handling.

### 1.2. Intended use

The gripper unit is designed for gripping and temporary secure holding of workpieces or other objects.

The unit is intended for installation / mounting in machines and equipment. The requirements of the applicable directives must be observed and complied with.

The unit may be used only within the range of its technical data. Any other use is deemed improper and unintended use. The manufacturer will not be liable for any damages resulting from improper use.

To use this unit as intended, it is also essential to comply with the manufacturer's specifications regarding commissioning, assembly, operation, maintenance and the ambient conditions. Any other use or use exceeding that specified is an infringement of use for intended purpose. The manufacturer shall not be liable for any damages arising from use other than the intended use.

### 1.3. Unintended use





If the unit is used directly as a guide or bracket for tools such as lasers, drills, milling machines, etc., this is deemed misuse. Likewise, the gripper is not a pressing tool.


This means that all actions that deviate from the functions of gripping, holding and releasing of a gripped object are deemed misuse.


### 1.4. Environmental and operating conditions





- Use the unit only within the application parameters defined in the Technical Catalog. The most recent version applies (according to Chapter 2.3 of the General Terms and Conditions).
- Clean ambient conditions at room temperature are required. If these conditions are not ensured, the maintenance interval will be shorter, depending on the actual utilization.
- The environment must be free of splashing water and vapors, and also of abrasive dust and process dust. This does not apply to units designed especially for unclean environments.



### 1.5. Safety information

1. There are potential risks associated with the unit, for example if:
  - the gripper is improperly used, installed or serviced.
  - the gripper is used other than for the intended purpose.
  - the EC Machine Directive, the accident prevention regulations, the VDE guidelines or the safety and installation instructions are not observed.
  
2. All personnel who are responsible for installation, commissioning and servicing must have read and understood the entire operating manual, in particular the chapter on »Safety«. It is recommended to have this confirmed in writing.
  
3. Installation and dismantling, mounting of the proximity switches, connections and commissioning may be carried out only by authorized personnel.
  
4.  Dangers exist due to units automatically starting up!
  - Do not reach into the open mechanical parts and the area between the gripper fingers.
  - Do not move any parts by hand when the unit is connected to the power supply.
  - Remove the power supply cables for assembly, modification, maintenance and adjustment of the unit.
  
5.  During connection, adjusting, commissioning and testing, measures must be taken to prevent the risk of inadvertent activation of the unit by the fitter / installer or other persons.
  
6.  There is a danger due to falling or ejected objects!
  - Take preventive measures to prevent the falling or ejection of potentially dangerous objects (machined workpieces, tools, chips, debris, waste, etc.).
  
7.  During operation dangers can be caused by the gripper due to:
  - moving or rotating parts
  - or hot surfaces – up to 110°C!

Therefore, suitable protective measures such as protective covers must be provided in accordance with the EC Machine Directive.
  
8.  **The electric gripper is not suitable for use in potentially explosive areas.**

If the gripper is to be used in special applications (e.g. potentially explosive areas), always comply with the required standards and regulations (e.g. EN 50014 and EN 50018).  
The approval for such special areas of application must always be obtained from Schunk in writing.
  
9.  The correct operation of the unit can be disrupted by contamination or running dry!
  - Observe the maintenance and cleaning intervals.
  
10. Ensure compliance with EMC directives when connecting the motor and the controller.

11.  The gripper is equipped with an electric drive.  
Serious injuries and major damages can be prevented by:
- Assignment of only qualified personnel for all work on/with the unit! (Personnel who are familiar with electric drive systems and with the installation, assembly, commissioning and operation of electric drives.)
  - Compliance with the applicable national accident prevention regulations etc. Cp. IEC 364 and CENELEC HD 384 or DIN VDE 0100 and IEC-Report 664 or VDE 0110 and national accident prevention regulations or VBG 4.)
  - During transport and handling, make sure that no components are bent and that no insulation clearances are changed. (Electric grippers contain electrostatically sensitive components.)
  - Establish all electrical connections in accordance with the information in this documentation and the relevant regulations (e.g. wire size, fuses, protective conductors).
12.  Repairs in and on the electric gripper may be carried out only by the manufacturer or an authorized repair center.  
Unauthorized opening and improper handling can result in bodily injury and material damage.
13.  Electronic devices are not fail-safe. The user is personally responsible for ensuring that the drive is in a safe state in the event of a failure.
14. Additional bore holes, threads or attachments not offered by SCHUNK as accessories may be mounted only after obtaining the approval of SCHUNK.
15. In addition, the applicable safety regulations and accident prevention regulations must be observed.
16.  Danger of personal injury or material damage.  
Faulty position parameters can lead to crushing, jamming or breakage of the attachments.
- Always adjust parameter specifications to the unit's operating environment.
  - Only specialist personnel or specially trained staff should carry out settings and enter parameters.

17.  Attachments can fall if the fittings or alterations to the machine or system are faulty. Serious bodily harm possible (e.g. laceration of the head) with fatal consequences.
- Check for compliance with EC Machine Directive item 1.4 for the safety requirements. (Check need for barriers etc.)
  - Only allow specialist personnel or specially trained staff to handle the machine / system.
  - Follow the assembly instructions.
  - Wear appropriate protective clothing (e.g. helmet).
18.  Contamination or dry-running can lead to malfunctions. Fatal head injuries can be caused by workpieces falling or being flung off.
- Comply with the maintenance and cleaning intervals.
  - Restrict access to the module's operating area.
  - Wear appropriate protective equipment (e.g. helmet).



**Note**

The CD-ROM for older versions of the unit includes a different configuration tool (PowerConfig). If you wish to use the older version, please contact your SCHUNK contact person.

Air-Oil Systems, Inc. www.airoil.com

## 2. Warranty

The warranty period is 24 months from the date of delivery when utilized as intended in single-shift operations and in compliance with the specified maintenance and lubrication intervals. Parts that come into contact with the workpiece and wearing parts are not covered by the warranty. See also our General Terms and Conditions in this regard.

The unit is considered defective when the basic gripping function is inoperable.

## 3. Scope of delivery

The scope of delivery includes:

- **Electric Variable Gripper EVG** (without top jaws) in the ordered model.
- Assembly and Operating Manual EVG
- DVD (Included only in the delivery of the optional external Controller MCS-12)
- USBtoRS232- Converter incl. Driver-CD



### Note

For optimum use of your SCHUNK gripper, the SCHUNK controller MCS-06 is recommended. The controller can be ordered separately.

Other accessories for the unit are available in the SCHUNK catalog, at [www.schunk.com](http://www.schunk.com) or from your SCHUNK contact person.



## 4. Technical Data

### 4.1. Basic data

The noise level emitted by the unit is  $\leq 70\text{dB(A)}$



**Note**

Additional technical data can be found in our catalog. The most recent version applies. (according to Terms and Conditions in Chapter 2.3)

The technical dimensions of the gripper can be found in the catalog data.

Designation	EVG 55 stroke 40	EVG 55 stroke 100
Stroke per finger	20 mm	50 mm
Max. gripping force bei $l=8$ Aeff * / 80% ED	24 N	57 N
Min. gripping force	5 N	3 N
Workpiece weight **	0,12 kg	0,28 kg
Opening time	0,6s	1,5s
Closing time	0,6s	1,5s
Deadweight	0,79 kg	1,1 kg
Mass moment of inertia Iy	8,98 kg cm <sup>2</sup>	18,7 kg cm <sup>2</sup>
Repeat accuracy ***	$\pm 0,05$ mm	$\pm 0,05$ mm
Max. finger length	125 mm	125 mm
Power supply for MCS-06	24 VDC	24 VDC
Rated current	3,6 Aeff	3,7 Aeff
Max. current	8 Aeff	8 Aeff
Max. speed	300 mm/s	400 mm/s
Max. acceleration	10000 mm/s <sup>2</sup>	10000 mm/s <sup>2</sup>
Gear reduction	2,37	2,37
Impulse encoder per revolution	2000	2000

**Table 1: Basic data**

\* The gripping force is the arithmetic sum of the individual forces acting on the gripper jaws at a distance of  $P=50$  mm where  $l=8$  Aeff =80% duty ratio and 6 mm pre-positioning and max. speed,  $M_{max} < 3$  seconds

\*\* Values for friction coefficient  $\mu = 0.1$  and safety factor  $v = 2$ . The values can be increased in the case of form-fitting.





\*\*\* Distribution of the end positions with 100 successive strokes.

### 4.2. Factory settings of all modules

DEFAULT values	
Communication	RS232
Data rate	9,600 Baud
Module address	12



### 4.3. Gripping force diagrams



Air-Oil Systems, Inc www.airoil.com

## 5. Description of the module

### 5.1. Design of the module

The gripper base jaws are designed so that many different types of fingers for parallel grippers can be mounted. The gripper is provided with power via a controller. The gripper only has to be connected to the controller.

The module is equipped with a brushless direct current servo motor with bevel gears and toothed belt.

The gripper can also use a magnetic brake that catches immediately in the event of a loss of current.

The unit is designed to grip, hold and release workpieces.

The servo-electric gripper has a software safety system for monitoring the end positions, voltage, current and temperature, with a function for switching off the unit if any of the permitted values are exceeded.

All the parameters, such as speed, stroke, position or motor current, are transferred to an external controller via the corresponding interface (RS 232, CAN Bus, Profibus).

Air-Oil Systems, Inc. www.airoil.com

## 5.2. Operating principle


 For optimum use of your SCHUNK gripper, the SCHUNK controller MCS-06 is recommended. The controller can be ordered separately..

The **actuator** (the brushless DC servo motor with resolver) is controlled by the **external (logic) controller**. This controller receives the required parameters from the master controller.

The motion sequences of the gripper are linear. The **gripper jaws** execute a mechanical motion. Their position is monitored constantly. The required data is transmitted by **sensors** back to the external logic controller.

The gripper is controlled via the **user interface**, where the required data is transmitted via the external logic controller. You can define the following parameters, for example:

- Current  $i$ ;
- Gripper jaw position (=distance between base jaws);
- Speed  $v$ ;
- Acceleration  $a$ .





### 5.3. Information on Controller MCS-06

#### 5.3.1. DVD

The DVD is included in the delivery of the MCS-12.

Content of DVD:

- MC Demo (configuration tool and commissioning tool)
- Operating manual in PDF format
- Software manual SCHUNK MotionControl in PDF format

#### 5.3.2. Technical data for MCS-06

**A controller is needed to operate the gripper.  
We recommend the MCS-06.**

Designation	Value / characteristics
MCS-06 Id number	0 306 030
Interfaces = communication type (data rate)	Profibus DP (auto-detect),
	RS232 (9.600 Baud)
	CAN
Output power supply	24 V DC
Rated current	6 A
Mass	0,45 kg
Control types	Current regulation
	Speed regulation
	Position regulation

**Table 2: Controller MCS-06 Data**

5.3.3. Layout of the MCS-06 controller




Figure 1: Layout of the MCS-06 controller

Type MCS-06	
/1/	Display LED for POW (displays available output power supply)
/2/	Display LED for RDY (displays communication readiness)
/3/	Display LED for ERR (displays occurring errors)
/4/	Terminal strip X1 for motor phases
/5/	Terminal strip X2 for encoder, Hall-effect sensors, resolver, power supply +5 VDC for encoder, resolver and Hall-effect sensors
/6/	Terminal strip X3 for digital inputs and outputs, encoder, power supply +24 VDC for logic
/7/	Terminal strip X4 for power supply +24 VDC for output
/8/	RS232 connection
/9/	CAN connection
/10/	Profibus connection

Table 3: Controller MCS-06 terminals and display elements

## 6. Assembly

### 6.1. Mechanical Connection



**Danger!**

Falling parts as a result of incorrect modifications and attachments to the machine or system! Fatal head injuries (e.g. lacerations) or server bodily injuries (e.g. contusions) are possible!

- Leave power switched off until all mounting work has been completed.
- Have mounting work carried out only by qualified or specially trained personnel.
- Wear proper protective gear (e.g. safety helmet).

Also observe the safety information on page 4.

Mount the unit so that:

- The connection cable does not present a hazard to personnel or the machine. (e.g.: prevent malfunctions by winding up the cable!)
- Personnel and the machine are not exposed to hazards. (e.g.: prevent crushing between machine parts; prevent collisions of machine parts!)

**Requirements for levelness of the bolting surface**


(in relation to the entire bolting surface for the gripper)

< 0.02 mm for an edge length up to 100 mm

< 0.05 mm for an edge length of 100 mm or more

Air-Oil Systems Inc. www.airoil.com

## 6.2. Assembly



**Figure 2: Mechanical connection**

The gripper can be fastened and mounted using the threads at the sides (including centering) available for that purpose. A further option is an adaptation via an L-shaped adapter plate with ISO 9409-1-A50 flange.

Type EVG 55	
/11/	L-shaped adapter plate with flange as per ISO 9409-1-A50
/12/	DIN EN ISO 4762 M4 mounting screws and centering sleeve $\varnothing 6 \times 5.35$

**Table 4: EVG mounting**



### 6.3. Special connection dimensions

The EVG gripper can be screwed on using the lateral M4 mounting threads. Two M3 mounting threads for the top jaws are available on each base jaw.




Figure 3: Connection dimensions

## 6.4. MCS-06 electrical connection

### 6.4.1. Notes

Observe the safety information in the standard "Electrical Equipment for Machines" (DIN EN 60204).

Commissioning is permitted only on the condition of compliance with ECM guidelines (89/336/EEC). For the Low-Voltage Directive 73/23/EEC, the harmonized standards of the series prEN 50178/DIN VDE 0160 apply for the grippers in combination with EN 60439-1/DIN VDE 0660 Part 500 and EN 60146/DIN VDE 0558.


### 6.4.2. Connection principle

The gripper is supplied with power via the controller. The gripper has to be connected to the controller.



#### **Danger of short circuit!**

The printed circuit board of the gripper or of the MCS-12 controller could be destroyed! Due to incorrect connection of the power supply. Note layout of the terminals.



### 6.4.1. Power supply requirements

Power supply (MCS-06)	24 V DC
Power supply for logic controller	24 V DC (bis 36 V DC)
Motor power supply (module)	24 V (+ 10% / - 4%)
Connected load	Number of modules x module nominal current x 1.2
Voltage ripple at output	Residual ripple less than 150 mVSS; Switching peaks less than 240 mVSS

**Table 5: Power supply requirements**

### 6.4.2. EMV fitting for the connection cable on the gripper

The EVG gripper has a connection board to which the signal lines and output lines for the MCS-06 controller can be connected. To remove the cover, loosen the countersunk screws. The connection cable is pulled through the EMV fitting.




Figure 4: Connection board with terminals on the EVG




Figure 5: Terminal pin assignment on the EVG



	Type EVG 55	Pin - assignment	Function	Cable color (for Schunk cables)
/13/	EMV fitting	-	-	
/14/	Cover	-		
/15/	Board with terminals	-		
/16/	Countersunk screws	-		
/17/	X5 terminal strip	1 2 3 4 5 6 7 8 9 10 11 12 13	Brake - Brake + Hall sensor 1 Hall sensor 2 Hall sensor 3 Encoder track A Encoder track B Encoder track C Encoder track A\ Encoder track B\ Encoder track C GND +5V	Brown (0.34 mm <sup>2</sup> ) White (0.34 mm <sup>2</sup> ) Yellow Pink Gray Black White Copper Purple Brown Orange Blue Red
/18/	X6 terminal strip	1 2	Shielding Motor phase W	Gray Black
/19/	X7 terminal strip	1 2	Shielding Motor phase W	Gray Black
/20/	X8 connector	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20	- - Encoder track C\ Encoder track B\ Encoder track A\ Encoder track C Encoder track B Encoder track A GND +5V Hall sensor 3 Hall sensor 2 Hall sensor 1 GND +5V - - - - -	
/21/	X9 terminal strip	1 2	Motor phase U Motor phase V	Red White
/22/	X10 terminal strip	1 2	Motor phase U Motor phase V	Red White
/23/	X23 connector	1 2	Brake + Brake -	

**Table 6: Terminal pin assignment**


**Caution**  
Incorrect wire insulation can lead to a short-circuit in the board.  
Can lead to malfunctions or destruction of the board.

- All electrical connection work to be carried out by appropriate specialist personnel only.
- Do not remove too much insulation from the wire strands.
- Do not connect the wires incorrectly.

**Caution**  
Overtightening the fastening screws can lead to the board breaking.  
Can lead to malfunctions or destruction of the board.

- Tighten the screws only slightly – the board is merely fixed in place.

- Lead the connection cable through the EMV fitting.
- Insulate approx. 90 mm of the MCS-06's connecting cable outer cover. Insulate approx. 5 mm of the individual wires in a manner suitable for the spring clamp connectors.
- The external cable shielding is connected to the EMV fitting. To do this, pull back the external shielding over the cable's outer cover.
- Fix the shielding in position using suitable shrink tubing, so that the shielding remains visible at the end of the cover.



**Figure 6 EMC fitting**

### 6.4.3. Connection assignment at X1 terminal



**Note**

The cable color refers to the pre-installed SCHUNK connection cable. You require the strands with a diameter of 1,0 mm<sup>2</sup> here.




Figure 7: X1 terminal

Pin	Function	Cable color
1	Motor phase U	Red
2	Motor phase V	White
3	Motor phase W	Black
4	Shielding	

Table 7: X1 terminal pin assignment

### 6.4.4. Connection assignment at X2 terminal



**Note**

The cable color refers to the pre-installed SCHUNK connection cable. You require the strands with a diameter of 0.15 mm<sup>2</sup> here.




Figure 8: X2 terminal

Pin	Function	Cable color (diff. encoder)
1	Resolver signal reference +	-
2	Resolver signal COSINE+	-
3	Resolver signal COSINE-	-
4	Resolver signal SINE+	-
5	Resolver signal SINE-	-
6	Encoder track A (or Adiff)	Black
7	Encoder track B (or Bdiff)	White
8	Encoder track C (or Adiff)	Purple
9	+5V for encoder and Hall sensors	Red
10	GND for encoder and Hall sensors	Blue
11	Hall sensor 1	Yellow
12	Hall sensor 2	Pink
13	Hall sensor 3	Gray
14	Brake -	Brown (0.34 mm <sup>2</sup> )
15	Brake +	White (0.34 mm <sup>2</sup> )
16	Resolver signal reference -	-

Table 8: X2 terminal pin assignment

6.4.5. Connection assignment at X3 terminal



**Note**

The cable color refers to the pre-installed SCHUNK connection cable. You require the strands with a diameter of 0.15 mm<sup>2</sup> here.




Figure 9: X3 terminal

Pin	Function	Cable color (diff. encoder)
1	Encoder track Bdiff	Brown
2	Encoder track Cdiff	Copper
3	Encoder track Cdiff	Orange
4	Digital output 1	-
5	Digital output 2	-
6	Digital output 3	-
7	Digital output 4	-
8	+24V logic supply	-
9	GND logic supply	-
10	Digital input 4	-
11	Digital input 3	-
12	Digital input 2	-
13	Digital input 1	-
14	Default	-

Table 9: X3 terminal pin assignment



6.4.6. Connection assignment at X4 terminal




Figure 10: X4 terminal

Pin	Function
1	+24V output supply
2	GND output supply
3	PE protective conductor

Table 10: X4 terminal pin assignment

Air-Oil Systems, Inc. www.airoil.com

## 6.5. Connection assignment of the interfaces

### 6.5.1. CAN connection assignment




Figure 11: CAN interface

Pin	Function	Description
1	-	-
2	CAN_L	CAN BUS signal (dominant low)
3	-	-
4	-	-
5	CAN_SHLD	Optional shielding
6	-	-
7	CAN_H	CAN BUS signal (dominant high)
8	-	-
9	-	-

Table 11: CAN interface pin assignment

6.5.2. PROFIBUS connection assignment





Figure 12: PROFIBUS interface

Pin	Function	Description
1		
2		
3	RxD/TxD-P	Received/transmitted data plus line (B line)
4		
5	GND	Reference potential for 5V supply voltage
6	+5 V	Supply voltage +5 V DC
7		
8	RxD/TxD-N	Received/transmitted data N line (A line)
9		

Table 12: PROFIBUS interface pin assignment

6.5.3. RS232 connection assignment




Figure 13: RS232 interface

Pin	Function	Description
1		
2	TxD	Transmitted data
3	RxD	Received data
4		
5	GND	Reference potential for data lines
6		
7		
8		
9		

Table 13: RS232 interface pin assignment

## 7. Function and handling



### Important!

Gripper base jaws can become blocked by accumulations on the toothed belt. Sustained short stroke travel can damage the gripper.

- Travel the entire stroke every 1000 cycles (or at least once a day).



### Attention!

After every start up, the Controller MCS06 has to search his commutation-offset. Therefore the gripper has to move an entire stroke.

The servo axis of the gripper normally moves as if hitting a mechanical stop. Therefore, the following points must be observed when handling the unit:

- The maximum gripper force refers to the load on the guides. Therefore, this force must not be built up until shortly before the workpiece.
- When the gripper travels in current mode the fingers accelerate. If gripping takes place at this point the fingers will be subject to the following forces:
  - a) increased gripping force proportional to the current
  - b) increased pulse proportional to the speed on impact; the impact speed should be kept as low as possible. This can be achieved by pre-positioning.
- If the gripper moves to the stop (even when gripping!) in positioning mode it will cause mechanical overload. This will reduce the gripper's service life.
- Use the magnetic brake (if installed) only when the fingers are idle.
- Check the lubrication of the guides at regular intervals; especially constant, very small strokes can lead to dry-running.



### Note

If the gripper travels in live mode, the gripper fingers accelerate.

The gripping forces acts on the gripper fingers when the gripping procedure starts.

This force is proportional to the current. In other words, the larger the current, the larger the gripping force.

The maximum permissible gripping force is achieved with the maximum permissible current (see technical data, page 9)

### 7.1. Pre-positioning

When gripping the workpiece, it is important to ensure that pre-positioning is carried out first up to approx. 1 to 5 mm before making contact with the workpiece. After this has been done (and not before), switch to live mode and build up force to grip the workpiece.




Figure 14: Pre-positioning

### 7.2. Example of an optimized gripping procedure

Position the gripper fingers slightly in front of the workpiece to be gripped. (See figure "Handling the unit" below.)

Switch to live mode and slowly increase the supply of current until you reach the desired gripping force. Once the current has reached the desired level, retaining it at that level will hold the workpiece.




Figure 15: Handling the unit

## 8. System integration of the Unit

### 8.1. Notes



**Danger!**

Personal injury and material damage possible!  
 Incorrect position parameters can result in crushing, pinching, or breakage of attachments.

- Always adapt parameters to the impact environment of the module.
- Have adjustments and parameter input carried out only by qualified or specially trained personnel.




**Danger!**

Severe head injuries can result from falling or flying workpieces!  
 Caused by incorrect programming.

- Have programming carried out only by qualified personnel.
- Persons within the sphere of action of the unit must wear suitable protective gear (e.g. safety helmet).

### 8.2. System structure



**Figure 16 Representation of the system structure**




- The number of connected modules depends on the bus that is used.
- You can assign up to 255 IDs.

### Data format

The data is transmitted in INTEL format (Little Endian Format).

### 8.3. SCHUNK Motion-Protocol


 **Note**  
 There is a separate, very detailed operating manual and a corresponding configuration and demonstration software (MC Demo) for the SCHUNK Motion Protocol. The following description is intended only for the initial commissioning with basic standard applications.

The SCHUNK Motion Protocol defines the format of the data to be exchanged between a SCHUNK module (gripper, rotary unit, etc.) and the higher-level controller (PC, PLC). The data exchange itself can take place by means of various bus systems. Currently, RS-232, Profibus-DP and CAN-Bus are supported


The actual payload data of a message in the Motion Protocol is not dependent on the specific bus system used. To send a message in the Motion Protocol, it must be "packed" in a message of the respective bus system. Accordingly, when a message is received from the bus system, the module message contained in the message has to be "unpacked".

The data frame of the Motion Protocol always includes the following elements:

- **D-Len** (1 byte; specified the number of following bytes)
- **Cmd** (1 byte; command code)
- **Data** (required data or parameters; length depends on command)




**Figure 12: Data frame for the Motion-Protocol**


 The details for each of the individual bus types can be found in the document "„MotionControl" (see DVD).



## 8.4. Overview of selected commands and messages

### 8.4.1. Commands for the module


 Further information can be found in the document "MotionControl".

 All values are given here in hexadecimal form.

Each of these commands is confirmed by a response from the module.

Designation	Command	Explanation
CMD_STOP	0x91	Command for stopping the module
CMD_REFERENCE	0x92	Conduct reference run
GET_STATE	0x95	State query to module (Chapter 8.4.2 see page 34)
MOVE_POS	0xB0	Conduct position run
MOVE_CUR	0xB3	Conduct current run
MOVE_VEL	0xB5	Conduct speed run

**Table 14 Commands**

 For the move command MOVE\_POS, there is an optional parameter:  
 - Current intensity (CUR)  
 If you do not specify this parameter, it will be taken from the last parameter used or the last movement command.

#### Special commands:

Designation	Command	Explanation
CMD_ACK	0x8B	Acknowledgment of error message
CMD_EMERGENCY_STOP	0x90	"FAST STOP"


**Table 15 Special commands**

### 8.4.2. GET\_STATE

The following parameters can be set for the command GET\_STATE:

- [mode]
- [PollTime]

This command can be used to get the parameters for position, speed and current, in addition to the status byte. The PollTime parameter is used to define how often, in [ms] the current status should be transmitted from the module.



**Applies only to Profibus:**  
The status byte is always sent with each response.

#### Sample values for the query of the parameter [mode]:

Value	Query after ...
0x01	... Position
0x02	... Speed
0x04	... Current
0x07	... Position, speed and current

### 8.4.3. Responses (Acknowledge) or spontaneous message from module

The module can automatically send a so called spontaneous message.

- For example, after a position run from the module to the master, the following can be sent:  
"Position XY reached" (CMD\_POS\_REACHED).

This also applies to error messages from the module to the master that do not directly follow a command.

- For example, a response of 1 (= no spontaneous message) follows a command to positively confirm it. A response of 2 (= spontaneous message) can follow, in which the module reports that it has not yet been referenced.  
(CMD\_INFO with the parameter INFO\_NOT\_REFERENCED)

These will be sent by the module only if the respective bus allows it.


Designation	Command	Explanation
CMD_POS_REACHED	0x94	Module confirms: "Position reached"
CMD_INFO	0x8A	Module reports an event and remains active.

**Table 16 Acknowledge from module**

### 8.4.4. Error messages from the module

Designation	Command	Explanation
CMD_ERROR	0x88	Error message
CMD_WARNING	0x89	Warning message

**Table 17 Possible error messages**




Further information can be found in the document "MotionControl".

## 9. Examples for data exchange between master controller and gripper


### 9.1. Application example for RS232

The SCHUNK Protocol is explained briefly on page 32.

 **Notes**

- The examples refer to a module with **module address 1**.
- Some time can pass between response 1 and response 2. Response 2 does not always have to appear. This depends on the command.

Further information can be found in the document "MotionControl".

 **Note**

If the included USBtoRS232-Converter is used, a driver has to be installed. The driver and a installation manual can be found on the enclosed Driver-CD.

#### 9.1.1. Referece run

##### Command from master to module

("Conduct reference run")

ID	D-Len	Cmd	Data	CRC16
0x05	0x01	0x01	0x92	0xD1 0x31

##### Response 1 from module to master

("Reference run - command received." - Module is moving.)

ID	D-Len	Cmd	Data	CRC16
0x07	0x01	0x03	0x92	0x4F 0x4B

##### Time-delayed-response 2 from module to master

(„Stoped at position position 5.792[mm].“)

ID	D-Len	Cmd	Data	CRC16
0x07	0x01	0x05	0x94	0x21 0x56 0xB9 0x40



9.1.2. Position run

**Command from master to module**

(„Move to position 10[mm]“)

ID		D-Len	Cmd	Data	CRC16	
0x05	0x01	0x05	0xB0	0x00 0x00 0x20 0x41	0x48	0x80

**Response 1 from module to master**

(„Will reach position in 3.358[s].“ - Movement being started.)

ID		D-Len	Cmd	Data	CRC16	
0x07	0x01	0x05	0xB0	0xEE 0xEE 0x56 0x40	0x7B	0xE4

**Time delays response 2 from module to master**

(„Have reached position 9,9969.“)

ID		D-Len	Cmd	Data	CRC16	
0x07	0x01	0x05	0x94	0xB6 0xF3 0x1F 0x41	0x7E	0xD5

9.1.3. Acknowledgment of an error message

**Error messages from module to master**

(“Power supply to motor switched off.“ - Switch power supply back on.) This message is sent every 15[s] until error is eliminated.

ID		D-Len	Cmd	Data	CRC16	
0x07	0x01	0x02	0x88	0x74	0x82	0x1B

**Command from master to module**

(“Acknowledge error message“ - CMD ACK)

ID		D-Len	Cmd	Data	CRC16	
0x05	0x01	0x01	0x8B		0x10	0xFB

**Response 1 from module to master**

(“Command acknowledge error message received.“)

ID		D-Len	Cmd	Data	CRC16	
0x07	0x01	0x03	0x8B	0x4F 0x4B	0x38	0x1E

**Response 2 info message from module to master**


(“No further errors exist.“)

ID		D-Len	Cmd	Data	CRC16	
0x07	0x01	0x03	0x8A	0x08 0x00	0x1A	0x19


Now a command has to be sent from the master to the module requesting the latter to move in the opposite direction.

## 9.2. Application example for CAN

The SCHUNK Protocol is explained briefly on page 32.

 **Note**

- The examples refer to a module with **module address 1**.
- Some time can pass between response 1 and response 2. Response 2 does not always have to appear. This depends on the command.

 Further information can be found in the document "MotionControl".

### 9.2.1. Reference run

#### Command from master to module

("Conduct reference run")

ID	DLC	D-Len	Cmd	Data
0x501	0x02	0x01	0x92	

#### Response 1 from module to master

("Reference run - command received. Module is moving.")

ID	DLC	D-Len	Cmd	Data
0x701	0x04	0x03	0x92	0x4F 0x4B

#### Time-delayed response 2 from module to master

(after a while: "Stopped at position 5.792[mm].")

ID	DLC	D-Len	Cmd	Data
0x701	0x06	0x05	0x93	0x21 0x56 0xB9 0x40



### 9.2.2. Position run

#### Command from master to module

("Moving to position 10[mm].")

ID	DLC	D-Len	Cmd	Data
0x501	0x06	0x05	0xB0	0x00 0x00 0x20 0x41

#### Response 1 from module to master

("Will reach position in 3.358[s]." Movement being started.)

ID	DLC	D-Len	Cmd	Data
0x701	0x06	0x05	0xB0	0xEE 0xEE 0x56 0x40

#### Time-delayed response 2 from module to master

("Have reached position 9.9969")

ID	DLC	D-Len	Cmd	Data
0x701	0x06	0x05	0x94	0xB6

### 9.2.3. Acknowledgment of an error message

#### Error message from module to master

("Power supply to motor switched off." - Switch power supply back on.) This message is sent every 15[s] until error is eliminated.

ID	DLC	D-Len	Cmd	Data
0x301	0x03	0x02	0x88	0x74

#### Command from master to module

("Acknowledge error message" - CMD ACK)

ID	DLC	D-Len	Cmd	Data
0x501	0x02	0x01	0x8B	

#### Response 1 from module to master

("Command acknowledge error message received.")

ID	DLC	D-Len	Cmd	Data
0x701	0x04	0x03	0x8B	0x4F 0x4B

#### Response 2 info message from module to master

("No further errors exist.")

ID	DLC	D-Len	Cmd	Data
0x701	0x04	0x03	0x8A	0x08 0x00

Now a command has to be sent from the master to the module requesting the latter to move in the opposite direction.

### 9.3. Application example for Profibus DP



**Notes**

- Some time can pass between response 1 and response 2. Response 2 does not necessarily have to appear, since the message is a spontaneous message.
- The SCHUNK Motion Protocol is explained briefly on page page 32.
- 0x?? represents any data.



Further information can be found in the document "MotionControl".

#### 9.3.1. Reference run

**Command from master to module**

("Conduct reference run")

D-Len	Cmd	Data	State (Byte 14)	MsgCount (Byte 15)
0x01	0x92	0x?? 0x?? 0x?? 0x?? 0x??		

**Response 1 from module to master**

("Reference run - command received." Module is moving.)

The "MsgCount" is being increased by one.

D-Len	Cmd	Data	State (Byte 14)	MsgCount (Byte 15)
0x03	0x92	0x4F 0x4B 0x?? 0x?? 0x?? 0x?? 0x?? 0x??	0x00	0x01

**Time-delayed response 2 from module to master**

(after a while: "Stopped at position 5.792[mm].")

D-Len	Cmd	Data	State (Byte 14)	MsgCount (Byte 15)
0x05	0x93	0x21 0x56 0xB9 0x40	0x61	0x01



The byte **MsgCount** is increased consecutively by 1 for each response to a previous command, except for "spontaneous messages" - in this case, the MsgCount is taken from the previous response.



9.3.2. Position run

**Command from master to module**

("Moving to position 10[mm].")

D-Len	Cmd	Data	State (Byte 14)	MsgCount (Byte 15)
0x05	0xB0	0x00 0x00 0x20 0x41 0x?? 0x??		

**Response 1 from module to master**

("Will reach position in 3.358[s]." Movement being started.)

The "MsgCount" is being increased by one.

D-Len	Cmd	Data	State (Byte 14)	MsgCount (Byte 15)
0x05	0xB0	0xEE 0xEE 0x56 0x40 0x?? 0x?? 0x?? 0x?? 0x?? 0x?? 0x?? 0x??	0x01	0x02

**Time-delayed response 2 from module to master**

("Have reached position 9.9969")

D-Len	Cmd	Data	State (Byte 14)	MsgCount (Byte 15)
0x05	0x94	0xB6 0xF3 0x1F 0x41 0x?? 0x?? 0x?? 0x?? 0x?? 0x?? 0x?? 0x??	0x61	0x02

Air-Oil Systems, Inc. www.airoil.com



### 9.3.3. Acknowledgment of an error message

#### Error message from module to master

("Power supply to motor switched off.")

- Switch power supply back on.) Extended diagnosis is supported.

D-Len	Cmd	Data	State (Byte 14)	MsgCount (Byte 15)
0x02	0x88	0x74 0x?? 0x?? 0x?? 0x?? 0x?? 0x?? 0x?? 0x??	0x30	0x02

#### Command from master to module

("Acknowledge error message" - CMD ACK)

D-Len	Cmd	Data	State (Byte 14)	MsgCount (Byte 15)
0x01	0x8B	0x?? 0x?? 0x?? 0x?? 0x?? 0x?? 0x?? 0x??		

#### Response 1 from module to master

("Command acknowledge error message received.") The "MsgCount" is being increased by one.

D-Len	Cmd	Data	State (Byte 14)	MsgCount (Byte 15)
0x03	0x8B	0x4F 0x4B 0x?? 0x?? 0x?? 0x?? 0x?? 0x?? 0x?? 0x?? 0x?? 0x??	0x20	0x03

#### Response 2 info message from module to master

("No further errors exist.")

D-Len	Cmd	Data	State (Byte 14)	MsgCount (Byte 15)
0x03	0x8A	0X08 0x00 0x?? 0x?? 0x?? 0x?? 0x?? 0x?? 0x?? 0x?? 0x?? 0x??	0x20	0x03

Now a command has to be sent from the master to the module requesting the latter to move in the opposite direction.



The byte **MsgCount** is increased consecutively by 1 for each response to a previous command, except for "spontaneous messages" - in this case, the MsgCount is taken from the previous response.



## 10. Troubleshooting

Event	Possible cause	Possible solution
<b>No LED lights up on controller</b>	(a) There is no voltage (b) Master (controller) at bus is not active	(a) Check power supply and logic voltage supply at controller (b) Check master, activate
<b>"POW" LED (green) on controller does not light up</b>	There is no voltage	Check power supply at controller
<b>"RDY" LED (green) on controller does not blink</b>	(a) Faulty connection (b) No voltage at logic	(a) Check connection (starting with Chapter 6.4 page 18) (b) Check power supply of logic at controller
<b>"ERR" LED (red) at controller blinks or lights up continuously</b>	(a) Undervoltage at "POW" (b) There is an error = Module reports CMD_ERROR	(a) Check power supply at controller (b) See software manual "MotionControl.pdf".
<b>Module does not respond / does not move</b>	(a) Encoder is connected incorrectly (b) Motor is connected incorrectly	(a) Check connection at gripper and at controller (starting with Chapter 6.4 page 18) (b) Check connection of motor at controller
<b>Module stops abruptly</b> (This can be reported by the module with the parameter <b>ERROR_CABLE_BREAK</b> , if the GSD file included in the delivery has been integrated.)	Malfunctions at the bus cable (connection to module was interrupted)	- Check bus cable for signs of damage, replace the cable if necessary. - See software manual "MotionControl.pdf".
<b>Motor does not turn</b>	Defective motor lines	Check the armature resistance: - Motor lines to each other: R = 0,4 ... 2,0 Ohm (depending on the cable length)
<b>The gripper does not execute the full stroke</b>	- Dirt between the cover plate - Dirt between the base jaws and the guide	Clean gripper and re-lubricate, if necessary.
<b>The gripping force drops</b>	(a) Accumulations of dirt	(a) Clean gripper (b) Re-lubricate gripper
<b>The gripper opens or closes abruptly</b>	(a) Accumulations of dirt	(a) Clean gripper (b) Re-lubricate gripper

## 11. Replacement of the module



### Hot surface!

The surfaces of the modules could become hot under normal operating conditions. Touching these surfaces may result in burns!

- Let the module cool down before replacing it.

- (1) Stop the relevant machine(s).
- (2) Switch off the power supply completely.
- (3) After the system has become idle, unscrew the countersunk screws on the cover plate on the EMV fitting side.
- (4) Carefully remove the cover plate.
- (5) Remove the wire strands from the terminals.
- (6) Completely remove the cover plate together with the cable.
- (7) Remove the unit from the machine or system.
- (8) Now remove the cover plate on the EMV fitting side on the new unit.
- (9) Take the new unit and mount it in the machine or system.
- (10) Reconnect the wire strands to the terminals.
- (11) Place the old cover plate together with the cable on the new unit.
- (12) Reattach the countersunk screws for the old cover plate.
- (13) Package the old unit together with the new cover plate (with a fault log, if appropriate).
- (14) Store the unit in a dry place.

## 12. Completely removing a unit from the machine



### Hot surface!

The surfaces of the modules could become hot under normal operating conditions.

- Touching these surfaces may result in burns! Let the module cool down before replacing it.

- (1) Stop the relevant machine(s).
- (2) Switch off the power supply completely.
- (3) After the system has become idle, unscrew the countersunk screws on the cover plate on the EMV fitting side.
- (4) Carefully remove the cover plate.
- (5) Remove the wire strands from the terminals.
- (6) Completely remove the cover plate together with the cable.
- (7) Remove the unit from the machine or system.
- (8) Package the unit (with a fault log, if appropriate).
- (9) Store the unit in a dry place.

## 13. Maintenance and care

The maintenance and lubrication intervals must be adapted to the ambient conditions and operating conditions. The following factors must be taken into account:

- Extreme operating temperatures
- Effects of condensation and humidity
- High vibrational stress
- Use in a vacuum
- Highly dynamic operation
- Constant, small stroke movements
- Effects of foreign substances (e.g. vapors, acids, etc.)

To keep the gripper functioning correctly, please observe the following instructions:

- Unless otherwise specified, tighten all screws and nuts to the DIN tightening torque and secure with Loctite No. 243.
- Do not expose the gripper to drilling emulsions.
- The gripper may be operated only at an ambient temperature between +5°C (+40 °F) and +55°C (+130 °F).
- When laying the cable, the bending radius must be observed. Torsional movements are not permissible.
- Since the system is a servo system, the motor can temporarily create forces far above the nominal values. These forces can overload the gripper and destroy it mechanically. Operate the gripper only within the range of the nominal data. Any overload reduces the service life of the system.
- Repeat accuracy of the gripping force is:  $\pm 15\%$   
The breakaway force can vary greatly from gripper to gripper!  
If an automatic gripper change is to be enabled, the breakaway force has to be determined in the higher-level controller for each initialization!
- For programming instructions, please refer to the manual for your controller.

### 13.1. Cleaning

#### 13.1.1. Gripper

The gripper corresponds to the protection class IP 40.

Clean the gripper when dry at regular intervals in order to remove all impurities and chips. These materials generally accumulate in the hollow spaces, on the linear guides of the gripper base jaws or on the edges of the gripper housing.

#### 13.1.1. Controller

The MCS-06 controller complies with protection class IP 30.

Clean the controller without water as needed to remove all contamination.

### 13.2. Lubrication

The profiled rail guides dry out faster during sustained travel with short strokes than during brief periods of travel with long strokes.

You should therefore travel a complete gripper stroke at least every 1000 cycles in order to avoid dry-running on the profiled rail guides.

After each day of production (or at least once a day), check that there is sufficient lubrication on the profiled rail guides for the gripper base jaws.

The quantity of lubricant and the lubrication intervals depend on the stroke lengths and stroke cycles.




Figure 17: Grease areas

Type EVG 55	
/23/	Profiled rail
/24/	Gripper base jaw
/24/	Profile carriage

Table 18: Grease areas

### 14. Disassembly of the module

The module may disassembled and repaired only by SCHUNK, otherwise the warranty expires!

## 15. Contact



### GERMANY – HEAD OFFICE

SCHUNK GmbH & Co. KG  
Spann - und Greiftechnik  
Bahnhofstrasse 106 – 134  
D – Lauffen / Neckar  
Tel. +49-7133-103-0  
Fax +49-7133-103-2399  
info@de.schunk.com  
www.schunk.com




### AUSTRIA

SCHUNK Intec GmbH  
Holzbauernstr. 20  
4050 Traun  
Tel. +43-7229-65770-0  
Fax +43-7229-65770-14  
info@at.schunk.com  
www.at.schunk.com



### BELGIUM, LUXEMBOURG

SCHUNK Intec N.V./S.A.  
Bedrijvencentrum Regio Aalst  
Industrielaan 4, Zuid III  
9320 Aalst-Erembodegem  
Tel. +32-53-853504  
Fax +32-53-836022  
info@be.schunk.com  
www.be.schunk.com



### GREAT BRITAIN, IRELAND

SCHUNK Intec Ltd.  
Cromwell Business Centre  
10 Howard Way,  
Interchange Park  
Newport Pagnell MK16 9QS  
Tel. +44-1908-611127  
Fax +44-1908-615525  
info@gb.schunk.com  
www.gb.schunk.com



### CHINA

SCHUNK Precision Machinery  
(Hangzhou) Co.,Ltd.  
6, 24th Street, HEDA  
Hangzhou 310018  
Tel. +86-571-8672-1000  
Fax +86-571-8672-8800  
info@cn.schunk.com  
www.cn.schunk.com



### DENMARK

SCHUNK Intec A/S  
Storhaven 7  
7100 Vejle  
Tel. +45-43601339  
Fax +45-43601492  
info@dk.schunk.com  
www.dk.schunk.com



### FRANCE

SCHUNK Intec SARL  
Parc d'Activités des Trois  
Noyers 15, Avenue James de  
Rothschild  
Ferrières-en-Brie  
77614 Marne-la-Vallée  
Cedex 3  
Tel. +33-1-64 66 38 24  
Fax +33-1-64 66 38 23  
info@fr.schunk.com  
www.fr.schunk.com



### NETHERLANDS

SCHUNK Intec B.V.  
Speldenmakerstraat 3d  
5232 BH 's-Hertogenbosch  
Tel. +31-73-6441779  
Fax +31-73-6448025  
info@nl.schunk.com  
www.nl.schunk.com

SCHUNK GmbH & Co.KG  
Shanghai  
Representative Office  
777 Zhao Jia Bang Road  
Pine City Hotel, Room 923  
Xuhui District  
Shanghai 200032  
Tel. +86-21-64433177  
Fax +86-21-64431922  
info@cn.schunk.com  
www.cn.schunk.com



### INDIA

SCHUNK India Branch Office  
# 80 B, Yeswanthpur  
Industrial Suburbs,  
Bangalore 560 022  
Tel. +91-80-41277361  
Fax +91-80-41277363  
info@in.schunk.com  
www.in.schunk.com



### ITALY

SCHUNK Intec S.r.l.  
Via Caio Plinio 5  
22072 Cermenate (CO)  
Tel. +39-031-770185  
Fax +39-031-771388  
info@it.schunk.com  
www.it.schunk.com



### HUNGARY

SCHUNK Intec Kft.  
Széchenyi út. 70.  
3530 Miskolc  
Tel. +36-46-50900-7  
Fax +36-46-50900-6  
info@hu.schunk.com  
www.hu.schunk.com



**POLAND**

SCHUNK Intec Sp.z o.o.  
Stara Iwiczna,  
ul. Stoneczna 116 A  
05-500 Piaseczno  
Tel. +48-22-7262500  
Fax +48-22-7262525  
info@pl.schunk.com  
www.pl.schunk.com



**PORTUGAL**

Sales Representative  
Victor Marques  
Tel. +34-937-556 020  
Fax +34-937-908 692  
Mobil +351-963-786 445  
info@pt.schunk.com  
www.pt.schunk.com



**SOUTH KOREA**

SCHUNK Intec Korea Ltd.  
# 907 Joongang  
Induspia 2 Bldg.,  
144-5 Sangdaewon-dong  
Jungwon-gu, Seongnam-si  
Kyunggi-do, 462-722  
Tel. +82-31-7376141  
Fax +82-31-7376142  
info@kr.schunk.com  
www.kr.schunk.com



**SPAIN**

SCHUNK Intec S.L.  
Foneria, 27  
08304 Mataró (Barcelona)  
Tel. +34-937 556 020  
Fax +34-937 908 692  
info@es.schunk.com  
www.es.schunk.com



**SWEDEN**

SCHUNK Intec AB  
Morabergsvägen 28  
152 42 Södertälje  
Tel. +46-8 554 421 00  
Fax +46-8 554 421 01  
info@se.schunk.com  
www.se.schunk.com



**SWITZERLAND,  
LIECHTENSTEIN**

SCHUNK Intec AG  
Soodring 19  
8134 Adliswil 2  
Tel. +41-44-7102171  
Fax +41-44-7102279  
info@ch.schunk.com  
www.ch.schunk.com



**CZECH REPUBLIC**

SCHUNK Intec s.r.o.  
Ernsta Macha 1  
643 00 Brno  
Tel. +420-545 229 095  
Fax +420-545 220 508  
info@cz.schunk.com  
www.cz.schunk.com



**MEXICO, VENEZUELA**

SCHUNK Intec S.A. de C.V.  
Av. Luis Vega y Monroy # 332  
Fracc. Plazas de Sol  
Santiago de Querétaro,  
Qro. 76099  
Tel. +52-442-223-6525  
Fax +52-442-223-7665  
info@mx.schunk.com  
www.mx.schunk.com



**USA**

SCHUNK Intec Inc.  
211 Kitty Hawk Drive  
Morrisville, NC 27560  
Tel. +1-919-572-2705  
Fax +1-919-572-2818  
info@us.schunk.com  
www.us.schunk.com



**CANADA**

SCHUNK Intec Corp.  
190 Britannia Road East,  
Units 23-24  
Mississauga, ON L4Z 1W6  
Tel. +1-905-712-2200  
Fax +1-905-712-2210  
info@ca.schunk.com  
www.ca.schunk.com



**SLOVAKIA**

SCHUNK Intec s.r.o.  
Mostná 62  
919 01 Nitra  
Tel. +421-37-3260610  
Fax +421-37-6421906  
info@sk.schunk.com  
www.sk.schunk.com



**TURKEY**

SCHUNK Intec  
Bağlama Sistemleri ve  
Otomasyon San. ve Tic. Ltd.  
Şti.  
Küçükyalı İş Merkezi  
Girne Mahallesi  
Irmak Sodak, A Blok, No: 9  
34852 Maltepe, İstanbul  
Tel. +90-216-366-2111  
Fax +90-216-366-2277  
info@tr.schunk.com  
www.tr.schunk.com