



---

# INSTALLATION, WIRING & CONFIGURATION

REVISION 1

FORM # WW07-709

LVS\_250  
(Wireless Baseboard Controller)




BUILDING INTELLIGENCE WORLDWIDE

## Overview

The LVS\_250 is a wireless controller designed to switch baseboard heaters within a mesh network, and is the Walker Wireless replacement for a baseboard thermostat. Different algorithms can be programmed into the LVS\_250 for a variety of different applications.

The LVS\_250 features a setpoint knob in Celsius, built in motion detection, a room temperature sensing thermistor with Walker Temperature Predicting Software and the ability to control and switch 240VAC.


## Features



1. Motion indication LED – When the LVS\_250 has detected motion the LED turns on.
2. Motion detector – Make sure the motion detector is never obstructed or covered.
3. Setpoint Knob – Adjust the Setpoint Knob to the desired room temperature. The minimum and maximum allowed temperature can be adjusted in the LVS\_250.
4. Radio Programming Header – This header is to program the onboard radio and should never be used for programming in the field.
5. Connection Header – This connection header connects the front of the LVS\_250 to the back of the LVS\_250.
6. Processor Programming Header – If a different algorithm is to be used or the settings are being changed via Easy-TOOL, use this header to reprogram the processor.
7. Communication Port – Used to view and change all settings locally in the LVS\_250.
8. Connection Wires – Used to connect to the 240VAC and Baseboard heater.

## Motion Detector

The built in motion detector allows the LVS\_250 to turn down the Setpoint when no bodies are detected in the zone. The motion detector has a range of 10 meters at a viewing angle of 150 degrees.



Below are the objects pertaining to the motion detector:

### **TM\_MOTN**

Is the amount of time in minutes to wait after no motion is detected before changing the Setpoint to unoccupied.

### **ST\_NO\_M**

The heating Setpoint to control to when the TM\_MOTN time has expired and the LVS\_250 goes into unoccupied mode.

When motion is detected, the LVS\_250 will revert back to the knob Setpoint for control. When no motion is detected for the specified time the LVS\_250 will go into unoccupied mode.


Make sure not to block or limit the vision of the motion detector. If the motion detector can not see motion it will always control to the no motion setpoint (ST\_NO\_M).

## Power Requirements

The LVS\_250 powers and switches 240VAC and draws a maximum of 200mA to operate when fully loaded.

## Hardware Configuration

The LVS\_250 is made to directly replace a mechanical thermostat controlling a baseboard heater. The LVS\_250 is to be wired in as shown below.




The 2 line wires from the back of the LVS\_250 connect to the 240VAC supply lines from the breaker box. The Load lines are connected to the baseboard heater(s).

The LVS\_250 is capable of switching 240VAC at a maximum 10A of current.

## Software Configuration

### Easy-TOOL


To connect the Atmel AVRISP mkII programming dongle to the LVS\_250, connect the ribbon cable header from the AVRISP mkII to the LVS\_250s processor programming header as shown in the picture below. If connected correctly the LED on the AVRISP mkII will turn green. Please see the Easy-TOOL user guide on how to program through the Atmel AVRISP mkII.



## Communication Port

The communication port on the base of the LVS\_250 allows all settings to be changed locally via a terminal program on a computer.

To connect the LVS\_250 to a computer for local changes a Cable-ROOMSTAT and DB9F6 (Both from Walker Technologies Corp.) are required. Connect the 3-pin end of the Cable-ROOMSTAT to the communication port on the base of the LVS\_250 with the painted white strip facing the corner of the LVS\_250. Connect the RJ12 end of the Cable-ROOMSTAT to the DB9F6 and then connect the DB9F6 to an available comm. port on the computer or an USB to Serial adapter.



The appropriate settings must be set in the terminal program used for proper communication to the LVS\_250. The settings are:

- Bits per Second: **9600**
- Data bits: **8**
- Parity: **None**
- Stop Bits: **1**
- Flow Control: **None**

## Terminal Screen

The terminal screen can be broken down into 4 sections:

```

102 PROCUAR      25.6 A L      U0      1s SCHEDUL      ON A      em1 C0      0
103 ROOMTMP     25.6 A L      U0      2s SET_MIN      5.0 A      em1 C0      0
104 MOTION_     100 A L      U0      3s SET_MAX      22.0 A      em1 C2      0
105 PK_CNTR      5 A L      U0      4s PROBAND      5.0 A      em1 C0      0
106 T_DELAY      0 A      U0      5s CTRESET      1.0 A      em1 C0      0
107 IOB_CNT      0 A      U0      6s CTLBIAS      -48.0 A L      em1 C0      0
108 INPUT_2     -62.6 A L      C4      7s ST_NO_M      15.0 A      em1 U6      0
109 DUTY_HR      0 A      U0      8s SETN_C1      15.0 A      em1 C3      0
110 DTHR/DY      0 A      U1      9s USED_ST      20.7 A L      em1 U3      0
111 RESETS_      1 A      U2      10 OUTP_C1      .0 A L      U7      0
112 REVERSN      318 A      U0      11 HEATING      .0 A      em1 C0      0
113 STPOINT     20.7 A L      U4      12s DO1_UAL      OFF A      em1 C1      0
114 MY_SAC_      6 A      U0      13s OFFSET_      -6.5 A      em1 U9      0
115 ADDRESS      12 A      U0      14 LOGENBL      OFF A      em1 C0      0
116 TIMESAC      7 A      U0      15s SLOP_GN      75 A      em1 C0      0
117 CHANNEL      15 A      U0      16s RR_PLUS      25 A      em1 C0      0
118 RF_URSN     2263 A      U0      17s RRMINUS      300 A      em1 C0      0
119 MYPANID     447 A      U0      18s T_MAXON      30 A      em1 U8      0
120 SET_PAN     447 A      U0      19s T_MINON      2 A      em1 C0      0
121 ST_ATSC     3FFF A      U0      20s T_MNOFF      5 A      em1 C0      0
122 MY_PIN_     AMQU A      U0      21s TM_MOTN      30 A      em1 U5      0
123 MY_NAME     ADR8 A      U0      22s 2OFFSET      .0 A      em1 C0      0
124 DEST_HI     13A200 A      U0      23 DEG_C/F      DegC A      em1 C0      0
125 DEST_LW     40342101 A      U0      24 USD_SNS      TMP1 A      em1 C0      0
27s SENSTMP    .0 A      em1 C5      0      25 MYSENSR      4 A      em1 C0      0
28s ST_SENS     .0 A      em1 C6      0      26s SET_IP2      25.0 A      em1 C0      0
29s SS_BATT     .0 A      em1 C7      0
30s SS_TMOT     .0 A      em1 C8      0
31s SS_CNTR     .0 A      em1 C9      0

STATE OFF      MODE DAY_
Me 00 00 00 00 00 00 00 00
DN 00 13 A2 00 40 34 21 01
Ch 15
OP 447
OI DDC9
Ur 2263
NA 464E
BH 0
AI 0

RM TEMP 25.6
00:03:35
0
U318 BE SHOF0 0 484 2
IPsens 4226 4226 10230 1 1023 4
256.7 256.7 -626.9 2 1023 5
SS .0 .0 0 3 0 6
ST 20.7 5.0 22.0 4 423 7
I1 25.6 PU 25.6 5 870 14
HT 500 500 0 -480 1 2 6 0 15
Rst 1 IOB 8
Mo 100 T_Mo 27 Last_Mo 3
RunS0 RunM0
Tmr 3 27 0 7
s0 dt0 ap0
DO1 OFF
PIN FFFF 41 4D 51 56
7FFF 80D8
    
```

1. Detailed Object data – Lists all information about each object in the LVS\_250
2. Control Overview – Displays a summary of all the control points for the LVS\_250
3. Radio Overview – Displays a summary of the radio settings
4. Selected Object – Displays the current selected object for changing

Refer to Appendix A for detailed information on each object type.

## Object Breakdown

Each object is listed with an abundance of information.

**10s USED\_HT 25.0 A L em1 U2 0**

10	Object number.
s	If there is a lower case "s" the object can be commanded in GCL, if it is mapped to a point.
USED_HT	The name of the object.
25.0	The current value of the object.
A	Displays if the object is in control by software (Auto "A") or has been set by a user (Manual "M").
L	If an "L" is displayed the objects value was written by the firmware in the LVS_250. If an "S" is displayed the objects value was written by GCL.
emlt	If an "e" is displayed SUPEREABLE is on and allows GCL to command the object. If an "m" is displayed SUPERMANUAL is on and the object can be commanded in manual mode. If an "l" is displayed SUPERLOCAL is on and GCL is able to command objects displaying "L". If a "t" is displayed TIMEDMANUAL is on and the point will revert to auto after the time set in EC_T_SUPER expires when command to manual (Physical Outputs only).
V2	The point the object will be mapped to in the Walker System. Displayed by a single letter (point type) followed by the point number (0-9). V – VA point C – VC point F – VF point I – IP point O – OP point
0	Count down timer. If the object was command by GCL or a Physical Output was command to manual, this displays the time left in minutes until the command is overwritten by the pervious value. Time is set in EC_T_SUPER.

## Navigating Through the Terminal Screen

The keyboard and arrow keys are used to navigate through the terminal screen and change objects.

◀ (Left Arrow)	Used to select the current displayed object.
▶ (Right Arrow)	Used to set the current setting to the selected object.
▲▼ (Up/Down Arrows)	Scroll through objects and change values on selected objects.
↵ (Enter/Return)	Cancel the change to an object or return to the object from its status menu.
"Q"	Writes settings to the radio.
"W"	Reads the settings from the radio.
"N"	Causes the radio to dump its Channel and Operational PAN ID and search for the network again.
Other Letters	Pressing a letter other than the 3 listed above will cycle through objects starting with that letter.



To change an object from Auto "A" to Manual "M" follow the steps below:

- Select the object so it is displayed in the Selected Object area of the terminal window.
- Press the Left arrow key to select the object.
- Press the Left arrow key again to display "STATUS" in place of the object name.
- Press the Left arrow for a third time to select the "STATUS"
- Press the Up/Down arrow keys until "Man" (Manual) is displayed
- Press the Right arrow key to enter set the command.
- Press Enter/Return to go back to the selected object.

To change the value of the selected object:

- Select the object so it is displayed in the Selected Object area of the terminal window.
- Make sure the point is in manual. Not all objects need to be in manual to command. See Appendix A for which objects need to be in manual.
- Press the Left arrow key to select the object.
- Use the Up/Down arrow keys until the desired value is reached. Or some objects let you enter the value by typing it in on the keyboard.
- Press the Right arrow key to enter set the value.

## ZigBee Mesh Network Settings

These objects are the settings required for communication over the Wireless ZigBee mesh network. Refer to the Walker Wireless Setup Document (WW01-709) for further information on setting up the ZigBee mesh network.

DEST_HI	The top 32bits of the MAC address. Set to the destination device (usually Zcoord)																																										
DEST_LW	The bottom 32 bits of the MAC address. Set to the destination device (usually Zcoord)																																										
SET_PAN	The PAN ID of he network to join.																																										
MY__PAN	The read PAN ID from the radio.																																										
SAC_ADR	The MicroSAC address the data is to be sent to.																																										
ADDRESS	The wireless address of the device.																																										
TIMESAC	Set to the MicroSAC address that is sending out the time.																																										
ST_ATSC	<p>Set the channels to scan. Each bit of the 2 bytes represents a channel to scan. The radio will only scan channels selected. If the desired network is on a channel not scanned the radio will not join.</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Channel</th> <th>Bit</th> <th>Channel</th> <th>Bit</th> <th>Channel</th> <th>Bit</th> </tr> </thead> <tbody> <tr> <td>B</td> <td>0</td> <td>11</td> <td>6</td> <td>17</td> <td>12</td> </tr> <tr> <td>C</td> <td>1</td> <td>12</td> <td>7</td> <td>18</td> <td>13</td> </tr> <tr> <td>D</td> <td>2</td> <td>13</td> <td>8</td> <td>19</td> <td>14</td> </tr> <tr> <td>E</td> <td>3</td> <td>14</td> <td>9</td> <td>1A</td> <td>15</td> </tr> <tr> <td>F</td> <td>4</td> <td>15</td> <td>10</td> <td></td> <td></td> </tr> <tr> <td>10</td> <td>5</td> <td>16</td> <td>11</td> <td></td> <td></td> </tr> </tbody> </table> <p style="text-align: center;">I.e. to scan all channels set to FFFF. To on scan 1A set to 8000.</p>	Channel	Bit	Channel	Bit	Channel	Bit	B	0	11	6	17	12	C	1	12	7	18	13	D	2	13	8	19	14	E	3	14	9	1A	15	F	4	15	10			10	5	16	11		
Channel	Bit	Channel	Bit	Channel	Bit																																						
B	0	11	6	17	12																																						
C	1	12	7	18	13																																						
D	2	13	8	19	14																																						
E	3	14	9	1A	15																																						
F	4	15	10																																								
10	5	16	11																																								